

PEPS SYSTEM

GENERAL INFORMATION	31-3	PEPS Circuit Diagram	31-41
General Information	31-3	PEPS Control Module Assembly	
Description	31-3	Terminal List	31-44
Specifications	31-4	Diagnostic Trouble Code (DTC) Chart	31-45
Tools	31-4	B1300	31-46
Function Description	31-5	B1301	31-47
PEPS Function Description	31-5	B1302	31-48
Smart Entry Function	31-5	B1303	31-49
Remote Entry Function	31-8	B1304	31-50
Mechanical Key Entry Function	31-9	B1305	31-52
One-button Start Function	31-10	B1306	31-53
One-button Stop Function	31-11	B1500	31-54
Emergency Stop Function	31-12	B1501	31-54
Back Up Start Function	31-12	B1516	31-54
Emergency Start Function	31-12	B1517	31-54
Starting Times Limit Function	31-12	B1502	31-61
Prompt Function	31-13	B1503	31-61
Engine and Vehicle Anti-theft Function	31-14	B1504	31-61
Diagnostic Tester Menu Function and Data Stream	31-15	B1505	31-61
PEPS System	31-15	B1506	31-66
IMMO System	31-23	B1508	31-70
Anti-theft Match	31-31	B150A	31-75
Smart Key Replacement After Vehicle Sold	31-31	B1510	31-75
PEPS Module Replacement After Vehicle Sold	31-32	B1518	31-81
EMS Replacement After Vehicle Sold	31-32	B1519	31-81
Smart Bracelet Key	31-33	U0100	31-88
Product Description	31-33	U0129	31-88
APP Download and Binding	31-34	U0140	31-88
Usage	31-34	U0329	31-88
Bracelet Main Function	31-35		
Low Battery Mode	31-35		
Charging	31-35		
Precautions	31-35		
Waterproof Description	31-36		
Matching Procedure	31-36		
DIAGNOSIS & TESTING	31-37	ON-VEHICLE SERVICE	31-89
Diagnosis & Testing	31-37	PEPS Control Module Assembly	31-89
Problem Symptoms Table	31-37	Removal	31-89
Diagnosis Procedure	31-38	Installation	31-89
Problem Repair (No DTC)	31-39	Front Low Frequency Antenna (for DCT Models)	31-90
DTC Confirmation Procedure	31-40	Removal	31-90
Intermittent DTC Troubleshooting	31-40	Installation	31-90
		Center Low Frequency Antenna	31-91
		Removal	31-91
		Installation	31-91
		Remove the rear low frequency antenna	31-92
		Removal	31-92
		Installation	31-92
		Rear Bumper Low Frequency	

Removal	31-93
Installation	31-93
Anti-theft Coil (for DCT Models)	31-94

Removal	31-94
Installation	31-94

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران





GENERAL INFORMATION

General Information

Description

E4T15B+DCT



PE0001001

31-PEPS SYSTEM


1 - ENGINE START STOP Switch	2 - PEPS Module
3 - Front Right Door Handle Sensor	4 - Immobilizer Coil
5 - Front Internal Low Frequency Antenna	6 - Center Internal Low Frequency Antenna
7 - Rear Low Frequency Antenna	8 - Front Left Door Handle Sensor
9 - Back Door Release Switch	10 - Rear Low Frequency Antenna (on Rear Bumper Crossmember)

PEPS system consists of PEPS controller, ENGINE START STOP switch, built-in low frequency antenna (3 antennas are equipped in vehicle to detect key position), immobilizer coil for back up starting, front left door handle sensor, luggage compartment door microswitch and remote controller (also called smart key).


Specifications**31****Torque Specifications**

Description	Torque (N·m)
Hexagon Flange Nut	7 ± 1

Tools**General Tool**

Digital Multimeter	 002
--------------------	--

Special Tool

X-431PAD Diagnostic Tester	 001
----------------------------	---


Function Description

PEPS Function Description

Function	
1 - Smart Entry Function	2 - Keyless Entry Function
3 - Mechanical Entry Function	4 - One-button Start Function
5 - One-button Stop Function	6 - Emergency Stop Function
7 - Back Up Start Function	8 - Emergency Start Function
9 - Starting Number Limit Function	10 - Prompt Function
11 - Engine Immobilizer Function	

31

Smart Entry Function




Smart Door Unlock (Keyless Fortifying Deactivation)

1. When bringing a smart key close to vehicle and pressing door handle switch with doors locked, vehicle will be unlocked.

Hint:

Only front left door is equipped with switches.

2. No matter where the smart key is (put in pocket, hang in the belt or put in bag), as long as the key is within approximately 1.2 m of door handle sensor, if pressing door handle sensor, vehicle will enter fortifying deactivation mode (turn signal lights will flash twice and four doors will be unlocked).
3. If any of following operations is not performed within 30 seconds after pressing door handle sensor (fortifying deactivation) under fortifying mode, all doors will be locked automatically.
 - (a) Open any door.
 - (b) Press the ENGINE START STOP switch.
 - (c) ENGINE START STOP switch is in ACC or ON position.



Smart Door Lock (Keyless Fortifying)


1. When exiting vehicle with smart key and pressing door handle switch with doors unlocked, vehicle will be locked.

Hint:

If any door is not closed properly, it will be unlocked automatically after locking to avoid leaving key inside vehicle.

- (a) When 4 doors, engine hood and engine compartment are completely closed, and ENGINE START STOP switch is in OFF position.
 - (b) Press door handle sensor when the smart key is outside the vehicle and within a 1.2 m semicircle area around the front left door handle.
 - (c) Vehicle enters fortifying mode (turn signal lights will flash once, horn sounds once and all doors will be locked).
2. Operation range
 - (a) Only distance between smart key and door handle sensor (1) is within specified operation range, smart key function can be used.
 - (b) When smart key battery is discharged or there is strong radio wave in operation position, smart key system also will do not operate normally.
 - (c) It is recommended that do not place smart key together with mobile phone and other radio equipment.
 - (d) Operation range is within 120 cm of each door handle sensor (1).
 - (e) If smart key is too close to door glass, handle or rear bumper, door handle sensor may not be used.
 - (f) When smart key is within operation range, any one even without carrying smart key can press door handle sensor on corresponding side to lock/unlock door.

3. When using smart key system, door handle sensor will invalid in following conditions.
 - (a) When ENGINE START STOP switch is in following positions (ACC or ON position).
 - (b) Smart key is left in cab or luggage compartment (at this time, alarm will sound, turn signal lights will flash and "Smart Key inside Vehicle" will be prompted on instrument cluster if pressing door handle sensor.)
 - (c) When smart key is not within exterior operation range.
 - (d) When any door is opened or not closed properly.
 - (e) When the smart key battery is discharged.



31

PE0005001



Smart Keyless Luggage Compartment Open

1. If all doors are unlocked, the luggage compartment external electronic switch is activated. At this time, press the switch to open luggage compartment without necessity of carrying smart key.
2. If door is under central lock state, luggage compartment external electronic switch will be disabled. At this time, it is necessary to bring smart key close to rear of vehicle and press electronic switch to open luggage compartment.
3. Precautions for smart entry function
 - (a) For safety, when remote control/central control or mechanical control is used to lock vehicle, if there is a smart key inside vehicle, system will disable door handle switch while remote control still can be used.
 - (b) In order to successfully perform door handle switch operation, do not rapidly operate door handle switch in succession within 0.5 second. and also do not rapidly operate luggage compartment external electronic switch.
 - (c) Smart keyless unlock and lock are only valid when power supply is shut off and four doors are closed properly, or system will not operate.
 - (d) Smart keyless unlock and lock are only valid when power supply is shut off and four doors are closed properly, or system will not operate.
 - (e) For power saving purpose, after vehicle is parked for 15 days, smart entry for front right door handle will be invalid, only smart entry for front left door handle can be used (it will return to normal if performing remote control unlock once or front left door HSU (door handle sensor)

31-PEPS SYSTEM

- (f) In some particular situations, such as smart key is too close to door, system may determine the key is inside vehicle, causing door handle sensor to be disabled. In this case, keyless entry function will not operate normally. At this time, it is necessary to use remote control to lock and unlock vehicle.

Remote Entry Function



1 - LED Indicator	2 - Lock Button
3 - Unlock Button	4 - Luggage Compartment Door Release Button
5 - Mechanical Key	6 - Mechanical Key Release Slider

Remote Lock (Fortifying) Function

1. Press lock button on smart key with power supply OFF, door will be locked, turn signal lights will flash (once), horn will sound (once) and vehicle will enter fortifying mode.
 - (a) Press lock button with four doors, hood and luggage compartment door closed properly, door will be locked, body anti-theft system will be turned on and vehicle will enter fortifying mode.
 - (b) If any door is not closed properly, lock system will not operate.
 - (c) If power supply is in ACC or ON position, remote lock function will not operate to avoid misoperation.
 - (d) If doors are closed properly while hood or luggage compartment door is not closed properly, lock system will lock doors, but body anti-theft system cannot be turned on and vehicle will not enter fortifying mode.

Remote Lock (Fortifying Deactivation) Function

1. Press the remote control unlock button, 4 door locks are unlocked, and turn signal light flashes twice, the vehicle enters the fortifying deactivation state.

Hint:

If any of following operations is not performed within 30 seconds after pressing remote unlock button (fortifying deactivation) under fortifying mode, all doors will be locked automatically.

- (a) Open any door.
- (b) Press the ENGINE START STOP switch.
- (c) ENGINE START STOP switch is in ACC or ON position.

Hint:

- Description

Press unlock button, so that door will be unlocked and luggage compartment door external switch will be activated (at this time, press luggage compartment external switch to open luggage compartment even if user does not bring valid key).


Under fortifying or anti-theft alarm mode, press unlock button to cancel body anti-theft alarm system.

Remote Luggage Compartment Function

1. Long press remote luggage compartment button (about 1.5 seconds), luggage compartment door will be unlocked, at this time, it is still necessary to press back door release switch to open back door.

Hint:

Open luggage compartment remotely cannot cancel vehicle fortifying.

Mechanical Key Entry Function

1. When key battery is weak or remote control function cannot operate normally caused by radio interference, it is possible to use mechanical key to lock and unlock vehicle.


31-PEPS SYSTEM

- Slide mechanical key release slider on back side of key and pull out mechanical key, then insert the key into front left door key cylinder and turn it clockwise or counterclockwise to lock or unlock vehicle.


Hint:

When vehicle fortifying is successful, mechanical key can be used to unlock, but it is illegal entry, and alarm will sound and turn signal lights will flash at that time.

One-button Start Function




1. Indicator does not come on
 - (a) Power supply is OFF and brake pedal (for DCT models) is not depressed, or engine has been started.



2. Amber
 - (a) Power supply state: ACC or ON, brake pedal (for DCT models) is not depressed.
3. Green
 - (a) Brake pedal (for DCT models) is depressed, and engine will start once the button is pressed.

4. One-button start function: It is activated at any power supply state (OFF, ACC, IGN) with legal smart key inside vehicle. Depress brake pedal (for DCT models), press ENGINE START STOP switch to start engine.


(a) Switching power supply state.



31

5. There are four positions for vehicle power supply: OFF, ACC, ON, ST (ignition). With brake pedal (for DCT models) not depressed, press ENGINE START STOP switch:

(a) Switching power supply state.



6. Precautions for one-button start function

- For DCT models, if it is not in P or N position, system will not perform starting operation.
- During start, if brake pedal (for DCT models) is released halfway, system will suspend starting.
- Press ENGINE START STOP switch and then release it when starting, system will judge if starting is successful and stop starting properly.
- For AT models, if it is not in P position, vehicle power supply state (ACC, IGN) will not return to OFF state.

One-button Stop Function

1. For common engine stop mode, 4 km/h of vehicle speed must be met.

Hint:

- For DCT models, if it not in P position, vehicle power supply state will not return to OFF, you must shift to P position before leaving vehicle after stopping. And check if power supply state is in OFF. Make sure that vehicle power supply is in OFF state and then leave vehicle. Otherwise, door cannot be locked.
- Simple method for distinguishing power supply in ACC or OFF:
 - Judged by color of indicator on ignition switch.
 - Under ACC state, instrument cluster will illuminate center display edge of LCD.
 - Operate buttons on remote controller, if lock operation is failed and unlock operation is successful, it indicates that vehicle power supply is not in OFF position.

31-PEPS SYSTEM

Emergency Stop Function

1. In order to stop engine in emergency, this system has emergency stop mode.

Hint:

- When vehicle speed is more than 4 km/h, press ENGINE START STOP switch for more than 3 seconds in succession.
- If pressing ENGINE START STOP switch for 3 times within 2 seconds with vehicle speed more than 4 km/h, engine will stop and power supply will return to ACC.

Caution:

- If this condition is not met, engine will not shut down and ignition switch is kept in ON.
- During driving, emergency stop will seriously affect normal driving. Do not use this function unless in emergency.

31

Back Up Start Function


1. If key can not be recognized by system due to weak battery or interference, PEPS system will not operate normally. At this time, system provides a method to back up start engine, following method can be used to start engine or turn on power supply.
 - (a) Lay key on bottom of rear cup holder with face up, and do not depress brake pedal (for DCT models).
 - (b) Press the ENGINE START STOP switch once. Power supply state will switch to ON, and "Verification is Successful, it is Possible to Start" is displayed on instrument cluster.
 - (c) Depress brake pedal (for DCT models) fully, press ENGINE START STOP switch to start engine.

Emergency Start Function

1. This system is provided with emergency start mode, to prevent failure in signal detecting brake pedal position (for DCT models), which may cause engine not to be started.

Caution:

- Please contact service station for inspection and repair as soon as possible.

**Starting Times Limit Function**

1. When serious damage occurs in system, in order to ensure driving safety and prevent steering system locking incorrectly, system will not allow user to start engine limitlessly and engine only can be started for 10 time. And each time engine starts successfully and travel, rest times will reduce one. Please contact Chery service station for repair as soon as possible.

Caution:

Only MT models have this function.

Hint:

- This system malfunction may be caused by any or several of the following reasons:
 - (a) Speed signal malfunction of front right wheel
 - (b) Speed signal malfunction of other three wheels
2. Precautions for starting times limit function
 - (a) Keyless entry and PEPS system obtains wheel speed signal from brake controller (ABS/ESP), if any wheel speed signal is malfunctioning, ABS/ESP system warning light in instrument cluster will come on.

- (b) If malfunction does not be repaired and maximum start times is reached, it is not allowed to start vehicle. Please contact Chery service station for repair immediately and reset "rest start times" with diagnostic tester. Otherwise, if same malfunction occurs next time, start times offered by system will be less than 10 times. (Specific value depends on residual times last time malfunction occurs.)

Prompt Function

To reduce misunderstanding of PEPS features from users and to facilitate the daily diagnosis of simple problems, system will prompt corresponding message to users through instrument cluster display, buzzer and external horn. Regardless of power supply state (OFF, ACC or ON), once PEPS sends information, instrument cluster will handle and display it.

Text Message Prompt	Buzzer	External Horn	Possible Cause
Smart key is not detected	Sound	\	There is no key in vehicle
Smart key is not detected	Sound	\	If you are in vehicle, find smart key and place it in vehicle, or check if passenger brings the key outside
System malfunction, it is allowed to start X times	Sound	\	Please contact Chery Repair Shop for repair immediately.
Please check and repair PEPS system	Sound	\	Please Contact Chery Service Station for Repair Immediately
Please shift to P or N to start	Sound	\	If you want to start engine, shift to P or N
Please depress clutch pedal to start/depress brake pedal to start	Sound	\	If you want to start engine, depress brake pedal (for DCT models) or clutch pedal (for MT models)
Please turn steering wheel to unlock steering column	Sound	\	Turn power supply on while shaking steering wheel to help steering column unlock successfully
Please press ENGINE START STOP switch to turn power supply on again	Sound	\	Turn power supply on while shaking steering wheel to help steering column unlock successfully
Please shift to P	Sound	\	Please shift to P and press ENGINE START STOP switch to turn off power supply.
Please pay attention that smart key is in vehicle	Sound	Sound 6 times	Be sure to carry smart key on person when leaving vehicle. Caution: Door handle switch will be disabled by system temporarily, please use remote controller to lock and unlock
Verification is successful and it is possible to start	Sound	\	It is displayed only when performing back up start and verification passed, and key battery is fully discharged usually
Please turn off power supply	Sound	\	User may leave vehicle with shift position not in P and power supply not in OFF
Smart key battery is low	Sound	\	Key battery still can be used, but it comes to failure due to low voltage, it is necessary to replace battery

31-PEPS SYSTEM

Engine and Vehicle Anti-theft Function

1. Anti-theft for models with PEPS can be divided into two types.
2. For DCT models, anti-theft can be divided into two separate parts - "PEPS and ECU encryption engine immobilizer".
3. For MT models, anti-theft can be divided into two separate parts - "PEPS and ECU encryption engine immobilizer" and "PEPS and ESCL encryption steering column lock anti-theft".
4. For DCT models
 - (a) After power supply is turned to ON, ECM will send one frame of validation data to PEPS via CAN bus to verify. Then PEPS will feedback one frame of validation data as response and send to ECM. If response from PEPS is correct, ECM will determine anti-theft can be canceled. Otherwise, ECM will not inject fuel and ignite.
5. For MT models
 - (a) After power supply is turned to ACC, PEPS will perform encrypted anti-theft validation with ESCL via special LIN line. If validation passes, ESCL will unlock, or ESCL keeps locking and steering wheel cannot be turned. And power supply cannot be turned to ON.
 - (b) After power supply is turned to ON, ECM will send one frame of validation data to PEPS via CAN bus to verify. Then PEPS will feedback one frame of validation data as response and send to ECM. If response from PEPS is correct, ECM will determine anti-theft can be canceled. Otherwise, ECM will not inject fuel and ignite.

31

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Diagnostic Tester Menu Function and Data Stream

PEPS System

Show Menu	
CHERY (CUSTOMIZED) V58.80 > Diagnostic program	
T19	T18
M1D/M1AFL2	T15/T17
A13T	M1A
M16PHEV	A11
A15/A15FL	B11FL/B11
S11	T11/T11FL
A21FL/A21	S21FL/S21
Chery (Customized)	
PE0070002	

1. Click "T19" to enter "Show Menu".

Show Menu	
CHERY (CUSTOMIZED) V58.80 > T19 > System Selection	
EMS (Engine Management System)	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)
ICM (Instrument Cluster Module)	BCM (Body Control Module)
RADAR (Radar Module)	EIPM (Electric Integrated Panel Module)
SRS (Supplemental Restraint System)	IHU (Infotainment Head Unit)
EPS (Electronic Power Steering)	PEPS (Passive Entry And Passive Start System)
CVT (Continuously Variable Transmission)	DCT (Dual Clutch Transmission)
SAM (Steering Angle Module)	IMMO (Immobilizer)
Chery (Customized) T19	
PE0071002	

31-PEPS SYSTEM

- Click "PEPS (Passive Entry And Passive Start System)" to enter PEPS system.

Show Menu

CHERY (CUSTOMIZED) V58.80 > T19 > System Selection > PEPS (Passive Entry And Passive Start System)

Version Information	Read Fault Code
Clear Fault Memory	Read Data Stream
Special function	

Chery (Customized) T19

PE0072002

- Display the PEPS system diagnostic list.

Show Menu

CHERY (CUSTOMIZED) V58.80 > T19 > System Selection > PEPS (Passive Entry And Passive Start System)

Version Information	Version information
Clear Fault Memory	
Special function	

Chery (Customized) T19

PE0073002

Vehicle Manufacturer Spare Part Number: 804000022AA
System Supplier Identifier: 9JF
Vehicle Manufacturer ECU Hardware Number: 2A4
System Supplier ECU Software Number: 18.3
ECU Manufacturing Date: 20180807
ECU Serial Number: 29
ESCL supplier Serial number: Not supported
ESCL SW version: Not supported
ESCL manufacturing Date: Not supported

OK

(a) Click "Version Information".

Show Menu

CHERY (CUSTOMIZED) V58.80 > T19 > System Selection > PEPS (Passive Entry And Passive Start System)

Read Current Fault Code	Read History Fault Code
-------------------------	-------------------------

Chery (Customized) T19

PE0074002

(b) Click "Read Fault Code" to display "Read Current Fault Code" and "Read History Fault Code".

(1) Read Current Fault Code: Read stored fault code of current malfunction.

(2) Read History Fault Code: Fault codes of previous malfunction have not been cleared, and these codes can be read using diagnostic tester.

Show Menu

CHERY (CUSTOMIZED) V58.80 > T19 > System Selection > PEPS (Passive Entry And Passive Start System)

PEPS Configuration Status:	Software Configuration Code
LF antenna Current	Smart Key Number
Power Management and Starter Status	Vehicle lock Status
Engine Switch Backlight Status:	ESCL Bolt Status
ESCL status	ESCL Learning Status
ESCL Engine Start Inhibition Status:	ESCL Thermal Protection Counter
ESCL Low Voltage Inhibition Counter	ESCL Failure Status1

Chery (Customized) T19

PE0075002

31-PEPS SYSTEM

31

Show Menu	
CHERY (CUSTOMIZED) V58.80 > T19 > System Selection > PEPS (Passive Entry And Passive Start System)	
LF antenna Current	Smart Key Number
Power Management and Starter Status	Vehicle lock Status
Engine Switch Backlight Status:	ESCL Bolt Status
ESCL status	ESCL Learning Status
ESCL Engine Start Inhibition Status:	ESCL Thermal Protection Counter
ESCL Low Voltage Inhibition Counter	ESCL Failure Status1
ESCL Failure Status2	
Chery (Customized) T19	
PE0076002	

(c) Click "Read Data Stream".

Data Stream			
CHERY (CUSTOMIZED) V58.80 > T19 > System Selection > PEPS (Passive Entry And Passive Start System)			
Name	Value	Unit	
PS/PEPS	PS/PEPS		
ESCL	No ESCL		
Transmission Type	AT		
(1 / 1)			
Chery (Customized) T19		Graph	Report
		Record	Help
		PE0077002	

(1) Vehicle configuration status of PEPS system

- Vehicle configuration information (PEPS, MT model with electronic steering column lock, AT or MT model)

Data Stream			
CHERY (CUSTOMIZED) V58.80 > T19 > System Selection > PEPS (Passive Entry And Passive Start System)			
Name	Value	Unit	
Software Configuration Code1	07		
Software Configuration Code2	52F821		
(1 / 1)			
Chery (Customized) T19			
Graph Report Record Help PE0078002			

31

(2) Software configuration code

- Software Configuration Code 1: Number of interior low frequency antennas (such as "07" refers to 3, "03" refers to 2).
- Software Configuration Code 2: After-sales personnel do not need to write configuration, for reference only.

Data Stream			
CHERY (CUSTOMIZED) V58.80 > T19 > System Selection > PEPS (Passive Entry And Passive Start System)			
Name	Value	Unit	
FR HSU	117	mA	
FL HSU	117	mA	
Bumper LF Antenna	126	mA	
Front LF Antenna	123	mA	
Middle LF Antenna	113	mA	
Rear LF Antenna	101	mA	
(1 / 1)			
Chery (Customized) T19			
Graph Report Record Help PE0079002			

31-PEPS SYSTEM

(3) Low frequency antenna current

- After-sales personnel do not need to pay attention to this menu.

Data Stream			
CHERY (CUSTOMIZED) V58.80 > T19 > System Selection > PEPS (Passive Entry And Passive Start System)			
Name	Value	Unit	
Smart Key Number	1		
(1 / 1)			
Chery (Customized) T19		Graph	Report
		Record	Help
		PE0080002	

(4) Smart key number

- Smart key number learned by PEPS module.

Data Stream			
CHERY (CUSTOMIZED) V58.80 > T19 > System Selection > PEPS (Passive Entry And Passive Start System)			
Name	Value	Unit	
ACC status	Inactive		
IG1 status	Inactive		
IG2 status	Inactive		
Starter relay status	Inactive		
(1 / 1)			
Chery (Customized) T19		Graph	Report
		Record	Help
		PE0081002	

(5) Power management and start status

- Activated status of vehicle power.

Data Stream			
CHERY (CUSTOMIZED) V58.80 > T19 > System Selection > PEPS (Passive Entry And Passive Start System)			
Name	Value	Unit	
Vehicle lock Status	Unlock		
(1 / 1)			
Chery (Customized) T19		Graph	Report
		Record	Help
		PE0082002	

(6) Vehicle lock status

- Vehicle lock and unlock status.

Data Stream			
CHERY (CUSTOMIZED) V58.80 > T19 > System Selection > PEPS (Passive Entry And Passive Start System)			
Name	Value	Unit	
Engine Switch Backlight Status	Inactive		
Engine switch IND A status	Active		
Engine switch IND G status	Inactive		
(1 / 1)			
Chery (Customized) T19		Graph	Report
		Record	Help
		PE0083002	

31-PEPS SYSTEM

(7) Engine switch backlight status

- Switching status of indicator light when pressing the ENGINE START STOP switch.

Show Menu	
CHERY (CUSTOMIZED) V58.80 > T19 > System Selection > PEPS (Passive Entry And Passive Start System)	
Write software configuration information (2 bits)	Write software configuration information (6 bits)
Write LF antenna Current	Release PSE inhibition state
ESCL Exit anti-scanning	
Chery (Customized) T19	
PE0095002	

(d) Special operation

(1) Write software configuration information (2 bits)

- After-sales does not need to input

(2) Write software configuration information (6 bits)

- After-sales does not need to input

(3) Write LF antenna current

Caution:

- After-sales are not allowed to set current

(4) Release PSE inhibition state

- When the system fails, the system will reserve 10 start times after the PSE inhibition is triggered. Once the number of times is exhausted, the function needs to be executed to resume the start times.

(5) ESCL exit anti-scanning

- When the ESCL enters anti-scan state, this function can be used to exit anti-scan state.

IMMO System

Show Menu	
CHERY (CUSTOMIZED) V58.80 > Diagnostic program	
T19	T18
M1D/M1AFL2	T15/T17
A13T	M1A
M16PHEV	A11
A15/A15FL	B11FL/B11
S11	T11/T11FL
A21FL/A21	S21FL/S21
Chery (Customized)	
PE0070002	

1. Click "T19" to enter "Show Menu".

Show Menu	
CHERY (CUSTOMIZED) V58.80 > T19 > System Selection	
EMS (Engine Management System)	ABS/ESP (Anti-lock Braking System/Electronic Stability Program)
ICM (Instrument Cluster Module)	BCM (Body Control Module)
RADAR (Radar Module)	EIPM (Electric Integrated Panel Module)
SRS (Supplemental Restraint System)	IHU (Infotainment Head Unit)
EPS (Electronic Power Steering)	PEPS (Passive Entry And Passive Start System)
CVT (Continuously Variable Transmission)	DCT (Dual Clutch Transmission)
SAM (Steering Angle Module)	IMMO (Immobilizer)
Chery (Customized) T19	
PE0096002	

31-PEPS SYSTEM

- Click "IMMO (Immobilizer)" to enter IMMO system.

Show Menu

CHERY (CUSTOMIZED) V58.80 > T19 > System Selection > IMMO (Immobilizer)

Version Information	Read fault code
Erase fault code	Read data stream
write data	After sale function

Chery (Customized) T19

PE0097002

- Displays IMMO system diagnostic list.

Show Menu

CHERY (CUSTOMIZED) V58.80 > T19 > System Selection > IMMO (Immobilizer)

Immobilizer status	Transponder Statusd
ECM status	TCU status
ESCL status	

Chery (Customized) T19

PE0099002

(a) Read data stream

Data Stream			
CHERY (CUSTOMIZED) V58.80 > T19 > System Selection > IMMO (Immobilizer)			
Name	Value	Unit	
Ignition	off		
Immobilizer condition	Immobilizer not in delivery condition		
Immobilizer security code	programmed		
Last time IMMO and Key authentication	failed		
Last time IMMO authentication ECM	succeeded		
Last time IMMO authentication TCU	(1 / 1) succeeded		
Chery (Customized) T19			
		Graph	Report
		Record	Help
PE0101002			

Data Stream			
CHERY (CUSTOMIZED) V58.80 > T19 > System Selection > IMMO (Immobilizer)			
Name	Value	Unit	
Last time IMMO authentication ECM	succeeded		
Last time IMMO authentication TCU	succeeded		
number of key was learnt	1		
The number of unsuccessful security access	0		
VIN	programmed		
Wait loop And Security code	(1 / 1) Wait loop is inactive, the Security code can be en		
Chery (Customized) T19			
		Graph	Report
		Record	Help
PE0102002			

- Immobilizer status
 - ENGINE START STOP switch status
 - IMMO status (whether it has been matched)
 - Vehicle identification number, anti-theft security code (whether it has been programmed)
 - Number of key learning
 - Whether IMMO and key, ECU certification is successful (TCU certification applies to CVT models)

31-PEPS SYSTEM

- When the authorization code (PIN code) is incorrectly entered multiple times, the security access will be delayed and the authorization code cannot be entered. Wait for the specified time before you can enter again.
- The number of times security access has failed

Data Stream			
CHERY (CUSTOMIZED) V58.80 > T19 > System Selection > IMMO (Immobilizer)			
Name	Value	Unit	
Last received transponder Id at a transponder position	programmed		
Last received transponder Id at a transponder position 1	not programmed		
Last received transponder Id at a transponder position 2	programmed		
Last received transponder Id at a transponder position 3	not programmed		
Last received transponder Id at a transponder position 4	not programmed		
Last received transponder Id at a transponder position 5	not programmed		
(1 / 2)			
Chery (Customized) T19			
Graph		Report	Record
		Help	PE0103002

Data Stream			
CHERY (CUSTOMIZED) V58.80 > T19 > System Selection > IMMO (Immobilizer)			
Name	Value	Unit	
Last received transponder Id at a transponder position 4	not programmed		
Last received transponder Id at a transponder position 5	not programmed		
Legal Transponder	Legal Transponder detected		
Ring antenna	succeeded		
SK	correct		
Transponder	Transponder detected		
(1 / 2)			
Chery (Customized) T19			
Graph		Report	Record
		Help	PE0104002

Data Stream			
CHERY (CUSTOMIZED) V58.80 > T19 > System Selection > IMMO (Immobilizer)			
Name	Value	Unit	
Transponder condition	Transponder not in delivery condition		
Transponder Id	At least one transponder Id is programmed		
Transponder ID	Transponder ID in the Immobilizer		
Transponder Id at transponderat transponder position 1	not programmed		
Transponder Id at transponderat transponder position 2	programmed		
Transponder Id at transponderat transponder position 3	(2 / 2) not programmed		
Chery (Customized) T19			
		Graph	Report
		Record	Help
PE0105002			

Data Stream			
CHERY (CUSTOMIZED) V58.80 > T19 > System Selection > IMMO (Immobilizer)			
Name	Value	Unit	
Transponder ID	Transponder ID in the Immobilizer		
Transponder Id at transponderat transponder position 1	not programmed		
Transponder Id at transponderat transponder position 2	programmed		
Transponder Id at transponderat transponder position 3	not programmed		
Transponder Id at transponderat transponder position 4	not programmed		
Transponder Id at transponderat transponder position 5	(2 / 2) not programmed		
Chery (Customized) T19			
		Graph	Report
		Record	Help
PE0105102			

- Key status
 - Antenna: Whether the coil works properly
 - Transponder: Whether the transponder is detected
 - Transponder condition: Whether the transponder is in the factory state, displays "Transponder not in delivery condition" after matching
 - SK: Whether the SK written in the transponder is correct
 - Transponder ID: Whether the Transponder ID information has been written to IMMO
 - Last received transponder Id at a transponder position ID: Whether the last authenticated transponder (current transponder) ID is in the IMMO. "programmed" indicates "in the IMMO".

31-PEPS SYSTEM

- Last received transponder Id at a transponder position 1 - 5: Which location of IMMO is the last authenticated transponder (current transponder) ID stored, that is, which key is the current transponder. If position 1 of the figure shows "programmed", that is, the current transponder is position 1. If the customer loses one of the keys, as long as the customer takes the remaining key, it can be determined which key is lost, erase the ID of lost key transponder, and the lost key (transponder) cannot be used to start the vehicle.
- Transponder ID, Transponder ID at transponder position 1 - 5: These refer to the storage status of keys in BCM or PEPS, indicating that how many keys (transponders) have been matched, and three "not programmed" mean that three transponders can be added. If "Delete key" is executed, the data stream will show "not programmed".

31

Data Stream			
CHERY (CUSTOMIZED) V58.80 > T19 > System Selection > IMMO (Immobilizer)			
Name	Value	Unit	
ECM Secret Key is programmed	YES		
ECM Security code is programmed	YES		
ECM staus	ECM is programmed		
ECM VIN code is programmed	YES		
Ignition staus	ON		
Immo-function is supported	YES		
(1 / 2)			
Chery (Customized) T19			
Graph Report Record Help PE0106002			

Data Stream			
CHERY (CUSTOMIZED) V58.80 > T19 > System Selection > IMMO (Immobilizer)			
Name	Value	Unit	
Ignition staus	ON		
Immo-function is supported	YES		
Last ECM authentication IMMO failed	NO		
Latest level access(27 03) SecurityAccess is successful	NO		
Latest level access(27 05) SecurityAccess is successful	NO		
Numbers of failed level access(27 05) SecurityAccess	0		
(1 / 2)			
Chery (Customized) T19			
Graph Report Record Help PE0107002			

Data Stream			
CHERY (CUSTOMIZED) V58.80 > T19 > System Selection > IMMO (Immobilizer)			
Name	Value	Unit	
Wait loop of level access(27 05) SecurityAccess is active	NO		
(2 / 2)			
Chery (Customized) T19			
Graph Report Record Help			
PE0107102			

31

- ECM status
 - Latest level access(27 05) SecurityAccess is successful: When PIN code is entered, if the result calculated by ECU with its own PIN code is inconsistent with the result calculated by diagnostic tester with PIN code, it is unsuccessful, "NO" will be displayed, indicating that the entered PIN code is inconsistent with the PIN code of ECU.
 - Latest level access(27 03) SecurityAccess is successful: When writing VIN or PIN to ECU, the diagnostic tester and ECU will perform an algorithm calculation. If it is not successful, it will prompt "NO".
 - Is ESCL programmed.

(b) Write data

- The "Write data" menu can also be used in the following two conditions (preconditions is that no new SK is learned in IMMO)
 - Misoperation (IMMO and ECM are reset at the same time);
 - The extreme situation of missing PIN code and VIN code caused by other unknown circumstances

31-PEPS SYSTEM

Show Menu	
CHERY (CUSTOMIZED) V58.80 > T19 > System Selection > IMMO (Immobilizer)	
Match all the systems.	Programming ECM
Programming IMMO(learn SK from EMS)	Programming IMMO(learn SK from TCU)
Reprogramming ECM	Reprogramming IMMO
Key match	Erase keys.
Write PIN	Programming TCU
Reset TCU	Programming ESCL
Erase ESCL	
Chery (Customized) T19	
PE0109002	

(c) Immobilizer match

(1) "Programming IMMO(learn SK from TCU), Programming TCU, Reset TCU" are applied to DCT models.

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Anti-theft Match

Smart Key Replacement After Vehicle Sold

1. Description

- (a) There are two match methods between smart key and system: "Replace with new key" and "Add old key".
- (1) "Add new key" refers to match blank key (never match with any system) with system. It usually happens when user would have additional new key on the basis of the old ones.
- (2) "Add old key" refers to rematch learned key with system (it is must be previous system).

Caution:

- If user lost a smart key with one key left, when replacing with a new smart key, perform as follows to replace with a new one: Learn the new key by "Add new key" service, delete all smart keys by "Delete all keys" service, then learn the remain two smart keys in order by "Add old key" service. If user finds the lost key, it can be reactivated by "Add old key" service on diagnostic tester. If not, even if the lost one is found, it cannot be used normally.

2. Match Operation

- (a) Anti-theft match description for "Add new key" is as follows:

- (1) Technician reads VIN in EMS of user's vehicle with diagnostic tester, then obtain PIN through VIN.
- (2) Place the smart key to be matched on the key mark in cup holder, enter anti-theft control system program on diagnostic tester, select "Add new key" menu, input PIN, diagnostic tester will perform "Add new key" program automatically.
- (3) After that, press unlock button and check if left and right turn signal light indicators on instrument cluster blink. If the indicators blink, new key is matched successfully, otherwise, new key is not matched successfully.

- (b) Anti-theft match description for "Add old key" is as follows:

- (1) Technician reads VIN in EMS of user's vehicle with diagnostic tester, then obtain PIN through VIN.
- (2) Enter anti-theft control system program on diagnostic tester, select "Delete all keys" menu.
- (3) Place the smart key to be matched on the key mark in cup holder, enter anti-theft control system program on diagnostic tester, select "Add old key" menu, input PIN, diagnostic tester will perform "Add old key" program automatically.
- (4) After that, press unlock button and check if left and right turn signal light indicators on instrument cluster blink. If the indicators blink, new key is matched successfully, otherwise, new key is not matched successfully.

Caution:

- When performing "Add old key", it is necessary to carry previous matched smart key and perform match operation one by one according to match procedures, or previous matched key will be disabled.
- Regardless of "Add new key" or "Add old key", only one smart key can be kept in vehicle and keep key on key mark in cup holder. Make sure that there is no other key in vehicle. If there is other key, bring it to a position 2 m away from vehicle.

31-PEPS SYSTEM

PEPS Module Replacement After Vehicle Sold

1. Technician reads VIN in EMS with diagnostic tester, then obtains PIN through VIN.
2. If vehicle is equipped with ESCL, make sure that ESCL is unlocked. After new PEPS is assembled successfully, press ignition switch (IG) to turn on power supply.
3. Enter anti-theft control system program on diagnostic tester, select "Program IMMO" menu; input PIN according to prompt on diagnostic tester, after "Program IMMO" is performed successfully, it will display "Program IMMO is successful".
4. Then match previous keys one by one according to instructions of "Add old key".
5. If vehicle is equipped with ESCL, enter anti-theft control system program on diagnostic tester and complete "Add old key", then keep power supply in OFF position, check state of ESCL with diagnostic tester, if ESCL is not in Anti-scanning state, replacement is completed, if ESCL is in Anti-scanning state, select "Delete ESCL", input PIN according to prompt on diagnostic tester, ESCL will be deleted successfully after about 10 minutes, then match ESCL according to description for ESCL replacement.

Caution:


- Please contact Chery service station to obtain PIN.
- Unmatched smart keyless entry and PEPS can switch power supply from IGN OFF to IGN ON for 50 times. Once it exceeds 50 times, PEPS cannot be used. So, do not turn on and off power supply at will with PEPS unmatched.
- If ESCL accidentally enters "Anti-scanning" protection mode, it is necessary to perform "Erase ESCL".

EMS Replacement After Vehicle Sold


1. Technician reads VIN in old EMS or smart keyless entry and PEPS unit with diagnostic tester, then obtains PIN through VIN.
2. After new EMS is assembled successfully, press ignition switch (IG) to turn on power supply.
3. Enter anti-theft control system program on diagnostic tester, select "Program EMS" menu; input VIN and PIN according to prompts on diagnostic tester. After "Program EMS" is performed successfully, it will display "Match EMS is successful".
4. Depress brake pedal (for DCT models)/clutch pedal (for MT models), press ignition switch once to check if vehicle can be started successful. If vehicle can be started successful, EMS replacement is completed, if vehicle cannot be started successful, EMS replacement is not completed.

Smart Bracelet Key

Product Description



1. Smart Bracelet Key



2. Smart Bracelet Key Charging Base

31-PEPS SYSTEM

APP Download and Binding

1. APP Download
 - (a) Scan the QR code on right side to download the phone APP "MVM Wearing".



2. Bracelet and Phone Binding
 - (a) Open APP "MVM Wearing", register/login account to switch to (device) list and select MyMVM to match and bind with bracelet.

Hint:

Make sure that Bluetooth of phone is in ON status. During connection process, hold the bracelet close to the phone. A MVM smart bracelet key can only be connected to a phone.


3. APP Settings
 - (a) To ensure the stable connection between bracelet and phone Bluetooth and the stable reception of message from phone to bracelet, please open the notification permission of APP "MVM Wearing" message.
 - (b) Detail setting methods: Enter APP "Personal" list, select "Use help" menu and select "Phone setting methods" to find the setting method available for your phone, then set your phone according to the setting procedures.

Usage


1. After bracelet is bound successfully, you can check time, sport data records, step numbers, calorie consumption, sleep monitoring, heart rate monitoring and message notification, etc.



Short Press Screen



Long Press Screen



Slide Up/Down Screen

PE0109402

- MVM smart bracelet key supports multiple operating ways: Turn the wrist to light screen, slide screen up and down to switch the classification section, short touch the screen to switch and check, long touch the screen to perform select operation, or operate the bottom button.
- In addition, you can quickly learn how to use the other functions of bracelet using the "MVM smart bracelet key" in APP "MVM Wearing".

Bracelet Main Function

Function	Description	Function	Description
Smart Key	Keyless entry vehicle	Sports and Health	Automatic step recording
	One-button start engine		Movement mileage recording
	Remote lock vehicle		calorie consumption recording
	Wireless unlock vehicle		Sleep monitoring
	Wireless opening luggage compartment		Heart rate monitoring (static, dynamic)
	Wireless opening window		Sedentary reminding
Message Reminding	Incoming call display reminding/ignoring/rejecting	Others	Movement target setting/target realized reminding
	Message display reminding (short message/WeChat, etc.)		Date and time display
	Vibration clock		Turning wrist to light screen
	Schedule reminding		Do not disturb mode
	Low battery reminding		Phone locating
Low Battery Mode	When bracelet power is lower than 10%, the general functions of bracelet will be turned off with PEPS function being kept, please charge the battery as soon as possible.		3ATM waterproof
Physical button	If the bracelet is crashed, long press the physical button for 7 seconds to restart the device.		OTA upgrade

Low Battery Mode

- Low battery reminding occurs when battery power is lower than 20%, and "Please charge the bracelet " is displayed on the screen. When battery power of bracelet drops to 10%, it will enter low battery mode, in this case, only the PEPS function is reserved for the bracelet.

Caution:

- After entering low battery mode, please charge the bracelet battery in time, to prevent the battery from being depleting, causing vehicle unable to unlock.

Charging

- Insert the charging base into power supply to charge (charging voltage is $5\text{ V} \pm 0.25\text{ V}$, current is 500 mA or less). Align the charging PIN on bracelet with the charging thimble on charging base to charge.

Caution:

- When low bracelet battery is prompted, please charge in time.

Precautions

- During daily use, avoid wearing the bracelet too tight, keep the contact areas of bracelet dry, and clean the band regularly with clean water. If allergy symptom occurs on contact area, remove the bracelet in time and then consult a doctor.
- When using heart rate measuring function of bracelet, please keep the wrist stationary during measurement.
- After exercise, if your wrist sweats, clean and dry your wrist and bracelet and wear them again.
- Keep the heart rate monitoring viewpoint and charging interface clean as much as possible.

31-PEPS SYSTEM

- Never expose the bracelet at excessively high or low temperature for a long time.

Waterproof Description

MVM smart bracelet key has 3ATM waterproof level. In everyday situations such as swimming, surfing, diving, snorkeling, etc., you can wear it with confidence.

- In the following conditions, the waterproof performance of bracelet may be affected, avoid these conditions during use:
 - Wear the device in a place with high temperature, high humidity and high pressure, such as taking a sauna, taking a bath in hot spring or professional diving.
 - When using the bracelet on beach, avoid the screen contacting with sand directly, clean the main body of product with fresh water in time to prevent the screen from being scratched.
 - The touch screen of bracelet does not support water operation. When the bracelet becomes wet, please wiper it with a soft cloth before operating.
 - Avoid dropping of the bracelet or other impacts.

Matching Procedure

The smart bracelet key does not match with vehicle at the factory. Match the bracelet with vehicle before delivering the vehicle to user. Matching procedure has the similar method with adding new smart key. The operating method is as follows:

- Obtain the Vehicle Identification Number (VIN), so as to use it to obtain the corresponding Personal Identification Number (PIN).
- Take out the smart bracelet key (regardless of the ON/OFF status of bracelet), and place the bracelet into the cup holder with key mark or onto the storage box.
 - For DCT models



- On diagnostic tester, enter "IMMO (Immobilizer)" - Key match - Add new key - input PIN, and diagnostic tester will perform "Add new key" program automatically.
- After a successful matching, long press the button on back side of smart bracelet key for 3 s to turn on the smart bracelet (if the bracelet cannot be turned on due to low battery, please charge it before use).
- Enter the smart bracelet "Vehicle key" menu, select "unlock" function, and short press the "unlock icon" once to establish RF connection between smart bracelet key and PEPS controller, at this time, the smart bracelet key is matched successfully.
- To ensure the intact function of smart bracelet key, please check the "Vehicle key" remote control function, keyless entry function and one-button start function of smart bracelet.
- For vehicle with remote start configuration, you can set the "start engine function" of bracelet to ON using the APP "MVM wearing" in phone. After the function is turned on, you can start engine using bracelet within a remote control range of 20 m.
- Generally, the fully charged smart bracelet key can be used for about 2 weeks. When battery power drops to 10% or less, the bracelet will enter low battery mode. In this mode, the screen and conventional functions of bracelet will be turned off with the remote control (short pressing the button on back side can unlock vehicle) and PEPS function being kept. The low battery mode can be used

DIAGNOSIS & TESTING

Diagnosis & Testing

Problem Symptoms Table

Hint:

Use symptoms table below to help determine cause of problem. Check each suspected area in sequence. Repair, replace or adjust faulty components as necessary.

Symptom	Suspected Area
Remote controller fails	Remote controller battery is weak
	There is remote control signal interference
	Remote controller enters failure mode (it is necessary to exit)
	Code is lost (add old key)
	PEPS malfunction
	Wireless key malfunction
	BCM malfunction
Vehicle cannot enter fortifying mode	Four doors, hood or luggage compartment door is abnormal
	Power supply is not in OFF state
	Door lock malfunction
	PEPS malfunction
	BCM malfunction
Vehicle cannot be unlocked	Door lock malfunction
	PEPS malfunction
	BCM malfunction
Microswitch cannot enter fortifying mode and be unlocked	Smart key is not within range
	Open or sticking in microswitch
	Power supply is not in OFF state
	Four doors, hood or luggage compartment door is abnormal
	Smart key in vehicle
	Smart key battery is low
Luggage compartment cannot be opened	Luggage compartment door switch fails (open, water leakage or sticking)
	Luggage Compartment door lock malfunction
	PEPS malfunction
	Short or open in wire harness
	BCM malfunction
Vehicle cannot be started (PEPS) (starter runs)	Anti-theft verification does not pass
Vehicle cannot be started (PEPS) (starter does not run)	Gear position is not in P/N (for DCT models)
	Clutch (for MT models)/brake switch (for DCT models) is abnormal
	ENGINE START STOP switch malfunction
	Circuit or starter relay is abnormal
	Starter malfunction
	Start times limit is activated
ESCL cannot be locked or unlocked	Vehicle is parked on slope (lock pin is stuck)
	Door signal is abnormal
	ENGINE START STOP switch cannot be turned on or off
	Short or open in wire harness
	Anti-theft verification fails
	Network communication malfunction

31-PEPS SYSTEM

Diagnosis Procedure

Hint

Use following procedures to troubleshoot the PEPS system.

1 Vehicle brought to workshop

Result

Proceed to
NEXT

31

NEXT

2 Check battery voltage

Check if battery voltage is normal.

OK

Standard voltage: Not less than 12 V

Result

Proceed to
OK
NG

NG

Replace battery

OK

3 Customer problem analysis

Result

Proceed to
NEXT

NEXT

4 Read DTCs

Result

Proceed to
No DTC
Current DTC
History DTC

History DTC

5 Problem Repair (No DTC)**Result**

Proceed to
NEXT

NEXT**Go to step 6****6 Troubleshoot according to Diagnostic Trouble Code (DTC) chart****31****Result**

Proceed to
NEXT

NEXT**Go to step 7****7 Troubleshoot according to Problem Symptoms Table****Result**

Proceed to
NEXT

NEXT**8 Conduct test and confirm malfunction has been repaired****Result**

Proceed to
NEXT

NEXT**End****Problem Repair (No DTC)**

If PEPS system has problems, but no DTC is stored in PEPS system, this problem is called a problem without DTC. Problems without DTC for PEPS system are divided into following types:

1. Indicator in instrument cluster does not come on or illuminates constantly (incorrect wire harness connection or indicator is damaged).
2. Troubleshooting recommendation: Check corresponding components according to problem symptom, and troubleshoot following the vehicle repair manual.

31-PEPS SYSTEM

DTC Confirmation Procedure

Confirm that battery voltage is normal before performing following procedures.

- Turn ENGINE START STOP switch to OFF.
- Connect diagnostic tester (the latest software) to diagnostic interface.
- Turn ENGINE START STOP switch to ON.
- Using diagnostic tester, record and clear DTCs stored in PEPS control module assembly.
- Turn ENGINE START STOP switch to OFF and wait several seconds.
- Use diagnostic tester to read DTCs.
- If DTC is detected, malfunction indicated by DTC is current. Go to DTC chart, and perform troubleshooting.
- If no DTC is detected, malfunction indicated by DTC is intermittent Please refer to Intermittent DTC Troubleshooting.

31

Intermittent DTC Troubleshooting

If malfunction is intermittent, perform the followings:


- Check if connector is loose.
- Check if wire harness is worn, pierced, pinched or partially broken.
- Wiggle related wire harness and connector and observe if signal in related circuit is interrupted.
- If possible, try to duplicate conditions under which DTC was set.
- Look for data that has changed or DTC to reset during wiggle test.
- Check for broken, bent, protruded or corroded terminals.
- Check and clean all wire harness connectors and body ground parts related to DTC.
- If multiple trouble codes were set, refer to circuit diagrams to look for any common body ground circuit or power supply circuit applied to DTC.
- Refer to any Technical Bulletin that may apply to this malfunction.

Body Ground Inspection


Body ground points are very important to the proper operation of circuits. Body ground points are often exposed to moisture, dirt and other corrosive environments. Corrosion (rust) may increase load resistance. This situation may change the way in which a circuit works. Circuits are very sensitive to proper body grounding. A loose or corroded body ground can affect the control circuit. Check the body ground points as follows:


1. Remove body ground bolt or nut.
2. Check all contact surfaces for tarnish, dirt and rust, etc.
3. Clean as necessary to ensure that contact is in good condition.
4. Reinstall body ground bolt or nut securely.
5. Check if there are add-on accessories that interfere with body ground circuit.
6. If several wire harnesses are crimped into one body ground terminal, check for proper crimps. Make sure all wire harnesses are clean, securely fastened with providing a good body ground path.

PEPS Circuit Diagram




31





31-PEPS SYSTEM

PEPS Control Module Assembly Terminal List



PE0128001

Terminal No.	Terminal Definition	Terminal No.	Terminal Definition
J101	Battery	J109	Clutch Switch Signal
J102	IG1 Relay Drive (High)	J110	Start Relay Detection
J103	ACC Relay Drive (High)	J111	Ignition Signal
J104	IG2 Relay Drive (High)	J112	-
J105	High Speed CAN Low	J113	Starter Relay (High)
J106	High Speed CAN High	J114	-
J107	Hard Wire Wheel Speed Signal (Front Right Wheel)	J115	-
J108	-	J116	Ground

Terminal No.	Terminal Definition	Terminal No.	Terminal Definition
J201	Spare Antenna Positive End	J209	-
J202	Spare Antenna Negative End	J210	Analog Ground
J203	ENGINE START STOP Switch Indicator Output (Green)	J211	ENGINE START STOP switch 1
J204	ENGINE START STOP Switch Backlight Output (White)	J212	-
J205	ENGINE START STOP Switch Indicator Output (Amber)	J213	ENGINE START STOP Switch 2
J206	Low Frequency Antenna 1 Negative	J214	Low Frequency Antenna 1 Positive
J207	Low Frequency Antenna 2 Negative	J215	Low Frequency Antenna 3 Negative
J208	Low Frequency Antenna 2 Positive	J216	Low Frequency Antenna 3 Negative

Terminal No.	Terminal Definition	Terminal No.	Terminal Definition
J301	Luggage Compartment Unlock Switch	J305	-
J302	Left Door Handle Sensor Negative	J306	Right Door Handle Sensor Negative
J303	Left Door Handle Sensor Positive	J307	Right Door Handle Sensor Negative
J304	Luggage Compartment Low Frequency Antenna Negative	J308	Luggage Compartment Low Frequency Antenna Positive

31-PEPS SYSTEM

Terminal No.	Terminal Definition	Terminal No.	Terminal Definition
J401	Electronic Steering Column Lock Module Control Ground	J406	Electronic Steering Column Lock Power Supply
J402	-	J407	-
J403	Electronic Steering Column Lock Ground	J408	Ground
J404	Electric Steering Column Lock Control Ground	J409	-
J405	-	J410	IG1 Power Supply

Diagnostic Trouble Code (DTC) Chart

DTC	DTC Definition
B1300	Internal Control Module EEPROM Error
B1301	Immobilizer and ECM Authentication Failed
B1302	VIN Not Programmed
B1303	The Antenna Communication is Disturbed
B1304	None Transponder was Detected
B1305	Immobilizer Has None Key was Storage
B1306	Security Code was not Programmed
B1500	Driver Door Outside LF Antenna
B1501	Passenger Door Outside LF Antenna
B1502	Front Internal LF Antenna
B1503	Middle Internal LF Antenna
B1504	Rear Internal LF Antenna
B1505	Bumper LF Antenna
B1506	Abnormality on Switches of Engine Switch
B1508	Abnormality in ACC Circuit
B1509	Abnormality in Brake Signal
B150A	Abnormality in Vehicle Speed Signal
B150C	Clutch Switch Signal Error
B150F	ESCL Anti Scanning
B1510	Abnormality on Wheel Speed Signal
B1515	ROM Checksum Failure
B1516	HSU Overload
B1517	HSU Switch Continuously Pressed
U0073	CAN Bus Off
U0100	Lost of Communication with Engine Control System Module
U0101	Lost of Communication with Transmission Control Unit
U0129	Lost Communication with Brake System Module
U0140	Lost Communication with Body Control Module
U0329	Lost Communication with Electronic Steering Column Lock
U1300	Software Configuration Error
B1518	Trunk/Back Door Unlock Switch Stuck Failure
B1519	Back Door Lock Switch Continuously Pressed

31-PEPS SYSTEM

DTC	B1300	Internal Control Module EEPROM Error
------------	--------------	---

Description

DTC	DTC Definition
B1300	Internal Control Module EEPROM Error

Procedure

31

1 Check for DTCs

- (a) Using diagnostic tester, clear DTC and read IMMO control module assembly DTC.
 (b) Check if DTC occurs again.

Result

Proceed to
OK
NG

OK

System is normal

NG

2 Check if vehicle PEPS control is normal

Result

Proceed to
OK
NG

OK

Turn off vehicle power supply (disconnect the negative battery cable), then clear DTC again

NG

Replace PEPS module

31-PEPS SYSTEM

DTC	B1301	Immobilizer and ECM Authentication Failed
-----	-------	---

Description

DTC	DTC Definition
B1301	Immobilizer and ECM Authentication Failed

Procedure

1 Check for DTCs

- (a) Using diagnostic tester, clear DTC and read IMMO control module assembly DTC.
 (b) Check if DTCs occur again.

Result

Proceed to
OK
NG

OK

System is normal

NG

2 Check if engine can be started normally

Result

Proceed to
OK
NG

OK

Turn off vehicle power supply (disconnect the negative battery cable), then clear DTC again

NG

Perform anti-theft match for PEPS and ECU module again

31-PEPS SYSTEM

DTC	B1302	VIN Not Programmed
-----	-------	--------------------

Description

DTC	DTC Definition
B1302	VIN Not Programmed

Procedure

31

1 Check for DTCs

- (a) Using diagnostic tester, clear DTC and read IMMO control module assembly DTC.
 (b) Check if DTCs occur again.

Result

Proceed to
OK
NG

OK

System is normal

NG

2 Turn off vehicle power supply (disconnect the negative battery cable), then clear DTC

Result

Proceed to
OK
NG

OK

System is normal

NG

Input VIN into PEPS again

DTC	B1303	The Antenna Communication is Disturbed
------------	--------------	---

Description

DTC	DTC Definition
B1303	The Antenna Communication is Disturbed

Procedure

1	Check for DTCs
----------	-----------------------

- (a) Using diagnostic tester, clear DTC and read IMMO control module assembly DTC.
 (b) Check if DTCs occur again.

Result

Proceed to
OK
NG

OK

System is normal

NG

Turn off vehicle power supply (disconnect the negative battery cable), then clear DTC

31

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



31-PEPS SYSTEM

DTC	B1304	None Transponder was Detected
------------	--------------	--------------------------------------

Description

DTC	DTC Definition
B1304	None Transponder was Detected

Procedure

31

1 Check for DTCs

- (a) Using diagnostic tester, clear DTC and read IMMO control module assembly DTC.
 (b) Check if DTCs occur again.

Result

Proceed to
OK
NG

OK

System is normal

NG

2 Check remote controller

- (a) Press remote controller and check if red LED indicator blinks normally

Result

Proceed to
OK
NG

NG

Go to step 4

OK

3 Check if smart key type is correct

- (a) Check if smart key is original key.

Result

Proceed to
OK
NG

NG

Replace with original smart key and perform test

OK

4 Remove smart key and check remote controller

- (a) Check if remote controller battery voltage is less than 3 V.
 (b) Check remote controller chip for water corrosion or burn.

Result

Proceed to
OK
NG

NG

Replace smart key

31

OK

5 Turn off vehicle power supply (disconnect the negative battery cable), then clear DTC

Result

Proceed to
OK
NG

OK

System is normal

NG

Replace smart key



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

31-PEPS SYSTEM

DTC	B1305	Immobilizer Has None Key was Storage
-----	-------	--------------------------------------

Description

DTC	DTC Definition
B1305	Immobilizer Has None Key was Storage

Procedure

31

1 Check for DTCs

- (a) Using diagnostic tester, clear DTC and read IMMO control module assembly DTC.
 (b) Check if DTCs occur again.

Result

Proceed to
OK
NG

NG

Enter anti-theft system and add key

OK

2 Reconfirm DTCs

- (a) Use diagnostic tester to clear DTCs.
 (b) Check if the same DTCs are still output.

Result

Proceed to
OK
NG

OK

System operates normally

NG

Replace PEPS control module assembly

31-PEPS SYSTEM

DTC	B1306	Security Code was not Programmed
------------	--------------	---

Description

DTC	DTC Definition
B1306	Security Code was not Programmed

Procedure**1 Check for DTCs**

- (a) Using diagnostic tester, clear DTC and read IMMO control module assembly DTC.
 (b) Check if DTCs occur again.

Result

Proceed to
OK
NG

NG

Rematch PEPS module

OK

2 Reconfirm DTCs

- (a) Use diagnostic tester to clear DTCs.
 (b) Check if the same DTCs are still output.

Result

Proceed to
OK
NG

OK

System operates normally

NG

Replace PEPS control module assembly

31-PEPS SYSTEM

DTC	B1500	Driver Door Outside LF Antenna
DTC	B1501	Passenger Door Outside LF Antenna
DTC	B1516	HSU Overload
DTC	B1517	HSU Switch Continuously Pressed


دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Circuit Diagram



31-PEPS SYSTEM

Description

DTC	DTC Definition
B1500	Driver Door Outside LF Antenna
B1501	Passenger Door Outside LF Antenna
B1516	HSU Overload
B1517	HSU Switch Continuously Pressed

Caution:

Take driver side low frequency antenna as an example to explain troubleshooting procedures for reference.

When performing electrical equipment diagnosis and test, always refer to circuit diagram for related circuit and component information.

Procedure

1 Check if PEPS module output voltage is normal.


- Turn ENGINE START STOP switch to OFF.
- Disconnect the negative battery cable.
- Disconnect the PEPS module connector J3.
- Check if wire harnesses are worn, pierced, pinched or partially broken.
- Check for broken, bent, protruded or corroded terminals.
- Check if related connector pins are in good condition.
- Connect the negative battery cable, turn ENGINE START STOP Switch to ON, use DC voltage band of digital multimeter to measure if voltage between output terminals J3-03 and J3-02 of PEPS module is normal.

OK

Multimeter Connection	Condition	Specified Condition
J3-03 - J3-02	Always	12 V

Result

Proceed to
OK
NG



NG

Replace PEPS control module assembly

OK

2 Measure resistance of door handle sensor

- Turn ENGINE START STOP switch to OFF.
- Disconnect the negative battery cable.
- Disconnect the front left door sensor connector F-008.
- Check if wire harnesses are worn, pierced, pinched or partially broken.
- Check for broken, bent, protruded or corroded terminals.
- Check if related connector pins are in good condition.
- Using ohm band of digital multimeter, measure if resistance of front left door handle sensor is normal.

OK

Multimeter Connection	Condition	Specified Condition
Front left door handle sensor terminal 1 - 2	Microswitch not pressed	∞
Front left door handle sensor terminal 1 - 2	Microswitch pressed	$\approx 1 \text{ K}\Omega$

Result

Proceed to
OK
NG

NG

Replace left door handle sensor

OK




31

3 Check front left door wire harness for open or short

- Disconnect the front left door wire harness connector F-001.
- Check if wire harnesses are worn, pierced, pinched or partially broken.
- Check for broken, bent, protruded or corroded terminals.
- Check if related connector pins are in good condition.
- Using ohm band of digital multimeter, measure resistance between terminals 1, 2 of connector F-008 and terminals 4, 3 of connector F-001 to check front left door wire harness for open.

OK

Multimeter Connection	Condition	Specified Condition
F-008-1 - F-001-4	Always	$\leq 1 \Omega$
F-008-2 - F-001-3	Always	$\leq 1 \Omega$




31-PEPS SYSTEM

- (f) Using ohm band of digital multimeter, measure resistance between terminals 1, 2 of front left door wire harness connector F-008 and body ground to check front left door wire harness for short to body ground.

OK

Multimeter Connection	Condition	Specified Condition
F-008-1 - Body ground	Always	∞
F-008-2 - Body ground	Always	∞



31


- (g) Connect the negative battery cable, turn ENGINE START STOP switch to ON, (confirm that connectors F-001 and B-024 are disconnected). Using DC voltage band of digital multimeter, measure voltage between terminals 1, 2 of front left door wire harness connector F-008 and body ground to check front left door wire harness for short to power supply.

OK

Multimeter Connection	Condition	Specified Condition
F-008-1 - Body ground	Always	0 V
F-008-2 - Body ground	Always	0 V

Result

Proceed to
OK
NG



NG

Replace front left door wire harness

OK

4


Check interior wire harness for open or short

- (a) Turn ENGINE START STOP switch to OFF.
(b) Disconnect the negative battery cable.

- (c) Using ohm band of digital multimeter, measure resistance between terminals 4, 3 of connector B-024 and terminals 2, 3 of connector J3 to check interior wire harness for open.

OK

Multimeter Connection	Condition	Specified Condition
B-024-4 - J3-02	Always	$\leq 1 \Omega$
B-024-4 - J3-03	Always	$\leq 1 \Omega$




PE0025002

- (d) Using ohm band of digital multimeter, measure resistance between terminals 4, 3 of interior wire harness connector B-024 and body ground to check interior wire harness for short to body ground.

OK

Multimeter Connection	Condition	Specified Condition
B-024-4 - Body ground	Always	∞
B-024-3 - Body ground	Always	∞



PE0027002


- (e) Connect the negative battery cable, turn ENGINE START STOP switch to ON, (confirm that PEPS module and connector J3 are disconnected). Using DC voltage band of digital multimeter, measure voltage between terminals 4, 3 of interior wire harness connector B-024 and body ground to check interior wire harness for short to power supply.

OK

Multimeter Connection	Condition	Specified Condition
B-024-4 - Body ground	Always	0 V
B-024-3 - Body ground	Always	0 V

Result

Proceed to
OK
NG



PE0029002

31-PEPS SYSTEM

OK	Replace PEPS module
NG	Replace interior wire harness

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



31-PEPS SYSTEM

DTC	B1502	Front Internal LF Antenna
DTC	B1503	Middle Internal LF Antenna
DTC	B1504	Rear Internal LF Antenna
DTC	B1505	Bumper LF Antenna

دیجیتال خودرو


شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



31-PEPS SYSTEM

Circuit Diagram



Description

DTC	DTC Definition
B1502	Front Internal LF Antenna
B1503	Middle Internal LF Antenna
B1504	Rear Internal LF Antenna
B1505	Bumper LF Antenna

Hint:

For above DTC troubleshooting, take "B1503 - Middle Internal LF Antenna Circuit Open" as an example.

Caution:

When performing electrical equipment diagnosis and test, always refer to circuit diagram for related circuit and component information.

31

Procedure**1 Check if PEPS module software configuration code is correct.**

- Using diagnostic tester, enter PEPS system.
- Read software configuration code and check if it is "07".

Result

Proceed to
OK
NG

NG

Input configuration code "07" again and clear DTC

OK

2 Measure resistance of low frequency antenna

- Turn ENGINE START STOP switch to OFF.
- Disconnect the negative battery cable.
- Disconnect the interior middle low frequency antenna (2) connector I-034.
- Check if wire harnesses are worn, pierced, pinched or partially broken.
- Check for broken, bent, protruded or corroded terminals.
- Check if related connector pins are in good condition.
- Using ohm band of digital multimeter, measure if resistance of interior middle low frequency antenna (2) is normal.

OK

Multimeter Connection	Condition	Specified Condition
Low frequency antenna (2)	Always	$\approx 10\text{ K}\Omega$

Result

Proceed to
OK
NG



31-PEPS SYSTEM

NG

Replace low frequency antenna


OK

3 Check interior wire harness for open or short

- (a) Turn ENGINE START STOP switch to OFF.
 (b) Disconnect the negative battery cable.
 (c) Disconnect low frequency antenna (2) connector I-034 and PEPS module connector J2.
 (d) Check if wire harnesses are worn, pierced, pinched or partially broken.
 (e) Check for broken, bent, protruded or corroded terminals.
 (f) Check if related connector pins are in good condition.
 (g) Using ohm band of digital multimeter, measure resistance between terminal 1 of connector I-034 and terminal 8 of connector J2, between terminal 2 of connector I-034 and terminal 7 of connector J2 to check instrument panel wire harness for open.

OK

Multimeter Connection	Condition	Specified Condition
I-034-1 - J2-8	Always	$\leq 1 \Omega$
I-034-1 - J2-7	Always	$\leq 1 \Omega$




PE0033002

- (h) Using ohm band of digital multimeter, measure resistance between terminals 1, 2 of connector I-034 and body ground separately to check instrument panel wire harness for short to body ground.

OK

Multimeter Connection	Condition	Specified Condition
I-034-1 - Body ground	Always	∞
I-034-2 - Body ground	Always	∞



PE0034002

- (i) Connect the negative battery cable (confirm that connectors I-034 and J2 are disconnected). Bridge joint ACC relay and IGN1 relay (connector J2 is disconnected, so ENGINE START STOP switch input is open). Using DC voltage band of digital multimeter, measure voltage between terminals 1, 2 of connector I-034 and body ground to check instrument panel wire harness for short to power supply.

OK

Multimeter Connection	Condition	Specified Condition
I-034-1 - Body ground	Always	0 V
I-034-2 - Body ground	Always	0 V

Result


Proceed to
OK
NG

OK

Replace PEPS module

NG

Replace instrument panel wire harness




31



31-PEPS SYSTEM

DTC	B1506	Abnormality on Switches of Engine Switch
-----	-------	--

Circuit Diagram



31-PEPS SYSTEM

Description

DTC	DTC Definition
B1506	Abnormality on Switches of Engine Switch

Caution:

When performing electrical equipment diagnosis and test, always refer to circuit diagram for related circuit and component information.

Procedure

1 Enter PEPS system and read related datastream

- Read datastream "Power Supply Management and Starting State" and "Engine Switch Backlight State".
- Press ENGINE START STOP switch, check datastream conversion activation state and backlight illumination state, to check if ENGINE START STOP switch input is normal.

Result

Proceed to
OK
NG

OK

Turn off vehicle power supply (disconnect the negative battery cable), then clear DTC again


NG

2 Check the ENGINE START STOP switch

- Turn ENGINE START STOP switch to OFF.
- Disconnect the negative battery cable.
- Disconnect the ENGINE START STOP switch connector I-024.
- Using ohm band of digital multimeter, measure resistance of ENGINE START STOP switch to check if ENGINE START STOP switch is normal.

OK

Multimeter Connection	Condition	Specified Condition
ENGINE START STOP switch terminal 2 - 1	Not pressed	∞
ENGINE START STOP switch terminal 2 - 1	Pushed	$\leq 1 \Omega$
ENGINE START STOP switch terminal 2 - 3	Not pressed	∞
ENGINE START STOP switch terminal 2 - 3	Pushed	$\leq 1 \Omega$
ENGINE START STOP switch terminal 1 - 3	Not pressed	∞
ENGINE START STOP switch terminal 1 - 3	Pushed	$\leq 1 \Omega$
ENGINE START STOP switch terminal 4 - 2	Not pressed	$\approx 6.33 \text{ K}\Omega$



PE0037002

31-PEPS SYSTEM

Multimeter Connection	Condition	Specified Condition
ENGINE START STOP switch terminal 5 - 2	Not pressed	$\approx 6.21 \text{ K}\Omega$
ENGINE START STOP switch terminal 8 - 2	Not pressed	$\approx 5.84 \text{ K}\Omega$

Result

Proceed to
OK
NG

31

NG

Replace ENGINE START STOP switch

OK


3

Check instrument panel wire harness for open or short

- Turn ENGINE START STOP switch to OFF.
- Disconnect the negative battery cable.
- Disconnect ENGINE START STOP switch connector I-024 and PEPS module connector J2.
- Check if wire harnesses are worn, pierced, pinched or partially broken.
- Check for broken, bent, protruded or corroded terminals.
- Check if related connector pins are in good condition.
- Using ohm band of digital multimeter, measure resistance between terminal 1 of connector I-024 and terminal 11 of connector J2, between terminal 2 of connector I-024 and terminal 10 of connector J2, between terminal 3 of connector I-024 and terminal 13 of connector J2, between terminal 4 of connector I-024 and terminal 4 of connector J2, between terminal 5 of connector I-024 and terminal 3 of connector J2, between terminal 8 of connector I-024 and terminal 5 of connector J2 to check instrument panel wire harness for open.

OK


Multimeter Connection	Condition	Specified Condition
I-024-1 - J2-11	Always	$\leq 1 \Omega$
I-024-2 - J2-10	Always	$\leq 1 \Omega$
I-024-3 - J2-13	Always	$\leq 1 \Omega$
I-024-4 - J2-04	Always	$\leq 1 \Omega$
I-024-5 - J2-03	Always	$\leq 1 \Omega$
I-024-8 - J2-05	Always	$\leq 1 \Omega$



- (h) Using ohm band of digital multimeter, measure resistance between terminals 1, 2, 3, 4, 5, 8 of connector I-024 and body ground separately to check instrument panel wire harness for short to body ground.

OK

Multimeter Connection	Condition	Specified Condition
I-024-1 - Body ground	Always	∞
I-024-2 - Body ground	Always	∞
I-024-3 - Body ground	Always	∞
I-024-4 - Body ground	Always	∞
I-024-5 - Body ground	Always	∞
I-024-8 - Body ground	Always	∞




31

- (i) Connect the negative battery cable (confirm that connectors I-024 and J2 are disconnected). Bridge joint ACC relay and IGN1 relay (ENGINE START STOP switch is disabled). Using DC voltage band of digital multimeter, measure voltage between terminals 1, 2, 3, 4, 5, 8 of connector I-024 and body ground to check instrument panel wire harness for short to power supply.

OK

Multimeter Connection	Condition	Specified Condition
I-024-1 - Body ground	Always	0 V
I-024-2 - Body ground	Always	0 V
I-024-3 - Body ground	Always	0 V
I-024-4 - Body ground	Always	0 V
I-024-5 - Body ground	Always	0 V
I-024-8 - Body ground	Always	0 V



Result

Proceed to
OK
NG

OK

Replace PEPS module


NG

Replace instrument panel wire harness

31-PEPS SYSTEM

DTC	B1508	Abnormality in ACC Circuit
-----	-------	----------------------------

Circuit Diagram



31-PEPS SYSTEM

Description

DTC	DTC Definition
B1508	Abnormality in ACC Circuit

Caution:

When performing electrical equipment diagnosis and test, always refer to circuit diagram for related circuit and component information.

Procedure

1 Check fuse

31

- (a) Measure fuse SB09-30A in engine compartment fuse and relay box with 21 W test light to check if test light comes on.

Result

Proceed to
OK
NG

OK

Turn off vehicle power supply (disconnect the negative battery cable), then turn on power supply again and clear DTC.

NG

2 Check if fuse base jack is abnormal

- (a) Remove fuse SB09-30A in engine compartment fuse and relay box and check fuse base jack for excessive clearance.

Result

Proceed to
OK
NG

NG

Adjust fuse base jack

OK

3 Adjust ACC relay

Result

Proceed to
OK
NG

OK

Replace ACC relay

NG

31-PEPS SYSTEM

4 Check if relay switch power supply is normal

- (a) Unplug FRY01-ACC relay in engine compartment fuse and relay box.
 (b) Using 21 W test light or digital multimeter, measure if power supply of ACC relay base No.30 jack is normal.

OK

Multimeter Connection	Condition	Specified Condition
ACC relay base 30 - Body ground (digital multimeter)	Always	Not less than 12 V
ACC relay base 30 - Body ground (21 W test light)	Always	ON

Result

Proceed to
OK
NG

NG**Replace front bumper wire harness****OK****5 Short connect the ACC relay base jack control switch**

- (a) Use a wire to bridge joint jacks 30 and 87 of ER01-ACC relay base in engine compartment fuse and relay box, and check engine compartment fuse and relay box for open.

Result

Proceed to
OK
NG

NG**Replace front bumper wire harness****OK****6 Check ACC relay control body ground**

- (a) Using ohm band of digital multimeter, measure resistance between jack 86 of ACC relay base and terminal 4 of engine compartment fuse and relay box to check engine compartment fuse and relay box for open.

OK

Multimeter Connection	Condition	Specified Condition
ACC relay base 86 - Engine compartment fuse and relay box 4	Always	$\leq 1 \Omega$

- (b) Using ohm band of digital multimeter, measure resistance between terminal 4 of engine compartment fuse and relay box and body ground to check if ground circuit is normal.

OK

Multimeter Connection	Condition	Specified Condition
Engine compartment fuse and relay box 4 - Body ground	Always	$\leq 1 \Omega$

Result

Proceed to
OK
NG

NG

Adjust GQ-016 ground position or replace front pumper wire harness.

31

OK

7 Check ACC relay control power supply side

- Disconnect the negative battery cable.
- Disconnect engine compartment fuse and relay box connectors Q-007 and B-018.
- Check if wire harnesses are worn, pierced, pinched or partially broken.
- Check for broken, bent, protruded or corroded terminals.
- Check if related connector pins are in good condition.
- Disconnect engine compartment fuse and relay box connector Q-007 and interior connector B-018, using ohm band of digital multimeter, measure resistance between jack 85 of ACC relay base and terminal 26 of engine compartment fuse and relay box connector Q-007.

OK

Multimeter Connection	Condition	Specified Condition
ACC relay base 85 - Q-007-26	Always	$\leq 1 \Omega$


- Disconnect the PEPS module connector J1.
- Check if wire harnesses are worn, pierced, pinched or partially broken.
- Check for broken, bent, protruded or corroded terminals.
- Check if related connector pins are in good condition.
- Using ohm band of digital multimeter, measure resistance between terminal 26 of connector B-018 and terminal 3 of connector J1.

OK

Multimeter Connection	Condition	Specified Condition
B-018-26 - J1-03	Always	$\leq 1 \Omega$

Result

Proceed to
OK
NG



PE0046102

31-PEPS SYSTEM

OK	Replace PEPS module
NG	Replace front bumper wire harness or interior wire harness

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



DTC	B150A	Abnormality in Vehicle Speed Signal
DTC	B1510	Abnormality on Wheel Speed Signal

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



31-PEPS SYSTEM

Circuit Diagram

31



31-PEPS SYSTEM

Description

DTC	DTC Definition
B150A	Abnormality in Vehicle Speed Signal
B1510	Abnormality on Wheel Speed Signal

Caution:

For above DTCs, refer to brake control system troubleshooting. If brake control system is normal, perform following diagnosis procedures.


Procedure

1 Check interior wire harness for open or short

- Turn ENGINE START STOP switch to OFF.
- Disconnect the negative battery cable.
- Disconnect the PEPS module connector J1 and connectors B-018 and Q-007.
- Check if wire harnesses are worn, pierced, pinched or partially broken.
- Check for broken, bent, protruded or corroded terminals.
- Check if related connector pins are in good condition.
- Using ohm band of digital multimeter, measure resistance between terminal 7 of connector J1 and terminals 20 of connector B-018 to check interior wire harness for open.

OK

Multimeter Connection	Condition	Specified Condition
J1-07 - B-018-20	Always	$\leq 1 \Omega$




PE0051002

31-PEPS SYSTEM

- (h) Using ohm band of digital multimeter, measure resistance between terminal 7 of connector J1 and body ground to check interior wire harness for short to body ground.

OK

Multimeter Connection	Condition	Specified Condition
B-034 -7 - Body ground	Always	∞




- (i) Connect the negative battery cable, turn ENGINE START STOP switch to ON, (confirm that connectors B-018 and Q-007 are disconnected). Using DC voltage band of digital multimeter, measure voltage between terminal 7 of connector J1 and body ground to check interior wire harness for short to power supply.

OK

Multimeter Connection	Condition	Specified Condition
J1-07 - Body ground	Always	0 V

Result

Proceed to
OK
NG



NG

Replace interior wire harness

OK

2

Check front bumper wire harness for open or short


- Turn ignition switch to OFF.
- Disconnect the negative battery cable.
- Disconnect the ESP controller connector Q-014.
- Check if wire harnesses are worn, pierced, pinched or partially broken.
- Check for broken, bent, protruded or corroded terminals.
- Check if related connector pins are in good condition.

31-PEPS SYSTEM

- (g) Using ohm band of digital multimeter, measure resistance between terminal 34 of connector Q-013 and terminal 20 of connector Q-007 to check front bumper wire harness for open.

OK


Multimeter Connection	Condition	Specified Condition
Q-013-34 - Q-007-20	Always	$\leq 1 \Omega$



- (h) Using ohm band of digital multimeter, measure resistance between terminal 20 of connector Q-007 and body ground to check front bumper wire harness for short to body ground.

OK

Multimeter Connection	Condition	Specified Condition
Q-007-20 - Body ground	Always	∞




- (i) Connect the negative battery cable, turn ignition switch to ON, (confirm that connectors Q-007 and B-018 are disconnected). Using DC voltage band of digital multimeter, measure voltage between terminal 20 of connector Q-007 and body ground to check front bumper wire harness for short to power supply.

OK

Multimeter Connection	Condition	Specified Condition
Q-007-20 - Body ground	Always	0 V

Result

Proceed to
OK
NG



31-PEPS SYSTEM

OK	Replace PEPS module
NG	Replace front bumper wire harness

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



DTC	B1518	Trunk/Back Door Unlock Switch Stuck Failure
DTC	B1519	Back Door Lock Switch Continuously Pressed

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



31-PEPS SYSTEM

Circuit Diagram

31



PE0060001

Description

DTC	DTC Definition
B1518	Trunk/Back Door Unlock Switch Stuck Failure
B1519	Back Door Lock Switch Continuously Pressed

Caution:

When performing electrical equipment diagnosis and test, always refer to circuit diagram for related circuit and component information.

Procedure**1 Check vehicle malfunction condition**

- (a) Press luggage compartment door release switch to check if luggage compartment door is open.

Result

Proceed to
OK
NG

OK

Turn off vehicle power supply (disconnect the negative battery cable), then turn on power supply again and clear DTC.

NG

2 Check luggage compartment door release switch

- (a) Turn ENGINE START STOP switch to OFF.
 (b) Disconnect the negative battery cable.
 (c) Disconnect the luggage compartment door release switch connector T-010.
 (d) Check if wire harnesses are worn, pierced, pinched or partially broken.
 (e) Check for broken, bent, protruded or corroded terminals.
 (f) Check if related connector pins are in good condition.
 (g) Using ohm band of digital multimeter, measure resistance of luggage compartment door release switch to check if luggage compartment door release switch is damaged.

OK

Multimeter Connection	Condition	Specified Condition
Luggage compartment door release switch 1 - 2	Not pressed	∞
Luggage compartment door release switch 1 - 2	Pushed	$\leq 1 \Omega$

Result

Proceed to
OK
NG



31-PEPS SYSTEM

NG

Replace luggage compartment door release switch

OK

3

Check luggage compartment door release switch ground side


- (a) Using ohm band of digital multimeter, measure resistance between terminal 2 of connector T-010 and body ground. to check ground side for normal.

OK

Multimeter Connection	Condition	Specified Condition
T-010-2 - Body ground	Always	$\leq 1 \Omega$

Result

Proceed to
OK
NG



NG

Handle T-002 ground wire harness

OK

4

Check back door release switch circuit signal voltage


- (a) Connect the negative battery cable.
 (b) Turn ENGINE START STOP switch to ON.
 (c) Using DC voltage band of digital multimeter, measure if signal voltage at terminal 1 of connector T-010 is normal.

OK

Multimeter Connection	Condition	Specified Condition
T-010-1 - Body ground	ON state	Not less than 12 V

Result

Proceed to
OK
NG



OK

Handle poor connector contact

NG

5


Check luggage compartment door wire harness for open or short

- Turn ENGINE START STOP switch to OFF.
- Disconnect the negative battery cable.
- Disconnect connectors T-001 and B-005.
- Check if wire harnesses are worn, pierced, pinched or partially broken.
- Check for broken, bent, protruded or corroded terminals.
- Check if related connector pins are in good condition.
- Using ohm band of digital multimeter, measure resistance between terminal 1 of connector T-010 and terminal 7 of connector T-001 to check luggage compartment door wire harness for open.

OK

Multimeter Connection	Condition	Specified Condition
T-010-01 - T-001-07	Always	$\leq 1 \Omega$


31



- Using ohm band of digital multimeter, measure resistance between terminal 1 of connector T-010 and body ground to check luggage compartment door wire harness for short to body ground.

OK

Multimeter Connection	Condition	Specified Condition
T-010-01 - Body ground	Always	∞



31-PEPS SYSTEM


- (i) Connect the negative battery cable, turn ignition switch to ON, (confirm that connectors T-010 and T-001 are disconnected). Using DC voltage band of digital multimeter, measure voltage between terminal 1 of connector T-010 and body ground to check luggage compartment door wire harness for short to power supply.

OK

Multimeter Connection	Condition	Specified Condition
T-010-01 - Body ground	Always	0 V

Result

Proceed to
OK
NG



NG

Replace back door wire harness


OK

6 Check interior wire harness for open or short

- (a) Disconnect the PEPS module connector J3.
 (b) Check if wire harnesses are worn, pierced, pinched or partially broken.
 (c) Check for broken, bent, protruded or corroded terminals.
 (d) Check if related connector pins are in good condition.
 (e) Using ohm band of digital multimeter, measure resistance between terminal 7 of connector B-005 and terminals 1 of connector J3 to check interior wire harness for open.

OK

Multimeter Connection	Condition	Specified Condition
B-005-07 - J3-01	Always	$\leq 1 \Omega$




31-PEPS SYSTEM

- (f) Using ohm band of digital multimeter, measure resistance between terminal 7 of connector B-005 and body ground to check interior wire harness for short to body ground.

OK

Multimeter Connection	Condition	Specified Condition
B-005-07 - Body ground	Always	∞




- (g) Connect the negative battery cable, turn ENGINE START STOP switch to ON, (confirm that connectors B-005 and J3 are disconnected). Using DC voltage band of digital multimeter, measure voltage between terminal 7 of connector B-005 and body ground to check interior wire harness for short to power supply.

OK

Multimeter Connection	Condition	Specified Condition
B-005-07 - Body ground	Always	0 V

Result

Proceed to
OK
NG



OK

Replace PEPS module

NG

Replace interior wire harness

31-PEPS SYSTEM

DTC	U0100	Lost of Communication with Engine Control System Module
DTC	U0129	Lost Communication with Brake System Module
DTC	U0140	Lost Communication with Body Control Module
DTC	U0329	Lost Communication with Electronic Steering Column Lock

Description

DTC	DTC Definition
U0100	Lost of Communication with Engine Control System Module
U0129	Lost Communication with Brake System Module
U0140	Lost Communication with Body Control Module
U0329	Lost Communication with Electronic Steering Column Lock

Procedure

1	Refer to "CAN COMMUNICATION" for troubleshooting
---	--

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

ON-VEHICLE SERVICE

PEPS Control Module Assembly


Removal

Warning/Caution/Hint

Caution:

- DO NOT separate PEPS controller and fixing bracket at will, or clamping structure of controller will be damaged, unless controller malfunction is confirmed by troubleshooting result, it can be removed and cannot be reused.
 - DO NOT replace PCB board of PEPS controller at will, or it cannot be traced back and may be make abnormal sound.
 - After replacing PEPS controller assembly, before performing key learning and anti-theft matching, do not press ENGINE START STOP switch at will if nor necessary (it is set that keyless start can be performed for 50 times), to prevent PEPS controller from being locked and causing vehicle power supply not to be turned on.
1. Turn ENGINE START STOP switch to OFF.
 2. Disconnect the negative battery cable.
 3. Remove the glove box assembly (See page 45-11).
 4. Remove the PEPS module.

(a) Disconnect the PEPS module connectors (arrow).



(b) Remove 2 coupling bolts (1) between PEPS module mounting bracket and instrument panel crossmember.

Tightening torque

$7 \pm 1 \text{ N}\cdot\text{m}$

(c) Unplug module from PEPS controller bracket in reverse direction of mounting.


Installation

1. Installation is in the reverse order of removal.

31-PEPS SYSTEM

Front Low Frequency Antenna (for DCT Models)**Removal**

1. Turn ENGINE START STOP switch to OFF.
2. Disconnect the negative battery cable.
3. Remove the auxiliary fascia console assembly (See page 45-7).
4. Remove the front low frequency antenna.
 - (a) Disconnect the connector (arrow) from front low frequency antenna.



- (b) Using a tool, detach low frequency antenna fixing clip (1) from automatic shift mechanism transition bracket.

Caution:

- DO NOT repeatedly remove and install it, and dispose it if it becomes loosen.

Installation

1. Installation is in the reverse order of removal.

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Center Low Frequency Antenna

Removal

1. Turn ENGINE START STOP switch to OFF.
2. Disconnect the negative battery cable.
3. Remove the auxiliary fascia console assembly (See page 45-7).
4. Remove the center low frequency antenna
 - (a) Disconnect the connector (arrow) from center low frequency antenna.



31

- (b) Using a tool, detach low frequency antenna fixing clip (1) from parking brake rear mounting bracket.

Caution:

- DO NOT repeatedly remove and install it, and dispose it if it becomes loosen.

Installation

1. Installation is in the reverse order of removal.




دیجیتال خودرو
شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

31-PEPS SYSTEM

Remove the rear low frequency antenna**Removal**

1. Turn ENGINE START STOP switch to OFF.
2. Disconnect the negative battery cable.
3. Remove the luggage compartment carpet assembly.
4. Remove the rear low frequency antenna assembly.
 - (a) Disconnect the connector (arrow) from rear low frequency antenna.



- (b) Using a tool, detach low frequency antenna fixing clip (1) from mounting hole.

Caution:

- DO NOT repeatedly remove and install it, and dispose it if it becomes loosen.

Installation

1. Installation is in the reverse order of removal.




شرکت دیجیتال خودرو (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Rear Bumper Low Frequency Antenna

Removal

1. Turn ENGINE START STOP switch to OFF.
2. Disconnect the negative battery cable.
3. Remove the rear bumper assembly (See page 48-25).
4. Remove the rear low frequency antenna assembly.
 - (a) Disconnect the connector (arrow) from rear bumper low frequency antenna.



31

- (b) Using a tool, detach low frequency antenna fixing clip (1) from rear bumper crossmember.

Caution:

- DO NOT repeatedly remove and install it, and dispose it if it becomes loosen.

Installation

1. Installation is in the reverse order of removal.

شرکت دیجیتال خودرو (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



31-PEPS SYSTEM


Anti-theft Coil (for DCT Models)**Removal**

1. Turn ENGINE START STOP switch to OFF.
2. Disconnect the negative battery cable.
3. Remove the auxiliary fascia console assembly (See page 45-7).

Hint:

Disconnect anti-theft coil connector (arrow) while removing auxiliary fascia console. Prevent wire harness from breaking.

4. Remove the anti-theft coil.
 - (a) Press two clips with left hand while hold coil (1) with right hand, and unplug it in opposite direction of installation direction with large force.

**Installation**

1. Installation is in the reverse order of removal.

Caution:

- The anti-theft coil must be installed with a smooth surface against the mounting surface, and ensure it is installed in place, otherwise it may fall off from the bracket, thus failing to carry out normal key learning and anti-theft matching.

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران