Suspension System

GENERAL

FRONT SUSPENSION SYSTEM FRONT STRUT ASSEMBLY FRONT LOWER ARM

REAR SUSPENSION SYSTEM REAR STRUT ASSEMBLY REAR SUSPENSION ARM

FRONT STABILIZER BAR

TRAILING ARM REAR STABILIZER BAR

TIRES / WHEELS FRONT WHEEL ALIGNMENT REAR WHEEL ALIGNMENT WHEEL RUNOUT WHEEL NUT TIGHTENING TIRE WEAR TIRE ROTATION

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

SUSPENSION SYSTEM

SS -2

GENERAL

SPECIFICATIONS E5F865DF

Items		Specifications			
		BETA M/T	BETA, DELTA A/T DSL M/T	DSL A/T	
Front	Model	Macpherson strut type			
suspen- sion	Shock absorber Type Stroke mm(in.) Identification color	Gas type 160.7(6.33) Red			
	Coil spring-2WD Inside dia. mm(in.) Outside dia. mm Load rate Kgf/mm Free height mm(in.) Identification color	Ø137.6(5.42) Ø165~168(6.50~6.61) 3.1±0.15 325.8(12.83) YELLOW	Ø137.6(5.42) Ø165~168(6.50~6.61) 3.1±0.15 332.3(13.08) GREEN	Ø137.5(5.41) Ø165~168(6.50~6.61) 3.1±0.15 338.7(13.34) ORANGE	
q	Coil spring-4WD Inside dia. mm(in.) Outside dia. mm(in.) Load rate Kgf/mm Free height mm(in.) Identification color	Ø137.5(5.41) Ø165~168(6.50~6.61) 3.2±0.16 328.1(12.92) YELLOW-YELLOW	Ø137.4(5.41) Ø165.1~168.1(6.50~6.62) 3.2±0.16 334.3(13.16) GREEN-GREEN	Ø137.4(5.41) Ø165.2~168.2(6.50~6.62) 3.2±0.16 340.6(13.41) ORANGE-ORANGE	
Rear	مانه (مسئولModel	Dualglink شرکت دیجیتال خو			
suspen- sion ایران	Shock absorber Type Stroke mm(in.) Identification color	Gas type 191.0(7.52) Hold Ulolu Ulol WHITE			
	Coil spring	2WD	4WD		
	Min. dia. mm(in.) Max. dia. mm(in.) Load rate Kgf/mm Measurement range of rate mm(in.) Free height mm(in.) Identification color	Ø100 (3.94) Ø170 (6.69) 2.8±0.14 154.3~300.8 (6.08~11.84) 346.5(13.64) YELLOW	Ø100 (3.94) Ø170 (6.69) 2.9±0.15 156.6~301.5(6.17~11.87) 349.8(13.77) WHITE		

GENERAL

Items		Specifications			
Wheel	Wheel alignment	Front		Rear	
& Tire	Dimension Toe-in mm(in.) Camber Caster angle(to ground) Caster angle(to body) King pin angle King pin offset mm(in.) Side slip mm(in.)	P215/65R16 ±2(0.079) 0°±30 3°32′±30′ 3°52′ 12°46′±30′ -9.73(0.383) ±3(0.118)	P235/60R16 ±2(0.079) 0°±30 3°32′±30′ 3°52′ 12°46′±30′ -10.41(0.410) ±3(0.118)	P215/65R16 4.6+3,-1 0°55´±30´ - - - - -	P235/60R16 4.6+3,-1 0°55´±30´ - - - -
	Wheel Size Run out mm(in.)	AL wheel 6.5JX16 Radial : 0.3(0.01), Lateral : 0.3(0.01)			
	Tire Size Inflation pressure kg/cm ² (psi)	P215/65R16, P235/60R16 2.1±0.07(30+1.0)			

TIGHTENING TORQUE

Items	Nm	Kgf⋅cm	lbf-ft
Front suspension			
Wheel nut	90~110	900~1100	66.4~81.2
Strut upper mounting nut	45~60	450~600	33.2~44.3
Strut lower mounting nut	140~160	1400~1600	103.3~118.0
Strut mounting self-locking nut	60~70	600~700	44.3~51.6
Speed sensor cable mounting bolt	7~11 کے	70~110	5.2~8.1
Lower arm mounting nut	80~90	800~900	59.0~66.4
Lower arm bush(A) mounting bolt	100~120	1000~1200	73.8~88.5
Lower arm bush(G) mounting bolt	14 <mark>0</mark> ~160	1400~1600	103. <mark>3~118</mark> .0
Stabilizer bracket mounting bolt	<mark>50</mark> ~65	500~650	36. <mark>9~48.</mark> 0
Stabilizer link mounting nut	100~120	1000~1200	73.8~88.5
Tie rod end ball joint mounting nut	45~60	450~600	33.2~44.3
Tie rod toe adjustment nut	50~60	500~600	36.9~44.3
Rear suspension			
Wheel nut	90~100	900~1100	66.4~81.2
Strut upper mounting nut	30~40	300~400	22.1~29.5
Strut lower mounting nut	140~160	1400~1600	103.3~118.0
Strut mounting self-locking nut	40~55	400~550	29.5~40.6
Speed sensor cable mounting bolt	7~11	70~110	5.2~8.1
Stabilizer bracket mounting bolt	50~65	500~650	36.9~48.0
Stabilizer link mounting nut	100~120	1000~1200	73.8~88.5
Tie rod toe adjustment nut	50~60	500~600	36.9~44.3
Suspension arm mounting bolt[2WD]	160~180	1600~1800	118.0~132.8
Suspension arm mounting bolt[4WD]	140~160	1400~1600	103.3~118.0
Cross member mounting bolt	100~120	1000~1200	73.8~88.5
Trailing arm bracket mounting bolt	100~120	1000~1200	73.8~88.5
Trailing arm to carrier mounting bolt	100~120	1000~1200	73.8~88.5
Differential mounting bolt	90~120	900~1200	59.0~88.5

Replace the self-locking nuts with new ones after removal.

SS -4

SUSPENSION SYSTEM

LUBRICANTS ECA8D26E

Item	Quantity
In insulator of strut	As required

SPECIAL TOOLS EBE96F7A

Tool(Number and Name)	Illusstration	Use
09216-21100 Mount bushing remover and installer	B1621100	Removal & installation of lower arm bushing(G)
09214-32000 Mount bushing remover and installer		Removal & installation of lower arm bushing(G)
	E1432000	
09529-21000 Trailing arm bushing remover installer	لین سامارین از تعمی E292100	Removal & installation of trailing arm bushing
09546-26000 Strut spring compressor	E4626000	Compression of the coil spring

GENERAL

TROUBLESHOOTING EBF3578C

Trouble sysmptom	Probable cause	See page
Hard steering	Improper front wheel alignment Excessive turning resistance of lower arm ball joint Flat tire No power assist	SS-45 - - -
Poor return of steering wheel to center	Improper front wheel alignment	SS-45
Poor ride quality	Improper front wheel alignment Damaged shock absorber Varied or dameged stabilizer Varied or dameged coil spring Worn lower arm bushing	SS-45 SS-7, 23 SS-20, 41 SS-11 SS-18
Abnormal tire wear	Improper front wheel alignment Worn of shock absorber	SS-45 SS-7 ,23
Wandering	Improper front wheel alignment Poor turning resistance of lower arm ball joint Loose or worn lower arm bushing	SS-45 - SS-18
Vehicle pulls to one side	Improper front wheel alignment Excessive turning resistance of lower arm ball joint Varied or dameged coil spring Bent lower arm Improper tire inflation pressure	SS-45 - - SS-11, 27 SS-16
Steering wheel shimmy رکاران خودرو در ایران	Improper front wheel alignment Excessive turning resistance of lower arm ball joint Varied or dameged stabilizer Worn lower arm bushing Worn of shock absorber Varied or dameged coil spring Improper front wheel alignment	SS-45 SS-20 SS-18 SS-7 SS-11
Bottoming	Broken or worn spring Malfunction of shock absorber	SS-11, 27 SS-7, 23

SUSPENSION SYSTEM

WHEEL AND TIRE DIAGNOSIS			
Radid wear at the center	Rapid wear at both shoulders	Wear at one shoulder	
KXDT001A	KXDT002A	KXDT003A	
 Center-tread down to fabric due to excessive over inflated tires Lack of rotation Excessive toe on drive wheels Heavy acceleration on drive 	 Underinflated tires Worn suspension components Excessive cornering speeds Lack of rotation 	 Toe adjustment out of specification Camber out of specification Damaged strut Damaged lower arm 	



FRONT SUSPENSION SYSTEM

FRONT SUSPENSION SYSTEM

FRONT STRUT ASSEMBLY

COMPONENT LOCATION EF49AC8B



EHQE101A

021-62999292

SS -8

SUSPENSION SYSTEM



EHQE101B

Spring upper pad

7.

SS -9

FRONT SUSPENSION SYSTEM

REMOVAL E2DBEF28

- Loosen the wheel nuts slightly. Raise the front of the vehicle, and make sure it is securely supported.
- 2. Remove the front wheel and tire(A) from front hub(B).

4. Remove the speed sensor cable mounting bolt(B) and speed sensor(A).



KHQE100B

5. Remove the nut(B) from the stabilizer bar link(A).

Ø

В

خودرو سامانه (مسئولیت محدود AUTION

Bej careful not to damage the hub bolts(C) then remove the front wheel and tire(A).

3. Remove the brake hose bracket(B) and speed sensor cable mounting bolt(C) from the strut assembly(A).



KHQE100E

KHQE100A

KIQE100A

021-62999292

SS -10

SUSPENSION SYSTEM

6. Remove the strut upper mounting nuts(A).



KHQE100C

7. Remove the strut lower mounting bolts(A) and then remove the strut assembly(B).





KHQE100D

FRONT SUSPENSION SYSTEM

DISASSEMBLY EA5EB9F7

- 1. Remove the dust cover(A) with a flat-tipped (-) screw driver.
- 3. Using the special tool (09546-26000), compress the coil spring(A) until there is only a little tension of the spring on the strut.



021-62999292

SUSPENSION SYSTEM

SS -12

INSPECTION EDDEEE02

- 1. Check the strut insulator bearing for wear or damage.
- 2. Check rubber parts for damage or deterioration.
- 3. Compress and extend the piston rod(A) and check that there is no abnormal resistance or unusual sound during operation.

DISPOSAL E401DB1D

- 1. Fully extend the piston rod.
- 2. Drill a hole on the A section to remove gas from the cylinder.



EHKD010A

FRONT SUSPENSION SYSTEM

REASSEMBLY E1D4D40B

- Install the spring lower pad(D) so that the protrusions(A) fit in the holes(C) in the spring lower seat(B).
- After seating the upper and lower ends of the coil spring(A) in the upper and lower spring seat grooves(B) correctly, tighten new self-locking nut temporarily.





KHQE130A

- 2. Compress coil spring using special tool (09546-26000).
 - Install compressed coil spring into shock absorber.

NOTE

a. Indicated two identification color marks on the coil spring; one follows model option (see page SS-2) the other follows load classification according to the below.

Pay attention to distinguish between the two marks and then install them.

- b. Install the coil spring wth the idemtification mark directed toward the knuckle.
- 3. After fully extending the piston rod, install the spring upper seat and insulator assembly.

- 5. Remove the special tool(09546-26000).
- 6. Tighten the self-locking nut to the specified torque.

Tightening torque

60~70 Nm(600~700 kgf·cm, 44.3~51.6 lbf·ft)

7. Apply grease to the strut upper bearing and install the insulator cap.

When applying the grease, be careful so that it isn't smeared on the insulator rubber.

021-62999292

SS -14

INSTALLATION E9B1AAEF

1. Install the strut assembly(B) and then install the strut lower mounting bolts(A).

Tightening torque

140~160 Nm (1400~1600 Kgf·cm, 103.3~118.0 lbf·ft)

- SUSPENSION SYSTEM
- 3. Install the nut(B) on the stabilizer bar link(A).

Tightening torque

100~120 Nm (1000~1200 Kgf·cm, 73.8~88.5 lbf·ft)







KHQE100B

KHQE100C

021-62999292

FRONT SUSPENSION SYSTEM

5. Install the brake hose bracket(B) and speed sensor cable mounting bolt(C) on the strut assembly(A).

Tightening torque

7~11 Nm (70~110 Kgf·cm, 5.2~8.1 lbf·ft)





KIQE100A

Be careful not to damage the hub bolts(C) then install the front wheel and tire(A).

SUSPENSION SYSTEM

FRONT LOWER ARM

COMPONENTS E1F19F76



021-62999292

FRONT SUSPENSION SYSTEM

REMOVAL E96D8DEB

B

Α

- Loosen the wheel nuts slightly. Raise the front of the vehicle, and make sure it is securely supported.
- 2. Remove the front wheel and tire(A) from front hub(B).

- SS -17
- 4. Remove the lower arm mounting bolts(A).



KHQE200B



3. Remove the lower arm ball joint mounting bolts(A).

remove the front wheel and tire(A).

Be careful not to damage the hub bolts(C) then



KHQE200A

KIQE100A

021-62999292

SS -18

REPLACEMENT EB9F14FA

1. Using the special tools(09214-32000 & 09216-211000), remove the bushing from the lower arm.

- SUSPENSION SYSTEM
- 3. Using the special tools(09214-32000 & 09216-21100), install the busing on the lower arm.





KHQE210C

FRONT SUSPENSION SYSTEM

INSTALLATION EEAF7A96

1. Install the lower arm mounting bolts(A).

Tightening torque

A bushing : 100~120 Nm (1000~1200 Kgf·cm, 73.8~88.5 lbf·ft) G bushing : 140~160 Nm (1400~1600 Kgf·cm, 103.3~118.0 lbf·ft) 3. Install the front wheel and tire(A) on the front hub(B).

Tightening torque 90~110 Nm (900~1100 Kgf·cm, 66.4~81.2 lbf·ft)



Tightening torque 100~120 Nm (1000~1200 Kgf·cm, 73.8~88.5 lbf·ft)



KHQE200A

SUSPENSION SYSTEM

FRONT STABILIZER BAR

COMPONENTS EC063896



021-62999292

FRONT SUSPENSION SYSTEM

REMOVAL E7C35609

- Loosen the wheel nuts slightly. Raise the front of the vehicle, and make sure it is securely supported.
- 2. Remove the front wheel and tire(A) from front hub(B).

- SS -21
- 4. Remove the rear mounting bolts of subframe.
- 5. Remove the stabilizer bracket(A) and bushing(B).
 - a. After loosen the bolts(C), then remove the bracket(A) and bushing(B).





Be careful not to damage the hub bolts(C) then remove the front wheel and tire(A).

Remove the stabilizer bar link(A).
 a. Remove the nut(B) and stabilizer bar link(A).





- KHQE300A
- b. Remove the stabilizer bracket and bushing on the opposite side in the same way.
- 6. Remove the stabilizer bar.

Be careful not to damage the pressure tube.

INSPECTION ED8731A3

- 1. Check the stabilizer bar for deterioration and damage.
- 2. Check all bolts for damage and deformation.
- 3. Check the stabilizer link dust cover for cracks or damage.

KHQE100E

b. Remove the stabilizer bar link on the opposite side in the same way.

021-62999292

SS -22

INSTALLATION EAE6F408

1. Install the bushing(B) on the stabilizer bar(A).

SUSPENSION SYSTEM

5. Install the nut(B) on the stabilizer bar link(A).

Tightening torque

100~120 Nm (1000~1200 Kgf·cm, 73.8~88.5 lbf·ft)



KHQE340A

Bring clamp(C) of stabilizer bar(A) into contact with bushing(B).

- 2. Install the bracket on the bushing(B).
- 3. After tightening the bolts of the bushing bracket temporarily, install the bushing bracket on the opposite side.

Tightening torque

С

50~65 Nm (500~650 Kgf·cm, 36.9~48.0 lbf·ft)

4. Install the rear mounting bolts of sub-frame.

6. Install the front wheel and tire(A) on the front hub(B).

Tightening torque 90~110 Nm (900~1100 Kgf·cm, 66.4~81.2 lbf·ft



KIQE100A

KHQE100E

Be careful not to damage the hub bolts(C) then install the front wheel and tire(A).

021-62999292

REAR SUSPENSION SYSTEM

REAR SUSPENSION SYSTEM

REAR STRUT ASSEMBLY

COMPONENT LOCATION E28CAFBC



WWW.DIGITALKHODRO.COM

021-62999292

021-62999292



SUSPENSION SYSTEM



COMPONENTS EF589D20



021-62999292

SS -26

REMOVAL E382BC39

- Loosen the wheel nuts slightly. Raise the rear of the vehicle, and make sure it is securely supported.
- 2. Remove the rear wheel and tire(A) from rear hub(B).

SUSPENSION SYSTEM

🚺 ΝΟΤΕ

Drum brake type : Remove the speed sensor cable mounting bolts(2EA) and the brake hose bracket. Disc brake type : Remove the speed sensor cable mounting bolt(1EA)

- 4. Remove the stabilizer bar link nut(B).
- 5. Remove the strut upper mounting nut(A).



- 3. Remove the speed sensor cable monting bolt(A).
- 6. Remove the strut lower mounting bolts(A) and then remove the strut assembly(B).





KHQE400C

KHQE400A

021-62999292

REAR SUSPENSION SYSTEM

DISASSEMBLY ECFFC844

 Using the special tool(09545-26000), compress the coil spring(A) until there is only a little tension on the strut(B).

С

INSPECTION EESEDDDE

- 1. Check the insulator for wear or damage.
- 2. Check rubber parts for damage or deterioration.
- 3. Compress and extend the piston rod(A) and check that there is no abnormal resistance or unusual sound during operating.



021-62999292

<u>SS -28</u>

DISPOSAL E6E0CB61

- 1. Fully extend the piston rod.
- 2. Drill a hole on the A section to remove gas from the cylinder.

SUSPENSION SYSTEM

REASSEMBLY EB6AF4DE

 Install the spring lower pad(D) so that the protrusions(A) fit in the holes(C) in the spring lower seat(B).



b. Install the coil spring with the identification mark directed toward the knuckle.

REAR SUSPENSION SYSTEM

- 3. After fully extending the piston rod, install the spring upper seat and insulator assembly.
- After seating the upper and lower ends of the coil spring(A) in the upper and lower spring seat grooves(B) correctly, tighten new self-locking nut temporarily.

INSTALLATION E8FB7A4C

1. Install the strut assembly(B) and then install the strut lower mounting bolts(A).

Tightening torque

140~160 Nm (1400~1600 Kgf·cm, 103.3~118.0 lbf·ft)





KHQE400B

WWW.DIGITALKHODRO.COM

021-62999292

021-62999292

SS -30

3. Install stabilizer bar link nut(B).

Tightening torque

100~120 Nm (1000~1200 Kgf·cm, 73.8~88.5 lbf·ft)

SUSPENSION SYSTEM

5. Install the rear wheel and tire(A) on the rear hub(B).

Tightening torque

90~110 Nm (900~1100 Kgf·cm, 66.4~81.2 lbf·ft)



Install the speed sensor cable mounting bolt(1EA)

REAR SUSPENSION ARM

COMPONENTS EB78B9E2



SS -31

021- 62 99 92 92



SUSPENSION SYSTEM



EHQE601B

REAR SUSPENSION SYSTEM

REPLACEMENT EODB0678

[2WD]

3.

1. Remove the trailing arm mounting bolt(A) and suspension arm mounting bolt(B).



2. Remove the opposite side trailing arm mounting bolt

After supporting the rear cross member assembly(B) with the jack(A), remove the cross member mounting

and suspension arm mounting bolt.

bolts and nuts(C).

Remove the suspension arm bracket mounting bolts(A).



KHQE600C

- 5. Remove the suspension arm(B).
- 6. Install the suspension arm bracket mounting bolts(A).
- **Tightening torque** 160~180 Nm (1600~1800 Kgf·cm, 118.0<mark>~132.8 lbf·ft)</mark>



KHQE600C

KHQE600B

021-62999292

SS -34

SUSPENSION SYSTEM

7. Make sure that the arrow mark(B) on the rear cross member(A) should place the front face of the vehicle.



KHQE640A

8. Rear suspension arm(C)-to-rear carrier bolts should be temporarily tightened, and then fully tightened with the vehicle on the ground in unloaded condition.

Tightening torque 160~180 Nm (1600~1800 Kgf·cm, 118.0~132.8 lbf·ft)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



REAR SUSPENSION SYSTEM

[4WD]

2.

3.

1. Remove the muffler(A).

Remove the coupling control connector(A).



KHQE605F

 After supporting the rear cross member assembly(B) with a jack(A), remove the cross member mounting bolts and nuts(C).



KHQE605B

KHQE605A

4.

KHQE605C

Remove the opposite side suspension mounting bolts. 6.

Ð

Remove the suspension arm mounting bolts(A).

6. Remove the propeller shaft. (see page DS-propeller shaft)

WWW.DIGITALKHODRO.COM

021-62999292

SS -35

021-62999292

SS -36

SUSPENSION SYSTEM

- 7. Remove the rear differential(A) from the cross member(B).
- 10. Install the suspension arm bracket mounting bolts(A).

```
Tightening torque
```

140~160 Nm (1400~1600 Kgf·cm, 103.3~118.0 lbf·ft)



9. Remove the suspension arm(B).

KHQE605D
021-62999292

REAR SUSPENSION SYSTEM

SS -37

KHQE605B

- 12. Install the propeller shaft. (see page DS-propeller shaft)
- 13. After supporting the rear cross member assembly(B) with the jack(A), install the cross member mounting bolts and nuts(C).

Tightening torque

100~120 Nm (1000~1200 Kgf·cm, 73.8~88.5 lbf·ft)

15. Rear suspension arm-to-rear carrier bolts(A) should be temporarily tightened, and then fully tightened with the vehicle on the ground in unloaded condition.

Tightening torque

140~160 Nm (1400~1600 Kgf·cm, 103.3~118.0 lbf·ft)



14. Install the coupling control connector(A).



KHQE605F



SS -38

TRAILING ARM

COMPONENTS ECEDCC87



REAR SUSPENSION SYSTEM

REMOVAL EF96FAF2

1. Remove the trailing arm mounting bolts(A).

SS -39

REPLACEMENT EA5D8FFF

TRAILING ARM BUSHING

1. Install the special tools(09529-21000 & 09216-21100) on the trailing arm(A).





Insert bush as to arrow direct toward trailing arm length.

021-62999292

SS -40

INSTALLATION EE30EDA5

Install the trailing arm(B).

a. Install the trailing arm mounting bolt(A).

Tightening torque

100~120 Nm (1000~1200 Kgf·cm, 73.8~88.5 lbf·ft)

b. Install the trailing arm bracket mounting bolt, nut.

Tightening torque	
100~120 Nm (1000~1200 Kgf·cm, 73.8~88.5 lbf·ft)	



KHQE500A

NOTE

The trailing arm mounting bolts, then fully tightened with the vehicle on the ground in unloaded condition.

021-62999292

SUSPENSION SYSTEM

REAR STABILIZER BAR

COMPONENTS E2530CA4



<u>SS -41</u>

021-62999292

SUSPENSION SYSTEM

SS -42

REMOVAL E7ECDA1F

- 1. Loosen the wheel nuts slightly. Raise the rear of the vehicle, and make sure it is securely supported.
- Remove the rear wheel and tire(A) from rear hub(B). 2.
- Remove the stabilizer bar mounting bolts(A) and then 4. remove the stabilizer bracket(B).



Remove the stabilizer bar link mounting nut(A). 3.



KHQE700A

021-62999292

REAR SUSPENSION SYSTEM

INSPECTION ED1E4EBB

- 1. If there is a crack and damage in the dust cover, replace the stabilizer bar link.
- 2. Mount the self-locking nut on the ball joint, and then measure the ball joint rotating torque.

Tightening torque

0.7~2 Nm (7~20 Kgf·cm, lbf·ft)





- 3. If the rotating torque is above the upper limit of the standard value, replace the stabilizer link.
- 4. If the rotating torque is below the lower limit of the standard value, the ball joint may be reused unless it has drag and excessive play.

WWW.DIGITALKHODRO.COM

021-62999292

SS -44

С

NOTE

2.

INSTALLATION E3DA2820

1. Install the bushing(B) on the stabilizer bar(A).

SUSPENSION SYSTEM

4. Install the stabilizer bar link mounting nut(A).

Tightening torque

100~120 Nm (1000~1200 Kgf·cm, 73.8~88.5 lbf·ft)



- Employ the same manner described above step 3 and 4 to the other side.
- 6. Install the rear wheel and tire(A) on the rear hub(B).

Tightening torque 90~110 Nm (900~1100 Kgf·cm, 66.4~81.2 lbf·ft)



Bring clamp(C) of stabilizer bar(A) into contact with

Install the stabilizer bracket(B) and then install the sta-

bushing(B).

bilizer bar mounting bolts(A).

B

KIQE300A

KHQE700A

🗥 CAUTION

Be careful not to damage the hub bolts(C) then install the rear wheel and tire(A).



KHQE700B

KHQE340A

5.

One side bracket should be temporarily tightened, 3. and then install the bushing on the opposite side.

Tightening torque 50~65 Nm (500~650 Kgf·cm, 36.9~48.0 lbf·ft)

WWW.DIGITALKHODRO.COM

SS -45

TIRES / WHEELS

TIRES / WHEELS

FRONT WHEEL ALIGNMENT

DESCRIPTION ECE9CCCD

WHEEL ALIGNMENT

When using a commercially-available computerized four wheel alignment equipment (caster, camber, toe) to inspect the front wheel alignment, always position the car on a level surface with the front wheels facing straight ahead. Prior to inspection, make sure that the front suspension and steering system are in normal operating condition and that the wheels and tires facestraight ahead and the tires are inflated to the specified pressure.

TOE

Toe is a measurement of how much the front of the wheels are turned in or out from the straight-ahead position.

When the wheels aree turned in toward the front of the vehicle, toe is positive (+) (toe in). When the wheels are turned out toward the front of the vehicle, toe is negative (-) (toe out). Toe is measured in degrees, from side to side, and totaled.

Toe-in(B-A or angle a+b) is adjusted by turning the tie rod turnbuckles. Toe-in on the left front wheel can be reduced by turning the tie rod toward the rear of the car. Toe- in change is adjusted by turning the tie rods for the right and left wheelss simultaneously at the same amount as follows.

Standard value

Toe-in (B-A) mm (in.) : 0±2 mm (0±0.08 in.)

🔟 ΝΟΤΕ

- Toe-in adjustment should be made by turning the right and left tie rods at the same amount.
- When adjusting toe-in, loosen the outer bellows clip to prevent twisting the bellows.
- After the adjustment, tighten the tie rod end lock nuts firmly and reinstall the bellows clip.
- Adjust each toe-in to be the range of ±1mm.

Tie rod end lock nuts(A) tightening torque 50~60 Nm (500~600 Kgf·cm, 36.9~44.3 lbf·ft)

Forward

EHHA850A

ITEM	Description	
A-B < 0	Positive (+) toe (toe in)	
A-B > 0	Negative (-) toe (toe out)	

SUSPENSION SYSTEM

SS -46

CAMBER

Camber is the inward or outward tilting of the wheels at the top.



CASTER

Caster is the tilting of the strut axis either forward or backward from vertical. A backward tilt is positive (+) and a forward tilt is negative (-).

Caster is pre-set at the factory and doesn't need to be adjusted. If the caster is not within the standard value, replace the bent or damaged parts.

Caster : $3^{\circ}32' \pm 30'$

🔟 ΝΟΤΕ

- The worn loose or damaged parts of the front suspension assembly must be replaced prior to measuring front wheel alignment.
- Camber and caster are pre-set to the specified value at the factory and don't need to be adjusted.
- If the camber and caster are not within specifications, replace bent or damaged parts.
- The difference of left and right wheels about the camber and the caster must be within the range of 0° ± 30′.

	KHC	2E800B
	Description	
Posit	ve camber angl	e
~,~~~	True vertical	
S	rut centerline	

When the wheel tilts out at the top, then the camber is positive (+).

When the wheel tilts in at the top, then the camber is negative (-).

The stering knuckle which is installed with the strut assembly is pre-set to the specified camber at the factory and doesn't need to be adjusted.

Camber : 0°±30'

TIRES / WHEELS

REAR WHEEL ALIGNMENT

DESCRIPTION EF8FF1CA

TOE-IN

Standard value 4.6(+3, -1) mm[0.18(+0.12, -0.04)in]

6

Ø)

O

KHQE910A







SUSPENSION SYSTEM

SS -48

WHEEL RUNOUT

DESCRIPTION EB4999C7

- 1. Jack up the vehicle and support it with jack stands.
- 2. Measure the wheel runout with a dial indicator as illustrated.
- 3. Replace the wheel if the wheel runout exceeds the limit.

Limit	Radial	Axial
Runout mm(in.)	0.3(0.012)	0.3(0.012)





ELCSD97A

WWW.DIGITALKHODRO.COM

021-62999292

TIRES / WHEELS

SS -49

WHEEL NUT TIGHTENING

DESCRIPTION E8BCE653

1. Tightening torque.

Tightening torque 90~110 Nm (900~1100 Kgf·cm, 66.4~81.2 lbf·ft)

When using an impact gun, final tightening torque should be checked using a torque wrench.



Check the torque again after tightening the wheel nuts



2.

Tightening order.

diagonally.

KHQE810B



021-62999292

SUSPENSION SYSTEM

SS -50

TIRE WEAR

DESCRIPTION EBDE1C52

1. Measure the tread depth of the tires.

Tread depth of tire [Limit] : 1.6 mm (0.06 in.)

2. If the remaining tread(A) depth is less than the limit, replace the tire.

🔟 ΝΟΤΕ

When the tread depth of the tires is less than 1.6 mm (0.06 in.), the wear indicators(B) will appear.





KHRSS79A

TIRES / WHEELS

TIRE ROTATION

DISCRIPTION EED76AD7





021-62999292

WWW.DIGITALKHODRO.COM

021-62999292

SUSPENSION SYSTEM

SS -52

ROTATION

Rotate the tires in the pattern illustrated.





WWW.DIGITALKHODRO.COM