Engine Mechanical System

General Information

Specifications

Description		Specifications	Limit
General			
Туре		V-type, DOHC	
Number of cylinders		8	
Bore		92mm (3.6220in)	
Stroke		87mm (3.4252in)	
Total displacement		4,627 cc (282.4 cu.in)	
Compression ratio		10.4 : 1	
Firing order		1-2-7-8-4-5-6-3	
Valve timing			
Intake valve	Opens (ATDC)	8°	
	Closes (ABDC)	74°	
Exhaust valve	Opens (BBDC)	62°	
	Closes (ATDC)	4°	0
Cylinder head			
Flatness of gasket surface		Less than 0.02mm (0.0008in) / 100 x 100	
Flatness of manifold mo	ounting surface	Less than 0.01mm (0.0004in) / 110 x 110	
Camshaft			
Camheight	Intake	41.6mm (16.4in)	
	Exhaust	41.5mm (16.3in)	
Camshaft bearing oil	No. 1 journal	0.025 ~ 0.057mm (0.0010 ~ 0.0022in)	
clearance(Intake/Exh- aust)	No. 2,3,4,5 journal	0.020 ~ 0.057mm (0.0008 ~ 0.0022in)	
Camshaft journal outer	No. 1 journal	35.964 ~ 35.980mm (1.4159 ~ 1.4165in)	
diameter(Intake/Exha- ust)	No. 2,3,4,5 journal	25.964 ~ 25.980mm (1.0222 ~ 1.0228in)	
Camshaft journal bore	No. 1 journal	36.005 ~ 36.021mm (1.4175 ~ 1.4181in)	
inner diameter(Intake/ Exhaust)	No. 2,3,4,5 journal	26.000 ~ 26.021mm (1.0236 ~ 1.0244in)	
End play		RH-In: 0.12 ~ 0.22mm (0.0047 ~ 0.0086in) RH-Ex. LH-In, LH-Ex: 0.12 ~ 0.22mm (0.0047 ~ 0.0086in)	
Valve			
Valve length	Intake	107.77mm (4.2429in)	
	Exhaust	107.75mm (4.2421in)	

General Information

EMA-3

Description		Specifications	Limit
Stem outer diameter	Intake	5.965 ~ 5.980mm (0.2348 ~ 0.2354in)	
	Exhaust	5.958 ~ 5.970mm (0.2346 ~ 0.2350in)	
Face angle (Intake/Exh	naust)	45.25° ~ 45.75°	
Thickness of	Intake	1.2mm (0.0472in)	
valve head (margin)	Exhaust	1.2mm (0.0472in)	
Valve stem to	Intake	0.020 ~ 0.047mm (0.0008 ~ 0.0018in)	
valve guide clearance	Exhaust	0.030 ~ 0.054mm (0.0012 ~ 0.0021in)	
Valve guide			
Inner diameter	Intake	6.000 ~ 6.012mm (0.2362 ~ 0.2367in)	
	Exhaust	6.000 ~ 6.012mm (0.2362 ~ 0.2367in)	
Valve seat			
Width of seat contact	Intake	1.15 ~ 1.45mm (0.0453 ~ 0.0571in)	
	Exhaust	1.35 ~ 1.65mm (0.0531 ~ 0.0650in)	
Seat angle	Intake	44.75° ~ 45.10°	
	Exhaust	44.75° ~ 45.10°	0
Valve spring			
Free length		47.8mm (1.8819in)	
Load 9	درو سامانه (مسئو	27.0±1.4kg/38mm(59.6±3.0 lb/1.496in)	
		69.3±2.4kg/28mm(152.85.4 lb/1.102in)	
Out of squareness	ال تعميركاران خو	Less than 1.5°	
Cylinder block			
Cylinder bore		92.000 ~ 92.030mm (3.6220 ~ 3.6232in)	
Flatness of gasket surf	ace	Total : Less than 0.05mm (0.0020in)	
		Bore to bore : Less than 0.02mm (0.0008in)	
Piston			
Piston outer diameter		91.945 ~ 91.975mm (3.6199 ~ 3.6211in)	
Piston to cylinder clear	ance	0.045 ~ 0.065mm (0.0018 ~ 0.0026in)	
Ring groove width	No. 1 ring groove	1.23 ~ 1.25mm (0.0484 ~ 0.0492in)	
	No. 2 ring groove	1.23 ~ 1.25mm (0.0484 ~ 0.0492in)	
	Oil ring groove	2.01 ~ 2.03mm (0.0791 ~ 0.0799in)	
Piston ring			
Ring width	No. 1 ring	1.17 ~ 1.19mm (0.0461 ~ 0.0469in)	
-			
	No. 2 ring	1.17 ~ 1.19mm (0.0461 ~ 0.0469in)	

Engine Mechanical System

Description		Specifications	Limit
Side clearance	No. 1 ring	0.04 ~ 0.08mm (0.0016 ~ 0.0031in)	
	No. 2 ring	0.04 ~ 0.08mm (0.0016 ~ 0.0031in)	
	Oil ring	0.06 ~ 0.15mm (0.0024 ~ 0.0059in)	
End gap	No. 1 ring	0.17 ~ 0.32mm (0.0067 ~ 0.0126in)	
	No. 2 ring	0.37 ~ 0.52mm (0.0146 ~ 0.0205in)	
	Oil ring	0.20 ~ 0.70mm (0.0079 ~ 0.0276in)	
Piston pin			•
Piston pin outer diame	eter	21.995 ~ 22.000mm (0.8659 ~ 0.8661in)	
Piston pin hole inner o	diameter	22.004 ~ 22.010mm (0.8663 ~ 0.8665in)	
Piston pin hole cleara	nce	0.004 ~ 0.015mm (0.0002 ~ 0.0006in)	
Connecting rod small	end hole inner diameter	22.007 ~ 22.018mm (0.8664 ~ 0.8668in)	
Connecting rod small	end hole clearance	0.007 ~ 0.023mm (0.0003 ~ 0.0009in)	
Connecting rod			
Connecting rod big er	id inner diameter	55.000 ~ 55.018mm (2.1654 ~ 2.1661in)	
Connecting rod bearing	ng oil clearance	0.018 ~ 0.036mm (0.0007 ~ 0.0014in)	0
Side clearance		0.1~ 0.3mm (0.0039 ~ 0.0118in)	
Crankshaft		6—	
Main journal outer dia	رو سامانه (مسeter	64.982 ~ 65.000mm (2.5583 ~ 2.5591in)	
Pin journal outer diam	eter	51.982 ~ 52.000mm (2.0465 ~ 2.0472in)	
Main bearing oil clear	ل تعميركارن ance	0.004 ~ 0.022mm (0.0002 ~ 0.0009in)	
End play		0.10 ~ 0.28mm (0.0039 ~ 0.0110in)	
Drive plate			•
Runout		0.25mm (0.0098in)	
Oil pump			•
Relief valve opening pressure		490±49.0kpa (5±0.5kg/cm², 71±7.1psi)	
Engine oil			•
Oil quantity	Total	7.5L(7.92US qt, 6.59Imp qt)	When replacing a short engine or a block assembly
quantity	Oil pan	6.2L(6.55US qt, 5.46lmp qt)	
	Drain and refill	6.7L(7.07US qt, 5.89Imp qt)	Including oil filter

General Information

EMA-5

Description		Specifications	Limit
Recommendatio (except Middle E		5W-20/GF4&SM	If not available, refer to the recommended API or ILSAC classification and SAE viscosity number.
Oil grade	Classification	API SL, SM or above ILSAC GF3, GF4 or above	Satisfy the requirement of the API or ILS-AC classification.
	SAE viscosity grade	Recommended SAE viscosity number	Refer to the "Lubrication System"
Oil pressure (at 1000rpm)		156.91kPa (1.6kgf/cm², 22.76psi) or above	Oil temperature in oil pan : 110±2°C (230 ±35.6°F)
Cooling system			
Cooling method		Forced circulation with cooling fan	
Coolant quantity		14L (14.79US qt, 12.31Imp qt)	
Thermostat	Туре	Wax pellet type	
0170	Opening temperature	82±2°C(179.6±3.6°F)	0
417	Pull opening temperature	95°C(203°F)	
Radiator cap	Main valve openingpressure	93.16 ~ 122.58kpa (0.95 ~ 1.25kg/cm², 13.51 ~ 17.78psi)	
درو در ایران	Vacuum valve openin- gpressure	0.98 ~ 4.90 kpa (0.01 ~ 0.05kg/cm², 0.14 ~ 0.71 psi)	
Water temperature se	nsor		
Туре		Thermister type	
Resistance	20°C(68°F)	2.45±0.14 kΩ	
	80°C(176°F)	0.3222 kΩ	

Engine Mechanical System

Tightening Torques

Item	Quantity	Nm	kgf.m	lb-ft
Cylinder head				
Cylinder head cover bolt (RH)	17	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Cylinder head cover bolt (LH)	18	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Cylinder head bolt (long bolt) (LH/RH)	20	32.4 ~ 36.3+ 88° ~92°+ 118°~122°	3.3 ~ 3.7+ 88°~ 92°+ 118°~122°	23.9 ~ 26.8+ 88° ~92°+ 118°~122°
Cylinder head bolt (flange bolt) (LH/RH)	4	32.4 ~ 36.3	3.3 ~ 3.7	23.9 ~ 26.8
Camshaft bearing cap bolt (LH/RH)	44	13.7 ~ 14.7	1.4 ~ 1.5	10.1 ~ 10.8
Pressure relief valve (LH/RH)	2	21.6 ~ 25.	2.2 ~ 2.6	15.9 ~ 18.8
Ignition coil bolt (LH/RH)	8	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Spark plug (LH/RH)	8	24.5 ~ 29.4	2.5 ~ 3.0	18.1 ~ 21.7
Oil control valve bolt (LH/RH)	4	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
OCV(oil control valve) filter (LH/RH)	2	53.9 ~ 63.7	5.5 ~ 6.5	39.8 ~ 47.0
CVVT assembly fixing bolt (LH/RH)	4	73.5 ~ 83.4	7.5 ~ 8.5	54.2 ~ 61.5
Water temperature sensor wiring bracket bolt	2	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Wa <mark>te</mark> r t <mark>emp</mark> erature sensor	1	19.6 ~ 39.2	2.0 ~ 4.0	14.5 ~ 28.9
Oil pres <mark>sure</mark> switch wiring bracket bolt	2	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Oil pressure switch	منا1: ا	14.7 ~ 21.6	1.5 ~ 2.2	10.8 ~ 15.9
Timing system	5 0			
Tim <mark>ing chain l</mark> ower cover bolt	14	23.5 ~ 27.5	2.4 ~ 2.8	17.4 ~ 20.3
Timing chain upper cover (LH/RH)	14	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Timing chain guide bolt (LH/RH)	2	21.6 ~ 25.5	2.2 ~ 2.6	15.9 ~ 18.8
Tensioner adapter bolt	3	21.6 ~ 25.5	2.2 ~ 2.6	15.9 ~ 18.8
Timing chain tensioner arm bolt (LH/RH)	2	21.6 ~ 25.5	2.2 ~ 2.6	15.9 ~ 18.8
Timing chain guide mounting bolt (LH/RH)	2	21.6 ~ 25.5	2.2 ~ 2.6	15.9 ~ 18.8
Timing chain tensioner bolt (LH/RH)	2	78.5 ~ 88.3	8.0 ~ 9.0	57.9 ~ 65.1
Cam to cam guide bolt (LH/RH)	4	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Crankshaft pulley bolt	1	392.3 ~ 402.1	40.0 ~ 41.0	289.3 ~ 296.6
Drive belt tensioner bolt	2	19.6 ~ 23.5	2.0 ~ 2.4	14.5 ~ 17.4
Alternator mounting bolt	2	29.4 ~ 41.2	3.0 ~ 4.2	21.7 ~ 30.4
Alternator bracket bolt (10X50)	4	29.4 ~ 41.2	3.0 ~ 4.2	21.7 ~ 30.4
Alternator bracket bolt (8X40)	1	19.6 ~ 26.5	2.0 ~ 2.7	14.5 ~ 19.5
Cooling fan clutch	1	58.8	6.0	43.4
Cooling fan bolt	3	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Cylinder block	•			

General Information

EMA-7

Item	Quantity	Nm	kgf.m	lb-ft
Drain plug	1	96.1 ~ 100.0	9.8 ~ 10.2	70.9 ~ 73.8
Connecting rod cap bolt	16	22.6 ~ 26.5+ 98° ~102°	2.3 ~ 2.7+ 98°~ 102°	16.6 ~ 19.5+ 98° ~102°
Lower crankcase assembly bolt (main bearing cap bolt)	20	37.3 ~ 41.2+120°	3.8 ~ 4.2+120°	27.5 ~ 30.4+120°
Lower crankcase assembly bolt (flange bolt)	15	21.6 ~ 25.5	2.2 ~ 2.6	15.9 ~ 18.8
Cylinder block rear cover bolt	12	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Cylinder block bank cover bolt	12	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Drive plate bolt	8	98.1 ~ 107.9	10.0 ~ 11.0	72.3 ~ 79.6
Cooling system				
Water pump pulley bolt	4	18.6 ~ 23.5	1.9 ~ 2.4	13.7 ~ 17.4
Cooling fan pulley bolt	1	76.5 ~ 80.4	7.8 ~ 8.2	56.4 ~ 59.3
Water pump bolt	9	19.6 ~ 24.5	2.0 ~ 2.5	14.5 ~ 18.1
Water temperature control assembly bolt	4	16.7 ~ 19.6	1.7 ~ 2.0	12.3 ~ 14.5
Water outlet fitting assembly bolt	2	16.7 ~ 19.6	1.7 ~ 2.0	12.3 ~ 14.5
Water inlet pipe bolt	3	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Water outlet pipe bolt	3	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Lubrication system	.: 11			
Oil level gauge guide bolt	جيس حو	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Oil filter assembly bolt	5	19.6 ~ 23.5	2.0 ~ 2.4	14.5 ~ 17.4
Oil cooler bolt	6	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Lower oil pan bolt	16	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Upper oil pan bolt	27	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Oil pump assembly bolt	4	19.6 ~ 23.5	2.0 ~ 2.4	14.5 ~ 17.4
Oil pump sprocket bolt	1	21.6 ~ 25.5	2.2 ~ 2.6	15.9 ~ 18.8
Intake and exhaust system				
Air cleaner assembly bolt	3	9.8 ~ 11.8	1.0 ~ 1.2	7.2 ~ 8.7
Intake manifold module nut	10	19.6 ~ 26.5	2.0 ~ 2.7	14.5 ~ 19.5
Exhaust manifold nut (LH/RH)	24	49.0 ~ 53.9	5.0 ~ 5.5	36.2 ~ 39.8
Exhaust manifold heat protector bolt (LH/RH)	6	8.8 ~ 10.8	0.9 ~ 1.1	6.5 ~ 8.0
Front muffler nut (LH/RH)	8	39.2 ~ 58.8	4.0 ~ 6.0	28.9 ~ 43.4
Main muffler nut	6	39.2 ~ 58.8	4.0 ~ 6.0	28.9 ~ 43.4
Tail pipe nut	2	39.2 ~ 58.8	4.0 ~ 6.0	28.9 ~ 43.4
Engine mounting				
Engine mounting bracket and engine fixing bolt (LH/RH)	8	49.0 ~ 63.7	5.0 ~ 6.5	36.2 ~ 47.0

Engine Mechanical System

Item	Quantity	Nm	kgf.m	lb-ft
Engine mounting insulator and engine mounting bracket fixing nut (LH/RH)	2	88.3 ~ 107.9	9.0 ~ 11.0	65.1 ~ 79.6
Engine mounting insulator and frame fixing nut (LH/RH)	6	49.0 ~ 63.7	5.0 ~ 6.5	36.2 ~ 47.0
Transmission mounting insulator and transmission fixing bolt	4	49.0 ~ 63.7	5.0 ~ 6.5	36.2 ~ 47.0
Transmission mounting insulator and frame fixing nut	4	29.4 ~ 39.2	3.0 ~ 4.0	21.7 ~ 28.9





General Information


EMA-9


Compression Pressure Inspection

MOTICE


If the there is lack of power, excessive oil consumption or poor fuel economy, measure the compression pressure.

- 1. Warm up engine to normal operating temperature(80~95°C(176-203°F)).
- 2. Remove the ignition coil connectors (A) and ignition coils (B).






SHMM19337N



SHMM19338N



3. Remove the spark plugs.

Using a 16mm plug wrench, remove the 8 spark plugs.

- 4. Check cylinder compression pressure.
 - 1) Insert a compression gauge into the spark plug hole.
 - 2) Fully open the throttle.
 - 3) Crank the engine over 7 times to measure compression pressure.

MOTICE

Always use a fully charged battery to obtain engine speed of 250 rpm or more.

Engine Mechanical System

4) Repeat step 1) though 3) for each cylinder.

MNOTICE

This measurement must be done in as short a time as possible.

Compression pressure:

1,078kPa (11.0kg/cm², 156psi)

Minimum pressure:

931kPa (9.5kg/cm², 135psi)

Difference between each cylinder:

98kPa (1.0kg/cm², 14psi) or less

- 5) If the cylinder compression in 1 or more cylinders is low, pour a small amount of engine oil into the cylinder through the spark plug hole and repeat step 1) through 3) for cylinders with low compression.
 - If adding oil helps the compression, it is likely that the piston rings and/or cylinder bore are worn or damaged.
 - If pressure stays low, a valve may be sticking or seating is improper, or there may be leakage past the gasket.
- 5. Reinstall the spark plugs.
- 6. Install the ignition coils and ignition connectors.

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران



General Information

EMA-11

Troubleshooting

Symptom	Suspect area	Remedy
Engine misfire with abnormal internal I-ower engine noises.	Worn crankshaft bearings. Loose or damaged engine drive plate.	Replace the crankshaft and bearings as required. Repair or replace the drive plate as required.
	Worn piston rings. (Oil consumption may or may not cause the engine to misfire.)	Inspect the cylinder for a loss of compression.Repair or replace as required.
	Worn crankshaft thrust bearings	Replace the crankshaft and bearings as required.
Engine misfire with abnormal valve tra- in noise.	Stuck valves. (Carbon buildup on the valve stem)	Repair or replace as required.
	Excessive worn or mis-aligned timing chain.	Replace the timing chain and sprocket as required.
	Worn camshaft lobes.	Replace the camshaft and valve lifters.
ر محارم	HLA sponge	Run the engine at 2500~3000rpm within 15 minutes. If it dosen't disappear, refer to cylinder head assembly in this group.
Engine misfire with coolant consumption.	 Faulty cylinder head gasket and/or cranking or other damage to the cylinder head and engine block cooling system. Coolant consumption may or may not cause the engine to overheat. 	 Inspect the cylinder head and engine block for damage to the coolant passages and/or a faulty head gasket. Repair or replace as required.
Engine misfire with excessive oil consumption.	Worn valves, guides and/or valve stem oil seals.	Repair or replace as required.
	Worn piston rings. (Oil consumption may or may not cause the engine to misfire)	 Inspect the cylinder for a loss of compression. Repair or replace as required.
Engine noise on start-up, but only lasting a few seconds.	Incorrect oil viscosity.	Drain the oil.Install the correct viscosity oil.
	Worn crankshaft thrust bearing.	Inspect the thrust bearing and crankshaft.Repair or replace as required.

Engine Mechanical System

Symptom	Suspect area	Remedy
Upper engine noise, regardless of eng-	Low oil pressure.	Repair or replace as required.
ine speed.	Broken valve spring.	Replace the valve spring.
	Worn or dirty valve lifters.	Replace the valve lifters.
	Stretched or broken timing chain and/ or damaged sprocket teeth.	Replace the timing chain and sprockets.
	Worn timing chain tensioner, if applicable.	Replace the timing chain tensioner as required.
	Worn camshaft lobes.	 Inspect the camshaft lobes. Replace the timing camshaft and valve lifters as required.
	Worn valve guides or valve stems.	Inspect the valves and valve guides, then repair as required.
	Stuck valves.Carbon on the valve stem or valve seat may cause the valve to stay open.	Inspect the valves and valve guides, then repair as required.
•	Worn drive belt, idler, tensioner and bearing.	Replace as required.
Lower engine noise, regardless of eng-	Low oil pressure.	Repair as required.
ine speed.	Loose or damaged drive plate.	Repair or replace the drive plate.
امانه (مسئولیت محدود)	Damaged oil pan, contacting the oil pump screen.	Inspect the oil pan.Inspect the oil pump screen.Repair or replace as required.
میرکاران خودرو در ایران	Oil pump screen loose, damaged or restricted.	Inspect the oil pump screen.Repair or replace as required.
	Excessive piston-to-cylinder bore clearance.	 Inspect the piston, piston pin and c-ylinder bore. Repair as required.
	Excessive piston pin-to-piston clearance.	 Inspect the piston, piston pin and the connecting rod. Repair or replace as required.
	Excessive connecting rod bearing clearance	Inspect the following components and repair as required. The connecting rod bearings. The connecting rods. The crankshaft pin journals.
	Excessive crankshaft bearing clearance.	Inspect the following components, and repair as required. The crankshaft bearings. The crankshaft main journals. The cylinder block.
	Incorrect piston, piston pin and connecting rod installation	 Verify the piston pins and connecting rods are installed correctly. Repair as required.

General Information

EMA-13

Symptom	Suspect area	Remedy
Engine noise under load.	Low oil pressure	Repair or replace as required.
	Excessive connecting rod bearing clearance.	Inspect the following components and repair as required: The connecting rod bearings. The connecting rods. The crankshaft.
	Excessive crankshaft bearing clearance.	Inspect the following components, and repair as required. The crankshaft bearings. The crankshaft main journals. The cylinder block.
Engine will not crank-crankshaft will not rotate.	Hydraulically locked cylinder.Coolant/antifreeze in cylinder.Oil in cylinder.Fuel in cylinder.	 Remove spark plugs and check for fluid. Inspect for broken head gasket. Inspect for cracked engine block or cylinder head. Inspect for a sticking fuel injector and/or leaking fuel regulator.
	Broken timing chain and/or timing chain and/or timing chain gears.	Inspect timing chain and gears.Repair as required.
مانه (مسئولیت محدود)	Material in cylinder. • Broken valve • Piston material • Foreign material	 Inspect cylinder for damaged components and/or foreign materials. Repair or replace as required.
میرکاران خودرو در ایران	Seized crankshaft or connecting rod bearings.	 Inspect crankshaft and connecting rod bearing. Repair as required.
	Bent or broken connecting rod.	Inspect connecting rods.Repair as required.
	Broken crankshaft.	Inspect crankshaft.Repair as required.

Engine Mechanical System

Special Service Tools

Tool (Number and name)	Illustration	Use
Crankshaft front oil seal installer (09231-2J300) (09231-H1100)	09231-H1100 09231-2J300	Installation of the front oil seal
	SHMM19367N	
Flywheel stopper (09231-2B100)		Removal and installation of the flywheel and crankshaft pulley
	SHDEM6201D	
Torque angle adapter (09221-4A000)	LCAC030A	Installation of bolts & nuts needing an angular method
Valve stem seal remover (09222-29000)	KDRF232A	Removal of the valve stem seal
Valve stem seal installer (09222-28200)		Installation of the valve stem seal
	SHMM19368N	

General Information

EMA-15


Tool (Number and name)	Illustration	Use
Valve spring compressor & holder (09222-3K000) (09222-3C300)	A	Removal and installation of the intake or exhaust valves A: 09222-3K000 B: 09222-3C300 (holder)
	ECRF003A	
Crankshaft rear oil seal installer (09231-2J400) (09231-H1100)	09231-H1100 09231-2J400	Installation of the crankshaft rear oil seal
	SHMM19369N	
Oil pan remover (09215-3C000)	ACJF125A	Removal of oil pan
Oil seal installer	شردت ديجينال حودرو ساما	Installation of the cylinder head cover oil
(09231-2J500) (09231-H1100)	09231-H1100 09231-2J500	seal & timing chain upper cover oil seal.
	SHMM19370N	
Timing chain locking tool (09231-2J600)		Holds the timing chain with timing chain guide & timing chain tensioner arm during installation.
	SHMM19371N	

Engine Mechanical System

Engine And Transaxle Assembly

Engine Mounting

Components



SHMM19372N

- 1. Engine support bracket LH
- 2. Engine support bracket RH

3. Engine mounting insulator

Engine And Transaxle Assembly

EMA-17

Engine And Transaxle Assembly


Removal

ACAUTION

- Use fender covers to avoid damaging painted surfaces.
- To avoid damage, unplug the wiring connectors carefully while holding the connector portion.


MOTICE

- Mark all wiring and hoses to avoid misconnection.
- 1. First, remove the transmission before removing the engine. (Refer to AT group)
- 2. Remove the bonnet. (Refer to BD group)
- 3. Remove the cowl cover and wiper arm. (Refer to BE group)
- 4. Disconnect the negative terminal from the battery.




SHMM19043N

5. Remove the engine cover (A).




SHMM19044N

6. Remove the radiator grill upper guard (A).



SHMM19045N


7. Loosen the drain plug (A) and drain the engine coolant.



SHMM19046N

Engine Mechanical System

Remove the radiator cap (A) to speed draining.




SHMM19047N

WARNING


Never remove the radiator cap when the engine is hot. Serious scalding could be caused by hot fluid under high pressure escaping from the radiator.

- 8. Recover refrigerant. (Refer to Air conditioner compressor in HA Group)
- 9. Remove the air duct (A) and the air cleaner assembly (B).




SHMM19048N

10. Disconnect the radiator upper hose (A) and lower hose (B).




SHMM19049N

11. Remove the radiator upper shroud (A).



SHMM19050N

12. Remove the cooling fan (A).




SHMM19051N

Engine And Transaxle Assembly

EMA-19


13. Remove the cooling fan clutch (A).



SHMM19052N


MNOTICE

Remove the cooling fan clutch (A) after fixing the cooling fan pulley (B) by inserting a pin (C) into the hole of it.




SHMM19053N

14. Disconnect the heater hoses (A), the fuel hose (B) and the purge control solenoid valve (PCSV) hose (C).



SHMM19054N


- 15. Remove the engine wire harness from the fuse and relay block.
 - 1) Remove the ECM connector (B) and the fuse and relay block cover (A).



SHMEM8008D


Engine Mechanical System

- 2) Remove the connectors (A) and the cable (B) from the fuse and relay block (C).
- 3) Remove the fuse and relay block (C).




SHMM19055N

4) Remove the fuse and relay block connector (A) and the multi connector (B).




SHMM19310N

5) Remove the fuse and relay block lower cover (A).




SHMM19056N

6) Remove the connector (A) from the fuse and relay block lower cover bracket.



SHMM19057N

7) Remove the earth cable (A) and the harness protector (B).




SHMM19311N

Engine And Transaxle Assembly


EMA-21

16. Remove the power steering pump pressure switch connector (A).




SHMM19058N

17. Remove the cable (A) from the battery.




SHMM19155N

18. Remove the air conditioner high pressure pipe (A). (Refer to HA group)




SHMM19059N



SHMM19060N


Engine Mechanical System




Engine And Transaxle Assembly

EMA-23

21. Remove the exhaust manifold (A).




SHMM19063N




22. Remove the engine mounting bracket nuts (A) and the earth cable (B).

Tightening torque:

 $49.0 \sim 63.7 \text{Nm}$ (5.0 $\sim 6.5 \text{kgf.m}$, $36.2 \sim 47.0 \text{lb-ft}$)



SHMM19065N



SHMM19066N

23. Remove the engine assembly from the vehicle by using hoist.

MNOTICE

When removing the engine assembly, be careful not to damage any surrounding parts or body components.

Engine Mechanical System

Installation

Installation is in the reverse order of removal.

Perform the following:

- · Adjust the shift cable.
- · Refill engine with engine oil.
- · Refill transaxle with fluid.
- Clean the battery posts and cable terminals with sandpaper assemble them, then apply grease to prevent corrosion.
- · Inspect for fuel leakage.
 - After assembling the fuel line, turn on the ignition switch (do not operate the starter) so that the fuel pump runs for approximately two seconds and fuel line pressurizes.
 - Repeat this operation two or three times, then check for fuel leakage at any point in the fuel lines.
- · Refill radiator with engine coolant.
- Bleed air from the cooling system.
 - Start engine and let it run until it warms up. (Until the radiator fan operates 3 or 4 times.)
 - Turn Off the engine. Check the level in the radiator, add coolant if needed. This will allow trapped air to be removed from the cooling system.
 - Put radiator cap on tightly, then run the engine again and check for leaks.



Cylinder Head Assembly


EMA-25

Cylinder Head Assembly

Cylinder Head

Components

[RH]




SHMM19326N

- 1. Cylinder head cover
- 2. Cylinder head cover oil seal
- 3. Cylinder head cover gasket
- 4. Exhaust CVVT assembly
- 5. Exhaust camshaft
- 6. Intake CVVT assembly
- 7. Intake camshaft
- 8. Cam to cam guide

- 9. Camshaft thrust bearing cap
- 10. Camshaft bearing cap
- 11. Pressure relief valve
- 12. Timing chain tensioner
- 13. Oil control valve
- 14. OCV filter
- 15. Roller finger follower
- 16. Hydraulic lash adjuster assembly
- 17. Valve spring retainer
- 18. Valve spring retainer lock
- 19. Valve spring
- 20. Valve stem seal
- 21. Valve
- 22. Cylinder head
- 23. Cylinder head gasket

Engine Mechanical System



SHMM19327N

- 1. Cylinder head cover
- 2. Cylinder head cover oil seal
- 3. Cylinder head cover gasket
- 4. Exhaust CVVT assembly
- 5. Exhaust camshaft
- 6. Intake CVVT assembly
- 7. Intake camshaft
- 8. Cam to cam guide

- 9. Camshaft thrust bearing cap
- 10. Camshaft bearing cap
- 11. Pressure relief valve
- 12. Timing chain tensioner
- 13. Oil control valve
- 14. OCV filter
- 15. Roller finger follower
- 16. Hydraulic lash adjuster assembly
- 17. Valve spring retainer
- 18. Valve spring retainer lock
- 19. Valve spring
- 20. Valve stem seal
- 21. Valve
- 22. Cylinder head
- 23. Cylinder head gasket

Cylinder Head Assembly

EMA-27


Removal

ACAUTION

- Use fender covers to avoid damaging painted surfaces.
- To avoid damaging the cylinder head, wait until the engine coolant temperature drops below normal operating temperature before removing it.
- When handling a metal gasket, take care not to fold the gasket or damage the contact surface of the gasket.
- To avoid damage, unplug the wiring connectors carefully while holding the connector portion.


MOTICE

- Mark all wiring and hoses to avoid misconnection.
- Turn the crankshaft pulley so that the No. 1 piston is at top dead center.
- 1. Disconnect the negative terminal from the battery.




SHMM19043N

2. Remove the engine cover (A).




SHMM19044N

3. Loosen the drain plug (A) and drain the engine coolant.



SHMM19046N

Remove the radiator cap (A) to speed draining.




SHMM19047N

WARNING

Never remove the radiator cap when the engine is hot. Serious scalding could be caused by hot fluid under high pressure escaping from the radiator.


Engine Mechanical System

4. Remove the air duct (A) and the air cleaner assembly (B).




SHMM19048N

5. Disconnect the radiator upper hose (A) and lower hose (B).




SHMM19049N

6. Disconnect the heater hoses (A), the fuel hose (B) and the purge control solenoid valve (PCSV) hose



SHMM19054N

7. Remove the cooling fan (A).




SHMM19051N

Cylinder Head Assembly

EMA-29


8. Remove the cooling fan clutch (A).



SHMM19052N


MNOTICE

Remove the cooling fan clutch (A) after fixing the cooling fan pulley (B) by inserting a pin (C) into the hole of it.




SHMM19053N

9. Turn the tensioner (B) clockwise and loosen, then remove the drive belt (A).



SHMM19067N


10. Remove the drive belt tensioner (A).



SHMM19068N


Engine Mechanical System

- 11. Remove the engine wiring harness from the cylinder head.
 - Disconnect the water temperature sensor connector (A) and the CVVT oil control valve connectors (B).




SHMM19069N

2) Disconnect the ETC module connector (A).




SHMM19070N

3) Disconnect the PCSV connector (A) and the injector connectors (B).



SHMM19071N

4) Disconnect the ignition coil connectors (A) and the wiring harness protector (B).




SHMM19072N

Cylinder Head Assembly


EMA-31

5) Disconnect the knock sensor connectors (A), the camshaft position sensor connectors (B), the oxygen sensor connector (C) and the condenser connector (D).




SHMM19073N

6) Disconnect the variable intake system solenoid valve connector (A) and the wiring harness protector (B).




SHMM19074N

7) Disconnect the knock sensor connectors (A), the camshaft position sensor connectors (B), the crankshaft position sensor connector (C), the oxygen sensor connector (D) and the condenser connector (E).



SHMM19075N


8) Disconnect the injector connectors (A).



SHMM19076N


Engine Mechanical System

9) Disconnect the ignition coil connectors (A) and the wiring harness protector (B).



SHMM19077N


10) Disconnect the oil pressure switch connector (A), the CVVT oil control valve connectors (B) and the air conditioner compressor switch connector (C).




SHMM19078N

SHMM19001N


12. Remove the oil level gauge (A).



13. Disconnect the oxygen sensor connector (A) and remove the oxygen sensor connector bracket (B).



SHMM19079N




SHMM19080N


Cylinder Head Assembly

EMA-33

14. Remove the exhaust manifold heat protector (A).




SHMM19002N




SHMM19003N

15. Remove the exhaust manifold (A).




SHMM19063N




SHMM19064N


16. Disconnect the PCV hose (A), the PCSV hose (B) and the water hoses (C) from the intake manifold module and the throttle body.




SHMM19081N


Engine Mechanical System






SHMM19082N









SHMM19009N

19. Remove the ignition coils (A).



SHMM19010N




SHMM19011N


Cylinder Head Assembly

EMA-35


20. Remove the cylinder head cover (A).




SHMM19012N



21. Remove the cylinder head cover gasket (A) and oil seal (B).




SHMM19016N



SHMM19017N


22. Remove the oil pressure switch wiring assembly and bracket (A).



SHMM19083N


Engine Mechanical System

23. Remove the water temperature sensor wiring assembly and bracket (A).




SHMM19019N

24. Remove the timing chain upper cover (A).




SHMM19020N




SHMM19021N

25. Remove the timing chain upper cover oil seal (A).




SHMM19022N




Cylinder Head Assembly

EMA-37

26. Remove the oil control valve (A).




SHMM19024N



SVIM19146D

27. Remove the cam to cam guide (A).




SHMM19025N



MOTICE

- Do not reuse the OCV when dropped.
- Keep the OCV clean.
- Do not hold the OCV sleeve (A) during servicing.
- When the OCV is installed on the engine, do not move the engine while holding the OCV yoke.




SHMM19027N

Engine Mechanical System


28. Align the timing mark of camshaft sprocket.

[LH]



SHMM19028N

[RH]




SHMM19029N

MOTICE


In case that the timing system has been disassembled wholly, the timing chain can be installed with all of chain installation mark of the sprocket and timing marked chain links aligned without additional marking. However, in case of on-vehicle repair (for cylinder head assembly, timing chain tensioner, CVVT, camshaft, HLA or etc.), which is not necessary to remove the timing chain completely, mark the timing chain corresponding to the chain installation marks on the sprocket with an identification when the No.1 piston is at TDC position because it is very difficult to align all of the chain installation mark of the sprocket and the timing marked chain links.

29. Remove the alternator (A).



SHMM19030N


30. Remove the water outlet pipe (A) and the water inlet pipe (B).



SHMM19084N

MNOTICE


Remove the drain plug (A) and drain the engine coolant.



EMA-39


SHMM19085N

31. Remove the water temperature control assembly (A) and the water outlet fitting assembly (B).




SHMM19033N


32. Remove the timing chain tensioner (A).



33. Remove the camshaft bearing caps (A) and the camshaft thrust bearing cap (B).




SHMM19036N



SHMM19037N







SHMM19035N

Engine Mechanical System

34. Remove the camshaft and CVVT assembly (A).




SHMM19160N




SHMM19161N

35. Remove the roller finger follower and the hydraulic lash adjuster assembly (A).




SHMM19040N

- 36. Remove the cylinder head (A).
 - 1) Uniformly loosen and remove the cylinder head bolts, in several passes, in the sequence shown.



SHMM19041N




SHMM19042N

EMA-41

WNOTICE


Head warpage or cracking could result from removing bolts in an incorrect order.

[RH]



SHMM19349N

[LH]




SVIM19121D


2) Lift the cylinder head from the dowels on the cylinder block and place the cylinder head on wooden blocks on a bench.

WNOTICE

Be careful not to damage the contact surfaces of the cylinder head and cylinder block. 37. Remove the cylinder head gasket (A).




SHMM19359N



Engine Mechanical System


Disassembly

1. Remove the roller finger follower and the hydraulic lash adjuster assembly (A).



SHMM19040N

- 2. Remove the valves.
 - 1) Using the SST(09222-3K000, 09222-3C300), compress the valve spring and remove retainer




- 3) Remove the valve spring.
- 4) Remove the valve.
- 5) Remove the valve stem seal.

MOTICE


Do not reuse old valve stem seals.

3. Remove the OCV filter(A).

[LH]








SHMM19119N

EMA-43

[RH]



SHMM19122N

4. Remove the pressure relief valve.



SHMM19312N


Inspection Cylinder Head

1. Inspect for flatness.

Using a precision straight edge and feeler gauge, measure the surface contacting cylinder block and the manifolds for warpage.

Flatness of cylinder head gasket surface

Standard: Less than 0.05mm(0.002in) [Less than 0.02mm(0.0008in)/100x100] Flatness of manifold gasket surface Standard: Less than 0.1mm(0.004in) [Less than 0.03mm(0.0012in)/110x110]



Inspect for cracks.

Check the combustion chamber, intake ports, exhaust ports and cylinder block surface for cracks. If cracked, replace the cylinder head.

Engine Mechanical System


Valve And Valve Spring

- 1. Inspect valve stems and valve guides.
 - 1) Using a caliper gauge, measure the inside diameter of the valve guide.

Valve guide I.D.

Intake / Exhaust :

 $6.000 \sim 6.012$ mm (0.2362 ~ 0.2367 in)



ECBF034A

 Using a micrometer, measure the diameter of the valve stem.

Valve stem O.D.

Intake : $5.965 \sim 5.980$ mm ($0.2348 \sim 0.2354$ in) Exhaust : $5.958 \sim 5.970$ mm ($0.2346 \sim 0.2350$ in)



KCRF227A

 Subtract the valve stem diameter measurement from the valve guide inside diameter measurement.

Valve stem-to-guide clearance

Intake : $0.020 \sim 0.047$ mm ($0.0008 \sim 0.0018$ in) Exhaust : $0.030 \sim 0.054$ mm ($0.0012 \sim 0.0021$ in)

- 2. Inspect valves.
 - 1) Check the valve is ground to the correct valve face angle.


Valve face angle:

Intake/Exhaust: 45.25°~ 45.75°

- 2) Check that the surface of the valve for wear. If the valve face is worn, replace the valve.
- 3) Check the valve head margin thickness. If the margin thickness is less than minimum, replace the valve.

Margin

Intake : 1.2mm (0.0472in) Exhaust : 1.2mm (0.0472in)



4) Check the valve length.

Length

Intake : 107.77mm (4.2429in) Exhaust : 107.75mm (4.2421in)

5) Check the surface of the valve stem tip for wear.If the valve stem tip is worn, replace the valve.

EMA-45

- 3. Inspect valve seats.
 - Check the valve seat for evidence of overheating and improper contact with the valve face.
 - If the valve seat is worn, replace cylinder head.
 - Before reconditioning the seat, check the valve guide for wear. If the valve guide is worn, replace cylinder head.
 - Recondition the valve seat with a valve seat grinder or cutter. The valve seat contact width should be within specifications and centered on the valve face.

Valve seat contact width:

Intake : 1.15 $^{\sim}$ 1.45mm (0.0453 $^{\sim}$ 0.0571in) Exhaust : 1.35 $^{\sim}$ 1.65mm (0.0531 $^{\sim}$ 0.0650in)

Valve seat angle :


Intake/Exhaust: 44.75°~ 45.10°

- 4. Inspect valve springs.
 - 1) Using a steel square, measure the out-of-square of the valve spring.
 - Using vernier calipers, measure the free length of the valve spring.

Valve spring

Free height: 47.8mm (1.8819in)

Out-of-square: 1.5°



KCRF205A


Camshaft

1. Inspect cam lobes.

Using a micrometer, measure the cam lobe height.

Cam height


Intake: 41.6mm (16.4in) Exhaust: 41.5mm (16.3in)



KCRF206A

If the cam lobe height is less than standard, replace the camshaft.

- 2. Inspect the camshaft journal clearance.
 - 1) Clean the bearing caps and camshaft journals.
 - 2) Place the camshafts on the cylinder head.
 - Lay a strip of plastigage across each of the camshaft journals.



SAMM29101I

Engine Mechanical System

4) Install the bearing cap (A) and thrust bearing cap(B) with specified torque.

Tightening torque:

1st step:

 $6.9 \sim 7.8$ N.m (0.7 ~ 0.8 kgf.m, $5.1 \sim 5.8$ lb-ft)


2nd step:

 $13.7 \sim 14.7$ N.m ($1.4 \sim 1.5$ kgf.m, $10.1 \sim 10.8$ lb-ft)

MOTICE


Do not turn the camshaft.

[LH]



SHMM19036N

[RH]



SHMM19037N

5) Remove the bearing caps.

6) Measure the plastigage at its widest point.

Camshaft bearing oil clearance

Intake/Exhaust:

No.1 journal:

 $0.025 \sim 0.057$ mm (0.0010 ~ 0.0022 in)

No.2, 3, 4, 5 journal:

 $0.020 \sim 0.057$ mm ($0.0008 \sim 0.0022$ in)

Camshaft journal outer diameter

Intake/Exhaust:

No.1 journal:

 $35.964 \sim 35.980$ mm (1.4159 ~ 1.4165 in)

No.2, 3, 4, 5 journal:

25.964 ~ 25.980mm (1.0222 ~ 1.0228in)

Camshaft journal bore inner diameter


Intake/Exhaust:

No.1 journal:

36.005 ~ 36.021mm (1.4175 ~ 1.4181in)

No.2, 3, 4, 5 journal:

26.000 ~ 26.021mm (1.0236 ~ 1.0244in)



SAMM29102L

If the oil clearance is greater than maximum, replace the camshaft. If necessary, replace cylinder head.

- 7) Completely remove the plastigage.
- 8) Remove the camshafts.

EMA-47

- 3. Inspect the camshaft end play.
 - 1) Install the camshafts.
 - 2) Install the bearing cap (A) and thrust bearing cap(B) with specified torque.


Tightening torque:

1st step:

 $6.9 \sim 7.8$ N.m (0.7 ~ 0.8 kgf.m, $5.1 \sim 5.8$ lb-ft)

2nd step:

 $13.7 \sim 14.7$ N.m ($1.4 \sim 1.5$ kgf.m, $10.1 \sim 10.8$ lb-ft)




SHMM19037N


3) Using a dial indicator, measure the end play while moving the camshaft back and forth.

Camshaft end play:

 $0.12 \sim 0.22$ mm (0.0047 ~ 0.0086 in)



SHMM19301N



SHMM19302N


If the end play is greater than maximum, replace the camshaft. If necessary, replace cylinder head.

4) Remove the camshafts.

Engine Mechanical System

CVVT Assembly

- 1. Inspect the CVVT assembly.
 - 1) Check that the CVVT assembly will not turn.
 - 2) Apply vinyl tape to the retard hole except the one indicated by the arrow in the illustration.
 - 3) Apply vinyl tape to the advance holde except the one indicated by the arrow in the illustration.



SHMM19124N

4) Wrap tape around the tip of the air gun and apply air of approx. 150kpa(1.5kgf/cm², 21psi) to the port of the camshaft. (Perform this in order to release the lock pin for the maximum default angle locking.)

In-default : Max retard
Ex-default : Max advance

MOTICE


When the oil splashes, wipe it off with a shop rag.

5) Under the condition of (3), turn the In-CVVT assembly to the advance angle side (the arrow marked direction in the illustration) with your hand.

Depending on the air pressure, the In-CVVT assembly will turn to the advance side without applying force by hand.

Under the condition of (3), turn the Ex-CVVT assembly to the retard angle side (the arrow marked direction in the illustration) with your hand.

Depending on the air pressure, the Ex-CVVT assembly will turn to the retard side without applying force by hand.



SGHEM7010N

6) Except the position where the lock pin meets at the maximum default angle, let the CVVT assembly turn back and forth and check the movable range and that there is no interference.

Standard:

Movable smoothly in the range about 22.5°


7) Turn the In-CVVT assembly with your hand and lock it at the maximum retard angle position (clockwise).

Turn the Ex-CVVT assembly with your hand and lock it at the maximum advance angle position.

EMA-49

HLA (Hydraulic Lash Adjuster)

With the HLA filled with engine oil, hold A and press B by hand. If B moves, replace the HLA.



EDB9030D

Problem	Possible cause	Action
Temporary noise when starting a cold engine	Normal	This noise will disappear after the oil in the engine reaches the normal pressure.
2. Continuous noise when the engine is started after parking more than 48 hours.	Oil leakage of the high pressure chamber on the HLA, allowing air to get in.	when engine runs at 2000-3000 rpm.If it doesn't disappear, refer to step 7 below.
3. Continuous noise when the engine is first started after rebuilding cylinder head.		
4. Continuous noise when the engine is started after excessively cranking the engine by the starter motor or band.	Oil leakage of the high-pressure chamber in the HLA, allowing air to get in.Insufficient oil in the HLA.	
5. Continuous noise when the engine is running after changing the HLA.		⚠CAUTION Do not run engine at a speed higher than 3000 rpm, as this may damage the HLA.
6. Continuous noise during idle after high engine speed.	Engine oil level too high or too low.	Check oil level.Drain or add oil as necessary.
	Excessive amount of air in the oil at high engine speed.	Check oil supply system.
	Deteriorated oil.	Check oil quality.lf deteriorated, replace with specified type.
7. Noise continues for more than 15 m-inutes.	Low oil pressure.	Check oil pressure and oil supply system of each part of engine.
	Faulty HLA.	Remove the cylinder head cover and press HLA down by hand. If it moves, replace the HLA. WARNING Be careful with the hot HLAS.

Engine Mechanical System

Reassembly


MNOTICE

- Thoroughly clean all parts to be assembled.
- Before installing the parts, apply fresh engine oil to all sliding and rotating surfaces.
- · Replace oil seals with new ones.
- 1. Install the OCV filter(A).

Tightening torque:


 $53.9 \sim 63.7$ Nm($5.5 \sim 6.5$ kgf.m, $39.8 \sim 47.0$ lb-ft)

[LH]



SHMM19121N






SHMM19122N

2. Install the valves.

1) Using the SST(09222-28200), push in a new oil seal.

MOTICE

- · Do not reuse old valve stem seals.
- Incorrect installation of the seal could result in oil leakage past the valve guides.




SHMM19125N

2) Install the valve, valve spring and spring retainer.

MOTICE

Place valve springs so that the side coated with enamel faces toward the valve spring retainer and then install the retainer.


3) Using the SST(09222 - 3K000, 09222-3C300), compress the spring and install the retainer locks. After installing the valves, ensure that the retainer locks are correctly in place before releasing the valve spring compressor.



SHMM19119N

EMA-51

- 4) Lightly tap the end of each valve stem two or three times with the wooden handle of a hammer to ensure proper seating of the valve and retainer lock
- 3. Install the roller finger follower and the hydraulic lash adjuster assembly (A).




SHMM19040N

- 1) Until installing HLA shall be held upright so that engine oil in HLA should not spill and assured that dust does not adhere to HLA.
- 2) HLA shall be inserted tenderly to the cylinder head not to spill engine oil from HLA. In case of spilling, air vent shall be done in accordance with the air bent procedure.

MOTICE

Stroke HLA in engine oil 4~5 times by pushing its cap while pushing the ball down slightly by hard steel wire.

(Take care not to severely push hard steel wire down since ball is several grames.)




LCGF133A

4. Install the pressure relief valve.

Tightening torque:

 $21.6 \sim 25.5 \text{Nm} (2.2 \sim 2.6 \text{kgf.m}, 15.9 \sim 18.8 \text{lb-ft})$



SHMM19312N



Installation

MNOTICE

- Thoroughly clean all parts to be assembled.
- Always use a new head and manifold gasket.
- The cylinder head gasket is a metal gasket. Take care not to bend it.
- Rotate the crankshaft, set the No.1 piston at TDC.
- 1. Install the cylinder head gasket (A).
 - 1) The sealant locations on cylinder head gasket, cylinder block and timing chain lower case must be free of engine oil and ETC.
 - 2) Before assembling the cylinder head gasket, the liquid sealant TB 1217H should be applied on the gap between cylinder block and timing chain lower case.

The part must be assembled within 5 minutes after sealant was applied.

MOTICE

Refer to below illustration to apply the sealant.

Bead width:


 $3.5 \sim 4.5 \text{ mm} (0.1378 \sim 0.1772 \text{ in})$

Sealant locations:

 $1.5 \sim 2.5$ mm (0.0591 ~ 0.0984 in)


from timing chain lower case inner surface

Recommended sealant: Liquid sealant TB1217H




SHMM19150N

Engine Mechanical System



SHMM19162N



3) Apply sealant on cylinder head gaskets after assembling cylinder head gaskets on cylinder

The part must be assembled within 5 minutes after sealant was applied.

MOTICE


Be careful of the installation direction.

EMA-53


4) Install the cylinder head.

MOTICE

Remove the extruded sealant after assembling cylinder heads.



SHMM19041N



SHMM19042N

- 2. Install the cylinder head bolts.
 - 1) Do not apply engine oil on the threads and under the heads of the cylinder head bolts.
 - 2) Using SST(09221-4A000), install and tighten the cylinder head bolts and plate washers, in several passes, in the sequence shown.

Tightening torque:


Cylinder head bolts (1~10):


32.4 \sim 36.3N.m(3.3 \sim 3.7kgf.m, 23.9 \sim 26.8lb-ft) + 88 $^{\circ}$ \sim 92 $^{\circ}$ + 118 $^{\circ}$ \sim 122 $^{\circ}$

Flange bolts (11~12):

 $32.4 \sim 36.3$ N.m $(3.3 \sim 3.7$ kgf.m, $23.9 \sim 26.8$ lb-ft)


[RH]





SHMM19149N

Engine Mechanical System



SHMM19313N


SHMM19314N



Install the CVVT assembly.


Tightening torque:

 $73.5 \sim 83.4$ N.m $(7.5 \sim 8.5$ kgf.m, $54.2 \sim 61.5$ lb-ft)



SHMM19373N


- Install camshaft to dowel pin of CVVT assembly.At this time, attend not to be installed to oil hole of camshaft.
- Hold the hexagonal head wrench portion of the camshaft with a vise, and install the bolt and CVVT assembly.
- Do not rotate CVVT assembly when camshaft is installed to dowel pin of CVVT assembly.
- 4. Install the roller finger follower and the hydraulic lash adjuster assembly (A).




SHMM19040N

EMA-55

5. Install the LH/RH camshaft assembly (A).




SHMM19160N




6. Install the timing chain to the camshaft sprocket.

SHMM19028N




SHMM19161N



SHMM19029N

MOTICE

- Apply a light coat of engine oil on camshaft journals.
- Assemble the timing mark of CVVT to the same level of cylinder head top surface.
- Be careful the right, left bank, intake, exhaust side before assembling.
- Turn the crankshaft to set the No.1 piston at TDC position.



SHMM19128N

Engine Mechanical System

MOTICE

- · Make sure the crankshaft is at TDC position.
- Align the chain installation mark (A) of the crankshaft sprocket and the timing mark (A) of the chain link, and then install the chain.

MNOTICE

In case of marking the timing chain links corresponding to the chain installation marks on the sprocket with an identification for on-vehicle repair (for cylinder head assembly, timing chain tensioner, CVVT, camshaft, HLA or etc.), align all of the chain installation mark of the sprocket and the timing marked chain links for reassembly.

MNOTICE


To install the timing chain with no slack between each shaft (cam, crank), follow the below procedure.

Crankshaft sprocket → Timing chain guide → Exhaust camshaft sprocket → Intake camshaft sprocket. (LH Bank)


Crankshaft sprocket → Timing chain guide → Intake camshaft sprocket → Exhaust camshaft sprocket. (RH Bank)

When reassembling the timing chain, make sure all of the chain installation mark of the sprocket and the timing marked chain links are aligned.

7. Install the camshaft bearing caps and the camshaft thrust bearing cap.



SHMM19036N



SHMM19037N

Tighten the bolts in order to below sequence.


Tightening torque:

1st step:


 $6.9 \sim 7.8 \text{N.m} \; (0.7 \sim 0.8 \text{kgf.m}, \, 5.1 \sim 5.8 \text{lb-ft})$

2nd step:

 $13.7 \sim 14.7$ N.m (1.4 ~ 1.5 kgf.m, $10.1 \sim 10.8$ lb-ft)



SHMM19038N




SHMM19039N

EMA-57

MOTICE

Be careful the right, left bank, intake, exhaust side before assembling.



ECBF036A

A: L(LH),R(RH)

B: I(Intake), E(Exhaust)

C : Journal number

D : Front mark

ACAUTION


Be sure to install the thrust bearing cap and bearing cap bolts in the correct places.

ه دیجیتال تعمیرکاران خودرو در ایران


8. Install the cam to cam guide (A).

Tightening torque:

 $9.8 \sim 11.8 \text{Nm} \ (1.0 \sim 1.2 \text{kgf.m}, \ 7.2 \sim 8.7 \text{lb-ft})$



SHMM19026N



SHMM19027N

Engine Mechanical System

- 9. Install the LH timing chain guide bolt (B) and then the LH timing chain tensioner (A).
 - 1) Install the timing chain tensioner & plug bolt in the hole on the cylinder head by hand.
 - 2) Tighten the plug bolt with the specified torque while pressing the timing chain on the LH intake CVVT

Tightening torque:

Timing chain guide bolt:

21.6 ~ 25.5Nm (2.2 ~ 2.6kgf.m, 15.9 ~ 18.8lb-ft)

Timing chain tensioner plug bolt:

 $78.5 \sim 88.3 \text{N.m} (8.0 \sim 9.0 \text{kgf.m}, 57.9 \sim 65.1 \text{lb-ft})$

WNOTICE

- 1. Do not reuse the timing chain tensioner.
- 2. Make sure the timing chain tensioner is at compressed transport position state.
- 3. Install the timing chain tensioner with the oil hole facing the plug bolt.

- 10. Install the RH timing chain guide bolt (B) and then the RH timing chain tensioner (A).
 - 1) Install the timing chain tensioner & plug bolt in the hole on the cylinder head by hand.
 - Tighten the plug bolt with the specified torque while pressing the timing chain on the RH intake CVVT.

Tightening torque:

Timing chain guide bolt:


21.6 ~ 25.5Nm (2.2 ~ 2.6kgf.m, 15.9 ~ 18.8lb-ft)

Timing chain tensioner plug bolt:


 $78.5 \sim 88.3$ N.m($8.0 \sim 9.0$ kgf.m, $57.9 \sim 65.1$ lb-ft)

MOTICE


- 1. Do not reuse the timing chain tensioner.
- 2. Make sure the timing chain tensioner is at compressed transport position state.
- 3. Install the timing chain tensioner with the oil hole facing the plug bolt.




SVIM19190D



SVIM19191D




SHMM19034N



SHMM19035N

EMA-59

- 11. Set tension of the timing chain tensioner.
 - 1) LH Bank
 - A. Press the timing chain on the LH intake CVVT by hand with the timing mark "L" on the LH intake and exhaust CVVT and the LH cylinder head upper surface aligned.




SVIM19173D


- B. To set tension of the timing chain tensioner, push the timing chain tensioner arm outward with a force about 150N (15.3kgf, 33.7lbf).
 - 1. Push the timing chain tensioner arm outward with a force about 150N (15.3kgf, 33.7lbf).
 - 2. Tension of the timing chain tensioner will set after the lock is released.

SVIM19174L

C. To check the tension of the timing chain tensioner, push the timing chain tensioner arm outward strongly. The distance between the cylinder head surface and end of tensioner plunger should be about 20mm (0.79inch).



SVIM19175L




SVIM19193L


Engine Mechanical System

2) RH Bank

A. To align the timing mark "R" on the RH intake and exhaust CVVT and the RH cylinder head upper surface, turn the exhaust CVVT about 20° counterclockwise while pressing the timing chain on the intake CVVT by hand with all of the chain installation mark of the sprocket and the timing marked chain links aligned.




B. To set tension of the timing chain tensioner, push the timing chain tensioner arm outward with a force about 150N (15.3kgf, 33.7lbf).




SVIM19177L

C. To check the tension of the timing chain tensioner, push the timing chain tensioner arm outward strongly. The distance between the tensioner body and end of tensioner plunger should be about 3.5mm (0.14inch).



SVIM19178L



SVIM19192L

- 3) After setting tension of the LH, RH timing chain tensioner, check timing again.
 - A. Make sure the chain installation mark of the sprocket and the timing marked chain links are aligned.
 - B. Rotate the crankshaft 2 revolutions in regular direction (clockwise viewed from front), confirm the timing marks on the LH, RH intake and exhaust CVVT and the RH cylinder head upper surfaces are aligned.

EMA-61

12. After rotating the crankshaft 2 revolutions in regular direction (clockwise viewed from front), confirm the timing mark.

MOTICE

Always turn the crankshaft clockwise.

Turning the crankshaft counter clockwise before building up oil pressure in the hydraulic timing chain tensioner may result in the chain disengaging from the sprocket teeth.

13.Install the water temperature control assembly (A) and the water outlet fitting assembly (B) with new O-ring and new gasket.

Tightening torque:

 $16.7 \sim 19.6$ N.m ($1.7 \sim 2.0$ kgf.m, $12.3 \sim 14.5$ lb-ft)




14. Install the water outlet pipe (A) and the water inlet pipe (B).

Tightening torque:

 $9.8 \sim 11.8$ Nm ($1.0 \sim 1.2$ kgf.m, $7.2 \sim 8.7$ lb-ft)

MOTICE

- Use new O-rings when reassembling.
- Never apply sort of oil on O-ring and O-ring groove of pipe end.
- O-ring must be free from scratching damage.
- Make clean the contact face before assembly.
- Insert pipe after to be wetting O-ring or inside of attaching hole by water or antifreeze.




Engine Mechanical System

MOTICE

Install the drain plug (A).

Tightening torque:

96.1~100.0N.m(9.8~10.2kgf.m,70.9~73.8lb-ft)




SHMM19085N

15. Install the alternator (A).

Tightening torque:

29.4 ~ 41.2N.m (3.0 ~ 4.2kgf.m, 21.7 ~ 30.4lb-ft)




SHMM19030N


16. Install the oil control valve(OCV) (A).

Tightening torque:

 $9.8 \sim 11.8 \text{N.m} \; (1.0 \sim 1.2 \text{kgf.m}, \, 7.2 \sim 8.7 \text{lb-ft})$



SHMM19024N




SHMM19025N

EMA-63


MOTICE

- Do not reuse the OCV when dropped.
- Keep the OCV clean.
- Do not hold the OCV sleeve (A) during servicing.
- When the OCV is installed on the engine, do not move the engine while holding the OCV yoke.




SVIM19146D


17. Use the SST (09231-2J500, 09231-H1100) install the timing chain upper cover oil seal (A).



SHMM19340N



SHMM19341N



Engine Mechanical System


18. Apply sealant to the timing chain upper cover.

- 1) Using a gasket scraper, remove all the old packing material from the gasket surfaces.
- Before assembling the timing chain upper cover, the liquid sealant TB1217H or LT5900H should be applied on upper cover.

The part must be assembled within 5 minutes after the sealant was applied.

Bead width : Ø2.5 \pm 0.5mm(0.1 \pm 0.002in)





SHMM19362N


MOTICE

- Clean the sealing face before assembling two parts.
- Remove harmful foreign materials on the sealing face before applying sealant.
- When applying sealant gasket, sealant must not protrude into the inside of upper cover.
- To prevent leakage of oil, apply sealant gasket to the inner threads of the bolt holes.


19. Install the timing chain upper cover (A).

Tightening torque:

 $9.8 \sim 11.8 \text{Nm} \ (1.0 \sim 1.2 \text{kgf.m}, 7.2 \sim 8.7 \text{lb-ft})$



SHMM19020N



SHMM19021N

EMA-65

20. Install the water temperature sensor wiring assembly and bracket (A).


Tightening torque:

Wiring bracket bolts:

 $9.8 \sim 11.8$ Nm ($1.0 \sim 1.2$ kgf.m, $7.2 \sim 8.7$ lb-ft)

Water temperature sensor:

19.6 ~ 39.2Nm (2.0 ~ 4.0kgf.m, 14.5 ~ 28.9lb-ft)



SHMM19019N

21. Install the oil pressure switch wiring assembly and bracket (A).


Tightening torque:

Wiring bracket bolts :

 $9.8 \sim 11.8 \text{Nm} \ (1.0 \sim 1.2 \text{kgf.m}, \ 7.2 \sim 8.7 \text{lb-ft})$


Oil pressure switch:

14.7 ~ 21.6Nm (1.5 ~ 2.2kgf.m, 10.8 ~ 15.9lb-ft)




SHMM19083N


22.Use the SST (09231-2J500, 09231-H1100), install the oil seal (B) and the gasket (A).



SHMM19342N



SHMM19343N




SHMM19152N

Engine Mechanical System

23. Install the cylinder head cover.

- The sealant locations on cylinder head and timing chain upper case must be free of engine oil and ETC.
- Before assembling the cylinder head cover, the liquid sealant TB 1217H or LT5900H should be applied on the gap between cylinder head and timing chain upper case.

The part must be assembled within 5 minutes after sealant was applied.




SHMM19151N


3) Install the cylinder head cover (A).
The part must be assembled within 5 minutes after sealant was applied.

Tightening torque:

1st step : 4.9 \sim 5.9N.m (0.5 \sim 0.6kgf.m, 3.6 \sim 4.3lb-ft) 2nd step : 9.8 \sim 11.8N.m (1.0 \sim 1.2kgf.m, 7.2 \sim 8.7lb-ft)



SHMM19012N




SHMM19013N

MOTICE


Tighten the cylinder head cover bolts as following method.

[RH]



SVIM19122D

[LH]




SVIM19123D

EMA-67


24. Install the ignition coils (A).

Tightening torque:

 $9.8 \sim 11.8 \text{N.m} (1.0 \sim 1.2 \text{kgf.m}, 7.2 \sim 8.7 \text{lb-ft})$



SHMM19010N




SHMM19011N


25. Install the knock sensors (A).

Tightening torque:

64.7 \sim 76.5N.m (6.6 \sim 7.8kgf.m, 47.7 \sim 56.4lb-ft)



SHMM19008N



SHMM19009N

Engine Mechanical System

26. Install the intake manifold module (A) tighten the nuts as following method.


Tightening torque:

1st step:

 $4.9 \sim 7.8$ N.m (0.5 \sim 0.8kgf.m, 3.6 \sim 5.8lb-ft)

2nd step:


 $19.6 \sim 26.5$ N.m ($2.0 \sim 2.7$ kgf.m, $14.5 \sim 19.5$ lb-ft)



SHMM19082N


MOTICE

Tighten the intake manifold nuts as followig method.



SHMM19153N

27. Reconnect the PCV hose (A), the PCSV hose (B) and the water hoses (C) to the intake manifold module and the throttle body.



SHMM190811


28.Install the exhaust manifold (A) tighten the nuts as following method.

Tightening torque:

 $49.0 \sim 53.9$ N.m ($5.0 \sim 5.5$ kgf.m, $36.2 \sim 39.8$ lb-ft)


MOTICE

The "TOP" mark of the gasket must be face the exhaust manifold.



SHMM19063N

EMA-69



SHMM19064N

MOTICE


Tighten the exhaust manifold nuts as followig method.

[LH]



SHMM19154N

[RH]




SHMM19363N


29. Install the exhaust manifold heat protector (A).

Tightening torque:

 $8.8 \sim 10.8$ N.m (0.9 \sim 1.1kgf.m, 6.5 \sim 8.0lb-ft)




SHMM19002N




SHMM19003N

Engine Mechanical System

30. Reconnect the oxygen sensor connector (A) and Install the oxygen sensor connector bracket (B).



SHMM19079N




SHMM19080N

31. Install the oil level gauge (A).

Tightening torque:


 $9.8 \sim 11.8$ Nm ($1.0 \sim 1.2$ kgf.m, $7.2 \sim 8.7$ lb-ft)



SHMM19001N


32. Install the engine wiring harness to the cylinder head.

 Reconnect the water temperature sensor connector (A) and the CVVT oil control valve connectors (B).



SHMM19069N


2) Reconnect the ETC module connector (A).



SHMM19070N


EMA-71

3) Reconnect the PCSV connector (A) and the injector connectors (B).




SHMM19071N

4) Reconnect the ignition coil connectors (A) and the wiring harness protector (B).




SHMM19072N

 Reconnect the knock sensor connectors (A), the camshaft position sensor connectors (B), the oxygen sensor connector (C) and the condenser connector (D).



SHMM19073N


6) Reconnect the variable intake system solenoid valve connector (A) and the wiring harness protector (B).



SHMM19074N


Engine Mechanical System

 Reconnect the knock sensor connectors (A), the camshaft position sensor connectors (B), the crankshaft position sensor connector (C), the oxygen sensor connector (D) and the condenser connector (E).




SHMM19075N

8) Reconnect the injector connectors (A).




SHMM19076N

9) Reconnect the ignition coil connectors (A) and the wiring harness protector (B).



SHMM19077N

10) Reconnect the oil pressure switch connector (A), the CVVT oil control valve connectors (B) and the air conditioner compressor switch connector (C).




SHMM19078N

EMA-73

33. Install the drive belt tensioner (A).


Tightening torque:

 $19.6 \sim 23.5$ N.m ($2.0 \sim 2.4$ kgf.m, $14.5 \sim 17.4$ lb-ft)



SHMM19068N

34. Turn the tensioner (B) clockwise and loosen, then install the drive belt (A).




SHMM19067N

35. Install the cooling fan clutch (A).

Tightening torque:


58.8N.m (6.0kgf.m, 43.4lb-ft)



SHMM19052N

MOTICE

Install the cooling fan clutch (A) after fixing the cooling fan pulley (B) by inserting a pin (C) into the hole of it.




SHMM19053N

Engine Mechanical System

36. Install the cooling fan (A).


Tightening torque:

 $8.8 \sim 13.7 \text{Nm} \; (0.9 \sim 1.4 \text{kgf.m}, \, 6.5 \sim 10.1 \text{lb-ft})$




SHMM19051N

37.Reconnect the heater hoses (A), the fuel hose (B) and the purge control solenoid valve (PCSV) hose (C).



SHMM19054N

38. Reconnect the radiator upper hose (A) and lower hose (B).




SHMM19049N

39. Install the air duct (A) and the air cleaner assembly (B).

Tightening torque:

9.8 ~ 11.8Nm (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)




SHMM19048N

Cylinder Head Assembly

EMA-75

40. Install the engine cover (A).



SHMM19044N

41. Reconnect the negative terminal to the battery.



SHMM19043N

MNOTICE


- · Refill engine oil.
- Clean the battery posts and cable terminals with sandpaper assemble them, then apply grease to prevent corrosion.
- · Inspect for fuel leakage.
 - After assembling the fuel line, turn on the ignition switch (do not operate the starter) so that the fuel pump runs for approximately two seconds and fuel line pressurizes.
 - Repeat this operation two or three times, then check for fuel leakage at any point in the fuel lines.
- Refill radiator and reservoir tank with engine coolant.
- Bleed air from the cooling system.
 - Start engine and let it run until it warms up. (Until the radiator fan operates 3 or 4 times.)
 - Turn Off the engine. Check the level in the radiator, add coolant if needed. This will allow trapped air to be removed from the cooling system.
 - Put radiator cap on tightly, then run the engine again and check for leaks.

Engine Mechanical System

Timing System

Timing Chain

Components



SHMM19325N


- 1. Timing chain upper cover
- 2. Timing chain upper cover oil seal
- 3. CVVT assembly
- 4. Camshaft
- 5. Timing chain lower cover
- 6. Timing chain lower cover gasket
- 7. Timing chain lower cover gasket
- 8. Timing chain lower cover oil seal
- 9. Water pump
- 10. Water pump gasket
- 11. Timing chain guide
- 12. Timing chain tensioner arm
- 13. Timing chain
- 14. Timing chain guide bolt

- 15. Tensioner adapter
- 16. Oil pump chain
- 17. Oil pump chain tensioner
- 18. Oil pump sprocket
- 19. Oil pump assembly
- 20. Crankshaft sprocket

EMA-77


Removal

- 1. Remove the cylinder head assembly. (Refer to cylinder head assembly in this group)
- 2. Remove the power steering pump. (Refer to ST group)




SHMM19086N






SHMM19031N

4. Remove the air conditioner compressor (A). (Refer to HA group)



SHMM19087N

5. Remove the cooling fan pulley (A).




SHMM19088N

ACAUTION

The cooling fan pulley bolt is left-hand thread. To remove the bolt, screw it clockwise.


Engine Mechanical System

6. Remove the water pump pulley (A).




SHMM19089N

7. Remove the drive belt tensioner (A).




SHMM19068N

8. Remove the oil filter and oil cooler assembly (A).



SHMM19090N

 Remove the lower oil pan(A).
 Insert the blade of SST(09215-3C000) between the upper oil pan and the lower oil pan. Cut off applied



SHMM19315N


MOTICE

- Insert the SST between the lower oil pan and the upper oil pan by tapping it with a plastic hammer in the direction of (1) arrow.
- After tapping the SST with a plastic hammer along the direction of (2) arrow around more than 2/3 edge of the lower oil pan, remove it from the lower oil pan.
- Do not turn over the SST abruptly without tapping. It be result in damage of the SST.
- Be careful not to damage the contact surfaces of Upper oil pan and lower oil pan.

EMA-79

10. Remove the upper oil pan (A).

Insert the blade of SST(09215-3C000) between the upper oil pan and the cylinder block. Cut off applied sealer and remove upper oil pan.




SHMM19316N

MOTICE

- Insert the SST between the upper oil pan and the cylinder block by tapping it with a plastic hammer in the direction of (1) arrow.
- After tapping the SST with a plastic hammer along the direction of (2) arrow around more than 2/3 edge of the upper oil pan, remove it from the upper oil pan.
- Do not turn over the SST abruptly without tapping. It be result in damage of the SST.
- Be careful not to damage the contact surfaces of Upper oil pan and cylinder block.


11. Remove the crankshaft pulley (A).



SHMM19098N

MNOTICE


Use the SST(flywheel stopper, 09231-2B100) to remove the crankshaft pulley bolt, after remove the starter.



SHMM19099N


Engine Mechanical System

12. Remove the front oil seal (A).




SHMM19100N

13. Remove the water pump (A).




SHMM19101N

14. Remove the water temperature control assembly (A).




SHMM19102N

15. Remove the O-ring from the water temperature control assembly (A).




SHMM19103N

16. Remove the timing chain lower cover (A).



SHMM19105N


17. Remove the O-ring from the timing chain cover (A).



SHMM19344N

EMA-81

18. Remove the timing chain tensioner arm (A) and the timing chain guide (B) and then remove the timing chain.




SHMM19126N




SHMM19127N

19. Insert a set pin after compressing the oil pump chain tensioner (A) and then remove the oil pump sprocket (B) and chain (C).



SHMM19169N


20. Remove the crankshaft sprocket (A) and friction plates (B).



SHMM19107N

Engine Mechanical System

21. Remove the tensioner adapter (A) and the timing chain guide bolts (B).



SHMM19108N

Installation

1. Install the tensioner adapter (A) and the timing chain guide bolts (B).


Tightening torque:

Tensioner adapter bolts:

 $21.6 \sim 25.5$ Nm ($2.2 \sim 2.6$ kgf.m, $15.9 \sim 18.8$ lb-ft)

Timing chain guide bolts:

 $21.6 \sim 25.5$ Nm ($2.2 \sim 2.6$ kgf.m, $15.9 \sim 18.8$ lb-ft)



SHMM19108N

Install the crankshaft sprocket (A) with the friction plates (B).


MOTICE

Completely fix the four friction plate clips and the sprocket groove.

Align the key-home of the friction plate with the key-home of the sprocket.

Be careful for the clip not to be folded.

The block is placed at bottom up before install the timing chain system and timing chain cover assembly.



SHMM19107N



، دیجیتال تعمیرکاران خودرو در ایران

EMA-83

ACAUTION


The mark of friction plate should be placed top. (Engine is placed bottom up)

3. Install the oil pump chain (C) with the oil pump sprocket (B) and oil pump chain tensioner (A).

Tightening torque:

A : 9.8 \sim 11.8Nm (1.0 \sim 1.2kgf.m, 7.2 \sim 8.7lb-ft)

B: 21.6 \sim 25.5Nm (2.2 \sim 2.6kgf.m, 15.9 \sim 18.8lb-ft)




SHMM19169N

4. Install the timing chain with the timing chain tensioner arm (A), the timing chain guide (B) and the timing chain locking tool (SST: 09231-2J600) (C).


Tightening torque:

Timing chain tensioner arm bolts:

21.6 ~ 25.5Nm (2.2 ~ 2.6kgf.m, 15.9 ~ 18.8lb-ft)




SHMM19126N



SHMM19127N

MOTICE

Align the timing mark of the friction plate and crankshaft sprocket.



SHMM19128N


Engine Mechanical System

5. Install the timing chain lower cover (A).

MOTICE

Assemble the timing chain lower cover with engine bottom up condition.

- The sealant locations on chain lower cover and on counter parts (cylinder head, cylinder block, and lower oil pan) must be free of engine oil and etc.
- 2) Install the new gasket (A) to the timing chain lower cover.




SHMM19344N


 Apply liquid sealant TB1217H or LT 5900H on timing chain lower cover. The part must be assembled within 5 minutes after sealant was applied.

Sealant should be applied in a continuous beed in each of the areas indicated below.

Bead width : \emptyset 2.5 \pm 0.5mm



SHMM19106N



SHMM19323N


MOTICE

During timing chain lower cover installation, care not to take off applied sealant on the timing chain lower cover by contact with other parts.

4) The dowel pins on the cylinder block and holes on the timing chain lower cover should be used as a reference in order to assemble the timing chain lower cover to be in exact position.

Tightening torque:

 $23.5 \sim 27.5 \text{Nm} \ (2.4 \sim 2.8 \text{kgf.m}, 17.4 \sim 20.3 \text{lb-ft})$



SHMM19105N

5) The firing and/or blow out test should not be performed within 30 minutes after the timing chain lower cover was assembled.


EMA-85


6. Install the cylinder head assembly. (Refer to cylinder head assembly in this group)

MOTICE


Before install the cylinder head assembly, place the engine up right.

- 7. Install the camshaft assembly. (Refer to cylinder head assembly in this group)
- 8. Remove the SST from the timing chain guide and the timing chain tensioner arm.
- 9. Install the timing chain to the camshaft sprocket. (Refer to cylinder head assembly in this group)






SHMM19028N



SHMM19029N



MOTICE

To install the timing chain with no slack between each shaft (cam, crank), follow the below procedure.

Crankshaft sprocket → Timing chain guide → Exhaust camshaft sprocket → Intake camshaft sprocket. (LH Bank)

Crankshaft sprocket → Timing chain guide → Intake camshaft sprocket → Exhaust camshaft sprocket. (RH Bank)

The timing mark of each sprockets should be matched with timing mark (color link) of timing chain during installation.

Engine Mechanical System

10.Install the timing chain tensioner. (Refer to cylinder head assembly in this group)

Tightening torque:

 $78.5 \sim 88.3$ N.m ($8.0 \sim 9.0$ kgf.m, $57.9 \sim 65.1$ lb-ft)

11. After rotating the crankshaft 2 revolutions in regular direction (clockwise viewed from front), confirm the timing mark.

MOTICE

Always turn the crankshaft clockwise.

Turning the crankshaft counter clockwise before building up oil pressure in the hydraulic timing chain tensioner may result in the chain disengaging from the sprocket teeth.

12.Install the O-ring to the water temperature control assembly (A).




SHMM19103N

13. Install the water temperature control assembly (A).

Tightening torque:

16.7 ~ 19.6N.m (1.7 ~ 2.0kgf.m, 12.3 ~ 14.5lb-ft)




SHMM19102N

14. Install the water pump (A).


Tightening torque:

19.6 ~ 24.5Nm (2.0 ~ 2.5kgf.m, 14.5 ~ 18.1lb-ft)



SHMM19101N

15. Using SST(09231-2J300, 09231-H1100), Install the front oil seal (A).




SHMM19345N

EMA-87

16. Install the crankshaft pulley (A).

Tightening torque:


392.3~402.1Nm(40.0~41.0kgf.m,289.3~296.6lb-ft)



SHMM19098N

MNOTICE

Use the SST(flywheel stopper, 09231-2B100) to Install the crankshaft pulley bolt, after remove the starter.




SHMM19099N

17. Install the upper oil pan.

- 1) Using a gasket scraper, remove all the old packing material from the gasket surfaces.
- 2) Before assembling the oil pan, the liquid sealant TB1217H should be applied on upper oil pan.

The part must be assembled within 5 minutes after the sealant was applied.

Bead width: 2.5mm(0.1in)




SHMM19143N

MOTICE

- Clean the sealing face before assembling two parts.
- Remove harmful foreign materials on the sealing face before applying sealant.
- When applying sealant gasket, sealant must not protrude into the inside of oil pan.
- To prevent leakage of oil, apply sealant gasket to the inner threads of the bolt holes.

Engine Mechanical System

3) Install the upper oil pan.




SHMM19094N

Uniformly tighten the bolts in several passes.

Tightening torque:

9.8 \sim 11.8Nm (1.0 \sim 1.2kgf.m, 7.2 \sim 8.7lb-ft)




SHMM19145N

18. Install the lower oil pan.

- 1) Using a gasket scraper, remove all the old packing material from the gasket surfaces.
- 2) Before assembling the oil pan, the liquid sealant TB1217H or LT5900H should be applied on lower oil pan.

The part must be assembled within 5 minutes after the sealant was applied.

Bead width: 2.5mm(0.1in)




SHMM19146N

UNOTICE

- Clean the sealing face before assembling two parts.
- Remove harmful foreign materials on the sealing face before applying sealant.
- When applying sealant gasket, sealant must not protrude into the inside of oil pan.
- To prevent leakage of oil, apply sealant gasket to the inner threads of the bolt holes.

EMA-89

3) Install the lower oil pan.




SHMM19092N

Uniformly tighten the bolts in several passes.

Tightening torque:

 $9.8 \simeq 11.8 \text{Nm} \; (1.0 \simeq 1.2 \text{kgf.m}, \, 7.2 \simeq 8.7 \text{lb-ft})$



SHMM19147N


19. Install the oil filter and oil cooler assembly (A).

Tightening torque:

Oil filter assembly bolts:

19.6 \sim 23.5Nm (2.0 \sim 2.4kgf.m, 14.5 \sim 17.4lb-ft) Oil cooler bolts :

 $9.8 \sim 11.8 \text{Nm} \ (1.0 \sim 1.2 \text{kgf.m}, 7.2 \sim 8.7 \text{lb-ft})$




SHMM19090N

20. Install the drive belt tensioner (A).

Tightening torque:

19.6 ~ 23.5Nm (2.0 ~ 2.4kgf.m, 14.5 ~ 17.4lb-ft)



SHMM19068N

Engine Mechanical System


21. Install the water pump pulley (A).

Tightening torque:

 $18.6 \sim 23.5 \text{Nm} \ (1.9 \sim 2.4 \text{kgf.m}, \ 13.7 \sim 17.4 \text{lb-ft})$

MOTICE

Tighten every bolt diagonally.




SHMM19089N

22. Install the cooling fan pulley (A).

Tightening torque:

76.5 ~ 80.4Nm (7.8 ~8.2kgf.m, 56.4 ~ 59.3lb-ft)




SHMM19088N

⚠CAUTION

The cooling fan pulley bolt is left-hand thread.

To assemble the bolt screw it counterclockwise.

23.Install the air conditioner compressor (A). (Refer to HA group)



SHMM19087N

24. Install the alternator bracket (A).


Tightening torque:

Bolts (B) 4EA:

 $29.4 \sim 41.2 \text{N.m} (3.0 \sim 4.2 \text{kgf.m}, 21.7 \sim 30.4 \text{lb-ft})$

Bolt (C) 1EA:


19.6 ~ 26.5N.m (2.0 ~ 2.7kgf.m, 14.5 ~ 19.5lb-ft)



SHMM19353N

EMA-91

25.Install the power steering pump. (Refer to ST group)



SHMM19086N

26.Install the removed parts. (Refer to cylinder head assembly installation procedure in this group)






Engine Mechanical System

Cylinder Block

Cylinder Block

Components



SHMM19328N

- 1. Cylinder block bank cover
- 2. Cylinder block bank cover gasket
- 3. Cylinder block rear cover
- 4. Cylinder block rear cover gasket
- 5. Separator
- 6. Drain plug
- 7. O-ring
- 8. Cylinder block
- 9. Lower crankcase assembly

- 10. Snap ring
- 11. Piston pin
- 12. Piston
- 13. Connecting rod
- 14. Connecting rod bearing
- 15. Crankshaft pulley
- 16. Friction plate
- 17. Crankshaft sprocket
- 18. Key

- 19. Crankshaft
- 20. Crankshaft main bearing
- 21. Crankshaft center main bearing
- 22. Crankshaft adapter
- 23. Drive plate
- 24. Adapter plate
- 25. Crankshaft rear oil seal

EMA-93


Removal

ACAUTION

- Use fender covers to avoid damaging painted surfaces.
- To avoid damage, unplug the wiring connectors carefully while holding the connector portion.


UNOTICE

- Mark all wiring and hoses to avoid misconnection.
- Inspect the timing chain before removing the cylinder head
- Turn the crankshaft pulley so that the No.1 piston is at top dead center.
- Engine removal is required for this procedure.
- Remove the engine assembly from the vehicle. (Refer to Engine and transaxle assembly in this group)
- 2. Install the engine to engine stand for disassembly.
- 3. Remove the intake manifold and exhaust manifold. (Refer to Intake and exhaust system in this group)
- 4. Remove the cylinder head. (Refer to Cylinder head in this group)
- 5. Remove the timing chain. (Refer to Timing system in this group)
- 6. Remove the water temperature control assembly. (Refer to Cooling system in this group)
- 7. Remove the oil pump. (Refer to Lubrication system in this group)
- 8. Remove the adapter plate (A) and the drive plate (B).




SVIM19164D

9. Remove the crankshaft adapter (A).



SVIM19165D


10. Remove the cylinder block rear cover (A).



SHMM19113N

Engine Mechanical System


11. Remove the separator (A).



SHMM19110N




12. Remove the cylinder block bank cover (A) and the gasket (B).



SHMM19104N

- 13. Check the connecting rod end play.
- 14. Check the connecting rod cap oil clearance.
- 15. Remove the piston and connecting rod assemblies.
 - 1) Using a ridge reamer, remove all the carbon from the top of the cylinder.
 - 2) Remove the connecting rod cap (A).




SHMM19116N

 Push the piston, connecting rod assembly and upper bearing through the top of the cylinder block.

MOTICE


- Keep the bearings, connecting rod and cap together.
- Arrange the piston and connecting rod assemblies in the correct order.
- 16. Check the main bearing oil clearance.
- 17. Check the crankshaft end play.
- 18. Remove the lower crankcase assembly (A).



SHMM19114N

EMA-95

19. Lift the crankshaft (A) out of engine, being careful not to damage journals.



SHMM19117N

MOTICE

Arrange the main bearings and center bearings in the correct order.

20. Check fit between piston and piston pin.

Try to move the piston back and forth on the piston pin. If any movement is felt, replace piston and piston pin as a set.

- 21. Remove the piston rings.
 - 1) Using a piston ring expander, remove the 2 compression rings.
 - 2) Remove 2 side rails and the spacer by hand.

MOTICE

Arrange the piston rings in the correct order only.

- 22. Disconnect connecting rod from piston.
 - 1) Remove the snap rings from piston.
 - 2) Remove the piston pin.
 - 3) Remove the connecting rod and the piston.


Inspection

Connecting Rod And Crankshaft

 Check the connecting rod end play.
 Using a feeler gauge, measure the end play while moving the connecting rod back and forth.

Standard end play:

 $0.10 \sim 0.28$ mm $(0.0039 \sim 0.0110$ in)



SHMM19317N

- 1) If out-of-tolerance, install a new connecting rod.
- 2) If still out-of-tolerance, replace the crankshaft.
- 2. Check the connecting rod bearing oil clearance.
 - 1) Check the match marks on the connecting rod and cap are aligned to ensure correct reassembly.
 - 2) Remove 2 connecting rod cap bolts.
 - 3) Remove the connecting rod cap and bearing half.
 - 4) Clean the crank pin and bearing.
 - 5) Place plastigage across the crank pin.

Engine Mechanical System

6) Reinstall the bearing half and cap, and torque the bolts.


Tightening torque:

22.6 \sim 26.5Nm (2.3 \sim 2.7kgf.m, 16.6 \sim 19.5lb-ft)

 $+ 98 \sim 102^{\circ}$

MOTICE

Do not turn the crankshaft.




SHMM19318N

- 7) Remove 2 bolts, connecting rod cap and bearing half
- 8) Measure the plastigage at its widest point.

Standard oil clearance:

 $0.018 \sim 0.036$ mm $(0.0007 \sim 0.0014$ in)



SHMM19130N

9) If the plastigage measures too wide or too narrow, remove the upper half of the bearing, install a new, complete bearing with the same color mark (select the color as shown in the next column), and recheck the clearance.

ACAUTION

Do not file, shim, or scrape the bearings or the caps to adjust clearance.

10) If the plastigage shows the clearance is still incorrect, try the next larger or smaller bearing (the color listed above or below that one), and check clearance again.


MOTICE

If the proper clearance cannot be obtained by using the appropriate larger or smaller bearings, replace the crankshaft and start over.

ACAUTION

If the marks are indecipherable because of an accumulation of dirt and dust, do not scrub them with a wire brush or scraper. Clean them only with solvent or detergent.

Connecting Rod Mark Location




EDQF196A

Discrimination Of Connecting Rod

Discrimination of connecting Noa			
Class	Mark	Connecting Rod Big-endinner Diameter	
а	А	55.000 ~ 55.006mm (2.1654 ~ 2.1656in)	
b	В	55.006 ~ 55.012mm (2.1656 ~ 2.1658in)	
С	С	55.012 ~ 55.018mm (2.1658 ~ 2.1661in)	

EMA-97

Crankshaft Pin Mark Location




SHMM19131N

Discrimination Of Crankshaft Pin Journal

Class	Mark	Crankshaft Pin Journalouter Diameter	
ı	А	51.994 ~ 52.000mm (2.0470 ~ 2.0472in)	
	В	51.9 <mark>8</mark> 8 ~ 51.994mm (2.0468 ~ 2.0470in)	
ىدولا)	لیے مہ	51.982 ~ 51.988mm (2.0465 ~ 2.0468in)	

ه دیجیتال تعمیرکاران خودرو در ایران

Connecting Rod Bearing Mark Location



ECRF021A

Discrimination Of Connecting Rod Bearing

Class	Color	Connecting Rod Bearing Thic- kness
А	Blue	1.500 ~ 1.503mm (0.0591 ~ 0.0592in)
В	Black	1.497 ~ 1.500mm (0.0589 ~ 0.0591in)
رکن ی دیا	None	1.494 ~ 1.497mm (0.0588 ~ 0.0589in)
ولين سا	Green	1.491 ~ 1.49 <mark>4mm</mark> (0.0587 ~ 0.0588in)
E	Yellow	1.488 ~ 1.491mm (0.0586 ~ 0.0587in)

11) Select the bearing by using selection table.

Connecting Rod Bearing Selection Table

Connecting Rod B- earing		Connecting Rod Mark		
		a(A)	b(B)	c(C)
Crank sh-	· ,	E(Yellow)	D(Green)	C(None)
aft pin jo- urnal ma- rk	II(B)	D(Green)	C(None)	B(Black)
	III(C)	C(None)	B(Black)	A(Blue)

Engine Mechanical System

- 3. Check the crankshaft bearing oil clearance.
 - To check main bearing-to-journal oil clearance, remove the lower crankcase assembly and bearing halves.
 - 2) Clean each main journal and bearing half with a clean shop tower.
 - 3) Place one strip of plastigage across each main journal.
 - 4) Reinstall the bearings and the lower crankcase assembly, and then torque the bolts.

Tightening torque:

Main bearing cap bolts (1~20)


37.3 \sim 41.2 N.m (3.8 \sim 4.2 kgf.m, 27.5 \sim 30.4 lb-ft) + 120°

Flange bolts (21~35)

 $21.6 \sim 25.5 \text{ N.m}$ (2.2 $\sim 2.6 \text{ kgf.m}$, $15.9 \sim 18.8 \text{ lb-ft}$)


MOTICE

Do not turn the crankshaft.



SHMM19115N

Use the SST(09221-4A000), install main bearing cap bolts.




SHMM19324N

5) Remove the lower crankcase assembly and bearing again, and measure the widest part of the plastigage.

Standard oil clearance:

0.004 ~ 0.022mm (0.0002 ~ 0.0009in)



SHMM19322N

6) If the plastigage measures too wide or too narrow, remove the upper half of the bearing, install a new, complete bearing with the same color mark (select the color as shown in the next column), and recheck the clearance.

ACAUTION

Do not file, shim, or scrape the bearings or the caps to adjust clearance.

EMA-99

7) If the plastigage shows the clearance is still incorrect, try the next larger or smaller bearing (the color listed above or below that one), and check clearance again.

MNOTICE

If the proper clearance cannot be obtained by using the appropriate larger or smaller bearings, replace the crankshaft and start over.


ACAUTION

If the marks are indecipherable because of an accumulation of dirt and dust, do not scrub them with a wire brush or scraper. Clean them only with solvent or detergent.

Cylinder block crankshaft journal bore mark location

Letters have been stamped on the block as a mark for the size of each of the 5 main journal bores.

Use them, and the numbers or bar stamped on the crank (marks for main journal size), to choose the correct bearings.




SHMM19132N

Discrimination Of Cylinder Block Crankshaft Journal Bore

Class	Mark	k Cylinder Block Crankshaftjou- rnal Bore Inner Diameter	
а	А	70.000 ~ 70.006mm (2.7559 ~2.7561in)	
b	В	70.006 ~ 70.012mm (2.7561 ~ 2.7564in)	
С	С	70.012 ~ 70.018mm (2.7564 ~ 2.7566in)	

Crankshaft Main Journal Mark Location




SHMM19131N

Discrimination Of Crankshaft Main Journal

Class	Mark	Crankshaft Main Journalouter Diameter
I	А	64.994 ~ 65.000mm (2.5588 ~2.5591in)
II	В	64.988 ~ 64.994mm (2.5586 ~ 2.5588in)
III	С	64.982 ~ 64.988mm (2.5583 ~2.5586in)

Engine Mechanical System

Crankshaft Main Bearing Mark Location



ECRF022A

Discrimination Of Crankshaft Main Bearing

Class	Color	Crankshaft Main Bearing Thic- kness	
А	Blue	2.507 ~ 2.510mm (0.0987 ~ 0.0988in)	
В	Black	2.5 <mark>04</mark> ~ 2.507mm (0.0986 ~ 0.0987in)	
عدو 2)	None	2.501 ~ 2.504mm (0.0985 ~ 0.0986in)	
D	Green	2.498 ~ 2.501mm (0.0983 ~ 0.0985in)	
E	Yellow	2.495 ~ 2.498mm (0.0982 ~ 0.0983in)	

8) Select the bearing by using selection table.

Crankshaft Main Bearing Selection Table


Crankshaft Main B- earing		Cylinder Block Crankshaft Jo- urnal Bore Mark		
		A (a)	B (b)	C (c)
Crank sh- aft main j- ournal m- ark	A (I)	E(Yellow)	D(Green)	C(None)
	B (II)	D(Green)	C(None)	B(Black)
	C (III)	C(None)	B(Black)	A(Blue)

4. Check crankshaft end play.

Using a dial indicator, measure the thrust clearance while prying the crankshaft back and forth with a screwdriver.

Standard end play:

 $0.10 \sim 0.28$ mm ($0.0039 \sim 0.0110$ in)



SHMM19364N

If the end play is greater than maximum, replace the center bearings as a set.

Thrust bearing thickness (center bearing)

2.36 ~ 2.40mm (0.0929 ~ 0.0945in)

EMA-101


 Inspect main journals and crank pins.
 Using a micrometer, measure the diameter of each main journal and crank pin.

Main journal diameter:

64.982 ~ 65.000mm (2.5583 ~ 2.5591in)

Crank pin diameter:

51.982 ~ 52.000mm (2.0465 ~ 2.0472in)



Connecting Rods

- When reinstalling, make sure that cylinder numbers put on the connecting rod and cap at disassembly match. When a new connecting rod is installed, make sure that the notches for holding the bearing in place are on the same side.
- Replace the connecting rod if it is damaged on the thrust faces at either end. Also if step wear or a severely rough surface of the inside diameter of the small end is apparent, the rod must be replaced as well
- Using a connecting rod aligning tool, check the rod for bend and twist. If the measured value is close to the repair limit, correct the rod by a press. Any connecting rod that has been severely bent or distorted should be replaced.

Allowable bend of connecting rod:

0.05mm / 100mm (0.0020 in/3.94 in) or less

Allowable twist of connecting rod:

0.1mm / 100mm (0.0039 in/3.94 in) or less

Engine Mechanical System


Cylinder Block

- 1. Remove the gasket material.
 - Using a gasket scraper, remove all the gasket material from the top surface of the cylinder block.
- 2. Clean the cylinder block.
 - Using a soft brush and solvent, thoroughly clean the cylinder block.
- 3. Inspect the top surface of the cylinder block for flatness.

Using a precision straight edge and feeler gauge, measure the surface contacting the cylinder head gasket for warpage.

Flatness of cylinder block gasket surface

Standard : Less than 0.05mm(0.0020 in), Less than 0.02mm(0.0008in) / 150 x 150



SHMM19355N

4. Inspect cylinder bore diameter.

Visually check the cylinder for vertical scratches.


If deep scratches are present, replace the cylinder block

5. Inspect cylinder bore diameter.

Using a cylinder bore gauge, measure the cylinder bore diameter at position in the thrust and axial directions.


Standard diameter

92.000 ~ 92.030mm (3.6220 ~ 3.6232in)



SHMM19356N

Check the cylinder bore size code on the cylinder block.



Crankshaft bore diameter grade


SHMM19132N

Discrimination Of Cylinder Bore Size

Class	Size code	Cylinder Boreinner Diameter
А	А	92.000 ~ 92.010mm (3.6220 ~ 3.6224in)
В	В	92.010 ~ 92.020mm (3.6224 ~ 3.6228in)
С	С	92.020 ~ 92.030mm (3.6228 ~ 3.6232in)

EMA-103

7. Check the piston size code(A) and the front mark(B) on the piston top face.



SHMM19133N

Discrimination Of Piston Outer Diameter

Class	Size code	Piston Outer Diameter
А	А	91.945 \sim 91.955mm (3.6199 \sim 3.6203in)
В	В	91.9 <mark>5</mark> 5 ~ 91.965mm (3.6203 ~ 3.6207in)
دوی)	ليث مح	91.965 ~ 91.975mm (3.6207 ~ 3.6211in)

8. Select the piston related to cylinder bore class.

Clearance: 0.045 ~ 0.065mm (0.0018 ~ 0.0026in)

Piston And Rings

- 1. Clean piston
 - 1) Using a gasket scraper, remove the carbon from the piston top.
 - 2) Using a groove cleaning tool, clean the piston ring grooves.
 - 3) Using solvent and a brush, thoroughly clean the piston.


MOTICE

Do not use a wire brush.

2. The standard measurement of the piston outside diameter is taken 15 mm (0.5906 in) from the bottom of the piston.

Standard diameter

 $91.945 \sim 91.975$ mm (3.6199 ~ 3.6211 in)



SHMM19357N

3. Calculate the difference between the cylinder bore diameter and the piston diameter.

Piston-to-cylinder clearance:

 $0.045 \sim 0.065$ mm (0.0018 ~ 0.0026 in)

Engine Mechanical System

4. Inspect the piston ring side clearance.

Using a feeler gauge, measure the clearance between new piston ring and the wall of the ring groove.

Piston ring groove width

No.1 : 1.23 \sim 1.25mm (0.0484 \sim 0.0492in) No.2 : 1.23 \sim 1.25mm (0.0484 \sim 0.0492in) Oil ring : 2.01 \sim 2.03mm (0.0791 \sim 0.0799in)

Piston ring width

No.1 : 1.17 \sim 1.19mm (0.0461 \sim 0.0469in) No.2 : 1.17 \sim 1.19mm (0.0461 \sim 0.0469in) Oil ring : 1.88 \sim 1.95mm (0.0740 \sim 0.0768in)

Piston ring side clearance

No.1 : $0.04 \sim 0.08$ mm ($0.0016 \sim 0.0031$ in) No.2 : $0.04 \sim 0.08$ mm ($0.0016 \sim 0.0031$ in) Oil ring : $0.06 \sim 0.15$ mm ($0.0024 \sim 0.0059$ in)



To measure the piston ring end gap, insert a piston ring into the cylinder bore. Position the ring at right angles to the cylinder wall by gently pressing it down with a piston. Measure the gap with a feeler gauge. If the gap exceeds the service limit, replace the piston ring. If the gap is too large, recheck the cylinder bore diameter against the wear limits. If the bore is over the service limit, the cylinder block must be replaced.

Piston ring end gap

No.1 : 0.17 \sim 0.32mm (0.0067 \sim 0.0126in) No.2 : 0.37 \sim 0.52m (0.0146 \sim 0.0205in) Oil ring : 0.20 \sim 0.70mm (0.0079 \sim 0.0276in)



ECKD001K



ECKD001G

If the clearance is greater than maximum, replace the piston.

EMA-105

Piston Pins

1. Measure the diameter of the piston pin.

Piston pin outer diameter:

21.995 ~ 22.000mm (0.8659 ~ 0.8661in)

Piston pin hole inner diameter :

22.004 ~ 22.010mm (0.8663 ~ 0.8665in)

Connecting rod small end inner diameter:

 $22.007 \sim 22.018$ mm (0.8664 ~ 0.8668 in)



2. Check the piston pin-to-piston clearance.

Piston pin-to-piston clearance:

0.004 ~ 0.015mm (0.0002 ~ 0.0006in)

Check the difference between the piston pin diameter and the connecting rod small end diameter.


Piston pin-to-connecting rod interference:

 $0.007 \sim 0.023 \text{mm} \; (0.0003 \sim 0.0009 \text{in})$

Reassembly

MOTICE

- · Thoroughly clean all parts to be assembled.
- Before installing the parts, apply fresh engine oil to all sliding and rotating surfaces.
- Replace all gaskets, O-rings and oil seals with new parts.
- 1. Assemble the piston and the connecting rod.
 - 1) Install the snap ring in one side of the piston pin hole.
 - 2) Align the piston front mark and the connecting rod front mark.




- Insert the piston pin into the piston pin hole and the small end bore of connecting rod.
- 4) Install the snap ring in the other side after inserting the piston pin.

MNOTICE

Apply a sufficient amount of engine oil to outer surface of the piston, inner surface of piston pin hole and small end bore of the connecting rod before inserting the piston pin.

Engine Mechanical System


- 2. Install the piston rings.
 - 1) Install the oil ring spacer and 2 side rails by hand.
 - Using a piston ring expander, install the 2 compression rings with the code mark facing upward.
 - 3) Position the piston rings so that the ring ends are as shown.



SHMM19346N

- 3. Install the connecting rod bearings.
 - 1) Align the bearing claw with the groove of the connecting rod or connecting rod cap.
 - Install the bearings(A) in the connecting rod and connecting rod cap(B).






SHMM19358N

4. Install the main bearings (A) (No.1,2,4,5 journal) and the center bearings (B) (No.3 journal).

MNOTICE


Upper bearings have an oil groove of oil holes; Lower bearings do not.

1) Align the bearing claw with the claw groove of the cylinder block, push in the 5 upper bearings.



SHMM19134N


 Align the bearing claw with the claw groove of the lower crankcase and push in the 5 lower bearings.



SHMM19365N

EMA-107

5. Place the crankshaft(A) on the cylinder block.




SHMM19117N

- Place the lower crankcase assembly on cylinder block.
 - 1) Using a gasket scraper, remove all the old packing material from the gasket surfaces.
 - 2) Install the O-ring (A) to cylinder block.
 - Before assembling the lower crankcase assembly, the liquid sealant TB1217H should be applied on cylinder block bottom.

The part must be assembled within 5 minutes after the sealant was applied.

Bead width: 2.5mm(0.1in)



SHMM19366N

MOTICE

- Clean the sealing face before assembling two parts.
- Remove harmful foreign materials on the sealing face before applying sealant.
- When applying sealant gasket, sealant must not protrude into the inside of cylinder block.

- To prevent leakage of oil, apply sealant gasket to the inner threads of the bolt holes.
- 4) Install the lower crankcase assembly.
- 7. Install the lower crankcase assembly bolts.
 - 1) Install and uniformly tighten the lower crankcase assembly bolts, in several passes, in the sequence shown.

Tightening torque

Main bearing cap bolts (1~20)

 $37.3 \sim 41.2 \; N.m$


 $(3.8 \sim 4.2 \text{ kgf.m}, 27.5 \sim 30.4 \text{ lb-ft}) + 120^{\circ}$

Flange bolts (21~35)

21.6 ~ 25.5 N.m (2.2 ~ 2.6 kgf.m, 15.9 ~ 18.8 lb-ft)


MOTICE

- Always use new main bearing cap bolts.
- If any of the bearing cap bolts are broken or deformed, replace it.



SHMM19115N

Use the SST(09221-4A000), install main bearing cap bolts.




SHMM19324N

Engine Mechanical System

- 2) Check that the crankshaft turns smoothly.
- 8. Check crankshaft end play.
- 9. Install the piston and connecting rod assemblies.

MOTICE

- Before installing the pistons, apply a coat of engine oil to the ring grooves and cylinder bores.
- The piston front mark (A) and the connecting rod front mark (B) must face the timing chain side of the engine.



SHMM19347N

- Install the ring compressor, check that the bearing is securely in place, then position the piston in the cylinder, and tap it in using the wooden handle of a hammer.
- Stop after the ring compressor pops free, and check the connecting rod-to-check journal alignment before pushing the piston into place.


3) Apply engine oil to the bolt threads. Install the rod caps with bearings, and torque the bolts.

Tightening torque:

 $22.6 \sim 26.5 Nm$

 $(2.3 \sim 2.7 \text{kgf.m}, 16.6 \sim 19.5 \text{lb-ft}) + 98 \sim 102^{\circ}$


Use SST(09221-4A000), install connecting rod bearing cap bolts.



SHMM19318N

MOTICE

- Always use new connecting rod bearing cap bolts.
- Maintain downward force on the ring compressor to prevent the rings from expanding before entering the cylinder bore.



SHMM19374N


EMA-109

10. Check the connecting rod end play.

11.Install the cylinder block rear cover (A) and a new gasket.

Tightening torque:

 $9.8 \sim 11.8$ Nm ($1.0 \sim 1.2$ kgf.m, $7.2 \sim 8.7$ lb-ft)




SHMM19113N

MOTICE

- Clean the sealing face before assembling two parts.
- Remove harmful foreign materials on the sealing face before applying sealant.
- Before assembling oil drain cover, the liquid sealant TB1217H should be applied to the oil drain cover.
- The part must be assembled within 5 minutes after sealant was applied.
- Apply sealant to the inner threads of the bolt holes.


12. Install the crankshaft adapter plate (A).




SVIM19165D

13. Using the SST(09231-2J400, 09231-H1100) and a plastic hammer, tap in a new oil seal(A) until SST surface is flush with the cylinder block.

At this time, the depth of the oil seal(A) from the cylinder block surface is 1mm(0.039in).



SHMM19319N



SHMM19140N

MOTICE

- Before assembling oil seal, the hardened sealant or injurious material located on the boundary area between cylinder block and lower crankcase must be removed.
- Apply engine oil to a new oil seal lip.
- When pressing oil seal, confirm to direction and take care not to damage oil seal.

Engine Mechanical System


14. Install the cylinder block bank cover (A) and a new gasket (B).

Tightening torque:

 $9.8 \sim 11.8$ Nm ($1.0 \sim 1.2$ kgf.m, $7.2 \sim 8.7$ lb-ft)


MNOTICE

The "F"mark of the gasket must be face the front of the engine.




SHMM19104N

15. Install the separator (A).



SHMM19110N




SHMM19111N

16. Install the drive plate (B) and the adapter plate (A).

Tightening torque:

98.1~107.9N.m(10.0~11.0kgf.m,72.3~79.6lb-ft)



SVIM19164D

- 17.Install the oil pump. (Refer to Lubrication system in this group)
- 18. Install the water temperature control assembly. (Refer to Cooling system in this group)
- 19.Install the timing chain. (Refer to Timing system in this group)
- 20.Install the cylinder head. (Refer to Cylinder head in this group)
- 21.Install the intake manifold and exhaust manifold. (Refer to Intake and exhaust system in this group)
- 22. Remove the engine from engine stand.
- 23. Install the engine assembly to the vehicle. (Refer to Engine and transaxle assembly in this group)

EMA-111

Cooling System

Coolant

Engine Coolant Refilling And Bleeding


WARNING

Never remove the radiator cap when the engine is hot. Serious scalding could be caused by hot fluid under high pressure escaping from the radiator.

ACAUTION


When pouring engine coolant, be sure to shut the relay box lid and not to let coolant spill on the electrical parts or the paint. If any coolant spills, rinse it off immediately.

- 1. Make sure the engine and radiator are cool to the touch.
- 2. Remove the radiator cap (A).



SHMM19047N

3. Loosen the drain plug (A) and drain the engine coolant.



SHMM19046N

- 4. Tighten the radiator drain plug(A) securely.
- 5. After draining engine coolant in the reservoir tank, clean the tank.
- 6. Fill the radiator with water through the radiator cap and tighten the cap.

MNOTICE

To most effectively bleed the air, pour the water slowly and press on the upper/lower radiator hoses.

- Start the engine and allow to come to normal operating temperature. Wait for the cooling fans to turn on several times. Accelerate the engine to aid in purging trapped air. Shut engine off.
- 8. Wait until the engine is cool.
- 9. Repeat steps 1 to 8 until the drained water runs clear.
- 10. Fill fluid mixture with coolant and water(5 : 5) (Tropical region – 4:6) slowly through the radiator cap. Push the upper/lower hoses of the radiator so as bleed air easily.

MOTICE

- · Use only genuine antifreeze/coolant.
- For best corrosion protection, the coolant concentration must be maintained year-round at 35% minimum.

Coolant concentrations less than 35% may not provide sufficient protection against corrosion or freezing.

 Coolant concentrations greater then 60% will impair cooling efficiency and are not recommended.

ACAUTION

- Do not mix different brands of antifreeze/coolants.
- Do not use additional rust inhibitors or antirust products; they may not be compatible with the coolant.

Engine Mechanical System

- 11. Start the engine and run coolant circulates.
 - When the cooling fan operates and coolant circulates, refill coolant through the radiator cap.
- 12. Repeat 11 until the cooling fan 3 \sim 5times and bleed air sufficiently out of the cooling system.
- 13.Install the radiator cap and fill the reservoir tank to the "MAX" line with coolant.
- 14. Run the vehicle under idle until the cooling fan operates 2 \sim 3 times.
- 15. Stop the engine and wait coolant gets cool.
- 16. Repeat 10 to 15 until the coolant level doesn't fall any more, bleed air out of the cooling system.

MOTICE

As it is to bleed air out to the cooling system and refill coolant when coolant gets cool completely, recheck the coolant level in the reservoir tank for 2 ~ 3 days after replacing coolant.


Coolant capacity: 14L (14.79US qt, 12.31 lmp qt)



EMA-113

Radiator

Components



SHMM19329N

- 1. Fan clutch
- 2. Cooling fan
- 3. Shroud
- 4. Coolant reservoir tank


- 5. Radiator
- 6. Radiator lower hose
- 7. Radiator upper hose
- 8. Mounting insulator

Engine Mechanical System

Inspection

Radiator Cap Testing

1. Remove the radiator cap, wet its seal with engine coolant, then install it to pressure tester.




ECKD501X

- 2. Apply a pressure of 93 \sim 123kPa (0.95 $^{\circ}$ 1.25kgf/cm², 14 \sim 19psi).
- 3. Check for a drop in pressure.
- 4. If the pressure drops, replace the cap.



Radiator Leakage Test

1. Wait until engine is cool, then carefully remove the radiator cap and fill the radiator with engine coolant, then install a pressure tester on it.



SHMM19303N

- 2. Apply a pressure of 93 \sim 123kPa (0.95 \sim 1.25kgf/cm², 14 \sim 19psi).
- 3. Inspect for engine coolant leaks and a drop in pressure.
- If the pressure drops, check hoses, the radiator and the water pump for leakage. If there is no leakage, inspect the heater core, the cylinder block and the cylinder head.
- 5. Remove the tester and reinstall the radiator cap.


MOTICE

Check for engine oil in coolant and/or coolant in engine oil.

EMA-115

Removal

1. Disconnect the negative terminal from the battery.




SHMM19043N

2. Remove the engine cover (A).




SHMM19044N

3. Remove the radiator grill upper guard (A).




SHMM19045N

4. Loosen the drain plug (A) and drain the engine coolant.



SHMM19046N

Remove the radiator cap (A) to speed draining.




SHMM19047N

WARNING

Never remove the radiator cap when the engine is hot. Serious scalding could be caused by hot fluid under high pressure escaping from the radiator.


Engine Mechanical System

5. Remove the air duct (A) and the air cleaner assembly (B).




SHMM19048N

6. Disconnect the radiator upper hose (A) and lower hose (B).




SHMM19049N

7. Remove the radiator upper shroud (A).




SHMM19050N

8. Remove the cooling fan (A).



SHMM19051N


9. Remove the cooling fan clutch (A).



SHMM19052N

MOTICE


Remove the cooling fan clutch (A) after fixing the cooling fan pulley (B) by inserting a pin (C) into the hole of it.



EMA-117

SHMM19053N

10. Remove the air conditioner high pressure pipe bracket bolt.



SHMM19135N

- 11. Remove the ATF cooler hose, the ATF cooler bracket bolts and the power steering oil cooler bracket bolts.
- 12. Remove the radiator & condenser mounting bolt.
- 13. Remove the radiator assembly from the vehicle.

ال خودرو سامانه (مسئولیت محدود)

، دیجیتال تعمیرکاران خودرو در ایران

Installation

- 1. Install the radiator assembly to the vehicle.
- 2. Install the radiator & condenser mounting bolt.

Tightening torque:

 $7.8 \sim 11.8$ Nm ($0.8 \sim 1.2$ kgf.m, $5.8 \sim 8.7$ lb-ft)

3. Install the ATF cooler hose, the ATF cooler bracket bolts and the power steering oil cooler bracket bolts.


Tightening torque:

 $9.8 \sim 11.8 \text{Nm} \ (1.0 \sim 1.2 \text{kgf.m}, 7.2 \sim 8.7 \text{lb-ft})$

4. Install the air conditioner high pressure pipe bracket bolt.

Tightening torque:

 $7.8 \sim 11.8$ Nm (0.8 ~ 1.2 kgf.m, $5.8 \sim 8.7$ lb-ft)




Engine Mechanical System

5. Install the cooling fan clutch (A).

Tightening torque:


58.8N.m (6.0kgf.m, 43.4lb-ft)



SHMM19052N

MOTICE

Install the cooling fan clutch (A) after fixing the cooling fan pulley (B) by inserting a pin (C) into the hole of it.




SHMM19053N

6. Install the cooling fan (A).

Tightening torque:

 $8.8 \sim 13.7 \text{Nm} \ (0.9 \sim 1.4 \text{kgf.m}, 6.5 \sim 10.1 \text{lb-ft})$




SHMM19051N

7. Install the radiator upper shroud (A).

Tightening torque:


 $7.8 \sim 11.8$ Nm (0.8 ~ 1.2 kgf.m, $5.8 \sim 8.7$ lb-ft)



SHMM19050N

EMA-119

8. Reconnect the radiator upper hose (A) and lower hose (B).




SHMM19049N

Install the air duct (A) and the air cleaner assembly (B).


Tightening torque:

 $9.8 \sim 11.8 \text{Nm} \ (1.0 \sim 1.2 \text{kgf.m}, \ 7.2 \sim 8.7 \text{lb-ft})$




SHMM19048N

10. Install the radiator grill upper guard (A).




SHMM19045N

11. Install the engine cover (A).



SHMM19044N

12. Reconnect the negative terminal from the battery.




SHMM19043N

13. Fill the radiator with coolant and check for leaks.

Engine Mechanical System

Water pump

Components



SHMM19330N


- 1. Drive belt
- 2. Drive belt tensioner
- 3. Drive belt idler
- 4. Cooling fan pulley

- 5. Water pump pulley
- 6. Water pump
- 7. Water pump gasket

EMA-121

Removal

1. Disconnect the negative terminal from the battery.




SHMM19043N

2. Remove the engine cover (A).




SHMM19044N

3. Remove the radiator grill upper guard (A).




SHMM19045N

4. Loosen the drain plug (A) and drain the engine coolant.



SHMM19046N

Remove the radiator cap (A) to speed draining.




SHMM19047N

WARNING

Never remove the radiator cap when the engine is hot. Serious scalding could be caused by hot fluid under high pressure escaping from the radiator.


Engine Mechanical System

5. Remove the air duct (A) and the air cleaner assembly (B).




SHMM19048N

6. Remove the radiator upper shroud (A).




SHMM19050N

7. Remove the cooling fan (A).



SHMM19051N


8. Remove the cooling fan clutch (A).



SHMM19052N

WNOTICE


Remove the cooling fan clutch (A) after fixing the cooling fan pulley (B) by inserting a pin (C) into the hole of it.



SHMM19053N


EMA-123

9. Turn the tensioner (B) clockwise and loosen, then remove the drive belt (A).




SHMM19067N

10. Remove the drive belt tensioner (A).



SHMM19068N

11. Remove the cooling fan pulley (A).




SHMM19088N

ACAUTION


The cooling fan pulley bolt is left-hand thread. To remove the bolt, screw it clockwise.

12. Remove the water pump pulley (A).



SHMM19089N

13. Remove the water pump (A).




SHMM19101N

Engine Mechanical System

Water pipe


- 1. Remove the intake manifold module. (Refer to intake and exhaust system in this group)
- 2. Remove the water outlet pipe (A) and the water inlet pipe (B).



SHMM19084N

MOTICE

Remove the drain plug (A) and drain the engine coolant.




SHMM19085N

Installation

1. Install the water pump (A).

Tightening torque:

19.6 ~ 24.5N.m (2.0 ~ 2.5kgf.m, 14.5 ~ 18.1lb-ft)



SHMM19101N


2. Install the water pump pulley (A).

Tightening torque:

18.6 ~ 23.5Nm (1.9 ~ 2.4kgf.m, 13.7 ~ 17.4lb-ft)

MOTICE

Tighten every bolt diagonally.




SHMM19089N

EMA-125

3. Install the cooling fan pulley (A).

Tightening torque:

 $76.5 \sim 80.4 \text{Nm} (7.8 \sim 8.2 \text{kgf.m}, 56.4 \sim 59.3 \text{lb-ft})$



SHMM19088N

ACAUTION


The cooling fan pulley bolt is left-hand thread.

To assemble the bolt, screw it counterclockwise.

4. Install the drive belt tensioner (A).


Tightening torque:

19.6 ~ 23.5N.m (2.0 ~ 2.4kgf.m, 14.5 ~ 17.4lb-ft)



SHMM19068N

5. Turn the tensioner (B) clockwise and loosen, then install the drive belt (A).




SHMM19067N

6. Install the cooling fan clutch (A).

Tightening torque:

58.8N.m (6.0kgf.m, 43.4lb-ft)




SHMM19052N

Engine Mechanical System

MOTICE

Install the cooling fan clutch (A) after fixing the cooling fan pulley (B) by inserting a pin (C) into the hole of it.




SHMM19053N

7. Install the cooling fan (A).

Tightening torque:

8.8 ~ 13.7Nm (0.9 ~ 1.4kgf.m, 6.5 ~10.1lb-ft)




SHMM19051N

8. Install the radiator upper shroud (A).


Tightening torque:

 $7.8 \sim 11.8$ Nm (0.8 ~ 1.2 kgf.m, $5.8 \sim 8.7$ lb-ft)



SHMM19050N

9. Reconnect the radiator upper hose (A) and lower hose (B).




SHMM19049N

EMA-127

10.Install the air duct (A) and the air cleaner assembly (B).


Tightening torque:

 $9.8 \sim 11.8 \text{Nm} (1.0 \sim 1.2 \text{kgf.m}, 7.2 \sim 8.7 \text{lb-ft})$




SHMM19048N

11. Install the radiator grill upper guard (A).




SHMM19045N

12. Install the engine cover (A).



SHMM19044N

13. Reconnect the negative terminal from the battery.



SHMM19043N

14. Fill the radiator with coolant and check for leaks.

Engine Mechanical System

Water pipe

1. Install the O-ring to the water pipes.

MNOTICE


- Use new O-rings when reassembling.
- Never apply sort of oil on O-ring and O-ring groove of pipe end.
- O-ring must be free from scratching damage.
- 2. Install the water outlet pipe (A) and the water inlet pipe (B).

Tightening torque:

 $9.8 \sim 11.8$ Nm ($1.0 \sim 1.2$ kgf.m, $7.2 \sim 8.7$ lb-ft)

MOTICE

- Make clean the contact face before assembly.
- Insert pipe after to be wetting O-ring or inside of attaching hole by water or antifreeze.




SHMM19084N

MNOTICE

Install the drain plug (A).

Tightening torque:

96.1~100.0N.m(9.8~10.2kgf.m,70.9~73.8lb-ft)



SHMM19085N

3. Install the intake manifold module. (Refer to intake and exhaust system in this group)

EMA-129


Troubleshooting Water Pump

Symptoms		Possibl	Remedy	
Coolant leakage	From the bleed hole of the water pu-	Visually check	Check leaks after about ten-minute	If coolant still leaks, repl- ace a water pump.
	тр		warming up.	If leakage stops, reuse the water pump (Do not replace the pump with a new one).
	From gaskets or b- olts		Check the tightening of the water pump mounting bolts.	Retighten the mounting bolts.
			Check damage of gaskets or inflow of dust.	_
	From outer surface of water pump		Check the material or any cracks of th- e water pump.	Poor material. If any cra- ck found, replace the wa- ter pump.
Noise (عومدود) درایران	From bearingsFrom mechanical seals		After starting the engine, check noise with a stethoscope.	If there is no noise, reuse the water pump(do not r- eplace it).
	Impeller interferen- ce		شرکت	If there is any noise from the water pump, remove the drive belt and rechec- k.
	عمیرکاران خودرو	Inspection after removing a drive belt	After removing a water pump and a drive belt, check n-	If there is noise, reuse the water pump. Check other drive line parts.
			oise again.	If there is no noise, replace the water pump with a new one.
		Inspection after removing a water pump	After removing a water pump and a drive belt, check n- oise again.	If there is any interference between them, replace the water pump with a new one.
Overheating	Damaged impeller Loosened impeller	Loosened impeller	Corrosion of the i- mpeller wing	Check engine coolant. Poor coolant quality / Maintenance check
			Impeller seperation from the shaft	Replace the water pump.

Engine Mechanical System

Thermostat

Components



SHMM19331N


- 1. Water temperature control assembly
- 2. Water temperature control assembly gasket
- 3. Water outlet fitting assembly

- 4. Water outlet fitting assembly gasket
- 5. Water inlet pipe
- 6. Water outlet pipe

EMA-131


Removal

1. Disconnect the negative terminal from the battery.




SHMM19043N

2. Remove the engine cover (A).




SHMM19044N

3. Loosen the drain plug (A) and drain the engine coolant.



SHMM19046N

Remove the radiator cap (A) to speed draining.




SHMM19047N

⊗WARNING

Never remove the radiator cap when the engine is hot. Serious scalding could be caused by hot fluid under high pressure escaping from the radiator.


4. Remove the air duct (A) and the air cleaner assembly (B).



SHMM19048N


Engine Mechanical System

5. Disconnect the ETC module connector (A).




SHMM19070N

6. Disconnect the PCV hose (A), the PCSV hose (B) and the water hoses (C) from the intake manifold module and the throttle body.




SHMM19081N

- 7. Remove the throttle body.
- 8. Remove the water temperature control assembly (A).



SHMM19102N

9. Remove the O-ring (A).




SHMM19103N

EMA-133

Installation

1. Install the O-ring (A).



SHMM19103N


2. Install the water temperature control assembly (A).

Tightening torque:

 $16.7 \sim 19.6 \text{N.m} \ (1.7 \sim 2.0 \text{kgf.m}, \ 12.3 \sim 14.5 \text{lb-ft})$


MOTICE

The protrusion of the gasket must be face the front of the engine.




SHMM19102N

- 3. Install the throttle body. (Refer to FL group)
- 4. Reconnect the PCV hose (A), the PCSV hose (B) and the water hoses (C) to the intake manifold module and the throttle body.



SHMM19081N

5. Reconnect the ETC module connector (A).




SHMM19070N

Engine Mechanical System

6. Install the air duct (A) and the air cleaner assembly (B).


Tightening torque:

 $9.8 \sim 11.8 \text{Nm} (1.0 \sim 1.2 \text{kgf.m}, 7.2 \sim 8.7 \text{lb-ft})$




SHMM19048N

7. Install the radiator grill upper guard (A).




SHMM19045N

8. Install the engine cover (A).



SHMM19044N

9. Reconnect the negative terminal from the battery.



SHMM19043N

10. Fill the radiator with coolant and check for leaks.

EMA-135

Troubleshooting

Symptoms		Possible Causes			Remedy		
Coolant leakage	•	From the therm- ostat gasket	Check the mounting bolts	•	Check the torque of the mounting bolts	•	Retighten the bolts and check leakage again.
			Check the gasket for damage	•	Check gasket or seal f- or damage	•	Replace gaskets and reuse the thermostat.
Cooled excessively		Low heater performance (cool air blowed-out) Thermogauge indicates 'LOW'	Visually check after removing the radiator cap.	1	Insufficient coolant or I-eakage.	•	After refilling coolant, recheck.
			GDS check & Starting engine	• * ys	Check DTCs Check connection of the fan clutch or the fan motor. If the fan clutch is alwaconnected, there will be noise at idle.	•	Check the engine coolant sensor, wiring and connectors. Replace the componants
			Remove the thermostat and inspect		Check if there are dusts or chips in the thermostat valve. Check adherence of the thermostat.		Clean the thermostat valve and reuse the thermostat. Replace the thermostat, if it doesn't work properly.
Heated excessively	يد	Engine overheated Thermogauge indicates 'HI'	Visually check after removing the radiator cap.		Insufficient coolant or I-eakage. ** Be careful when removing a radiator cap of the overheated vehicle. Check air in cooling system.		After refilling coolant, recheck. Check the cylinder head gaskets for damage and the tightening torque of the mounting bolts.
			GDS check & Starting engine		Check DTCs Check the fan motor performance as temperature varies. Check if the fan clutch slips. Check the water pump adherence or impeller damaged.	•	Check the engine coolant sensor, wiring and connectors. Check the fan motor, the relay and the connector. Replace the fan clutch, if it doesn't work properly. Replace the water pump, if it doesn't work properly.
			Immerse the thermostat in boiling water and inspection.	* pe	After removing the thermostat, check it works properly. Check the thermostat ones at the valve opening toperature.	•	Replace the thermostat, if it doesn't work properly .

Engine Mechanical System


Lubrication System

Engine Oil

Engine Oil And Filter Replacement


ACAUTION

- Prolonged and repeated contact with mineral oil will result in the removal of natural fats from the skin, leading to dryness, irritation and dermatitis. In addition, used engine oil contains potentially harmful contaminants which may cause skin cancer.
- Exercise caution in order to minimize the length and frequency of contact of your skin to used oil.
 Wear protective clothing and gloves. Wash your skin thoroughly with soap and water, or use water-less hand cleaner, to remove any used engine oil. Do not use gasoline, thinners, or solvents.
- In order to preserve the environment, used oil and used oil filter must be disposed of only at designated disposal sites.
- Park the car on level ground.
 Start the engine and let it warm up.
- 2. Drain engine oil.
 - 1) Remove the oil filler cap.
 - After lifting the car, remove the oil drain plug (A) and drain oil into a container.



SHMM19156N

- 3. Replace the oil filter.
 - 1) Remove the oil filter cap from the oil filter body.
 - 2) Remove the oil filter element.
 - 3) Check and clean the oil filter installation surface.
 - 4) Check the part number of a new oil filter is same as old one.
 - 5) Install a new oil filter element (A) and two new O-rings (B).



SHMM19158N

- 6) Apply clean engine oil to the new O-rings.
 Lightly screw the oil filter cap into place, and tighten it until the O-ring contacts the seat.
- 7) Finally tighten it again by specified tightening torque.

Tightening torque:

25N.m (2.54kgf.m, 18.4lb-ft)

Lubrication System

EMA-137

- 4. Fill new engine oil.
 - 1) Install the oil drain plug with a new gasket.

Tightening torque:

34.3 \sim 44.1N.m (3.5 \sim 4.5kgf.m, 25.3 \sim 32.5lb-ft)

2) Fill with new engine oil, after removing the engine oil level gauge.

Capacity

Total: 7.5L (7.92US qt, 6.59Imp qt) Oil pan: 6.2 L (6.55 US qt, 5.46 Imp qt)

Drain and refill including oil filter: 6.7L (7.07US qt,

5.89lmp qt)

- Fill a half oil of the total amount first and do the rest again after about one minute later.
- Do not fill oil over the 'F' line, checking the level with the oil level gauge.
- 3) Install the oil filler cap and oil level gauge.
- 5. Start the engine and check to be sure no oil is leaking from the drain plug or oil filter.
- 6. Recheck the engine oil level.

Inspection

- 1. Check the engine oil quality. Check the oil deterioration, entry of water, discoloring of thinning. If the quality is visibly poor, replace the oil.
- 2. Check the engine oil level.

After warming up the engine and then 5 minutes after the engine stop, oil level should be between the "L" and "F" marks in the dipstick.

If low, check for leakage and add oil up to the "F" mark.

MOTICE

Do not fill with engine oil above the "F" mark.





Engine Mechanical System


Selection Of Engine Oil

Recommendation (except Middle East): 5W-20/GF4&SM (If not available, refer to the recommended API or ILSAC

classification and SAE viscosity number.)
API classification : SL, SM or above
ILSAC classification : GF3. GF4 or above

SAE viscosity grade: Refer to the recommended SAE

viscosity number.



SAMM29103L

MNOTICE

For best performance and maximum protection of all types of operation, select only those lubricants which:


- 1. Satisfy the requirement of the API or ILSAC classification.
- 2. Have proper SAE grade number for expected ambient temperature range.
- 3. Lubricants that do not have both an SAE grade number and API or ILSAC service classification on the container should not be used.

Lubrication System

EMA-139

Oil Pump

Components



SHMM19332N

- 1. Oil filter cap
- 2. Oil filter cap O-ring
- 3. Oil filter
- 4. Oil filter assembly


- 5. Oil filter assembly gasket
- 6. Oil cooler assembly
- 7. Oil cooler gasket
- 8. Lower oil pan

- 9. Upper oil pan
- 10. Oil level gauge
- 11. Oil pump sprocket
- 12. Oil pump assembly

Engine Mechanical System


Removal

- 1. Drain engine oil.
 - 1) Remove the oil filler cap.
 - 2) After lifting the car, remove the oil drain plug (A) and drain oil into a container.



SHMM19156N


2. Remove the oil filter and oil cooler assembly (A).



SHMM19090N

3. Remove the lower oil pan(A).

Insert the blade of SST(09215-3C000) between the upper oil pan and the lower oil pan. Cut off applied sealer and remove the lower oil pan.



SHMM19315N

MOTICE


- Insert the SST between the lower oil pan and the upper oil pan by tapping it with a plastic hammer in the direction of (1) arrow.
- After tapping the SST with a plastic hammer along the direction of (2) arrow around more than 2/3 edge of the lower oil pan, remove it from the lower oil pan.
- Do not turn over the SST abruptly without tapping. It be result in damage of the SST.
- Be careful not to damage the contact surfaces of Upper oil pan and lower oil pan.

Lubrication System

EMA-141

4. Remove the upper oil pan (A).


Insert the blade of SST(09215-3C000) between the upper oil pan and the cylinder block. Cut off applied sealer and remove upper oil pan.



SHMM19316N

MOTICE

- Insert the SST between the upper oil pan and the cylinder block by tapping it with a plastic hammer in the direction of (1) arrow.
- After tapping the SST with a plastic hammer along the direction of (2) arrow around more than 2/3 edge of the upper oil pan, remove it from the upper oil pan.
- Do not turn over the SST abruptly without tapping. It be result in damage of the SST.
- Be careful not to damage the contact surfaces of Upper oil pan and cylinder block.
- 5. Remove the oil pump assembly (A) after remove the oil pump sprocket (B).



SHMM19348N

Installation

1. Install the oil pump assembly (A) and then oil pump sprocket (B).


Tightening torque:

Oil pump assembly bolts:

 $19.6 \sim 23.5 \text{Nm} \ (2.0 \sim 2.4 \text{kgf.m}, 14.5 \sim 17.4 \text{lb-ft})$

Oil pump sprocket bolts:

 $21.6 \sim 25.5$ Nm ($2.2 \sim 2.6$ kgf.m, $15.9 \sim 18.8$ lb-ft)




SHMM19348N

- 2. Install the upper oil pan.
 - Using a gasket scraper, remove all the old packing material from the gasket surfaces.
 - Before assembling the oil pan, the liquid sealant TB1217H or LT5900H should be applied on upper oil pan.

The part must be assembled within 5 minutes after the sealant was applied.

Bead width: 2.5mm(0.1in)




SHMM19143N

Engine Mechanical System

MOTICE

- Clean the sealing face before assembling two parts.
- Remove harmful foreign materials on the sealing face before applying sealant.
- When applying sealant gasket, sealant must not protrude into the inside of oil pan.
- To prevent leakage of oil, apply sealant gasket to the inner threads of the bolt holes.
- 3) Install the upper oil pan.




SHMM19094N

Uniformly tighten the bolts in several passes.

Tightening torque:

9.8 ~ 11.8Nm (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)




SHMM19145N

- 3. Install the lower oil pan.
 - 1) Using a gasket scraper, remove all the old packing material from the gasket surfaces.
 - 2) Before assembling the oil pan, the liquid sealant TB1217H or LT5900H should be applied on lower oil pan.

The part must be assembled within 5 minutes after the sealant was applied.

Bead width: 2.5mm(0.1in)



SHMM19146N


UNOTICE

- Clean the sealing face before assembling two parts.
- Remove harmful foreign materials on the sealing face before applying sealant.
- When applying sealant gasket, sealant must not protrude into the inside of oil pan.
- To prevent leakage of oil, apply sealant gasket to the inner threads of the bolt holes.


Lubrication System

EMA-143

3) Install the lower oil pan.



Tightening torque:



4. Install the oil filter and oil cooler assembly (A).


Tightening torque:

Oil filter assembly bolts:

 $19.6 \sim 23.5 \text{Nm} (2.0 \sim 2.4 \text{kgf.m}, 14.5 \sim 17.4 \text{lb-ft})$


Oil cooler bolts:

 $9.8 \sim 11.8 \text{Nm} \ (1.0 \sim 1.2 \text{kgf.m}, 7.2 \sim 8.7 \text{lb-ft})$



SHMM19090N

5. Refill the engine oil.



SHMM19147N


Engine Mechanical System

Oil Pressure Switch


Inspection

1. Check the continuity between the terminal and the body with an ohmmeter.

If there is no continuity, replace the oil pressure switch.



Check the continuity between the terminal and the body when the fine wire is pushed. If there is continuity even when the fine wire is pushed, replace the switch.



ECKD001Y






Intake And Exhaust System

EMA-145

Intake And Exhaust System

Intake Manifold

Components



SHMM19333N


- 1. PCSV (Purge control solenoid valve)
- 2. Delivery pipe assembly
- 3. Injector clip
- 4. Injector

- 5. VIS solenoid valve
- 6. ETC module
- 7. Intake manifold module

Engine Mechanical System


Removal

1. Disconnect the negative terminal from the battery.




SHMM19043N

2. Remove the engine cover (A).




SHMM19044N

3. Remove the air duct (A) and the air cleaner assembly (B).




SHMM19048N

4. Disconnect the fuel hose (A) and the purge control solenoid valve (PCSV) hose (B).




SHMM19375N

5. Disconnect the ETC module connector (A).



SHMM19070N


6. Disconnect the PCSV connector (A) and the injector connectors (B).



SHMM19071N


EMA-147

7. Disconnect the variable intake system solenoid valve connector (A) and the wiring harness protector (B).




SHMM19074N

8. Disconnect the injector connectors (A).




SHMM19076N

9. Disconnect the PCV hose (A), the PCSV hose (B) and the water hoses (C) from the intake manifold module and the throttle body.



SHMM19081N

10. Remove the intake manifold module (A).



SHMM19082N

Engine Mechanical System

Installation

1. Installation the intake manifold module (A), tighten the nuts as following method.


Tightening torque:


1st step:

 $4.9 \sim 7.8$ N.m (0.5 \sim 0.8kgf.m, 3.6 \sim 5.8lb-ft)


2nd step:

19.6 \sim 26.5N.m (2.0 \sim 2.7kgf.m, 14.5 \sim 19.5lb-ft)






2. Reconnect the PCV hose (A), the PCSV hose (B) and




SHMM19081N

3. Reconnect the injector connectors (A).



SHMM19076N






SHMM19153N


EMA-149

4. Reconnect the variable intake system solenoid valve connector (A) and the wiring harness protector (B).




SHMM19074N

5. Reconnect the PCSV connector (A) and the injector connectors (B).




SHMM19071N

6. Reconnect the ETC module connector (A).




SHMM19070N

7. Reconnect the fuel hose (A) and the purge control solenoid valve (PCSV) hose (B).



SHMM19304N


8. Install the air duct (A) and the air cleaner assembly (B).



SHMM19048N

Engine Mechanical System

9. Install the engine cover (A).



SHMM19044N

10. Reconnect the negative terminal to the battery.






SHMM19043N

EMA-151

Exhaust Manifold

Components



SHMM19334N


- 1. Exhaust manifold heat protector
- 2. Exhaust manifold

- 3. Exhaust manifold gasket
- 4. Exhaust manifold stay

Engine Mechanical System

Removal

1. Disconnect the negative terminal from the battery.




SHMM19043N

2. Remove the engine cover (A).




SHMM19044N

Remove the air duct (A) and the air cleaner assembly (B).




SHMM19048N

4. Remove the oil level gauge (A).




SHMM19001N

5. Disconnect the oxygen sensor connector (A) and remove the oxygen sensor connector bracket (B).





SHMM19079N




SHMM19080N

EMA-153






SHMM19351N




SHMM19352N

7. Remove the exhaust manifold heat protector (A).




SHMM19002N




SHMM19003N

8. Remove the exhaust manifold (A).



SHMM19063N



SHMM19064N

Engine Mechanical System

Installation


1. Install the exhaust manifold (A).

Tightening torque:

 $49.0 \sim 53.9$ N.m ($5.0 \sim 5.5$ kgf.m, $36.2 \sim 39.8$ lb-ft)

MOTICE


The "TOP" mark of the gasket must be face the exhaust manifold.






Tighten the exhaust manifold mounting nuts as following method.

[LH]




SHMM19154N

[RH]



SHMM19064N




SHMM19363N

EMA-155


2. Install the exhaust manifold heat protector (A).

Tightening torque:

 $8.8 \sim$ 10.8 N.m (0.9 \sim 1.1kgf.m, 6.5 \sim 8.0lb-ft)



SHMM19002N




SHMM19003N


3. Install the LH/RH exhaust manifold stay (A).

Tightening torque:

34.3 \sim 41.2N.m (3.5 \sim 4.2kgf.m, 25.3 \sim 30.4lb-ft)




SHMM19351N




SHMM19352N

Engine Mechanical System

4. Reconnect the oxygen sensor connector (A) and Install the oxygen sensor connector bracket (B).



SHMM19079N




SHMM19080N

5. Install the oil level gauge (A).

Tightening torque:

 $9.8 \sim 11.8 \text{Nm} \ (1.0 \sim 1.2 \text{kgf.m}, \ 7.2 \sim 8.7 \text{lb-ft})$




SHMM19001N

6. Install the air duct (A) and the air cleaner assembly (B).

Tightening torque:


9.8 ~ 11.8Nm (1.0 ~ 1.2kgf.m, 7.2 ~ 8.7lb-ft)



SHMM19048N

EMA-157

7. Install the engine cover (A).



SHMM19044N

8. Reconnect the negative terminal to the battery.






SHMM19043N

Engine Mechanical System

Muffler

Components



SHMM19335N


- 1. Front muffler
- 2. Catalytic converter

- 3. Main muffler
- 4. Tail pipe

EMA-159


Removal

1. Remove the front muffler (A).




SHMM19157N

2. Remove the main muffler (A).



SHMM19138N

3. Remove the tail pipe (A).




SHMM19139N

Installation

1. Install the tail pipe (A).

Tightening torque:

 $39.2 \sim 58.8 \text{Nm} \; (4.0 \sim 6.0 \text{kgf.m}, \, 28.9 \sim 43.4 \text{lb-ft})$




SHMM19139N

2. Install the main muffler (A).

Tightening torque:

39.2 ~ 58.8Nm (4.0 ~ 6.0kgf.m, 28.9 ~ 43.4lb-ft)




SHMM19138N

Engine Mechanical System

3. Install the front muffler (A).

Tightening torque:

 $39.2 \sim 58.8$ Nm ($4.0 \sim 6.0$ kgf.m, $28.9 \sim 43.4$ lb-ft)



SHMM19157N



