

## General Information

## ATA-3

### General Information

#### Specifications

Item	Specifications	
Transmission type	A6MF2	
Engine model	Gasoline 2.4 GDI	
Torque converter type	3-element, 1-stage, 2-phase type	
Torque converter size	Ø236 mm (9.2913 in.)	
Oil pump system	Parachoid	
Friction elements	Clutch: 2EA	
	Brake: 3EA	
	OWC : 1EA	
Planetary gear	3EA	
Gear ratio	1st	4.212
	2nd	2.637
	3rd	1.800
	4th	1.386
	5th	1.000
	6th	0.772
	Reverse	3.385
Final gear ratio	2.885	
Fluid pressure balance piston	2EA	
Accumulator	4EA	
Solenoid valve	8EA (VFS:6EA, ON/OFF:2EA)	
Shift lever position	4 Range (P,R,N,D)	
Oil filter	1EA	

VFS: Variable Force Solenoid

## ATA-4

## Automatic Transaxle System

## Sensors

Input Speed Sensor

▷ Type: Hall effect sensor

▷ Specifications

Operation condition (°C)°F		((-40~150)) -40~302
Air gap(mm)in.		(0.95~1.65)0.037~0.065
Output voltage(V)	High	1.18~1.68
	Low	0.59~0.84

Output Speed Sensor

▷ Type: Hall effect sensor

▷ Specifications

Operation condition (°C)°F		((-40~150)) -40~302
Air gap(mm)in.		(0.55~1)0.0217~0.0394
Output voltage	High	1.18~1.68
	Low	0.59~0.84

## Oil Temperature Sensor

▷ Type: Negative thermal coefficient type

▷ Specifications

Temp. [(°C)°F]	Resistance (kΩ)
(-40)-40	48.1
(-20)-4.0	15.6
(0)32.0	5.88
(20)68.0	2.51
(40)104.0	1.11
(60)140.0	0.61
(80)176.0	0.32
(100)212.0	0.18
(120)248.0	0.10
(140)284.0	0.06
(150)302.0	0.05

## Inhibitor Switch

▷ Type: Combination of output signals from 4 terminals

▷ Specifications

Power supply (V)	12
Output type	Pin to Pin

## Solenoid Valves

Direct control VFS[26/B, T/CON]

▷ Control type : Normal low type

Control Pressure kpa (kgf/cm <sup>2</sup> , psi)	9.81~500.14 (0.1~5.1, 1.42~72.54)
Current value(mA)	50~850
Internal resistance(Ω)	5.1

Direct control VFS[UD/B, OD/C, 35R/C]

▷ Control Type : Normal high type

Control Pressure kpa (kgf/cm <sup>2</sup> , psi)	500.14~9.81 (5.1~0.1, 72.54~1.42)
Current value(mA)	50~850
Internal resistance(Ω)	5.1

Line Pressure Control VFS

▷ Control type : Normal high type

Control Pressure kpa (kgf/cm <sup>2</sup> , psi)	500.14~9.81 (5.1~0.1, 72.54~1.42)
Current value(mA)	50~850
Internal resistance(Ω)	5.1

ON/OFF Solenoid Valve(SS-A, SS-B)

▷ Control type : Normal low type

Control pressure kpa (kgf/cm <sup>2</sup> , psi)	490.33(5.0, 71.12)
Internal resistance(Ω)	10~11

## General Information

## ATA-5

Solenoid Valve Operation Table

	SS-A	SS-B	UD/B-VFS	OD/C-VFS	35R/C-VFS	26/B-VFS
			N/H	N/H	N/H	N/L
N, P	●		●		●	
1	△			△	●	
2				●	●	●
3		●		●		
4					●	
5		●	●			
6			●		●	●
L	●				●	
R	●	●	●			

● : Connected status

△ : Connected at vehicle speed above 8km/h

# دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



## ATA-6

## Automatic Transaxle System

## Tightening Torques

Item	N.m	Kgf.m	lb-ft
TCM installation mounting bolt	9.8~11.8	1.0~1.2	7.2~8.7
Shift cable bracket mounting bolt	14.7~21.6	1.5~2.2	10.8~15.9
Input shaft speed sensor mounting bolt	9.8~11.8	1.0~1.2	7.2~8.7
Output shaft speed sensor mounting bolt	9.8~11.8	1.0~1.2	7.2~8.7
Shift lever assembly bolt	9.8~14.7	1.0~1.5	7.2~10.8
Inhibitor switch mounting bolt	9.8~11.8	1.0~1.2	7.2~8.7
Valve body cover mounting bolt	13.8~14.7	1.3~1.5	9.4~10.8
Eyebolt	34.3~44.1	3.5~4.5	25.3~32.6
Oil drain plug	34.3~44.1	3.5~4.5	25.3~32.6
Oil level plug	34.3~44.1	3.5~4.5	25.3~32.6
Torque converter mounting bolt	45.1~52.0	4.6~5.3	33.3~38.3
Starter motor mounting bolts	42.2~53.9	4.3~5.5	31.1~39.8
Automatic transaxle upper mounting bolt (TM=>Eng)	42.2~53.9	4.3~5.5	31.1~39.8
Automatic transaxle lower mounting bolt (Eng=>TM)	42.2~48.1	4.3~4.9	31.1~35.4
	42.2~53.9	4.3~5.5	31.1~39.8
Automatic transaxle support bracket bolt	88.3~107.9	9.0~11.0	65.1~79.6

## Lubricants

Item	Specified lubricant	Quantity
Transaxle fluid	SK ATF SP-IV, MICHANG ATF SP-IV, NOCA ATF SP-IV, Kia Genuine ATF SP-IV	7.1L (1.88 U.S gal., 7.50 U.S.qt., 6.24 Imp.qt.)

Item	Specified sealant
------	-------------------




## Sealant


Rear cover	LOCTITE FMD-546 or THREE-BOND TB1281B
Torque converter housing	
Valve body cover	

# General Information

# ATA-7

## Special Service Tools

Tools (Number and name)	Illustration	Use
09200-38001 Engine support fixture	 <p style="text-align: right;">KKBF030A</p>	Removal and installation of the transaxle.
09453-3L240 Oil seal installer	 <p style="text-align: right;">S97AT9116D</p>	Installation of transaxle case oil seal. [Using with handle (SST No.:09231-H1100)]
09231-H1100 Bar	 <p style="text-align: right;">SLD766035D</p>	Installation of transaxle case oil seal. [Using with oil seal installer (SST No.:09453-3L240)]

**ATA-8****Automatic Transaxle System****Automatic Transaxle System****Automatic Transaxle****Components Location**

STFAT1001D

- |                             |                             |
|-----------------------------|-----------------------------|
| 1. Converter housing        | 5. Manual control lever     |
| 2. Automatic transaxle case | 6. Air breather hose        |
| 3. Rear cover               | 7. Inhibitor switch         |
| 4. Valve body cover         | 8. Solenoid valve connector |


# Automatic Transaxle System

## ATA-9

### Removal

1. Remove the following items;

- Engine cover (A).
- Air cleaner assembly and air duct (B). (Refer to "Intake and Exhaust system" in EM group.)
- Battery and battery tray (C). (Refer to "Charging system" in EE group.)




STFAA1002D

# ATA-10


# Automatic Transaxle System

2. Remove the ground line after removing the bolt (A).



STFAT1003N

3. Disconnect the solenoid valve connector (A) and inhibitor switch connector (B).




STFAT1004N

4. Remove the control cable (C) after removing the nut (A) and the bolt (B).


**Tightening torque:**

- (A) 9.8 ~ 14.7 N.m (1.0 ~ 1.5 kgf.m, 7.2 ~ 10.8 lb-ft)
- (B) 14.7 ~ 21.6 N.m (1.5 ~ 2.2 kgf.m, 10.9 ~ 15.9 lb-ft)



SLMAT0005D

5. Remove the solenoid valve connector and inhibitor switch connector wiring mounting bracket (A).




SSLAT0046D



# Automatic Transaxle System


# ATA-11

6. Disconnect the hose (B) after removing the automatic transaxle fluid cooler hose clamp (A).



SSLAT0042D

7. Remove the wiring bracket installation bolt (A).




STFAT1003D

8. Remove the automatic transaxle upper mounting bolt (A-2ea) and the starter motor mounting bolt (B-2ea).


**Tightening torque:**

(A),(B): 42.2 ~ 54.0 N.m (4.3 ~ 5.5 kgf.m, 31.1 ~ 39.8 lb-ft)



SYFAT0001D

9. Remove the mounting cover (A).



STFAT1004D


# ATA-12

# Automatic Transaxle System

10. Remove the support bracket mounting bolts (A).


**Tightening torque:**

88.3 ~ 107.9 N.m (9.0 ~ 11.0 kgf.m, 65.1 ~ 79.8 lb-ft)



STFAT1005D

11. Using the engine support fixture (SST No.: 09200-38001), hold the engine and transaxle assembly safely.




SHDAA6002D

12. Remove the automatic transaxle mounting support bracket (C).

**Tightening torque:**

(A) 78.5 ~ 98.1 N.m (8.0 ~ 10.0 kgf.m, 57.9 ~ 72.3 lb-ft)

(B) 58.9 ~ 78.5 N.m (6.0 ~ 8.0 kgf.m, 43.4 ~ 57.9 lb-ft)




STFAT1006N

13. Lift the vehicle with a jack.

14. Remove the under cover (A).

**Tightening torque:**

7.8 ~ 11.8 N.m (0.8 ~ 1.2 kgf.m, 5.8 ~ 8.7 lb-ft)




STFAT1007D

# Automatic Transaxle System

## ATA-13

15. Remove the wiring bracket installation bolt (A).




STFAT1008D

16. Remove the following items;

- Sub frame assembly. (Refer to "Front suspension system" in SS group.)
- Drive shaft assembly. (Refer to "Drive shaft assembly" in DS group.)

17. Remove the dust cover (A).




SYFAT0025D

18. Remove the torque converter mounting bolt (A-4ea) with rotating the crankshaft.


**Tightening torque:**

45.1 ~ 52.0 N.m (4.6 ~ 5.3 kgf.m, 33.3 ~ 38.3 lb-ft)



SYFAT0004D

19. Remove the drive shaft cover mounting bolt (A).



STFAT1009D

## ATA-14


## Automatic Transaxle System

20. Remove the automatic transaxle with a jack after removing the mounting bolt (A-4ea, B-2ea).

**Tightening torque:**

(A) 42.2 ~ 48.1 N.m (4.3 ~ 4.9 kgf.m, 31.1 ~ 35.4 lb-ft)

(B) 42.2 ~ 54.0 N.m (4.3 ~ 5.5 kgf.m, 31.1 ~ 39.8 lb-ft)



SYFAT0024D

**Installation**

1. Installation is the reverse of removal.

**CAUTION**

If the oil seal on the transaxle case side is damaged and fluid is leaking, replace the oil seal with a new unit. When installing the new oil seal, use the specialized tool (oil seal installer, 09453-3L240).

**NOTICE**

After replacement or reinstallation procedure of the automatic transaxle assembly, must perform procedures below.

- Adding automatic transaxle fluid. (Refer to "Hydraulic system (Fluid)" in this group)
- After servicing the automatic transaxle or TCM, clear the diagnostic trouble codes (DTC) using the GDS tool.  
*Diagnostic trouble codes (DTC) cannot be cleared by disconnecting the battery.*
- When deleting diagnostic trouble code, use the GDS as possible.
- When replacing the automatic transaxle, reset the automatic transaxle's values by using the GDS.
- Perform TCM learning after replacing the transaxle to prevent slow transaxle response, jerky acceleration and jerky startup. (Refer to "Automatic transaxle control system (Repair procedures)" in this group)

# Hydraulic System

ATA-15

## Hydraulic System

### Description

The hydraulic system consists of oil, an oil filter, an oil pump, and a valve body (valves and solenoid valves). The oil pump is powered by the engine. ATF passes through the oil filter and gets distributed along the oil channels. The oil becomes highly pressurized as it exits the oil pump and passes through the line pressure valve before being fed to the clutch & brake control valve, clutch, and brakes. TCM controls the hydraulic pressure using solenoid valves and controls clutch and brake operations.

# دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



# ATA-16

# Automatic Transaxle System

## Components Location



SSLAT0001D

- 1. Automatic transaxle
- 2. Valve body assembly
- 3. Oil pump assembly


# Hydraulic System

## ATA-17

### Oil Pump


#### Description

The oil pump is built-in as a single unit with the 26 brake chamber. Rotation of the pump builds the hydraulic pressure needed for the lubrication of the various parts of the transaxle and operation of the clutch and brakes. The oil also circulates through the torque converter and the cooler.



SSLAT0101D

#### Components



SSLAT0002D


1. Reaction shaft support assembly
2. Oil pump housing
3. Driven gear
4. Drive gear
5. Oil seal

6. Bushing-Housing
7. Reaction shaft
8. Bushing-Reaction shaft
9. Sleeve
10. Bolt

# ATA-18

# Automatic Transaxle System

## Oil Pump Operation Flow



SSLAT0003D

- 1. Inhale(Oil filter)
- 2. Inhale(Valve body)
- 3. Outlet
- 4. 26/B operation pressure

- 5. 35R/C operation pressure
- 6. Lubrication
- 7. Line up clutch operation pressure
- 8. Line up clutch cancellation




# Hydraulic System

# ATA-19

## Fluid

### Components Location



STFAT1017D

1. Injection hole(eyebolt)
2. Oil level plug
3. Oil drain plug

## ATA-20

## Automatic Transaxle System

### Service Adjustment Procedure

#### Oil level Check

##### **NOTICE**

A check of ATF level is not normally required during scheduled services. If an oil leak is found, perform the oil level check procedure after repairs are completed.

##### **CAUTION**

When checking the oil level, be careful not to enter dust, foreign matters, etc. from fill hole.

1. Remove the eyebolt (A).


#### Eyebolt tightening torque:

34.3 ~ 44.1 N.m (3.5 ~ 4.5 kgf.m, 25.3 ~ 32.6 lb-ft)

##### **CAUTION**

Always replace the gasket of the eyebolt use new one whenever loosening eyebolt.

2. Add ATF SP-IV 700cc to the ATF injection hole.




SLMAT0008D

3. Start the engine. (Don't step on brake and accelerator simultaneously.)
4. Confirm that the temperature of the A/T oil temperature sensor is 50~60°C(122~140°F) with the GDS.
5. Shift the select lever slowly from "P" to "D", then "D" to "P" and repeat one more at idle.

##### **CAUTION**

Keep on each speed position more than 2 sec.

6. Lift the vehicle, then remove the oil level plug (A) from the valve body cover.



SVGAT0002D

##### **CAUTION**

At this time, the vehicle must be at a level state.

7. If the oil flows out of the overflow plug in thin steady stream, the oil level is correct.

Then finish the procedure and tighten the oil plug.

##### **NOTICE**

Oil level check (excess or shortage) method

- Excess: Oil flows out in thick stream.
- Shortage: No oil flows out of the overflow plug.

##### **CAUTION**

If there is no damage at the automatic transaxle and the oil cooler, the oil cooler hose, transaxle case, valve body tightening state are normal, ATF must drip out after performing above 1 to 7 procedures. After performing above 1 to 7 procedures, if the oil doesn't drip out, inspect the automatic transaxle assembly.

##### **CAUTION**

Replace the gasket of the oil level plug and use new one whenever loosening the oil level plug.

#### Oil level plug tightening torque:

34.3 ~ 44.1 N.m (3.5 ~ 4.5 kgf.m, 25.3 ~ 32.6 lb-ft)

8. Put down the vehicle with the lift and then tighten the eyebolt.

# Hydraulic System

## ATA-21

### Replacement


#### NOTICE

ATF of 6 speed automatic transaxle doesn't need to be replaced. If the vehicle is used severely in business or personal use, replace ATF every 60,000 miles.

Severe usage is defined as

- Driving in rough road (Bumpy, Gravel, Snowy, Unpaved road, etc)
- Driving in mountain road, ascent/descent
- Repetition of short distance driving
- More than 50% operation in heavy city traffic during hot weather above 32° C (89.6° F) .
- Police, Taxi, Commercial type operation or trailer towing, etc

1. Remove the drain plug (A) and reinstall the drain plug after draining ATF totally.



SYFAT0003D

#### Drain plug tightening torque:

34.3 ~ 44.1 N.m (3.5 ~ 4.5 kgf.m, 25.3 ~ 32.6 lb-ft)



#### CAUTION

The gasket of the drain plug use new one.

2. Fill the oil about 5 liters through eyebolt.
3. Check the oil level. (Refer to "Hydraulic system (Fluid)" in this group)


## ATA-22

## Automatic Transaxle System

### Valve Body


#### Description

The valve body is essential to automatic transaxle control and consists of various valves used to control the oil feed from the oil pump. Specifically, these valves consist of pressure regulator valves, oil redirection valves, shift valves, and manual valves. The body also features electronic solenoid valves that ensure smooth gear changes.



SSLAT0103D

### Components Location



SSLAT0004D


1. PCV adjust screw
2. Solenoid valve
3. Oil temperature sensor

4. Accumulator
5. Low & reverse brake(LR/B) pressure flow hole
6. Under drive brake (UD/B) pressure flow hole

# Hydraulic System

# ATA-23

## Valve Body Flow



SSLAT0005D

- |                             |                            |
|-----------------------------|----------------------------|
| 1. To cooler                | 9. Lubrication(front)      |
| 2. From cooler              | 10. 35R clutch pressure    |
| 3. Lubrication(rear)        | 11. 26 brake pressure      |
| 4. Overdrive pressure       | 12. From oil pump          |
| 5. Reducing pressure (red2) | 13. To oil pump            |
| 6. Reducing pressure (red1) | 14. Underdrive pressure    |
| 7. From damper pressure     | 15. Low & reverse pressure |
| 8. To damper pressure       |                            |

## ATA-24


## Automatic Transaxle System

## Removal

1. Remove the battery and the battery tray. (Refer to "Charging system" in EE group.)
2. Remove the under cover (A).

## Tightening torque:

7.8 ~ 11.8 N.m (0.8 ~ 1.2 kgf.m, 5.8 ~ 8.7 lb-ft)



STFAT1007D

3. Replace new gasket and the plug after draining the automatic transaxle fluid by removing the drain plug. (Refer to "Hydraulic system (Fluid)" in this group)
4. Remove the valve body cover (B) and eyebolt (A).


## Tightening torque:

(A) 34.3 ~ 44.1 N.m (3.5 ~ 4.5 kgf.m, 25.3 ~ 32.6 lb-ft)

(B) 13.8 ~ 14.7 N.m (1.3 ~ 1.5 kgf.m, 9.4 ~ 10.8 lb-ft)

## ⚠ CAUTION

Always replace the gasket of the eyebolt use new one whenever loosening eyebolt.




STFAT1018D

5. Remove the plate and the detent spring (A) after removing the bolt.

## Tightening torque:

24.5 ~ 35.3 N.m (2.5 ~ 3.6 kgf.m, 18.1 ~ 26.0 lb-ft)



SLMAT0023D


# Hydraulic System

# ATA-25

6. Remove the bolt (3ea) after disconnecting the solenoid valve (A) connector and the oil temperature sensor connector (B).

### Tightening torque:

9.8 ~ 11.8 N.m (1.0 ~ 1.2 kgf.m, 7.2 ~ 8.7 lb-ft)




SSLAT1112N

7. Remove the valve body assembly (A).

### Tightening torque:

9.8 ~ 11.8 N.m (1.0 ~ 1.2 kgf.m, 7.2 ~ 8.7 lb-ft)



SCMAT0008L

## Installation

1. Installation is the reverse of removal.

### CAUTION

After replacement or reinstallation procedure of the valve body assembly, must perform procedures below.

### NOTICE

- Continue to apply liquid gasket at application points at the valve body cover with  $\varnothing 2.5\text{mm}$  (0.0984in.) thickness.

Liquid gasket Part name :

Threebond 1281B or LOCTITE FMD-546

- Adding automatic transaxle fluid. (Refer to "Hydraulic system (Fluid)" in this group)
- Perform TCM learning after replacing the valve body to prevent slow transaxle response, jerky acceleration and jerky startup. (Refer to "Automatic transaxle control system (Repair procedures)" in this group)

## ATA-26


## Automatic Transaxle System

### Clutch & Brake

#### Description

The 6-spd automatic transaxle consists of an overdrive clutch (OD/C), a one-way clutch (OWC), a lower and reverse brake (LR/B), an underdrive brake (UD/B), a 26 brake (26/B), and a 35R clutch (35R/C). These clutches and brakes are operated by controlling the hydraulic pressure.

#### Components Location



SSLAT1006N

- |                               |                        |
|-------------------------------|------------------------|
| 1. Overdrive clutch (OD/C)    | 5. 26 brake(26/B)      |
| 2. One way clutch (OWC)       | 6. 35R clutch (35R/C)  |
| 3. Low & Reverse brake (LR/B) | 7. Damper clutch (D/C) |
| 4. Underdrive brake (UD/B)    |                        |




# Clutch & Brake

# ATA-27

## Power Flow Chart

P,N	UD/B	LR/B	26/B	35R/C	OD/C	OWC
		●				



SSLAT1007N


▣ Direction of Rotation

- ▶ Lower & Reverse Brake (LR/B) Activation → Overdrive (O/D) Hub Lock → Mid & Rear P/C Lock
- ▶ Input Shaft Rotation → Rear Sun Gear Rotation → Rear Inner Pinion Rotation (Reverse) → Rear Outer Pinion Rotation → Rear Annulus Gear Rotation → Front Annulus Gear Rotation → Front Pinion Rotation → Front Sun Gear Rotation (Reverse) → Underdrive (U/D) Hub Rotation (Reverse)
- ▶ Input shaft rotation → Overdrive Clutch (OD/C) Retainer Rotation
- ▶ Input shaft rotation → 35R Clutch Rotation

# ATA-28

# Automatic Transaxle System


R	UD/B	LR/B	26/B	35R/C	OD/C	OWC
		●		●		



SSLAT1008N

■ Power Delivery Route


- ▶ Middle carrier locked and middle sun gear in rotation
- ▶ Rotating the middle planetary gear's sun gear while its carrier is locked in place slows down and reverse rotates the annulus gear (front carrier), resulting in power transfer to the front carrier.
- ▶ The rear planetary gear's rear and front annulus gears rotate at a reduced rate, resulting in reverse, zero load rotation of the front planetary gear's front sun gear.



# Clutch & Brake

# ATA-29

D1	UD/B	LR/B	26/B	35R/C	OD/C	OWC
	●	(○)				●



SSLAT1009N

■ Power Delivery Route


- ▶ Front sun gear and middle & rear carrier locked and rear sun gear in constant rotation
- ▶ When the rear sun gear is rotated, power is reduced at the rear planetary gear and then delivered to the rear and front annulus gears. The power is then reduced again at the front planetary gear, whose sun gear is locked in place, and then delivered to the front carrier.
- ▶ Here, the middle annulus gear, which comprises of a single unit with the front carrier, rotates and results in reverse, zero load rotation of the middle sun gear.



# ATA-30

# Automatic Transaxle System


D2	UD/B	LR/B	26/B	35R/C	OD/C	OWC
	●		●			



SSLAT1010N

■ Power Delivery Route


- ▶ Front sun gear and middle sun gear locked and rear sun gear in constant rotation
- ▶ Rotating the rear sun gear delivers power to the rear & front annulus gears, and reaction from the front carrier and the middle annulus gear, to which the sun gear is attached, transfers to the middle and rear carriers, resulting in power equilibrium and power transfer to the front carrier.



# Clutch & Brake

# ATA-31

D3	UD/B	LR/B	26/B	35R/C	OD/C	OWC
	●			●		



SSLAT1011N

■ Power Delivery Route


- ▶ Front sun gear locked and middle and rear sun gears in rotation
- ▶ Rotating the middle sun gear and the rear sun gear transfers power to the rear and front annulus gears, and reaction from the front carrier and the middle annulus gear, to which the sun gear is attached, transfers to the middle and rear carriers, resulting in power equilibrium and power transfer to the front carrier.



# ATA-32

# Automatic Transaxle System


D4	UD/B	LR/B	26/B	35R/C	OD/C	OWC
	●				●	



SSLAT1012N

■ Power Delivery Route


- ▶ Front sun gear locked and rear carrier and rear sun gears in rotation
- ▶ Activation of the overdrive clutch (OD/C) synchronizes the rear planetary gear's carrier and sun gears. The 1:1 rotation ratio passes through the rear and front annulus gears and reaches the front planetary gear's front carrier, to which the sun gear is attached.
- ▶ Here, the middle planetary gear's middle sun gear rotates at a faster rate in the normal direction and at zero load due to the actions of the reduced annulus gear and the carrier having a 1:1 rotation ratio.



# Clutch & Brake

# ATA-33

D5	UD/B	LR/B	26/B	35R/C	OD/C	OWC
				●	●	



SSLAT1013N

■ Power Delivery Route


- ▶ Middle and rear carriers, middle sun gear, and rear sun gear in rotation
- ▶ The middle planetary gear's middle carrier and sun gear rotate simultaneously, resulting in the 1:1 rotation ratio being transferred to the middle annulus gear (front carrier).
- ▶ Here, the rear planetary gear rotates in a 1:1 rotation ratio, as it would when the 4th gear is engaged; however, the front planetary gear remains unrestrained and the front sun gear rotates in the normal direction, at a zero load, and at a rotation ratio of 1:1.



# ATA-34

# Automatic Transaxle System

D6	UD/B	LR/B	26/B	35R/C	OD/C	OWC
			●		●	



SSLAT1014N

■ Power Delivery Route

- ▶ Middle carrier in rotation and middle sun gear locked
- ▶ When the middle planetary gear's sun gear is locked in place and the train's carrier's allowed to rotate, the middle annulus gear increases its rate of rotation and transfers power to the front carrier.
- ▶ Here, the rear planetary gear maintains a 1:1 rotation ratio as it would when 4th or 5th gear is engaged; however, the front planetary gear remains unrestrained and the front sun gear rotates at a faster rate in the normal direction and at zero load.





# Automatic Transaxle Control System


ATA-35

## Automatic Transaxle Control System

### Description

Automatic transaxle system relies on various measurement data to determine the current control status and extrapolate the necessary compensation values. These values are used to control the actuators and achieve the desired control output. If a problem with the drivetrain, including the transaxle, has been identified, perform self-diagnosis and basic transaxle inspection (oil and fluid inspection) and then check the control system's components using the diagnosis tool.

### Control System Composition



SSLAT1104N

## ATA-36

# Automatic Transaxle System

### Fault Diagnosis

Features a fail-safe mechanism that prevents dangerous situations from developing in the event of a transaxle failure. The limp home mode engages if the transaxle malfunctions. In this mode, the transaxle operates at a minimal functionality level, making it possible for the vehicle to reach a service center.

**Fail-Safe:** Prevents dangerous situations from developing in the event of a malfunction.

**Limp Home:** Maintains minimal functionality (\*) in the event of a malfunction, making it possible for the vehicle to reach a service center.

(\*) Minimal Functionality: Drive (fixed gear setting), Reverse, and Neutral

### Self-diagnosis

TCM is in constant communication with the control system's components (sensors and solenoids). If an abnormal signal is received for longer than the predefined duration, TCM recognizes a fault, stores the fault code in memory, and then sends out a fault signal through the self-diagnosis terminal. Such fault codes are independently backed up and will not be cleared even if the ignition switch is turned off, the battery is disconnected, or the TCM connector is disconnected.

#### ⚠ CAUTION

Disconnecting a sensor or an actuator connector while the ignition switch is in the "On" position generates a diagnostic trouble code (DTC) and commits the code to memory. In such event, disconnecting the battery will not clear the fault diagnosis memory. The diagnosis tool must be used to clear the fault diagnosis memory.

#### ⚠ CAUTION

- Before removing or installing any part, read the diagnostic trouble codes and then disconnect the battery negative (-) terminal.
- Before disconnecting the cable from battery terminal, turn the ignition switch to OFF. Removal or connection of the battery cable during engine operation or while the ignition switch is ON could cause damage to the TCM.
- When checking the generator for the charging state, do not disconnect the battery '+' terminal to prevent the ECM from damage due to the voltage.
- When charging the battery with the external charger, disconnect the vehicle side battery terminals to prevent damage to the TCM.

### Checking Procedure (Self-diagnosis)

#### ⚠ CAUTION

- When battery voltage is excessively low, diagnostic trouble codes can not be read. Be sure to check the battery for voltage and the charging system before starting the test
- Diagnosis memory is erased if the battery or the TCM connector is disconnected. Do not disconnect the battery before the diagnostic trouble codes (DTC) are completely read and recorded.

### Inspection Procedure (Using the GDS)

1. Turn OFF the ignition switch.
2. Connect the GDS to the data link connector on the lower crash pad.
3. Turn ON the ignition switch.
4. Use the GDS to check the diagnostic trouble code.
5. Repair the faulty part from the diagnosis chart.
6. Erase the diagnostic trouble code.
7. Disconnect the GDS.

#### ⚠ CAUTION

- Perform TCM learning after replacing the automatic transaxle to prevent slow automatic transaxle response, jerky acceleration and jerky startup. (Refer to "Automatic transaxle control system (Repair procedures)" in this group)
- Adding automatic transaxle fluid. (Refer to "Hydraulic system (Fluid)" in this group)
- After servicing the automatic transaxle or TCM, clear the diagnostic trouble code (DTC) using the GDS tool. Diagnostic trouble codes (DTC) cannot be cleared by disconnecting the battery.

# Automatic Transaxle Control System

## ATA-37

### Adjustment


#### TCM Learning

When shift shock is occurred or parts related with the transaxle are replaced, TCM learning should be performed.

In the following case, TCM learning is required.

- Transaxle assembly replacement
  - TCM replacement
  - TCM upgrading
1. TCM learning condition
    - ATF temperature: 40~100°C (104~212°F)
  2. TCM learning procedure
    - A. Stop learning
 

Repeat the below shift pattern four times or more with stepping on the brake.




#### B. Driving learning

1. Drive the vehicle through all gears at D range.  
Drive from stop to 1st to 2nd to 3rd to 4th to 5th to 6th with keeping fixed throttle open.
2. Down shift from 6th to 5th, 5th to 4th, 4th to 3rd, 3rd to 2nd, 2nd to 1st.
3. Repeat the above driving pattern four times or more.  
Up-shift throttle open : 15~25%

# ATA-38

# Automatic Transaxle System

## Circuit Diagram




SSLAT1106N

# Automatic Transaxle Control System

## ATA-39

### Components Location [Vehicle Components]



STFAT1019D


- 1. Automatic transaxle
- 2. Transaxle control module (TCM)

- 3. Shift lever
- 4. DLC

# ATA-40

# Automatic Transaxle System

## [Transaxle Components]



STFAT1026D

- 1. Input speed sensor
- 2. Output speed sensor
- 3. Solenoid valve connect
- 4. Oil temperature sensor

- 5. Valve body assembly
- 6. Solenoid valve
- 7. Inhibitor switch

# Automatic Transaxle Control System

## ATA-41


### Transaxle Control Module (TCM)

#### Description

Transaxle Control Module (TCM) is the automatic transaxle's brain. The module receives and processes signals from various sensors and implements a wide range of transaxle controls to ensure optimal driving conditions for the driver. TCM is programmed for optimal response to any on-road situation. In the event of a transaxle failure or malfunction, TCM stores the fault information in memory so that the technician may reference the code and quickly repair the transaxle.

#### Functions

- Monitors the vehicle's operating conditions to determine the optimal gear setting.
- Performs a gear change if the current gear setting differs from the identified optimal gear setting.
- Determines the need for damper clutch (D/C) activation and engages the clutch accordingly.
- Calculates the optimal line pressure level by constantly monitoring the torque level and adjusts the pressure accordingly.
- Diagnoses the automatic transaxle for faults and failures.



STFAT1015D




اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

# ATA-42

# Automatic Transaxle System

## 1. TCM Connector and Terminal Function



SYFFL0400N

## 2. TCM Terminal Function

### Connector [CHG-AG]

Pin	Description	Pin	Description
1	-	54	-
2	Line pressure control solenoid valve (LINE_VFS)	55	-
3	Torque converter control solenoid valve (T/CON_VFS)	56	-
4	35R clutch control solenoid valve (35R/C_VFS)	57	-
5	-	58	-
6	-	59	-
7	Inhibitor switch signal "S1"	60	-
8	Inhibitor switch signal "S2"	61	-
9	Inhibitor switch signal "S3"	62	-
10	Inhibitor switch signal "S4"	63	-
11	-	64	-
12	-	65	ON/OFF solenoid valve B(SS-B)
13	-	66	ON/OFF solenoid valve B(SS-A)
14	-	67	Battery (B+)
15	-	68	-
16	-	69	Oil temperature sensor (+)
17	-	70	-
18	-	71	-
19	-	72	-
20	-	73	Output speed sensor signal
21	-	74	Sports mode up switch
22	-	75	-
23	Underdrive brake control solenoid valve (UD/B_V-FS)	76	-
24	26 brake control solenoid valve (26/B_VFS)	77	-



## Automatic Transaxle Control System

## ATA-43

Pin	Description	Pin	Description
25	Overdrive clutch control solenoid valve (OD/C_VF-S)	78	-
26	-	79	-
27	-	80	-
28	-	81	-
29	-	82	-
30	-	83	-
31	-	84	-
32	-	85	-
33	-	86	Solenoid supply power 1
34	-	87	Solenoid supply power 2
35	-	88	Battery (B+)
36	-	89	-
37	-	90	Output speed sensor power
38	-	91	Input speed sensor power
39	-	92	-
40	-	93	-
41	-	94	Input speed sensor signal
42	-	95	Sports mode down switch
43	-	96	-
44	Ground (Power 1)	97	-
45	Ground (Power 2)	98	-
46	Shift lock solenoid	99	-
47	-	100	-
48	Oil temperature sensor (-)	101	-
49	-	102	-
50	-	103	-
51	-	104	-
52	Sports mode select switch	105	-
53	-		

## ATA-44

## Automatic Transaxle System

TCM Terminal Input/ Output Signal  
Connector [CHG-AG]

Pin	Description	Condition	Input/output value	
			Type	Level
1	-			
2	Line pressure control solenoid valve (LINE_VFS)		Output	0V/Battery voltage level
				9V < Battery voltage level < 16V
3	Torque converter control solenoid valve (T/CON_VFS)		Output	0V/Battery voltage level
				9V < Battery voltage level < 16V
4	35R clutch control solenoid valve (35R/C_VFS)		Output	0V/Battery voltage level
				9V < Battery voltage level < 16V
5	-			
6	-			
7	Inhibitor switch signal "S1"	High	Input	0V/Battery voltage level
		Low		9V < Battery voltage level < 16V
8	Inhibitor switch signal "S2"	High	Input	0V/Battery voltage level
		Low		9V < Battery voltage level < 16V
9	Inhibitor switch signal "S3"	High	Input	0V/Battery voltage level
		Low		9V < Battery voltage level < 16V
10	Inhibitor switch signal "S4"	High	Input	0V/Battery voltage level
		Low		9V < Battery voltage level < 16V
11	-			
12	-			
13	-			
14	-			
15	-			
16	-			
17	-			
18	-			
19	-			
20	-			
21	-			
22	-			
23	Underdrive brake control solenoid valve (UD/B_VFS)		Output	0V/Battery voltage level
				9V < Battery voltage level < 16V
				Power supply : V_SOL2

## Automatic Transaxle Control System

## ATA-45

Pin	Description	Condition	Input/output value	
			Type	Level
24	26 brake control solenoid valve (26/B_VFS)		Output	0V/Battery voltage level
				9V < Battery voltage level < 16V
				Power supply : V_SOL2
25	Overdrive clutch control solenoid valve (OD/C_VFS)		Output	0V/Battery voltage level
				9V < Battery voltage level < 16V
				Power supply : V_SOL1
26	-			
27	-			
28	-			
29	-			
30	-			
31	-			
32	-			
33	-			
34	-			
35	-			
36	-			
37	-			
38	-			
39	-			
40	-			
41	-			
42	-			
43	-			
44	Ground (Power 1)		Ground	0V
45	Ground (Power 2)		Ground	0V
46	Shift lock solenoid	High	Output	0V/Battery voltage level
		Low		9V < Battery voltage level < 16V
47	-			
48	Oil temperature sensor (-)		Ground	0V
49	-			
50	-			
51	-			

## ATA-46

## Automatic Transaxle System

Pin	Description	Condition	Input/output value	
			Type	Level
52	Sports mode select switch	Sport mode	Input	0V/Battery voltage level
		Other		9V < Battery voltage level < 16V
53	-			
54	-			
55	-			
56	-			
57	-			
58	-			
59	-			
60	-			
61	-			
62	-			
63	-			
64	-			
65	ON/OFF solenoid valve B(SS-B)	High	Output	0V/Battery voltage level
		Low		9V < Battery voltage level < 16V
66	ON/OFF solenoid valve A (SS-A)	High	Output	0V/Battery voltage level
		Low		9V < Battery voltage level < 16V
67	Battery power (B <sup>+</sup> )	ON	Power	0V/Battery voltage level
		OFF		9V < Battery voltage level < 16V
68	-			
69	Oil temperature sensor (+)	ON	Input	0V/3.3V
		OFF		
70	-			
71	-			
72	-			
73	Output speed sensor signal	High	Input	0.7V/1.4V
		Low		
74	Sports mode up switch	Up ON	Input	0V/Battery voltage level
		Other		9V < Battery voltage level < 16V
75	-			
76	-			
77	-			
78	-			

## Automatic Transaxle Control System


## ATA-47

Pin	Description	Condition	Input/output value	
			Type	Level
79	-			
80	-			
81	-			
82	-			
83	-			
84	-			
85	-			
86	Solenoid supply power 1	ON	Power	0V/Battery voltage level
		OFF		9V < Battery voltage level < 16V
87	Solenoid supply power 2	ON	Power	0V/Battery voltage level
		OFF		9V < Battery voltage level < 16V
88	Battery power (B+)	ON	Power	0V/Battery voltage level
		OFF		9V < Battery voltage level < 16V
89	-			
90	Output speed sensor power	ON	Power	0V/7.5V
		OFF		
91	Input speed sensor power	ON	Power	0V/7.5V
		OFF		
92	-			
93	-			
94	Input speed sensor signal	High	Input	0.7V/1.4V
		Low		
95	Sports mode down switch	Down ON	Input	0V/Battery voltage level
		Other		9V < Battery voltage level < 16V
96	-			
97	-			
98	-			
99	-			
100	-			
101	-			
102	-			
103	-			
104	-			
105	-			

# ATA-48

# Automatic Transaxle System


## Circuit Diagram



STFAT1107N

# Automatic Transaxle Control System

# ATA-49



STFAT1108N

## ATA-50

## Automatic Transaxle System

## Inspection

## TCM Problem Inspection Procedure


1. TEST TCM GROUND CIRCUIT: Measure resistance between TCM and chassis ground using the backside of TCM harness connector as TCM side check point. If the problem is found, repair it.

**Specification:** Below  $1\Omega$

2. TEST TCM CONNECTOR: Disconnect the TCM connector and visually check the ground terminals on TCM side and harness side for bent pins or poor contact pressure. If the problem is found, repair it.
3. If problem is not found in Step 1 and 2, the TCM could be faulty. If so, make sure there were no DTC's before swapping the TCM with a new one, and then check the vehicle again. If DTC's were found, examine this first before swapping TCM.
4. RE-TEST THE ORIGINAL TCM: Install the original TCM (may be broken) into a known-good vehicle and check the vehicle. If the problem occurs again, replace the original TCM with a new one. If problem does not occur, this is intermittent problem (Refer to "Intermittent Problem Inspection Procedure" in Basic Inspection Procedure).

## Replacement

1. Turn ignition switch OFF.
2. Disconnect the negative (-) battery cable.
3. Disconnect the TCM connector (A).




STFAT1010D

4. Remove the TCM (C) after removing the mounting bolts (A) and nut (B).

## TCM installation bolt/nut:

9.8 ~ 11.8 N.m (1.0 ~ 1.2 kgf.m, 7.2 ~ 8.7 lb-ft)



STFAT1011D

## Installation

1. Installation is reverse of removal.

## NOTICE

*In the case of the vehicle equipped with immobilizer or button engine start system, perform "Key Teaching" procedure together (Refer to "Immobilizer" or "Button Engine Start System in BE group).*




# Automatic Transaxle Control System

## ATA-51

### Transaxle Oil Temperature Sensor

#### Description

Transaxle oil temperature sensor monitors the automatic transaxle fluid's temperature and conveys the readings to TCM. It is an NTC (Negative Thermal Coefficient) sensor whose resistance has an inversely proportional relationship with the temperature level. Data produced by this sensor is used to identify damper clutch activation and deactivation zones within the low temperature and high temperature range and to compensate hydraulic pressure levels during gear changes.




SSLAT0109D

#### Specifications

▷ Type: Negative Thermal Coefficient Type

Temp. [(°C)°F]	Resistance (kΩ)
(-40)-40	48.1
(-20)-4.0	15.6
(0)32.0	5.88
(20)68.0	2.51
(40)104.0	1.11
(60)140.0	0.61
(80)176.0	0.32
(100)212.0	0.18
(120)248.0	0.10
(140)284.0	0.06
(150)302.0	0.05



SSLAT1110N


# ATA-52

# Automatic Transaxle System


## Circuit Diagram

[Circuit Diagram]

Oil Temperature Sensor [CRD04]




TCM [CHG-AG]




[Connection Information]

Terminal	Connected to	Function
9	TCM CHG-AG (48)	Oil temperature sensor (-)
13	TCM CHG-AG (69)	Oil temperature sensor (+)


[Harness Connector]



Solenoid Valve Connector [CRD04]



TCM Connector [CHG-AG]



TCM Connector [CHG-BG]

STFAT1120N

# Automatic Transaxle Control System

## ATA-53

### Inspection


1. Turn ignition switch OFF.
2. Disconnect the oil temperature sensor connector.
3. Measure resistance between sensor signal terminal and sensor ground terminal.
4. Check that the resistance is within the specification.

### Removal

1. Remove the battery and the battery tray. (Refer to "Charging system" in EE group.)
2. Remove the under cover (A).

### Tightening torque:

7.8 ~ 11.8 N.m (0.8 ~ 1.2 kgf.m, 5.8 ~ 8.7 lb-ft)



STFAT1007D

3. Replace new gasket and the plug after draining the automatic transaxle fluid by removing the drain plug. (Refer to "Hydraulic system (Fluid)" in this group)

4. Remove the valve body cover (B) and eyebolt (A).


### Tightening torque:

(A) 34.3 ~ 44.1 N.m (3.5 ~ 4.5 kgf.m, 25.3 ~ 32.6 lb-ft)

(B) 13.8 ~ 14.7 N.m (1.3 ~ 1.5 kgf.m, 9.4 ~ 10.8 lb-ft)


### CAUTION

Always replace the gasket of the eyebolt use new one whenever loosening eyebolt.



STFAT1018D

5. Disconnect the oil temperature sensor connector (A).



SCMAT0012L


## ATA-54

## Automatic Transaxle System

6. Remove the oil temperature sensor (A) after removing a bolt.

**Tightening torque:**

9.8 ~ 11.8 N.m (1.0 ~ 1.2 kgf.m, 7.2 ~ 8.7 lb-ft)



SCMAT0013L

دیجیتال خودرو  
شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

**Installation**

1. Installation is the reverse of removal.

**NOTICE**

After replacement or reinstallation procedure of the valve body assembly, must perform procedures below.

- Continue to apply liquid gasket at application points at the valve body cover with  $\varnothing 2.5\text{mm}$  (0.0984in.) thickness.

Liquid gasket Part name :

Threebond 1281B or LOCTITE FMD-546

- Adding automatic transaxle fluid. (Refer to "Hydraulic system (Fluid)" in this group)


# Automatic Transaxle Control System

## ATA-55

### Input Speed Sensor

#### Description

Input speed sensor is a vital unit that measures the rate of rotation of the input shaft inside the transaxle and delivers the readings to the TCM. The sensor provides critical input data that's used in feedback control, damper clutch control, gear setting control, line pressure control, clutch activation pressure control, and sensor fault analysis.



SSLAT0016D

#### Specifications

▷ Type: Hall effect sensor

Operation condition [°C(°F)]		((-)40~150) -40~302
Air gap(mm)in.		(0.95~1.65)0.037~0.065
Output voltage(V)	High	1.18~1.68
	Low	0.59~0.84

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




# ATA-56

# Automatic Transaxle System

## Circuit Diagram

[Circuit Diagram]


**Input & Output Speed Sensor [CRD04]**



[Connection Information]

Terminal	Connected to	Function
14	TCM CHG-AG (91)	Input speed sensor power
8	TCM CHG-AG (94)	Input speed sensor signal
3	TCM CHG-AG (90)	Output speed sensor power
4	TCM CHG-AG (73)	Output speed sensor signal

[Harness Connector]



**Solenoid Valve Connector [CRD04]**

105	104	103	102	101	100	99	98	97	96	95	94	93	92	91	90	89	88	87	86	85
84	83	82	81	80	79	78	77	76	75	74	73	72	71	70	69	68	67	66	65	64
63	62	61	60	59	58	57	56	55	54	53	52	51	50	49	48	47	46	45	44	43
42	41	40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22
21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1

**TCM Connector [CHG-AG]**

91	90	89	88	87	86	85	84	83	82	81	80	79	78	77	76	75	74	73	72	71	70	69	68	67	66	65	64	63	62	61	60	59	58	57	56	55	54	53	52	51	50	49	48	47	46	45	44	43	42	41	40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
6	5																																																																																									
4	3																																																																																									
2	1																																																																																									

**TCM Connector [CHG-BG]**

# Automatic Transaxle Control System

# ATA-57

## Signal Waveform




Fig.1

SSLAA1002N




Fig.2

SSLAA1003N

Fig 1) Input/Output speed sensor at low speed

Fig 2) Input/Output speed sensor at high speed

## ATA-58

## Automatic Transaxle System

**Inspection**

1. Check signal waveform of Input & output speed sensor using the GDS.


**Specification:** Refer to "Signal Wave Form" section.

**Removal**

1. Remove the battery and the battery tray. (Refer to "Charging system" in EE group.)
2. Remove the under cover (A).

**Tightening torque:**

7.8 ~ 11.8 N.m (0.8 ~ 1.2 kgf.m, 5.8 ~ 8.7 lb-ft)



STFAT1007D

3. Replace new gasket and the plug after draining the automatic transaxle fluid by removing the drain plug. (Refer to "Hydraulic system (Fluid)" in this group)

4. Remove the valve body cover (B) and eyebolt (A).

**Tightening torque:**

(A) 34.3 ~ 44.1 N.m (3.5 ~ 4.5 kgf.m, 25.3 ~ 32.6 lb-ft)


(B) 13.8 ~ 14.7 N.m (1.3 ~ 1.5 kgf.m, 9.4 ~ 10.8 lb-ft)

**CAUTION**

Always replace the gasket of the eyebolt use new one whenever loosening eyebolt.

**NOTICE**

Remove installation bolts in the engine compartment first and then remove others under the vehicle.




STFAT1018D

5. Remove the plate and the detent spring (A) after removing the bolt.

**Tightening torque:**

24.5 ~ 35.3 N.m (2.5 ~ 3.6 kgf.m, 18.1 ~ 26.0 lb-ft)



SVGAA0006D



# Automatic Transaxle Control System

# ATA-59


6. Remove the bolt (3ea) after disconnecting the solenoid valve connector (A) and the oil temperature sensor connector (B).

### Tightening torque:

9.8 ~ 11.8 N.m (1.0 ~ 1.2 kgf.m, 7.2 ~ 8.7 lb-ft)

### CAUTION

Be careful not to damage the harness lock connector.




SSLAT1112N

7. Remove the valve body assembly (A).

### Tightening torque:

9.8 ~ 11.8 N.m (1.0 ~ 1.2 kgf.m, 7.2 ~ 8.7 lb-ft)




SCMAT0008L

8. Disconnect the input & output speed sensor connector(A).

9. Remove the input & output speed sensor (B) after removing the bolts(2ea).

### Tightening torque:

9.8 ~ 11.8 N.m (1.0 ~ 1.2 kgf.m, 7.2 ~ 8.7 lb-ft)



SCMAT0011L

### Installation

1. Installation is the reverse of removal.

### NOTICE

After replacement or reinstallation procedure of the valve body assembly, must perform procedures below.

- Continue to apply liquid gasket at application points at the valve body cover with  $\varnothing 2.5\text{mm}$  (0.0984in.) thickness.

Liquid gasket Part name :

Threebond 1281B or LOCTITE FMD-546

- Adding automatic transaxle fluid. (Refer to "Hydraulic system (Fluid)" in this group)


## ATA-60

## Automatic Transaxle System

## Output Speed Sensor

## Description

The output speed sensor is a vital unit that measures the rate of rotation of the transaxle's turbine shaft and output shaft, and delivers the readings to the TCM. The sensor provides critical input data that's used in feedback control, damper clutch control, gear setting control, line pressure control, clutch activation pressure control, and sensor fault analysis.



SSLAT0016D

## Specifications

▷ Type: Hall effect sensor

Operation condition [ $^{\circ}\text{C}$ ( $^{\circ}\text{F}$ )]		((-40~150)) -40~302
Air gap(mm)in.		(0.55~1) 0.0217~0.0394
Output voltage	High	1.18~1.68
	Low	0.59~0.84

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



# Automatic Transaxle Control System


# ATA-61

## Circuit Diagram

[Circuit Diagram]

Input & Output Speed Sensor [CRD04]


TCM [CHG-AG]




[Connection Information]

Terminal	Connected to	Function
14	TCM CHG-AG (91)	Input speed sensor power
8	TCM CHG-AG (94)	Input speed sensor signal
3	TCM CHG-AG (90)	Output speed sensor power
4	TCM CHG-AG (73)	Output speed sensor signal


[Harness Connector]



Solenoid Valve Connector [CRD04]



TCM Connector [CHG-AG]



TCM Connector [CHG-BG]

STFAT1121N

# ATA-62

# Automatic Transaxle System

## Signal Waveform




Fig.1

SSLAA1002N




Fig.2

SSLAA1003N

Fig 1) Input/Output speed sensor at low speed

Fig 2) Input/Output speed sensor at high speed

# Automatic Transaxle Control System

## ATA-63

### Inspection

1. Check signal waveform of Input & output speed sensor using the GDS.


**Specification:** Refer to "Signal Wave Form" section.

### Removal

1. Remove the battery and the battery tray. (Refer to "Charging system" in EE group.)
2. Remove the under cover (A).

### Tightening torque:

7.8 ~ 11.8 N.m (0.8 ~ 1.2 kgf.m, 5.8 ~ 8.7 lb-ft)



STFAT1007D

3. Replace new gasket and the plug after draining the automatic transaxle fluid by removing the drain plug. (Refer to "Hydraulic system (Fluid)" in this group)

4. Remove the valve body cover (B) and eyebolt (A).

### Tightening torque:

(A) 34.3 ~ 44.1 N.m (3.5 ~ 4.5 kgf.m, 25.3 ~ 32.6 lb-ft)


(B) 13.8 ~ 14.7 N.m (1.3 ~ 1.5 kgf.m, 9.4 ~ 10.8 lb-ft)

### CAUTION

Always replace the gasket of the eyebolt use new one whenever loosening eyebolt.

### NOTICE

Remove installation bolts in the engine compartment first and then remove others under the vehicle.




STFAT1018D

5. Remove the plate and the detent spring (A) after removing the bolt.

### Tightening torque:

24.5 ~ 35.3 N.m (2.5 ~ 3.6 kgf.m, 18.1 ~ 26.0 lb-ft)



SVGAA0006D

# ATA-64

# Automatic Transaxle System


6. Remove the bolt (3ea) after disconnecting the solenoid valve connector (A) and the oil temperature sensor connector (B).

**Tightening torque:**

9.8 ~ 11.8 N.m (1.0 ~ 1.2 kgf.m, 7.2 ~ 8.7 lb-ft)

**CAUTION**

Be careful not to damage the harness lock connector.




SSLAT1112N

7. Remove the valve body assembly (A).

**Tightening torque:**

9.8 ~ 11.8 N.m (1.0 ~ 1.2 kgf.m, 7.2 ~ 8.7 lb-ft)




SCMAT0008L

8. Disconnect the input & output speed sensor connector(A).

9. Remove the input & output speed sensor (B) after removing the bolts(2ea).

**Tightening torque:**

9.8 ~ 11.8 N.m (1.0 ~ 1.2 kgf.m, 7.2 ~ 8.7 lb-ft)



SCMAT0011L

**Installation**

1. Installation is the reverse of removal.

**NOTICE**

After replacement or reinstallation procedure of the valve body assembly, must perform procedures below.

- Continue to apply liquid gasket at application points at the valve body cover with Ø2.5mm (0.0984in.) thickness.

Liquid gasket Part name :

Threebond 1281B or LOCTITE FMD-546

- Adding automatic transaxle fluid. (Refer to "Hydraulic system (Fluid)" in this group)


# Automatic Transaxle Control System

# ATA-65

## Torque Converter Control Solenoid Valve (T/CON\_VFS)

### Description

Torque converter control solenoid valve (T/CON\_VFS) is attached to the valve body. This variable force solenoid valve directly controls the hydraulic pressure inside the torque converter.



SSLAT0018D

### Specifications

Direct control VFS[T/CON]

▷ Control type : Normal low type

Control Pressure kpa (kgf/cm <sup>2</sup> , psi)	9.81~500.14 (0.1~5.1, 1.42~72.54)
Current value(mA)	50~850
Internal resistance(Ω)	5.1

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




# ATA-66

# Automatic Transaxle System

## Circuit Diagram


[Circuit Diagram]

[Connection Information]



Terminal	Connected to	Function
17	TCM CHG-AG (2)	Line Pressure Control Solenoid Valve (LINE_VFS)
16	TCM CHG-AG (23)	Underdrive Brake Control Solenoid Valve(UD/B_VFS)
11	TCM CHG-AG (24)	26 Brake Control Solenoid Valve (26/B_VFS)
12	TCM CHG-AG (65)	SS-B Solenoid Valve(ON/OFF)
5	TCM CHG-AG (87)	Solenoid Valve power 2
2	TCM CHG-AG (3)	Torque Converter Control Solenoid Valve(T/CON_VFS)
7	TCM CHG-AG (25)	Overdrive Clutch Control Solenoid Valve(OD/C_VFS)
6	TCM CHG-AG (4)	35R Clutch Control Solenoid Valve (35R/C_VFS)
18	TCM CHG-AG (66)	SS-A Solenoid Valve(ON/OFF)
10	TCM CHG-AG (86)	Solenoid Valve power 1

[Harness Connector]



Solenoid Valve Connector [CRD04]

105	104	103	102	101	100	99	98	97	96	95	94	93	92	91	90	89	88	87	86	85
84	83	82	81	80	79	78	77	76	75	74	73	72	71	70	69	68	67	66	65	64
63	62	61	60	59	58	57	56	55	54	53	52	51	50	49	48	47	46	45	44	43
42	41	40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22
21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1

TCM Connector [CHG-AG]

91	90	89	88	87	86	85	84	83	82	81	80	79	78	77	76	75	6	5
74	73	72	71	70	69	68	67	66	65	64	63	62	61	60	59	58	4	3
57	56	55	54	53	52	51	50	49	48	47	46	45	44	43	42	41	2	1
40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24		
23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7		

TCM Connector [CHG-BG]

STFAT1124N



# Automatic Transaxle Control System

## ATA-67

### Inspection

1. Turn ignition switch OFF.
2. Disconnect the oil temperature sensor connector.
3. Measure resistance between sensor signal terminal and sensor ground terminal.
4. Check that the resistance is within the specification.

### Removal

#### NOTICE

Replacing an on/off solenoid valve (SS-A, SS-B) does not require additional hydraulic pressure adjustment; however, the hydraulic pressure will need to be adjusted after replacing the VFS solenoid valve. If replacing the VFS solenoid valve; also replace the valve body assembly. (Refer to "Valve Body" in this group)

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




## ATA-68

## Automatic Transaxle System

## 26 Brake Control Solenoid Valve(26/B\_VFS)

## Description

26 brake control solenoid valve(26/B\_VFS) is attached to the valve body. This variable force solenoid valve directly controls the hydraulic pressure inside the 26 brake.



SSLAT0018D

## Specifications

Direct control VFS[26/B]

▷ Control type : Normal low type

Control Pressure kpa (kgf/cm <sup>2</sup> , psi)	9.81~500.14 (0.1~5.1, 1.42~72.54)
Current value(mA)	50~850
Internal resistance(Ω)	5.1

دیجیتال خودرو  
شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




# Automatic Transaxle Control System

# ATA-69

## Circuit Diagram


[Circuit Diagram]

[Connection Information]



Terminal	Connected to	Function
17	TCM CHG-AG (2)	Line Pressure Control Solenoid Valve (LINE_VFS)
16	TCM CHG-AG (23)	Underdrive Brake Control Solenoid Valve(UD/B_VFS)
11	TCM CHG-AG (24)	26 Brake Control Solenoid Valve (26/B_VFS)
12	TCM CHG-AG (65)	SS-B Solenoid Valve(ON/OFF)
5	TCM CHG-AG (87)	Solenoid Valve power 2
2	TCM CHG-AG (3)	Torque Converter Control Solenoid Valve(T/CON_VFS)
7	TCM CHG-AG (25)	Overdrive Clutch Control Solenoid Valve(OD/C_VFS)
6	TCM CHG-AG (4)	35R Clutch Control Solenoid Valve (35R/C_VFS)
18	TCM CHG-AG (66)	SS-A Solenoid Valve(ON/OFF)
10	TCM CHG-AG (86)	Solenoid Valve power 1

[Harness Connector]



**Solenoid Valve Connector [CRD04]**

105	104	103	102	101	100	99	98	97	96	95	94	93	92	91	90	89	88	87	86	85
84	83	82	81	80	79	78	77	76	75	74	73	72	71	70	69	68	67	66	65	64
63	62	61	60	59	58	57	56	55	54	53	52	51	50	49	48	47	46	45	44	43
42	41	40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22
21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1

**TCM Connector [CHG-AG]**

91	90	89	88	87	86	85	84	83	82	81	80	79	78	77	76	75	6	5
74	73	72	71	70	69	68	67	66	65	64	63	62	61	60	59	58	4	3
57	56	55	54	53	52	51	50	49	48	47	46	45	44	43	42	41	2	1
40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24		
23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7		

**TCM Connector [CHG-BG]**

STFAT1124N

## ATA-70

## Automatic Transaxle System

### Inspection

1. Turn ignition switch OFF.
2. Disconnect the oil temperature sensor connector.
3. Measure resistance between sensor signal terminal and sensor ground terminal.
4. Check that the resistance is within the specification.

### Removal

#### NOTICE

*Replacing an on/off solenoid valve (SS-A, SS-B) does not require additional hydraulic pressure adjustment; however, the hydraulic pressure will need to be adjusted after replacing the VFS solenoid valve. If replacing the VFS solenoid valve; also replace the valve body assembly. (Refer to "Valve Body" in this group)*

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




# Automatic Transaxle Control System

## ATA-71

### Line Pressure Control Solenoid Valve

#### Description

Line pressure control solenoid valve is attached to the valve body. This variable force solenoid valve directly controls the hydraulic pressure inside the line pressure.



SSLAT0019D

#### Specifications

Direct control VFS[LINE Pressure]

▷ Control type : Normal low type

Control Pressure kpa (kgf/cm <sup>2</sup> , psi)	500.14~9.81 (5.1~0.1, 72.54~1.42)
Current value(mA)	50~850
Internal resistance(Ω)	5.1

دیجیتال خودرو  
شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




# ATA-72

# Automatic Transaxle System

## Circuit Diagram


[Circuit Diagram]

[Connection Information]




Terminal	Connected to	Function
17	TCM CHG-AG (2)	Line Pressure Control Solenoid Valve (LINE_VFS)
16	TCM CHG-AG (23)	Underdrive Brake Control Solenoid Valve(UD/B_VFS)
11	TCM CHG-AG (24)	26 Brake Control Solenoid Valve (26/B_VFS)
12	TCM CHG-AG (65)	SS-B Solenoid Valve(ON/OFF)
5	TCM CHG-AG (87)	Solenoid Valve power 2
2	TCM CHG-AG (3)	Torque Converter Control Solenoid Valve(T/CON_VFS)
7	TCM CHG-AG (25)	Overdrive Clutch Control Solenoid Valve(OD/C_VFS)
6	TCM CHG-AG (4)	35R Clutch Control Solenoid Valve (35R/C_VFS)
18	TCM CHG-AG (66)	SS-A Solenoid Valve(ON/OFF)
10	TCM CHG-AG (86)	Solenoid Valve power 1


[Harness Connector]



Solenoid Valve Connector [CRD04]



TCM Connector [CHG-AG]



TCM Connector [CHG-BG]

STFAT1124N

# Automatic Transaxle Control System

## ATA-73

### Inspection

1. Turn ignition switch OFF.
2. Disconnect the oil temperature sensor connector.
3. Measure resistance between sensor signal terminal and sensor ground terminal.
4. Check that the resistance is within the specification.

### Removal

#### NOTICE

Replacing an on/off solenoid valve (SS-A, SS-B) does not require additional hydraulic pressure adjustment; however, the hydraulic pressure will need to be adjusted after replacing the VFS solenoid valve. If replacing the VFS solenoid valve; also replace the valve body assembly. (Refer to "Valve Body" in this group)

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




## ATA-74

## Automatic Transaxle System

## 35R Clutch Control Solenoid Valve(35R/C\_VFS)

## Description

35R clutch control solenoid valve(35R/C\_VFS) is attached to the valve body. This variable force solenoid valve directly controls the hydraulic pressure inside the 35R clutch.



SSLAT0018D

## Specifications

Direct control VFS[35R/C]

▷ Control type : Normal low type

Control Pressure kpa (kgf/cm <sup>2</sup> , psi)	500.14~9.81 (5.1~0.1,72.54~1.42)
Current value(mA)	50~850
Internal resistance(Ω)	5.1

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران






# Automatic Transaxle Control System

# ATA-75

## Circuit Diagram


[Circuit Diagram]

[Connection Information]




Terminal	Connected to	Function
17	TCM CHG-AG (2)	Line Pressure Control Solenoid Valve (LINE_VFS)
16	TCM CHG-AG (23)	Underdrive Brake Control Solenoid Valve(UD/B_VFS)
11	TCM CHG-AG (24)	26 Brake Control Solenoid Valve (26/B_VFS)
12	TCM CHG-AG (65)	SS-B Solenoid Valve(ON/OFF)
5	TCM CHG-AG (87)	Solenoid Valve power 2
2	TCM CHG-AG (3)	Torque Converter Control Solenoid Valve(T/CON_VFS)
7	TCM CHG-AG (25)	Overdrive Clutch Control Solenoid Valve(OD/C_VFS)
6	TCM CHG-AG (4)	35R Clutch Control Solenoid Valve (35R/C_VFS)
18	TCM CHG-AG (66)	SS-A Solenoid Valve(ON/OFF)
10	TCM CHG-AG (86)	Solenoid Valve power 1


[Harness Connector]



Solenoid Valve Connector [CRD04]



TCM Connector [CHG-AG]



TCM Connector [CHG-BG]

STFAT1124N

## ATA-76

## Automatic Transaxle System

### Inspection

1. Turn ignition switch OFF.
2. Disconnect the oil temperature sensor connector.
3. Measure resistance between sensor signal terminal and sensor ground terminal.
4. Check that the resistance is within the specification.

### Removal

#### NOTICE

*Replacing an on/off solenoid valve (SS-A, SS-B) does not require additional hydraulic pressure adjustment; however, the hydraulic pressure will need to be adjusted after replacing the VFS solenoid valve. If replacing the VFS solenoid valve; also replace the valve body assembly. (Refer to "Valve Body" in this group)*

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




# Automatic Transaxle Control System

## ATA-77

### Underdrive Brake Control Solenoid Valve(UD/B\_VFS)

#### Description

Underdrive brake control solenoid valve(UD/B\_VFS) is attached to the valve body. This variable force solenoid valve directly controls the hydraulic pressure inside the underdrive brake.



SSLAT0018D

#### Specifications

Direct control VFS[35R/C]

▷ Control type : Normal low type

Control Pressure kpa (kgf/cm <sup>2</sup> , psi)	500.14~9.81 (5.1~0.1, 72.54~1.42)
Current value(mA)	50~850
Internal resistance(Ω)	5.1

دیجیتال خودرو  
شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




# ATA-78

# Automatic Transaxle System

## Circuit Diagram


[Circuit Diagram]

[Connection Information]



Terminal	Connected to	Function
17	TCM CHG-AG (2)	Line Pressure Control Solenoid Valve (LINE_VFS)
16	TCM CHG-AG (23)	Underdrive Brake Control Solenoid Valve(UD/B_VFS)
11	TCM CHG-AG (24)	26 Brake Control Solenoid Valve (26/B_VFS)
12	TCM CHG-AG (65)	SS-B Solenoid Valve(ON/OFF)
5	TCM CHG-AG (87)	Solenoid Valve power 2
2	TCM CHG-AG (3)	Torque Converter Control Solenoid Valve(T/CON_VFS)
7	TCM CHG-AG (25)	Overdrive Clutch Control Solenoid Valve(OD/C_VFS)
6	TCM CHG-AG (4)	35R Clutch Control Solenoid Valve (35R/C_VFS)
18	TCM CHG-AG (66)	SS-A Solenoid Valve(ON/OFF)
10	TCM CHG-AG (86)	Solenoid Valve power 1

[Harness Connector]



**Solenoid Valve Connector [CRD04]**

105	104	103	102	101	100	99	98	97	96	95	94	93	92	91	90	89	88	87	86	85
84	83	82	81	80	79	78	77	76	75	74	73	72	71	70	69	68	67	66	65	64
63	62	61	60	59	58	57	56	55	54	53	52	51	50	49	48	47	46	45	44	43
42	41	40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22
21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1

**TCM Connector [CHG-AG]**

91	90	89	88	87	86	85	84	83	82	81	80	79	78	77	76	75	6	5
74	73	72	71	70	69	68	67	66	65	64	63	62	61	60	59	58	4	3
57	56	55	54	53	52	51	50	49	48	47	46	45	44	43	42	41	2	1
40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24		
23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7		

**TCM Connector [CHG-BG]**

STFAT1124N

# Automatic Transaxle Control System

## ATA-79

### Inspection

1. Turn ignition switch OFF.
2. Disconnect the oil temperature sensor connector.
3. Measure resistance between sensor signal terminal and sensor ground terminal.
4. Check that the resistance is within the specification.

### Removal

#### NOTICE

Replacing an on/off solenoid valve (SS-A, SS-B) does not require additional hydraulic pressure adjustment; however, the hydraulic pressure will need to be adjusted after replacing the VFS solenoid valve. If replacing the VFS solenoid valve; also replace the valve body assembly. (Refer to "Valve Body" in this group)

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




## ATA-80

## Automatic Transaxle System

## Overdrive Clutch Control Solenoid Valve(OD/C\_VFS)

## Description

Overdrive clutch control solenoid valve(OD/C\_VFS) is attached to the valve body. This variable force solenoid valve directly controls the hydraulic pressure inside the overdrive clutch.



SSLAT0018D

## Specifications

Direct control VFS[35R/C]

▷ Control type : Normal low type

Control Pressure kpa (kgf/cm <sup>2</sup> , psi)	500.14~9.81 (5.1~0.1, 72.54~1.42)
Current value(mA)	50~850
Internal resistance(Ω)	5.1

دیجیتال خودرو  
شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




# Automatic Transaxle Control System

# ATA-81

## Circuit Diagram


[Circuit Diagram]

[Connection Information]



Terminal	Connected to	Function
17	TCM CHG-AG (2)	Line Pressure Control Solenoid Valve (LINE_VFS)
16	TCM CHG-AG (23)	Underdrive Brake Control Solenoid Valve(UD/B_VFS)
11	TCM CHG-AG (24)	26 Brake Control Solenoid Valve (26/B_VFS)
12	TCM CHG-AG (65)	SS-B Solenoid Valve(ON/OFF)
5	TCM CHG-AG (87)	Solenoid Valve power 2
2	TCM CHG-AG (3)	Torque Converter Control Solenoid Valve(T/CON_VFS)
7	TCM CHG-AG (25)	Overdrive Clutch Control Solenoid Valve(OD/C_VFS)
6	TCM CHG-AG (4)	35R Clutch Control Solenoid Valve (35R/C_VFS)
18	TCM CHG-AG (66)	SS-A Solenoid Valve(ON/OFF)
10	TCM CHG-AG (86)	Solenoid Valve power 1

[Harness Connector]



Solenoid Valve Connector [CRD04]

105	104	103	102	101	100	99	98	97	96	95	94	93	92	91	90	89	88	87	86	85
84	83	82	81	80	79	78	77	76	75	74	73	72	71	70	69	68	67	66	65	64
63	62	61	60	59	58	57	56	55	54	53	52	51	50	49	48	47	46	45	44	43
42	41	40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22
21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1

TCM Connector [CHG-AG]

91	90	89	88	87	86	85	84	83	82	81	80	79	78	77	76	75	6	5
74	73	72	71	70	69	68	67	66	65	64	63	62	61	60	59	58	4	3
57	56	55	54	53	52	51	50	49	48	47	46	45	44	43	42	41	2	1
40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24		
23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7		

TCM Connector [CHG-BG]

STFAT1124N

## ATA-82

## Automatic Transaxle System

### Inspection

1. Turn ignition switch OFF.
2. Disconnect the oil temperature sensor connector.
3. Measure resistance between sensor signal terminal and sensor ground terminal.
4. Check that the resistance is within the specification.

### Removal

#### NOTICE

*Replacing an on/off solenoid valve (SS-A, SS-B) does not require additional hydraulic pressure adjustment; however, the hydraulic pressure will need to be adjusted after replacing the VFS solenoid valve. If replacing the VFS solenoid valve; also replace the valve body assembly. (Refer to "Valve Body" in this group)*

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران






# Automatic Transaxle Control System

## ATA-83

### SS-A Solenoid Valve(ON/OFF)

#### Description

SS-A solenoid valve is attached to the valve body and is an on/off solenoid valve that is used to change gears. SS-A Solenoid valve(ON/OFF) is installed at valve body.



SSLAT0020D

#### Specifications

ON/OFF Solenoid Valve(SS-A, SS-B)

▷ Control type : Normal low type

Control pressure kpa (kgf/cm <sup>2</sup> , psi)	490.33(5.0, 71.12)
Internal resistance(Ω)	10~11

دیجیتال خودرو  
شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




# ATA-84

# Automatic Transaxle System

## Circuit Diagram


[Circuit Diagram]

[Connection Information]



Terminal	Connected to	Function
17	TCM CHG-AG (2)	Line Pressure Control Solenoid Valve (LINE_VFS)
16	TCM CHG-AG (23)	Underdrive Brake Control Solenoid Valve(UD/B_VFS)
11	TCM CHG-AG (24)	26 Brake Control Solenoid Valve (26/B_VFS)
12	TCM CHG-AG (65)	SS-B Solenoid Valve(ON/OFF)
5	TCM CHG-AG (87)	Solenoid Valve power 2
2	TCM CHG-AG (3)	Torque Converter Control Solenoid Valve(T/CON_VFS)
7	TCM CHG-AG (25)	Overdrive Clutch Control Solenoid Valve(OD/C_VFS)
6	TCM CHG-AG (4)	35R Clutch Control Solenoid Valve (35R/C_VFS)
18	TCM CHG-AG (66)	SS-A Solenoid Valve(ON/OFF)
10	TCM CHG-AG (86)	Solenoid Valve power 1

[Harness Connector]



Solenoid Valve Connector [CRD04]

105	104	103	102	101	100	99	98	97	96	95	94	93	92	91	90	89	88	87	86	85
84	83	82	81	80	79	78	77	76	75	74	73	72	71	70	69	68	67	66	65	64
63	62	61	60	59	58	57	56	55	54	53	52	51	50	49	48	47	46	45	44	43
42	41	40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22
21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1

TCM Connector [CHG-AG]

91	90	89	88	87	86	85	84	83	82	81	80	79	78	77	76	75	6	5
74	73	72	71	70	69	68	67	66	65	64	63	62	61	60	59	58	4	3
57	56	55	54	53	52	51	50	49	48	47	46	45	44	43	42	41	2	1
40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24		
23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7		

TCM Connector [CHG-BG]

STFAT1124N

# Automatic Transaxle Control System

## ATA-85

### Inspection

1. Turn ignition switch OFF.
2. Disconnect the oil temperature sensor connector.
3. Measure resistance between sensor signal terminal and sensor ground terminal.
4. Check that the resistance is within the specification.

### Removal


#### NOTICE

Replacing an on/off solenoid valve (SS-A, SS-B) does not require additional hydraulic pressure adjustment; however, the hydraulic pressure will need to be adjusted after replacing the VFS solenoid valve. If replacing the VFS solenoid valve; also replace the valve body assembly. (Refer to "Valve Body" in this group)

1. Remove the battery and the battery tray. (Refer to "Charging system" in EE group.)
2. Remove the under cover (A).

#### Tightening torque:

7.8 ~ 11.8 N.m (0.8 ~ 1.2 kgf.m, 5.8 ~ 8.7 lb-ft)



STFAT1007D

3. Replace new gasket and the plug after draining the automatic transaxle fluid by removing the drain plug. (Refer to "Hydraulic system (Fluid)" in this group)


4. Remove the valve body cover (A) and eyebolt (B).

#### Tightening torque:

(A) 13.8 ~ 14.7 N.m (1.3 ~ 1.5 kgf.m, 9.4 ~ 10.8 lb-ft)  
 (B) 34.3 ~ 44.1 N.m (3.5 ~ 4.5 kgf.m, 25.3 ~ 32.6 lb-ft)

#### CAUTION

Always replace the gasket of the eyebolt use new one whenever loosening eyebolt.



STFAT1018D

#### NOTICE

Remove installation bolts in the engine compartment first and


## ATA-86

## Automatic Transaxle System

5. Remove the bolt (3ea) after disconnecting the solenoid valve connector (A) and the oil temperature sensor connector (B).


**Tightening torque:**

9.8 ~ 11.8 N.m (1.0 ~ 1.2 kgf.m, 7.2 ~ 8.7 lb-ft)



SSLAT1112N

6. Remove the solenoid valve (A) after removing the solenoid support.




SSLAT0112D

**Installation**

1. Installation is the reverse of removal.

**NOTICE**

- When installing, apply the ATF oil or white vaseline to the O-ring (A) not to be damaged.



SSLAT0113D

- Continue to apply liquid gasket at application points at the valve body cover with  $\text{Ø}2.5\text{mm}$  (0.0984in.) thickness.

Liquid gasket Part name :

Threebond 1281B or LOCTITE FMD-546

- Adding automatic transaxle fluid. (Refer to "automatic transaxle system" in this group.)


# Automatic Transaxle Control System

## ATA-87

### SS-B Solenoid Valve(ON/OFF)

#### Description

SS-B solenoid valve is attached to the valve body and is an on/off solenoid valve that is used to change gears. SS-B Solenoid valve(ON/OFF) is installed at valve body.



SSLAT0020D

#### Specifications

ON/OFF Solenoid Valve(SS-A, SS-B)

▷ Control type : Normal low type

Control pressure kpa (kgf/cm <sup>2</sup> , psi)	490.33(5.0, 71.12)
Internal resistance(Ω)	10~11

دیجیتال خودرو  
شرکت دیجیتال خودرو سامانه (مسئولیت محدود)  
اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




# ATA-88

# Automatic Transaxle System

## Circuit Diagram


[Circuit Diagram]

[Connection Information]



Terminal	Connected to	Function
17	TCM CHG-AG (2)	Line Pressure Control Solenoid Valve (LINE_VFS)
16	TCM CHG-AG (23)	Underdrive Brake Control Solenoid Valve(UD/B_VFS)
11	TCM CHG-AG (24)	26 Brake Control Solenoid Valve (26/B_VFS)
12	TCM CHG-AG (65)	SS-B Solenoid Valve(ON/OFF)
5	TCM CHG-AG (87)	Solenoid Valve power 2
2	TCM CHG-AG (3)	Torque Converter Control Solenoid Valve(T/CON_VFS)
7	TCM CHG-AG (25)	Overdrive Clutch Control Solenoid Valve(OD/C_VFS)
6	TCM CHG-AG (4)	35R Clutch Control Solenoid Valve (35R/C_VFS)
18	TCM CHG-AG (66)	SS-A Solenoid Valve(ON/OFF)
10	TCM CHG-AG (86)	Solenoid Valve power 1

[Harness Connector]



Solenoid Valve Connector [CRD04]

105	104	103	102	101	100	99	98	97	96	95	94	93	92	91	90	89	88	87	86	85
84	83	82	81	80	79	78	77	76	75	74	73	72	71	70	69	68	67	66	65	64
63	62	61	60	59	58	57	56	55	54	53	52	51	50	49	48	47	46	45	44	43
42	41	40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22
21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1

TCM Connector [CHG-AG]

91	90	89	88	87	86	85	84	83	82	81	80	79	78	77	76	75	6	5
74	73	72	71	70	69	68	67	66	65	64	63	62	61	60	59	58	4	3
57	56	55	54	53	52	51	50	49	48	47	46	45	44	43	42	41	2	1
40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24		
23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7		

TCM Connector [CHG-BG]

STFAT1124N

# Automatic Transaxle Control System

## ATA-89

### Inspection

1. Turn ignition switch OFF.
2. Disconnect the oil temperature sensor connector.
3. Measure resistance between sensor signal terminal and sensor ground terminal.
4. Check that the resistance is within the specification.

### Removal


#### NOTICE

Replacing an on/off solenoid valve (SS-A, SS-B) does not require additional hydraulic pressure adjustment; however, the hydraulic pressure will need to be adjusted after replacing the VFS solenoid valve. If replacing the VFS solenoid valve; also replace the valve body assembly. (Refer to "Valve Body" in this group)

1. Remove the battery and the battery tray. (Refer to "Charging system" in EE group.)
2. Remove the under cover (A).

#### Tightening torque:

7.8 ~ 11.8 N.m (0.8 ~ 1.2 kgf.m, 5.8 ~ 8.7 lb-ft)



STFAT1007D

3. Replace new gasket and the plug after draining the automatic transaxle fluid by removing the drain plug. (Refer to "Hydraulic system (Fluid)" in this group)

4. Remove the valve body cover (B) and eyebolt (A).


#### Tightening torque:

(A) 34.3 ~ 44.1 N.m (3.5 ~ 4.5 kgf.m, 25.3 ~ 32.6 lb-ft)

(B) 13.8 ~ 14.7 N.m (1.3 ~ 1.5 kgf.m, 9.4 ~ 10.8 lb-ft)

#### CAUTION

Always replace the gasket of the eyebolt use new one whenever loosening eyebolt.



STFAT1018D

#### NOTICE

Remove installation bolts in the engine compartment first and


## ATA-90

## Automatic Transaxle System

5. Remove the bolt (3ea) after disconnecting the solenoid valve connector (A) and the oil temperature sensor connector (B).


**Tightening torque:**

9.8 ~ 11.8 N.m (1.0 ~ 1.2 kgf.m, 7.2 ~ 8.7 lb-ft)



SSLAT1112N

6. Remove the solenoid valve (A) after removing the solenoid support.




SSLAT0112D

**Installation**

1. Installation is the reverse of removal.

**NOTICE**

- When installing, apply the ATF oil or white vaseline to the O-ring (A) not to be damaged.



SSLAT0113D

- Continue to apply liquid gasket at application points at the valve body cover with  $\text{Ø}2.5\text{mm}$  (0.0984in.) thickness.

Liquid gasket Part name :

Threebond 1281B or LOCTITE FMD-546

- Adding automatic transaxle fluid. (Refer to "Hydraulic system (Fluid)" in this group)




# Automatic Transaxle Control System

## ATA-91

### Inhibitor Switch

#### Description

Inhibitor Switch monitors the lever's position (PRND) and is used to control gear setting signals.



SSLAT1113N

#### Specifications

▷ Type: Combination of output signals from 4 terminals

Power supply (V)	12
Output type	Pin to Pin

#### Signal Code Table


	P	P-R	R	R-N	N	N-D	D
Signal 1	1	0	0	0	1	1	1
Signal 2	0	0	0	1	1	0	0
Signal 3	1	1	0	0	0	0	0
Signal 4	1	1	1	1	1	1	0

# ATA-92

# Automatic Transaxle System

## Circuit Diagram

[Circuit Diagram]



[Connection Information]

Terminal	Connected to	Function
4	TCM CHG-AG (10)	Signal 1 input
8	TCM CHG-AG (9)	Signal 2 input
7	TCM CHG-AG (7)	Signal 3 input
9	TCM CHG-AG (8)	Signal 3 input
3	IG.1	IG 1
1	Start power(ON)	Start power(ON) 12V
2	Start relay	Start relay

[Harness Connector]



**Solenoid Valve Connector [CHG01]**

105	104	103	102	101	100	99	98	97	96	95	94	93	92	91	90	89	88	87	86	85
84	83	82	81	80	79	78	77	76	75	74	73	72	71	70	69	68	67	66	65	64
63	62	61	60	59	58	57	56	55	54	53	52	51	50	49	48	47	46	45	44	43
42	41	40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22
21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1

**TCM Connector [CHG-AG]**

91	90	89	88	87	86	85	84	83	82	81	80	79	78	77	76	75	6	5
74	73	72	71	70	69	68	67	66	65	64	63	62	61	60	59	58	4	3
57	56	55	54	53	52	51	50	49	48	47	46	45	44	43	42	41	2	1
40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24		
23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7		

**TCM Connector [CHG-BG]**


STFAT1123N

# Automatic Transaxle Control System

# ATA-93


## Removal

1. Make sure vehicle does not roll before setting room side shift lever and T/M side manual control lever to "N" position.
2. Remove the battery and the battery tray. (Refer to "Charging system" in EE group.)
3. Remove the air cleaner assembly. (Refer to "Intake manifold" in EM group.)
4. Remove the shift cable mounting nut (B).
5. Disconnect the inhibitor switch connector (A).



SLMAT0008N

6. Remove the manual control lever (A) and the washer (B) after removing a nut (C).



SSLAT1115N


### CAUTION

When installing, affix the manual control lever and the inhibitor switch with  $\varnothing 5\text{mm}$  (0.1969in.). Then tighten the inhibitor assembly mounting bolts.

7. Remove the inhibitor assembly (A) after removing the bolts (2ea).

### Tightening torque:

9.8 ~ 11.8 N.m (1.0 ~ 1.2 kgf.m, 7.2 ~ 8.7 lb-ft)



SSLAT1116N

### CAUTION

When installing, tighten the inhibitor assembly mounting bolt lightly, so that necessary adjustments can be made. Tighten to specifications.

## Installation


1. Installation is the reverse of removal.

# ATA-94

# Automatic Transaxle System

## Shift Lever

### Components



STFAT1020N

- 1. Shift lever knob & boots assembly
- 2. Shift lever assembly

- 3. Control cable assembly
- 4. Manual control lever (T/M side)


# Automatic Transaxle Control System

## ATA-95

### Removal


#### Shift Lever Assembly Replacement

1. Remove the center console assembly. (Refer to "Interior(console)" in BD group.)
2. Disconnect sports mode connector (A).



STFAT1012D

3. Remove the shift cable (B).




STFAT1109N

4. Remove the shift lever assembly (B) by removing the bolts (A-4ea).

#### Tightening torque:

9.8 ~ 14.7 N.m (1.0 ~ 1.5 kgf.m, 7.2 ~ 10.9 lb-ft)



STFAT1014D

5. Installation is the reverse of removal.

#### NOTICE


Make sure vehicle does not roll before setting room side shift lever and T/M side manual control lever to "N" position.

# ATA-96

# Automatic Transaxle System

## Control Cable Replacement

1. Remove the center console assembly. (Refer to "Interior(console)" in BD group.)
2. Remove the control cable (B).




STFAT1109N

3. Remove the control cable assembly in the vehicle after removing the nuts (B) and the retainer (A).


### Tightening torque:

9.8 ~ 14.7 N.m (1.0 ~ 1.5 kgf.m, 7.2 ~ 10.9 lb-ft)



SSLAT0032D

4. Remove the nut (C).
5. Remove the cable (B) from the bracket (A) at transaxle assembly side (Refer to "Automatic Transaxle" in this group).



SSLAT1004L

6. Remove the control cable inside of cab.

## Installation

1. Installation is the reverse of removal.

### NOTICE

Make sure vehicle does not roll before setting room side shift lever and T/M side manual control lever to "N" position.

# Automatic Transaxle Control System

## ATA-97


### Adjustment

#### Adjusting method for T/M control cable

1. Make sure vehicle does not roll before setting room side shift lever and T/M side manual control lever to "N" position.
2. Connect room side shift lever and control cable.
3. Push cable to "F" direction shown to eliminate FREE PLAY.
4. Tighten adjusting nut (A).

#### Tightening torque:

9.8 ~ 14.7 N.m (1.0 ~ 1.5 kgf.m, 7.2 ~ 10.9 lb-ft)



SLMAT0028D

5. After adjusting, check to be sure that this part operates as designed at each range of T/M side corresponding to each position of room lever.

