Body Electrical System



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

WWW.DIGITALKHODRO.COM



GENERAL

GENERAL

GENERAL TROUBLESHOOTING

INFORMATION E8A45E43

BEFORE TROUBLESHOOTING

- 1. Check applicable fuses in the appropriate fuse/relay box.
- 2. Check the battery for damage, state of charge, and clean and tight connections.

🔟 ΝΟΤΕ

- Do not quick-charge a battery unless the battery ground cable has been disconnected, otherwise you will damage the alternator diodes.
- Do not attempt to crank the engine with the battery ground cable loosely connected or you will severely damage the wiring.
- 3. Check the alternator belt tension.

HANDLING CONNECTORS

- 1. Make sure the connectors are clean and have no loose wire terminals.
- 2. Make sure multiple cavity connectors are packed with grease (except watertight connectors).
- 3. All connectors have push-down release type locks (A).

5. Some mounted connectors cannot be disconnected unless you first release the lock and remove the connector from its mount bracket (A).



- ETKD150B
- 6. Never try to disconnect connectors by pulling on their wires; pull on the connector halves instead.
- 7. Always reinstall plastic covers.



ETKD150C

ETKD150A

4. Some connectors have a clip on their side used to attach them to a mount bracket on the body or on another component. This clip has a pull type lock.

WWW.DIGITALKHODRO.COM

021- 62 99 92 92

BODY ELECTRICAL SYSTEM

BE -4

9.

8. Before connecting connectors, make sure the terminals (A) are in place and not bent.



Check for loose retainer (A) and rubber seals (B).



ETKD150F

- 11. Insert the connector all the way and make sure it is securely locked.
- 12. Position wires so that the open end of the cover faces down.



ETKD150E

ETKD150D

10. The backs of some connectors are packed with grease. Add grease if necessary. If the grease(A) is contaminated, replace it.

ETKD150G

WWW.DIGITALKHODRO.COM

GENERAL

HANDLING WIRES AND HARNESSES

- 1. Secure wires and wire harnesses to the frame with their respective wire ties at the designated locations.
- 2. Remove clips carefully; don't damage their locks (A).
- 4. After installing harness clips, make sure the harness doesn't interfere with any moving parts.
- 5. Keep wire harnesses away from exhaust pipes and other hot parts, from sharp edges of brackets and holes, and from exposed screws and bolts.
- 6. Seat grommets in their grooves properly (A). Do not leave grommets distorted (B).





- Do not use wires or harnesses with broken insulation. Replace them or repair them by wrapping the break with electrical tape.
- 2. After installing parts, make sure that no wires are pinched under them.
- 3. When using electrical test equipment, follow the manufacturer's instructions and those described in this manual.

ETKD150I

BE -6

4. If possible, insert the probe of the tester from the wire side (except waterproof connector).





BODY ELECTRICAL SYSTEM

FIVE-STEP TROUBLESHOOTING

- Verify the complaint Turn on all the components in the problem circuit to verify the customer complaint. Note the symptoms. Do not begin disassembly or testing until you have narrowed down the problem area.
- 2. Analyze the schematic

Look up the schematic for the problem circuit. Determine how the circuit is supposed to work by tracing the current paths from the power feed through the circuit components to ground. If several circuits fail at the same time, the fuse or ground is a likely cause. Based on the symptoms and your understanding of the circuit operation, identify one or more possible causes of the problem.

- Isolate the problem by testing the circuit Make circuit tests to check the diagnosis you made in step 2. Keep in mind that a logical, simple procedure is the key to efficient troubleshooting. Test for the most likely cause of failure first. Try to make tests at points that are easily accessible.
 - Fix the problem

Once the specific problem is identified, make the repair. Be sure to use proper tools and safe procedures.

Make sure the circuit works

Turn on all components in the repaired circuit in all modes to make sure you've fixed the entire problem. If the problem was a blown fuse, be sure to test all of the circuits on the fuse. Make sure no new problems turn up and the original problem does not recur.

ETKD150L

GENERAL

SPECIFICATIONS EA4A7D47

MULTIFUNCTION SWITCH

Items	Specifications
Rated voltage	DC 12 V
Operating temperature range	-30°C ~ +80°C (-22 ~ +176°F)
Rated load	
Dimmer & passing switch	High : 1A (Relay load)
	Low : 1A (Relay load)
	Passing : 1A (Relay load)
Lighting switch	Lighting: 1A (Relay load)
Turn signal & lane change switch	6.6±0.5A (Lamp load)
Wiper & mist switch	Low, High: 5A (Motor load)
	Intermittent : 0.22±0.05A (Relay load)
	Lock : Max. 28A (Motor load)
	Mist : 5A (Motor load)
Washer switch	4A (Motor load)
Variable intermittent volume switch	Max. 25mA
Rear wiper & washer switch	Rear wiper: 200mA (Relay load)
	Rear washer: 4A (Motor load)

INSTRUMENTS AND WARNING SYSTEM

Warning lamps	Bulb wattage (W)	Color
Illumination	LED	White green
High beam	سرخت درودرو LED	Blue
Low fuel	LED	Amber
Turn signal (LH, RH)	اولین س	Green
Battery (charge)	LED	Red
Oil pressure	1.4	Red
Air bag	1.4	Red
Parking brake	LED	Red
Seat belt	LED	Red
Check engine	1.4	Amber
ABS	LED	Amber
Door ajar	LED	Red
Tailgate open	LED	Amber
Immobilizer	LED	Amber
Cruise	LED	Green
SET	LED	Green
Glow	LED	Amber
Water separater	LED	Red
4WD	LED	Green
4WD LOCK	LED	Amber
TCS (ESP)	LED	Amber
TCS OFF (ESP OFF)	LED	Amber

WWW.DIGITALKHODRO.COM

021-62 99 92 92

BODY ELECTRICAL SYSTEM

INDICATORS AND GAUGE

Speedometer Type Input spec. Indication			Specifications						
Type Input spec.									
	o Stepper motor ty	/pe							
Indication	o Hall IC type : 4 pulses/rev.								
	o Km/h : 637rpm x 4 pulses/rev. indicates 60Km/h								
	o MPH : 1024 rpm	x 4 pulse	s/rev. inc	licates 60MF	ΡΉ				
Standard values	Velocity (km/h)	20		40	6	60	80		100
	Tolerance (km/h)	20.4-24	.7	42.5-46.5	64	-69	86-91.6	10	8.4-114
	Velocity (km/h)	120		140	1	60	180		200
	Tolerance (km/h)	130-13	6	152-158	174.	4-181	196.4-203	3 2'	16-223
						I			
	Velocity (MPH)	1	0	2	0		40	e	60
	Tolerance (MPH)	10.5	-13.5	21-	24	42	2.4-46	64	-68
	Velocity (MPH)	/elocity (MPH) 80		10	00		120	Rei	mark
	Tolerance (MPH)	85.4	4-90	107-	112	12	29-134		
Туре	o Stepper motor ty	pe							
Input spec.	o 4cyl : 2pulses/re	v.(2.0 GSI	11 12	1. 1. 1. 1. 1.					
	o 4cyl : 2pulses/re Revolution (RPM)	v.(2.0 GSI 1,000	2,000	3,000	SL), 4pu 4,000	lses/rev.(l 5,000	6,000	7,000	Remark
Input spec. Standard values	o 4cyl : 2pulses/re Revolution (RPM) Tolerance (RPM)	v.(2.0 GSI	11 12	1. 1. 1. 1. 1.				7,000 ±210	Remark Gasoline
Input spec.	o 4cyl : 2pulses/re Revolution (RPM)	v.(2.0 GSI 1,000	2,000	3,000	4,000	5,000	6,000		
Input spec. Standard values	o 4cyl : 2pulses/re Revolution (RPM) Tolerance (RPM)	v.(2.0 GSI 1,000 ±100 ±100	2,000 ±125 ±125	3,000 ±150 ±150	4,000 ±150 ±150	5,000 ±150 ±150	6,000 ±180 ±180	±210	Gasoline
Input spec. Standard values و فودرو در ایران	o 4cyl : 2pulses/re Revolution (RPM) Tolerance (RPM) Tolerance (RPM)	v.(2.0 GSI 1,000 ±100 ±100	2,000 ±125 ±125	3,000 ±150 ±150	4,000 ±150 ±150	5,000 ±150 ±150	6,000 ±180 ±180	±210	Gasoline
Input spec. Standard values و العران	o 4cyl : 2pulses/re Revolution (RPM) Tolerance (RPM) Tolerance (RPM)	v.(2.0 GSI 1,000 ±100 ±100	2,000 ±125 ±125	3,000 ±150 ±150	4,000 ±150 ±150	5,000 ±150 ±150	6,000 ±180 ±180	±210	Gasoline
Input spec. Standard values g objective Standard values g standard	o 4cyl : 2pulses/re Revolution (RPM) Tolerance (RPM) Tolerance (RPM)	v.(2.0 GSI 1,000 ±100 ±100	2,000 ±125 ±125	3,000 ±150 ±150	4,000 ±150 ±150	5,000 ±150 ±150	6,000 ±180 ±180	±210	Gasoline
Input spec. Standard values	o 4cyl : 2pulses/re Revolution (RPM) Tolerance (RPM) Tolerance (RPM)	v.(2.0 GSI 1,000 ±100 ±100	2,000 ±125 ±125	3,000 ±150 ±150	4,000 ±150 ±150	5,000 ±150 ±150	6,000 ±180 ±180	±210 -	Gasoline
Input spec. Standard values g object of the spectrum of the	o 4cyl : 2pulses/re Revolution (RPM) Tolerance (RPM) Tolerance (RPM) o Tap the tachome o Stepper motor ty	v.(2.0 GSI 1,000 ±100 ±100	2,000 ±125 ±125 vent hyst	3,000 ±150 ±150 erisis effects	4,000 ±150 ±150	5,000 ±150 ±150	6,000 ±180 ±180	±210	Gasoline
Input spec. Standard values g objective Standard values g standard	o 4cyl : 2pulses/re Revolution (RPM) Tolerance (RPM) Tolerance (RPM) o Tap the tachome o Stepper motor ty Level	v.(2.0 GSI 1,000 ±100 ±100	2,000 ±125 ±125 vent hyst Resis	$3,000$ ± 150 ± 150 erisis effects tance (Ω)	4,000 ±150 ±150	5,000 ±150 ±150	6,000 ±180 ±180 Gauge -40	±210 - angle (°)	Gasoline
Input spec. Standard values g object of the spectrum Standard values g Standard valu	o 4cyl : 2pulses/re Revolution (RPM) Tolerance (RPM) Tolerance (RPM) o Tap the tachome o Stepper motor ty Level E (Empty)	v.(2.0 GSI 1,000 ±100 ±100	2,000 ±125 ±125 vent hyst Resis	3,000 ±150 ±150 erisis effects tance (Ω) 94.4	4,000 ±150 ±150	5,000 ±150 ±150	6,000 ±180 ±180	±210 - angle (°) ± 2.4	Gasoline

ETQF001A

GENERAL

Items		Specifications	
Temperature gauge Type	o Stepper motor type		
Standard values	Temperature	Angle (°)	Resistance (Ω)
	49°C	-40	195
	71°C	-7 ± 2.4	86.5
	110°C	-7 ± 2.4	24
	127.4°C	35 ± 5	16.1

LIGHTING SYSTEM

Items	Bulb wattage (W)	
Head lamp	60W /55W (High / Low beam)	
Front turn signal lamp	21W x 2EA	
Front position lamp	5W	
Front fog lamp	27W	
Rear combination lamps Tail/stop lamp Back up lamp Turn signal lamp Rear fog lamp	5W / 21W 16W 21W 21W	
Side repeater lamp	5W	
Luggage & glove lamp	5W	
Room lamp	10W	
Cargo room lamp	10W	
Center high mounted stop lamp	LED	
Map lamp	10W x 2	
License plate lamp	5W	

BE -10

BODY ELECTRICAL SYSTEM

AUDIO

Items	K240 (K260)	M280 (J290)
Rated output	Max. 20W x 4	Max. 20W x 4 (Max. 35Wx4)
Load impedance	4 x 4	4 x 4 (2 x 4)
Band	AM/FM, LW/MW/FM	AM/FM, LW/MW/FM
Tuning type	PLL Synthesized type	PLL Synthesized type
Dark current	Max. 2mA (Max. 3.8mA)	Max. 2mA (Max. 3.8mA)
	AM : 531 ~ 1602KHZ/9 KHZ	AM : 531 ~ 1602KHZ/9 KHZ
	FM : 87.5 ~ 108MHZ/100 KHZ	FM : 87.5 ~ 108 MHZ/100KHZ
Frequency range / Channel	LW : 153 ~ 279KHZ/1 KHZ	LW : 153 ~ 279 KHZ/1KHZ
	MW : 531 ~ 1602KHZ/9KHZ	MW : 531 ~ 1602KHZ/9KHZ
	FM : 87.5~108 MHZ/50KHZ	FM : 87.5~108 MHZ/50KHZ

WINDSHIELD WIPER AND WASHER

Items	Specifications
Windshield wiper motor Speed/current at 20kgf·cm load test (2.0 Nm, 1.47 lbf·ft) Speed/current at 70kgf·cm load test (7.0 Nm, 5.16 lbf·ft) Torque when locking	Low : 40~48 rpm/4.0A or less High : 59~73 rpm/5.0A or less Low : 34~42 rpm/7.0A or less High : 49~61 rpm/9.0A or less Low : 38N.m/35A or less High : 32N.m/37A or less
Windshield washer motor Motor type Pump type Current Discharge pressure Flow rate Overload capacity (Continuous operation) With water Racing	DC ferrite magnet Centrifugal type Max. 5.0A Min. 1.8kgf/cm ² Min. 1,450cc/min. Max. 60 sec. Max. 20 sec.
Rear wiper motor Speed/current at no load test Speed/current at 10 kgf·cm load test (1.0 Nm, 0.74 lbf·ft) Torque when locking Wiping angle	28 rpm/Max. 2.2A 21~29 rpm/Max. 3.5A Min. 80 kgf·cm/Max.14A 157° ± 3°

GENERAL

TROUBLESHOOTING E5ECAB55

INSTRUMENTS AND WARNING SYSTEM

Symptom	Possible cause	Remedy
Speedometer does not operate	No.22 fuse (10A) blown Speedometer faulty Vehicle speed sensor faulty Wiring or ground faulty	Check for short and replace fuse Check speedometer Check vehicle speed sensor Repair if necessary
Tachometer does not operate	No.22 fuse (10A) blown Tachometer faulty Wiring or ground faulty	Check for short and replace fuse Check tachometer Repair if necessary
Fuel gauge does not operate	No.22 fuse (10A) blown Fuel gauge faulty Fuel sender faulty Wiring or ground faulty	Check for short and replace fuse Check gauge Check fuel sender Repair if necessary
Low fuel warning lamp does not light up	No.6 fuse (10A) blown Bulb burned out Fuel sender faulty Wiring or ground faulty	Check for short and replace fuse Replace bulb Check fuel sender Repair if necessary
Water temperature gauge does not operate	No.22 fuse (10A) blown Water temperature gauge faulty Water temperature sender faulty Wiring or ground faulty	Check for short and replace fuse Check gauge Check sender Repair if necessary
Oil pressure warning lamp does not light up	No.6 fuse (10A) blown Bulb burned out Oil pressure switch faulty Wiring or ground faulty	Check for short and replace fuse Replace bulb Check switch Repair if necessary
Low brake fluid warning lamp does not light up	No.6 fuse (10A) blown and the game Bulb burned out Brake fluid level warning switch faulty Parking brake switch faulty Wiring or ground faulty	Check for short and replace fuse Replace bulb Check switch Check switch Repair if necessary
Open door warning lamp and tailgate warning lamp do not light up	No.22 fuse (10A) blown Bulb burned out Door switch faulty Tailgate switch faulty Wiring or ground faulty	Check for short and replace fuse Replace bulb Check switch Check switch Repair if necessary
Seat belt warning lamp does not light up	No.6 fuse (10A) blown Bulb burned out Seat belt switch faulty Wiring or gound faulty	Check for short and replace fuse Replace bulb Check switch Repair if necessary
All illumination lights do not light up	Battery fusible link (50A) blown Tail lamp relay faulty No.6, No.7 fuse (10A) blown Rheostat faulty Wiring or ground faulty	Replace the fusible link Check relay Check for short and replace fuse Check rheostat Repair if necessary

BODY ELECTRICAL SYSTEM

LIGHTING SYSTEM

Symptom	Possible cause	Remedy
One lamp does not light (all exterior)	Bulb burned out Socket, wiring or ground faulty	Replace bulb Repair if necessary
Head lamps do not light	Bulb burned out No.28 fuse (10A) blown Head lamp fuse (15A) blown Head lamp relay faulty Lighting switch faulty Wiring or ground faulty	Replace bulb Check for short and replace fuse Check for short and replace fuse Check relay Check switch Repair if necessary
Tail lamps and license plate lamps do not light	Bulb burned out No.3, No.7 fuse (10A) blown Battery fusible link (50A) blown Tail lamp relay faulty ETACS module faulty Lighting switch faulty Wiring or ground faulty	Replace bulb Check for short and replace fuse Replace the fusible link Check relay Check ETACS module Check switch Repair if necessary
Stop lamps do not light	Bulb burned out No.31 fuse (15A) blown Stop lamp switch faulty Wiring or ground faulty	Replace bulb Check for short and replace fuse Adjust or replace switch Repair if necessary
Instrument lamps do not light (Tail lamps light)	Rheostat faulty Wiring or ground faulty	Check rheostat Repair if necessary
Turn signal lamp does not flash on one side	Bulb burned out Turn signal switch faulty Wiring or ground faulty	Replace bulb Check switch Repair if necessary
Turn signal lamps do not light	Bulb burned out No.24 fuse (10A) blown Flasher unit faulty Turn signal switch faulty Wiring or ground faulty	Replace bulb Check for short and replace fuse Check flasher unit Check switch Repair if necessary
Hazard warning lamps do not light	Bulb burned out No.29 fuse (10A) blown Flasher unit faulty Hazard switch faulty Hazard relay faulty Wiring or ground faulty	Replace bulb Check for short and replace fuse Check flasher unit Check switch Check relay Repair if necessary
Flasher rate too slow or too fast	Lamps' wattages are smaller or larger than specified Defective flasher unit	Replace lamps Check flasher unit
Back up lamps do not light	Bulb burned out No.24 fuse (10A) blown Back up lamp switch(M/T) faulty Transaxle range switch(A/T) faulty Wiring or ground faulty	Replace bulb Check for short and replace fuse Check switch Check switch Repair if necessary
Front fog lamps do not light	Bulb burned out Front fog lamp fuse (15A) blown Front fog lamp relay faulty Front fog lamp switch faulty Wiring or ground faulty	Replace bulb Check for short and replace fuse Check relay Check switch Repair if necessary

WWW.DIGITALKHODRO.COM

GENERAL

BE -13

Symptom	Possible cause	Remedy
Rear fog lamps do not light	Bulb burned out No.19 fuse (10A) blown No.25 fuse (15A) blown Rear fog lamp switch faulty Rear fog lamp relay faulty Wiring or ground faulty	Replace bulb Check for short and replace fuse Check for short and replace fuse Check switch Check relay Repair if necessary
Room lamp does not light	Bulb burned out No.22 fuse (10A) blown Room lamp switch faulty Door switch faulty ETACS module faulty Wiring or ground faulty	Replace bulb Check for short and replace fuse Check switch Check switch Check ETACS module Repair if necessary
Map lamp does not light	Bulb burned out No.25 fuse (15A) blown Map lamp switch faulty Wiring or ground faulty	Replace bulb Check for short and replace fuse Check switch Repair if necessary
Tailgate room lamp does not light	Bulb burned out No.25 fuse (15A) blown Trunk room lamp switch (4 door) faulty Tailgate switch (5 door) faulty Wiring or ground faulty	Replace bulb Check for short and replace fuse Check switch Check switch Repair if necessary

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

BE -14

BODY ELECTRICAL SYSTEM

AUDIO

There are six areas where a problem can occur: wiring harness, the radio, the cassette tape deck, the CD player, the speaker, and antenna. Troubleshooting enables you to confine the problem to a particular area.



ETQF001C

021-62999292



ETQF001D

BE -16

BODY ELECTRICAL SYSTEM



GENERAL

CHART 3



ETDD001D

021-62999292

BE -17

BODY ELECTRICAL SYSTEM

BE -18

CHART 4

1. RADIO



ETA9010F

GENERAL

2. TAPE



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

1. CD WILL NOT BE ACCEPTED



ETA9010H

021- 62 99 92 92

WWW.DIGITALKHODRO.COM

BE -20

BODY ELECTRICAL SYSTEM

2. NO SOUND

Does it play if a good quality CD is inserted ?	Yes Replace defective CD.
No Does the "WAIT" indicator flicker ? No Are the radio and CD player connected securely ? Yes Repair or replace CD player if the combined radio cassette operates properly.	Yes Return it to normal temperature, and recheck operation. Does it operate properly ? Yes O.K. No Securely connect the radio and CD player. No
	ETA9010O
 3. CD SOUND SKIPS 1) Sound sometimes skips when part Is CD face scratched or dirty ? No Does it play properly if CD is replace with an existing proper CD ? 	Yes CD is defective, or clean CD.
Yes	
Replace CD.	
 2) Sound sometimes skips when driv (Stop vehicle, and check it.) (Check by using a CD which is free Does sound skip when the side of the CD player is tapped ? 	ing. e of scratches, dirt or other damage.) <u>No</u> Check for skipping while driving and contact a service shop.
Securely mount the CD player.	

ETA9010I

WWW.DIGITALKHODRO.COM

021-62999292

GENERAL

4. SOUND QUALITY IS POOR



ETA9010J

BE -22

BODY ELECTRICAL SYSTEM





ETA9010L

021-62999292

GENERAL

CHART 8



ETA9010N

021-62999292

BE -24

BODY ELECTRICAL SYSTEM

WINDSHIELD WIPER

1. Wiper low and wiper high does not work.



ETQF901F

WWW.DIGITALKHODRO.COM

021-62999292

GENERAL

BE -25

POWER WINDOW

 No windows operate from the main switch on the driver's door.



ETQF901H

WWW.DIGITALKHODRO.COM

BE -26

BODY ELECTRICAL SYSTEM

3. Passenger's side window does not operate.



WWW.DIGITALKHODRO.COM

GENERAL

POWER DOOR LOCK

1. Lock function works but unlock function does not work.

Since door unlock relay is fail, replace the door unlock relay.

2. Unlock function works but lock function does not work.

Since door lock relay is fail, replace the door lock relay.

3. When passenger side knob is controlled, all doors interlocks, but when driver side knob is controlled, all doors do not interlock.



ETQF901J

021-62999292

BE -28

BODY ELECTRICAL SYSTEM

4. When passenger side knob is controlled. All doors interlocks. But when the driver side knob is controlled, all doors do not interlock.



ETQF901K

021-62999292

GENERAL

BE -29

5. Both sides do not interlock either.



ETQF901L

BE -30

BODY ELECTRICAL SYSTEM

KEYLESS ENTRY & BURGLAR ALARM SYSTEM

1. Alarm does not work. (Hazard lamp works)



2. When hood is opened inside the car like alarm test, horn does not work.



ETQF901N

WWW.DIGITALKHODRO.COM

021-62999292

BE -31

GENERAL

3. When door is opened inside the car like alarm test, horn does not work (If tailgate and hood is opened, alarm works)



When tailgate is opened inside the car like alarm test, 4. horn does not work.



ETQF901P

ETQF901O

021-62999292

BE -32

BODY ELECTRICAL SYSTEM

5. When the vehicle is locked by the transmitter, central door lock function works but hazard lamp doesn't blink.



ETKE901R

021-62999292

GENERAL

BE -33

7. Central door lock function works, but keyless entry system does not work.



ETKE901S

AUDIO SYSTEM

COMPONENTS E085DAD0



WWW.DIGITALKHODRO.COM

BODY ELECTRICAL SYSTEM

AUDIO SYSTEM

AUDIO UNIT

COMPONENTS ED8BB7DA



WWW.DIGITALKHODRO.COM



BODY ELECTRICAL SYSTEM



ETQF010C
021-62999292

AUDIO SYSTEM



WWW.DIGITALKHODRO.COM

021-62999292

BE -38

BODY ELECTRICAL SYSTEM



AUDIO SYSTEM

REMOVAL E3DD1577

- 1. Disconnect the negative(-) battery terminal.
- 2. Remove the upper plate from the transmission shift lever, then remove the 3 screws holding the center facia panel.

Remove the center facia panel(A) and disconnect the wire connectors.

INSPECTION EEFOC2E6

TAPE HEAD AND CAPSTAN CLEANING

- To obtain optimum performance, clean the head(A), and capstan(B) as often as necessary, depending on frequency of use and tape cleanness.
- 2. To clean the tape head and capstan, use a cotton swab dipped in ordinary rubbing alcohol. Wipe the head(A) and capstan(B).





KTQE260J

4. Installation is the reverse of removal.

WWW.DIGITALKHODRO.COM

BODY ELECTRICAL SYSTEM

BE -40

SPEAKERS

CIRCUIT DIAGRAM EBF0908A



AUDIO SYSTEM

REMOVAL EFFEDE9B

FRONT DOOR SPEAKER

- 1. Remove the front door trim panel (see BD group front door).
- 2. Remove the front door speaker after removing 4 screws.
- 3. Installation is the reverse of removal.

TWEETER SPEAKER

 Remove the delta cover from the front door then disconnect the 2P connector. Remove the tweeter speaker(A).



- 3. Installation is the reverse of removal. REAR DOOR SPEAKER
- 1. Remove the rear door trim panel (see BD group rear door).
- 2. Remove the rear door speaker after removing 4 screws.
- 2. Installation is the reverse of removal.

WOOFER SPEAKER

- 1. Remove the assist side seat (see BD group front seats)
- 2. Remove the woofer speaker(A) from the assist side floor after removing 2 bolts and 2 nuts.





KTQE280C

KTQE260B

WWW.DIGITALKHODRO.COM

021-62999292

BE -42

BODY ELECTRICAL SYSTEM

3. Installation is the reverse of removal.

EXTERNAL AMP

- 1. Open the tailgate then remove the luggage floor mat and trim.
- 2. Remove the external amp(A) from the luggage right side floor.

INSPECTION E134E5FC

- 1. Check the speaker with an ohmmeter. If an ohmmeter indicates the correct impedance of the speaker when checking between the speaker (+) and speaker (-) of the same channel, the speaker is ok.
- 2. If a clicking sound is emitted from the speaker when the ohmmeter is connected to the speaker terminals, the speaker is ok.



AUDIO SYSTEM

ANTENNA

COMPONENTS EDGEABAC



021-62999292

BODY ELECTRICAL SYSTEM

BE -44

REMOVAL EAEFDAAF

- 1. Remove the rear roof trim (see BD group-roof trim).
- 2. Disconnect the 1P connector(A) and antenna jack(B) from the roof antenna.
- 3. Remove the roof antenna after removing a nut.





MULTI FUNCTION SWITCH

BE -45

MULTI FUNCTION SWITCH

COMPONENTS E675CEA9



ETQF050G

WWW.DIGITALKHODRO.COM

MULTI FUNCTION SWITCH

REMOVAL ECDA242D

Prior to removing of the multifunction switch assembly in vehicles equipped with air bags, be careful to keep the following items.

A CAUTION

- Never attempt to disassemble or repair the air bag module or clock spring. If faulty, replace it.
- Do not drop the air bag module or clock spring or allow contact with water, grease or oil. Replace if a dent, crack, deformation or rust are detected.
- The air bag module should be stored on a flat surface and placed so that the pad surface is facing upward. Do not place anything on top of it.
- Do not expose the air bag module to temperatures over 93°C (200°F).
- After deployment of an air bag, replace the clock spring with a new one.
- Wear gloves and safety glasses when handling an air bag that has already been deployed.
- An undeployed air bag module should only be disposed of in accordance with the procedures. mentioned in the Restraints section.
- When you disconnect the air bag module-clock spring connector, take care not to apply excesive force to it.
- The removed air bag module should be stored in a clean, dry place.
- Prior to installing the clock spring, align the mating mark and "NEUTRAL" position indicator of the clock spring, and, after turning the front wheels to the straight-ahead position, install the clock spring to the column switch. If the mating mark of the clock spring is not properly aligned, the steering wheel may not completely rotate during a turn, or the flat cable within the clock spring may be severed, obstructing normal operation of the SRS and possibly leading to serious injury to the vehicle's driver. To inspect the clock spring, refer to the Restraints section.

BODY ELECTRICAL SYSTEM

1. Disconnect the negative(-) battery terminal.

🔟 ΝΟΤΕ

Prior to doing any further work after disconnection of the battery cable, wait at least 30 seconds.



2. Remove the 2 screws holding the air bag module with an asterix wrench. (Tor-x socket) Disconnect the horn connector and the air bag module connector, and remove the air bag module(A).



KTQE230A

MULTI FUNCTION SWITCH

- 3. Remove the steering wheel after removing a nut.
- 5. Remove the steering column upper and lower shrouds after removing 3 screws.





KTQE230C

4. Align the steering shaft with wheel then remove the steering wheel using special tool (09561-11002).

CAUTION

Do not hammer on the steering wheel to remove it; dong so may damage the collapsible mechanism.

6. Remove the 3 screwsholding the multi-function switch, then disconnect the wire connector. Remove the multi-function switch assembly.



KTQE230D

KTUE050B

KTQE230B

7. Installation is the reverse of removal.

INSPECTION E7ECD22C

LIGHTING SWITCH INSPECTION

With the multifunction switch in each position, make sure that continuity exists between the terminals below. If continuity is not as specified, replace the multifunction switch.



LIGHTING SWITCH [M20-1] LIGHTING SWITCH [M20-1]

Terminal Position	14	15	16	17
OFF				
I	0			-0
II	0	0	0	-0

ETQF040B

LIGHTING SWITCH (WITH AUTO-LIGHT CONTROL) [M20-1]

Terminal Position	14	15	16	17
OFF				
I	0			—0
II	0	0		—0
AUTO			0	—0

ETQF040A

BODY ELECTRICAL SYSTEM

DIMMER AND PASSING SWITCH [M20-1]

Terminal Position	1	2	10	11
HU		\bigcirc		—0
HL			0-	—0
Р	\bigcirc	_0		—0

HU : Head lamp high beam

HL : Head lamp low beam

P : Head lamp passing switch

ETFA040B

TURN SIGNAL SWITCH [M20-1]



WIPER AND WASHER SWITCH INSPECTION

With the multifunction switch in each position, make sure that continuity exists between the terminals below. If continuity is not as specified, replace the multifunction switch.



KTDD075I

WWW.DIGITALKHODRO.COM

MULTI FUNCTION SWITCH

WIPER SWITCH [M20-2]

Terminal						-		
Position	1	2	3	4	5	6	13	14
MIST				\circ	$\left\{ \right\}$			
OFF		0-	-					
INT		0-	-		\circ	ρ	○ - ^	Ş
LOW		0-			ρ			
HI	\bigcirc				\bigcirc			

ETFA040D

WASHER SWITCH [M20-2]

Terminal Position	5	7
OFF		
ON	0	O
	•	ETFA040

REAR WIPER & WASHER SWITCH [M20-2]

Terminal Position	ستولي	مان ¹ 0 (م	11 درو سا	.12 تال خو	••• شرکت دیجی
Rear washer	0			-0	
و در وجون	ن خودر	يركارار	ال تعه	ديجية	اولين سامانه
INT	0	-0			
ON	0		—0		
Rear washer	0			O	
				ETQF04	0D



BODY ELECTRICAL SYSTEM

BE -50

HORNS

COMPONENTS E39CA0C9



HORNS

HORN

REMOVAL E55C083D

- 1. Remove the head lamps assembly.
- 2. Remove the horns(high:A, low:B) assembly after removing a bolt, then disconnect the 2P connector.

INSPECTION EB38F5C2

- 1. Test the horn by connecting battery voltage to the 1 terminal and ground the 2 terminal.
- 2. The horn should make a sound. If the horn fails to make a sound, replace it.

ADJUSTMENT

Operate the horn, and adjust the tone to a suitable level by turning the adjusting screw.

NOTE

After adjustment, apply a small amount of paint around the screw head to keepit from loosening.



HORN RELAY INSPECTION

- 1. Remove the horn relay(A) from the engine compartment relay box.
- 2. Check for continuity between the terminals.
- 3. There should be continuity between the No.1 and No.2 terminals when power and ground are connected to the No.4 and No.3 terminals.
- 4. There should be no continuity between the No.1 and No.2 terminals when power is disconnected.





Terminal				
Power (No.3-No.4)	1	2	3	4
Disconnected			0	_0
Connected	0	-0	Θ	+

ETKE215E

KTQE210K

WWW.DIGITALKHODRO.COM

021-62999292

BODY ELECTRICAL SYSTEM

KEYLESS ENTRY AND BURGLAR ALARM

KEYLESS ENTRY AND BURGLAR ALARM

COMPONENTS ED5122D1



DESCRIPTION EAE2E05D

BURGLAR ALARM SYSTEM

The burglar alarm system is armed automatically after the doors, hood, and tailgate are closed and locked.

The system is set off when any of these things occur :

- A door is forced open.
- A door is unlocked without using the transmitter.
- The tailgate is opened without using the key.
- The hood is opened.
- The engine starter circuit and battery circuit are bypassed by breaking the ignition switch.

When the system is set off, the alarm (horn) sounds and the hazard lamp flash for about two minutes or until the system is disarmed by unlocking the transmitter.

For the system to arm, the ignition switch must be off and the key removed. Then, the ETACS module must receive signals that the doors, hood, and tailgate are closed and locked. When everything is closed and locked, none of the control unit inputs are grounded.

The door switches, hood switch and tailgate switch are all open then immediately after locking the doors with the remote transmitter the system arms.

If anything is opened or improperly unlocked after the system is armed, the ETACS module gets a ground signal from that switch, and the system is set off.

If one of the switches is misadjusted or there is a short in the system, the system will not arm. As long as the ETACS module continues to get a ground signal, it thinks the vehicle is not closed and locked and will not arm.

An alarm that sounds for no apparent reason may have been set off by a switch that is on the threshold of misadjustment. In this case, it may only take a significant change in outside temperature, the vibration of a passing truck, or someone bumping into the vehicle to make the alarm sound.

BODY ELECTRICAL SYSTEM

KEYLESS ENTRY SYSTEM

The burglar alarm system is integrated with the keyless entry system. The keyless entry system allows you to lock and unlock the vehicle with the remote transmitter. When you push the LOCK button, all doors lock. When you push the UNLOCK button all doors unlock.

The room lamp, if its switch is in the center position, will come on when you press the UNLOCK button. If you do not open a door, the light will go off in about 30 seconds, the doors will automatically relock, and the burglar alarm system will rearm. If you relock the doors with the remote transmitter within 30 seconds, the light will go off immediately.

You cannot lock or unlock the doors with the remote transmitter if the key is in the ignition switch.

The system will signal you when the doors lock and unlock by flashing the hazard lamp once when they lock, and twice when they unlock.

KEYLESS ENTRY AND BURGLAR ALARM

ANTI-THEFT FUNCTION EEDF4E6E

1. ARM FUNCTION

Pressing the remote key lock button will result in a 0.5-second pulse issued to lock all doors.

Pressing the remote keypad unlock button once will result in a 0.5-second unlock pulse issued to unlock all doors.

As part of the arming sequence the alarm first enters a pre-armed state before falling into the armed state. During this pre-armed state alarm triggers are ignored. Pre-armed state can be reached from the alarmed state, the start inhibit state or the disarmed state. Pre-Arming of the alarm can be achieved by a press of the lock button on the remote key.

In the pre-armed state the visible and audible warnings are disabled.

This system enters the armed state if it is in the prearmed state and,after 0.6 sec, check actuator lock and each door, hood and tailgate close,and no door warning switch (no key in ignition).

On entering the arm state, a single flash of the hazard lamps is given, period of cycle 2 second, duty rate 50%.

If transmitter(TX) lock signal is received when a door, tailgate or hood is open, then lock output is given and a flash of hazard is not given.

After the armed state is entered, if a lock signal is received then a single flash of the hazard lamps is given, period of cycle 2 second, duty rate 50%.

The armed state cannot be reached by locking the car with the keys.



ETQF115Q

- Time specification T1 : 0.5 ± 0.1 sec. T2 : Max. 2 sec.
- T3 : 1.0 ± 0.2 sec.

2. DISARM FUNCTION

Disarming can be performed while the alarm is armed, or alarming, orafter alarming. The alarm can be disarmed by the following methods :

- Pressing the unlock button on the transmitter(TX) key. The hazard lamps shall be flashed twice for 1sec period (of cycle), 50% duty rate.
- If door warning switch is on, IGN1 and IGN2 are on in arm state, then arm state should be immediately cancelled. This means that the driveris inside the vehicle before pushing TX lock, so system should not arm.

In the disarm state the visible and audible warnings are disabled and start is enabled.

In the disarm state, if TX key unlock command is received, then the hazard lamps shall be flashed twice for period of cycle 1 sec, 50% duty rate.





WWW.DIGITALKHODRO.COM

3. ALARM FUNCTION

- European contries
 Once armed, should any door, hood or the tailgate be opened, then :
 - Start relay drive output is disabled, so starting is inhibited.
 - Audible (horn) and visual (hazard lamp) warnings are issued, for 27 seconds duration. The horn warning is continuously occurring in this period. The hazard lamps operate with 1 sec period, 50 % duty rate.

The alarm is given in the case where a door is opened with a key.



Once armed, should any door, hood or the tailgate be opened, then.

- Start relay drive output is disabled, so starting is inhibited.
- Audible (horn) and visual (hazard lamp) warnings are issued, for three cycles, each cycle 27±2 sec. duration on, 10±1 sec. off. The horn warning is continuously occurring during the on period. The hazard lamps operate with 1 sec period, 50 % duty rate during the on period.

The alarm is given in the case where a door is opened with a key.

After this time, the system maintains the start inhibit state, where no audible and visual warnings are issued but engine starting is not possible.

BODY ELECTRICAL SYSTEM



Time specification T1 : 27 ± 2 sec. T2 : 10 ± 1 sec. T3 : 0.5 ± 0.1 sec.

4. OPERATION DURING ALARM CONDITIONS

1) Cancelling audible alarm with the remote transmitter.

CASE 1 : Door closed

During or after alarming and then closing all doors and a transmitter (TX) lock signal is received Then

- The lock command is executed with 0.5 sec. ON
- Horn and start inhibition are OFF
- Hazard lamp is flashed one time (period : 2 sec., duty: 50%, within2 sec.)
- The state goes to arming mode (after a lock state check)
- The start is enabled



Time specification T1 : 0.5 sec. T2 : 1.0 ± 0.2 sec.

CASE 2 : Door Open

During or after alarming, with a door open and a TX lock signal is received Then

 The lock command is executed with 0.5 sec. ON

WWW.DIGITALKHODRO.COM

KEYLESS ENTRY AND BURGLAR ALARM

- Horn is disabled and start is enabled after confirmation of actuator lock

At this time, when the door is closed,

- Hazard lamp is flashed one time (period : 2 sec., duty 50%)
- The state goes to arming mode



New alarm conditions

2)

Second alarm condition during alarming.

When another alarm occurs during alarming, the starting is disabled, and the alarm continues to sound for the remained time of warning signal. The alarm continues to sound after the second alarm condition is removed. New alarm condition occurs after alarming (with

all entrances closed)

If any entrance is opened again then

- The horn is ON 3 times (EC area : one time for 27sec.)
- Start is disabled
- Hazard lamps flash during the ON time of horn

New alarm condition occur after alarming (with any entrance open).

If another entrance is opened, the ETACS module keeps start disabled and there is no horn output.



ETOC100N

- Key operation during alarm After the alarm state or start inhibit state are entered, if door warning switch on (key in ignition) & IGN 2 ON, if IGN 2 state is changed to OFF within 30sec., remain in alarm state.
- 4) Disarming using the key

During alarming, in case that door warning switch (key in) is ON and then IGN1 and IGN2 are both ON for 30 sec continuously, the alarm is cancelled,and the system enters the disarm state. After alarming, in case that door warning switch (key in) is ON and then IGN1 and IGN2 are both ON for 30 sec continuously, the alarm is cancelled,and the system enters the disarm state.



5. ALARM STATE IN POWER DOWN

If the battery is disconnected to the ETACS module in the following states :

- Alarm
- After alarming

Upon restoring the battery, the alarm state shall be entered and the alarm cycle shall restarted (timer reset to 0).



ETHA115Z

WWW.DIGITALKHODRO.COM

ETACS MODULE INPUT SIGNAL

TEST E01D55EA

1. Disconnect the wire connector from the ETACS module.



ETQF250C

Terminals No.	Test condition	Standard value
A6-B12 (GND)	Door switch "ON" (Door opened)	Below 1
ئولیت محدود)	Door switch "OFF" (Door closed)	1M or higher
C13-B12 (GND)	Tailgate switch "ON" (Tailgate opened)	Below 1
	Tailgate switch "OFF" (Tailgate closed)	1M or higher
	Engine hood switch "ON" (Engine hood opened)	Below 1
C12-B12 (GND)	Engine hood switch "OFF" (Engine hood closed)	1M or higher
	Driver's door switch "ON" (Driver's door opened)	Below 1
A5-B12 (GND)	Driver's door switch "OFF" (Driver's door closed)	1M or higher
	Assist door switch "ON" (Assist door opened)	Below 1
A18-B12 (GND)	Assist door switch "OFF" (Assist door closed)	1M or higher
	Door warning switch "ON" (Key inserted)	Battery voltage
A16-B12 (GND)	Door warning switch "OFF" (Key removed)	Below 1V
A2-B12 (GND)	Always	Battery voltage
A15-B12 (GND)	Ignition switch is turned to "ON" position	Battery voltage

2. Inspect the connector on wire harness side as shown in the below.

BODY ELECTRICAL SYSTEM

KEYLESS ENTRY AND BURGLAR ALARM

BE -59

Terminals No.	Test condition	Standard value
	Driver's door lock switch "ON" (Driver's door unlock detection)	Below 1
C1-B12 (GND)	Driver's door lock switch "OFF" (Driver's door lock detection)	1M or higher
	Assist door lock switch "ON" (Assist door unlock detection)	Below 1
C2-B12 (GND) Assist door lock switch "OFF" (Assist door lock detection)		1M or higher
	Rear door lock switch "ON" (Rear door unlock detection)	Below 1
C9-B12 (GND)	C9-B12 (GND) Rear door lock switch "OFF" (Rear door lock detection)	
A4-B12 (GND)	Engine Start	Battery voltage
B12(GND) - Body ground	Always	Below 1
B6-B12 (GND)	Burglar alarm horn operation	ON

شرکت دیجیتال خود و سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

021-62999292

BE -60

INSPECTION E8E7627B

FRONT DOOR LOCK ACTUATOR INSPECTION

- Remove the front door trim panel. (see BD group-1. front door)
- Disconnect the 6P connector from the actuator. 2.

BODY ELECTRICAL SYSTEM

REAR DOOR LOCK ACTUATOR INSPECTION

- Remove the rear door trim panel. (see BD group-rear 1. door)
- 2. Disconnect the 6P connector from the actuator.



KTKD048A

KTKD047A

3. Check actuator operation by connecting power and ground according to the table. To prevent damage to the actuator, apply battery voltage only momentarily.

Terminal Position		4	6
Front loft	Lock	\ominus	\oplus
Front left	Unlock	\oplus	\ominus
Encat sight	Lock	\oplus	\ominus
Front right	Unlock	\bigcirc	\oplus

3. Check actuator operation by connecting power and ground according to the table. To prevent damage to the actuator, apply battery voltage only momentarily.

Terminal Position		3
Lock	\oplus	\ominus
Unlock	\ominus	\oplus
Lock	\ominus	\oplus
Unlock	\oplus	\ominus
	Lock Unlock Lock	Lock Lo

ETQF275B

KEYLESS ENTRY AND BURGLAR ALARM

FRONT DOOR LOCK SWITCH INSPECTION

- 1. Remove the front door trim panel. (see BD group-front door)
- 2. Disconnect the 6P connector from the actuator.

REAR DOOR LOCK SWITCH INSPECTION

- 1. Remove the rear door trim panel. (see BD group-rear door)
- 2. Disconnect the 6P connector from the actuator.



KTKD047A

3. Check for continuity between the terminals in each switch position according to the table.

Terminal Position		1	2	3
Encret left	Lock	0		\bigcirc
Front left	Unlock	0	-	
	Lock	0		\cap
Front right	Unlock		\bigcirc	$\bigcap_{i=1}^{n}$

ETQF280A

3. Check for continuity between the terminals in each switch position according to the table.

Terminal Position		4	5	6
Deerleft	Lock		\bigcirc	—O
Rear left	Unlock	\bigcirc		
	Onioon			\smile
	Lock	\frown		\frown
_	LOCK	\bigcirc		\cup
Rear right	Unlock		0	———————————————————————————————————————

ETQF280B

KTKD048A

021-62999292

BE -62

TAILGATE LOCK ACTUATOR INSPECTION

- 1. Remove the tailgate trim panel. (see BD group - tailgate)
- 2. Disconnect the 6P connector from the actuator.



3. Check actuator operation by connecting power and ground according to the table. To prevent damage to the actuator, apply battery voltage only momentarily.

Terminal Position	4	6
LOCK	(+)	$\overline{\bigcirc}$
UNLOCK	Θ	\oplus

ETQF165B

BODY ELECTRICAL SYSTEM

TAILGATE LOCK SWITCH INSPECTION

- 1. Remove the tailgate trim panel. (see BD group tailgate)
- 2. Disconnect the 6P connector from the actuator.



3. Check for continuity between the terminal in each switch position according to the table.



ETQF180C

KEYLESS ENTRY AND BURGLAR ALARM

DOOR SWITCH INSPECTION

Remove the door switch and check for continuity between the terminals.



TAILGATE SWITCH INSPECTION

- 1. Remove the tailgate trim panel.
- 2. Remove the tailgate latch after removing 3 bolts and disconnect the 2P connector from the tailgate switch.

[FRONT DOOR SWITCH]

Terminal Position	1	2	Body (Ground)
Free(Door open)	0	0	——O
Push(Door close)	c).	+1 I	
وليت محدود)	a (amin	رو ساماد	ETQF180

[REAR DOOR SWITCH]

Terminal Position	2	1(Ground)
Free(Door open)	0	O
Push(Door close)		

ETQF180E

KTQE804A

3. Check for continuity between the terminals according to the table.

Terminal Position	1	2(Ground)
Tailgate open	0	O
Tailgate close		

ETKE175C

WWW.DIGITALKHODRO.COM

HOOD SWITCH INSPECTION

1. Disconnect the 1P connector from the hood switch.

BODY ELECTRICAL SYSTEM

DOOR WARNING SWITCH INSPECTION

- 1. Remove the driver's crash pad lower panel. (see BD group-crash pad)
- 2. Disconnect the 6P connector from the door warning switch.



2. Check for continuity between the terminal and ground according to the table.

Terminal Position	Ground (Body)	1
Hood open (Free)	0	———————————————————————————————————————
Hood close (Push)		

ETPD180B

3. Check for continuity between the terminals in each position according to the table.

Terminal Key position	5	6
Insert	0	O
Removal		

ETQF180F

KEYLESS ENTRY AND BURGLAR ALARM

BURGLAR ALARM HORN INSPECTION

1. Remove the horn after removing a bolts and disconnect the 2P connector from the horn.



TRANSMITTER

INSPECTION E387AAFE

- 1. Check that the red light flickers when the door lock or unlock button is pressed on the transmitter.
- 2. Remove the battery and check voltage if the red light doesn't flicker.

Standard voltage : 3V

 Test the horn by connecting battery power to the terminal 1 and ground the terminal 2. The horn should make a sound. If the horn fails to make a sound replace it.

KTQE994A

- 3. Replace the transmitter battery with a new one, if voltage is below 3V then try to lock and unlock the doors with the transmitter by pressing the lock or unlock button five or six times.
- 4. If the door lock still does not operates, register the transmitter code, then try to lock and unlock the doors.
- 5. If the door lock still does not operates, replace the transmitter.

TRANSMITTER CODE REGISTRATION E5471EF4

1. Connect the DLC cable of hi-scan to the data link connector (16 pins) in driver side crash pad lower panel, turn the power on hi-scan.



2. Select the vehicle model and then do "CODE SAV-ING".



After selecting "CODE SAVING" menu, button "EN-TER" key, then the screen will be shown as below.

	KEYLESS ENTRY CODE SAVING
1	. REMOVE THE IG.KEY FROM KEY CYLINDER.
2	. CONNECT THE DLC CABLE TO THE 16 PIN DATA LINK CONNECTOR.
3	AFTER PRESSING [ENTER], FINISH CODE SAVING WITHIN 10 SECONDS.
4	. PRESS [ENTER], IF YOU ARE READY!
<u> </u>	ETQF06
4.	After removing the ignition key from key cylinder, pus "ENTER" key to proceed to the next mode for cod saving.
	Follow steps 1 to 3 and then code saving is completed
	KEYLESS ENTRY CODE SAVING

FOR 1 SECOND.

3.

- 2. IF SAVE ONE MORE PRESS OTHER TRANSMITTER [LOCK] BUTTON FOR 1 SECOND.
- 3. PRESS [ESC] AND DISCONNECT DLC CABLE FROM VEHICLE AND CHECK THE KEYLESS ENTRY SYSTEM.

ETQF065N

BODY ELECTRICAL SYSTEM

ETACS (ELECTRONIC TIME AND ALARM CONTROL SYSTEM)

BE -67

ETACS (ELECTRONIC TIME AND ALARM CONTROL SYSTEM)

DESCRIPTION EBBAF59A



SPECIFICATIONS

Items	Specifications
Rated voltage	DC 12V
Operating voltage	DC 9 ~ 16V
Dark current	3mA(ETACS) or 4mA(ETACS & RECEIVER)
Insulation resistance	100M or more
RATED LOAD	
Burglar alarm horn	DC 12V, 200mA (Inductance load)
Chime bell	DC 12V, 350mA (Inductance load)
Rear defogger relay	DC 12V, 200mA (Inductance load)
Hazard lamp relay	DC 12V, 200mA (Inductance load)
Tail lamp relay	DC 12V, 200mA (Inductance load)
Seat belt warning indicator	DC 12V, LED (Lamp load)
Room lamp	DC 12V, 12W (Lamp load)
Power window relay	DC 12V, 200mA (Inductance load)
Intermittent wiper relay	DC 12V, 200mA (Inductance load)
Key hole illumination lamp	DC 12V, 5W (Lamp load)
Door lock relay	DC 12V, 2W (Lamp load)
Door unlock relay	DC 12V, 200mA (Inductance load)
Start inhibit relay	DC 12V, 200mA (Inductance load)
Windshield deicer relay	DC 12V, 200mA (Inductance load)
Rear fog lamp relay	DC 12V, 200mA (Inductance load)

BODY ELECTRICAL SYSTEM

ELECTRONIC TIME AND ALARM CONTROL MODULE

CIRCUIT DIAGRAM E16D8004

BE -68



WWW.DIGITALKHODRO.COM

ETACS (ELECTRONIC TIME AND ALARM CONTROL SYSTEM)

ETACS MODULE INPUT SIGNAL

TEST E7D25E1C

- 2. Inspect the connector on wire harness side as shown in the below.
- Disconnect the wire connector from the ETACS module.



Terminal No.	Connector A	Connector B	Connector C
	Room lamp	Windshield deicer relay	Driver's door lock switch
2	B+ ••	0 00 D.R.L	Assist door lock switch
ئولىت 3حدود)	IGN1	Tail lamp relay	
4	Alternator (L)	Seat belt indicator	
5	Driver door switch	Key hole illumination	
6	Door switch	Burglar alarm relay	0.
7	-	Rear defogger relay	-
8	-	Power window relay	Door unlock relay
9	Windshield deicer switch	Wiper relay	Rear door lock switch
10	Front fog lamp switch	Rear fog lamp relay	Auto door unlock
11	Head lamp switch	Chime bell	-
12	Washer switch	Ground	Hood switch
13	Diagnosis		Tailgate switch
14	Signal ground		Hazard lamp relay
15	IGN2		Start inhibit relay
16	Door warning switch		Door lock relay
17	-		
18	Assist door switch		
19	Tail lamp switch		
20	Code saving		
21	Seat belt switch		
22	Rear defogger switch		
23	Rear fog lamp switch		

BODY ELECTRICAL SYSTEM

Terminal No.	Connector A	Connector B	Connector C
24	Intermittent wiper switch		
25	Intermittent wiper volume		
26	Speed sensor		

ETACS MODULE INPUT SIGNAL TEST

Pin No.	Input signal name	Test condition	Desired result
A3	IGN1	Ignition switch ON or START	Check for voltage to ground; There should be battery voltage
A15	IGN2	Ignition switch ON	Check for voltage to ground; There should be battery voltage
A4	Alternator "L"	Engine start condition	Check for voltage to ground; There should be battery voltage
A16	Door warning switch	Key is inserted into the ignition switch	Check for voltage to ground; There should be battery voltage
A6	All door switch	One of all doors is opened	Check for continuity to ground; There should be continuity
A5	Driver's door switch	Driver's door open	Check for continuity to ground; There should be continuity
A18	Assist door switch	Assist door open	Check for continuity to ground; There should be continuity
C9	Rear door lock switch	One of rear doors is unlock	Check for continuity to ground; There should be continuity
و در اداغ	Tailgate switch	Tailgate open	Check for continuity to ground; There should be continuity
A9	Windshield deicer switch	Windshield deicer switch ON	Check for continuity to ground; There should be continuity
C12	Hood switch	Hood open	Check for continuity to ground; There should be continuity
A12	Washer switch	Washer switch ON	Check for continuity to ground; There should be continuity
A24	Intermittent wiper switch	INT. wiper switch ON	Check for continuity to ground; There should be continuity
A25	Intermittent wiper volume switch	INT. wiper volume switch ON	Resistance should vary from 0 to 50k
A22	Rear defogger switch	Rear defogger switch ON	Check for continuity to ground; There should be continuity
A19	Tail lamp switch	Tail lamp switch ON	Check for continuity to ground; There should be continuity
A21	Seat belt switch	Seat belt is unbuckled	Check for continuity to ground; There should be continuity
A20	Code saving tool	Code save signal	There should be open at unused
A2	Battery (+)	Constant	Check for voltage to ground ; There should be battery voltage
B12	Ground	Constant	Check for continuity to ground ; There should be continuity

WWW.DIGITALKHODRO.COM

ETACS (ELECTRONIC TIME AND ALARM CONTROL SYSTEM)

BE -71

Pin No.	Input signal name	Test condition	Desired result
C1	Driver's door lock switch	Driver's door is unlock	Check for continuity to ground ; There should be continuity
C2	Assist door lock switch	Assist door is unlock	Check for continuity to ground ; There should be continuity
A11	Head lamp switch	Head lamp switch ON	Check for continuity to ground ; There should be continuity
A26	Speed sensor	Speed sensor input	Check for voltage to ground; There should be about 0~5V
A10	Front fog lamp switch	Front fog lamp switch ON Tail lamp swtich ON	Check for continuity to ground ; There should be continuity
C10	Air bag signal	Ignition switch ON	Check for voltage to ground ; There should be about 5V

REMOVAL EA0965B8

- 1. Disconnect the negative (-) battery terminal.
- 2. Remove the shift lever upper plate and lower trim.
- 3. Remove the ETACS module (A) after removing 2 bolts.

INSPECTION E433A3B6

(VR=50k)

While operating the components, check whether the operations are normal as shown in the timing chart.

1. VARIABLE INTERMITTENT WIPER



4. Installation is the reverse of removal.

021- 62 99 92 92

BODY ELECTRICAL SYSTEM

SEAT BELT WARNING TIMER

BE -72

2. WASHER TIMER



4.

- After ALT "L" ON, if the defogger is switched ON, the defogger output is ON for 20 minutes duration.
- If the defogger switch is pressed again, or if the ignition is switched OFF during this time, the defogger output is OFF.



T1: 20 ± 1min.

T1 : 6±1 sec., T2 : 0.45 ± 0.1 sec., T3 : 0.3 ± 0.1 sec.

- 5. DECAYED ROOM LAMP & KEYLESS UNLOCK TIMER
 - When the first door (driver's or assist) is opened, the room lamp shall brighten. When the last door is closed, the room lamp will drop to 75% intensity, then fade out over 5-6 seconds.
 - 2) If the door switch is ON for less than 0.1 sec., then no illumination occurs.
 - 3) The fade resolution is over 32 steps.
 - 4) The room lamp must not flicker during fade operation, if the ignition is switched ON.

ETMB902B
ETACS (ELECTRONIC TIME AND ALARM CONTROL SYSTEM)

BE -73

5) With keyless UNLOCK, when the door is closed, the room lamp is turned ON, then OFF after about 30 seconds. While the room lamp is ON due to keyless UNLOCK, if another UNLOCK is received, the room lamp is again ON for 30 seconds.

While the room lamp is ON, If the door is opened, the lamp is continued to ON. If the door is closed, the lamp follows as the above step 1.

If keyless LOCK (ARM state) is received during fade out, the room lamp is switched off immediately.



- 6. CENTRAL DOOR LOCK/UNLOCK
 - 1) The driver's door lock, assist door lock, or the inside door lock knob is switched LOCK to UN-LOCK or UNLOCK to LOCK, the all doors lock and unlock outputs will follow.
 - 2) Battery connecting would not change the LOCK/UNLOCK states.



ETQF983D

T1 : 0.5 ± 0.1 sec.

- 7. IGNITION KEY REMINDER
 - If the key is in the ignition and the driver's door or assist door is opened and the vehicle is locked using driver's knob or assist knob, then the central locking system will issue an unlock pulse of 1 second duration to the all doors thus preventing locking of the vehicle. (With a knob remains locked, if the switch in the actuator is not changed, the central locking shall issue 1 pulse of 1 seconds duration and 3 pulses of 0.5 second duration to unlock the vehicle.)



- ETPD120A
- T1,T3: 0.5 sec., T2: 1 sec., T4: Max.0.5 sec.
- 8. POWER WINDOW TIMER
 - When the ignition is switched ON, the power window relay output is turned ON.
 - 2) When the ignition is switched OFF, the power window output is maintained ON for 30 seconds and then turned OFF.
 - With the state of step 2, if the driver's door or assist door is opened, the output shall be turned OFF immediately.



T1: 30 ± 3 sec.

021-62999292

BE -74

- 9. DOOR OPEN WARNING
 - 1) If the key is in the ignition key cylinder and the driver's door is opened, the chime bell sounds continually (period:0.9 sec. Duty rate:50%).
 - 2) If the door is closed or the key is removed, the chime stops immediately.

BODY ELECTRICAL SYSTEM

- 11. CRASH DOOR UNLOCK
 - With the ignition turned ON, if the air bag is deployed, a crash signal is received and send an UNLOCK output to all doors UNLOCK.
 - 2) After UNLOCK output, when LOCK is set, UN-LOCK pulse is output for 5 second period again.



T1 : 10±1 sec. T2 : 0~10 sec.

WWW.DIGITALKHODRO.COM

021-62999292

ETACS (ELECTRONIC TIME AND ALARM CONTROL SYSTEM)

13. REAR FOG LAMP CONTROL

- With the ignition switch and the head lamp switch turned ON, if the rear fog lamp switch is turned ON, the rear fog lamp relay output is ON.
- 2) With the rear fog lamp output ON if the rear fog lamp switch is pressed again, the rear fog lamp switch is pressed again, the rear fog lamp output is OFF.

IGN, TAIL SWITCH	OFF OFF	
H/LAMP SWITCH or FRT FOG LAMP SWITCH	ON OFF	
REAR FOG LAMP SWITCH	ON OFF	
REAR FOG LAMP	ON OFF	







ETQF983I

T1: 20 ± 1min.

BE -75

BODY ELECTRICAL SYSTEM

ETACS INPUT/OUTPUT MONITORING

INPUT/OUTPUT MONITORING	ACTUATION	REMARKS
IGN1		
IGN2		
ALT "L"		
Key in switch		
Start inhibit relay	Start inhibit relay	with Keyless-entry
Power window relay	Power window relay	
Tail lamp switch		
Rear fog switch		
Head lamp switch		
Front fog switch		
Tail lamp relay	Tail lamp relay	
Rear fog relay	Rear fog relay	
Hazard lamp relay	Hazard lamp relay	with Keyless-entry
Driver seat belt indicator	Driver seat belt indicator	
Room lamp output	Room lamp output	
IGN key hole illumination	IGN key hole illumination	
Driver door open switch		
Assist door open switch	صرحت دیجیتال خود	
4 door open switch		
Hood open switch	اولين سامانه ديجيتا	with Keyless-entry
Tailgate switch		
Driver door actuator position switch		
Assist door actuator position switch		
Door lock relay	Door lock relay	
Door unlock relay	Door unlock relay	
Rear door actuator position switch		
Washer switch		
Wiper INT switch		
Rear defogger switch		
Wiper relay	Wiper relay	
Rear defogger relay	Rear defogger relay	
Front deicer switch		
Front deicer relay	Front deicer relay	
Driver seatbelt switch		
Burglar horn relay	Burglar horn relay	with Keyless-entry
Chime bell	Chime bell	
Wiper INT volume		

ETACS (ELECTRONIC TIME AND ALARM CONTROL SYSTEM)

BE -77

INPUT/OUTPUT MONITORING	ACTUATION	REMARKS
Speed signal		
Tx data record		with keyless-entry



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

BODY ELECTRICAL SYSTEM

FUSES AND RELAYS

COMPONENTS E0C35031



FUSES AND RELAYS

BE -79



BODY ELECTRICAL SYSTEM

RELAY BOX (ENGINE COMPARTMENT)

COMPONENTS EDCABE3B



FUSES AND RELAYS

INSPECTION E3A40D4F

POWER RELAY TEST (TYPE A)

Check for continuity between the terminals.

- 1. There should be continuity between the No.1 and No.2 terminals when power and ground are connected to the No.4 and No.3 terminals.
- 2. There should be no continuity between the No.1 and No.2 terminals when power is disconnected.

POWER RELAY TEST (TYPE B)

Check for continuity between the terminals.

- 1. There should be continuity between the No.1 and No.2 terminals when power and ground are connected to the No.5 and No.3 terminals.
- 2. There should be continuity between the No.1 and No.4 terminals when power is disconnected.



Terminal Power (No.3-No.4)	1	2	3	4
Disconnected			0	-O
Connected	\bigcirc	-	Θ	

Power (No.3-No.5)	3	5	1	2	4
Disconnected			<u> </u>		-0
Connected	Θ—	(+)	0-	-0	
					FTVFA

ETKE215H

ETKE903A

WWW.DIGITALKHODRO.COM

021-62999292

BE -82

POWER RELAY TEST (TYPE C)

Check for continuity between the terminals.

- 1. There should be continuity between the No.1 and No.4 terminals when power and ground are connected to the No.3 and No.2 terminals.
- 2. There should be no continuity between the No.1 and No.4 terminals when power is disconnected.



ETQF927A

Terminal Power (No.2-No.3)	2	3	1	4
Disconnected	0	-0		
Connected	Θ		0	—0

ETKE215B

WWW.DIGITALKHODRO.COM

021-62999292

BODY ELECTRICAL SYSTEM

FUSES AND RELAYS

RELAY BOX (PASSENGER COMPARTMENT)

COMPONENTS EEC8C25E



WWW.DIGITALKHODRO.COM

BE -84

BODY ELECTRICAL SYSTEM

CIRCUIT

FUSE	(A)	Circuit Protected
1	30A	Left power window switch
2	30A	Right power window switch
3	10A	Right rear combination lamp, Glove box ILL, Illuminations
4	30A	Rear defogger relay
5	15A	SRS control module
6	10A	Instrument cluster, ETACM/TACM
7	10A	Left head lamp, Left rear combination lamp, License lamp
8	10A	Digital clock, Audio, Power outside mirror folding module, Power outside mirror & mirror folding switch
9	20A	Cigarette lighter
10	15A	(SPARE)
11	10A	Rear fog lamp relay
12	10A	Left/Right power outsider mirror & mirror folding motor, Rear defogger switch
13	10A	Audio
14	20A	Ignition coil(2.7 GAS)
15	10A	Immobilizer control module (2.7 GAS)
16	15A	Rear power outlet #1/#2
17	10A	(Not used)
18	20A	Left/Right front seat warmer switch
19	10A	A/C control module (Manaul A/C)
20	10A	Burglar alarm relay, Transaxle range switch, Ignition lock switch
21	30A	Ignition switch (IG2, START)
22	10A	Room lamp, A/C control module, Digital clock, ETACM/TACM, Key remind switch
23	20A	Audio amp #2, Sub woofer
24	10A	Hazard switch, Auto light & Photo sensor, Transaxle range switch
25	10A	Instrument cluster, Pre-excitation resistor
26	15A	Safety relay
27	10A	Sunroof controller, A/C control module, Blower relay, ETACM/TACM
28	10A	PTC heater relay, Fuel filter heater relay, DRL control module, Head lamp relay
29	10A	Hazard switch, Hazard relay, Immobilizer control module (2.7 GAS)
30	20A	Sunroof controller, Door lock/unlock relay
31	15A	Stop lamp switch, Power outside mirror folding module
32	10A	(Not used)
33	10A	Cruise control module, Stop lamp switch, TCS switch, ESP switch, 4WD ECM,
		ECM, PCM, TCM, Pulse generator 'A'/'B', Vehicle speed sensor
34	20A	Front wiper relay, Front wiper motor, Multifunction switch
35	20A	4WD/ECM
36	15A	Winshield defogger relay
37	10A	TCM (2.7 GAS/DSL)
38	10A	G-Sensor, ESP control module, ABS control module, Multipurpos check connector

ETQF992B

FUSES AND RELAYS

BE -85





INSPECTION EB589ADB

POWER RELAY TEST (TYPE A)

Check for continuity between the terminals.

- 1. There should be continuity between the No.1 and No.2 terminals when power and ground are connected to the No.4 and No.3 terminals.
- 2. There should be no continuity between the No.1 and No.2 terminals when power is disconnected.

BODY ELECTRICAL SYSTEM

POWER RELAY TEST (TYPE B)

Check for continuity between the terminals.

- 1. There should be continuity between the No.1 and No.2 terminals when power and ground are connected to the No.5 and No.3 terminals.
- 2. There should be no continuity between the No.1 and No.4 terminals when power is disconnected.



ET	FQF034/	٩

Terminal Power (No.3-No.4)	1	2	3	4
Disconnected			0	—0
Connected	0	\cap	Θ	+

Terminal 3 5 1 2 4 Power (No.3-No.5) \bigcirc \bigcirc Disconnected \bigcirc (+) \bigcirc Connected \bigcirc ETKE215H

ETKE903A

ETQF035A

FUSES AND RELAYS

POWER RELAY TEST (TYPE C)

Check for continuity between the terminals.

- 1. There should be continuity between the No.1 and No.5 terminals when power and ground are connected to the No.4 and No.2 terminals.
- 2. There should be no continuity between the No.3 and No.5 terminals when power is disconnected.

10

2

Hazard lamp relay

1 0 3



ETKE038A



021-62999292

BODY ELECTRICAL SYSTEM

INDICATORS AND GAUGES

COMPONENTS E84D67D2



INDICATORS AND GAUGES

INSTRUMENT CLUSTER

COMPONENTS E56388D2



WWW.DIGITALKHODRO.COM

BODY ELECTRICAL SYSTEM

BE -90

CIRCUIT DIAGRAM E997BDD1



ETQF300E

021- 62 99 92 92

INDICATORS AND GAUGES

REMOVAL E4AE7BDD

- 1. Disconnect the negative(-) battery terminal.
- 2. Remove the cluster facia panel(A) after removing 2 screws.



INSPECTION EOADCAE7

SPEEDOMETER

- 1. Adjust the pressure of the tires to the specified level.
- 2. Drive the vehicle onto a speedometer tester. Use wheel chocks as appropriate.
- 3. Check if the speedometer indicator range is within the standard values.

\Lambda CAUTION

Do not operate the clutch suddenly or increase/ decrease speed rapidly while testing.

🚺 ΝΟΤΕ

Tire wear and tire over or under inflation will increase the indication error.

Remove the cluster(A) after removing 4 screws, then disconnect the wire connectors.

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



KTQE230G

4. Installation is the reverse of removal.



BE -91

BODY ELECTRICAL SYSTEM

Velocity (km/h)	20	40	60	80	100
Tolerance (km/h)	20.7-24.7	42.5-46.5	64-69	86-91.6	108.4-114
Velocity (km/h)	120	140	160	180	200
Tolerance (km/h)	130-136	152-158	174.4-181	196.4-203	216-223

Velocity (MPH)	10	20	40	60	80	100	120
Tolerance (MPH)	10.5-13.5	21-24	42.4-46	64-68	85.4-90	107-112	129-134

VEHICLE SPEED SENSOR

- Connect the positive (+) lead from battery to terminal 31and negative (-) lead to terminal 2.
- 2. Connect the positive (+) lead from tester to terminal 3 and the negative (-) lead to terminal 2.
- 3. Rotate the shaft.
- 4. Check that there is voltage change from approx. 0V to 11V or more between terminals 2 and 3.
- 5. The voltage change should be 4 times for every revolution of the speed sensor shaft. If operation is not as specified, replace the sensor.

TACHOMETER

- 1. Connect the scan tool to the diagnostic link connector or install a tachometer.
- 2. With the engine started, compare the readings of the tester with that of the tachometer. Replace the tachometer if the tolerance is exceeded.

- 1. Reversing the connections of the tachometer will damage the transistor and diodes inside.
- 2. When removing or installing the tachometer, be careful not to drop it or subject it to severe shock.

FUEL GAUGE

- 1. Disconnect the fuel sender connector from the fuel sender.
- 2. Connect a 3.4 watt, 12V test bulb to terminals 5 and 6 on the wire harness side connector.
- 3. Turn the ignition switch to the ON, and then check that the bulb lights up and the fuel gauge needle moves to full.



ETQF986A

INDICATORS AND GAUGES

FUEL MAIN SENDER

1. Using an ohmmeter, measure the resistance between terminals 5 and 6 of main sender connector(A) at each float level.



ETQF987A

2. Also check that the resistance changes smoothly when the float is moved from "F" to "E".

Position	Resistance()
Sender (E)	104.8 ± 1
Warning lamp	89.9 ± 1
ران خودر 1/2ر ایران	انه د پدره <u>+ 13.7 میرک</u> ا
Sender (F)	4.2 ± 1

3. If the height resistance is unsatisfied, replace the fuel sender as an assembly.

After completing this test, wipe the sender dry and reinstall it in the fuel tank.

FUEL SUB SENDER

1. Using an ohmmeter, measure the resistance between terminals 1 and 2 of SUB sender connector(A) at each float level.



KTQE988A

2. Also check that the resistance changes smoothly when the float is moved from "F" to "E".

J	Position	Resistance()	
	Sender (E)	95.2 ± 1	
	1/2	90.2 ± 1	
ويين	Sender (F)	3.8 ± 1	

3. If the height resistance is unsatisfied, replace the fuel sender as an assembly.

After completing this test, wipe the sender dry and reinstall it in the fuel tank.

ENGINE COOLANT TEMPERATURE GAUGE

- 1. Disconnect the wiring connector(3 pins) from the engine coolant temperature sender in the engine compartment.
- 2. Turn the ignition switch ON. Check that the gauge needle indicates cool. Turn the ignition switch OFF.
- 3. Connect a 12V, 3.4 watt test bulb between the harness side connector terminal 2 and ground.
- 4. Turn the ignition switch ON.
- 5. Verify that the test bulb flashes and that the indicator moves to HOT.

If operation is not as specified, replace the engine coolant temperature gauge. Then recheck the system.



BODY ELECTRICAL SYSTEM

ENGINE COOLANT TEMPERATURE SENDER

1. Using an ohmmeter, measure the resistance between terminal 2 of sender connector and ground.



ETKE110I

2. If the resistance value is not as shown in the table, replace the temperature sender.

Temperature (°C)	49	71	110	127.4
Gauge angle (°)	-40	-7±2.4	-7 <u>±2.4</u>	35±5
Resistance ()	195	86.5	24	16 .1

KTQE530C

INDICATORS AND GAUGES

OIL PRESSURE SWITCH

- 1. Check that there is continuity between the oil press switch terminal and ground with the engine off.
- 2. Check that there is no continuity between the terminal and ground with the engine running.
- 3. If operation is not as specified, replace the switch.





KTQE530B

BRAKE FLUID LEVEL WARNING SWITCH

- 1. Remove the connector from the switch located at the brake fluid reservoir.
- Verify that continuity exists between switch terminals 1 and 2 while pressing the switch (float) down with a rod.

OIL PRESSURE WARNING LAMP

1. Disconnect the connector from the warning switch and ground the terminal on the wire harness side connector.

TQE530A

2. Turn the ignition switch ON. Check that the warning lamp lights up.If the warning lamp doesn't light, test the bulb or inspect the wire harness.



V5BE060M

BODY ELECTRICAL SYSTEM

BRAKE FLUID LEVEL WARNING LAMP

- 1. Start the engine.
- 2. Release the parking brake.
- 3. Remove the connector from the brake fluid level warning switch.
- 4. Ground the connector at the harness side.
- 5. Verify that the warning lamp lights.

PARKING BRAKE SWITCH

The parking brake switch(A) is a push type located under the parking brake lever. To adjust, move the switch mount up and down with the parking brake lever released all the way.

- 1. Check that there is continuity between the terminal and switch body with the switch ON (Lever is pulled).
- 2. Check that there is no continuity between the terminal and switch bodywith the switch OFF (Lever is released).

If continuity is not as specified, replace the switch or inspect its ground connection.



ETKE060O

021-62999292

BE -97

INDICATORS AND GAUGES

DOOR SWITCH

Remove the door switch and check for continuity between the terminals.



KTQE804A

[FRONT DOOR SWITCH]

Terminal Position	1	2	Body (Ground)
Free(Door open)	0	0	-0
Push(Door close)		• 1 1	
وليت محدود)	inno) a	رو سامان	ETQF021

[REAR DOOR SWITCH]

Terminal Position	2	1 (Ground)
Free(Door open)	0	———————————————————————————————————————
Push(Door close)		

ETQF021B

SEAT BELT SWITCH

- 1. Remove the connector from the switch.
- 2. Check for continuity between terminals.

Seat belt condition	Continuity
Fastened	Non-conductive ()
Not fastened	Conductive (0)



SEAT BELT WARNING LAMP

With the ignition switch turned ON, verify that the lamp glows.

Seat belt condition	Warning lamp
Fastened	OFF
Not fastened	ON

BODY ELECTRICAL SYSTEM

POWER DOOR LOCKS

COMPONENTS EEE9277C



POWER DOOR LOCKS

POWER DOOR LOCK **ACTUATORS**

INSPECTION EAABD58B

FRONT DOOR LOCK ACTUATOR INSPECTION

- Remove the front door trim panel. (see BD group-1. front door)
- Disconnect the 6P connector from the actuator. 2.

REAR DOOR LOCK ACTUATOR INSPECTION

- 1. Remove the rear door trim panel. (see BD group-rear door)
- 2. Disconnect the 6P connector from the actuator.



3. Check actuator operation by connecting power and ground according to the table. To prevent damage to the actuator, apply battery voltage only momentarily.

Position	erminal	2	3
Poor loft	Lock	\oplus	\ominus
Rear left	Unlock	\ominus	\oplus
Deerricht	Lock	\ominus	\oplus
Rear right	Unlock	\oplus	\ominus

ETQF275B

KTKD047A

3. Check actuator operation by connecting power and ground according to the table. To prevent damage to the actuator, apply battery voltage only momentarily.

T Position	erminal	4	6
Eropt loft	Lock	\ominus	\oplus
Front left	Unlock	\oplus	\bigcirc
Encret sight	Lock	\oplus	\bigcirc
Front right	Unlock	\ominus	\oplus

ETKE270B

WWW.DIGITALKHODRO.COM

021-62999292

BE -100

TAILGATE LOCK ACTUATOR INSPECTION

- 1. Remove the tailgate trim panel. (see BD group-tailgate)
- 2. Disconnect the 6P connector from the actuator.



 Check actuator operation by connecting power and ground according to the table. To prevent damage to the actuator, apply battery voltage only momentarily.

Terminal Position	4	6
Lock	\oplus	\bigcirc
Unlock	\ominus	\oplus

ETQF270B

3.

BODY ELECTRICAL SYSTEM

FRONT DOOR LOCK SWITCH INSPECTION

- 1. Remove the front door trim panel. (see BD groupfront door)
- 2. Disconnect the 6P connector from the actuator.

KTKD047A

T Position	erminal	1	2	3
	Lock	\bigcirc		———————————————————————————————————————
Front left	Unlock	\bigcirc	-0	
	Lock	\bigcirc		———————————————————————————————————————
Front right	Unlock		0	

switch position according to the table.

Check for continuity between the terminals in each

ETQF281A

POWER DOOR LOCKS

REAR DOOR LOCK SWITCH INSPECTION

- 1. Remove the rear door trim panel. (see BD group-rear door)
- 2. Disconnect the 6P connector from the actuator.

TAILGATE LOCK SWITCH INSPECTION

- 1. Remove the tailgate trim panel. (see BD group tailgate)
- 2. Disconnect the 6P connector from the actuator.



KTKD048A

3. Check for continuity between the terminals in each switch position according to the table.

Terminal Position		4	5	6
Deerleft	Lock		\bigcirc	-
Rear left	Unlock	0		-
	Lock	0		-
Rear right	Unlock		\bigcirc	\frown

ETQF280B

 Terminal
 1
 2
 3

 Position
 1
 2
 3

 Lock
 O
 O

 Unlock
 O
 O

ETQF281B

BODY ELECTRICAL SYSTEM

POWER DOOR LOCK RELAY

INSPECTION E61B12FE

- 1. Remove the negative(-) battery terminal.
- 2. Remove the driver side crash pad lower panel.
- 3. Remove the door lock and unlock relay(A) from the cross member bracket, then check for continuity between the terminals.





Terminal Power (No.2-No.4)	2	4	1	3	5
Disconnected				0-	$- \bigcirc$
Connected	Θ—		0		-0

ETQF932A

KTQE230H

POWER DOOR LOCKS

POWER DOOR LOCK SWITCH

INSPECTION EB108AF7

DRIVER'S DOOR LOCK SWITCH INSPECTION

- 1. Remove the driver's door trim panel. (see BD group front door)
- 2. Disconnect the 14P connector from the door lock switch assembly.



ASSIST DOOR LOCK SWITCH INSPECTION

- 1. Remove the assist door trim panel. (see BD group front door)
- 2. Disconnect the 10P connector from the door lock switch assembly.



3. Check for continuity between the terminals in each switch position according to the table.

KTQE530J

3. Check for continuity between the terminals in each switch position according to the table.

Terminal Position	4	10	11
Lock		0	———————————————————————————————————————
Unlock	0		

ETQF933A

Terminal Position	3	4	7
Lock		o	0
Unlock	0		O

ETQF934A

BODY ELECTRICAL SYSTEM

POWER DOOR MIRRORS

COMPONENTS E5DE98A0



POWER DOOR MIRRORS

BE -105

POWER DOOR MIRROR SWITCH

CIRCUIT DIAGRAM EFFOB5A9



WWW.DIGITALKHODRO.COM

021- 62 99 92 92

BE -106

INSPECTION ECF1E314

- 1. Remove the driver's door trim panel. (see BD groupfront door)
- 2. Disconnect the 8P connector from the power door mirror switch.



3. Check for continuity between the terminals in each switch position according to the table.

Class	Terminal Direction	1	3	4	5	6	7	8
	UP	0-			0-	-0-	-0	-0
	DOWN	0-			\bigcirc		-0	-
LEFT HAND	OFF	0-			-0-	-	-0	
	LEFT	0-			-0-	0-	-0	-0
	RIGHT	0-			-0-	\bigcirc	-0	ρ
	UP		\circ	\downarrow	\bigcirc		-	-0
	DOWN		\bigcirc	-0-	0-		-0	-0
RIGHT	OFF		\circ	-0-	\bigcirc		-0	
HAND	LEFT		0-	\bigcirc	-0-		-0	-0
	RIGHT		0-	0			-0	-0

ETQF936A

BODY ELECTRICAL SYSTEM

MIRROR FOLDING SWITCH INSPECTION

Terminal Position	2	7
ON(PUSH)	0	0
OFF(FREE)		

ETQF937A



WWW.DIGITALKHODRO.COM

021-62999292

POWER DOOR MIRRORS

DOOR MIRROR FOLDING CONTROL MODULE

CIRCUIT DIAGRAM EAFFCA2D



INSPECTION E335D8B8

1. While operating the folding mirror switch, check if the operations are normal as shown in the timing chart.



KTQE530M

ETKE002A

2. If operations are abnormal, check the control unit (A) inside of driver's door trim panel.

WWW.DIGITALKHODRO.COM

BE -107

POWER DOOR MIRROR ACTUATOR

INSPECTION E196E530

- 1. Disconnect the power door mirror connector from the harness.
- 2. Apply battery voltage to each terminal as shown in the table and verify that the mirror operates properly.

BODY ELECTRICAL SYSTEM

MIRROR HEATER INSPECTION

Terminal Position	7	8
Heater	0	O

ETQF195D

MIRROR FOLDING INSPECTION



ETQF310A

Terminal Position	1	2	3
UP	\oplus	\oplus	\bigcirc
DOWN	Θ	Θ	\oplus
OFF	\oplus	\oplus	\oplus
LEFT	Θ	\oplus	Θ
RIGHT	\oplus	Θ	\oplus

ETQF195B

021-62999292
POWER WINDOWS

POWER WINDOWS

COMPONENTS E716BBC5





BE -109

POWER WINDOW MOTOR

INSPECTION E9761ACB

FRONT POWER WINDOW MOTOR INSPECTION

- 1. Remove the front door trim panel. (see BD group-front door)
- 2. Disconnect the 2P connector from the motor.

Image: state stat

3. Connect the motor terminals directly to battery voltage (12V) and check that the motor operates smoothly. Next, reverse the polarity and check that the motor operates smoothly in the reverse direction. If the operation is abnormal, replace the motor.

Posi	tion	Terminal	1	2
	UP	Clockwise	Θ	\oplus
LH	DOWN	Counter- clockwise	\oplus	\ominus
БП	DOWN	Clockwise	\oplus	\ominus
RH	UP	Counter- clockwise	Θ	\oplus

ETQF057A

BODY ELECTRICAL SYSTEM

[WITH DRIVER'S SIDE SAFETY WINDOW]

Position		Terminal	1	2
Driver's	UP	Clockwise	Θ	\oplus
side	DOWN	Counter- clockwise	\oplus	Θ

ETQF057B

REAR POWER WINDOW MOTOR INSPECTION

- 1. Remove the rear door trim panel. (see BD group-rear door)
- 2. Disconnect the 2P connector from the motor.

Line to the total of total

KTQE280B

3. Connect the motor terminals directly to battery voltage (12V) and check that the motor operates smoothly. Next, reverse the polarity and check that the motor operates smoothly in the reverse direction. If the operation is abnormal, replace the motor.

Posi	Terminal Position		1	2
	UP	Clockwise	\ominus	\oplus
LH	DOWN	Counter- clockwise	\oplus	\ominus
БЦ	DOWN	Clockwise	\oplus	\ominus
RH	UP	Counter- clockwise	Θ	\oplus

ETQF057A

WWW.DIGITALKHODRO.COM

POWER WINDOWS

BE -111

POWER WINDOW SWITCH

CIRCUIT DIAGRAM EDDAA75F



WWW.DIGITALKHODRO.COM

BE -112

BODY ELECTRICAL SYSTEM



WWW.DIGITALKHODRO.COM

021-62999292

BE -113

POWER WINDOWS

INSPECTION EDEC355E

POWER WINDOW MAIN SWITCH

1. Remove the power window main switch from the driver's door trim panel.

•

.....



KTQE530J

2. Check for continuity between the terminals.

Terminal		Fron	t left			Front	right			Rea	r left			Rear	right	
Position	14	5	6	10	001	7	2	10	12	14	13	10	8	7	9	10
سئوليى ٩ ٣محدود)	0-	-0	0-	-09	0-	-0	0-	-05	0	-0	0	-0	\circ	-0	0	-0
OFF		0—	_0_	_0	0—		-0-	-0	0—		_0_	-0	0		-0-	_0
خودر bown بران	-0	0-	0	9	0-	0-	-0	0	0	0	0	-0		0-	-0	P

ETQF945A

WWW.DIGITALKHODRO.COM

ASSIST POWER WINDOW SWITCH

1. Remove the assist power window switch from the assist door trim panel.



2. Check for continuity between the terminals. If continuity is not as specified in the table, replace the power window switch.

Terminal Position	1	2	4	6	7
	\bigcirc				
UP	Ŭ			<u> </u>	—0
OFF	0				
	0				
DOWN	0—	_0	0	-0	

ETQF946A

[WITH DOOR LOCK SWITCH]

[WITHOUT DOOR LOCK SWITCH]

Terminal Position	5	6	8	9	10
UP	0—		0	_0	_0
OFF	0—	_0	0		$\left \right\rangle$
DOWN	0	-0		0	-0

ETQF947A

BODY ELECTRICAL SYSTEM

REAR POWER WINDOW SWITCH

1. Remove the rear power window switch from the rear door trim panel.



2. Check for continuity between the terminals. If continuity is not as specified in the table, replace the power window switch.



ETQF946A

POWER WINDOWS

POWER WINDOW RELAY

INSPECTION E59CF36B

- 1. Remove the power window relay(A) from the passenger compartment junction block(B).
- 2. There should be continuity between the No.1 and No.4 terminals when power and ground are connected to the No.3 and No.2 terminals.
- 3. There should be no continuity between the No.1 and No.4 terminals when power is disconnected.

(C

2 3

4

в

3

ETKE061A Terminal 3 Power 2 1 4 (No.2-No.3) \bigcirc -0 Disconnected Connected \bigcirc -(+) \bigcirc (

Ċ

Ю

ETKE215B



WINDSHIELD GLASS DEICER

COMPONENTS EAF1DA72

Windshield glass deicer system prevent windshield wiper from freezing in the winter season. It consist of deicer in the lower part of windshield glass, switch and relay.

BODY ELECTRICAL SYSTEM

ETACS module receives an input signal from the deicer switch, then controls relay.

Operating condition is the same that of rear window defogger system.

Since the generator "L" is switched ON, if the deicer switch is ON, then deicer output is ON for 20 minutes.



WWW.DIGITALKHODRO.COM

WWW.DIGITALKHODRO.COM

WINDSHIELD GLASS DEICER

BE -117

WINDSHIELD GLASS DEICER

INSPECTION EC38E8ED

- Disconnect the windshield glass deicer connetor(A) 1. from the wiper motor linkage.
- 3. Turn the ignition switch ON and the windshield deicer switch ON, then measure the voltage between the terminals of harness side deicer connector.



KTQE948A

BODY ELECTRICAL SYSTEM

WINDSHIELD GLASS DEICER SWITCH

INSPECTION EB9FEDFE

- 1. Disconnect the negative(-) battery terminal.
- 2. Remove the center facia panel then disconnect the 6P connector from the windshield glass deicer switch.



3. Check for continuity between terminals while operating the deicer switch.

Terminal Position	3	6	4	1	5	2
ON	0—	-0			9	9
OFF						ILL.
						ETQF949/

WINDSHIELD GLASS DEICER

WINDSHIELD GLASS DEICER TIMER

INSPECTION EEAFBB92



While operating the components, check whether the operations are normal as shown in the timing chart.

- 1. After ALT "L" ON, if the deicer is switched ON, the deicer output is ON for 20 minutes duration.
- 2. If the deicer switch is pressed again, or if the ignition is switched OFF during this time, deicer output is OFF.



ETQF017A

T1 : 20 ± 1min.

BE -119

WWW.DIGITALKHODRO.COM

BODY ELECTRICAL SYSTEM

WINDSHIELD GLASS DEICER RELAY

INSPECTION EFDF2AFA

- 1. Remove the windshield deicer relay(A) from the passenger compartment relay box.
- 2. Check for continuity between the terminals.
- 3. There should be continuity between the No.1 and No.2 terminals when power and ground are connected to the No.4 and No.3 terminals.
- 4. There should be no continuity between the No.1 and No.2 terminals when power is disconnected.





ETQF034B

Terminal Power (No.3-No.4)	1	2	3	4
Disconnected			0	-
Connected	\bigcirc	-0	Θ	+

ETKE903A

REAR WINDOW DEFOGGER

COMPONENTS E644AE06



BE -121

021-62999292

BE -122

REAR WINDOW DEFOGGER PRINTED HEATER

INSPECTION E0E74505

A CAUTION

Wrap tin foil around the end of the voltmeter test lead to prevent damaging the heater line. Apply finger pressure on the tin foil, moving the tin foil along the grid line to check for open circuits.



Turn on the defogger switch and use a voltmeter to 1. measure the voltage of each heater line at the glass center point. If a voltage of approximately 6V is indicated by the voltmeter, the heater line of the rear window is considered satisfactory.

BODY ELECTRICAL SYSTEM

2. If a heater line is burned out between the center point and (+) terminal, the voltmeter will indicate 12V.



ETA9165C

3. If a heater line is burned out between the center point and (-) terminal, the voltmeter will indicate 0V.



ETA9165D



ETA9165B

REAR WINDOW DEFOGGER

4. To check for open circuits, slowly move the test lead in the direction that the open circuit seems to exist. Try to find a point where a voltage is generated or changes to 0V. The point where the voltage has changed is the open-circuit point.

Voltage changes before and after open circuited point

When measured from negative

terminal side (Section

Positive teminal Tester B

reads resistance

with no broken grid line)



ETA9165E

5. Use an ohmmeter to measure the resistance of each heater line between a terminal and the center of a grid line, and between the same terminal and the center of one adjacent heater line. The section with a broken heater line will have a resistance twice as that in other sections. In the affected section, move the test lead to a position where the resistance sharply changes.

(Section with broken grid

line) Center point

¥×

twice as large as tester terminal

Ω)

 (Ω)

REPAIR OF BROKEN HEATER LINE

Prepare the following items :

- 1. Conductive paint.
- 2. Paint thinner.
- 3. Masking tape.
- 4. Silicone remover.
- 5. Using a thin brush :

Masking tape

Wipe the glass adjacent to the broken heater line, clean with silicone remover and attach the masking tape as shown. Shake the conductive paint container well, and apply three coats with a brush at intervals of about 15 minutes apart. Remove the tape and allow sufficient time for drying before applying power. For a better finish, scrape away excess deposits with a knife after the paint has completely dried. (Allow 24 hours).

ETA9165G

ETA9165F

BODY ELECTRICAL SYSTEM

REAR WINDOW DEFOGGER SWITCH

INSPECTION ED889BA0

- 1. Remove the negative(-) battery terminal.
- 2. Remove the center facia panel then disconnect the 6P connector from the rear window defogger switch.



3. Check for continuity between terminals while operating the defogger switch.

Position	3	4	1	5	2
ON	0			\mathbf{Q}	Ŷ
OFF					ILL.

ETQF951A

REAR WINDOW DEFOGGER RELAY

INSPECTION E17D60BA

- 1. Remove the rear window defogger relay(A) from the passenger compartment junction block(B).
- 2. There should be continuity between the No.1 and No.4 terminals when power and ground are connected to the No.3 and No.2 terminals.
- 3. There should be no continuity between the No.1 and No.4 terminals when power is disconnected.





Terminal				
Power (No.2-No.3)	2	3	1	4
	\bigcirc			
Disconnected	\bigcirc			
Connected	Θ		0	-0
· · · · · · · · · · · · · · · · · · ·				

ETKE215B

ETKE042B

BE -125

BODY ELECTRICAL SYSTEM

WINDSHIELD WIPER / WASHER

COMPONENTS ECBB882C



WWW.DIGITALKHODRO.COM

WINDSHIELD WIPER / WASHER SWITCH

INSPECTION E8DDA5BB

Check for continuity between the terminals while operating the wiper and washer switch.





ولین سامان⁸ تعمیرکاران خود ود. ایران WIPER SWITCH

Terminal Position	1	2	3	4	5	6	13	14
MIST				0-	-0			
OFF		0-	\bigcirc					
INT		0-	-		\circ	P	^	% -⊖
LOW		0-			ρ			
н	\bigcirc				-0			

ETDD075C

WASHER SWITCH

Terminal Position	5	7
OFF		
ON	0	O

ETDD075D

BE -127

BODY ELECTRICAL SYSTEM

FRONT WIPER MOTOR

COMPONENTS E46D633E



WWW.DIGITALKHODRO.COM

WWW.DIGITALKHODRO.COM

021-62999292

WINDSHIELD WIPER / WASHER

REMOVAL E0D3CA48

- 1. Detach the wiper cap, then remove the windshield wiper arm and blade after removing a nut(A).
- Remove the windshield wiper motor and linkage assembly after removing 2 bolts.
 Disconnect the wiper motor connector(A) and windshield deicer connector(B) from the wiper motor & linkage assembly.





ETKE250B

WWW.DIGITALKHODRO.COM

INSTALLATION E73E2EDC

1. Install the wiper arm and blade to the specified position.

Specified position	А	В
Distance (mm)	31~41	31~41

352

168

312

341

157

396

279

BODY ELECTRICAL SYSTEM

INSPECTION EAGA5DDC

SPEED OPERATION CHECK

- 1. Remove the connector from the wiper motor.
- Attach the positive (+) lead from the battery to terminal
 4 and the negative (-) lead to terminal 1.
- 3. Check that the motor operates at low speed.
- 4. Connect the positive (+) lead from the battery to terminal 5 and the negative (-) lead to terminal 1.
- 5. Check that the motor operates at high speed.



ETQF310B

ETQF400D

WINDSHIELD WIPER / WASHER

AUTOMATIC STOP OPERATION CHECK

2 3

Æ

1

- 1. Operate the motor at low speed using the stalk control.
- 2. Stop the motor operation anywhere except at the off position by disconnecting terminal 4.
- 3. Connect terminals 2 and 4.
- 4. Connect the positive (+) lead from the battery to terminal 3 and the negative (-) lead to terminal 1.
- 5. Check that the motor stops running at the off position.

4 5

KTQE953A





BODY ELECTRICAL SYSTEM

FRONT WASHER MOTOR

REMOVAL EDEA0B68

- 1. Disconnect the negative(-) battery terminal.
- 2. Remove the front bumper cover. (see BD group-front bumper)
- Remove the washer hose and the washer motor con-3. nector.
- 4.

INSPECTION EB6870E8

- 1. With the washer motor connected to the reservoir tank, fill the reservoir tank with water.
- 2. Connect positive (+) and negative (-) battery cables to terminals 2 and 1 respectively to see that the washer motor runs and water sprays from the front nozzles.
- 3. Check that the motor operates normally.



KTOF220D

Installation is the reverse of removal. 5.



[Windshield & rear washer motor]

ETOE390B

WWW.DIGITALKHODRO.COM

WINDSHIELD WIPER / WASHER



[Windshield washer motor]

ETQF390C





WWW.DIGITALKHODRO.COM

BODY ELECTRICAL SYSTEM

REAR WIPER / WASHER

COMPONENTS E5A59E71



WWW.DIGITALKHODRO.COM

REAR WIPER / WASHER

REAR WIPER MOTOR

REMOVAL EFC9B580

- 1. Detach the wiper cap(A), then remove the rear wiper arm after removing a nut(B).
- 3. Open the tailgate glass then remove the rear wiper motor cover(A).
- 4. Disconnect the rear wiper motor connector then remove the rear wiper motor(B) after removing 3 nuts.





KTQE220B

Tightening torque Nut(A) : 10~13 Nm (100~130 kgf·cm, 7.2~9.4 lbf·ft)

INSTALLATION EC59EBF5

1. Install the rear wiper arm and blade to the specified position.

Specified position	Α
Distance	19 ± 5 mm

Specified position : The first deicer line from bottom of the rear window.

BODY ELECTRICAL SYSTEM

INSPECTION E04EC0FD

- 1. Remove the 4P connector from the rear wiper motor.
- 2. Connect battery positive (+) and negative (-) cables to terminals 3 and 4 respectively.
- 3. Check that the motor operates normally. Replace the motor if it operates abnormally.



unit:mm



ETQF400E

REAR WIPER / WASHER

REAR WASHER SWITCH

INSPECTION EE2037A2

With the rear wiper & washer switch in each position, make sure that continuity exists between the terminals below. If continuity is not as specified, replace the multifunction switch.





REAR WIPER & WASHER SWITCH

Terminal Position	9	10	11	12
Rear washer	0			—O
OFF				
INT	\bigcirc	_0		
ON	0		-0	
Rear washer	0			O

ETQF073A

KTDD075I

ETQF390B

BODY ELECTRICAL SYSTEM

BE -138

REAR WASHER MOTOR

INSPECTION E154DDA1

6

- 1. With the washer motor connected to the reservoir tank, fill the reservoir tank with water.
- Connect positive(+) and negative(-) battery cables to terminals 3 and 1 respectively to see that the washer motor runs and water is pumped.
- 3. Check that the motor operates normally. Replace the motor if it operates abnormally.







ETQF220E

AUTOMATIC DIMMING FUNCTION

be controlled by the dimming ON/OFF button (A):

green Status Indicator LED (C) turning off.

To protect your vision during nighttime driving, your mirror will automatically dim upon detecting glare from the vehicles traveling behind you. The auto-dimming function can

Pressing and holding the feature control button (A)

for more than 3 but less than 6 seconds turns the

auto-dimming function OFF which is indicated by the

Pressing and holding the feature control button (A)

again for more than 3 but less than 6 seconds turns

the auto-dimming function ON which is indicated by

ELECTROCHROMIC INSIDE REAR VIEW MIRROR

BE -139

EB7936AE

ELECTROCHROMIC INSIDE REAR VIEW MIRROR

DESCRIPTION E6DC1B1D

The ECM (ElectroChromic inside rear view Mirror) is for dimming the reflecting light from a vehicle behind at night, in order the user not to be dazzled by the light. The front looking sensor detects brightness of the surroundings, while the rearward looking sensor the strength of the reflecting light so that adjusts the reflexibility of the mirror in the range of 7~85%. But, when the reverse gear is engaged, it stops functioning.

the green Status Indicator LED (C) turning on. **NOTE** The mirror defaults to the "ON" position each time 1. the vehicle is started. 2. The display may change state (ON/OFF) during this 3 second hold time. 1 2 3 4 1. Ground 6. IGN (12V) 5 6 10. Reverse gear signal pog 7 8 9 10

1.

2.

ETQE280J

- 1. The front looking sensor sees if the brightness of the surroundings is low enough for the mirror to operate its function.
- 2. The rearward looking sensor detects glaring of the reflecting light from a vehicle behind.
- 3. The ECM is darkened to the level as determined by the rearward looking sensor. When the glaring is no longer detected, the mirror stops functioning.



ETQF241B

ETQF241A

WWW.DIGITALKHODRO.COM

WWW.DIGITALKHODRO.COM

021-62999292

BE -140

INSPECTION EFE91A06

Check it by the procedure below to see if the function of the ECM is normal.

- 1. Turn the ignition key to the "ON" position.
- 2. Cover the front looking sensor (D) to stop functioning.
- 3. Shed a light to the rearward looking sensor (B).
- 4. The ECM should be darkened as soon as the rearward looking sensor detects the glaring of the light.

🔟 ΝΟΤΕ

If this test is performed in daytime, the ECM may be darkened as soon as the front looking sensor is covered.

- 5. When the reverse gear is engaged, the ECM should not be darkened.
- 6. When shedding lights to both the front looking and rearward looking sensors, the ECM should not be darkened.

COMPASS MIRROR

FUNCTION E1FB67CC

The compass can be turned ON and OFF and will remember the last state when the ignition is cycled. To turn the display feature ON/OFF:

- 1. Press and release the feature control button (A) to turn the display feature OFF.
- Press and release the feature control button (A) again to turn the display back ON. Additional options can be set with press and hold se-

quences of the feature control button (A) and are detailed below. There is a difference between magnetic north and true north. The compass in the mirror can compensate for this difference when it knows the magnetic zone in which it is operating. This is set either by the dealer or by the user.

BODY ELECTRICAL SYSTEM

ADJUSTMENT E38E9CB3

TO ADJUST THE ZONE SETTING:

- 1. Determine the desired zone number based upon your current location on the zone maps.
- 2. Press and hold the feature control button (A) for more than 6 but less than 9 seconds, the current zone number will appear on the display (B).
- 3. Pressing and holding the feature control button (A) again will cause the numbers to increment (Note: they will repeat ...13, 14, 15, 1, 2,..). Releasing the button when the desired Zone Number appears on the display will set the new zone.
- 4. Within about 5 seconds the compass will start displaying a compass heading again.

TO RE-CALIBRATE THE COMPASS:

There are some conditions that can cause changes to the vehicle magnets. Items such as installing a ski rack or a antenna or even some body repair work on the vehicle can cause changes to the vehicle's magnetic field. In these situations, the compass will need to be re-calibrated to quickly correct for these changes.

- Press and hold the feature control button (A) for more than 9 seconds. When the compass memory is cleared a "C" will appear in the display (B).
- 2. To calibrate the compass, drive the vehicle is 2 complete circles at less than 8 KPH (5 MPH).



ETQF241C

WWW.DIGITALKHODRO.COM

ELECTROCHROMIC INSIDE REAR VIEW MIRROR

ZONE MAP



WWW.DIGITALKHODRO.COM

BODY ELECTRICAL SYSTEM

SEAT WARMER

COMPONENTS E3ABC815



SEAT WARMER

SEAT WARMER SWITCH

INSPECTION E81CF52A

1. Disconnect the negative (-) battery terminal.

ILL.

OFF

2. Remove the seat warmer switch from the floor console upper cover.

SEAT WARMER INSPECTION

1. Check for continuity and measure the resistance between the terminals.

Standard value : 2.6 ± 10%



ETQF990A

Standard value				
28 ± 3.5°C (Continuity)				
37 ± 3.0°C (Short)				

BODY ELECTRICAL SYSTEM

BE -144

SUNROOF

COMPONENTS EC10DB2A



WWW.DIGITALKHODRO.COM
021-62999292

BE -145

SUNROOF

CIRCUIT DIAGRAM E7DEE1BC



SUN ROOF SWITCH

INSPECTION ED1FFECD

- 1. Disconnect the negative (-) battery terminal.
- 2. Detach the lens from the overhead console then remove the 2 screws holding the overhead console.



 Disconnect the sunroof switch connector(6P) and map lamp connector(2P)then remove the overhead console lamp assembly from the headliner. Check for continuity between the terminals of sunroof switch connector. If the continuity is not as specified, replace the sunroof switch.



ETQF963A

BODY ELECTRICAL SYSTEM

Terminal Position	2	4	5	6
SLIDE OPEN	0			0
CLOSE/DOWN	0	_0		
TILT UP	0		_0	

ETQF964A



SUNROOF

BE -147

SUN ROOF RELAY

INSPECTION EABF3D4A

 Disconnect the 10P connector (A) and 6P connector (B) from the sunroof controller(C).



ETKE450A

2. Inspect the connectors on the wire harness side, as shown in the chart.

خود Connector	Tester connection	اوامنانه ديجيتال	Specified condition
	1-Ground	Constant	Continuity
	7-Ground	Sunroof switch position (slide) CLOSE	Continuity
	6-Ground	Sunroof switch position (slide) OPEN	Continuity
	4-Ground	Ignition switch position ON	Battery voltage
M94-1	5-Ground	Sunroof switch position (Tilt) UP	Continuity
10194-1	8-Ground	Sunroof switch position (Tilt) DOWN	Continuity
	2-10	No.1 limit switch OFF	No continuity
	2-10 No.1 limit switch ON		Continuity
	3-9	No.2 limit switch OFF	No continuity
	3-9	No.2 limit switch ON	Continuity
	5-Ground	Constant	Continuity
M04 0	6(+) - 4(-)	Battery connection between terminal 6(+) and 4(-)	Motor turns clockwise
M94-2	4(+) - 6(-)	Battery connection between terminal 4(+) and 6(-)	Motor turns counter- clockwise
	3-Ground	Constant	Battery voltage

SUN ROOF MOTOR

INSPECTION EBFF3CD8

1. Remove the sunroof motor after removing 3 screws and disconnect the 10P connector from the sunroof motor.



BODY ELECTRICAL SYSTEM

2. Inspect the sunroof motor side connector while the battery voltage and ground are connected as below table.

Terminal Position	3	4	5	10
TILT UP	\oplus			Û
SLIDE CLOSE/DOWN	\oplus	\bigcirc		
SLIDE OPEN	\oplus		\ominus	

ETQF965A

3. Inspect the sunroof motor harness side, as shown in the chart.

UTester connection	Condition	Specified condition
3-Ground	IGN2 switch ON	Battery voltage
1-Ground	Constant	Continuity
6-Ground	Constant	Battery voltage

LIGHTING SYSTEM

BE -149

LIGHTING SYSTEM

COMPONENTS E073BA5C



WWW.DIGITALKHODRO.COM

HEAD LAMPS

REMOVAL E496D86C

- 1. Disconnect the negative(-) battery terminal.
- 2. Remove the head lamp mounting bolts (2EA), then disconnect the lamp connectors.



3. Replace the head lamp bulb(A), position bulb(B) and turn signal bulbs(C).

BODY ELECTRICAL SYSTEM

AIMING INSTRUCTIONS E917ADE8

HEAD LAMP AIMING

The head lamps should be aimed with the proper beamsetting equipment, and in accordance with the equipment manufacturer's instructions.

If there are any regulations pertinent to the aiming of head lamps in the area where the vehicle is to be used, adjust so as to meet those requirements.

Alternately turn the adjusting gear to adjust the head lamp aiming. If beam-setting equipment is not available, proceed as follows :

- 1. Inflate the tires to the specified pressure and remove any loads from the vehicle except the driver, spare tire, and tools.
- 2. The vehicle should be placed on a flat floor.
- 3. Draw vertical lines (Vertical lines passing through respective head lamp centers) and a horizontal line (Horizontal line passing through center of head lamps) on the screen.

4. With the head lamp and battery in normal condition, aim the head lamps so the brightest portion falls on the horizontal and vertical lines.

Make vertical and horizontal adjustments to the lower beam using the adjusting wheel.





ETQF210D

ETQF210P

4. Installation is the reverse of removal.

LIGHTING SYSTEM

FRONT FOG LAMP AIMING

The front fog lamps should be aimed as the same manner of the head lamps aiming.

With the front fog lamps and battery normal condition, aim the front fog lamps by turning the adjusting gear.



HEAD LAMP AND FOG LAMP AIMING POINT

					Unit : mm
Vehicle condition	H1	H2	W1	W2	L
Without driver	904	694	1,356	1,176	3 000
With driver	891	681	1,550	1,170	3,000

ETQF082A

BE -151

KTQE210C

021-62999292

BE -152

BODY ELECTRICAL SYSTEM

 Turn the low beam on without driver aboard. The cut-off line should be projected in the allowable range (shaded region).



021-62999292

LIGHTING SYSTEM

INSPECTION E50CE3EF

HEAD LAMP RELAY

Pull out the head lamp relay(Low) (A) and head lamp 1. relay (High) (B) from the engine compartment relay box.



Terminal				
Power (No.3-No.4)	1	2	3	4
(110.3-110.4)				
Disconnected			0	-O
Connected	\bigcirc	-0	Θ	(+)

ETKE215E

BE -153





3

ETKE224C

TURN SIGNAL LAMP

REMOVAL EFDAFA81

- 1. Disconnect the negative (-) battery terminal.
- 2. Remove the 3 screws holding the rear combination lamp then disconnect the wire connector.



 Remove the rear combination lamp and replace the bulbs; stop & tail lamp (A), turn signal lamp (B), back up lamp (C), rear fog lamp(D).





ETQF210M

4. Installation is the reverse of removal.

WWW.DIGITALKHODRO.COM

BODY ELECTRICAL SYSTEM

LIGHTING SYSTEM

ROOM LAMP

REMOVAL E2EC28F0

- Disconnect the negative(-) battery terminal. 1.
- 2. screwdriver, then replace the bulb.
- 3. screws and disconnecting the 3P connector.

INSPECTION E79D7695

Remove the room lamp assembly then check for continuity between terminals.



BODY ELECTRICAL SYSTEM

BE -156

OVERHEAD CONSOLE LAMP

REMOVAL EC824C0D

- 1. Disconnect the negative (-) battery terminal.
- 2. Detach the lamp lens from the overhead console lamp with a flat-tip screwdriver, then replace the bulb.
- 3. Remove the overhead console lamp assembly after removing 2 screws and disconnecting the connector.



Remove the overhead console lamp assembly then check for continuity between terminals.



KTQE972A

	Sort	Map lamp switch			
	Position	O LH		R	Н
	Terminal	ON	OFF	ON	OFF
مانا	اولين سا		6		
	2	0		\bigcirc	
					ETQF007

WWW.DIGITALKHODRO.COM

LIGHTING SYSTEM

TURN / HAZARD LAMPS

INSPECTION EC9A6EAA

HAZARD LAMP SWITCH

- 1. Disconnect the negative (-) battery terminal.
- 2. Remove the hazard lamp switch from the center facia panel and disconnect the 10P connector.



3. Operate the switch and check for continuity between terminals with an ohmmeter.

Terminal Position	2	3	6	9	10	5	7	8
OFF	Q	Q				0-		-0
ON		روم ILL.	0-	-0-	-0		0-	-

ETQF086A

HAZARD LAMP RELAY

- 1. Remove the hazard lamp relay (A) from the passenger compartment relay box.
- 2. Check for continuity between terminals.



Power (No.2-No.4)	2	4	1	3	5
Disconnected		U		0-	-0
Connected	<u> </u>		\bigcirc		———————————————————————————————————————

ETQF762C

WWW.DIGITALKHODRO.COM

021-62999292

BE -158

FLASHER UNIT

INSPECTION EFAAADBD

1. Remove the flasher unit(A) from the passenger compartment relay box.

BODY ELECTRICAL SYSTEM

3. Connect the two turn signal lamps in parallel to terminal 1. Check that the bulbs turn on and off.

NOTE

The turn signal lamps should flash 60 to 120 times per minute. If one of the front or rear turn signal lamps has an open circuit, the number of flashes will be more than 120 per minute. If operation is not as specified, replace the flasher unit.

Connect the positive (+) lead from the battery to terminal 2 and the negative (-) lead to terminal 3.

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران







KTDA212A

LIGHTING SYSTEM

FRONT FOG LAMPS

REMOVAL E5F783B6

- 1. Disconnect the negative(-) battery terminal.
- 2. Disconnect the 2P connector (A) then remove the front fog lamp from the front bumper.

INSPECTION E8449A3F

FRONT FOG LAMP RELAY

- 1. Remove the front fog lamp relay (A) from the engine compartment relay box.
- 2. There should be continuity between the No.1 and No.2 terminals when power and ground are connected to the No.4 and No.3 terminals.
- 3. There should be no continuity between the No.1 and No.2 terminals when power is disconnected.



KTQE801B

Terminal Power (No.3-No.4)	1	2	3	4
Disconnected			0	———————————————————————————————————————
Connected	0	-0	Θ	

ETKE215E

021-62999292

BODY ELECTRICAL SYSTEM

BE -160

FRONT FOG LAMP SWITCH

- 1. Disconnect the negative(-) battery terminal.
- 2. Remove the front fog lamp switch from the center facia panel and disconnect the 6P connector.



3. Operate the switch and check for continuity between terminals with an ohmmeter.

Terminal Position	3	4	1	5	2
ON	0—		IND.	9	0
OFF					ILL.

ETQF962A



WWW.DIGITALKHODRO.COM

LIGHTING SYSTEM

TAIL, PARKING AND LICENSE LAMPS

REMOVAL EBE8283F

- 1. Disconnect the negative (-) battery terminal.
- 2. Remove the license plate lamp after removing 2 screws.
- 3. Replace the bulb.
- 4. Installation is the reverse of removal.



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



BE -161

021-62999292

BE -162

STOP LAMPS

REMOVAL EE888DC3

HIGH MOUNTED STOP LAMP

- 1. Disconnect the negative (-) battery terminal.
- 2. Open the tailgate glass then pull up the cover(A).
- 3. Remove the high mounted stop lamp assembly after removing 2 nuts, then disconnect the wire connector(B).





KTQE210J

4. Installation is the reverse of removal.

BODY ELECTRICAL SYSTEM

LIGHTING SYSTEM

COURTESY AND TRUNK LAMPS

REMOVAL E47D53DC

- 1. Disconnect the negative (-) battery terminal.
- Remove the trunk room lamp lens with a flat-tip screw-2. driver and replace the bult.

INSPECTION EAD9C0D0

Remove the trunk room lamp assembly then check for continuity between terminals.

C Remove the trunk room lamp assembly after remov-3. ing 2 screws, then disconnect the 3P connector. 1 2 3 KTKD087A Terminal 2 3 1 Position 0 ON \bigcirc KTKD008A \bigcirc 6 \bigcirc DOOR Installation is the reverse of removal. 4. OFF

BODY ELECTRICAL SYSTEM

AUTO LIGHTING CONTROL SYSTEM

DESCRIPTION E5837ED9

The auto light control system operates by using the auto light switch. If you set the multi-function to "AUTO" position, the tail lamp and head lamp will be turned automatically on or off according to external illumination.

SPECIFICATIONS

Items	Specifications
Rated voltage	12V
Load	Max. 200mA (Relay load)
Detection illuminations Tail lamp Head lamp	ON : 24 ± 5.2 (Lux), 0.81 ± 0.05V OFF : 48 ± 10.5 (Lux), 1.41 ± 0.05V ON : 6 ± 1.4 (Lux), 0.36 ± 0.05V OFF : 12 ± 2.7 (Lux), 0.51 ± 0.05V

COMPONENTS E0F32574



AUTO LIGHTING CONTROL SYSTEM

CIRCUIT DIAGRAM EDFA9B7C



ETQF200L

BE -165

AUTO LIGHT CONTORL MODULE

INSPECTION EF3E0AFE

1. Remove the photo & auto light sensor (A) from the center crash pad upper.





Continuity

Constant

BODY ELECTRICAL SYSTEM

1-Ground

llej

AUTO LIGHT SWITCH

INSPECTION EC6ACF8E

Operate the auto light switch, then check for continuity between terminals of 18P multi-function switch connector.



ETQF092A

021-62999292

BE -167

BODY ELECTRICAL SYSTEM

DAYTIME RUNNING LIGHTS

CIRCUIT DIAGRAM EFEB9DFA



021-62999292

BE -169

DAYTIME RUNNING LIGHTS

INSPECTION EC69D3A1

OPERATION CHECK

Check that the lights operate according to the following timing chart.

IGN SWITCH	ON OFF
ALTERNATOR "L"	ON OFF
D.R.L	ON OFF
TAIL LAMP SWITCH	ON OFF
RHEOSTAT	ON OFF

ETMB711B

INSPECT CIRCUITS FOR DAYTIME RUNNING LIGHT SYSTEM

- 1. Disconnect the wire connector to DRL module(A) from the right side strut housing.
- 2. Inspect the connector on wire harness side as shown.



[DRL module harness side connector]

ETQF260A

Tester connection	Condition	Specified condition
1-Ground	Constant	Continuity
میرکاران 5-Ground	Head lamp switch OFF	No continuity
قمیرکاران Ground در ایران	Head lamp switch ON	Continuity
6-Ground	Constant	Continuity
7-Ground	Constant	Battery voltage
	Ignition switch ON or START	Battery voltage
9-Ground	Ignition switch ACC or LOCK	No voltage
11-Ground	Constant	Battery voltage
	Engine Stop	No voltage
3-Ground	Engine Running	Battery voltage

If circuit is not as specified, refer to schematic diagram and inspect short or circuits.

BODY ELECTRICAL SYSTEM

HEAD LAMP LEVELLING DEVICE

COMPONENTS E7A6EA0D



WWW.DIGITALKHODRO.COM

HEAD LAMP LEVELING SWITCH

CIRCUIT DIAGRAM ESEEE81E



021-62999292

BE -172

INSPECTION E08735BB

1. Disconnect the 5P switch connector from the floor side crash pad switch plate.

- **BODY ELECTRICAL SYSTEM**
- 2. Connect the battery voltage between terminals 4 and 5(Reference voltage=V_B)
- 3. Measure the voltage between terminals 3 and 4(V).
- 4. Check the percent ratio(V/V_Bx 100%) between voltages V_B and V at each position.



Position No.	Rotation	Ratio(±5%)	Voltage (V)
0	0°	88.7%	11.97 ± 0.5V
1	20°	78.5%	10.60 ± 0.5V
2	40°	71.7%	9.68 ± 0.5V
3	60°	67.87%	9.16 ± 0.5V

5. If the voltage is not as specified, replace the head lamp levelling switch.

IMMOBILIZER CONTROL SYSTEM

IMMOBILIZER CONTROL SYSTEM

DESCRIPTION E24EB329

The immobilizer system will disable the vehicle unless the proper ignition key is used, in addition to the currently available anti-theft systems such as car alarms, the immobilizer system aims to drastically reduce the rate of auto theft. There are two types of immobilizer. One is a "SMARTRA (SMART TRansponder Antenna)" type and another is a "shinchang" type.

- 1. SMARTRA type immobilizer
 - The "SMARTRA" type immobilizer system is applied to the D2.0 engine and 2.0 engine.
 - The SMARTRA system consists of a transponder located in the ignition key, a coil antenna, a SMARTRA unit, an indicator light and the ECM.
 - The SMARTRA communicates to the ECM (Engine Control Module) via a dedicated communications line. Since the vehicle engine management system is able to control engine mobilization, it is the most suitable unit to control the SMARTRA.



ETQE716A

- When the key is inserted in the ignition and turned to the ON position, the coil antenna sends power to the transponder in the ignition key. The transponder then sends a coded signal back through the SMARTRA unit to the ECM.
- If the proper key has been used, the ECM will energize the fuel supply system. The immobilizer indicator light in the cluster will simultaneously come on for more than five seconds, indicating that the SMARTRA unit has recognized the code sent by the transponder.

- If the wrong key has been used and the code was not received or recognized by the ECM the indicator light will continue blinking for about five seconds until the ignition switch is turned OFF.
- If it is necessary to rewrite the ECM to learn a new key, the dealer needs the customer's vehicle, all its keys and the Hi-scan (pro) equipped with an immobilizer program card. Any key that is not learned during rewriting will no longer start the engine.
- The immobilizer system can store up to four key codes.
- If the customer has lost his key, and cannot start the engine, contact HMC motor service station.
- 2. Shinchang type immobilizer
 - The "Shinchang " type immobilizer system is applied to the 2.7 engine.
 - The shinchang system consists of a transponder located in the ignition key, a coil antenna, an ICM (Immobilizer control module), an indicator light and the ECM.
 - When the key is inserted in the ignition and turned to the ON position, the coil antenna sends power to the transponder in the ignition key. The transponder then sends a coded signal back through the coil antenna to the ICM.
 - If the ID code transmitted from the key does not match the pre-registered code in the ICM, injection is not performed by the engine ECM. Hence, each vehicle has a set of keys containing a unique ID code which are registered on the ICM. This signal is captured by the coil antenna located in the front section of the steering handle lock and transmitted to the ICM. The ICM analyses and verifies the signal to determine if the signal matches the pre-registered code.If the signal is verified, the ICM transmits a message to the engine ECM to allow injection. The immobilizer indicator light in the cluster will simultaneously come on for more than five seconds, indicating that the ICM has recognized the code sent by the transponder. If the signal is not verified by the ICM, fuel injection is not performed by the engine ECM. The indicator light will continue blinking for five seconds until the ignition switch is turned OFF.Communication between ICM and ECM communicates through the K-line of ECM. K-line is also used for the communication between ECM and scan tool. there is a regal inside of ICM to switch the communication.
 - If it is necessary to rewrite the ICM to learn a new key, the dealer needs the customer's vehicle, all its keys and the Hi-scan (pro) equipped with an immobilizer program card. Any key that is not learned during rewriting will no longer start the engine.

WWW.DIGITALKHODRO.COM

021-62999292

BE -173

BODY ELECTRICAL SYSTEM

- The immobilizer system can store up to four key codes.
- If the customer has lost his key, and cannot start the engine, contact HMC motor service station.

OPERATION EF2110C5

ECM (ENGINE CONTROL MODULE)

1. SMARTRA type immobilizer

The ECM carries out a check of the ignition key using a special encryption algorithm, which is programmed into the transponder as well as the ECM simultaneously. Only if the results are equal, the engine can be started. The data of all transponders, which are valid for the vehicle, are stored in the ECM.

2. Shinchang type immobilizer

In the Ignition ON position, the engine ECM receives information from the ICM and permits injection to take place.

SMARTRA UNIT

The SMARTRA carries out communication with the built-in transponder in the ignition key. This wireless communication runs on RF (Radio frequency of 125 kHz). The SMAR-TRA is mounted at the behind of the crush pad under panel close to the antenna coil for RF transmission and receiving. The RF signal from the transponder, received by the antenna coil, is converted into messages for serial communication by the SMARTRA device. And, the received messages from the ECM are converted into an RF signal, which is transmitted to the transponder by the antenna. The SMARTRA does not carry out the validity check of the transponder or the calculation of encryption algorithm. This device is only an advanced interface, which converts the RF data flow of the transponder into serial communication to the ECM and vice versa.



ETQE710E

ICM (IMMOBILIZER CONTROL MODULE)

The ICM carries out communication with the built-in transponder in the ignition key. This wireless communication runs on RF (Radio frequency of 125 kHz). The ICM is mounted at the behind of the crush pad under panel close to the antenna coil for RF transmission and receiving.

The ICM carries out a check of the ignition key using a special encryption algorithm, which is programmed into the transponder as well as the ICM simultaneously. Only if the results are equal, transmits the signal to the ECM to permits injection. The data of all transponders, which are valid for the vehicle, are stored in the ICM.

The transponder has an advanced encryption algorithm. During the key teaching procedure, the transponder will be programmed with vehicle specific data. The vehicle specific data are written into the transponder memory. The write procedure is once only; therefore, the contents of the transponder can never be modified or changed.



ETQE470C

WWW.DIGITALKHODRO.COM

CIRCUIT DIAGRAM (1) E355CEC4



BE -175

BE -176

BODY ELECTRICAL SYSTEM





SCHEMATIC DIAGRAM E9DDF549



BE -177

021-62999292

BE -178

BODY ELECTRICAL SYSTEM





WWW.DIGITALKHODRO.COM

IMMOBILIZER CONTROL SYSTEM

DIAGNOSIS OF IMMOBILIZER

FAULTS EDDBEB5F

- Function of the SMARTRA/ICM and the transponder.
- Data (stored in the ECM/ICM related to the immobilizer function.
- Communication between the ECM and the SMAR-TRA/ICM.

THE FOLLOWING TABLE SHOWS THE ASSIGNMENT OF IMMOBILIZER RELATED FAULTS TO EACH TYPE :

Immobilizer Related Faults	Fault types	Diagnostic codes
Transponder fault	 Corrupted data from transponder More than one transponder in the magnetic field (Antenna coil) No transponder (Key without transponder) in the magnetic field (Antenna coil) Transponder not in the password mode Transponder transport data has been changed6. Transponder programming error 	P1693 (Transponder no response error/ transponder invalid response, Transponder status error, Transponder programming error)
SMARTRA/ICM fault	1. Antenna coil error	P1690(D2.0) P1691(β2.0, 2.7) (Antenna coil error)
تمالیت محدود)	 Communication line error (Open/Short etc.) Invalid message from SMARTRA/ICM to ECM 	P1678 (2.7) P1690 (D2.0, β2.0)(SMARTRA/ICM no response, SMARTRA message error)
ECM/ICM internal per- manent memory(EEP- ROM) fault	 ECM/I/ICM internal permanent memory (EEPROM) fault Invalid write operation to permanent memory (EEPROM) 	P1677(2.7) P1695(D2.0, β2.0) (ECM/ICM memory error)
ECM/ICM fault	1. Request from ECM/ICM is invalid (Protocol layer violation- Invalid request, check sum error etc.)	P1679(2.7) P1694(D2.0, β2.0) (ECM/ICM message error)
Immobilizer indicator lamp error	Immobilizer indicator lamp error (Cluster)	P1692(D2.0, β2.0) (Immobilizer lamp error)
Tester (HI-SCAN) fault	1. Request from tester is invalid(Protocol layer violation- Invalid request, check sum error etc.)	P1697(D2.0, β2.0) (Tester message error)
Invalid key fault	 Virgin transponder at EMS status " Learnt" Learnt (Invalid) Transponder at EMS status " Learnt" (Authentication fail) 	P1696(D2.0, β2.0), P1698(D2.0, β2.0) (Authentication fail)

BODY ELECTRICAL SYSTEM

PROBLEMS AND REPLACEMENT PARTS :

Problem	Part set	Hi-scan (pro) required?
All keys have been lost	Blank key (4)	YES
Antenna coil unit does not work	Antenna coil unit	NO
ECM/ICM does not work	ECM/ICM	YES
Ignition switch does not work	Ignition switch with Antenna coil unit	YES
Unidentified vehicle specific data occurs	Key, ECM/ICM	YES
SMARTRA unit does not work	SMARTRA unit	NO

REPLACEMENT OF ECM/ICM AND SMARTRA

In case of a defective ECM/ICM, the unit has to be replaced with a "virgin" or "neutral" ECM/ICM. All keys have to be taught to the new ECM/ICM. Keys, which are not taught to the ECM/ICM, are invalid for the new ECM/ICM (Refer to key teaching procedure). The vehicle specific data have to be left unchanged due to the unique programming of transponder.

In case of a defective SMARTRA, there is no special procedure required. A new SMARTRA device simply replaces the old one. There are no transponder-related data stored in this device.

NEUTRALISING OF ECM/ICM

The ECM/ICM can be set to the "neutral" status by a tester. A valid ignition key is inserted and after ignition on is recorded, the ECM/ICM requests the vehicle specific data from the tester. The communication messages are described at "Neutral Mode". After successfully receiving the data, the ECM/ICM is neutralized.

The ECM/ICM remains locked. Neither the limp home mode nor the "twice ignition on" function, is accepted by the ECM/ICM.

The teaching of keys follows the procedure described for the virgin ECM/ICM. The vehicle specific data have to be unchanged due to the unique programming of the transponder. If data should be changed, new keys with a virgin transponder are requested.


BE -181

DTC P1677 EMS VIN DATA ERROR (EMS HAS DIFFERENT VIN)

DTC DETECTING CONDITION EEOFEA53

DTC No.	Detecting Condition	Possible Cause	Related engine
P1677	ICM memory error	ICM internal permanent memory (EEPROM) fault, Invalid write operation to permanent memory (EEPROM).	2.7

INSPECTION PROCEDURE EDD0F765

- 1. PROBLEM VERIFICATION
 - 1) Connect the hi-scan (pro) to data link connector.
 - 2) Turn the ignition switch to ON and verify the DTC "P1677" is displayed.
 - 3) Erase the DTC "P1677" with the hi-scan (pro) and then monitor again.

Is the same code displayed ?

Problem is intermittent and ICM memory was not cleared.

Key teaching procedure

2. KEY TEACHING PROCEDURE BUILD TO A LOUD

- 1) Connect the hi-can (pro) to data link connector.
- 2) Turn the ignition switch to ON and select "TEACHING" mode of immobilizer system on the hi-scan (pro).
- 3) Input the pin code which consists of 6 digits.

🔟 NOTE

NO

YES

Because the pin code is security code, contact authorized HMC service staff to know the pin code.

4) If the data is correct, the key teaching is completed.

Is the key taught completely ?

NO

Check for these problems ;

- Storage of invalid data in transponder.
- Different kind of transponder.
- Omitted transponder in the key.



Check if DTC "P1677" is displayed again

021-62999292

BE -182

- 3. CHECK IF DTC "P1677" IS DISPLAYED AGAIN
 - 1) Connect the hi-scan (pro) to data link connector.
 - 2) Erase the DTC with the hi-scan (pro).
 - 3) Check if DTC "P1677" is displayed again.

Is the same code displayed ?

NO

Problem is intermittent and ICM memory was not cleared.

YES

If all the tests are OK, replace the ICM and recheck.

🔟 ΝΟΤΕ

After replacing the ICM, key teaching must be done.



ولین سامانه دیجیتال تعمیرکاران خودرو در ایران



WWW.DIGITALKHODRO.COM

021-62999292

BODY ELECTRICAL SYSTEM

BE -183

DTC P1678 EMS NO REQUEST (EMS DATA LINE OPEN, NO IMMO.)

DTC DETECTING CONDITION EATACSEF

DTC No.	Detecting Condition	Possible Cause	Related engine
P1678	ICM no responce, ICM message error	Communication line error (Open/Short etc.), Invalid message from ICM to ECM	2.7

INSPECTION PROCEDURE EB3033E7

- 1. PROBLEM VERIFICATION
 - 1) Connect the hi-scan (pro) to data link connector.
 - 2) Turn the ignition switch to ON and verify the DTC "P1678" is displayed.
 - 3) Erase the DTC "P1678" with the hi-scan (pro) and then monitor again.

Is the same code displayed ?

NO

Problem is intermittent and ICM memory was not cleared

YES

Check engine control main relay

2. CHECK ENGINE CONTROL MAIN RELAY

1) Check that an operating noise can be heard from the engine control main relay(A).

2) Check for continuity between the terminals of main relay.

Terminal Power (No.2-No.3)	2	3	1	4
Disconnected	0	—0		
Connected	Θ—	+	<u> </u>	—0

ETKE215B

BE -184

BODY ELECTRICAL SYSTEM



2) Measure the power input voltage of ICM between ICM harness connector terminal 1 and body ground.

Specification : approximately B+ (12V)



ETQE927C

IMMOBILIZER CONTROL SYSTEM

Is the voltage within the specification?

NO

Check for these problems ;

- A blown ECU fusible link (20A) or sensor fuse (10A) in the engine compartment relay & fuse box.
- An open or short in the wire between the engine control main relay and ICM.



Check harness and connector between ICM and body ground

4. CHECK HARNESS AND CONNECTOR BETWEEN ICM AND BODY GROUND Check for continuity between ICM harness connector(M23-1) terminal 8 and body ground.





اولین سامانه دیجیتال تعمیرکاران جاید ا

NO

Repair an open in the wire between the ICM and the body ground.

YES

Check harness and connector between ICM and ECM

 CHECK HARNESS AND CONNECTOR BETWEEN ICM AND ECM Check for continuity between ICM harness connector(M23-1) terminal 6 and ECM harness connector (C30-1) terminal 3. Is there continuity ?

NO

Repair an open in the wire between the ICM and the ECM.



If all the tests are OK, replace the ICM and recheck.

BODY ELECTRICAL SYSTEM

DTC P1679 EMS DATA FAIL (DATA FRAME, CS, MESSAGE ERROR)

DTC DETECTING CONDITION E49D3BD0

DTC No.	Detecting Condition	Possible Cause	Related engine
P1679	ICM message error	Request from ICM is invalid (Protocol layer violation- Invalid request, check sum error etc.)	2.7

INSPECTION PROCEDURE EE2FEAE9

- 1. PROBLEM VERIFICATION
 - 1) Connect the hi-scan (pro) to data link connector.
 - 2) Turn the ignition switch to ON and verify the DTC "P1679" is displayed.
 - 3) Erase the DTC "P1679" with the hi-scan (pro) and then monitor again.

Is the same code displayed ?



Is there continuity ?

NO

Repair an open in the wire between the ICM and the ECM.

YES

If all the tests are OK, replace the ICM or ECM and recheck.

BE -187

021-62999292

DTC P1690 SMARTRA NO RESPONSE

DTC DETECTING CONDITION EBBFBFE4

DTC No.	Detecting Condition	Possible Cause	Application engine
P1690	SMARTRA no response, SMARTRA message error	Communication line error (Open/Short etc.), Invalid message from SMARTRA to ECM	D2.0, 2.0

INSRECTION PROCEDURE E9B6F5FC

1. PROBLEM VERIFICATION

- 1) Connect the hi-scan (pro) to data link connector.
- 2) Turn the ignition switch to ON and verify the DTC "P1690" is displayed.
- 3) Erase the DTC "P1690" with the hi-scan (pro) and then monitor again.

Is the same code displayed ?

NO

Problem is intermittent and engine control module memory was not cleared.

YES

Check engine control main relay

2. CHECK ENGINE CONTROL MAIN RELAY

1) Check that an operating noise can be heard from the engine control main relay(A).

2) Check for continuity between the terminals of main relay.

Terminal Power (No.2-No.3)	2	3	1	4
Disconnected	0	—0		
Connected	Θ—	+	<u> </u>	\bigcirc

ETKE215B

BE -188

BODY ELECTRICAL SYSTEM



2) Measure the power input voltage of SMARTRA between SMARTRA harness connector terminal 4 and body ground.

Specification : approximately B+ (12V)



ETQE927E

Is the voltage within the specification?

NO

Check for these problems ;

- A blown ECU fusible link (20A) or sensor fuse (10A) in the engine compartment relay & fuse box.
- An open or short in the wire between the engine control main relay and SMARTRA unit.



Check harness and connector between SMARTRA unit and body ground

4. CHECK HARNESS AND CONNECTOR BETWEEN SMARTRA UNIT AND BODY GROUND Check for continuity between SMARTRA harness connector terminal 3 and body ground.



 CHECK HARNESS AND CONNECTOR BETWEEN SMARTRA UNIT AND ECM Check for continuity between SMARTRA harness connector terminal 5 and ECM harness connector(C230-1/C130-1) terminal(11/47). Is there continuity ?

NO

Repair an open in the wire between the SMARTRA unit and the ECM.



If all the tests are OK, replace the SMARTRA unit and recheck.

BODY ELECTRICAL SYSTEM

DTC P1691 ANTENNA COIL ERROR

DTC DETECTING CONDITION E273AC8E

DTC No.	Detecting Condition	Possible Cause	Related engine
P1691	Antenna coil error	An open in the wire between SMARTRA and antenna coil, Faulty antenna coil	D2.0: P1690 2.0: P1691

INSPECTION PROCEDURE E6073A9E

1. PROBLEM VERIFICATION

- 1) Connect the hi-scan (pro) to data link connector.
- 2) Turn the ignition switch to ON and verify the DTC "P1691"is displayed.
- 3) Erase the DTC "P1691" with the hi-scan (pro) and then monitor again.

Is the same code displayed ?

NO

Problem is intermittent and engine control module memory was not cleared.

YES

Check for continuity between antenna coil and SMARTRA unit

- 2. CHECK FOR CONTINUITY BETWEEN ANTENNA COIL AND SMARTRA UNIT
 - 1) Check for continuity between SMARTRA harness connector terminal 1 and antenna coil harness connector(M11) terminal 2.
 - 2) Check for continuity between SMARTRA harness connector terminal 2 and antenna coil harness connector(M11) terminal 1.

Is there continuity ?

NO

Repair an open in the wire between the antenna coil and the SMARTRA unit.

YES

If all the tests are OK, replace the antenna coil assembly and recheck.

BE -191

DTC DETECTING CONDITION E117FFAA

DTC No.	Detecting Condition	Possible Cause	Application engine
P1691	Antenna coil error	An open in the wire between ICM and antenna coil, Faulty antenna coil	2.7

INSPECTION PROCEDURE E6073A9E

- 1. PROBLEM VERIFICATION
 - 1) Connect the hi-scan (pro) to data link connector.
 - 2) Turn the ignition switch to ON and verify the DTC "P1691"is displayed.
 - 3) Erase the DTC "P1691" with the hi-scan (pro) and then monitor again.

Is the same code displayed ?

NO

Problem is intermittent and engine control module memory was not cleared.

YES

Check for continuity between antenna coil and SMARTRA unit

- 2. CHECK FOR CONTINUITY BETWEEN ANTENNA COIL AND SMARTRA UNIT
 - 1) Check for continuity between SMARTRA harness connector terminal 1 and antenna coil harness connector(M11) terminal 2.
 - 2) Check for continuity between SMARTRA harness connector terminal 2 and antenna coil harness connector(M11) terminal 1.

Is there continuity ?

NO

Repair an open in the wire between the antenna coil and the SMARTRA unit.

YES

If all the tests are OK, replace the antenna coil assembly and recheck.

BODY ELECTRICAL SYSTEM

DTC P1692 IMMOBILIZER LAMP ERROR

DTC DETECTING CONDITION ECE9C3BF

DTC No.	Detecting Condition	Possible Cause	Related engine
P1692	Immobilizer indicator lamp error	Immobilizer indicator lamp error (Cluster)	D2.0, 2.0

INSPECTION PROCEDURE EFA27ABE

1. PROBLEM VERIFICATION

- 1) Connect the hi-scan (pro) to data link connector.
- 2) Turn the ignition switch to ON and verify the DTC "P1692" is displayed.
- 3) Erase the DTC "P1692" with the hi-scan (pro) and then monitor again.

Is the same code displayed ?

NO

Problem is intermittent and engine control module memory was not cleared.

YES

Check cluster and ECM connectors

2. CHECK CLUSTER AND ECM CONNECTORS Thoroughly check connectors for loose, poor connection, bent, corrosion, contamination, deterioration, or damage. Are all connectors good?

YES

Repair or replace it.

NO

Check for open in harness

IMMOBILIZER CONTROL SYSTEM

BE -193

- 3. CHECK FOR OPEN IN HARNESS
 - 1) Turn ignition switch to OFF and disconnect Cluster and ECM connectors.
 - 2) Measure resistance between the terminals 7 of Cluster harness connector (M15-3) and (17/81) of ECM harness connector (C230-1/C130-1).

Specification: below 1



Replace the cluster

 REPLACE THE CLUSTER Temporarily install a good cluster. Is operating of the immobilizer lamp possible?



Replace the cluster.

NO

Proceed with ECM problem procedure.

BODY ELECTRICAL SYSTEM

DTC P1693 TRANSPONDER NO RESPONSE ERROR / INVALID RESPONSE

DTC DETECTING CONDITION ECB3B822

DTC No.	Detecting Condition	Possible Cause	Related engine
P1693	Transponder no response error/ transponder invalid response, Transponder status error,Transponder programming error	Corrupted data from transponder, More than one transponder in the magnetic field (Antenna coil), No transponder (Key without transponder) in the magnetic field (Antenna coil), Transponder not in the password mode, Transponder transport data hasbeen changed,Transpon- der programming error	D2.0, 2.0, 2.7

INSPECTION PROCEDURE EFBAFD32

1. PROBLEM VERIFICATION

- 1) Connect the hi-scan (pro) to data link connector.
- 2) Turn the ignition switch to ON and verify the DTC "P1693" is displayed.
- 3) Erase the DTC "P1693" with the hi-scan (pro) and then monitor again.

Is the same code displayed ?

شرکت دیجیتال خودرو سامانه (مسئولیت و 🛯 رد

Problem is intermittent and engine control module or ICM memory was not cleared.

YES

Key teaching procedures

2. KEY TEACHING PROCEDURE

- 1) The key teaching is done after replacing a defective ECM or ICM for providing of additional keys to the vehicle owner.
- 2) Connect the hi-scan (pro) to data link connector.
- 3) Turn the ignition switch to ON and select "TEACHING" mode of immobilizer system on the hi-scan (pro).
- 4) Input the pin code which consists of 6 digits.

🔟 ΝΟΤΕ

Because the pin code is security code, contact authorized HMC service staff to know the pin code.

- 5) If incorrect pin code is inputted for 3 consecutive times, ECM or ICM should disallow key teaching function for 1 hours.
- 6) If the data is correct, the key teaching is completed.

WWW.DIGITALKHODRO.COM

021-62999292

IMMOBILIZER CONTROL SYSTEM

Is the key taught completely ?

NO

Check for these problems ;

- Storage of invalid data in transponder.
- Different kind of transponder.
- Omitted transponder in the key.

YES

Check if DTC "P1693" is displayed again

- 3. CHECK IF DTC "P1693" IS DISPLAYED AGAIN
 - 1) Connect the hi-scan (pro) to data link connector.
 - 2) Turn the ignition switch to ON and verify the DTC "P1693" is displayed.

Is the same code displayed ?

NO

Problem is intermittent and engin control module or ICM memory was not cleared.

۰

YES

Replace the key set assembly and key teaching must be done.

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران

BODY ELECTRICAL SYSTEM

DTC P1694 EMS MESSAGE ERROR

DTC DETECTING CONDITION E26EACC5

DTC No.	Detecting Condition	Possible Cause	Related engine
P1694	ECM message error	Request from ECM is invalid (Protocol layer violation- Invalid request, check sum error etc.)	2.0

INSPECTION PROCEDURE EE9A4A44

- 1. PROBLEM VERIFICATION
 - 1) Connect the hi-scan (pro) to data link connector.
 - 2) Turn the ignition switch to ON and verify the DTC "P1694" is displayed.
 - 3) Erase the DTC "P1694" with the hi-scan (pro) and then monitor again.

Is the same code displayed ?

Problem is intermittent and engine control module memory was not cleared.

Check harness and connector between SMARTRA unit and ECM

 CHECK HARNESS AND CONNECTOR BETWEEN SMARTRA UNIT AND ECM Check for continuity between SMARTRA harness side connector terminal 5 and ECM harness side connector (C130-1) terminal 47. Is there continuity ?

NO

NO

YES

Repair an open in the wire between the SMARTRA unit and the ECM.

YES

If all the tests are OK, replace the SMARTRA unit or ECM and recheck.

NOTE

After replacing the ECM, key teaching must be done.

BE -197

DTC P1695 EMS MEMORY ERROR

DTC DETECTING CONDITION EBAA9FD9

DTC No.	Detecting Condition	Possible Cause	Application engine
P1695	ECM memory error	ECM internal permanent memory (EEPROM) fault, Invalid write operation to permanent memory (EEPROM).	D2.0, 2.0

INSPECTION PROCEDURE EEF865DF

1. PROBLEM VERIFICATION

- 1) Connect the hi-scan (pro) to data link connector.
- 2) Turn the ignition switch to ON and verify the DTC "P1695" is displayed.
- 3) Erase the DTC "P1695" with the hi-scan (pro) and then monitor again.

Is the same code displayed ?

NO

Problem is intermittent and engine control module memory was not cleared.

YES

Key teaching procedures

2. KEY TEACHING PROCEDURES

- 1) Connect the hi-can (pro) to data link connector.
- 2) Turn the ignition switch to ON and select "TEACHING" mode of immobilizer system on the hi-scan (pro).
- 3) Input the pin code which consists of 6 digits.

🔟 ΝΟΤΕ

Because the pin code is security code, contact authorized HMC service staff to know the pin code.

4) If the data is correct, the key teaching is completed.

Is the key taught completely ?

NO

Check for these problems ;

- Storage of invalid data in transponder.
- Different kind of transponder.
- Omitted transponder in the key.

YES

Check if DTC "P1695" is displayed again

021-62999292

BODY ELECTRICAL SYSTEM

BE -198

- 3. CHECK IF DTC "P1695" IS DISPLAYED AGAIN
 - 1) Connect the hi-scan (pro) to data link connector.
 - 2) Erase the DTC with the hi-scan (pro).
 - 3) Check if DTC "P1695" is displayed again.

Is the same code displayed ?

NO

Problem is intermittent and engine control module memory was not cleared.

YES

If all the tests are OK, replace the ECM and recheck.

🔟 ΝΟΤΕ

After replacing the ECM, key teaching must be done.



ولین سامانه دیجیتال تعمیرکاران خودرو در ایران



DTC P1696 AUTHENTICATION FAIL

DTC DETECTING CONDITION EDEBD366

DTC No.	Detecting Condition	Possible Cause	Related engine			
P1696, P1698	Authentication fail	Virgin transponder at ECM status "Learnt", Learnt (Invalid) Transponder at ECM status "Learnt" (Authentication fail)	D2.0, 2.0			

INSPECTION PROCEDURE E9AD8075

- 1. PROBLEM VERIFICATION
 - 1) Connect the hi-scan (pro) to data link connector.
 - 2) Turn the ignition switch to ON and verify the DTC "P1696" or "P1698" is displayed.
 - 3) Erase the DTC "P1696" or "P1698" with the hi-scan (pro) and then monitor again.

Is the same code displayed ?

Problem is intermittent and engine control module memory was not cleared.

Replace the transponder key

2. REPLACE THE TRANSPONDER KEY Use another key supplied with the vehicle.

Is starting of the vehicle possible?



NO

YES

Replace the faulty key.



Check the state of the transponder key

3. CHECK THE STATE OF THE TRANSPONDER KEY Check the state of the transponder key by using the tester.

Is the ignition key virgin?



Replace the faulty ley.



Teach the ignition key.



BE -199

BODY ELECTRICAL SYSTEM

DTC P1697 HI-SCAN MESSAGE ERROR

DTC DETECTING CONDITION E41D38EA

DTC No.	Detecting Condition	Possible Cause	Application engine			
P1697	Tester message error	Request from tester is invalid (Protocol layer violation- Invalid request, check sum error etc.)	D2.0, 2.0			

INSPECTION PROCEDURE E67DB687

1. PROBLEM VERIFICATION

- 1) Connect the hi-scan (pro) to data link connector.
- 2) Turn the ignition switch to ON and verify the DTC "P1697" is displayed.
- 3) Erase the DTC "P1697" with the hi-scan (pro) and then monitor again.

Is the same code displayed ?

NO

YES

Problem is intermittent and engine control module memory was not cleared.

Replace the tester(HI-SCAN)

ولين سامانه ديجيتال تعميركاران خودرو در ايران

TEACHING PROCEDURE EEE6B7E5

Key Teaching Procedure

Key teaching must be done after replacing a defective ECM(ICM) or when providing additional keys to the vehicle owner.

The procedure starts with an ECM(ICM) request for vehicle specific data(PIN code : 6digits) from the tester. The "virgin" ECM(ICM) stores the vehicle specific data and the key teaching can be started. The "learnt" ECM(ICM) compares the vehicle specific data from the tester with the stored data. If the data are correct, the teaching can proceed.

If incorrect vehicle specific data have been sent to the ECM(ICM) three times, the ECM(ICM) will reject the request of key teaching for one hour. This time cannot be reduced by disconnecting the battery or any other manipulation. After reconnecting the battery, the timer starts again for one hour.

The key teaching is done by ignition on with the key and additional tester commands. The ECM(ICM) stores the relevant data in the EEPROM and in the transponder. Then the ECM(ICM) runs the authentication required for confirmation of the teaching process. The successful programming is then confirmed by a message to the tester.

If the key is already known to the ECM(ICM) from a previous teaching, the authentication will be accepted and the EEPROM data are updated. There is no changed transponder content (this is impossible for a learnt transponder).

The attempt to repeatedly teach a key, which has been taught already during the same teaching cycle, is recognized by the ECM(ICM). This rejects the key and a message is sent to the tester.

The ECM(ICM) rejects invalid keys, which are presented for teaching. A message is sent to the tester. The key can be invalid due to faults in the transponder or other reasons, which result from unsuccessful programming of data. If the ECM(ICM) detects different authenticators of a transponder and an ECM(ICM), the key is considered to be invalid.

The maximum number of taught keys is 4.

If an error occurs during the Immobilizer Service Menu, the ECM(ICM) status remains unchanged and a specific fault code is stored. If the ECM(ICM) status and the key status do not match for teaching of keys, the tester procedure will be stopped and a specific fault code will be stored at ECM(ICM).



BE -201

021-62999292

ETQE740B

WWW.DIGITALKHODRO.COM

021-62999292

BE -202

BODY ELECTRICAL SYSTEM

021-62999292

User Password Teaching Procedure

The user password for limp home is taught at the service station. The owner of the vehicle can select a number with four digits.

User password teaching is only accepted by a "learnt" ECM(ICM). Before first teaching of user password to an ECM(ICM), the status of the password is "virgin". No limp home function is possible.

The teaching is started by ignition on, with a valid key and sending the user password by tester. After successful teaching, the status of the user password changes from "virgin" to "learnt". The learnt user password can also be changed. This can be done if the user password status is "learnt" and the tester sends authorization of access, either the old user password or the vehicle specific data. After correct authorization, the ECM(ICM) requests the new user password. The status remains "learnt" and the new user password will be valid for the next limp home mode.

If incorrect user passwords or wrong vehicle specific data have been sent to the ECM(ICM) three times, the ECM(ICM) will reject the request to change the password for one hour. This time cannot be reduced by disconnecting the battery or any other actions. After reconnecting the battery, the timer starts again for one hour.

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



021-62999292

BE -203

IMMOBILIZER CONTROL SYSTEM

LIMP HOME FUNCTION E2EB475B



BE -204

1. LIMP HOME BY TESTER

If the ECM(ICM) detects the fault of the SMARTRA or transponder, the ECM(ICM) will allow limp home function of the immobilizer. Limp home is only possible if the user password (4 digits) has been given to the ECM(ICM) before. This password can be selected by the vehicle owner and is programmed at the service station.

The user password can be sent to the ECM(ICM) via the special tester menu.

Only if the ECM(ICM) is in status "learnt" and the user password status is "learnt" and the user password is correct, the ECM(ICM) will be unlocked for a period of time (30 sec.). The engine can only be started during this time. After the time has elapsed, engine start is not possible.

If the wrong user password is sent, the ECM(ICM) will reject the request of limp home for one hour. Disconnecting the battery or any other action cannot reduce this time. After connecting the battery to the ECM(ICM), the timer starts again for one hour.

2. LIMP HOME BY IGNITION KEY

The limp home can be activated also by the ignition key. The user password can be input to the ECM(ICM) by a special sequence of ignition on/off.

Only if the ECM(ICM) is in status "learnt" and the user password status is "learnt" and the user password is correct, the ECM(ICM) will be unlocked for a period of time (30 sec.). The engine can be started during this time. After the time has elapsed, engine start is not possible. After a new password has been input, the timer (30 sec.) will start again.

After ignition off, the ECM(ICM) is locked if the timer has elapsed 8 seconds. For the next start, the input of the user password is requested again.



BODY ELECTRICAL SYSTEM

021-62999292

BE -205

IGNITION SYSTEM

IGNITION SYSTEM

IGNITION SWITCH

INSPECTION ECD023FC



- 1. Disconnect the ignition switch connector(6P) and the door warning switch connector(6P) under the steering column.
- 2. Check for continuity between the terminals.
- 3. If continuity is not as specified, replace the switch.

TERMINAL		اولين سا ignition switch اولين سا				STEERING		DOOR WARNING SWITCH		KEY HOLE ILLUMINATION			
POSITION KEY		5	3	1	2	4	6	TRAVEL	TRAVEL	5	6	3	4
LOCK	REMOVAL							LOCK					
								LOCK	UNTOOK				
ACC	INSERT	0	-0					UNLOCK		00			
ON		0	-0-	0	<u> </u>	0					— 0		
START]	0			0								

ETQF980A

ETQF094A