# **General Information**

### **General Information**

#### General

The supplemental restraint system (SRS) is designed to supplement the seat belt to help reduce the risk or severity of injury to the driver and passenger by activating and deploying the driver, passenger, side airbag and belt pretensioner in certain frontal or side collisions.

The SRS (Airbag) consists of ; a driver side airbag module located in the center of the steering wheel, which contains the folded cushion and an inflator unit ; a passenger side airbag module located in the passenger side crash pad contains the folded cushion assembled with inflator unit ; side airbag modules located in the front seat contain the folded cushion and an inflator unit ; curtain airbag modules located inside of the headliner which contains folded cushions and inflator units. The impact sensing function of the SRSCM is carried out by electronic accelerometer that continuously measure the vehicle's acceleration and delivers a corresponding signal through amplifying and filtering circuitry to the microprocessor.

#### SRSCM (SRS Control Module)

SRSCM will detect front impact with front impact sensor, and side impact with side impact sensor, and determine airbag module deployment.

- 1. DC/DC converter: DC/DC converter in power supply unit includes up/down transformer converter, and provide ignition voltage for 2 front airbag ignition circuits and the internal operation voltage of the SRSCM. If the internal operation voltage is below critical value setting, it will perform resetting.
- Safety sensor: Safety sensor is located in airbag ignition circuit. Safety sensor will operate airbag circuit at any deployment condition and release airbag circuit safely at normal driving condition. Safety sensor is a double contact electronic switch that will close detecting acceleration above certain criteria.
- 3. Back up power supply: SRSCM has separate back up power supply, that will supply deployment energy instantly in low voltage condition or upon power failure by front crash.

- Self diagnosis: SRSCM will constantly monitor current SRS operation status and detect system failure while vehicle power supply is on, system failure may be checked with trouble codes using scan tool. (Hi- Scan)
- Airbag warning lamp on: Upon detecting error, the module will transmit signal to SRSCM indicator lamp located at cluster. MIL lamp will indicate driver SRS error. Upon ignition key on, SRS lamp will turn on for about six seconds.
- Trouble code registration: Upon error occurrence in system, SRSCM will store DTC corresponding to the error. DTC can be cleared only by Hi-Scan. However, if an internal fault code is logged or if a crash is recorded the fault clearing should not happen.
- Self diagnostic connector: Data stored in SRSCM memory will be output to Hi-Scan or other external output devices through connector located below driver side crash pad.
- 8. Once airbag is deployed, SRSCM should not be used again but replaced.
- SRSCM will determine whether passenger put on seat belt by the signal from built-in switch in seat belt buckle, and deploy front seat airbag at each set crash speed.
- 10. Side airbag deployment will be determined by SRSCM that will detect satellite sensor impact signal upon side crash, irrespective to seat belt condition.

# RT-4

Restraint

#### Specification

Item	Resistance (Ω)
Driver Airbag (DAB)	1.5 ~ 5.7
Passenger Airbag (PAB)	1.5 ~ 5.7
Side Airbag (SAB)	1.5 ~ 5.7
Curtain Airbag (CAB)	1.5 ~ 5.7
Seat Belt Retractor Pretensioner (BPT)	1.5 ~ 5.7

#### **Tightening Torques**

Item	kgf.m	Nm	lb-ft
Driver Airbag (DAB)	0.8 ~ 1.1	7.8 ~ 10.8	$5.8 \sim 8.0$
Passenger Airbag (PAB)	Bolt :0.7 ~ 1.1 Nut : 0.6 ~ 0.7	6.9 ~ 10.8 5.9 ~ 6.9	5.1 ~ 8.0 4.3 ~ 5.0
Curtain Airbag (CAB)	1.2 ~ 1.5	11.8 ~ 14.7	8.7 ~ 10.9
Side Airbag (SAB)	$0.7 \sim 0.9$	6.9 ~ 8.8	5.1 ~ 6.5
Seat Belt Anchor Bolt (BPT)	$4.0 \sim 5.5$	39.2 ~53.9	28.9 ~ 39.8
SRSCM	$0.7 \sim 2.0$	6.9 ~19.6	5.1 ~ 14.5
Fro <mark>nt Impac</mark> t Sensor (FIS) Mounting nut	0.7 ~ 0.9	6.9 ~ 8.8	5.1 ~ 6.5
Side Impact Sensor (SIS) Mounting Bolt	0.7 ~ 0.9	6.9 ~ 8.8	5.1 ~ 6.5

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

# **General Information**

RT-5

### **Special Service Tools**

Tool(Number and Name)	Illustration	Use
Deployment tool 0957A-34100A		Airbag deployment tool
	ARIE500A	
Deployment adapter 0957A-38510		Use with deployment tool. (DAB)
	BRIF501Y	
Deployment adapter 0957A-2E110 (مسئولیت محدود)	URBF001H	Use with deployment tool. (PAB)
Deployment adapter 0957A-3F100		Use with deployment tool. (SAB)
Deployment adapter	ERKDUUIP	Use with deployment tool.
0957A-38500	C C C C C C C C C C C C C C C C C C C	(CAB, BPT)
	ARIE500C	

021-62999292

### **RT-6**

### **Restraint**

Tool(Number and Name)	Illustration	Use
Dummy 0957A-38200		Simulator to check the resistanceof ea- ch wiring harness
	ARIE500D	
Dummy adapter 0957A-3F000		Use with dummy (SAB)
	ERKD001G	
Dummy adapter 0957A-2G000	ARIESOOF	Use with dummy (DAB, CAB, BPT)
Dummy adapter 9,095 01,159,46 0957A-2E100	EP ( CLOSE OF CLOSE O	Use with dummy (PAB)

DAB : Driver Airbag

PAB : Passenger Airbag

SAB : Side Airbag

CAB : Curtain Airbag

BPT : Seat Belt Retractor Pretensioner

# **General Information**

#### Precautions

#### **General Precautions**

Please read the following precautions carefully before performing the airbag system service.

Observe the instructions described in this manual, or the airbags could accidentally deploy and cause damage or injuries.

• Except when performing electrical inspections, always turn the ignition switch OFF and disconnect the negative cable from the battery, and wait at least three minutes before beginning work.

#### 

The contents in the memory are not erased even if the ignition switch is turned OFF or the battery cables are disconnected from the battery.

- Use the replacement parts which are manufactured to the same standards as the original parts and quality.
   Do not install used SRS parts from another vehicle.
   Use only new parts when making SRS repairs.
- Carefully inspect any SRS part before you install it. Do not install any part that shows signs of being dropped or improperly handled, such as dents, cracks or deformation.



ARIE500H

• Before removing any of the SRS parts (including the disconnection of the connectors), always disconnect the SRS connector.

#### Airbag Handling and Storage

Do not disassemble the airbags; it has no serviceable parts. Once an airbag has been deployed, it cannot be repaired or reused.

For temporary storage of the air bag during service, please observe the following precautions.

- Store the removed airbag with the pad surface up.
- Keep free from any oil, grease, detergent, or water to prevent damage to the airbag assembly.



Store the removed airbag on secure, flat surface away from any high heat source (exceeding 85 C/185 F).

- Never perform electrical inspections to the airbags, such as measuring resistance.
- Do not position yourself in front of the airbag assembly during removal, inspection, or replacement.
- Refer to the scrapping procedures for disposal of the damaged airbag.
- Be careful not to bump or impact the SRS unit or the side impact sensors or front impact sensors whenever the ignition switch is ON, wait at least three minutes after the ignition switch is turned OFF before begin work.
- During installation or replacement, be careful not to bump (by impact wrench, hammer, etc.) the area around the SRS unit and the side impact sensor and the front impact sensors. The airbags could accidentally deploy and cause damage or injury.

# Restraint

- Replace the front airbag module, SRSCM, FIS when deploying the front airbag. Replace the airbag wiring when the airbag wiring get damaged. Replace the side airbag module, the curtain airbag module, SRSCM, SIS when deploying the side airbag. Replace the airbag when the airbag wiring get damaged.
- After a collision in which the airbags or the side air bags did not deploy, inspect for any damage or any deformation on the SRS unit and the side impact sensors. If there is any damage, replace the SRS unit, the front impact sensor and/or the side impact sensors.
- Do not disassemble the SRS unit, the front impact sensor or the side impact sensors.
- Turn the ignition switch OFF, disconnect the battery negative cable and wait at least three minutes before beginning installation or replacement of the SRS unit.
- Be sure the SRS unit, the front impact sensor and side impact sensors are installed securely with the mounting bolts.
- Do not spill water or oil on the SRS unit, or the front impact sensor or the side impact sensors and keep them away from dust.
- Store the SRS unit, the front impact sensor and the side impact sensors in a cool (15  $\sim$  25 C/ 59  $\sim$  77 F) and dry (30  $\sim$  80% relative humidity, no moisture) area.

#### Wiring Precautions

SRS wiring can be identified by special yellow outer covering Observe the instructions described in this section.

• Never attempt to modify, splice, or repair SRS wiring. If there is an open or damage in SRS wiring, replace the harness.



ARIE500I

Be sure to install the harness wires so that they are not pinched, or interfere with other parts.



ARIE500J

• Make sure all SRS ground locations are clean, and grounds are securely fastened for optimum metal-to-metal contact. Poor grounding can cause intermittent problems that are difficult to diagnose.

### 021-62999292

RT-9

# **General Information**

#### **Precautions for Electrical Inspections**

 When using electrical test equipment, insert the probe of the tester into the wire side of the connector.
 Do not insert the probe of the tester into the terminal side of the connector, and do not tamper with the connector.



ARIE500K

- Use a u-shaped probe. Do not insert the probe forcibly.
- Use specified service connectors for troubleshooting.
   Using improper tools could cause an error in inspection due to poor metal contact.

#### Spring-laded Lock Connector

Some SRS system connectors have a spring-loaded lock.

#### **Airbag Connector**

#### Disconnecting

To release the lock, pull the spring-loaded sleeve (A) and he slider (B), while holding the opposite half of the connector.

Pull the connector halves apart. Be sure to pull on the sleeve and not on the connector half.



#### Connecting

Hold both connector halves and press firmly until the projection(C) of the sleeve-side connector clicks to lock.



ARJF500F

### WWW.DIGITALKHODRO.COM

### 021-62999292

Restraint

# RT-10

#### Warning Lamp Activation

#### Warning Lamp Behavior after Ignition On

As soon as the operating voltage is applied to the SRSCM ignition input, the SRSCM activates the warning lamp for a bulb check.

The lamp shall turn on for 6 seconds during the initialization phase and be turned off afterward.

However, in order to indicate the driver, the warning lamp shall turn on for 6 seconds and off for one second then on continuously after the operating voltage is applied if any active fault exists.

1. Active fault or historical fault counter is greater or equal to 10



### SRSCM Independent Warning Lamp Activation

There are certain fault conditions in which the SRSCM cannot function and thus cannot control the operation of the standard warning lamp. In these cases, the standard warning lamp is directly activated by appropriate circuitry that operates independently of the SRSCM. These cases are:

- 1. Loss of battery supply to the SRSCM : warning lamp turned on continuously.
- 2. Loss of internal operating voltage : warning lamp turned on continuously.
- 3. Loss of Microprocessor operation : warning lamp turned on continuously.
- 4. SRSCM not connected : warning lamp turned on continuously through the shorting bar.

# Component Replacement After Deployment

Before doing any SRS repairs, use the Hi-Scan Pro to check for DTCs. Refer to the Diagnostic Trouble Code list for repairing of the related DTCs.

When the front airbag(s) deployed after a collision, replace the following items.

- SRSCM
- Deployed airbag(s)
- Seat belt pretensioner(s)
- Front impact sensors
- SRS wiring harnesses
- Inspect the clock spring for heat damage.

If any damage found, replace the clock spring.

When the side/curtain airbag(s) deployed after a collision, replace the following items.

- SRSCM
- Deployed airbag(s)
- Side impact sensor(s) for the deployed side(s)
- SRS wiring harnesses

After the vehicle is completely repaired, confirm the SRS airbag system is OK.

Turn the ignition switch ON, the SRS indicator should come on for about 6 seconds and then go off.

# **General Information**

#### Components



SBHRT9001L

- 1. Driver Airbag (DAB)
- 2. Steering Wheel
- 3. Clock Spring
- 4. Seat Belt Pretensioner (BPT)
- 5. Front Side Impact Sensor (FSIS)
- 6. Side Airbag (SAB)

- 7. Passenger Airbag (PAB)
- 8. Front Impact Sensor (FIS)
- 9. Curtain Airbag (CAB)
- 10. Supplemental Restraint System Control Module(SRSCM)
- 11. Airbag Warning Lamp
- 12. Rear Side Impact Sensor (RSIS)

021-62999292

### Restraint

### **Components Location**

**RT-12** 

Supplemental Restraint System Control Module (SRSCM)



SBHRT9003N

# **General Information**

#### Side Impact Sensor (SIS)

# **RT-13**



SBHRT9002L

# Restraint

### Driver Airbag (DAB) / Passenger Airbag (PAB)



SBHRT9006N

# **General Information**

### Side Airbag (SAB)



SBHRT9007N

Restraint

#### Seat Belt Retractor Pretensioner (BPT)



# SRSCM

### SRSCM

### SRS Control Module (SRSCM)

#### Description

The primary purpose of the SRSCM (Supplemental Restraints System Control Module) is to discriminate between an event that warrants restraint system deployment and an event that does not. The SRSCM must decide whether to deploy the restraint system or not. After determining that pretensioners and/or airbag deployment is required, the SRSCM must supply sufficient power to the pretensioners and airbag igniters to initiate deployment.

The SRSCM determines that an impact may require deployment of the pretensioners and airbags from data obtained from impact sensors and other components in conjunction with a safing function.

Components

The SRSCM will not be ready to detect a crash or to activate the restraint system devices until the signals in the SRSCM circuitry stabilize.

It is possible that the SRSCM could activate the safety restraint devices in approximately 2 seconds but is guaranteed to fully function after prove-out is completed.

The SRSCM must perform a diagnostic routine and light a system readiness indicator at key-on. The system must perform a continuous diagnostic routine and provide fault annunciation through a warning lamp indicator in the event of fault detection. A serial diagnostic communication interface will be used to facilitate servicing of the restraint control system.



### **RT-17**

# Restraint

021-62999292

### **RT-18**

#### Removal

- 1. Remove the ignition key from the vehicle.
- 2. Disconnect the battery negative cable and wait for at least three minutes before beginning work.
- 3. Disconnect the DAB, PAB, SAB, CAB and BPT connectors.
- 4. Remove the floor console. (Refer to the Body group console)
- 5. Disconnect the SRSCM harness connector from the SRSCM.



 Remove the SRSCM mounting bolts(4EA) from the SRSCM, then remove the SRSCM.

#### Installation

- 1. Remove the ignition key from the vehicle.
- 2. Disconnect the battery negative cable and wait for at least three minutes before beginning work.
- 3. Install the SRSCM with the SRSCM mounting bolts.

# Tightening torque (SRSCM Mounting Bolt) : 6.9 $\sim$ 19.6 Nm (0.7 $\sim$ 2.0 kgf.m, 5.1 $\sim$ 14.5 lb.ft)



SBHRT8052D

#### **WNOTICE**

Use new mounting bolts when replacing the SRSCMafter a collision.

- 4. Connect the SRSCM harness connector.
- 5. Install the heater ducts and floor console. (Refer to the Body group console)
- 6. Connect the DAB, PAB, SAB, CAB and BPT connectors.
- 7. Reconnect the battery negative cable.
- 8. After installing the SRSCM, confirm proper system operation:
  - Turn the ignition switch ON; the SRS indicator light should be turned on for about six seconds and then go off.

# SRSCM

021-62999292

### Front Impact Sensor (FIS)

### Description

The front impact sensor (FIS) is installed in the Front End Module (FEM). They are remote sensors that detect acceleration due to a collision at its mounting location. The primary purpose of the Front Impact Sensor (FIS) is to provide an indication of a collision. The Front Impact Sensor (FIS) sends acceleration data to the SRSCM.

#### Components



SBHRT9003N

# Restraint

#### Removal

#### 

- Removal of the airbag must be performed according to the precautions/ procedures described previously.
- Before disconnecting the front impact sensor connector, disconnect the front airbag connector(s).
- Do not turn the ignition switch ON and do not connect the battery cable while replacing the front impact sensor.
- 1. Disconnect the battery negative cable, and wait for at least three minutes before beginning work.
- 2. Remove the front bumper. (Refer to the Body group-Bumper)
- 3. Disconnect the Front Impact Sensor connector.
- 4. Remove the Front Impact Sensor mounting nut.

#### Installation

#### 

- Do not turn the ignition switch ON and do not contact the battery cable while replacing the front impact sensor.
- 1. Install the new Front Impact Sensor.
- 2. Tighten the Front Impact Sensor mounting nut.

#### **Tightening torque**

:  $6.8 \sim 8.8$  Nm ( $0.7 \sim 0.9$  kgf.m,  $5.1 \sim 6.5$  lb.ft)

- 3. Connect the Front Impact Sensor connector and install the front bumper. (Refer to the Body group-Bumper)
- 4. Reconnect the battery negative cable.
- 5. After installing the Front Impact Sensor, confirm proper system operation:
  - Turn the ignition switch ON the SRS indicator light should be turned on for about six seconds and then go off.

SBHRT8702D

5. Remove the Front Impact Sensor.

# SRSCM

### Side Impact Sensor (SIS)

#### Description

The Side Impact Sensor (SIS) system consists of two front SIS which are installed in the center pillar (LH and RH) and two rear SIS which are installed in the rear pillar (LH and RH).

#### Components

They are remote sensors that detect acceleration due to collision at their mounting locations. The primary purpose of the Side Impact Sensor (SIS) is to provide an indication of a collision. The Side Impact Sensor (SIS) sends acceleration data to the SRSCM.



### **RT-21**

021-62999292

### 021-62999292

# **RT-22**

# Restraint

#### Removal

Front Side Impact Sensor

#### 

- Removal of the airbag must be performed according to the precautions/procedures described previously.
- Before disconnecting the side impact sensor connector(s), disconnect the side airbag connector (s).
- Do not turn the ignition switch ON and do not connect the battery cable while replacing the side impact sensor.
- 1. Disconnect the battery negative cable, and wait for at least three minutes before beginning work.
- 2. Remove the door scuff trim. (Refer to the Body group- Interior trim)
- 3. Remove the center pillar trim. (Refer to the Body group- Interior trim)
- 4. Disconnect the Side Impact Sensor connector and remove the Side Impact Sensor mounting bolt.

4Th

#### Rear Side Impact Sensor

- 1. Disconnect the battery negative cable and wait for at least three minutes before beginning work.
- 2. Remove the rear seat. (Refer to the Body group-Seat)
- 3. Remove the rear seat side back. (Refer to the Body group- Seat)
- 4. Disconnect the side impact sensor connector.
- 5. Loosen the side impact sensor mounting bolt and remove the side impact sensor.

SBHRT8752D

SBHRT8751D

# SRSCM

### Installation

Front Side Impact Sensor

### 

- Do not turn the ignition switch ON and do not connect the battery cable while replacing the side impact sensor.
- 1. Install the new Side Impact Sensor with the bolt then connect the SRS harness connector to the Side Impact Sensor.

#### Tightening torque

: 6.8  $\sim$  8.8 Nm (0.7  $\sim$  0.9 kgf.m, 5.1  $\sim$  6.5 lb.ft)

- 2. Install the center pillar trim. (Refer to the Body group-Interior trim)
- 3. Install the door scuff trim. (Refer to the Body group-Interior trim)
- 4. Reconnect the battery negative cable.
- 5. After installing the Side Impact Sensor, confirm proper system operation:
  - Turn the ignition switch ON, the SRS indicator light should be turned on for about six seconds and then go off.

### **Rear Side Impact Sensor**

#### 

- Do not turn the ignition switch ON and do not connect the battery cable while replacing the side impact sensor.
- 1. Install the new Side Impact Sensor with the bolt then connect the SRS harness connector to the Side Impact Sensor.

#### **Tightening torque**

: 6.8  $\sim$  8.8 Nm (0.7  $\sim$  0.9 kgf.m, 5.1  $\sim$  6.5 lb.ft)

- 2. Install the rear seat side back. (Refer to the Body group- Seat)
- 3. Install the rear seat . (Refer to the Body group- Seat)
- 4. Reconnect the battery negative cable.
- 5. After installing the Side Impact Sensor, confirm proper system operation:
  - Turn the ignition switch ON, the SRS indicator light should be turned on for about six seconds and then go off.

شرکت دیج<mark>یتال خودرو سامانه (مسئولیت محدود</mark>

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

**RT-24** 



SBHRT9025N

### 021-62999292

# Restraint

# SRSCM

Circuit Diagram (2)



SBHRT9026N

021-62999292

# RT-25

**RT-26** 

Circuit Diagram (3)



SBHRT9027N

# Restraint

# SRSCM

**SRSCM** Connector Terminal

**Harness Connector** 

6	5	4	3	2	1		10	9	8	7	6	5	4	3	2	1
12	11	10	9	8	7		20	19	18	17	16	15	14	13	12	11
18	17	16	15	14	13		30	29	28	27	26	25	24	23	22	21
24	23	22	21	20	19		40	39	38	37	36	35	34	33	32	31

CONNECTOR A

CONNECTOR B

Shorting bar (\_\_\_\_\_): located on the upper side of pin 1 and 2 of SRSCM connector A Note: For short circuit check, shorting bar must be opened. Use a plastic clip as a shorting bar opener for disconnecting shorting bar.

			SBHRT9011N
Pin	Function (Connector A)	Pin	Function (Connector B)
1	Airbag Warning Lamp	1	Curtain Airbag [Driver] Low
2	Ground	2	Curtain Airbag [Driver] High
3	(2nd stage) Driver Airbag Low	3	Side Airbag [Rear-Passenger] High
4	(2nd stage) Driver Airbag High	4	Side Airbag [Rear-Passenger] Low
5	(1st stage) Driver Airbag High	5	Side Airbag [Rear-Driver] Low
6	(1st stage) Driver Airbag Low	6	Side Airbag [Rear-Driver] High
7	- 00 0	7	Side Airbag [Front-Passenger] High
(8)	ستال خودر و سام <del>ا</del> نه (مسئولیت م	8	Side Airbag [Front-Passenger] Low
9	(2nd stage) Passenger Airbag Low	9	Seat Belt Pretensioner [Front-Passenger] Low
10	(2nd stage) Passenger Airbag High	Lol 10	Seat Belt Pretensioner [Front-Passenger] High
11	(1st stage) Passenger Airbag High	11	Curtain Airbag [Passenger] Low
12	(1st stage) Passenger Airbag Low	12	Curtain Airbag [Passenger] High
13	Crash Output	13	-
14	-	14	-
15	Front Impact Sensor [Driver] Low	15	-
16	Front Impact Sensor [Driver] High	16	-
17	Front Impact Sensor [Passenger] High	17	Seat Belt Pretensioner [Front-Driver] High
18	Front Impact Sensor [Passenger] Low	18	Seat Belt Pretensioner [Front-Driver] Low
19	-	19	Side Airbag [Front-Driver] Low
20	-	20	Side Airbag [Front-Driver] High
21	-	21	Side Impact Sensor [Rear-Driver] Low
22	K-Line Diagnostic	22	Side Impact Sensor [Rear-Driver]High
23	-	23	Side Impact Sensor [Rear-Passenger] High
24	Ignition	24	Side Impact Sensor [Rear-Passenger] Low
		25	-

# **RT-27**

### 021-62999292

### **RT-28**

### Restraint

Pin	Function (Connector A)	Pin	Function (Connector B)
		26	Side Impact Sensor [Front-Driver] High
		27	Side Impact Sensor [Front-Driver] Low
		28	Side Impact Sensor [Front-Passenger] Low
		29	Side Impact Sensor [Front-Passenger] High
		30	-
		31	-
		32	-
		33	-
		34	-
		35	-
		36	-
		37	-
		38	-
		39	-
		40	
Ч		<u>.</u> -	

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

# SRSCM

Diagnostic Trouble Code (DTC) Table

DTC	Fault Descriptions	Remark
B1101	Battery voltage high	
B1102	Battery voltage low	
B1326	Driver Side Front Impact Sensor Leakage to ground	
B1327	Driver Side Front Impact Sensor Leakage to battery	
B1328	Driver Side Front Impact Sensor Defect	
B1329	Driver Side Front Impact Sensor Communication Error	
B1330	Driver Side Front Impact Sensor Wrong ID	
B1331	Passenger Side Front Impact Sensor Leakage to ground	
B1332	Passenger Side Front Impact Sensor Leakage to battery	
B1333	Passenger Side Front Impact Sensor Defect	
B1334	Passenger Side Front Impact Sensor Communication Error	
B1335	Passenger Side Front Impact Sensor Wrong ID	
B1346	1st Stage Driver airbag Resistance too high (open)	
B1347	1st Stage Driver airbag Resistance too low (short)	
B1348	1st Stage Driver airbag Circuit leakage to ground	
B1349	1st Stage Driver airbag Circuit leakage to battery	
B1352	1st Stage Passenger airbag Resistance too high (open)	
B1353	1st Stage Passenger airbag Resistance too low (short)	
B1354	1st Stage Passenger airbag Circuit leakage to ground	
B1355	1st Stage Passenger airbag Circuit leakage to battery	
B1361	Pretensioner front-Driver Resistance too high (open)	
B1362	Pretensioner front-Driver Resistance too low (short)	
B1363	Pretensioner front-Driver Circuit leakage to ground	
B1364	Pretensioner front-Driver Circuit leakage to battery	
B1367	Pretensioner front-Passenger Resistance too high (open)	
B1368	Pretensioner front-Passenger Resistance too low (short)	
B1369	Pretensioner front-Passenger Circuit leakage to ground	
B1370	Pretensioner front-Passenger Circuit leakage to battery	
B1378	Side airbag front-driver Resistance too high (open)	
B1379	Side airbag front-driver Resistance too low (short)	
B1380	Side airbag front-driver Circuit leakage to ground	
B1381	Side airbag front-driver Circuit leakage to battery	
B1382	Side airbag front-passenger Resistance too high (open)	
B1383	Side airbag front-passenger Resistance too low (short)	

### 021-62999292

# **RT-29**

### 021-62999292

# **RT-30**

# Restraint

DTC	Fault Descriptions	Remark
B1384	Side airbag front-passenger Circuit leakage to ground	
B1385	Side airbag front-passenger Circuit leakage to battery	
B1395	Squib Cross coupling	
B1400	SIS front-driver defect	
B1401	SIS front-driver circuit short to ground	
B1402	SIS front-driver circuit short to battery	
B1403	SIS front-passenger defect	
B1404	SIS front-passenger circuit short to ground	
B1405	SIS front-passenger circuit short to battery	
B1409	SIS front-driver communication error	
B1410	SIS front-passenger communication error	
B1412	SIS rear-Driver communication error	
B1413	SIS rear-Passenger communication error	
B1414	SIS front-driver Wrong ID	
B1415	SIS front-passenger Wrong ID	
B1416	SIS rear-Driver Wrong ID	
B1417	SIS rear-Passenger Wrong ID	
B1418	SIS rear-Driver defect	
B1419	SIS rear-Passenger defect	
B1429	Side airbag rear-driver resistance too high	
B1430	Side airbag rear-driver resistance too low	
B1431	Side airbag rear-driver circuit short to ground	
B1432	Side airbag rear-driver circuit short to battery	
B1433	Side airbag rear-passenger resistance too high	
B1434	Side airbag rear-passenger t resistance too low	
B1435	Side airbag rear-passenger circuit short to ground	
B1436	Side airbag rear-passenger t circuit short to battery	
B1451	SIS rear-Driver circuit Short to Ground	
B1452	SIS rear-Driver circuit Short to Battery	
B1454	SIS rear-Driver circuit Short to Ground	
B1455	SIS rear-Passenger circuit Short to Battery	
B1473	Inflatable Curtain-driver Resistance too high (open)	
B1474	Inflatable Curtain-driver Resistance too low (short)	
B1475	Inflatable Curtain-driver Circuit leakage to ground	
B1476	Inflatable Curtain-driver Circuit leakage to battery	

### WWW.DIGITALKHODRO.COM

# SRSCM

# **RT-31**

DTC	Fault Descriptions	Remark
B1477	Inflatable Curtain-passenger Resistance too high (open)	
B1478	Inflatable Curtain-passenger Resistance too low (short)	
B1479	Inflatable Curtain-passenger Circuit leakage to ground	
B1480	Inflatable Curtain-passenger Circuit leakage to battery	
B1481	2nd Stage Driver airbag Resistance too high (open)	
B1482	2nd Stage Driver airbag Resistance too low (short)	
B1483	2nd Stage Driver airbag Circuit leakage to ground	
B1484	2nd Stage Driver airbag Circuit leakage to battery	
B1485	2nd Stage Passenger airbag Resistance too high (open)	
B1486	2nd Stage Passenger airbag Resistance too low (short)	
B1487	2nd Stage Passenger airbag Circuit leakage to ground	
B1488	2nd Stage Passenger airbag Circuit leakage to battery	
B1620	Internal fault - Replace ECU	
B1650	Crash recorded in 1st Stage only (Replace ACU)	
B1651	Crash recorded (Driver Side - Replace ACU)	
B1652	Crash recorded (Passenger Side - Replace ACU)	
B1670	Crash recorded in Full stage (Replace ACU)	
B2500	Warning lamp failure	

الین سامانه دیجیتال تعمیرکاران خودرو در ایران

# Restraint

### B1101 Battery Voltage High

#### **General Description**

SRSCM (Supplemental Restraints System Control Module) checks input voltage when "IG ON" to make air bag system work properly.

If input voltage is out of normal range, there can be malfunction in system operation. In this case, Check battery and charging system.

### DTC Detecting Condition

#### **DTC Description**

The SRSCM sets DTC B1101 and turns warning light on if voltage above threshold value is detected for more than 4 sec. (If voltage within threshold value is detected When the SRSCM returns to normal condition. SRSCM regards DTC as being cleared and turns warning light off).

lte	m	Detecting Condition	Possible cause
DTC Strategy		Check voltage	Poor connection of connected
Enable Conditions		Ignition "ON"	part.
Threshold Value		<ul> <li>Vbatt ≥ 16</li> </ul>	Open/Short circuit in power ha- rness.
Diagnostic	Qualificati- on	More than 4 sec	Open/Short circuit in ground harness.
Time	De-Qualifi- cation	More than 4 sec	<ul><li>Faulty charging system.</li><li>Faulty SRSCM.</li></ul>

#### Specification

Test Condition	Voltage
Idle & WOT	Approx. $9 \le Vbatt \le 16$
يتال خودرو شمنه استوتيت محدود	

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

# SRSCM

021-62999292

# RT-33

#### **Diagnostic Circuit Diagram**



#### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.



SBHRT9500L

#### 

- H : Historical fault
- P : Present fault

YES • Go to "W/Harness Inspection" procedure.

5. Is DTC present problem ?

▶ Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

▶ Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

### WWW.DIGITALKHODRO.COM

### 021-62999292

Restraint

# **RT-34**

#### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?



NO • Go to "Charging System Inspection" procedure.

### **Charging System Inspection**

- 1. Engine "ON", headight and heatwire "ON".
- 2. Measure voltage between the battery terminal (+) and (-) maintaining ENG. RPM 2,500RPM (idle) over 2 minutes.

**Specification :** Approx.  $9 \le \text{Vbatt} \le 16$ 

3. Is the measured voltage within specifications?

**YES** • Go to "Power Circuit Inspection" procedure.

NO Substitute with a known-good alternator and check for proper operation. If the problem is corrected, replace alternator and then go to "Verification of Vehicle Repair" procedure.

### Power Circuit Inspection

- 1. Ignition "OFF'.
- 2. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 3. Disconnect the SRSCM connector.
- 4. Connect the battery (-) terminal cable and start engine.
- 5. Measure voltage between power terminal of the SRSCM harness connector and chassis ground.

**Specification :** Approx.  $9 \le \text{Vbatt} \le 16$ 

- 6. Is the measured voltage within specifications?
- **YES •** Go to "Ground circuit inspection" procedure.
- ► Thoroughly check all connectors (and connections) for looseness, bending, corrosion, contamination, deterioration, and/or damage. Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

#### **Ground Circuit Inspection**

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 3. Disconnect the SRSCM connector.
- 4. Measure resistance between ground terminal of the SRSCM harness connector and chassis ground.

#### Specification : Approx. 1 $\Omega$ below.

5. Is the measured resistance within specifications?

- YES ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- NO Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?
- **YES** Go to the applicable troubleshooting procedure.
- NO ► System is performing to specification at this time.

# SRSCM

# B1102 Battery Voltage Low

### General Description

SRSCM (Supplemental Restraints System Control Module) checks input voltage when "IG ON" to make air bag system work properly.

If input voltage is out of normal range, there can be malfunction in system operation. In this case, Check battery and charging system.

#### **DTC Detecting Condition**

#### **DTC Description**

The SRSCM sets DTC B1102 and turns warning light on if voltage below threshold value is detected for more than 4 sec. (If voltage within threshold value is detected When the SRSCM returns to normal condition. SRSCM regards DTC as being cleared and turns warning light off).

Item		Detecting Condition		Possible cause	
DTC Strategy		•	Check voltage		Poor connection of connected
Enable Conditions		•	Ignition "ON"		part.
Threshold Value		•	Vbatt ≤ 9	<ul> <li>Open/Short circuit in power had rness.</li> </ul>	
Diagnostic Time	Qualificati- on	•	More than 4 sec	<ul> <li>Open/Short circuit in groun harness.</li> <li>Faulty charging system.</li> <li>Faulty SRSCM.</li> </ul>	
	De-Qualifi- cation	•	More than 4 sec		
Specifica	tion			-	0

Test Condition	Voltage
Idle & WOT	Approx. $9 \le V$ batt $\le 16$
عيتال خودرو شاماته (مستوتيت محدود)	

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



**RT-35** 

### Restraint

#### **Diagnostic Circuit Diagram**



#### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.



SBHRT9501L

- H : Historical fault
- P : Present fault

YES • Go to "W/Harness Inspection" procedure.

5. Is DTC present problem ?

▶ Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

▶ Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

### WWW.DIGITALKHODRO.COM

# SRSCM

#### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?



NO • Go to "Charging System Inspection" procedure.

#### **Charging System Inspection**

- 1. Engine "ON", headight and heatwire "ON".
- 2. Measure voltage between the battery terminal (+) and (-) maintaining ENG. RPM 2,500RPM (idle) over 2 minutes.

**Specification :** Approx.  $9 \le Vbatt \le 16$ 

3. Is the measured voltage within specifications?

**YES** • Go to "Power Circuit Inspection" procedure.

NO Substitute with a known-good alternator and check for proper operation. If the problem is corrected, replace alternator and then go to "Verification of Vehicle Repair" procedure.

#### Power Circuit Inspection

- 1. Ignition "OFF'.
- 2. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 3. Disconnect the SRSCM connector.
- 4. Connect the battery (-) terminal cable and start engine.
- 5. Measure voltage between power terminal of the SRSCM harness connector and chassis ground.

**Specification :** Approx.  $9 \le Vbatt \le 16$ 

- 6. Is the measured voltage within specifications?
- **YES** Go to "Ground circuit inspection" procedure.
- NO ► Thoroughly check all connectors (and connections) for looseness, bending, corrosion, contamination, deterioration, and/or damage. Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

#### **Ground Circuit Inspection**

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 3. Disconnect the SRSCM connector.
- 4. Measure resistance between ground terminal of the SRSCM harness connector and chassis ground.

#### Specification : Approx. 1 $\Omega$ below.

5. Is the measured resistance within specifications?

- YES ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- NO Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

#### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?
- **YES** Go to the applicable troubleshooting procedure.
- NO System is performing to specification at this time.

Restraint

### B1326 FIS(Front Impact Sensor)-Driver Short to Ground

#### **General Description**

Front Impact Sensor(FIS)located at both sides of the front of engine room detects head-on collision. When FIS delivers collision signal to SRSCM, SRSCM checks if safing sensor located in SRSCM detects collusion.

and if both FIS and safing sensor detects collision simultaneously, SRSCM operates front air bag.

#### **DTC Detecting Condition**

#### **DTC Description**

The SRSCM sets DTC B1326 if there is short to ground in DFIS harness.

Item		Detecting Condition		Possible cause				
DTC Strategy		•	Check voltage					
Enable Conditions		•	Ignition "ON"	1				
Threshold Value		•	DFIS no acceleration data, and line voltage < 3V	•	Short to ground in harness.			
Diagnostic Time	Qualificati- on	•	Ini(Start Up):2.1s (2 times) Steady:500µs x 8 + 2.2s (2 times)	•	Faulty DFIS. Faulty SRSCM.			
	De-Qualifi- cation	•	Ini(Start Up):1 time Steady:1 time					

#### Diagnostic Circuit Diagram



SBHRT9601L
## 021-62999292

**RT-39** 

## SRSCM

### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.

🛛 DT	C					
Eras	e All DTC	Freeze Frame	DTC Status	Ense Selective DTC		
	Description				State	
B1326	FIS-Driver short	to Ground				
				SE	BHRT95	02L
Q		CE				

- H : Historical fault

- P : Present fault

5. Is DTC present problem ?

- **YES** Go to "W/Harness Inspection" procedure.
- ▶ Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM

memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

► Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.
- NO ► Go to "Main harness circuit inspection" procedure.

### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 3. Disconnect DFIS connector and SRSCM main harness connector.
- 4. Measure resistance between terminal "FIS-Driver ( + )" or "FIS-Driver ( )" of the DFIS harness connector and chassis ground.

#### Specification : $^{\infty}$

- 5. Is the measured resistance within specifications?
- **YES •** Go to "Component Inspection" procedure.
- NO Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

### Component Inspection

- 1. Ignition "ON" & Engine "OFF" and Using a scan tool, clear the DTC.
- 2. Ignition "OFF".
- 3. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 4. Disconnect DFIS connector .
- 5. Substitute the DFIS and check for proper operation.
- 6. Is DTC present problem ?
- YES ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- **NO** Substitute a known-good DFIS, and check for proper operation.

If the problem is corrected, replace DFIS and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

Refer to the DTC B1101 : Battery Voltage High.

021-62999292

## Restraint

## B1327 FIS(Front Impact Sensor)-Driver Short to Battery

#### **General Description**

Front Impact Sensor(FIS)located at both sides of the front of engine room detects head-on collision. When FIS delivers collision signal to SRSCM, SRSCM checks if safing sensor located in SRSCM detects collusion.

and if both FIS and safing sensor detects collision simultaneously, SRSCM operates front air bag.

#### **DTC Detecting Condition**

#### **DTC Description**

The SRSCM sets DTC B1327 if there is short to power harness in DFIS harness.

Item			Detecting Condition		Possible cause
DTC S	trategy	•	Check voltage		
Enable Conditions		•	Ignition "ON"	Short to power in harness	
Threshold Value		•	DFIS no acceleration data, and line voltage >11V		
Diagnostic Time	Qualificati- on	•	Ini(Start Up):0.2s (100ms x 2) Steady:500µs x 8 + 2.2s (2 times)	].	Faulty DFIS. Faulty SRSCM.
	De-Qualifi- cation • Ini(Start Up):1 time • Steady:1 time				

#### Diagnostic Circuit Diagram



SBHRT9601L

# SRSCM

### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.

DT	C			
Ens	se All DTC Freeze Frame	DTC Status	Erase Selective DTC	
	Description			State
B1327	FIS-Driver short to Battery			
			SE	HRT9503
	<b>NOTICE</b> <i>H</i> : Historical fault			

- P : Present fault

5. Is DTC present problem ?

**YES** • Go to "W/Harness Inspection" procedure.

NO Displaying nothing(no DTC) or DTC with lab-

el "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

▶ Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

## **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?
- **YES** Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

NO ► Go to "Main harness circuit inspection" procedure.

## Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 3. Disconnect DFIS connector and SRSCM main harness connector.
- 4. Ignition "ON" & Engine "OFF"
- 5. Measure voltage between terminal "FIS-Driver ( + )" or "FIS-Driver ( - )" of the DFIS harness connector and chassis ground.

#### Specification: 0 V

- 6. Is the measured Voltage within specifications?
- **YES** Go to "Component Inspection" procedure.
- NO
   ▶ Substitute the SRSCM main harness and check for proper operation.
   If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

### **Component Inspection**

- Ignition "ON" & Engine "OFF" and Using a scan tool, clear the DTC.
- 2. Ignition "OFF".
- 3. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 4. Disconnect DFIS connector .
- 5. Substitute the DFIS and check for proper operation.
- 6. Is DTC present problem ?
- **YES** Substitute a known-good SRSCM, and check for proper operation.

If the problem is corrected, replace SRSCM and d then go to "Verification of Vehicle Repair" procedure.

► Substitute a known-good DFIS, and check for proper operation. If the problem is corrected, replace DFIS and then go to "Varification of Variation Density"

then go to "Verification of Vehicle Repair" procedure.

## Verification of Vehicle Repair

Refer to the DTC B1101 : Battery Voltage High.

## WWW.DIGITALKHODRO.COM

## 021- 62 99 92 92

## 021-62999292

## Restraint

## B1328 FIS(Front Impact Sensor)-Driver Defect

### **General Description**

Front Impact Sensor(FIS)located at both sides of the front of engine room detects head-on collision. When FIS delivers collision signal to SRSCM, SRSCM checks if safing sensor located in SRSCM detects collusion.

and if both FIS and safing sensor detects collision simultaneously, SRSCM operates front air bag.

### **DTC Detecting Condition**

#### **DTC Description**

The SRSCM sets DTC B1328 if there is any fault in Driver side front impact sensor.

	<u> </u>		
lte	em	Detecting Condition	Possible cause
DTC S	trategy	Check Data	
Enable Conditions		Ignition "ON"	
Thresho	ld Value	<ul><li>DFIS send defect code</li><li>DFIS output is not expected value</li></ul>	Poor connection of connected part.
Diagnostic	Qualificati- on	<ul> <li>Ini(Start Up):100 ms (500µs x 20)</li> <li>Steady:1s (10ms x 100)</li> </ul>	<ul><li>Faulty DFIS.</li><li>Faulty SRSCM.</li></ul>
Time	De-Qualifi- cation	<ul> <li>Ini(Start Up):IGN off -&gt; on</li> <li>Steady:IGN off -&gt; on</li> </ul>	

#### **Diagnostic Circuit Diagram**



SBHRT9601L

## 021-62999292

**RT-43** 

## SRSCM

### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.

DT 💈	TC					
Ere	se All DTC	Freeze Frame	DTC Status	Erase Selective DTC		
	Description				State	
B1328	DRIVER FIS DE	FECT				
				:	SBHRT95	04
	NOTIO	CE torical fault				

- P : Present fault

5. Is DTC present problem ?

**YES** • Go to "W/Harness Inspection" procedure.

NO Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

> Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

> ▶ Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.
- **NO** Go to "Component Inspection" procedure.

### **Component Inspection**

- 1. Ignition "ON" & Engine "OFF" and Using a scan tool, clear the DTC.
- 2. Ignition "OFF".
- 3. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 4. Disconnect DFIS connector .
- 5. Substitute the DFIS and check for proper operation.
- 6. Is DTC present problem ?
- YES Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM an-

d then go to "Verification of Vehicle Repair" procedur

Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

NO Substitute a known-good DFIS, and check for proper operation.

If the problem is corrected, replace DFIS and then go to "Verification of Vehicle Repair" procedure.

## Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?

**YES** • Go to the applicable troubleshooting procedure.

NO ► System is performing to specification at this time.

Restraint

021-62999292

### B1329 FIS(Front Impact Sensor)-Driver Communication error

#### **General Description**

Front Impact Sensor(FIS)located at both sides of the front of engine room detects head-on collision. When FIS delivers collision signal to SRSCM, SRSCM checks if safing sensor located in SRSCM detects collusion.

and if both FIS and safing sensor detects collision simultaneously, SRSCM operates front air bag.

#### **DTC Detecting Condition**

#### **DTC Description**

The SRSCM sets DTC B1329 if there is any error in communication between DFIS and SRSCM

				-	
Item		Detecting Condition			Possible cause
DTC S	trategy	Check Data			
Enable Conditions		Ignition "ON"			
Threshold Value		DFIS no accelerat een 3V and 11V)	ion data, and line voltage is ok (betw-		Poor connection of connected part.
Diagnostic	Qualificati- on	1 time			Faulty DFIS. Faulty SRSCM.
Time	De-Qualifi- cation	1 time			

#### Diagnostic Circuit Diagram



SBHRT9601L

## 021-62999292

**RT-45** 

## SRSCM

### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.

	DIC				
E	rase All DTC Freeze	Frame	DTC Status	Erase Selective DTC	
	Description				State
B1329	DRIVER FIS COMM. ERROR	2			
				SE	3HRT9505
	- H : Historica	l fault			
	- P : Present :	fault			
5.	Is DTC prese	nt proble	m ?		

**YES** • Go to "W/Harness Inspection" procedure.

NO ▷ Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

> Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

> Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.
- **NO •** Go to "Component Inspection" procedure.

### **Component Inspection**

- 1. Ignition "ON" & Engine "OFF" and Using a scan tool, clear the DTC.
- 2. Ignition "OFF".
- 3. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 4. Disconnect DFIS connector .
- 5. Substitute the DFIS and check for proper operation.
- 6. Is DTC present problem ?
- YES ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM an-

d then go to "Verification of Vehicle Repair" procedur

Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

NO Substitute a known-good DFIS, and check for proper operation.

If the problem is corrected, replace DFIS and then go to "Verification of Vehicle Repair" procedure.

## Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?

**YES** • Go to the applicable troubleshooting procedure.

NO ► System is performing to specification at this time.

### 021-62999292

## Restraint

## B1330 FIS(Front Impact Sensor)-Driver Wrong ID

#### **General Description**

Front Impact Sensor(FIS)located at both sides of the front of engine room detects head-on collision. When FIS delivers collision signal to SRSCM, SRSCM checks if safing sensor located in SRSCM detects collusion.

and if both FIS and safing sensor detects collision simultaneously, SRSCM operates front air bag.

#### **DTC Detecting Condition**

#### **DTC Description**

The SRSCM sets DTC B1330 if DFIS with wrong ID is detected

Item			Detecting Condition		Possible cause	
DTC S	trategy	•	Check Data			
Enable Conditions		•	Ignition "ON"			
Threshold Value		•	DFIS ID is different from programmed in ACU . Faulty DEIS w		Faulty DFIS with wrong ID.	
Diagnostic	Qualificati- on	•	1 time	•	Faulty SRSCM.	
Time	De-Qualifi- cation	•	1 time			

#### Diagnostic Circuit Diagram



SBHRT9601L

## 021-62999292

**RT-47** 

## SRSCM

### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.

🗧 D <sup>-</sup>	TC					
Ere	ise All DTC	Freeze Frame	DTC Status	Erase Selective DTO	;	
	Description				State	
B1330	FIS-Driver Wrong	I ID				
jāi						-
					SBHRT95	606
		CE				

- H : Historical fault

- P : Present fault

5. Is DTC present problem ?

**YES** • Go to "W/Harness Inspection" procedure.

NO ▷ Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

> Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

> ▶ Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

2. Thoroughly check shorting connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.
- **NO •** Go to "Component Inspection" procedure.

### **Component Inspection**

- 1. Ignition "ON" & Engine "OFF" and Using a scan tool, clear the DTC.
- 2. Ignition "OFF".
- 3. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 4. Disconnect DFIS connector .
- 5. Substitute the DFIS and check for proper operation.
- 6. Is DTC present problem ?
- YES Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM an-

d then go to "Verification of Vehicle Repair" procedur

Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

NO Substitute a known-good DFIS, and check for proper operation.

If the problem is corrected, replace DFIS and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?

**YES** • Go to the applicable troubleshooting procedure.

NO ► System is performing to specification at this time.

021- 62 99 92 92

## Restraint

## B1331 FIS(Front Impact Sensor)-Passenger Short to Ground

#### **General Description**

Front Impact Sensor(FIS)located at both sides of the front of engine room detects head-on collision. When FIS delivers collision signal to SRSCM, SRSCM checks if safing sensor located in SRSCM detects collusion.

and if both FIS and safing sensor detects collision simultaneously, SRSCM operates front air bag.

#### **DTC Detecting Condition**

#### **DTC Description**

The SRSCM sets DTC B1331 if there is short to ground in PFIS harness.

lte	m		Detecting Condition		Possible cause
DTC S	trategy	•	Check voltage		
Enable Conditions		•	Ignition "ON"	Short to ground in harness	
Threshold Value		•	PFIS no acceleration data, and line voltage < 3V		
Diagnostic	Qualificati- on	•	Ini(Start Up):2.1s (2 times) Steady:500µs x 8 + 2.2s (2 times)	]:	Faulty PFIS. Faulty SRSCM.
Time	De-Qualifi- cation	•	Ini(Start Up):1 time Steady:1 time		

#### Diagnostic Circuit Diagram



SBHRT9602L

## 021-62999292

RT-49

## SRSCM

### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.

	DTC					٥
	Erase All DTC	Freeze Frame	DTC Status	Erase Selective DTC		
	Description				State	
B133	FIS-Passenger	short to Ground				
				S	BHRT95	507l
	- H : His	torical fault				
	- P : Pre	esent fault				
5.	ls DTC p	present prot	olem ?			
Y	ES	Go to "W/H	arness Ins	pection" pro	ocedu	re.

▶ Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

> Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

> ▶ Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.
- NO ► Go to "Main harness circuit inspection" procedure.

### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 3. Disconnect PFIS connector and SRSCM main harness connector.
- 4. Measure resistance between terminal "FIS-Passenger ( + )" or "FIS-Passenger ( )" of the PFIS harness connector and chassis ground.

#### Specification : $^{\infty}$

- 5. Is the measured resistance within specifications?
- **YES •** Go to "Component Inspection" procedure.
- NO Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

### Component Inspection

- 1. Ignition "ON" & Engine "OFF" and Using a scan tool, clear the DTC.
- 2. Ignition "OFF".
- 3. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 4. Disconnect PFIS connector .
- 5. Substitute the PFIS and check for proper operation.
- 6. Is DTC present problem ?
- YES ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedur
- **NO** Substitute a known-good PFIS, and check for proper operation.

If the problem is corrected, replace PFIS and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

Refer to the DTC B1101 : Battery Voltage High.

## WWW.DIGITALKHODRO.COM

## 021-62999292

Restraint

## B1332 FIS(Front Impact Sensor)-Passenger Short to Battery

#### **General Description**

Front Impact Sensor(FIS)located at both sides of the front of engine room detects head-on collision. When FIS delivers collision signal to SRSCM, SRSCM checks if safing sensor located in SRSCM detects collusion.

and if both FIS and safing sensor detects collision simultaneously, SRSCM operates front air bag.

#### **DTC Detecting Condition**

#### **DTC Description**

The SRSCM sets DTC B1332 if there is short to power harness in PFIS harness.

ltem	Detecting Condition	Possible cause
DTC Strategy	Check voltage	
Enable Conditions	Ignition "ON"	
Threshold Value	PFIS no acceleration data, and line voltage >11V	Short to power in harness.
Qualifica Diagnostic on	<ul> <li>i- Ini(Start Up):0.2s (100ms x 2)</li> <li>Steady:500µs x 8 + 2.2s (2 times)</li> </ul>	<ul><li>Faulty PFIS.</li><li>Faulty SRSCM.</li></ul>
Time De-Qual cation	<ul> <li>i- Ini(Start Up):1 time</li> <li>Steady:1 time</li> </ul>	
Trouble Codes(D	nect scantool. ngine "OFF", select "Diagnostic C)" mode. trouble code and present of clear the DTC.	problem ? 'W/Harness Inspection" procedure. ing nothing(no DTC) or DTC with lab orical) shows that Fault is intermitten poor contact in the part's and/or SR nector or was repaired and SRSCM ras not cleared. y check connectors for looseness, ection, bending, corrosion, contamin erioration, or damage. or replace as necessary and then gr ation of Vehicle Repair" procedure.

## WWW.DIGITALKHODRO.COM

### 021-62999292

## 021-62999292

**RT-51** 

## SRSCM

#### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?
- **YES** Repair as necessary and then go to "Verification of Vehicle Repair" procedure.
- NO ► Go to "Main harness circuit inspection" procedure.

### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 3. Disconnect PFIS connector and SRSCM main harness connector.
- 4. Ignition "ON" & Engine "OFF"
- Measure voltage between terminal "FIS-Passenger (+)" or "FIS-Passenger (-)" of the PFIS harness connector and chassis ground.

#### Specification : 0V

- 6. Is the measured Voltage within specifications?
- **YES** Go to "Component Inspection" procedure.
- NO ► Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

### **Component Inspection**

- 1. Ignition "ON" & Engine "OFF" and Using a scan tool, clear the DTC.
- 2. Ignition "OFF".
- 3. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 4. Disconnect PFIS connector .
- 5. Substitute the PFIS and check for proper operation.
- 6. Is DTC present problem ?
- YES ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedur
- NO ► Substitute a known-good PFIS, and check for proper operation. If the problem is corrected, replace PFIS and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?
- **YES** Go to the applicable troubleshooting procedure.
- NO ► System is performing to specification at this time.

## 021- 62 99 92 92

## Restraint

## B1333 FIS(Front Impact Sensor)-Passenger Defect

#### **General Description**

Front Impact Sensor(FIS)located at both sides of the front of engine room detects head-on collision. When FIS delivers collision signal to SRSCM, SRSCM checks if safing sensor located in SRSCM detects collusion.

and if both FIS and safing sensor detects collision simultaneously, SRSCM operates front air bag.

#### **DTC Detecting Condition**

#### **DTC Description**

The SRSCM sets DTC B1333 if there is any fault in Passenger side front impact sensor

of o Beleeting condition				
Item		Detecting Condition	Possible cause	
DTC Strategy		Check Data		
Enable Conditions		Ignition "ON"		
Threshold Value		<ul><li>PFIS send defect code</li><li>PFIS output is not expected value</li></ul>	Poor connection of connected part.	
Diagnostic	Qualificati- on	<ul> <li>Ini(Start Up):100 ms (500µs x 20)</li> <li>Steady:1s (10ms x 100)</li> </ul>	<ul><li>Faulty PFIS.</li><li>Faulty SRSCM.</li></ul>	
Time	De-Qualifi- cation	<ul> <li>Ini(Start Up):IGN off -&gt; on</li> <li>Steady:IGN off -&gt; on</li> </ul>	0	

#### **Diagnostic Circuit Diagram**



SBHRT9602L

## 021-62999292

**RT-53** 

## SRSCM

### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.

D1	DTC				
Era	ise All DTC	Freeze Frame	DTC Status	Erase Selective DTC	
	Description				State
B1333	PASS. FIS DEFE	ECT			
				SE	HRT9509
- (	ΔΝΟΤΙΟ	E			

- H : Historical fault

- P : Present fault

5. Is DTC present problem ?

**YES** • Go to "W/Harness Inspection" procedure.

NO ▷ Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

> Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

> ▶ Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

#### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.
- **NO** Go to "Component Inspection" procedure.

#### **Component Inspection**

- 1. Ignition "ON" & Engine "OFF" and Using a scan tool, clear the DTC.
- 2. Ignition "OFF".
- 3. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 4. Disconnect PFIS connector .
- 5. Substitute the PFIS and check for proper operation.
- 6. Is DTC present problem ?
- YES ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM an-

d then go to "Verification of Vehicle Repair" procedur

Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

NO Substitute a known-good PFIS, and check for proper operation.

If the problem is corrected, replace PFIS and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?

**YES** • Go to the applicable troubleshooting procedure.

NO ► System is performing to specification at this time.

## Restraint

021-62999292

### B1334 FIS(Front Impact Sensor)-Passenger Communication error

#### **General Description**

Front Impact Sensor(FIS)located at both sides of the front of engine room detects head-on collision. When FIS delivers collision signal to SRSCM, SRSCM checks if safing sensor located in SRSCM detects collusion.

and if both FIS and safing sensor detects collision simultaneously, SRSCM operates front air bag.

#### **DTC Detecting Condition**

#### **DTC Description**

The SRSCM sets DTC B1334 if there is any error in communication between PFIS and SRSCM

lte	Item		Detecting Condition		Possible cause
DTC Strategy		•	Check Data		
Enable C	onditions	•	Ignition "ON"		
Threshold Value		•	PFIS no acceleration data, and line voltage is ok (betw- een 3V and 11V)	•	Poor connection of connected part.
Diagnostic	Qualificati- on	•	1 time	•	Faulty PFIS. Faulty SRSCM.
Time	De-Qualifi- cation	•	1 time		0

#### Diagnostic Circuit Diagram



SBHRT9602L

## 021-62999292

**RT-55** 

## SRSCM

### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.

<b>D</b>	ſĊ				
En	ise All DTC Freeze	Frame	DTC Status	Ense Selective DTC	
	Description				State
B1334	PASS. FIS COMM. ERROR				
				<u></u>	
				SE	3HRT9510
l					
	H: Historica	l fault			
- (	P : Present f	ault			
5. I	s DTC preser	nt proble	m ?		
Y	S 🕨 Go to	"W/Har	ness Insp	pection" pro	cedure
1	ogsen c		mo) a	Junig	

▶ Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

▶ Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.
- **NO •** Go to "Component Inspection" procedure.

### **Component Inspection**

- 1. Ignition "ON" & Engine "OFF" and Using a scan tool, clear the DTC.
- 2. Ignition "OFF".
- 3. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 4. Disconnect PFIS connector .
- 5. Substitute the PFIS and check for proper operation.
- 6. Is DTC present problem ?
- YES ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM an-

d then go to "Verification of Vehicle Repair" procedur

Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

NO Substitute a known-good PFIS, and check for proper operation.

If the problem is corrected, replace PFIS and then go to "Verification of Vehicle Repair" procedure.

## Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?

**YES** • Go to the applicable troubleshooting procedure.

NO ► System is performing to specification at this time.

## Restraint

## B1335 FIS(Front Impact Sensor)-Passenger Wrong ID

#### **General Description**

Front Impact Sensor(FIS)located at both sides of the front of engine room detects head-on collision. When FIS delivers collision signal to SRSCM, SRSCM checks if safing sensor located in SRSCM detects collusion.

and if both FIS and safing sensor detects collision simultaneously, SRSCM operates front air bag.

#### **DTC Detecting Condition**

#### **DTC Description**

The SRSCM sets DTC B1335 if PFIS with wrong ID is detected.

ltei	m	Detecting Condition	Possible cause
DTC Strategy		Check Data	
Enable Conditions		Ignition "ON"	
Threshol	d Value	PFIS ID is different from programmed in ACU	Faulty PFIS with wrong ID.
Diagnostic	Qualificati- on	• 1 time	<ul> <li>Faulty SRSCM.</li> </ul>
Time	De-Qualifi- cation	• 1 time	
<ul> <li>Ignition ' Trouble C</li> <li>Monitor trouble cc</li> <li>Using a s</li> <li>DTC</li> <li>Erase AIIDTC</li> <li>Description</li> <li>B1335 FIS-Passenger W</li> </ul>	OFF", conne "ON"& Eng Codes(DTC) diagnostic ode. scan tool, cla frees frame	ect scantool.       Image: Select "Diagnostic"         ine "OFF", select "Diagnostic"       Image: Select "Diagnostic"         imode.       Image: Select "Diagnostic"         trouble code and present of       Image: Displaying el "H"(history caused by post connection of the present of the prese	WHarness Inspection" procedure. Ing nothing(no DTC) or DTC with laterical) shows that Fault is intermitter poor contact in the part's and/or SF ector or was repaired and SRSCI s not cleared. check connectors for looseness, ction, bending, corrosion, contamir ioration, or damage. r replace as necessary and then g ion of Vehicle Repair" procedure.

## 021-62999292

**RT-57** 

## SRSCM

#### Terminal and Connector Inspection

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination. deterioration, or damage.
- 3. Has a problem been found?



**NO** • Go to "Component Inspection" procedure.

### Component Inspection

- 1. Ignition "ON" & Engine "OFF" and Using a scan tool, clear the DTC.
- 2. Ignition "OFF".
- 3. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 4. Disconnect PFIS connector .
- 5. Substitute the PFIS and check for proper operation.
- 6. Is DTC present problem ?
- YES Substitute a known-good SRSCM, and check for proper operation.

If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedur

Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

**NO** Substitute a known-good PFIS, and check for proper operation.

If the problem is corrected, replace PFIS and then go to "Verification of Vehicle Repair" procedure.

#### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?
- YES Go to the applicable troubleshooting procedure.
- NO System is performing to specification at this time.





## Restraint

## B1346 Driver Airbag Resistance too High (1st stage)

#### General Description

Driver Air bag module (hereinafter referred to DAB) located at center of steering wheel protects driver by reducing impact of collision.DAB is consist of air bag, pat cover and two inflator.

There are power, circuit for ignition, gas generator and diffuser screen in inflator.

Air bag reduces impact of collision by fillied up gas.

In collision, pat cover splits and through this crack, air bag emerges and deploys.

Inflator generates gas that expands air bag.

Clock spring is located between steering wheel and column. It connects SCSRM to DAB.

#### 

Never measure resistance of DAB directly, Current of measuring device may cause unexpected air bag deploy.

#### DTC Detecting Condition

#### **DTC Description**

The SRSCM sets DTC B1346 if the measured resistance value of DAB circuit is more than the threshold value.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

Item		Detecting Condition	Possible cause
DTC Strategy		Check Resistance	
Enable Conditions		Ignition "ON"	Poor connection of connected part.
Threshold Value		• DAB 1st stage Squib resistance $\geq 6.4\Omega$	Poor connection between shor-
Diagnostic	Qualificati- on	• More than 2.5s (250ms x 10)	<ul> <li>ting bar and release pin.</li> <li>Faulty DAB.</li> <li>Faulty Clock spring.</li> </ul>
Time	De-Qualifi- cation	• More than 5s	Faulty SRSCM.

#### Specification

Test Condition	Resistance
Ignition ON	$1.4\Omega \le$ Squib resistance $\le 6.4\Omega$

## 021-62999292

## SRSCM

**RT-59** 

### **Diagnostic Circuit Diagram**



## 021-62999292

Restraint

## **RT-60**

3. Has a problem been found?



YES 

 Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO** • Go to "Squib Circuit Inspection" procedure.

#### Squib Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Remove the DAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-2G000) to DAB connector of the clock spring harness connector.

#### **WNOTICE**

If dummy and dummy adaptor are not able to be prepared, use a known-good DAB or  $2\Omega$  resistor.

#### WARNING

Lay Removed DAB facing upward for unexpected air bag deploy.

- 4. Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?
- YES Go to "Clock Spring Circuit Inspection" procedure.
- **NO** Substitute a known-good DAB assembly, and check for proper operation.

If the problem is corrected, replace DAB and then go to "Verification of Vehicle Repair" procedure.

### **Clock Spring Circuit Inspection**

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Remove DAB module and disconnect SRSCM connector of the clock spring harness.

#### 

Lay Removed DAB facing upward for unexpected air bag deploy .

4. Measure resistance between terminal "Low.1" and "High.1" of the Clock Spring harness connector.

**Specification :** approx. 1 Ω below

- 5. Is the measured resistance within specifications?
- YES 
  Go to "Main harness circuit inspection" procedure.
- NO Substitute the Clock spring and check for proper operation. If the problem is corrected, replace Clock spring and then go to "Verification of Vehicle Repair procedure.

#### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Remove DAB module and disconnect SRSCM connector of the clock spring harness.

#### 

Lay Removed DAB facing upward for unexpected air bag deploy.

4. Measure resistance between terminal "Low.1" and "High.1" of the DAB harness connector.

Specification : approx. 1  $\Omega$  below

- 5. Is the measured resistance within specifications?
- Substitute a known-good SRSCM, and chec-YES k for proper operation.

If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.

Substitute the SRSCM main harness and NO check for proper operation. If the problem is corrected, replace SRSCM

main harness and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

Refer to the DTC B1101 : Battery Voltage High.

## SRSCM

## **RT-61**

## B1347 Driver Airbag Resistance too Low (1st stage)

#### **General Description**

Driver Air bag module (hereinafter referred to DAB) located at center of steering wheel protects driver by reducing impact of collision.

DAB is consist of air bag, pat cover and two inflator.

There are power, circuit for ignition, gas generator and diffuser screen in inflator.

Air bag reduces impact of collision by fillied up gas.

In collision, pat cover splits and through this crack, air bag emerges and deploys.

Inflator generates gas that expands air bag.

Clock spring is located between steering wheel and column. It connects SCSRM to DAB.

#### 

Never measure resistance of DAB directly, Current of measuring device may cause unexpected air bag deploy.

## DTC Detecting Condition

#### **DTC Description**

The SRSCM sets DTC B1347 if the measured resistance value of DAB circuit is less than the threshold value( $1.0\Omega$ )\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

Ite	m	Detecting Condition	Possible cause
DTC Strategy		Check Resistance	
Enable Conditions		شرکت دیجیتان خودرو ۳۵N" Ignition	<ul> <li>Poor connection of connected part.</li> </ul>
Thresho	ld Value	• DAB 1st stage Squib resistance $\leq 1.4\Omega$	Poor connection between shor-
Diagnostic	Qualificati- on	• More than 2.5s (250ms x 10)	<ul> <li>ting bar and release pin.</li> <li>Faulty DAB.</li> <li>Faulty Clock spring.</li> </ul>
Time	De-Qualifi- cation	More than 5s	Faulty SRSCM.

#### Specification

Test Condition	Resistance
Ignition ON	$1.4\Omega \le$ Squib resistance $\le 6.4\Omega$

# 021- 62 99 92 92

## **RT-62**

## Restraint

### **Diagnostic Circuit Diagram**



### WWW.DIGITALKHODRO.COM

#### 021-62999292

## 021-62999292

RT-63

## SRSCM

3. Has a problem been found?



YES 

 Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO** • Go to "Squib Circuit Inspection" procedure.

### Squib Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Remove the DAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-2G000) to DAB connector of the clock spring harness connector.

### 

If dummy and dummy adaptor are not able to be prepared, use a known-good DAB or  $2\Omega$  resistor.

#### 

Lay Removed DAB facing upward for unexpected air bag deploy .

- 4. Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?
- YES 
  Go to "Clock Spring Circuit Inspection" procedure.
- **NO** Substitute a known-good DAB assembly, and check for proper operation.

If the problem is corrected, replace DAB and then go to "Verification of Vehicle Repair" procedure.

### **Clock Spring Circuit Inspection**

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- module and disconnect SRSCM 3. Remove DAB connector of the clock spring harness.

#### 

Lay Removed DAB facing upward for unexpected air bag deploy .

4. Measure resistance between terminal "Low.1" and "High.1" of the Clock Spring harness connector.

**Specification :** approx. 1  $\Omega$  below

- 5. Is the measured resistance within specifications?
- YES 
  Go to "Main harness circuit inspection" procedure.
- NO Substitute the Clock spring and check for proper operation. If the problem is corrected, replace Clock spring and then go to "Verification of Vehicle Repair procedure.

#### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- module and disconnect SRSCM 3. Remove DAB connector of the clock spring harness.

#### 

Lay Removed DAB facing upward for unexpected air bag deploy.

4. Measure resistance between terminal "Low.1" and "High.1" of the DAB harness connector.

Specification : approx. 1 Ω below

5. Is the measured resistance within specifications?

Substitute a known-good SRSCM, and chec-YES k for proper operation.

> If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.

**NO** Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

Refer to the DTC B1101 : Battery Voltage High.

## Restraint

021-62999292

## B1348 Driver Airbag resistance circuit short to Ground (1st stage)

#### **General Description**

**RT-64** 

Driver Air bag module (hereinafter referred to DAB) located at center of steering wheel protects driver by reducing impact of collision.

DAB is consist of air bag, pat cover and two inflator.

There are power, circuit for ignition, gas generator and diffuser screen in inflator.

Air bag reduces impact of collision by fillied up gas.

In collision, pat cover splits and through this crack, air bag emerges and deploys.

Inflator generates gas that expands air bag.Clock spring is located between steering wheel and column.

It connects SCSRM to DAB.

#### 

Never measure resistance of DAB directly, Current of measuring device may cause unexpected air bag deploy. 

#### DTC Detecting Condition

#### **DTC Description**

The SRSCM sets DTC B1348 if there is a short to ground in DAB harness

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while

Ite	m	Detecting Condition	Possible cause
DTC Strategy		Check Voltage	
Enable Conditions		• Ignition "ON" مودرو	• Short to ground in DAB harnes- s.
Threshold Value		<ul> <li>DAB 1st stage Squib line Voltage is &lt; 0.9V</li> </ul>	Poor connection of connected
Diagnostic on Time De-Qual	Qualificati- on	• More than 2.5s (250ms x 10)	<ul> <li>Part.</li> <li>Faulty DAB.</li> <li>Faulty Clock spring.</li> </ul>
	De-Qualifi- cation	More than 5s	Faulty SRSCM.

#### Specification

Test Condition	Voltage
Ignition ON	$0.9V \le Squib line Voltage \le 2.9V$

## 021-62999292

## SRSCM

**RT-65** 

#### **Diagnostic Circuit Diagram**



Restraint

021-62999292

## **RT-66**

3. Has a problem been found?



YES 

 Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO** • Go to "Squib Circuit Inspection" procedure.

#### Squib Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Remove the DAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-2G000) to DAB connector of the clock spring harness connector.

#### 

If dummy and dummy adaptor are not able to be prepared, use a known-good DAB or  $2\Omega$  resistor.

#### 

Lay Removed DAB facing upward for unexpected air bag deploy .

- 4. Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?
- YES 
  Go to "Clock Spring Circuit Inspection" procedure.
- **NO** Substitute a known-good DAB assembly, and check for proper operation. If the problem is corrected, replace DAB and

then go to "Verification of Vehicle Repair" procedure.

#### **Clock Spring Circuit Inspection**

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- module and disconnect SRSCM 3. Remove DAB connector of the clock spring harness.

#### 

Lay Removed DAB facing upward for unexpected air bag deploy .

4. Measure resistance between terminal "Low.1" or "High.1" of the clock spring harness connector and chassis ground.

#### Specification : $\infty$

- 5. Is the measured resistance within specifications?
- YES > Go to "Main harness circuit inspection" procedure.
- Substitute the Clock spring and check for pr-NO oper operation. If the problem is corrected, replace Clock sprin-

g and then go to "Verification of Vehicle Repair " procedure.

#### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- module and disconnect SRSCM 3. Remove DAB connector of the clock spring harness.

#### 

Lay Removed DAB facing upward for unexpected air bag deploy.

4. Measure resistance between terminal "Low.1" or "High.1" of the DAB harness connector and chassis ground.

#### Specification : ∞

- 5. Is the measured resistance within specifications?
- **YES** > Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- Substitute the SRSCM main harness and NO check for proper operation. If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

#### Verification of Vehicle Repair

Refer to the DTC B1101 : Battery Voltage High.

## SRSCM

## **RT-67**

## B1349 Driver Airbag resistance circuit short to Battery (1st stage)

#### General Description

Driver Air bag module (hereinafter referred to DAB) located at center of steering wheel protects driver by reducing impact of collision.

DAB is consist of air bag, pat cover and two inflator.

There are power, circuit for ignition, gas generator and diffuser screen in inflator.

Air bag reduces impact of collision by fillied up gas.

In collision, pat cover splits and through this crack, air bag emerges and deploys.

Inflator generates gas that expands air bag.

Clock spring is located between steering wheel and column. It connects SCSRM to DAB.

#### 

Never measure resistance of DAB directly, Current of measuring device may cause unexpected air bag deploy.

#### DTC Detecting Condition

#### **DTC Description**

The SRSCM sets DTC B1349 if there is a short to power in DAB harness

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

Item		Detecting Condition	Possible cause
DTC Strategy		Check Resistance	
Enable Conditions		Ignition "ON"	• Short to power in DAB harness
Threshold Value		DAB 1st stage Squib line voltage is > 2.9V	Poor connection of connected
Diagnostic	Qualificati- on	• More than 2.5s (250ms x 10)	<ul> <li>part.</li> <li>Faulty DAB.</li> <li>Faulty Clock spring.</li> </ul>
	De-Qualifi- cation	• More than 5s	Faulty SRSCM.

#### Specification

Test Condition	Voltage
Ignition ON	$0.9V \le Squib line Voltage \le 2.9V$

## Restraint

021-62999292

#### **Diagnostic Circuit Diagram**

**RT-68** 



## WWW.DIGITALKHODRO.COM

### 021-62999292

## 021-62999292

RT-69

## SRSCM

3. Has a problem been found?



YES 

 Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO** • Go to "Squib Circuit Inspection" procedure.

#### Squib Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Remove the DAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-2G000) to DAB connector of the clock spring harness connector.

#### 

If dummy and dummy adaptor are not able to be prepared, use a known-good DAB or  $2\Omega$  resistor.

#### 

Lay Removed DAB facing upward for unexpected air bag deploy .

- 4. Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?
- YES 
  Go to "Clock Spring Circuit Inspection" procedure.
- **NO** Substitute a known-good DAB assembly, and check for proper operation.

If the problem is corrected, replace DAB and then go to "Verification of Vehicle Repair" procedure.

#### **Clock Spring Circuit Inspection**

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Remove DAB module and disconnect SRSCM connector of the clock spring harness.

#### 

Lay Removed DAB facing upward for unexpected air bag deploy .

4. Connect the battery (-) terminal cable to the battery and Ignition "ON" & Engine "OFF".

5. Measure Voltage between terminal "Low.1" or "High.1" of the clock spring harness connector and chassis ground.

#### Specification: 0V

- 6. Is the measured resistance within specifications?
- YES > Go to "Main harness circuit inspection" procedure.
- Substitute the Clock spring and check for pr-NO oper operation. If the problem is corrected, replace Clock sprin-

g and then go to "Verification of Vehicle Repair " procedure.

#### Main harness Circuit Inspection

- 1. Ignition "OFF" and wait at least one minutes.
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Remove DAB module and disconnect SRSCM connector of the main harness.
- 4. Connect the battery (-) terminal cable to the battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.

#### 

Lay Removed DAB facing upward for unexpected air bag deploy.

5. Measure voltage between terminal "Low.1" or "High. 1" of the DAB harness connector and chassis ground.

Specification : approx. 0V

- 6. Is the measured voltage within specifications?
- Substitute a known-good SRSCM, and chec-YES k for proper operation.

If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.

NO Substitute the SRSCM main harness and check for proper operation. If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

#### Verification of Vehicle Repair

Refer to the DTC B1101 : Battery Voltage High.

## WWW.DIGITALKHODRO.COM

021-62999292

## Restraint

## B1352 Passenger Airbag Resistance too High (1st Stage)

#### **General Description**

Passenger Air bag module (hereinafter referred to PAB) located at passenger side crush pad protects passenger by reducing impact of collision.

PAB is consist of air bag, pat cover and inflator.

Air bag reduces impact of collision by fillied up gas.

Inflator keeps gas and uses it to deploy air bag on collision.

#### 

Never measure resistance of PAB directly, Current of measuring device may cause unexpected air bag deploy.

Ignition ON

#### **DTC Description**

The SRSCM sets DTC B1352 if the measured resistance value of PAB circuit is more than the threshold value.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while

 $1.4\Omega \leq$  Squib resistance  $\leq 6.4\Omega$ 

#### **DTC Detecting Condition**

lte	Item Detecting Condition		Possible cause
DTC S	trategy	Check Resistance	
Enable Conditions		Ignition "ON"	<ul> <li>Poor connection of connected part.</li> <li>Poor connection between shor-</li> </ul>
Threshold Value		• PAB 1st stage Squib resistance $\geq 6.4\Omega$	
Diagnostic Time	Qualificati- on	• More than 2.5s (250ms x 10)	<ul> <li>Faulty PAB.</li> <li>Faulty SRSCM.</li> </ul>
	De-Qualifi- cation	شرکت دیجیتال خودرو هMore than 5s	
Specificat	tion	اوليجساوانه درجيتال يتعمى كاياديد	
Test Condition		est Condition	Resistance

## 021- 62 99 92 92

## SRSCM

**RT-71** 

### **Diagnostic Circuit Diagram**



### WWW.DIGITALKHODRO.COM

Restraint

## **RT-72**

### Terminal and Connector Inspection

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

YES 

 Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO** • Go to "Squib Circuit Inspection" procedure.

### Squib Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Remove the PAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-2E100) to PAB harness connector.

**WNOTICE** 

If dummy and dummy adaptor are not able to be prepared, use a known-good PAB or  $2\Omega$  resistor.

#### 

Lay Removed PAB facing upward for unexpected air bag deploy.

- 4. Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?



**YES** • Go to "Main harness circuit inspection" procedure.

NO Substitute a known-good PAB assembly, and check for proper operation.

If the problem is corrected, replace PAB and then go to "Verification of Vehicle Repair" procedure.

### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect PAB connector and SRSCM main harness connector.

#### 

Lay Removed PAB facing upward for unexpected air bag deploy .

4. Measure resistance between terminal "Low.1" and "High.1" of the PAB harness connector.

Specification : approx. 1 Ω below

- 5. Is the measured resistance within specifications?
- YES 

   Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- Substitute the SRSCM main harness and NO check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present?
- **YES** Go to the applicable troubleshooting procedure.
- System is performing to specification at this NO time.

## SRSCM

## **RT-73**

## B1353 Passenger Airbag Resistance too Low (1st stage)

#### **General Description**

Passenger Air bag module (hereinafter referred to PAB) located at passenger side crush pad protects passenger by reducing impact of collision.

PAB is consist of air bag, pat cover and inflator.

Air bag reduces impact of collision by fillied up gas.

Inflator keeps gas and uses it to deploy air bag on collision.

#### 

Never measure resistance of PAB directly, Current of measuring device may cause unexpected air bag deploy.

Ignition ON

#### **DTC Description**

The SRSCM sets DTC B1353 if the measured resistance value of PAB circuit is less than the threshold value.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

 $1.4\Omega \leq$  Squib resistance  $\leq 6.4\Omega$ 

#### **DTC Detecting Condition**

lte	m	Detecting Condition		Possible cause	
DTC S	trategy	Check Resistance		Poor connection of connected	
Enable Conditions •		Ignition "ON"			
Threshold Value		• PAB 1st stage Squib resistance $\leq$	1.4Ω	<ul> <li>part.</li> <li>Poor connection between shor-</li> </ul>	
Diagnostic	Qualificati- on	• More than 2.5s (250ms x 10)	ů D a	<ul> <li>Faulty PAB.</li> <li>Faulty SRSCM.</li> </ul>	
	De-Qualifi- cation	• More than 5s جيتال خودرو	شرکت دی		
Sp <mark>ecifica</mark>	tion	يانه در ميتال تعميركارانيم	Intrudel		
Test Condition		Ch St	Resistance		

Restraint

#### **Diagnostic Circuit Diagram**



### WWW.DIGITALKHODRO.COM
# SRSCM

### Terminal and Connector Inspection

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

YES 

 Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO** • Go to "Squib Circuit Inspection" procedure.

### Squib Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Remove the PAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-2E100) to PAB harness connector.

**WNOTICE** 

If dummy and dummy adaptor are not able to be prepared, use a known-good PAB or  $2\Omega$  resistor.

### 

Lay Removed PAB facing upward for unexpected air bag deploy.

- 4. Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?



**YES** • Go to "Main harness circuit inspection" procedure.

NO Substitute a known-good PAB assembly, and check for proper operation.

> If the problem is corrected, replace PAB and then go to "Verification of Vehicle Repair" procedure.

### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect PAB connector and SRSCM main harness connector.

#### 

Lay Removed PAB facing upward for unexpected air bag deploy .

4. Measure resistance between terminal "Low.1" and "High.1" of the PAB harness connector.

Specification : approx. 1 Ω below

- 5. Is the measured resistance within specifications?
- YES 

   Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- Substitute the SRSCM main harness and NO check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present?
- **YES** Go to the applicable troubleshooting procedure.
- System is performing to specification at this NO time.

# 021-62999292

# **RT-76**

# Restraint

# B1354 Passenger Airbag Resistance Circuit Short to Ground (1st Stage)

### **General Description**

Passenger Air bag module (hereinafter referred to PAB) located at passenger side crush pad protects passenger by reducing impact of collision.

PAB is consist of air bag, pat cover and inflator.

Air bag reduces impact of collision by fillied up gas.

Inflator keeps gas and uses it to deploy air bag on collision.

# 

Never measure resistance of PAB directly, Current of measuring device may cause unexpected air bag deploy.

# **DTC Description**

The SRSCM sets DTC B1354 if there is a short to ground in PAB harness

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

### **DTC Detecting Condition**

Item		Detecting Cond	tion Possible cau	se
DTC Strategy		Check Resistance		
Enable Conditions		Ignition "ON"	Short to ground in P	AB harnes-
Threshold Value		PAB 1st stage Squib line Voltage	is < 0.9V s. • Poor connection of	connected
Diagnostic Time	Qualificati- on	• More than 2.5s (250ms x 10)	part. <ul> <li>Faulty PAB.</li> </ul>	
	De-Qualifi- cation	• More than 5s 9295	Faulty SRSCM.	
Specifica	tion	نهديد ميتال تعميركا باين خ		
Test Condition			Voltage	
Ignition ON		Ignition ON	$0.9V \le Squib line Voltage \le 2.9V$	

# 021- 62 99 92 92

# SRSCM

**RT-77** 

### **Diagnostic Circuit Diagram**



# WWW.DIGITALKHODRO.COM

Restraint

# **RT-78**

### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

NO • Go to "Squib Circuit Inspection" procedure.

### Squib Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Remove the PAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-2E100) to PAB harness connector.

**WNOTICE** 

If dummy and dummy adaptor are not able to be prepared, use a known-good PAB or  $2\Omega$  resistor.

### **WARNING**

Lay Removed PAB facing upward for unexpected air bag deploy .

- Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?
- **YES** Go to "Main harness circuit inspection" procedure.
- NO Substitute a known-good PAB assembly, and check for proper operation.

If the problem is corrected, replace PAB and then go to "Verification of Vehicle Repair" procedure.

# Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect PAB connector and SRSCM main harness connector.

### WARNING

Lay Removed PAB facing upward for unexpected air bag deploy .

4. Measure resistance between terminal "Low.1" or "High.1" of the PAB harness connector and chassis ground.

### Specification : $\infty$

- 5. Is the measured resistance within specifications?
- YES ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM an-

d then go to "Verification of Vehicle Repair" procedure.

NO Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

# Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?

**YES** • Go to the applicable troubleshooting procedure.

NO ► System is performing to specification at this time.

021-62999292

# **RT-79**

# B1355 Passenger Airbag Resistance Circuit Short to Battery (1st Stage)

#### **General Description**

Passenger Air bag module (hereinafter referred to PAB) located at passenger side crush pad protects passenger by reducing impact of collision.

PAB is consist of air bag, pat cover and inflator.

Air bag reduces impact of collision by fillied up gas.

Inflator keeps gas and uses it to deploy air bag on collision.

### 

Never measure resistance of PAB directly, Current of measuring device may cause unexpected air bag deploy.

### **DTC Description**

The SRSCM sets DTC B1355 if there is a short to power in PAB harness.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

#### **DTC Detecting Condition**

lte	em	Detecting Cond	lition	Possible cause	
DTC Strategy		Check Resistance			
Enable Conditions		Ignition "ON"		• Short to power in PAB harness.	
Thresho	ld Value	PAB 1st stage Squib line voltage	<ul> <li>PAB 1st stage Squib line voltage is &gt; 2.9V</li> </ul>		
Diagnostic	Qualificati- on	• More than 2.5s (250ms x 10)		<ul><li>Poor connection of connected part.</li><li>Faulty PAB.</li></ul>	
Time	De-Qualifi- cation	• More than 5s 9.00	شرکت دیج	Faulty SRSCM.	
Specifica	Specification				
Test Condition				Voltage	
Ignition ON		0.9V ≤ Squ	uib line Voltage $\leq$ 2.9V		

Restraint

021-62999292

#### **Diagnostic Circuit Diagram**



# SRSCM

### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

NO • Go to "Squib Circuit Inspection" procedure.

### Squib Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Remove the PAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-2E100) to PAB harness connector.

**WNOTICE** 

If dummy and dummy adaptor are not able to be prepared, use a known-good PAB or  $2\Omega$  resistor.

### **WARNING**

Lay Removed PAB facing upward for unexpected air bag deploy .

- Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?
- **YES** Go to "Main harness circuit inspection" procedure.

NO
 ▶ Substitute a known-good PAB assembly, and check for proper operation.
 If the problem is corrected, replace PAB and then go to "Verification of Vehicle Repair" procedure.

# Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect PAB connector and SRSCM main harness connector.

### WARNING

Lay Removed PAB facing upward for unexpected air bag deploy .

- Connect the battery (-) terminal cable to the battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- Measure voltage between terminal "Low.1" or "High.
   1" of the PAB harness connector and ch

### Specification : approx. 0V

6. Is the measured voltage within specifications?

- YES Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- NO Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

# Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?
- **YES** Go to the applicable troubleshooting procedure.
- NO ► System is performing to specification at this time.

# Restraint

# **B1361 Pretensioner Front-Driver Resistance too High**

#### **General Description**

Seat Belt Pretensioner(hereinafter referred to BPT) is located at both side of center pillar.

BPT tightens seat belt before air bag deploys to protect passenger from bumping against crush pad, steering wheel and front window.

In BPT, there are a ignition circuit and cylinder for rewinding belt.

Cylinder has piston that can rewind seat belt in it.

Gas chamber generates expansive force of gases to push piston in cylinder.

#### 

Never measure resistance of BPT directly, Current of measuring device may cause unexpected BPT depoy.

#### **DTC Detecting Condition**

### DTC Description

The SRSCM sets DTC B1361 if the measured resistance value of DBPT circuit is more than the threshold value.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

Item		Detecting Condition	Possible caus	е
DTC S	trategy	Check Resistance	9	
Enable Conditions		Ignition "ON"	Poor connection of	connected
Threshold Value		• DBPT resistance $\geq 6.4\Omega$	<ul> <li>part.</li> <li>Poor connection betw</li> </ul>	veen shor-
Diagnostic	Qualificati- on	• More than 2.5s (250ms x 10)	ting bar and release p Faulty DBPT.	
Time	De-Qualifi- cation	اولین سامانه دیجیتال توریف More than 5s	Faulty SRSCM.	

#### Specification

Test Condition	Resistance
Ignition ON	$1.4\Omega \le$ Squib resistance $\le 6.4\Omega$

# **RT-83**

### **Diagnostic Circuit Diagram**



### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.



SBHRT9520L

#### **MOTICE**

- H : Historical fault
- P : Present fault

#### 5. Is DTC present problem ?

NO

**YES** • Go to "W/Harness Inspection" procedure.

▶ Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

▶ Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

# WWW.DIGITALKHODRO.COM

Restraint

# **RT-84**

### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

NO • Go to "Squib Circuit Inspection" procedure.

### Squib Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Disconnect DBPT module and connect the dummy (0957A-38200) and dummy adapter (0957A-2G000) to main harness connector.

**WNOTICE** If dummy and dummy adaptor are not able to be prepared, use a known-good DBPT or  $2\Omega$  resistor.

- Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?



**NO** • Substitute a known-good DBPT assembly, and check for proper operation.

If the problem is corrected, replace DBPT and then go to "Verification of Vehicle Repair" procedure.

# Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect DBPT connector and SRSCM main harness connector.
- 4. Measure resistance between terminal "Low" and "High" of the DBPT harness connector.

### Specification : approx. 1 $\Omega$ below

- 5. Is the measured resistance within specifications?
- ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- NO ► Substitute the SRSCM main harness and check for proper operation. If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

# Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- Using a scan tool, clear the DTC.
- Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?
- **YES** Go to the applicable troubleshooting procedure.
- NO ► System is performing to specification at this time.

# **RT-85**

# B1362 Pretensioner Front-Driver Resistance too Low

#### **General Description**

Seat Belt Pretensioner(hereinafter referred to BPT) is located at both side of center pillar.

BPT tightens seat belt before air bag deploys to protect passenger from bumping against crush pad, steering wheel and front window.

In BPT, there are a ignition circuit and cylinder for rewinding belt.

Cylinder has piston that can rewind seat belt in it.

Gas chamber generates expansive force of gases to push piston in cylinder.

#### 

Never measure resistance of BPT directly, Current of measuring device may cause unexpected BPT depoy.

#### **DTC Detecting Condition**

## DTC Description

The SRSCM sets DTC B1362 if the measured resistance value of DBPT circuit is less than the threshold value.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

Item		Detecting Condition	Possible cause
DTC S	trategy	Check Resistance	
Enable Conditions		Ignition "ON"	Poor connection of connected
Threshold Value		• DBPT resistance $\leq 1.4\Omega$	<ul> <li>part.</li> <li>Poor connection between shor-</li> </ul>
Diagnostic	Qualificati- on	• More than 2.5s (250ms x 10)	ting bar and release pin. <ul> <li>Faulty DBPT.</li> </ul>
Time	De-Qualifi- cation	اولین سامانه دیجینال تعمیر More than 5s	Faulty SRSCM.

#### Specification

Test Condition	Resistance
Ignition ON	$1.4\Omega \le$ Squib resistance $\le 6.4\Omega$

021-62999292

# Restraint

#### **Diagnostic Circuit Diagram**



### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.



SBHRT9521L



- H : Historical fault
- P : Present fault

#### 5. Is DTC present problem ?

NO

**YES** > Go to "W/Harness Inspection" procedure.

Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

▶ Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

# SRSCM

#### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO** • Go to "Squib Circuit Inspection" procedure.

### **Squib Circuit Inspection**

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Disconnect DBPT module and connect the dummy (0957A-38200) and dummy adapter (0957A-2G000) to main harness connector.

**WNOTICE** If dummy and dummy adaptor are not able to be prepared, use a known-good DBPT or  $2\Omega$  resistor.

- Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?



**NO** • Substitute a known-good DBPT assembly, and check for proper operation.

If the problem is corrected, replace DBPT and then go to "Verification of Vehicle Repair" procedure.

### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect DBPT connector and SRSCM main harness connector.
- 4. Measure resistance between terminal "Low" and "High" of the DBPT harness connector.

#### Specification : approx. 1 $\Omega$ below

- 5. Is the measured resistance within specifications?
- ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- NO ► Substitute the SRSCM main harness and check for proper operation. If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?
- **YES** Go to the applicable troubleshooting procedure.
- NO ► System is performing to specification at this time.

# Restraint

# B1363 Pretensioner front-Driver resistance circuit short to Ground

#### **General Description**

Seat Belt Pretensioner(hereinafter referred to BPT) is located at both side of center pillar.

BPT tightens seat belt before air bag deploys to protect passenger from bumping against crush pad, steering wheel and front window.

In BPT, there are a ignition circuit and cylinder for rewinding belt.

Cylinder has piston that can rewind seat belt in it.

Gas chamber generates expansive force of gases to push piston in cylinder.

#### 

Never measure resistance of BPT directly, Current of measuring device may cause unexpected BPT depoy.

#### **DTC Detecting Condition**

Item		Detecting Condition	Possible cause
DTC Strat	tegy	Check Resistance	
Enable Conditions		Ignition "ON"	Short to ground in DBPT harn-
Threshold Value		<ul> <li>DBPT Squib line Voltage is &lt; 0.9V</li> </ul>	<ul> <li>ess.</li> <li>Poor connection of connected</li> </ul>
Qu Diagnostic	ualificati- on	• More than 2.5s (250ms x 10)	part. <ul> <li>Faulty DBPT.</li> </ul>
	e-Qualifi- cation	• More than 5s	Faulty SRSCM.

#### Specification

Test Condition	Voltage
Ignition ON	$0.9V \le Squib line Voltage \le 2.9V$

The SRSCM sets DTC B1363 if there is a short to ground in DBPT harness.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

# **RT-89**

### **Diagnostic Circuit Diagram**



### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.



SBHRT9522L

#### 

- H : Historical fault
- P : Present fault

#### 5. Is DTC present problem ?

NO

**YES** > Go to "W/Harness Inspection" procedure.

▶ Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

▶ Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

# WWW.DIGITALKHODRO.COM

Restraint

# RT-90

### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

NO • Go to "Squib Circuit Inspection" procedure.

### Squib Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Disconnect DBPT module and connect the dummy (0957A-38200) and dummy adapter (0957A-2G000) to main harness connector.

NOTICE

If dummy and dummy adaptor are not able to be prepared, use a known-good DBPT or  $2\Omega$  resistor.

- Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?



NO ► Substitute a known-good DBPT assembly, and check for proper operation.

If the problem is corrected, replace DBPT and then go to "Verification of Vehicle Repair" procedure.

# Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect DBPT connector and SRSCM main harness connector.
- 4. Measure resistance between terminal "Low" or "High" of the DBPT harness connector and chassis ground.

### Specification : $\infty$

- 5. Is the measured resistance within specifications?
  - **YES** Substitute a known-good SRSCM, and check for proper operation.

If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.

NO
 ▶ Substitute the SRSCM main harness and check for proper operation.
 If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?

NO ► System is performing to specification at this time.

**YES** • Go to the applicable troubleshooting procedure.

# **RT-91**

# B1364 Pretensioner front-Driver resistance circuit short to Battery

#### General Description

Seat Belt Pretensioner(hereinafter referred to BPT) is located at both side of center pillar.

BPT tightens seat belt before air bag deploys to protect passenger from bumping against crush pad, steering wheel and front window.

In BPT, there are a ignition circuit and cylinder for rewinding belt.

Cylinder has piston that can rewind seat belt in it.

Gas chamber generates expansive force of gases to push piston in cylinder.

#### 

Never measure resistance of BPT directly, Current of measuring device may cause unexpected BPT depoy.

#### DTC Detecting Condition

#### **Detecting Condition** Item **Possible cause DTC Strategy** Check Resistance Short to power in DBPT harne-Ignition "ON" **Enable Conditions** • • SS Threshold Value DBPT Squib line voltage is > 2.9V Poor connection of connected Qualificatipart. More than 2.5s (250ms x 10) Faulty DBPT. on Diagnostic Faulty SRSCM. • Time De-Qualifi-More than 5s cation

#### Specification

Test Condition	Voltage
Ignition ON	$0.9V \le Squib line Voltage \le 2.9V$

The SRSCM sets DTC B1364 if there is a short to power in DBPT harness.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

# Restraint

021-62999292

#### **Diagnostic Circuit Diagram**



### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.



SBHRT9523L

#### 

- H : Historical fault
- P : Present fault

5. Is DTC present problem ?

NO

- **YES** > Go to "W/Harness Inspection" procedure.
  - Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

▶ Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

# WWW.DIGITALKHODRO.COM

# SRSCM

### Terminal and Connector Inspection

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?
- YES 

   Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO** • Go to "Squib Circuit Inspection" procedure.

### Squib Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Disconnect DBPT module and connect the dummy (0957A-38200) and dummy adapter (0957A-2G000) to main harness connector.

**WNOTICE** If dummy and dummy adaptor are not able to be prepared, use a known-good DBPT or  $2\Omega$  resistor.

- Connect (-) terminal cable to battery and Ignition 4. "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?



**NO •** Substitute a known-good DBPT assembly, and check for proper operation.

If the problem is corrected, replace DBPT and then go to "Verification of Vehicle Repair" procedure.

# Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect DBPT connector and SRSCM main harness connector.
- 4. Connect the battery (-) terminal cable to the battery and Ignition "ON" & Engine "OFF".
- 5. Measure voltage between terminal "Low" or "High" of the DBPT harness connector and chassis ground.

### Specification : approx. 0V

- 6. Is the measured voltage within specifications?
- Substitute a known-good SRSCM, and chec-YES k for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- **NO** > Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?



- **YES** Go to the applicable troubleshooting procedure.
- NO System is performing to specification at this time.

# Restraint

# B1367 Pretensioner Front-Passenger Resistance too High

#### **General Description**

Seat Belt Pretensioner(hereinafter referred to BPT) is located at both side of center pillar.

BPT tightens seat belt before air bag deploys to protect passenger from bumping against crush pad, steering wheel and front window.

In BPT, there are a ignition circuit and cylinder for rewinding belt.

Cylinder has piston that can rewind seat belt in it.

Gas chamber generates expansive force of gases to push piston in cylinder.

#### 

Never measure resistance of BPT directly, Current of measuring device may cause unexpected BPT depoy.

#### **DTC Detecting Condition**

### DTC Description

The SRSCM sets DTC B1367 if the measured resistance value of PBPT circuit is more than the threshold value.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

Item		Detecting Condition	Possible cause
DTC Strategy		Check Resistance	
Enable Conditions		Ignition "ON"	<ul> <li>Poor connection of connected</li> </ul>
Threshold Value		• PBPT resistance $\geq 6.4\Omega$	<ul> <li>part.</li> <li>Poor connection between shor-</li> </ul>
Diagnostic	Qualificati- on	• More than 2.5s (250ms x 10)	ting bar and release pin. <ul> <li>Faulty PBPT.</li> </ul>
Time	De-Qualifi- cation	اولین سامانه دیجیتال تورسه More than 5s	• Faulty SRSCM.

#### Specification

Test Condition	Resistance
Ignition ON	$1.4\Omega \le$ Squib resistance $\le 6.4\Omega$

# **RT-95**

### **Diagnostic Circuit Diagram**



Monitor Scantool Data

5. Is DTC present problem ?

YES

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.



SBHRT9524L



- H : Historical fault
- P : Present fault

- ► Go to "W/Harness Inspection" procedure.
- NO ► Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

Restraint

# **RT-96**

#### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO** • Go to "Squib Circuit Inspection" procedure.

### **Squib Circuit Inspection**

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Disconnect PBPT module and connect the dummy (0957A-38200) and dummy adapter (0957A-2G000) to main harness connector.

**WNOTICE** 

If dummy and dummy adaptor are not able to be prepared, use a known-good PBPT or  $2\Omega$  resistor.

- Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?



NO ► Substitute a known-good PBPT assembly, and check for proper operation.

If the problem is corrected, replace PBPT and then go to "Verification of Vehicle Repair" procedure.

### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect PBPT connector and SRSCM main harness connector.
- 4. Measure resistance between terminal "Low" and "High" of the PBPT harness connector.

### Specification : approx. 1 $\Omega$ below

- 5. Is the measured resistance within specifications?
- ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- NO ► Substitute the SRSCM main harness and check for proper operation. If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

# Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?
- **YES** Go to the applicable troubleshooting procedure.
- NO ► System is performing to specification at this time.

# **RT-97**

# B1368 Pretensioner Front-Passenger Resistance too Low

#### **General Description**

Seat Belt Pretensioner(hereinafter referred to BPT) is located at both side of center pillar.

BPT tightens seat belt before air bag deploys to protect passenger from bumping against crush pad, steering wheel and front window.

In BPT, there are a ignition circuit and cylinder for rewinding belt.

Cylinder has piston that can rewind seat belt in it.

Gas chamber generates expansive force of gases to push piston in cylinder.

#### 

Never measure resistance of BPT directly, Current of measuring device may cause unexpected BPT depoy.

#### **DTC Detecting Condition**

# DTC Description

The SRSCM sets DTC B1368 if the measured resistance value of PBPT circuit is less than the threshold value.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

Item		Detecting Condition	Possible cause
DTC S	trategy	Check Resistance	
Enable Conditions		Ignition "ON"	Poor connection of connected
Threshold Value		• PBPT resistance $\leq 1.4\Omega$	<ul> <li>part.</li> <li>Poor connection between shor-</li> </ul>
Diagnostic	Qualificati- on	• More than 2.5s (250ms x 10)	ting bar and release pin. • Faulty PBPT.
Time	De-Qualifi- cation	• More than 5s	Faulty SRSCM.

#### Specification

Test Condition	Resistance		
Ignition ON	$1.4\Omega \le$ Squib resistance $\le 6.4\Omega$		

021-62999292

# Restraint

#### **Diagnostic Circuit Diagram**



Monitor Scantool Data

5. Is DTC present problem ?

YES

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.



SBHRT9525L



- H : Historical fault
- P : Present fault

- ► Go to "W/Harness Inspection" procedure.
- NO ► Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

# 021-62999292

**RT-99** 

# SRSCM

### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO** • Go to "Squib Circuit Inspection" procedure.

### Squib Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Disconnect PBPT module and connect the dummy (0957A-38200) and dummy adapter (0957A-2G000) to main harness connector.

**WNOTICE** If dummy and dummy adaptor are not able to be prepared, use a known-good PBPT or  $2\Omega$  resistor.

- Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?



NO ► Substitute a known-good PBPT assembly, and check for proper operation. If the problem is corrected, replace PBPT and then go to " Verification of Vehicle Repair" procedure.

### Main harness Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect PBPT connector and SRSCM main harness connector.
- 4. Measure resistance between terminal "Low" and "High" of the PBPT harness connector.

### Specification : approx. 1 $\Omega$ below

- 5. Is the measured resistance within specifications?
- ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- NO ► Substitute the SRSCM main harness and check for proper operation. If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

# Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- Using a scan tool, clear the DTC.
- Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?
- **YES** Go to the applicable troubleshooting procedure.
- NO ► System is performing to specification at this time.

# Restraint

# B1369 Pretensioner Front-Passenger Resistance Circuit Short to Ground

#### General Description

Seat Belt Pretensioner(hereinafter referred to BPT) is located at both side of center pillar.

BPT tightens seat belt before air bag deploys to protect passenger from bumping against crush pad, steering wheel and front window.

In BPT, there are a ignition circuit and cylinder for rewinding belt.

Cylinder has piston that can rewind seat belt in it.

Gas chamber generates expansive force of gases to push piston in cylinder.

#### 

Never measure resistance of BPT directly, Current of measuring device may cause unexpected BPT depoy.

#### **DTC Detecting Condition**

#### **Detecting Condition** Item **Possible cause DTC Strategy** Check Resistance Short to ground in PBPT harne-Ignition "ON" **Enable Conditions** • • SS. Threshold Value PBPT Squib line Voltage is < 0.9V Poor connection of connected Qualificatipart. More than 2.5s (250ms x 10) Faulty PBPT. on Diagnostic Faulty SRSCM. ٠ Time De-Qualifi-More than 5s cation

#### Specification

Test Condition	Voltage			
Ignition ON	$0.9V \le Squib line Voltage \le 2.9V$			

The SRSCM sets DTC B1369 if there is a short to ground in PBPT harness.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

# **RT-101**

### **Diagnostic Circuit Diagram**



Monitor Scantool Data

5. Is DTC present problem ?

YES

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.



SBHRT9526L



- H : Historical fault
- P : Present fault

- ► Go to "W/Harness Inspection" procedure.
- NO ► Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

Restraint

# RT-102

### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

NO • Go to "Squib Circuit Inspection" procedure.

# Squib Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Disconnect PBPT module and connect the dummy (0957A-38200) and dummy adapter (0957A-2G000) to main harness connector.

**WNOTICE** 

If dummy and dummy adaptor are not able to be prepared, use a known-good PBPT or  $2\Omega$  resistor.

- Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?



NO ► Substitute a known-good PBPT assembly, and check for proper operation.

If the problem is corrected, replace PBPT and then go to "Verification of Vehicle Repair" procedure.

### Main harness Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect PBPT connector and SRSCM main harness connector.
- 4. Measure resistance between terminal "Low" or "High" of the PBPT harness connector and chassis ground.

### Specification : $\infty$

- 5. Is the measured resistance within specifications?
- **YES** Substitute a known-good SRSCM, and check for proper operation.

If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.

NO
 ▶ Substitute the SRSCM main harness and check for proper operation.
 If the problem is corrected, replace SRSCM main harness and then go to "Verification of

Vehicle Repair" procedure.

### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- Using a scan tool, clear the DTC.
- Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?

NO ► System is performing to specification at this time.

**YES** • Go to the applicable troubleshooting procedure.

021-62999292

# **RT-103**

# B1370 Pretensioner Front-Passenger Resistance Circuit Short to Battery

#### General Description

Seat Belt Pretensioner(hereinafter referred to BPT) is located at both side of center pillar.

BPT tightens seat belt before air bag deploys to protect passenger from bumping against crush pad, steering wheel and front window.

In BPT, there are a ignition circuit and cylinder for rewinding belt.

Cylinder has piston that can rewind seat belt in it.

Gas chamber generates expansive force of gases to push piston in cylinder.

#### 

Never measure resistance of BPT directly, Current of measuring device may cause unexpected BPT depoy.

#### **DTC Detecting Condition**

#### **Detecting Condition** Item **Possible cause DTC Strategy** Check Resistance Short to ground in PBPT harne-Ignition "ON" **Enable Conditions** • • SS. Threshold Value PBPT Squib line Voltage is < 0.9V Poor connection of connected Qualificatipart. More than 2.5s (250ms x 10) Faulty PBPT. on Diagnostic Faulty SRSCM. ٠ Time De-Qualifi-More than 5s cation

#### Specification

Test Condition	Voltage			
Ignition ON	$0.9V \le Squib line Voltage \le 2.9V$			

The SRSCM sets DTC B1370 if there is a short to power in PBPT harness.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

021-62999292

# Restraint

### **Diagnostic Circuit Diagram**



Monitor Scantool Data

5. Is DTC present problem ?

YES

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.



SBHRT9527L



- H : Historical fault
- P : Present fault

- ► Go to "W/Harness Inspection" procedure.
- NO ► Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

# SRSCM

#### Terminal and Connector Inspection

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?
- YES 

   Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO** • Go to "Squib Circuit Inspection" procedure.

### Squib Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Disconnect PBPT module and connect the dummy (0957A-38200) and dummy adapter (0957A-2G000) to main harness connector.

**WNOTICE** If dummy and dummy adaptor are not able to be prepared, use a known-good PBPT or  $2\Omega$  resistor.

- Connect (-) terminal cable to battery and Ignition 4. "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?



**NO •** Substitute a known-good PBPT assembly, and check for proper operation.

If the problem is corrected, replace PBPT and then go to "Verification of Vehicle Repair" procedure.

### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect PBPT connector and SRSCM main harness connector.
- 4. Connect the battery (-) terminal cable to the battery and Ignition "ON" & Engine "OFF".
- 5. Measure voltage between terminal "Low" or "High" of the PBPT harness connector and chassis ground.

Specification : approx. 0V

- 6. Is the measured voltage within specifications?
- Substitute a known-good SRSCM, and chec-YES k for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- **NO** > Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?



- **YES** Go to the applicable troubleshooting procedure.
- NO System is performing to specification at this time.

# 021-62999292

# Restraint

# B1378 Side Airbag Front-Driver Resistance too High

### **General Description**

Side Airbag (hereinafter referred to SAB) located in driver and passenger seat protects passenger's head and shoulder. SAB is consist of air bag and inflator.

Air bag reduces impact of collision by fillied up gas.

Inflator keeps gas and uses it to deploy air bag on collision.

### 

Never measure resistance of SAB directly, Current of measuring device may cause unexpected air bag deploy.

#### **DTC Detecting Condition**

### DTC Description

The SRSCM sets DTC B1378 if the measured resistance value of DSAB circuit is more than the threshold value.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

lte	m	Detecting Condition	Possible cause
DTC Strategy		Check Resistance	
Enable Conditions		Ignition "ON"	<ul><li>Poor connection of connected part.</li><li>Poor connection between shor-</li></ul>
Threshold Value		• DSAB resistance $\geq 6.4\Omega$	
Diagnostic Time	Qualificati- on	More than 2.5s (250ms x 10)	ting bar and release pin. <ul> <li>Faulty DSAB.</li> </ul>
	De-Qualifi- cation	• More than 5s	Faulty SRSCM.
Specificat	tion		

# Test ConditionResistanceIgnition ON $1.4\Omega \leq \text{Squib resistance} \leq 6.4\Omega$

# **RT-107**

### **Diagnostic Circuit Diagram**



Monitor Scantool Data

5. Is DTC present problem ?

YES

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.



SBHRT9528L



- H : Historical fault
- P : Present fault

- ► Go to "W/Harness Inspection" procedure.
- NO ► Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

Restraint

# RT-108

### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

NO • Go to "Squib Circuit Inspection" procedure.

# Squib Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Disconnect DSAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-3F000) to main harness connector.

**WNOTICE** If dummy and dummy adaptor are not able to be prepared, use a known-good DSAB or  $2\Omega$  resistor.

- Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?



**NO** • Substitute a known-good DSAB assembly, and check for proper operation.

If the problem is corrected, replace DSAB and then go to "Verification of Vehicle Repair" procedure.

# Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect DSAB connector and SRSCM main harness connector.
- 4. Measure resistance between terminal "Low" and "High" of the DSAB harness connector.

### **Specification :** approx. 1 $\Omega$ below

- 5. Is the measured resistance within specifications?
- ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- NO ► Substitute the SRSCM main harness and check for proper operation. If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

# Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- Using a scan tool, clear the DTC.
- Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?
- **YES** Go to the applicable troubleshooting procedure.
- NO ► System is performing to specification at this time.

# **RT-109**

# B1379 Side Airbag Front-Driver Resistance too Low

#### **General Description**

Side Airbag (hereinafter referred to SAB) located in driver and passenger seat protects passenger's head and shoulder. SAB is consist of air bag and inflator.

Air bag reduces impact of collision by fillied up gas.

Inflator keeps gas and uses it to deploy air bag on collision.

### 

Г

Never measure resistance of SAB directly, Current of measuring device may cause unexpected air bag deploy.

#### **DTC Detecting Condition**

### Т Itom L Detecting Condition Dessible seves

**DTC Description** 

by sending current for a while.

The SRSCM sets DTC B1379 if the measured resistance value of DAB circuit is less than the threshold value.

\*In this case, SRSCM checks if there's any fault in circuit

Item		Detecting Condition			Possible cause
DTC S	trategy	•	Check Resistance		
Enable C	onditions	•	Ignition "ON"	•	Poor connection of connected
Thresho	ld Value	•	DSAB resistance $\leq 1.4\Omega$		part. Poor connection between shor-
Diagnostic Time	Qualificati- on	•	More than 2.5s (250ms x 10)		ting bar and release pin. <li>Faulty DSAB.</li>
	De-Qualifi- cation	•	More than 5s	•	Faulty SRSCM.
0 10					

#### Specification

Test Condition	Resistance		
Ignition ON	$1.4\Omega \leq \text{Squib resistance} \leq 6.4\Omega$		

021-62999292

# Restraint

### **Diagnostic Circuit Diagram**



Monitor Scantool Data

5. Is DTC present problem ?

YES

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.



SBHRT9529L



- H : Historical fault
- P : Present fault

- ► Go to "W/Harness Inspection" procedure.
- NO ► Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.
# SRSCM

#### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO •** Go to "Squib Circuit Inspection" procedure.

### **Squib Circuit Inspection**

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Disconnect DSAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-3F000) to main harness connector.

**WNOTICE** If dummy and dummy adaptor are not able to be prepared, use a known-good DSAB or  $2\Omega$  resistor.

- Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?



NO ► Substitute a known-good DSAB assembly, and check for proper operation.

If the problem is corrected, replace DSAB and then go to "Verification of Vehicle Repair" procedure.

### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect DSAB connector and SRSCM main harness connector.
- 4. Measure resistance between terminal "Low" and "High" of the DSAB harness connector.

#### Specification : approx. 1 $\Omega$ below

- 5. Is the measured resistance within specifications?
- ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- NO ► Substitute the SRSCM main harness and check for proper operation. If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?
- **YES** Go to the applicable troubleshooting procedure.
- NO ► System is performing to specification at this time.

021-62999292

# Restraint

### B1380 Side Airbag Front-Driver Resistance Circuit Short to Ground

### **General Description**

Side Airbag (hereinafter referred to SAB) located in driver and passenger seat protects passenger's head and shoulder. SAB is consist of air bag and inflator.

Air bag reduces impact of collision by fillied up gas.

Inflator keeps gas and uses it to deploy air bag on collision.

### 

Never measure resistance of SAB directly, Current of measuring device may cause unexpected air bag deploy.

#### DTC Detecting Condition

#### Item **Detecting Condition Possible cause DTC Strategy** Check Resistance • Short to ground in DSAB harn-**Enable Conditions** • Ignition "ON" ess. **Threshold Value** • DSAB Squib line Voltage is < 0.9V Poor connection of connected Qualificatipart. More than 2.5s (250ms x 10) on Faulty DSAB. Diagnostic Faulty SRSCM. Time De-Qualifi-More than 5s cation

#### Specification

Test Condition	Voltage
Ignition ON	$0.9V \le$ Squib line Voltage $\le 2.9V$

### **DTC Description**

The SRSCM sets DTC B1380 if there is a short to ground in DSAB harness.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

# **RT-113**

### **Diagnostic Circuit Diagram**



Monitor Scantool Data

5. Is DTC present problem ?

YES

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.



SBHRT9530L



- H : Historical fault
- P : Present fault

- ► Go to "W/Harness Inspection" procedure.
- NO ► Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

Restraint

# RT-114

### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

NO • Go to "Squib Circuit Inspection" procedure.

### Squib Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Disconnect DSAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-2G000) to main harness connector.

**WNOTICE** 

If dummy and dummy adaptor are not able to be prepared, use a known-good DSAB or  $2\Omega$  resistor.

- Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?



NO ► Substitute a known-good DSAB assembly, and check for proper operation.

If the problem is corrected, replace DSAB and then go to "Verification of Vehicle Repair" procedure.

### Main harness Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect DSAB connector and SRSCM main harness connector.
- 4. Measure resistance between terminal "Low" or "High" of the DSAB harness connector and chassis ground.

### Specification : $\infty$

- 5. Is the measured resistance within specifications?
  - YES ► Substitute a known-good SRSCM, and check for proper operation.

If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.

NO
 ▶ Substitute the SRSCM main harness and check for proper operation.
 If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- Using a scan tool, clear the DTC.
- Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?
- **YES** Go to the applicable troubleshooting procedure.
- NO ► System is performing to specification at this time.

021-62999292

# **RT-115**

## B1381 Side Airbag Front-Driver Resistance Circuit Short to Battery

### General Description

Side Airbag (hereinafter referred to SAB) located in driver and passenger seat protects passenger's head and shoulder. SAB is consist of air bag and inflator.

Air bag reduces impact of collision by fillied up gas.

Inflator keeps gas and uses it to deploy air bag on collision.

### 

Never measure resistance of SAB directly, Current of measuring device may cause unexpected air bag deploy.

#### DTC Detecting Condition

#### Item **Detecting Condition Possible cause DTC Strategy** Check Resistance • Short to power in DSAB harne-**Enable Conditions** • Ignition "ON" SS. **Threshold Value** • DSAB Squib line voltage is > 2.9V Poor connection of connected Qualificatipart. More than 2.5s (250ms x 10) on Faulty DSAB. Diagnostic Faulty SRSCM. Time De-Qualifi-More than 5s cation

#### Specification

Test Condition	Voltage
Ignition ON	$0.9V \le$ Squib line Voltage $\le 2.9V$

**DTC Description** 

The SRSCM sets DTC B1381 if there is a short to power in DSAB harness.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

021-62999292

# Restraint

#### **Diagnostic Circuit Diagram**



Monitor Scantool Data

5. Is DTC present problem ?

YES

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.



SBHRT9531L



- H : Historical fault
- P : Present fault

- ► Go to "W/Harness Inspection" procedure.
- NO ► Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check shorting bar/horting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

# SRSCM

### Terminal and Connector Inspection

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?
- YES 

   Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO** • Go to "Squib Circuit Inspection" procedure.

### Squib Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Disconnect DSAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-3F000) to main harness connector.

**WNOTICE** 

If dummy and dummy adaptor are not able to be prepared, use a known-good DSAB or  $2\Omega$  resistor.

- 4. Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?



**NO >** Substitute a known-good DSAB assembly, and check for proper operation.

> If the problem is corrected, replace DSAB and then go to "Verification of Vehicle Repair" procedure.

### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect DSAB connector and SRSCM main harness connector.
- 4. Connect the battery (-) terminal cable to the battery and Ignition "ON" & Engine "OFF".
- 5. Measure voltage between terminal "Low" or "High" of the DSAB harness connector and chassis ground.

Specification : approx. 0V

- 6. Is the measured voltage within specifications?
- Substitute a known-good SRSCM, and chec-YES k for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- **NO** > Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?



- **YES** Go to the applicable troubleshooting procedure.
- NO System is performing to specification at this time.

021-62999292

# Restraint

### B1382 Side Airbag Front-Passenger Resistance too High

### **General Description**

Side Airbag (hereinafter referred to SAB) located in driver and passenger seat protects passenger's head and shoulder. SAB is consist of air bag and inflator.

Air bag reduces impact of collision by fillied up gas.

Inflator keeps gas and uses it to deploy air bag on collision.

### 

Never measure resistance of SAB directly, Current of measuring device may cause unexpected air bag deploy.

#### **DTC Detecting Condition**

### **DTC Description**

The SRSCM sets DTC B1382 if the measured resistance value of PSAB circuit is more than the threshold value.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

Item		Detecting Condition	Possible cause	
DTC Strategy		Check Resistance		
Enable Conditions		Ignition "ON"	Poor connection of connected	
Threshold Value		• PSAB resistance $\geq 6.4\Omega$	<ul><li>part.</li><li>Poor connection between shor-</li></ul>	
Diagnostic	Qualificati- on	• More than 2.5s (250ms x 10)	ting bar and release pin. <li>Faulty PSAB.</li>	
Time	De-Qualifi- cation	More than 5s	Faulty SRSCM.	
Specifica	tion			

# Test ConditionResistanceIgnition ON $1.4\Omega \le$ Squib resistance $\le 6.4\Omega$

# RT-119

### **Diagnostic Circuit Diagram**



### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.



SBHRT9532L

#### 

- H : Historical fault
- P : Present fault

#### 5. Is DTC present problem ?

NO

**YES** > Go to "W/Harness Inspection" procedure.

▶ Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check shorting bar/horting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

▶ Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

Restraint

# **RT-120**

### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO** • Go to "Squib Circuit Inspection" procedure.

### **Squib Circuit Inspection**

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Disconnect PSAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-3F000) to main harness connector.

**WNOTICE** If dummy and dummy adaptor are not able to be prepared, use a known-good PSAB or  $2\Omega$  resistor.

- Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?



**NO** • Substitute a known-good PSAB assembly, and check for proper operation.

If the problem is corrected, replace PSAB and then go to "Verification of Vehicle Repair" procedure.

### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect PSAB connector and SRSCM main harness connector.
- 4. Measure resistance between terminal "Low" and "High" of the PSAB harness connector.

#### Specification : approx. 1 $\Omega$ below

- 5. Is the measured resistance within specifications?
- ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- NO ► Substitute the SRSCM main harness and check for proper operation. If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?
- **YES** Go to the applicable troubleshooting procedure.
- NO ► System is performing to specification at this time.

# **RT-121**

### B1383 Side Airbag Front-Passenger Resistance too Low

### **General Description**

Side Airbag (hereinafter referred to SAB) located in driver and passenger seat protects passenger's head and shoulder. SAB is consist of air bag and inflator.

Air bag reduces impact of collision by fillied up gas.

Inflator keeps gas and uses it to deploy air bag on collision.

### 

Never measure resistance of SAB directly, Current of measuring device may cause unexpected air bag deploy.

#### **DTC Detecting Condition**

### DTC Description

The SRSCM sets DTC B1383 if the measured resistance value of PSAB circuit is less than the threshold value.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

Item		Detecting Condition	Possible cause	
DTC Strategy		Check Resistance		
Enable Conditions		Ignition "ON"	Poor connection of connected	
Threshold Value		• PSAB resistance $\leq 1.4\Omega$	<ul><li>part.</li><li>Poor connection between shor-</li></ul>	
Q Diagnostic	ualificati- on	• More than 2.5s (250ms x 10)	ting bar and release pin. <ul> <li>Faulty PSAB.</li> </ul>	
	e-Qualifi- cation	More than 5s	Faulty SRSCM.	
Specificatio	on			

# Test ConditionResistanceIgnition ON $1.4\Omega \leq \text{Squib resistance} \leq 6.4\Omega$

# Restraint

### **Diagnostic Circuit Diagram**



### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.



SBHRT9533L

#### 

- H : Historical fault
- P : Present fault

### 5. Is DTC present problem ?

NO

**YES** > Go to "W/Harness Inspection" procedure.

▶ Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check shorting bar/horting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

▶ Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

# SRSCM

#### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO •** Go to "Squib Circuit Inspection" procedure.

### **Squib Circuit Inspection**

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Disconnect PSAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-3F000) to main harness connector.

**WNOTICE** 

If dummy and dummy adaptor are not able to be prepared, use a known-good PSAB or  $2\Omega$  resistor.

- Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?



**NO** • Substitute a known-good PSAB assembly, and check for proper operation.

If the problem is corrected, replace PSAB and then go to "Verification of Vehicle Repair" procedure.

### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect PSAB connector and SRSCM main harness connector.
- 4. Measure resistance between terminal "Low" and "High" of the PSAB harness connector.

#### Specification : approx. 1 $\Omega$ below

- 5. Is the measured resistance within specifications?
- ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- NO ► Substitute the SRSCM main harness and check for proper operation. If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?
- **YES** Go to the applicable troubleshooting procedure.
- NO ► System is performing to specification at this time.

021-62999292

# Restraint

## B1384 Side Airbag Front-Passenger Resistance Circuit Short to Ground

**DTC Description** 

by sending current for a while.

in PSAB harness.

The SRSCM sets DTC B1384 if there is a short to ground

\*In this case, SRSCM checks if there's any fault in circuit

### **General Description**

Side Airbag (hereinafter referred to SAB) located in driver and passenger seat protects passenger's head and shoulder. SAB is consist of air bag and inflator.

Air bag reduces impact of collision by fillied up gas.

Inflator keeps gas and uses it to deploy air bag on collision.

### 

Never measure resistance of SAB directly, Current of measuring device may cause unexpected air bag deploy.

#### DTC Detecting Condition

#### Item **Detecting Condition Possible cause DTC Strategy** Check Resistance • Short to ground in PSAB harn-**Enable Conditions** • Ignition "ON" ess. **Threshold Value** • PSAB Squib line Voltage is < 0.9V Poor connection of connected Qualificatipart. More than 2.5s (250ms x 10) on Faulty PSAB. Diagnostic Faulty SRSCM. Time De-Qualifi-More than 5s cation

#### Specification

Test Condition	Voltage
Ignition ON	$0.9V \le$ Squib line Voltage $\le 2.9V$

WWW.DIGITALKHODRO.COM

# **RT-125**

### **Diagnostic Circuit Diagram**



### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.



SBHRT9534L



- H : Historical fault



5. Is DTC present problem ?

NO

- **YES** > Go to "W/Harness Inspection" procedure.
  - ▶ Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check shorting bar/horting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

▶ Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

Restraint

# **RT-126**

### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO** • Go to "Squib Circuit Inspection" procedure.

### **Squib Circuit Inspection**

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Disconnect PSAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-3F000) to main harness connector.

**WNOTICE** 

If dummy and dummy adaptor are not able to be prepared, use a known-good PSAB or  $2\Omega$  resistor.

- Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?



NO Substitute a known-good PSAB assembly,

and check for proper operation. If the problem is corrected, replace PSAB and then go to "Verification of Vehicle Repair" procedure.

### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect PSAB connector and SRSCM main harness connector.
- 4. Measure resistance between terminal "Low" and "High" of the PSAB harness connector.

#### Specification : approx. 1 $\Omega$ below

- 5. Is the measured resistance within specifications?
- ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- NO ► Substitute the SRSCM main harness and check for proper operation. If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?
- **YES** Go to the applicable troubleshooting procedure.
- NO ► System is performing to specification at this time.

021-62999292

# **RT-127**

## B1385 Side Airbag Front-Passenger Resistance Circuit Short to Battery

#### **General Description**

Side Airbag (hereinafter referred to SAB) located in driver and passenger seat protects passenger's head and shoulder. SAB is consist of air bag and inflator.

Air bag reduces impact of collision by fillied up gas.

Inflator keeps gas and uses it to deploy air bag on collision.

### 

Never measure resistance of SAB directly, Current of measuring device may cause unexpected air bag deploy.

#### DTC Detecting Condition

#### Item **Detecting Condition Possible cause DTC Strategy** Check Resistance • Short to power in PSAB harne-**Enable Conditions** • Ignition "ON" SS. **Threshold Value** • PSAB Squib line voltage is > 2.9V Poor connection of connected Qualificatipart. More than 2.5s (250ms x 10) on Faulty PSAB. Diagnostic Faulty SRSCM. Time De-Qualifi-More than 5s cation

#### Specification

Test Condition	Voltage
Ignition ON	$0.9V \le$ Squib line Voltage $\le 2.9V$

# DTC Description

The SRSCM sets DTC B1385 if there is a short to power in PSAB harness.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

# Restraint

### **Diagnostic Circuit Diagram**



### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.



SBHRT9535L

#### 

- H : Historical fault
- P : Present fault

#### 5. Is DTC present problem ?

NO

**YES** > Go to "W/Harness Inspection" procedure.

▶ Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check shorting bar/horting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

▶ Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

# 021-62999292

**RT-129** 

# SRSCM

#### Terminal and Connector Inspection

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?
- YES 

   Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO** • Go to "Squib Circuit Inspection" procedure.

### Squib Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Disconnect PSAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-3F000) to main harness connector.

**WNOTICE** If dummy and dummy adaptor are not able to be

prepared, use a known-good PSAB or  $2\Omega$  resistor. Connect (-) terminal cable to battery and Ignition 4.

- "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?



**NO >** Substitute a known-good PSAB assembly, and check for proper operation.

If the problem is corrected, replace PSAB and then go to "Verification of Vehicle Repair" procedure.

### Main harness Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect PSAB connector and SRSCM main harness connector.
- 4. Connect the battery (-) terminal cable to the battery and Ignition "ON" & Engine "OFF".
- 5. Measure voltage between terminal "Low" or "High" of the PSAB harness connector and chassis ground.

Specification : approx. 0V

- 6. Is the measured voltage within specifications?
- Substitute a known-good SRSCM, and chec-YES k for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- **NO** > Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?



- **YES** Go to the applicable troubleshooting procedure.
- NO System is performing to specification at this time.

### **B1395 Firing Loops Interconnection Fault**

#### **General Description**

very air bag module has its firing circuit that ignits powder to deploy air bag according to signal of SRSCM.

SRSCM checks every air bag module when ignition "ON". Once any fault is detected, it is erased only by scantool.

#### **DTC Detecting Condition**

Item

# **DTC Strategy** Check current(PWM type) • Е Diag Т

**Detecting Condition** 

### **DTC Description**

The SRSCM sets DTC B1395 if there's any short circuit in harness of every firing circuit to one another.

2.000.00039					
Enable Conditions		Ignition "ON"			
Threshold Value		is crosscoupled.		<ul> <li>short circuit in squib harne</li> <li>SRSCM.</li> </ul>	
agnostic	Qualificati- on	•	More than 2ms x 3		
Time De-Qualification	•	NA			
<b>۹</b> حدود)	وليت م	۲. سئ	مرکت دیجیتال خودرو سامانه (م	)-	

Restraint

Possible cause

### **Diagnostic Circuit Diagram**



SBHRT9609L

**RT-131** 

021- 62 99 92 92

### WWW.DIGITALKHODRO.COM

### 021-62999292

# RT-132

# Restraint

#### Monitor Scantool Data Verification of Vehicle Repair 1. Ignition "OFF", connect scantool. After a repair, it is essential to verify that the fault has been corrected. 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode. 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode 3. Monitor diagnostic trouble code and present of trouble code. 2. Using a scan tool, clear the DTC. 4. Using a scan tool, clear the DTC. 3. Operate the vehicle within DTC Enable conditions in General information. DTC 🗧 4. Are any DTC present ? YES Go to the applicable troubleshooting procedure. Description State NO System is performing to specification at this B1395 FIRING LOOPS INTERCONNEC. time. SBHRT9536L - H : Historical fault - P : Present fault 5. Is DTC present problem ? YES Check for short between ignition circuits of DAB, PAB, BPT, CAB, SAB. If the condition of harness and component is OK, this fault is caused by SRSCM internal error so replace a knowngood SRSCM and then go to "Verification of vehicle Repair" procedure. NO Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

### WWW.DIGITALKHODRO.COM

# RT-133

# B1400 SIS(Side Impact Sensor) Front-Driver defect

### **General Description**

Side Impact Sensor(SIS) is located in both side of center pillar detects broad collision.

When SIS delivers collision signal to SRSCM, SRSCM checks if safing sensor located in SRSCM detects collusion. and if both SIS and safing sensor detects collision simultaneously, SRSCM operates side air bag.

### **DTC Description**

The SRSCM sets DTC B1400 if there is any fault in DSIS circuit.

### **DTC Detecting Condition**

Item		Detecting Condition	Possible cause
DTC Strategy		Check Data	
Enable Conditions		Ignition "ON"	
Threshold Value		<ul><li>DSIS send defect code</li><li>DSIS output is not expected value</li></ul>	<ul> <li>Faulty DSIS circuit.</li> <li>Faulty DSIS.</li> </ul>
Diagnostic	Qualificati- on	<ul> <li>Ini(Start Up):100 ms (500µs x 20)</li> <li>Steady:1s (10ms x 100)</li> </ul>	Faulty SRSCM.
Time	De-Qualifi- cation	<ul> <li>Ini(Start Up):IGN off -&gt; on</li> <li>Steady:IGN off -&gt; on</li> </ul>	0

### **Diagnostic Circuit Diagram**



SBHRT9610L

# 021-62999292

Restraint

# **RT-134**

### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.

D1	ſĊ				
Ere	se All DTC	Freeze Frame	DTC Status	Erase Selective DTC	
	Description				State
B1400	DRIVER SIS DE	TECT			
	<u> </u>				
				SI	BHRT9537
r					
		∍⊏ orical fault			

. HIStorical laul

- P : Present fault

5. Is DTC present problem ?

**YES** • Go to "W/Harness Inspection" procedure.

NO Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

2. Thoroughly check shorting connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

- 3. Has a problem been found?
- YES Repair as necessary and then go to "Verification of Vehicle Repair" procedure.
- **NO** Go to "Component Inspection" procedure.

### **Component Inspection**

- 1. Ignition "ON" & Engine "OFF" and Using a scan tool, clear the DTC.
- 2. Ignition "OFF".
- 3. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 4. Disconnect DSIS connector .
- 5. Substitute the DSIS and check for proper operation.
- 6. Is DTC present problem ?
- YES > Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM an-

d then go to "Verification of Vehicle Repair" procedure.

Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

Substitute a known-good DSIS, and check NO for proper operation.

If the problem is corrected, replace DSIS and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present?

**YES** • Go to the applicable troubleshooting procedure.

System is performing to specification at this NO time.

021-62999292

# RT-135

## B1401 SIS(Side Impact Sensor)Front-Driver Circuit Short to Ground

### **General Description**

Front Side Impact Sensor(FSIS) is located in both side of center pillar detects broad collision.

When SIS delivers collision signal to SRSCM, SRSCM checks if safing sensor located in SRSCM detects collusion. and if both SIS and safing sensor detects collision simultaneously, SRSCM operates side air bag and curtain air bag.

### **DTC Description**

The SRSCM sets DTC B1401 if there is a short to ground in DSIS harness.

### **DTC Detecting Condition**

Item		Detecting Condition			Possible cause
DTC Strategy		•	Check voltage		
Enable Conditions		•	Ignition "ON"	<ul> <li>Short to ground in DSIS har ss.</li> </ul>	
Thresho	Threshold Value		DSIS no acceleration data, and line voltage $\leq$ 3V		
Diagnostic	Qualificati- on	•	Ini(Start Up):2.1s (2 times) Steady:500µs x 8 + 2.2s (2 times)	•	Faulty DSIS. Faulty SRSCM.
Time	De-Qualifi- cation	•	Ini(Start Up):1 time Steady:1 time		0

### **Diagnostic Circuit Diagram**



SBHRT9610L

## 021-62999292

Restraint

# RT-136

### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.

D D	TC				
Ere	ise All DTC	Freeze Frame	DTC Sieles	Erase Selective DTC	
	Description				State
B1401	SIS front-Driver c	ircuit short to Ground			
				S	BHRT9538
l		F			
		orical fault			
		ant foult			

- P : Present fault

5. Is DTC present problem ?

- **YES** Go to "W/Harness Inspection" procedure.
- NO ▷ Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM

memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

▶ Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

2. Thoroughly check shorting connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.
- NO ► Go to "Main harness circuit inspection" procedure.

### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 3. Disconnect DSIS connector and SRSCM main harness connector.
- 4. Measure resistance between terminal "Low" or "High" of the DSIS harness connector and chassis ground.

### Specification : $^{\infty}$

- 5. Is the measured resistance within specifications?
- **YES •** Go to "Component Inspection" procedure.
- NO Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

### Component Inspection

- 1. Ignition "ON" & Engine "OFF" and Using a scan tool, clear the DTC.
- 2. Ignition "OFF".
- 3. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 4. Disconnect DSIS connector .
- 5. Substitute the DSIS and check for proper operation.
- 6. Is DTC present problem ?
- YES ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- **NO •** Substitute a known-good DSIS, and check for proper operation.

If the problem is corrected, replace DSIS and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

Refer to the DTC B1101 : Battery Voltage High.

021- 62 99 92 92

# **RT-137**

# B1402 SIS(Side Impact Sensor)Front-Driver Circuit Short to Battery

### **General Description**

Front Side Impact Sensor(FSIS) is located in both side of center pillar detects broad collision.

When SIS delivers collision signal to SRSCM, SRSCM checks if safing sensor located in SRSCM detects collusion. and if both SIS and safing sensor detects collision simultaneously, SRSCM operates side air bag and curtain air bag.

#### **DTC Description**

The SRSCM sets DTC B1402 if there is short to power harness in DSIS harness.

### **DTC Detecting Condition**

Item		Detecting Condition			Possible cause
DTC S	trategy	•	Check voltage		
Enable Conditions		•	Ignition "ON"	<ul> <li>Short to power in DSIS harn</li> <li>s.</li> </ul>	
Threshold Value		•	DSIS no acceleration data, and line voltage >11V		
Diagnostic	Qualificati- on	•	Ini(Start Up):0.2s (100ms x 2) Steady:500µs x 8 + 2.2s (2 times)	•	Faulty DSIS. Faulty SRSCM.
Time	De-Qualifi- cation	•	Ini(Start Up):1 time Steady:1 time		0

### **Diagnostic Circuit Diagram**



SBHRT9610L

## 021-62999292

Restraint

# **RT-138**

### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.

D1	Erace AI DTC Freeze Frame DTC Status Erace Selective DTC Description State B1402 SIS front-Driver circuit short to Battery SBHRT953					
Era	se All DTC	Freeze Frame	DTC Siekes	Erase Selective DTC		
	Description				State	
B1402	SIS front-Driver	circuit short to Battery				
B1402						
÷					a a	
				SE	3HRT953	9
Ç		CE				

- H : Historical fault

- P : Present fault

5. Is DTC present problem ?

- **YES** Go to "W/Harness Inspection" procedure.
- NO Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

▶ Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

2. Thoroughly check shorting connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.
- NO ► Go to "Main harness circuit inspection" procedure.

### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 3. Disconnect DSIS connector and SRSCM main harness connector.
- 4. Ignition "ON" & Engine "OFF"
- 5. Measure voltage between terminal "Low" or "High" of the DSIS harness connector and chassis ground.

### Specification : 0V

- 6. Is the measured Voltage within specifications?
- **YES •** Go to "Component Inspection" procedure.
- NO ► Substitute the SRSCM main harness and check for proper operation. If the problem is corrected, replace SRSCM

main harness and then go to "Verification of Vehicle Repair" procedure.

### **Component Inspection**

- 1. Ignition "ON" & Engine "OFF" and Using a scan tool, clear the DTC.
- 2. Ignition "OFF".
- 3. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 4. Disconnect DSIS connector .
- 5. Substitute the DSIS and check for proper operation.
- 6. Is DTC present problem ?

If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.

NO Substitute a known-good DSIS, and check for proper operation.

If the problem is corrected, replace DSIS and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

Refer to the DTC B1101 : Battery Voltage High.

# 021- 62 99 92 92

YES ► Substitute a known-good SRSCM, and check for proper operation.

# **RT-139**

### B1403 SIS(Side Impact Sensor)Front-Passenger Defect

#### General Description

Side Impact Sensor(SIS) is located in both side of center pillar detects broad collision.

When SIS delivers collision signal to SRSCM, SRSCM checks if safing sensor located in SRSCM detects collusion. and if both SIS and safing sensor detects collision simultaneously, SRSCM operates side air bag.

### **DTC Description**

The SRSCM sets DTC B1403 if there is any fault in PSIS circuit.

### **DTC Detecting Condition**

Item		Detecting Condition	Possible cause
DTC Strategy		Check Data	
Enable Conditions		Ignition "ON"	
Threshold Value		<ul><li>PSIS send defect code</li><li>PSIS output is not expected value</li></ul>	<ul> <li>Faulty PSIS circuit.</li> <li>Faulty PSIS.</li> </ul>
Diagnostic Time	Qualificati- on	<ul> <li>Ini(Start Up):100 ms (500µs x 20)</li> <li>Steady:1s (10ms x 100)</li> </ul>	Faulty SRSCM.
	De-Qualifi- cation	<ul> <li>Ini(Start Up):IGN off -&gt; on</li> <li>Steady:IGN off -&gt; on</li> </ul>	0

### **Diagnostic Circuit Diagram**



SBHRT9611L

# 021-62999292

Restraint

# **RT-140**

### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.

DTC	х И	
Erese	AUDIC Freeze Frame DTC Status Erase Selective DTC	
	Description	State
B1403	PASS. SIS DETECT	
	ya la la la chi di chi di sa la la la la chi di chi di chi a c	
	e	BHRT9540L
0.		
	H : Historical fault	
	P : Present fault	
. Is	DTC present problem ?	
YΕ	S  Go to "W/Harness Inspection" pro	ocedure.
NC	Displaying nothing(no DTC) or DT	C with lat
	el "H"(historical) shows that Fault is i	ntermitter
	caused by poor contact in the part's	
	SCM connector or was repaired ar	nd SRSCI
	memory was not cleared.	
	Thoroughly check connectors for lo	
	poor connection, bending, corrosion, ation, deterioration, or damage.	contamin
	<ul> <li>Repair or replace as necessary a</li> </ul>	nd then a
	to "Verification of Vehicle Repair" pro-	-
on	ponent Inspection	
l. Io	nition "ON" & Engine "OFF" and Using	a scan too

- clear the DTC.
- 2. Ignition "OFF".
- 3. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 4. Disconnect PSIS connector .
- 5. Substitute the PSIS and check for proper operation.

- 6. Is DTC present problem ?
- YES Substitute a known-good SRSCM, and check for proper operation.

If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.

Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

NO Substitute a known-good PSIS, and check for proper operation. If the problem is corrected, replace PSIS and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present?

YES Go to the applicable troubleshooting procedure.

NO System is performing to specification at this time.

# 021-62999292

# RT-141

# B1404 SIS(Side Impact Sensor)Front-Passenger Circuit Short to Ground

### **General Description**

Front Side Impact Sensor(FSIS) is located in both side of center pillar detects broad collision.

When SIS delivers collision signal to SRSCM, SRSCM checks if safing sensor located in SRSCM detects collusion. and if both SIS and safing sensor detects collision simultaneously, SRSCM operates side air bag and curtain air bag.

### **DTC Description**

The SRSCM sets DTC B1404 if there is a short to ground in PSIS harness.

### **DTC Detecting Condition**

Item DTC Strategy Enable Conditions Threshold Value		Detecting Condition	Possible cause
		Check voltage	
Enable C	onditions	Ignition "ON"	
Threshold Value		<ul> <li>PSIS no acceleration data, and line voltage &lt; 3V</li> </ul>	• Short to ground in PSIS harne-
Diagnostic	Qualificati- on	<ul> <li>Ini(Start Up):2.1s (2 times)</li> <li>Steady:500µs x 8 + 2.2s (2 times)</li> </ul>	<ul><li>Faulty PSIS.</li><li>Faulty SRSCM.</li></ul>
Time	De-Qualifi- cation	<ul> <li>Ini(Start Up):1 time</li> <li>Steady:1 time</li> </ul>	0

### **Diagnostic Circuit Diagram**



SBHRT9611L

## 021-62999292

Restraint

# **RT-142**

### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.

DTC					٥	
Erase /	All DTC Fr	eeze Franie	DTC Status	Erase Selective DTC		
	Description				State	
B1404	SIS front-Passenger circ	uit short to Ground				
-						
				SE	3HRT9541L	-
Û	NOTICE					
- F	H : Historia	cal fault				
- F	P : Presen	t fault				
5. Is	DTC pres	ent proble	em?			
YES	Go	to "W/Ha	rness Insp	ection" pro	cedure.	
10	gsizo		uus) u	its cut g		
NC				DTC) or DT at Fault is i		
	SCM o	connector	or was r	the part's a epaired an		
		•	t cleared.	tors for la		~

Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

2. Thoroughly check shorting connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

### 3. Has a problem been found?

- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.
- NO ► Go to "Main harness circuit inspection" procedure.

### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 3. Disconnect PSIS connector and SRSCM main harness connector.
- 4. Measure resistance between terminal "Low" or "High" of the PSIS harness connector and chassis ground.

### Specification : $^{\infty}$

- 5. Is the measured resistance within specifications?
- **YES •** Go to "Component Inspection" procedure.
- NO Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

### Component Inspection

- 1. Ignition "ON" & Engine "OFF" and Using a scan tool, clear the DTC.
- 2. Ignition "OFF".
- 3. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 4. Disconnect PSIS connector .
- 5. Substitute the PSIS and check for proper operation.
- 6. Is DTC present problem ?
- YES Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- NO ► Substitute a known-good PSIS, and check for proper operation.

If the problem is corrected, replace PSIS and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

Refer to the DTC B1101 : Battery Voltage High.

# WWW.DIGITALKHODRO.COM

### 021-62999292

# **RT-143**

### B1405 SIS(Side Impact Sensor)Front-Passenger Circuit Short to Battery

### **General Description**

Front Side Impact Sensor(FSIS) is located in both side of center pillar detects broad collision.

When SIS delivers collision signal to SRSCM, SRSCM checks if safing sensor located in SRSCM detects collusion. and if both SIS and safing sensor detects collision simultaneously, SRSCM operates side air bag and curtain air bag.

#### **DTC Description**

The SRSCM sets DTC B1405 if there is short to power harness in PSIS harness.

### **DTC Detecting Condition**

Item DTC Strategy Enable Conditions Threshold Value Qualificat on		Detecting Condition	Possible cause
DTC S	trategy	Check voltage	
Enable C	onditions	Ignition "ON"	
Thresho	ld Value	<ul> <li>PSIS no acceleration data, and line voltage &gt;11V</li> </ul>	Short to power in PSIS harness
Diagnostic	Qualificati- on	<ul> <li>Ini(Start Up):0.2s (100ms x 2)</li> <li>Steady:500µs x 8 + 2.2s (2 times)</li> </ul>	<ul><li>Faulty PSIS.</li><li>Faulty SRSCM.</li></ul>
DTC Strategy Enable Conditions Threshold Value Diagnostic Time De-Qua	De-Qualifi- cation	<ul> <li>Ini(Start Up):1 time</li> <li>Steady:1 time</li> </ul>	

### **Diagnostic Circuit Diagram**



SBHRT9611L

## 021-62999292

Restraint

# RT-144

### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.

D1	ſC				
Era	se All DTC	Freeze Frame	DTC Status	Erase Selective DTC	
	Description				State
B1404	SIS front-Passenger	circuit short to Battery			
	<u> va a a a</u>				
				S	BHRT954
r	INOTICE				
	NOTICE				

5. Is DTC present problem ?

- **YES** Go to "W/Harness Inspection" procedure.
- NO Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

▶ Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

# **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

2. Thoroughly check shorting connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.
- NO ► Go to "Main harness circuit inspection" procedure.

### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 3. Disconnect PSIS connector and SRSCM main harness connector.
- 4. Ignition "ON" & Engine "OFF"
- 5. Measure voltage between terminal "Low" or "High" of the PSIS harness connector and chassis ground.

### Specification : 0V

- 6. Is the measured Voltage within specifications?
- **YES •** Go to "Component Inspection" procedure.
- NO ► Substitute the SRSCM main harness and check for proper operation. If the problem is corrected, replace SRSCM

main harness and then go to "Verification of Vehicle Repair" procedure.

### **Component Inspection**

- 1. Ignition "ON" & Engine "OFF" and Using a scan tool, clear the DTC.
- 2. Ignition "OFF".
- Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 4. Disconnect PSIS connector .
- 5. Substitute the PSIS and check for proper operation.
- 6. Is DTC present problem ?

NO Substitute a known-good PSIS, and check for proper operation.

If the problem is corrected, replace PSIS and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

Refer to the DTC B1101 : Battery Voltage High.

YES Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" pr-

### 021-62999292

# **RT-145**

### B1409 SIS(Side Impact Sensor) Front-Driver Communication Error

#### General Description

Side Impact Sensor(SIS) is located in both side of center pillar detects broad collision.

When SIS delivers collision signal to SRSCM, SRSCM checks if safing sensor located in SRSCM detects collusion. and if both SIS and safing sensor detects collision simultaneously, SRSCM operates side air bag.

### **DTC Description**

The SRSCM sets DTC B1409 if there is any error in communication between DSIS and SRSCM.

### **DTC Detecting Condition**

lte	Item Detecting Condition		Possible cause	
DTC Strategy		Check Data		
Enable Conditions		Ignition "ON"		
Threshold Value		<ul> <li>DSIS no acceleration data, and line voltage is ok (betw- een 3V and 11V)</li> </ul>	<ul> <li>Faulty DSIS circuit.</li> <li>Faulty DSIS.</li> </ul>	
Diagnostic Time	Qualificati- on	• 1 time	Faulty SRSCM.	
	De-Qualifi- cation	• 1 time	0	

### **Diagnostic Circuit Diagram**



SBHRT9610L

# 021-62999292

Restraint

# **RT-146**

### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.

DTC						
Erase All DTC		Freeze Frame	DTC Seius	Erase Selective DTC		
Descri	ption				State	
1409 DRIVE	R SIS COMM	I. ERROR				
				0		
0				51	BHRT9543	L
		rical fault				
		ent fault				
. Is DT	C pre	esent prob	lem ?			
YES	► G	o to "W/H	arness Ins	pection" pro	cedure.	
NO	► D	isplaying n	othing(no	DTC) or DT	C with I	а
				at Fault is i		
				the part's a		
				repaired an	nd SRS	С
		-	ot cleared.	otoro for la		
		• •		ctors for lo		
	•		ition, or da		contan	
				ecessary a	nd then	0
		•	•	Repair" pro		
• • • • •			octor In			

### Terminal and Connector Inspection

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

2. Thoroughly check shorting connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage ...

- 3. Has a problem been found?
- **YES** Repair as necessary and then go to "Verification of Vehicle Repair" procedure.
- **NO** Go to "Component Inspection" procedure.

### **Component Inspection**

- 1. Ignition "ON" & Engine "OFF" and Using a scan tool, clear the DTC.
- 2. Ignition "OFF".
- 3. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 4. Disconnect PSIS connector .
- 5. Substitute the PSIS and check for proper operation.
- 6. Is DTC present problem ?
- YES 
  Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- Substitute the SRSCM main harness and ch-NO eck for proper operation. If the problem is corrected, replace SRSCM

main harness and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present?
- **YES** Go to the applicable troubleshooting procedure.

NO

System is performing to specification at this time.
## 021-62999292

## **RT-147**

## B1410 SIS(Side Impact Sensor) Front-Passenger Communication Error

### General Description

Side Impact Sensor(SIS) is located in both side of center pillar detects broad collision.

When SIS delivers collision signal to SRSCM, SRSCM checks if safing sensor located in SRSCM detects collusion. and if both SIS and safing sensor detects collision simultaneously, SRSCM operates side air bag.

#### **DTC Description**

The SRSCM sets DTC B1410 if there is any error in communication between PSIS and SRSCM.

#### **DTC Detecting Condition**

	<u> </u>		
Item		Detecting Condition	Possible cause
DTC S	trategy	Check Data	
Enable Conditions		Ignition "ON"	
Threshold Value		<ul> <li>PSIS no acceleration data, and line voltage is ok (betw- een 3V and 11V)</li> </ul>	<ul> <li>Faulty PSIS circuit.</li> <li>Faulty PSIS.</li> </ul>
Diagnostic Time	Qualificati- on	• 1 time	Faulty SRSCM.
	De-Qualifi- cation	• 1 time	0

#### **Diagnostic Circuit Diagram**



SBHRT9611L

## 021-62999292

Restraint

## RT-148

### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.

🛛 DT	C				(
Eras	e All DTC Freeze Frame	, Di	'C Status	Erase Selective DTC	
	Description				State
B1410	PASSENGER SIS COMM. ERROR				
÷÷	<u></u>	i <u> </u>	- 0 - 0 - 0	3-3-3-3-3-3-3-3-3	1
				S	BHRT954
Q					
	H : Historical fa	ault			
	P : Present fau	lt			

5. Is DTC present problem ?

- **YES** Go to "W/Harness Inspection" procedure.
- NO Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

▶ Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

2. Thoroughly check shorting connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage..

- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.
- **NO •** Go to "Component Inspection" procedure.

### **Component Inspection**

- 1. Ignition "ON" & Engine "OFF" and Using a scan tool, clear the DTC.
- 2. Ignition "OFF".
- 3. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 4. Disconnect PSIS connector .
- 5. Substitute the PSIS and check for proper operation.
- 6. Is DTC present problem ?
- YES ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM an-

d then go to "Verification of Vehicle Repair" procedure.

Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

NO Substitute a known-good PSIS, and check for proper operation.

If the problem is corrected, replace SRSCM and d then go to "Verification of Vehicle Repair" procedure.

## Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?

**YES** • Go to the applicable troubleshooting procedure.

NO ► System is performing to specification at this time.

## **RT-149**

## B1412 SIS(Side Impact Sensor)Rear-Driver Communication error

#### **General Description**

Side Impact Sensor(SIS) is located in both side of C pillar detects broad collision.

When SIS delivers collision signal to SRSCM, SRSCM checks if safing sensor located in SRSCM detects collusion. and if both SIS and safing sensor detects collision simultaneously, SRSCM operates side air bag.

#### **DTC Description**

The SRSCM sets DTC B1412 if there is any error in communication between RDSIS and SRSCM.

#### **DTC Detecting Condition**

lte	em	Detecting Condition	Possible cause	
DTC S	trategy	Check Data		
Enable Conditions		Ignition "ON"		
Threshold Value		<ul> <li>RDSIS no acceleration data, and line voltage is ok (bet- ween 3V and 11V)</li> </ul>	<ul> <li>Faulty RDSIS circuit.</li> <li>Faulty RDSIS.</li> </ul>	
Diagnostic Time	Qualificati- on	• 1 time	Faulty SRSCM.	
	De-Qualifi- cation	• 1 time		

#### **Diagnostic Circuit Diagram**



SBHRT9612L

## 021-62999292

Restraint

## RT-150

### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.

D1	ſĊ					
Ens	se All DTC	Freeze Frame	DTC Status	Erase Selective DTC		
	Description				State	
B1412	SIS rear-Driver of	ommunication error				
				6	3HRT98	5/6
				0		7
r						

- P : Present fault

5. Is DTC present problem ?

**YES** • Go to "W/Harness Inspection" procedure.

NO Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

▶ Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

2. Thoroughly check shorting connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.
- **NO •** Go to "Component Inspection" procedure.

### **Component Inspection**

- 1. Ignition "ON" & Engine "OFF" and Using a scan tool, clear the DTC.
- 2. Ignition "OFF".
- 3. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 4. Disconnect RDSIS connector .
- 5. Substitute the RDSIS and check for proper operation.
- 6. Is DTC present problem ?
- YES ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM an-

d then go to "Verification of Vehicle Repair" procedure.

Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

NO Substitute a known-good RDSIS, and check for proper operation.

If the problem is corrected, replace SRSCM and d then go to "Verification of Vehicle Repair" procedure.

## Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?



NO ► System is performing to specification at this time.

## 021-62999292

## RT-151

## B1413 SIS(Side Impact Sensor)Rear-Passenger Communication error

### General Description

Side Impact Sensor(SIS) is located in both side of C pillar detects broad collision.

When SIS delivers collision signal to SRSCM, SRSCM checks if safing sensor located in SRSCM detects collusion. and if both SIS and safing sensor detects collision simultaneously, SRSCM operates side air bag.

#### **DTC Description**

The SRSCM sets DTC B1413 if there is any error in communication between RPSIS and SRSCM.

#### **DTC Detecting Condition**

lte	em	Detecting Condition	Possible cause
DTC S	trategy	Check Data	
Enable Conditions		Ignition "ON"	
Threshold Value		<ul> <li>RPSIS no acceleration data, and line voltage is ok (bet- ween 3V and 11V)</li> </ul>	<ul> <li>Faulty RPSIS circuit.</li> <li>Faulty RPSIS.</li> </ul>
Diagnostic Time	Qualificati- on	• 1 time	Faulty SRSCM.
	De-Qualifi- cation	• 1 time	0

#### **Diagnostic Circuit Diagram**



SBHRT9613L

## 021-62999292

Restraint

# RT-152

### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.

rame DTC Status Erase Selective DTC State ation error
ation error

- H : Historical fault
- P : Present fault

5. Is DTC present problem ?

**YES** • Go to "W/Harness Inspection" procedure.

NO Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

> Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

> ▶ Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

## **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

2. Thoroughly check shorting connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.
- **NO** Go to "Component Inspection" procedure.

### **Component Inspection**

- 1. Ignition "ON" & Engine "OFF" and Using a scan tool, clear the DTC.
- 2. Ignition "OFF".
- 3. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 4. Disconnect PSIS connector .
- 5. Substitute the RRPSIS and check for proper operation.
- 6. Is DTC present problem ?
- YES Substitute a known-good SRSCM, and check for proper operation.

If the problem is corrected, replace SRSCM and d then go to "Verification of Vehicle Repair" procedure.

Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

NO Substitute a known-good RPSIS, and check for proper operation.

If the problem is corrected, replace SRSCM and d then go to "Verification of Vehicle Repair" procedure.

## Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?
- **YES** Go to the applicable troubleshooting procedure.
- NO ► System is performing to specification at this time.

## **RT-153**

## B1414 SIS(Side Impact Sensor) Front-Driver Wrong ID

#### **General Description**

Front Side Impact Sensor(FSIS) is located in both side of center pillar detects broad collision.

When SIS delivers collision signal to SRSCM, SRSCM checks if safing sensor located in SRSCM detects collusion. and if both SIS and safing sensor detects collision simultaneously, SRSCM operates side air bag and curtain air bag.

#### **DTC Description**

The SRSCM sets DTC B1414 if DSIS with wrong ID  $% \left( \mathcal{D}_{1}^{2}\right) =0$  is detected.

#### **DTC Detecting Condition**

ltem		Detecting Condition			Possible cause
DTC Strategy		•	Check Data		
Enable Conditions Threshold Value		•	Ignition "ON"		
		•	DSIS ID is different from programmed in ACU	DSIS with wrong ID.	
Diagnostic	Qualificati- on	•	1 time	•	Faulty SRSCM.
Time	De-Qualifi- cation	•	1 time	0-	0

#### **Diagnostic Circuit Diagram**



SBHRT9610L

### 021-62999292

## 021-62999292

Restraint

# RT-154

### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.

D	TC					
Era	ase All DTC	Freeze Frame	DTC Steins	Erase Selective DTC		
	Description				State	
B1414	IS front-Driver Wr	ong ID				
i					<del>,</del>	-
				SE	BHRT9	547
l.		E				
-	H : Hist	orical fault				
	P : Pres	sent <mark>fault</mark>				
5 I	s DTC p	resent prot	olem ?			

YES Go to "W/Harness Inspection" procedure.

NO ► Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

▶ Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

## **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

2. Thoroughly check shorting connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.
- **NO** Go to "Component Inspection" procedure.

### **Component Inspection**

- 1. Ignition "ON" & Engine "OFF" and Using a scan tool, clear the DTC.
- 2. Ignition "OFF".
- 3. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 4. Disconnect DSIS connector .
- 5. Substitute the DSIS and check for proper operation.
- 6. Is DTC present problem ?
- YES ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM an-

d then go to "Verification of Vehicle Repair" procedure.

Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

NO Substitute a known-good DSIS, and check for proper operation.

If the problem is corrected, replace SRSCM and d then go to "Verification of Vehicle Repair" procedure.

## Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?



NO ► System is performing to specification at this time.

## WWW.DIGITALKHODRO.COM

## **RT-155**

### B1415 SIS(Side Impact Sensor) Front-Passenger Wrong ID

#### **General Description**

Front Side Impact Sensor(FSIS) is located in both side of center pillar detects broad collision.

When SIS delivers collision signal to SRSCM, SRSCM checks if safing sensor located in SRSCM detects collusion. and if both SIS and safing sensor detects collision simultaneously, SRSCM operates side air bag and curtain air bag.

#### **DTC Description**

The SRSCM sets DTC B1415 if PSIS with wrong ID  $\,$  is detected.

#### **DTC Detecting Condition**

Item		Detecting Condition			Possible cause
DTC Strategy		•	Check Data		
Enable Conditions		•	Ignition "ON"		
Threshold Value		•	PSIS ID is different from programmed in ACU	PSIS with wrong ID.	
Diagnostic	Qualificati- on	•	1 time	]•	Faulty SRSCM.
Time	De-Qualifi- cation	•	1 time	0-	0

#### **Diagnostic Circuit Diagram**



SBHRT9611L

### 021-62999292

## 021-62999292

Restraint

## RT-156

### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.

DT 🗧	ſĊ					
Ere	se All DTC	Freeze Frame	DTC Steius	Erase Selective DTC		
	Description				State	
B1415	SIS front-Passer	nger Wrong ID				
-						
				SI	3HRT95	548
ſ				0.		
		orical fault				
		sent fault				

5. Is DTC present problem ?

- **YES** Go to "W/Harness Inspection" procedure.
- NO Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

▶ Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

2. Thoroughly check shorting connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.
- **NO** Go to "Component Inspection" procedure.

### **Component Inspection**

- 1. Ignition "ON" & Engine "OFF" and Using a scan tool, clear the DTC.
- 2. Ignition "OFF".
- 3. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 4. Disconnect PSIS connector .
- 5. Substitute the PSIS and check for proper operation.
- 6. Is DTC present problem ?
- YES ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM an-

d then go to "Verification of Vehicle Repair" procedure

Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

NO Substitute a known-good PSIS, and check for proper operation.

If the problem is corrected, replace SRSCM and d then go to "Verification of Vehicle Repair" procedure.

## Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?



NO ► System is performing to specification at this time.

## 021-62999292

## RT-157

## B1416 SIS(Side Impact Sensor)Rear-Driver Wrong ID

### **General Description**

Rear Side Impact Sensor(RSIS) is located in both side of C pillar detects broad collision.

When SIS delivers collision signal to SRSCM, SRSCM checks if safing sensor located in SRSCM detects collusion. and if both SIS and safing sensor detects collision simultaneously, SRSCM operates side air bag.

### **DTC Detecting Condition**

#### DTC Description

The SRSCM sets DTC B1416 if RDSIS with wrong ID is detected.

	<u></u>				
lte	Item		Detecting Condition		Possible cause
DTC S	DTC Strategy				
Enable Conditions		•	Ignition "ON"	RDSIS with wrong ID.	
Threshold Value		•	RDSIS ID is different from programmed in ACU		
Diagnostic Time	Qualificati- on	•	1 time	•	Faulty SRSCM.
	De-Qualifi- cation	•	1 time		

#### Diagnostic Circuit Diagram



SBHRT9612L

## 021-62999292

Restraint

## RT-158

### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.

D1	ſĊ					
Ena	se All DTC	Freeze Frame	DTC Seite	Erase Selective DTC		
	Description				State	
B1416	RR DIRVER SIS-W	RONG ID				
				91	BHRT9	540
	-	_		01	5111(15)	575
		E orical fault				
	11.111310	nour raun				

- P : Present fault

5. Is DTC present problem ?

**YES** • Go to "W/Harness Inspection" procedure.

NO Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

▶ Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

2. Thoroughly check shorting connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.
- **NO •** Go to "Component Inspection" procedure.

### **Component Inspection**

- 1. Ignition "ON" & Engine "OFF" and Using a scan tool, clear the DTC.
- 2. Ignition "OFF".
- 3. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 4. Disconnect RDSIS connector .
- 5. Substitute the RDSIS and check for proper operation.
- 6. Is DTC present problem ?
- YES ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM an-

d then go to "Verification of Vehicle Repair" procedure.

Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

NO Substitute a known-good RDSIS, and check for proper operation.

If the problem is corrected, replace SRSCM and d then go to "Verification of Vehicle Repair" procedure.

## Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?



NO ► System is performing to specification at this time.

021-62999292

## **RT-159**

## B1417 SIS(Side Impact Sensor)Rear-Passenger Wrong ID

#### **General Description**

Rear Side Impact Sensor(RSIS) is located in both side of C pillar detects broad collision.

When SIS delivers collision signal to SRSCM, SRSCM checks if safing sensor located in SRSCM detects collusion. and if both SIS and safing sensor detects collision simultaneously, SRSCM operates side air bag.

#### **DTC Detecting Condition**

**DTC Description** 

The SRSCM sets DTC B1417 if RPSIS with wrong ID is detected.4

Item		Detecting Condition			Possible cause
DTC Strategy		Check Data			
Enable Conditions		•	Ignition "ON"	1	
Threshold Value		•	RPSIS ID is different from programmed in ACU	].	RPSIS with wrong ID.
Qualificati- Diagnostic on		•	1 time	•	Faulty SRSCM.
Time	De-Qualifi- cation	•	1 time		

#### **Diagnostic Circuit Diagram**



SBHRT9613L

## 021-62999292

Restraint

## **RT-160**

#### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.

D1	TC				
Era	se All DTC	Freeze Frame	DTC Status	Erase Selective DTC	
	Description				State
B1417	RR PASS.SIS-W	RONG ID			
<u></u>	a ∎ 16666				
				SI	BHRT9550
	NOTIO	CE torical fault			

- P : Present fault

5. Is DTC present problem ?

**YES** • Go to "W/Harness Inspection" procedure.

NO Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

> Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

> Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

#### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

2. Thoroughly check shorting connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.
- **NO** Go to "Component Inspection" procedure.

#### **Component Inspection**

- 1. Ignition "ON" & Engine "OFF" and Using a scan tool, clear the DTC.
- 2. Ignition "OFF".
- 3. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 4. Disconnect RPSIS connector .
- 5. Substitute the RPSIS and check for proper operation.
- 6. Is DTC present problem ?
- YES Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM an-

d then go to "Verification of Vehicle Repair" procedure.

Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

NO Substitute a known-good RPSIS, and check for proper operation.

If the problem is corrected, replace SRSCM and d then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?

**YES** • Go to the applicable troubleshooting procedure.

NO ► System is performing to specification at this time.

## B1418 SIS(Side Impact Sensor)Rear-Driver Defect

#### **General Description**

Side Impact Sensor(SIS) is located in both side of C pillar detects broad collision.

When SIS delivers collision signal to SRSCM, SRSCM checks if safing sensor located in SRSCM detects collusion. and if both SIS and safing sensor detects collision simultaneously, SRSCM operates side air bag.

#### **DTC Detecting Condition**

lte	Item Detecting Condition		Possible cause
DTC S	trategy	Check Data	
Enable Conditions		Ignition "ON"	
Threshold Value		<ul><li>RDSIS send defect code</li><li>RDSIS output is not expected value</li></ul>	<ul> <li>Faulty RDSIS circuit.</li> <li>Faulty RDSIS.</li> </ul>
Diagnostic	Qualificati- on	<ul> <li>Ini(Start Up):100 ms (500µs x 20)</li> <li>Steady:1s (10ms x 100)</li> </ul>	Faulty SRSCM.
Time	De-Qualifi- cation	<ul> <li>Ini(Start Up):IGN off -&gt; on</li> <li>Steady:IGN off -&gt; on</li> </ul>	

**DTC Description** 

The SRSCM sets DTC B1418 if there is any error in

communication between RDSIS and SRSCM.

#### **Diagnostic Circuit Diagram**



SBHRT9612L

# DT 404

021-62999292

## **RT-161**

## 021-62999292

Restraint

# RT-162

### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.

🛛 Di	TC				
Ere	ise All DTC	Freeze Frame	DTC Status	Erase Selective DTC	
	Description				State
B1418	SIS rear-Driver d	efect			
6					
				SE	BHRT9551
. (		СЕ			
-	· H : Hist	orical fault			
	D . Dre	a such far all			

- P : Present fault

5. Is DTC present problem ?

**YES** • Go to "W/Harness Inspection" procedure.

NO Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

▶ Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

2. Thoroughly check shorting connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.
- **NO •** Go to "Component Inspection" procedure.

### **Component Inspection**

- 1. Ignition "ON" & Engine "OFF" and Using a scan tool, clear the DTC.
- 2. Ignition "OFF".
- 3. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 4. Disconnect RDSIS connector .
- 5. Substitute the RDSIS and check for proper operation.
- 6. Is DTC present problem ?
- YES ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM an-

d then go to "Verification of Vehicle Repair" procedure.

Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

NO Substitute a known-good RDSIS, and check for proper operation.

If the problem is corrected, replace SRSCM and d then go to "Verification of Vehicle Repair" procedure.

## Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?

**YES** • Go to the applicable troubleshooting procedure.

NO ► System is performing to specification at this time.

### 021-62999292

## **RT-163**

### B1419 SIS(Side Impact Sensor)Rear-Passenger Defect

#### General Description

Side Impact Sensor(SIS) is located in both side of C pillar detects broad collision.

When SIS delivers collision signal to SRSCM, SRSCM checks if safing sensor located in SRSCM detects collusion. and if both SIS and safing sensor detects collision simultaneously, SRSCM operates side air bag.

#### **DTC Description**

The SRSCM sets DTC B1419 if there is any error in communication between PSIS and SRSCM.

#### **DTC Detecting Condition**

Item		Detecting Condition	Possible cause
DTC S	trategy	Check Data	
Enable Conditions		Ignition "ON"	
Threshold Value		<ul><li> RPSIS send defect code</li><li> RPSIS output is not expected value</li></ul>	<ul> <li>Faulty RPSIS circuit.</li> <li>Faulty RPSIS.</li> </ul>
Diagnostic	Qualificati- on	<ul> <li>Ini(Start Up):100 ms (500µs x 20)</li> <li>Steady:1s (10ms x 100)</li> </ul>	Faulty SRSCM.
Time	De-Qualifi- cation	<ul> <li>Ini(Start Up):IGN off -&gt; on</li> <li>Steady:IGN off -&gt; on</li> </ul>	0

#### **Diagnostic Circuit Diagram**



SBHRT9613L

### 021-62999292

## 021-62999292

Restraint

# RT-164

### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.

D1	TC .					
Ena	se All DTC	Freeze Frame	DTC Status	Erase Selective DTC		
	Description				State	
B1419	SIS rear-Passen	ger defect				
	<u>, , , , , , , , , , , , , , , , , , , </u>		- <u></u>	-d-d-d-d-d-		-
				S	BHRT9	552
ſ		CF				
		torical fault				
- (	P : Pres	sent fault				

5. Is DTC present problem ?

- **YES** Go to "W/Harness Inspection" procedure.
- NO ▷ Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

▶ Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

## **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

2. Thoroughly check shorting connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.
- **NO •** Go to "Component Inspection" procedure.

### **Component Inspection**

- 1. Ignition "ON" & Engine "OFF" and Using a scan tool, clear the DTC.
- 2. Ignition "OFF".
- 3. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 4. Disconnect RPSIS connector .
- 5. Substitute the RPSIS and check for proper operation.
- 6. Is DTC present problem ?
- YES ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM an-

d then go to "Verification of Vehicle Repair" procedure.

Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

NO Substitute a known-good RPSIS, and check for proper operation.

If the problem is corrected, replace SRSCM and d then go to "Verification of Vehicle Repair" procedure.

## Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?

**YES** • Go to the applicable troubleshooting procedure.

NO ► System is performing to specification at this time.

## **RT-165**

## B1429 Side Airbag Rear-Driver Resistance too High

#### **General Description**

Rear Side Airbag (hereinafter referred to RSAB) is located in driver and passenger side rear seat.

It protects passenger's head and shoulder in broad collision.

RSAB is consist of air bag and inflator.

Air bag reduces impact of collision by fillied up gas.

Inflator keeps gas and uses it to deploy air bag on collision.

#### 

Never measure resistance of RSAB directly, Current of measuring device may cause unexpected air bag deploy.

#### **DTC Detecting Condition**

#### DTC Description

The SRSCM sets DTC B1429 if the measured resistance value of DRSAB circuit is more than the threshold value.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

Item		Detecting Condition	Possible cause
DTC Strategy		Check Resistance	
Enable Conditions		Ignition "ON"	Poor connection of connected
Threshold Value		• DRSAB resistance $\geq 6.4\Omega$	<ul> <li>Poor connection between shor-</li> </ul>
Diagnostic	Qualificati- on	• More than 2.5s (250ms x 10)	ting bar and release pin. <ul> <li>Faulty DRSAB.</li> </ul>
Time	De-Qualifi- cation	More than 5s	Faulty SRSCM.

#### **Specification**

Test Condition	Resistance
Ignition ON	$1.4\Omega \le$ Squib resistance $\le 6.4\Omega$

021-62999292

## Restraint

#### **Diagnostic Circuit Diagram**



#### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.



SBHRT9553L

#### 

- H : Historical fault
- P : Present fault

#### 5. Is DTC present problem ?

NO

**YES** > Go to "W/Harness Inspection" procedure.

▶ Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

▶ Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

## WWW.DIGITALKHODRO.COM

## SRSCM

#### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO** • Go to "Squib Circuit Inspection" procedure.

#### **Squib Circuit Inspection**

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Disconnect RDSAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-3F000) to main harness connector.

**WNOTICE** 

If dummy and dummy adaptor are not able to be prepared, use a known-good RDSAB or  $2\Omega$  resistor.

- Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?



NO ► Substitute a known-good RDSAB assembly, and check for proper operation.

If the problem is corrected, replace RDSAB and d then go to "Verification of Vehicle Repair" procedure.

#### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect RDSAB connector and SRSCM main harness connector.
- 4. Measure resistance between terminal "2" and "1" of the RDSAB harness connector.

#### Specification : approx. 1 $\Omega$ below

- 5. Is the measured resistance within specifications?
- ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- NO ► Substitute the SRSCM main harness and check for proper operation. If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

#### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?
- **YES** Go to the applicable troubleshooting procedure.
- NO ► System is performing to specification at this time.

## Restraint

## B1430 Side Airbag Rear-Driver Resistance too Low

#### **General Description**

Rear Side Airbag (hereinafter referred to RSAB) is located in driver and passenger side rear seat.

It protects passenger's head and shoulder in broad collision.

RSAB is consist of air bag and inflator.

Air bag reduces impact of collision by fillied up gas.

Inflator keeps gas and uses it to deploy air bag on collision.

#### 

Never measure resistance of RSAB directly, Current of measuring device may cause unexpected air bag deploy.

#### **DTC Detecting Condition**

#### DTC Description

The SRSCM sets DTC B1430 if the measured resistance value of DRSAB circuit is less than the threshold value.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

Item		Detecting Condition	Possible cause
DTC S	trategy	Check Resistance	
Enable Conditions		Ignition "ON"	Poor connection of connected
Threshold Value		• DRSAB resistance $\leq 1.4\Omega$	<ul> <li>part.</li> <li>Poor connection between shor-</li> </ul>
Diagnostic	Qualificati- on	• More than 2.5s (250ms x 10)	ting bar and release pin. <li>Faulty DRSAB.</li>
Time	De-Qualifi- cation	More than 5s	Faulty SRSCM.

#### **Specification**

Test Condition	Resistance
Ignition ON	$1.4\Omega \le$ Squib resistance $\le 6.4\Omega$

## **RT-169**

#### **Diagnostic Circuit Diagram**



#### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.



SBHRT9554L

#### **MOTICE**

- H : Historical fault
- P : Present fault

#### 5. Is DTC present problem ?

NO

**YES** > Go to "W/Harness Inspection" procedure.

▶ Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

▶ Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

Restraint

## RT-170

### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

NO • Go to "Squib Circuit Inspection" procedure.

### Squib Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Disconnect RDSAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-3F000) to main harness connector.

**WNOTICE** 

If dummy and dummy adaptor are not able to be prepared, use a known-good RDSAB or  $2\Omega$  resistor.

- Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?



NO ► Substitute a known-good RDSAB assembly, and check for proper operation.

If the problem is corrected, replace RDSAB and d then go to "Verification of Vehicle Repair" procedure.

### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect RDSAB connector and SRSCM main harness connector.
- 4. Measure resistance between terminal "2" and "1" of the RDSAB harness connector.

#### Specification : approx. 1 $\Omega$ below

- 5. Is the measured resistance within specifications?
- ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- NO ► Substitute the SRSCM main harness and check for proper operation. If the problem is corrected, replace SRSM main harness and then go to "Verification of Vehicle Repair" procedure.

## Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- Using a scan tool, clear the DTC.
- Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?
- **YES** Go to the applicable troubleshooting procedure.
- NO ► System is performing to specification at this time.

021-62999292

## **RT-171**

## B1431 Side Airbag Rear-Driver Resistance Circuit Short to Ground

#### **General Description**

Rear Side Airbag (hereinafter referred to RSAB) is located in driver and passenger side rear seat.

It protects passenger's head and shoulder in broad collision.

RSAB is consist of air bag and inflator.

Air bag reduces impact of collision by fillied up gas.

Inflator keeps gas and uses it to deploy air bag on collision.

#### 

Never measure resistance of RSAB directly, Current of measuring device may cause unexpected air bag deploy.

#### **DTC Detecting Condition**

### **DTC Description**

The SRSCM sets DTC B1431 if there is a short to ground in DRSAB harness.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

Item		Detecting Condition	Possible cause
DTC Strategy		Check Resistance	Short to ground in DRSAB har-
Enable Conditions		Ignition "ON"	ness.
Threshold Value		DRSAB Squib line Voltage is < 0.9V	Poor connection of connected part.
Diagnostic	Qualificati- on	• More than 2.5s (250ms x 10)	Poor connection between shor- ting bar and release pin.
Time	De-Qualifi- cation	More than 5s	<ul><li>Faulty DRSAB.</li><li>Faulty SRSCM.</li></ul>

#### **Specification**

Test Condition	Voltage
Ignition ON	$0.9V \le Squib line Voltage \le 2.9V$

## Restraint

#### **Diagnostic Circuit Diagram**



#### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.



SBHRT9555L

#### **MOTICE**

- H : Historical fault
- P : Present fault

#### 5. Is DTC present problem ?

NO

**YES** > Go to "W/Harness Inspection" procedure.

▶ Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

► Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

## SRSCM

### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO** • Go to "Squib Circuit Inspection" procedure.

### Squib Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Disconnect RDSAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-3F000) to main harness connector.

**WNOTICE** 

If dummy and dummy adaptor are not able to be prepared, use a known-good RDSAB or  $2\Omega$  resistor.

- Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?



**NO** • Substitute a known-good RDSAB assembly, and check for proper operation.

If the problem is corrected, replace RDSAB and then go to "Verification of Vehicle Repair" procedure.

#### Main harness Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect RDSAB connector and SRSCM main harness connector.
- 4. Measure resistance between terminal "1" or "2" of the RDSAB harness connector and chassis ground.

#### Specification : $\infty$

- 5. Is the measured resistance within specifications?
- ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- NO ► Substitute the SRSCM main harness and check for proper operation. If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

## Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- Using a scan tool, clear the DTC.
- Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?
- **YES** Go to the applicable troubleshooting procedure.
- NO ► System is performing to specification at this time.

021-62999292

## Restraint

## B1432 Side Airbag Rear-Driver Resistance Circuit Short to Battery

#### **General Description**

Rear Side Airbag (hereinafter referred to RSAB) is located in driver and passenger side rear seat.

It protects passenger's head and shoulder in broad collision.

RSAB is consist of air bag and inflator.

Air bag reduces impact of collision by fillied up gas.

Inflator keeps gas and uses it to deploy air bag on collision.

#### 

Never measure resistance of RSAB directly, Current of measuring device may cause unexpected air bag deploy.

#### **DTC Detecting Condition**

#### **DTC Description**

The SRSCM sets DTC B1432 if there is a short to power in DRSAB harness.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

Item		Detecting Condition	Possible cause
DTC Strategy		Check Resistance	Short to power in DRSAB harn-
Enable Conditions		Ignition "ON"	ess. <ul> <li>Poor connection of connected part.</li> </ul>
Threshold Value		DRSAB Squib line voltage is > 2.9V	
Diagnostic	Qualificati- on	• More than 2.5s (250ms x 10)	<ul> <li>Poor connection between shor- ting bar and release pin.</li> </ul>
Time	De-Qualifi- cation	More than 5s	<ul><li>Faulty DRSAB.</li><li>Faulty SRSCM.</li></ul>

#### **Specification**

Test Condition	Voltage
Ignition ON	$0.9V \le Squib line Voltage \le 2.9V$

## **RT-175**

#### **Diagnostic Circuit Diagram**



#### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.



SBHRT9556L

#### **MOTICE**

- H : Historical fault
- P : Present fault

5. Is DTC present problem ?

NO

- YES > Go to "W/Harness Inspection" procedure.
  - ▶ Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

▶ Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

Restraint

## **RT-176**

### Terminal and Connector Inspection

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?
- **YES** Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO** • Go to "Squib Circuit Inspection" procedure.

### Squib Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Disconnect RDSAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-3F000) to main harness connector.

**WNOTICE** 

If dummy and dummy adaptor are not able to be prepared, use a known-good RDSAB or  $2\Omega$  resistor.

- Connect (-) terminal cable to battery and Ignition 4. "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?



**NO •** Substitute a known-good RDSAB assembly, and check for proper operation.

If the problem is corrected, replace RDSAB and then go to "Verification of Vehicle Repair" procedure.

### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect RDSAB connector and SRSCM main harness connector.
- 4. Connect the battery (-) terminal cable to the battery and Ignition "ON" & Engine "OFF".
- 5. Measure voltage between terminal "1 or 2" of the RDSAB harness connector and chassis ground.

#### Specification : approx. 0V

- 6. Is the measured voltage within specifications?
- Substitute a known-good SRSCM, and chec-YES k for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- **NO** > Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?



- **YES** Go to the applicable troubleshooting procedure.
- NO System is performing to specification at this time.

021-62999292

## **RT-177**

### B1433 Side Airbag Rear-Passenger Resistance too High

#### **General Description**

Rear Side Airbag (hereinafter referred to RSAB) is located in driver and passenger side rear seat.

It protects passenger's head and shoulder in broad collision.

RSAB is consist of air bag and inflator.

Air bag reduces impact of collision by fillied up gas.

Inflator keeps gas and uses it to deploy air bag on collision.

#### 

Never measure resistance of RSAB directly, Current of measuring device may cause unexpected air bag deploy.

#### **DTC Detecting Condition**

#### DTC Description

The SRSCM sets DTC B1433 if the measured resistance value of PRSAB circuit is more than the threshold value.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

Item		Detecting Condition	Possible cause
DTC Strategy		Check Resistance	
Enable Conditions		Ignition "ON"	Poor connection of connected part. Poor connection between shor-
Threshold Value		• PRSAB resistance $\geq 6.4\Omega$	
Diagnostic	Qualificati- on	• More than 2.5s (250ms x 10)	ting bar and release pin. <li>Faulty PRSAB.</li>
Time	De-Qualifi- cation	More than 5s	Faulty SRSCM.

#### **Specification**

Test Condition	Resistance
Ignition ON	$1.4\Omega \le$ Squib resistance $\le 6.4\Omega$

## Restraint

#### **Diagnostic Circuit Diagram**



#### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.



SBHRT9557L

#### 

- H : Historical fault
- P : Present fault

5. Is DTC present problem ?

NO

- **YES** > Go to "W/Harness Inspection" procedure.
  - ▶ Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

▶ Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

## WWW.DIGITALKHODRO.COM

## SRSCM

#### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO** • Go to "Squib Circuit Inspection" procedure.

#### **Squib Circuit Inspection**

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Disconnect RPSAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-3F000) to main harness connector.

**WNOTICE** 

If dummy and dummy adaptor are not able to be prepared, use a known-good RPSAB or  $2\Omega$  resistor.

- Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?



NO ► Substitute a known-good RPSAB assembly, and check for proper operation.

If the problem is corrected, replace RPSAB and then go to "Verification of Vehicle Repair" procedure.

#### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect RPSAB connector and SRSCM main harness connector.
- 4. Measure resistance between terminal "2" and "1" of the RPSAB harness connector.

#### **Specification :** approx. 1 $\Omega$ below

- 5. Is the measured resistance within specifications?
- YES ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- NO ► Substitute the SRSCM main harness and check for proper operation. If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

#### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?
- **YES** Go to the applicable troubleshooting procedure.
- NO ► System is performing to specification at this time.

### 021-62999292

## Restraint

### B1434 Side Airbag Rear-Passenger Resistance too Low

#### **General Description**

Rear Side Airbag (hereinafter referred to RSAB) is located in driver and passenger side rear seat.

It protects passenger's head and shoulder in broad collision.

RSAB is consist of air bag and inflator.

Air bag reduces impact of collision by fillied up gas.

Inflator keeps gas and uses it to deploy air bag on collision.

#### 

Never measure resistance of RSAB directly, Current of measuring device may cause unexpected air bag deploy.

#### **DTC Detecting Condition**

#### DTC Description

The SRSCM sets DTC B1434 if the measured resistance value of PRSAB circuit is less than the threshold value.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

Item		Detecting Condition	Possible cause
DTC Strategy		Check Resistance	
Enable Conditions		Ignition "ON"	Poor connection of connected part. Poor connection between shor-
Threshold Value		• PRSAB resistance $\leq 1.4\Omega$	
Diagnostic	Qualificati- on	• More than 2.5s (250ms x 10)	ting bar and release pin. <ul> <li>Faulty PRSAB.</li> </ul>
Time	De-Qualifi- cation	More than 5s	Faulty SRSCM.

#### **Specification**

Test Condition	Resistance
Ignition ON	$1.4\Omega \le$ Squib resistance $\le 6.4\Omega$

## **RT-181**

#### **Diagnostic Circuit Diagram**



#### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.



SBHRT9558L

#### 

- H : Historical fault
- P : Present fault

5. Is DTC present problem ?

NO

- **YES** > Go to "W/Harness Inspection" procedure.
  - ▶ Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

▶ Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

Restraint

## RT-182

### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

NO • Go to "Squib Circuit Inspection" procedure.

### Squib Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Disconnect RPSAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-3F000) to main harness connector.

**WNOTICE** 

If dummy and dummy adaptor are not able to be prepared, use a known-good RPSAB or  $2\Omega$  resistor.

- Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?



NO ► Substitute a known-good RPSAB assembly, and check for proper operation.

If the problem is corrected, replace RPSAB and then go to "Verification of Vehicle Repair" procedure.

### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect RPSAB connector and SRSCM main harness connector.
- 4. Measure resistance between terminal "2" and "1" of the RPSAB harness connector.

#### Specification : approx. 1 $\Omega$ below

- 5. Is the measured resistance within specifications?
- ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- NO ► Substitute the SRSCM main harness and check for proper operation. If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

## Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- Using a scan tool, clear the DTC.
- Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?
- **YES** Go to the applicable troubleshooting procedure.
- NO ► System is performing to specification at this time.
021-62999292

## **RT-183**

## B1435 Side Airbag Rear-Passenger Resistance Circuit Short to Ground

#### **General Description**

Rear Side Airbag (hereinafter referred to RSAB) is located in driver and passenger side rear seat.

It protects passenger's head and shoulder in broad collision.

RSAB is consist of air bag and inflator.

Air bag reduces impact of collision by fillied up gas.

Inflator keeps gas and uses it to deploy air bag on collision.

#### 

Never measure resistance of RSAB directly, Current of measuring device may cause unexpected air bag deploy.

#### **DTC Detecting Condition**

#### **DTC Description**

The SRSCM sets DTC B1435 if there is a short to ground in PRSAB harness.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

Item		Detecting Condition	Possible cause			
DTC Strategy		Check Resistance	Short to ground in PRSAB har-			
Enable Conditions		Ignition "ON"	ness.			
Threshold Value		PRSAB Squib line Voltage is < 0.9V	Poor connection of connected part.			
Diagnostic	Qualificati- on	• More than 2.5s (250ms x 10)	Poor connection between shor- ting bar and release pin.			
- sys	De-Qualifi- cation	More than 5s	<ul><li>Faulty PRSAB.</li><li>Faulty SRSCM.</li></ul>			

#### **Specification**

Test Condition	Voltage
Ignition ON	$0.9V \le Squib line Voltage \le 2.9V$

021-62999292

## Restraint

#### **Diagnostic Circuit Diagram**



#### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.



SBHRT9559L

#### **WNOTICE**

- H : Historical fault
- P : Present fault

#### 5. Is DTC present problem ?

NO

**YES** > Go to "W/Harness Inspection" procedure.

▶ Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

► Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

## 021-62999292

**RT-185** 

# SRSCM

#### Terminal and Connector Inspection

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?
- YES 

   Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO** • Go to "Squib Circuit Inspection" procedure.

#### Squib Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Disconnect RPSAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-3F000) to main harness connector.

**WNOTICE** 

If dummy and dummy adaptor are not able to be prepared, use a known-good RPSAB or  $2\Omega$  resistor.

- 4. Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?



**NO** Substitute a known-good RPSAB assembly, and check for proper operation.

> If the problem is corrected, replace RPSAB and then go to "Verification of Vehicle Repair" procedure.

#### Main harness Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect RPSAB connector and SRSCM main harness connector.
- 4. Measure resistance between terminal "1" or "2" of the RPSAB harness connector and chassis ground.

#### Specification : $\infty$

- 5. Is the measured resistance within specifications?
- YES 
  Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- **NO** > Substitute the SRSCM main harness and check for proper operation. If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

#### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?
- **YES** Go to the applicable troubleshooting procedure.
- NO System is performing to specification at this time.

## Restraint

## B1436 Side Airbag Rear-Passenger Resistance Circuit Short to Battery

#### General Description

Rear Side Airbag (hereinafter referred to RSAB) is located in driver and passenger side rear seat.

It protects passenger's head and shoulder in broad collision.

RSAB is consist of air bag and inflator.

Air bag reduces impact of collision by fillied up gas.

Inflator keeps gas and uses it to deploy air bag on collision.

#### 

Never measure resistance of RSAB directly, Current of measuring device may cause unexpected air bag deploy.

#### **DTC Detecting Condition**

#### **DTC Description**

The SRSCM sets DTC B1436 if there is a short to power in PRSAB harness.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

Item	Detecting Condition	Possible cause	
DTC Strategy	Check Resistance	Short to power in PRSAB harn-	
Enable Conditions	Ignition "ON"	ess.	
Threshold Value	PRSAB Squib line voltage is > 2.9V	Poor connection of connected part.	
Diagnostic On Time De-Qualifi- cation	• More than 2.5s (250ms x 10)	<ul> <li>Poor connection between shorting bar and release pin.</li> <li>Faulty PRSAB.</li> <li>Faulty SRSCM.</li> </ul>	

#### **Specification**

Test Condition	Voltage
Ignition ON	$0.9V \le Squib line Voltage \le 2.9V$

## **RT-187**

#### **Diagnostic Circuit Diagram**



#### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.



SBHRT9560L

#### 

- H : Historical fault
- P : Present fault

#### 5. Is DTC present problem ?

NO

**YES** > Go to "W/Harness Inspection" procedure.

▶ Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

▶ Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

## WWW.DIGITALKHODRO.COM

Restraint

# **RT-188**

### Terminal and Connector Inspection

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

**YES** Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO** • Go to "Squib Circuit Inspection" procedure.

### Squib Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Disconnect RPSAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-3F000) to main harness connector.

**WNOTICE** 

If dummy and dummy adaptor are not able to be prepared, use a known-good RPSAB or  $2\Omega$  resistor.

- Connect (-) terminal cable to battery and Ignition 4. "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?



**NO •** Substitute a known-good RPSAB assembly, and check for proper operation.

If the problem is corrected, replace RPSAB and then go to "Verification of Vehicle Repair" procedure.

### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect RPSAB connector and SRSCM main harness connector.
- 4. Connect the battery (-) terminal cable to the battery and Ignition "ON" & Engine "OFF".
- 5. Measure voltage between terminal "1 or 2" of the RPSAB harness connector and chassis ground.

Specification : approx. 0V

- 6. Is the measured voltage within specifications?
- Substitute a known-good SRSCM, and chec-YES k for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- **NO** > Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?



- **YES** Go to the applicable troubleshooting procedure.
- NO System is performing to specification at this time.

021-62999292

## **RT-189**

## B1451 SIS(Side Impact Sensor)rear-Driver Circuit Short to Ground

#### **General Description**

Rear Side Impact Sensor(RSIS) is located in both side of rear seat back panel detects rear side collision.

When RSIS delivers collision signal to SRSCM, SRSCM checks whether safing sensor located in SRSCM detects collusion. and if both RSIS and safing sensor detects collision simultaneously, SRSCM operates rear side air bag.

#### **DTC Description**

The SRSCM sets DTC B1451 if there is a short to ground in RDSIS harness.

#### **DTC Detecting Condition**

ltem		Detecting Condition	Possible cause
DTC Strategy		Check voltage	
Enable Conditions		Ignition "ON"	
Thresho	ld Value	<ul> <li>RDSIS no acceleration data, and line voltage &lt; 3V</li> </ul>	<ul> <li>Short to ground in RDSIS harn- ess.</li> </ul>
Diagnostic	Qualificati- on	<ul> <li>Ini(Start Up):2.1s (2 times)</li> <li>Steady:500µs x 8 + 2.2s (2 times)</li> </ul>	<ul><li>Faulty RDSIS.</li><li>Faulty SRSCM.</li></ul>
E	De-Qualifi- cation	<ul> <li>Ini(Start Up):1 time</li> <li>Steady:1 time</li> </ul>	

#### **Diagnostic Circuit Diagram**



SBHRT9612L

## WWW.DIGITALKHODRO.COM

## 021-62999292

Restraint

# **RT-190**

### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.

С					
e All DTC	Freeze Frame	DTC Status	Erase Selective DTC		
Description				State	
RR DIRVER SIS	SHORT TO GND				
	e All DTC Description	e AUDTC Freeze Frame	e All DTC Freeze Frame DTC Status Description	e All DTC Freeze Frame DTC Status Erase Selective DTC Description	e All DTC Freeze Frame UTC Status Erase Selective UTC Description State

- H : Historical fault

- P : Present fault

5. Is DTC present problem ?

**YES** • Go to "W/Harness Inspection" procedure.

NO Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

## **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

- 3. Has a problem been found?
- **YES** Repair as necessary and then go to "Verification of Vehicle Repair" procedure.
- NO ▶ Go to "Main harness circuit inspection" procedure.

### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 3. Disconnect RDSIS connector and SRSCM main harness connector.
- 4. Measure resistance between terminal "1" or "2" of the DSIS harness connector and chassis ground.

#### Specification : $\infty$

- 5. Is the measured resistance within specifications?
- **YES** Go to "Component Inspection" procedure.
- NO Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

### **Component Inspection**

- 1. Ignition "ON" & Engine "OFF" and Using a scan tool, clear the DTC.
- 2. Ignition "OFF".
- 3. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 4. Disconnect RDSIS connector .
- 5. Substitute the RDSIS and check for proper operation.
- 6. Is DTC present problem ?
- Substitute a known-good SRSCM, and chec-YES k for proper operation. If the problem is corrected, replace SRSCM an-

d then go to "Verification of Vehicle Repair" procedure.

NO Substitute a known-good RDSIS, and check for proper operation. If the problem is corrected, replace DSIS and then go to "Verification of Vehicle Repair" procedure.

## Verification of Vehicle Repair

Refer to the DTC B1101 : Battery Voltage High.

021-62999292

## **RT-191**

## B1452 SIS(Side Impact Sensor)Rear-Driver Circuit Short to Battery

#### **General Description**

Rear Side Impact Sensor(RSIS) is located in both side of rear seat back panel detects rear side collision.

When RSIS delivers collision signal to SRSCM, SRSCM checks whether safing sensor located in SRSCM detects collusion. and if both RSIS and safing sensor detects collision simultaneously, SRSCM operates rear side air bag.

#### **DTC Description**

The SRSCM sets DTC B1452 if there is short to power harness in DSIS harness.

#### **DTC Detecting Condition**

Item		Detecting Condition			Possible cause
DTC Strategy		•	Check voltage		
Enable Conditions		•	Ignition "ON"	<ul> <li>Short to power in RDSIS has ess.</li> </ul>	
Threshold Value		•	RDSIS no acceleration data, and line voltage >11V		
Diagnostic	Qualificati- on	•	Ini(Start Up):0.2s (100ms x 2) Steady:500µs x 8 + 2.2s (2 times)	•	Faulty RDSIS. Faulty SRSCM.
	De-Qualifi- cation	•	Ini(Start Up):1 time Steady:1 time		0

#### **Diagnostic Circuit Diagram**



SBHRT9612L

## WWW.DIGITALKHODRO.COM

## 021-62999292

Restraint

# RT-192

### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.

D1	TC					
Era	se All DTC	Freeze Frame	DTC Status	Erase Selective DTC		
	Description				State	
B1452	RR DIRVER SIS	SHORT TO BATT				
				SE	BHRT95	562
		CE forical fault				

- н : Historical fai

- P : Present fault

5. Is DTC present problem ?

- **YES** Go to "W/Harness Inspection" procedure.
- NO Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

▶ Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

## **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.
- NO ► Go to "Main harness circuit inspection" procedure.

### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 3. Disconnect RDSIS connector and SRSCM main harness connector.
- 4. Ignition "ON" & Engine "OFF"
- 5. Measure voltage between terminal "1" or "2" of the RDSIS harness connector and chassis ground.

#### Specification : 0V

- 6. Is the measured Voltage within specifications?
- **YES •** Go to "Component Inspection" procedure.
- NO ► Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

## **Component Inspection**

- 1. Ignition "ON" & Engine "OFF" and Using a scan tool, clear the DTC.
- 2. Ignition "OFF".
- Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 4. Disconnect RDSIS connector .
- 5. Substitute the RDSIS and check for proper operation.
- 6. Is DTC present problem ?

d then go to "Verification of Vehicle Repair" procedure.

NO ► Substitute a known-good RDSIS, and check for proper operation.

If the problem is corrected, replace DSIS and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

Refer to the DTC B1101 : Battery Voltage High.

YES ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM an-

021-62999292

## **RT-193**

## B1454 SIS(Side Impact Sensor)Rear-Passenger Circuit Short to Ground

#### **General Description**

Rear Side Impact Sensor(RSIS) is located in both side of rear seat back panel detects rear side collision.

When RSIS delivers collision signal to SRSCM, SRSCM checks whether safing sensor located in SRSCM detects collusion. and if both RSIS and safing sensor detects collision simultaneously, SRSCM operates rear side air bag.

#### **DTC Description**

The SRSCM sets DTC B1454 if there is a short to ground in RPSIS harness.

#### **DTC Detecting Condition**

Item		Detecting Condition			Possible cause
DTC Strategy		•	Check voltage		
Enable Conditions		•	Ignition "ON"	<ul> <li>Short to ground in RPSIS has ess.</li> </ul>	
Threshold Value		•	RDSIS no acceleration data, and line voltage >11V		
Diagnostic	Qualificati- on	•	Ini(Start Up):2.1s (2 times) Steady:500µs x 8 + 2.2s (2 times)	.  .	Faulty RPSIS. Faulty SRSCM.
	De-Qualifi- cation	•	Ini(Start Up):1 time Steady:1 time		0

#### **Diagnostic Circuit Diagram**



SBHRT9613L

## WWW.DIGITALKHODRO.COM

## 021-62999292

Restraint

# RT-194

### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.

DT 🛛	C					
Era	se All DTC	Freeze Frame	DTC Status	Erase Selective DTC		
	Description				State	
81454	RR PASS.SIS SH	HORT TO GND				
				SE	BHRT9	56
ſ						

- H : Historical fault
- P : Present fault

5. Is DTC present problem ?

- **YES** Go to "W/Harness Inspection" procedure.
- NO ▷ Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

▶ Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.
- NO ► Go to "Main harness circuit inspection" procedure.

### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 3. Disconnect RPSIS connector and SRSCM main harness connector.
- 4. Measure resistance between terminal "1" or "2" of the RPSIS harness connector and chassis ground.

#### Specification : $\infty$

- 5. Is the measured resistance within specifications?
- **YES •** Go to "Component Inspection" procedure.
- NO ► Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

### **Component Inspection**

- Ignition "ON" & Engine "OFF" and Using a scan tool, clear the DTC.
- 2. Ignition "OFF".
- 3. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 4. Disconnect RPSIS connector .
- 5. Substitute the RPSIS and check for proper operation.
- 6. Is DTC present problem ?
- YES ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM an-

d then go to "Verification of Vehicle Repair" procedure.

 NO
 ▶ Substitute a known-good RPSIS, and check for proper operation.
 If the problem is corrected, replace RPSIS and then go to "Verification of Vehicle Repair" procedure.

## Verification of Vehicle Repair

Refer to the DTC B1101 : Battery Voltage High.

021-62999292

## **RT-195**

## B1455 SIS(Side Impact Sensor)Rear-Passenger Circuit Short to Battery

#### **General Description**

Rear Side Impact Sensor(RSIS) is located in both side of rear seat back panel detects rear side collision.

When RSIS delivers collision signal to SRSCM, SRSCM checks whether safing sensor located in SRSCM detects collusion. and if both RSIS and safing sensor detects collision simultaneously, SRSCM operates rear side air bag.

#### **DTC Description**

The SRSCM sets DTC B1455 if there is short to power harness in RPSIS harness.

#### **DTC Detecting Condition**

ltem		Detecting Condition			Possible cause
DTC Strategy		•	Check voltage		
Enable Conditions		•	Ignition "ON"		
Threshold Value		•	RPSIS no acceleration data, and line voltage >11V	<ul> <li>Short to power in RPSIS hai ss.</li> </ul>	
Diagnostic	Qualificati- on	•	Ini(Start Up):0.2s (100ms x 2) Steady:500µs x 8 + 2.2s (2 times)	].	Faulty RPSIS. Faulty SRSCM.
<u> </u>	De-Qualifi- cation	•	Ini(Start Up):1 time Steady:1 time		0

#### **Diagnostic Circuit Diagram**



SBHRT9613L

## WWW.DIGITALKHODRO.COM

## 021-62999292

Restraint

# **RT-196**

### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.

DT	TC					
Era	se All DTC	Freeze Frame	DTC Status	Erase Selective DTC		
	Description				State	
B1455	RR PASS.SIS SH	HORT TO BATT.				
	<u>, , , , , , , , , , , , , , , , , , , </u>					
				SE	BHRT95	64

- H : Historical fault

- P : Present fault

5. Is DTC present problem ?

**YES** • Go to "W/Harness Inspection" procedure.

NO ▷ Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

▶ Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

- **YES** Repair as necessary and then go to "Verification of Vehicle Repair" procedure.
- NO Go to "Main harness circuit inspection" procedure.

### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 3. Disconnect RPSIS connector and SRSCM main harness connector.
- 4. Ignition "ON" & Engine "OFF"
- 5. Measure voltage between terminal "1" or "2" of the RPSIS harness connector and chassis ground.

#### Specification : 0V

- 6. Is the measured Voltage within specifications?
- **YES •** Go to "Component Inspection" procedure.
- NO ► Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

## **Component Inspection**

- Ignition "ON" & Engine "OFF" and Using a scan tool, clear the DTC.
- 2. Ignition "OFF".
- 3. Disconnect the battery (-) terminal cable from the battery, and wait at least one minutes.
- 4. Disconnect RPSIS connector .
- 5. Substitute the RPSIS and check for proper operation.
- 6. Is DTC present problem ?
- YES ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM an-

d then go to "Verification of Vehicle Repair" procedure.

 NO
 ▶ Substitute a known-good RPSIS, and check for proper operation.
 If the problem is corrected, replace RPSIS and then go to "Verification of Vehicle Repair" procedure.

## Verification of Vehicle Repair

Refer to the DTC B1101 : Battery Voltage High.

## 021-62999292

021-62999292

## **RT-197**

## B1473 Inflatable Curtain Airbag Front-Driver Resistance too High

#### **General Description**

Curtain Airbag (hereinafter referred to CAB)is located at driver and passenger side of headliner

It protects passenger's head and shoulder from fragments of glass or something sharpen caused by overturn.

CAB is consist of air bag and inflator.

Air bag reduces impact of collision by fillied up gas.

Inflator keeps gas and uses it to deploy air bag on collision.

#### 

Never measure resistance of CAB directly, Current of measuring device may cause unexpected air bag deploy.

#### **DTC Detecting Condition**

#### **DTC Description**

The SRSCM sets DTC B1473 if the measured resistance value of DCAB circuit is more than the threshold value.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

Item			Detecting Condition		Possible cause
DTC Strategy		•	Check Resistance		
Enable Conditions		•	Ignition "ON"	•	<ul> <li>Poor connection of connected part.</li> <li>Poor connection between shor-</li> </ul>
Thre <mark>sho</mark> ld Value		•	DCAB resistance $\geq 6.4\Omega$		
Qualificati- Diagnostic on		•••	More than 2.5s (250ms x 10)	ting bar and release pin. • Faulty DCAB.	ting bar and relea <mark>se pin</mark> . Faulty DCAB.
Time	De-Qualifi- cation	••	More than 5s	Ċ	Faulty SRSCM.

## Restraint

#### **Diagnostic Circuit Diagram**



Monitor Scantool Data

5. Is DTC present problem ?

YES

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.



SBHRT9565L



- H : Historical fault
- P : Present fault

- ► Go to "W/Harness Inspection" procedure.
- NO ► Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

# SRSCM

#### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO** • Go to "Squib Circuit Inspection" procedure.

#### **Squib Circuit Inspection**

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Disconnect DCAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-2G000) to main harness connector.

**MOTICE** 

If dummy and dummy adaptor are not able to be prepared, use a known-good DCAB or  $2\Omega$  resistor.

- Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?



NO ► Substitute a known-good DCAB assembly, and check for proper operation.

If the problem is corrected, replace DCAB and then go to "Verification of Vehicle Repair" procedure.

### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect DCAB connector and SRSCM main harness connector.
- 4. Measure resistance between terminal "Low" and "High" of the DCAB harness connector.

#### Specification : approx. 1 $\Omega$ below

- 5. Is the measured resistance within specifications?
- ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- NO ► Substitute the SRSCM main harness and check for proper operation. If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

#### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?
- **YES** Go to the applicable troubleshooting procedure.
- NO ► System is performing to specification at this time.

021-62999292

## Restraint

## B1474 Inflatable Curtain Airbag Front-Driver Resistance too Low

#### General Description

Curtain Airbag (hereinafter referred to CAB)is located at driver and passenger side of headliner

It protects passenger's head and shoulder from fragments of glass or something sharpen caused by overturn.

CAB is consist of air bag and inflator.

Air bag reduces impact of collision by fillied up gas.

Inflator keeps gas and uses it to deploy air bag on collision.

#### 

Never measure resistance of CAB directly, Current of measuring device may cause unexpected air bag deploy.

#### **DTC Detecting Condition**

#### **DTC Description**

The SRSCM sets DTC B1474 if the measured resistance value of DCAB circuit is less than the threshold value.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

Item		Detecting Condition	Possible cause
DTC Strategy		Check Resistance	
Enable Conditions		Ignition "ON"	Poor connection of connected
Thresho	ld Value	DCAB resistance $\leq 1.4\Omega$	Poor connection between shor-
Diagnostic	Qualificati- on	More than 2.5s (250ms x 10)	ting bar and release pin. <li>Faulty DCAB.</li>
Time	De-Qualifi- cation	More than 5s	Faulty SRSCM.

## **RT-201**

#### **Diagnostic Circuit Diagram**



Monitor Scantool Data

- Data
- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.



SBHRT9566L



- H : Historical fault
- P : Present fault

- ► Go to "W/Harness Inspection" procedure.
- NO ► Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

5. Is DTC present problem ?

YES

Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

Restraint

# **RT-202**

### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

NO • Go to "Squib Circuit Inspection" procedure.

### Squib Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Disconnect DCAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-2G000) to main harness connector.

**MOTICE** 

If dummy and dummy adaptor are not able to be prepared, use a known-good DCAB or  $2\Omega$  resistor.

- Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?



NO ► Substitute a known-good DCAB assembly, and check for proper operation.

If the problem is corrected, replace DCAB and then go to "Verification of Vehicle Repair" procedure.

### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect DCAB connector and SRSCM main harness connector.
- 4. Measure resistance between terminal "Low" and "High" of the DCAB harness connector.

#### Specification : approx. 1 $\Omega$ below

- 5. Is the measured resistance within specifications?
- ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- NO ► Substitute the SRSCM main harness and check for proper operation. If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- Using a scan tool, clear the DTC.
- Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?
- **YES** Go to the applicable troubleshooting procedure.
- NO ► System is performing to specification at this time.

021- 62 99 92 92

# **RT-203**

## B1475 Inflatable Curtain Airbag Front-Driver Resistance Circuit Short to Ground

#### **General Description**

Curtain Airbag (hereinafter referred to CAB)is located at driver and passenger side of headliner

It protects passenger's head and shoulder from fragments of glass or something sharpen caused by overturn.

CAB is consist of air bag and inflator.

Air bag reduces impact of collision by fillied up gas.

Inflator keeps gas and uses it to deploy air bag on collision.

#### 

Never measure resistance of CAB directly, Current of measuring device may cause unexpected air bag deploy.

#### **DTC Detecting Condition**

#### Item **Detecting Condition Possible cause** DTC Strategy **Check Resistance** ٠ Short to ground in DCAB harn-Enable Conditions Ignition "ON" ess. Poor connection of connected Threshold Value DCAB Squib line Voltage is < 0.9V part. Qualificati-Poor connection between shor-More than 2.5s (250ms x 10) on ting bar and release pin. Diagnostic Faulty DCAB. Time De-Qualifi-• More than 5s • Faulty SRSCM. cation

#### Specification

Test Condition	Voltage
Ignition ON	$0.9V \le Squib line Voltage \le 2.9V$

The SRSCM sets DTC B1475 if there is a short to ground in DCAB harness.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

## Restraint

#### **Diagnostic Circuit Diagram**



**Monitor Scantool Data** 

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.



SBHRT9567L



- H : Historical fault
- P : Present fault

- ► Go to "W/Harness Inspection" procedure.
- NO ► Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

5. Is DTC present problem ?

YES

Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

## 021-62999292

**RT-205** 

# SRSCM

#### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO** • Go to "Squib Circuit Inspection" procedure.

#### **Squib Circuit Inspection**

- 1. Ignition "OFF"
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Disconnect DCAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-2G000) to main harness connector.

**WNOTICE** 

If dummy and dummy adaptor are not able to be prepared, use a known-good DCAB or  $2\Omega$  resistor.

- Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?



**NO** Substitute a known-good DCAB assembly, and check for proper operation.

If the problem is corrected, replace DCAB and then go to "Verification of Vehicle Repair" procedure.

#### Main harness Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect DCAB connector and SRSCM main harness connector.
- 4. Measure resistance between terminal "Low" or "High" of the DCAB harness connector and chassis ground.

#### Specification : $\infty$

- 5. Is the measured resistance within specifications?
  - **YES** Substitute a known-good SRSCM, and check for proper operation.

If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.

NO ► Substitute the SRSCM main harness and check for proper operation. If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

## Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?

NO ► System is performing to specification at this time.

**YES** • Go to the applicable troubleshooting procedure.

Restraint

021-62999292

## B1476 Inflatable Curtain Airbag Front-Driver Resistance Circuit Short to Battery

#### General Description

Curtain Airbag (hereinafter referred to CAB)is located at driver and passenger side of headliner

It protects passenger's head and shoulder from fragments of glass or something sharpen caused by overturn.

CAB is consist of air bag and inflator.

Air bag reduces impact of collision by fillied up gas.

Inflator keeps gas and uses it to deploy air bag on collision.

#### 

Never measure resistance of CAB directly, Current of measuring device may cause unexpected air bag deploy.

More than 5s

#### **DTC Detecting Condition**

cation

Item		Detecting Condition	Possible cause	
DTC Strategy		Check Resistance	Short to power in DCAB ha	rne-
Enable Conditions		Ignition "ON"	SS.	
Thre <mark>s</mark> hold Value		DCAB Squib line voltage is > 2.9V	<ul> <li>Poor connection of connection of connection</li> </ul>	cted
Diagnostic	Qualificati- on	• More than 2.5s (250ms x 10)	Poor connection between s ting bar and release pin.	hor-
Time	De-Qualifi-	Mary them 5	Faulty DCAB.	

Faulty SRSCM.

#### Specification

Test Condition	Voltage
Ignition ON	$0.9V \le Squib line Voltage \le 2.9V$

The SRSCM sets DTC B1476 if there is a short to power in DCAB harness.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

## **RT-207**

#### **Diagnostic Circuit Diagram**



Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.



SBHRT9568L



- H : Historical fault
- P : Present fault

- ► Go to "W/Harness Inspection" procedure.
- NO ► Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

5. Is DTC present problem ?

YES

Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

Restraint

# **RT-208**

### Terminal and Connector Inspection

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?
- YES 

   Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO** • Go to "Squib Circuit Inspection" procedure.

### Squib Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Disconnect DCAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-2G000) to main harness connector.

**WNOTICE** 

If dummy and dummy adaptor are not able to be prepared, use a known-good DCAB or  $2\Omega$  resistor.

- Connect (-) terminal cable to battery and Ignition 4. "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?



**NO >** Substitute a known-good DCAB assembly, and check for proper operation.

If the problem is corrected, replace DCAB and then go to "Verification of Vehicle Repair" procedure.

## Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect DCAB connector and SRSCM main harness connector.
- 4. Connect the battery (-) terminal cable to the battery and Ignition "ON" & Engine "OFF".
- 5. Measure voltage between terminal "Low" or "High" of the DCAB harness connector and chassis ground.

Specification : approx. 0V

- 6. Is the measured voltage within specifications?
- Substitute a known-good SRSCM, and chec-YES k for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- **NO** > Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

#### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?



- **YES** Go to the applicable troubleshooting procedure.
- NO System is performing to specification at this time.

021-62999292

## **RT-209**

## B1477 Inflatable Curtain Airbag Front-Passenger Resistance too High

#### **General Description**

Curtain Airbag (hereinafter referred to CAB)is located at driver and passenger side of headliner

It protects passenger's head and shoulder from fragments of glass or something sharpen caused by overturn.

CAB is consist of air bag and inflator.

Air bag reduces impact of collision by fillied up gas.

Inflator keeps gas and uses it to deploy air bag on collision.

#### 

Never measure resistance of CAB directly, Current of measuring device may cause unexpected air bag deploy.

#### **DTC Detecting Condition**

#### **DTC Description**

The SRSCM sets DTC B1477 if the measured resistance value of PCAB circuit is more than the threshold value.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

Item		Detecting Condition	Possible cause
DTC Strategy		Check Resistance	
Enable Conditions		Ignition "ON"	Poor connection of connected
Thre <mark>sho</mark> ld Value		• PCAB resistance $\geq 6.4\Omega$	<ul> <li>Poor connection between shore</li> </ul>
Diagnostic	Qualificati- on	<ul> <li>More than 2.5s (250ms x 10)</li> </ul>	ting bar and release pin. <ul> <li>Faulty PCAB.</li> </ul>
Time بران	De-Qualifi- cation	اولین سامانه دیجیتال تعدید	Faulty SRSCM.

#### Specification

Test Condition	Resistance
Ignition ON	$1.4\Omega \le$ Squib resistance $\le 6.4\Omega$

021-62999292

## Restraint

#### **Diagnostic Circuit Diagram**



Monitor Scantool Data

5. Is DTC present problem ?

YES

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.



SBHRT9569L



- H : Historical fault
- P : Present fault

- ► Go to "W/Harness Inspection" procedure.
- NO ► Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

## WWW.DIGITALKHODRO.COM

# SRSCM

#### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO** • Go to "Squib Circuit Inspection" procedure.

#### **Squib Circuit Inspection**

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Disconnect PCAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-2G000) to main harness connector.

**WNOTICE** If dummy and dummy adaptor are not able to be prepared, use a known-good PCAB or  $2\Omega$  resistor.

- Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?



NO ► Substitute a known-good DCAB assembly, and check for proper operation.

If the problem is corrected, replace DCAB and then go to "Verification of Vehicle Repair" procedure.

#### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect PCAB connector and SRSCM main harness connector.
- 4. Measure resistance between terminal "Low" and "High" of the PCAB harness connector.

#### Specification : approx. 1 $\Omega$ below

- 5. Is the measured resistance within specifications?
- ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- NO ► Substitute the SRSCM main harness and check for proper operation. If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

#### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?
- **YES** Go to the applicable troubleshooting procedure.
- NO ► System is performing to specification at this time.

## Restraint

## B1478 Inflatable Curtain Airbag Front-Passenger Resistance too Low

#### **General Description**

Curtain Airbag (hereinafter referred to CAB)is located at driver and passenger side of headliner

It protects passenger's head and shoulder from fragments of glass or something sharpen caused by overturn.

CAB is consist of air bag and inflator.

Air bag reduces impact of collision by fillied up gas.

Inflator keeps gas and uses it to deploy air bag on collision.

#### 

Never measure resistance of CAB directly, Current of measuring device may cause unexpected air bag deploy.

#### **DTC Detecting Condition**

#### **DTC Description**

The SRSCM sets DTC B1478 if the measured resistance value of PCAB circuit is less than the threshold value.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

Item		Detecting Condition	Possible cause
DTC Strategy		Check Resistance	
Enable Conditions		Ignition "ON"	Poor connection of connected
Threshold Value		• PCAB resistance $\leq 1.4\Omega$	<ul> <li>Poor connection between shor-</li> </ul>
Diagnostic	Qualificati- on	More than 2.5s (250ms x 10)	ting bar and release pin. <li>Faulty PCAB.</li>
Time بران	De-Qualifi- cation	• More than 5s	Faulty SRSCM.

#### Specification

Test Condition	Resistance
Ignition ON	$1.4\Omega \le$ Squib resistance $\le 6.4\Omega$

## **RT-213**

#### **Diagnostic Circuit Diagram**



Monitor Scantool Data

5. Is DTC present problem ?

YES

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.



SBHRT9570L



- H : Historical fault
- P : Present fault

- ► Go to "W/Harness Inspection" procedure.
- NO ► Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

Restraint

# **RT-214**

### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO •** Go to "Squib Circuit Inspection" procedure.

### **Squib Circuit Inspection**

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Disconnect PCAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-2G000) to main harness connector.

**WNOTICE** If dummy and dummy adaptor are not able to be prepared, use a known-good PCAB or  $2\Omega$  resistor.

- Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?



**NO** • Substitute a known-good DCAB assembly, and check for proper operation.

If the problem is corrected, replace DCAB and then go to "Verification of Vehicle Repair" procedure.

### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect PCAB connector and SRSCM main harness connector.
- 4. Measure resistance between terminal "Low" and "High" of the PCAB harness connector.

#### Specification : approx. 1 $\Omega$ below

- 5. Is the measured resistance within specifications?
- ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- NO ► Substitute the SRSCM main harness and check for proper operation. If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- Using a scan tool, clear the DTC.
- Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?
- **YES** Go to the applicable troubleshooting procedure.
- NO ► System is performing to specification at this time.

RT-215

021-62999292

## B1479 Inflatable Curtain Airbag Front-Passenger Resistance Circuit Short to

### Ground

#### **General Description**

Curtain Airbag (hereinafter referred to CAB)is located at driver and passenger side of headliner

It protects passenger's head and shoulder from fragments of glass or something sharpen caused by overturn.

CAB is consist of air bag and inflator.

Air bag reduces impact of collision by fillied up gas.

Inflator keeps gas and uses it to deploy air bag on collision.

#### 

Never measure resistance of CAB directly, Current of measuring device may cause unexpected air bag deploy.

#### **DTC Detecting Condition**

#### **DTC Description**

The SRSCM sets DTC B1479 if there is a short to ground in PCAB harness.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

Item		Detecting Condition	Possible cause
DTC Strategy		Check Resistance	Short to ground in PCAB harn-
Enable C	onditions	Ignition "ON"     ON	ess.
Thresho	Id Value	PCAB Squib line Voltage is < 0.9V	Poor connection of connected part.
Diagnostic	Qualificati- on	• More than 2.5s (250ms x 10)	Poor connection between shor- ting bar and release pin.
Time	De-Qualifi- cation	More than 5s	<ul><li>Faulty PCAB.</li><li>Faulty SRSCM.</li></ul>

#### Specification

Test Condition	Voltage
Ignition ON	$0.9V \le Squib line Voltage \le 2.9V$

## Restraint

#### **Diagnostic Circuit Diagram**



Monitor Scantool Data

5. Is DTC present problem ?

YES

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.



SBHRT9571L



- H : Historical fault
- P : Present fault

- ► Go to "W/Harness Inspection" procedure.
- NO ► Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

## 021-62999292

**RT-217** 

# SRSCM

#### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO** • Go to "Squib Circuit Inspection" procedure.

#### **Squib Circuit Inspection**

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Disconnect PCAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-2G000) to main harness connector.

**WNOTICE** If dummy and dummy adaptor are not able to be

prepared, use a known-good PCAB or  $2\Omega$  resistor.

- Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?



NO • Substitute a known-good DCAB assembly, and check for proper operation.

If the problem is corrected, replace DCAB and then go to "Verification of Vehicle Repair" procedure.

#### Main harness Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect PCAB connector and SRSCM main harness connector.
- 4. Measure resistance between terminal "Low" or "High" of the PCAB harness connector and chassis ground.

#### Specification : $\infty$

- 5. Is the measured resistance within specifications?
- **YES** Substitute a known-good SRSCM, and check for proper operation.

If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.

NO ► Substitute the SRSCM main harness and check for proper operation. If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

#### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?

NO ► System is performing to specification at this time.

**YES** • Go to the applicable troubleshooting procedure.

021-62999292

## Restraint

## B1480 Inflatable Curtain Airbag Front-Passenger Resistance Circuit Short to

### Battery

#### **General Description**

Curtain Airbag (hereinafter referred to CAB)is located at driver and passenger side of headliner

It protects passenger's head and shoulder from fragments of glass or something sharpen caused by overturn.

CAB is consist of air bag and inflator.

Air bag reduces impact of collision by fillied up gas.

Inflator keeps gas and uses it to deploy air bag on collision.

#### 

Never measure resistance of CAB directly, Current of measuring device may cause unexpected air bag deploy.

#### **DTC Detecting Condition**

#### **DTC Description**

The SRSCM sets DTC B1480 if there is a short to power in PCAB harness.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

Item		Detecting Condition	Possible cause
DTC Strategy		Check Resistance	Short to power in PCAB harne-
Enable C	onditions	Ignition "ON"     O	ss.
Threshold Value		PCAB Squib line voltage is > 2.9V	Poor connection of connected part.
Di <mark>agnostic</mark>	Qualificati- on	• More than 2.5s (250ms x 10)	Poor connection between shor- ting bar and release pin.
Time	De-Qualifi- cation	More than 5s	<ul><li>Faulty PCAB.</li><li>Faulty SRSCM.</li></ul>

#### Specification

Test Condition	Voltage
Ignition ON	$0.9V \le Squib line Voltage \le 2.9V$
# **RT-219**

#### **Diagnostic Circuit Diagram**



Monitor Scantool Data

5. Is DTC present problem ?

YES

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.



SBHRT9572L



- H : Historical fault
- P : Present fault

- ► Go to "W/Harness Inspection" procedure.
- NO ► Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

Restraint

# **RT-220**

### Terminal and Connector Inspection

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?
- **YES** Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO** • Go to "Squib Circuit Inspection" procedure.

### Squib Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Disconnect PCAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-2G000) to main harness connector.

**WNOTICE** 

If dummy and dummy adaptor are not able to be prepared, use a known-good PCAB or 2Ω resistor.

- 4. Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?



**NO >** Substitute a known-good DCAB assembly, and check for proper operation.

If the problem is corrected, replace DCAB and then go to "Verification of Vehicle Repair" procedure.

### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect PCAB connector and SRSCM main harness connector.
- 4. Connect the battery (-) terminal cable to the battery and Ignition "ON" & Engine "OFF".
- 5. Measure voltage between terminal "Low" or "High" of the PCAB harness connector and chassis ground.

Specification : approx. 0V

- 6. Is the measured voltage within specifications?
- Substitute a known-good SRSCM, and chec-YES k for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- **NO** > Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?



- **YES** Go to the applicable troubleshooting procedure.
- NO System is performing to specification at this time.

# **RT-221**

### B1481 Driver Airbag Resistance too High(2nd stage)

#### General Description

Driver Air bag module (hereinafter referred to DAB) located at center of steering wheel protects driver by reducing impact of collision.

DAB is consist of air bag, pat cover and inflator.

There are power, circuit for ignition, gas generator and diffuser screen in inflator.

Air bag reduces impact of collision by fillied up gas.

In collision, pat cover splits and through this crack, air bag emerges and deploys.

Inflator generates gas that expands air bag.

Clock spring is located between steering wheel and column. It connects SCSRM to DAB.

#### 

Never measure resistance of DAB directly, Current of measuring device may cause unexpected air bag deploy.

Dual output type airbag deploys two bags in sequence within specified time difference.

It can protect driver with less impact of gas expention force, that can reduce driver's injury

Constituent is the same as single output type airbag.

#### **DTC Detecting Condition**

ودرودرالان		اولین Detecting Condition تعمیرکاران خ	Possible cause
DTC Strategy		Check Resistance	
Enable Conditions		Ignition "ON"	Poor connection of connected part.
Threshold Value		• DAB 2nd stage resistance $\geq 6.4\Omega$	Poor connection between shor-
Diagnostic	Qualificati- on	• More than 2.5s (250ms x 10)	<ul> <li>ting bar and release pin.</li> <li>Faulty DAB.</li> <li>Faulty Clock spring.</li> </ul>
Time	De-Qualifi- cation	More than 5s	Faulty SRSCM.

#### Specification

Test Condition	Resistance	
Ignition ON	$1.4\Omega \le$ Squib resistance $\le 6.4\Omega$	

#### **DTC Description**

The SRSCM sets DTC B1481 if the measured resistance value of DAB circuit is more than the threshold value.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

### 021-62999292

# **RT-222**

# Restraint

#### **Diagnostic Circuit Diagram**



### WWW.DIGITALKHODRO.COM

RT-223

021-62999292

# SRSCM

3. Has a problem been found?



**YES** > Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO** • Go to "Squib Circuit Inspection" procedure.

#### Squib Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Remove the DAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-2G000) to DAB connector of the clock spring harness connector.

#### 

If dummy and dummy adaptor are not able to be prepared, use a known-good DAB or  $2\Omega$  resistor.

#### 

Lay Removed DAB facing upward for unexpected air bag deploy .

- 4. Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?
- YES 
  Go to "Clock Spring Circuit Inspection" procedure.
- **NO** Substitute a known-good DAB assembly, and check for proper operation.

If the problem is corrected, replace DAB and then go to "Verification of Vehicle Repair" procedure.

### **Clock Spring Circuit Inspection**

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Remove DAB module and disconnect SRSCM connector of the clock spring harness.

#### 

Lay Removed DAB facing upward for unexpected air bag deploy.

4. Measure resistance between terminal "Low.2" and "High.2" of the Clock Spring harness connector.

Specification : approx. 1 Ω below

5. Is the measured resistance within specifications?

- YES 
  Go to "Main harness circuit inspection" procedure.
- Substitute the Clock spring and check for pr-NO oper operation. If the problem is corrected, replace Clock sprin-

g and then go to "Verification of Vehicle Repair " procedure.

#### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Remove DAB module and disconnect SRSCM connector of the clock spring harness.

#### WARNING

Lay Removed DAB facing upward for unexpected air bag deploy.

4. Measure resistance between terminal "Low.2" and "High.2" of the DAB harness connector.

**Specification :** approx. 1  $\Omega$  below

- 5. Is the measured resistance within specifications?
- YES Substitute a known-good SRSCM, and check for proper operation.

If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.

Substitute the SRSCM main harness and NO check for proper operation.

> If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

Refer to the DTC B1101 : Battery Voltage High.

# Restraint

### B1482 Driver Airbag Resistance too Low(2nd stage)

#### General Description

Driver Air bag module (hereinafter referred to DAB) located at center of steering wheel protects driver by reducing impact of collision.

DAB is consist of air bag, pat cover and inflator.

There are power, circuit for ignition, gas generator and diffuser screen in inflator.

Air bag reduces impact of collision by fillied up gas.

In collision, pat cover splits and through this crack, air bag emerges and deploys.

Inflator generates gas that expands air bag.

Clock spring is located between steering wheel and column. It connects SCSRM to DAB.

#### 

Never measure resistance of DAB directly, Current of measuring device may cause unexpected air bag deploy.

Dual output type airbag deploys two bags in sequence within specified time difference.

It can protect driver with less impact of gas expention force, that can reduce driver's injury

Constituent is the same as single output type airbag.

#### **DTC Detecting Condition**

DTC	Description
-----	-------------

The SRSCM sets DTC B1482 if the measured resistance value of DAB circuit is less than the threshold value( $1.0\Omega$ )

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

Ite	ودرودرف	خ	Detecting Condition	$\mathbf{O}$	Possible cause
DTC Strategy		•	Check Resistance		<ul> <li>Poor connection of connected part.</li> <li>Poor connection between shor</li> </ul>
Enable Conditions		•	Ignition "ON"	•	
Threshold Value		•	DAB 2nd stage resistance $\leq 1.4\Omega$	•	
Diagnostic	Qualificati-	•	More than 2.5s (250ms x 10)	•	ting bar and release pin. Faulty DAB. Faulty Clock spring.
Time	De-Qualifi- cation	•	More than 5s	•	Faulty SRSCM.

#### Specification

Test Condition	Resistance	
Ignition ON	$1.4\Omega \le$ Squib resistance $\le 6.4\Omega$	

### 021-62999292

# SRSCM

**RT-225** 

### Diagnostic Circuit Diagram



### WWW.DIGITALKHODRO.COM

### 021-62999292

Restraint

# **RT-226**

3. Has a problem been found?



YES 

 Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO** • Go to "Squib Circuit Inspection" procedure.

#### Squib Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Remove the DAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-2G000) to DAB connector of the clock spring harness connector.

#### 

If dummy and dummy adaptor are not able to be prepared, use a known-good DAB or  $2\Omega$  resistor.

#### 

Lay Removed DAB facing upward for unexpected air bag deploy .

- 4. Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?
- YES 
  Go to "Clock Spring Circuit Inspection" procedure.
- **NO** Substitute a known-good DAB assembly, and check for proper operation.

If the problem is corrected, replace DAB and then go to "Verification of Vehicle Repair" procedure.

### **Clock Spring Circuit Inspection**

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- module and disconnect SRSCM 3. Remove DAB connector of the clock spring harness.

#### 

Lay Removed DAB facing upward for unexpected air bag deploy.

4. Measure resistance between terminal "Low.2" and "High.2" of the Clock Spring harness connector.

Specification : approx. 1 Ω below

- 5. Is the measured resistance within specifications?
- YES 
  Go to "Main harness circuit inspection" procedure.
- NO Substitute the Clock spring and check for proper operation. If the problem is corrected, replace Clock spring and then go to "Verification of Vehicle Repair procedure.

#### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Remove DAB module and disconnect SRSCM connector of the clock spring harness.

#### 

Lay Removed DAB facing upward for unexpected air bag deploy.

4. Measure resistance between terminal "Low.2" and "High.2" of the DAB harness connector.

Specification : approx. 1 Ω below

- 5. Is the measured resistance within specifications?
- YES > Substitute a known-good SRSCM, and check for proper operation.

If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.

**NO** Substitute the SRSCM main harness and check for proper operation. If the problem is corrected, replace SRSCM

main harness and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?

**YES** • Go to the applicable troubleshooting procedure.

System is performing to specification at this NO time.

# **RT-227**

### B1483 Driver Airbag Resistance Circuit Short to Ground(2nd stage)

#### **General Description**

Driver Air bag module (hereinafter referred to DAB) located at center of steering wheel protects driver by reducing impact of collision.

DAB is consist of air bag, pat cover and inflator.

There are power, circuit for ignition, gas generator and diffuser screen in inflator.

Air bag reduces impact of collision by fillied up gas.

In collision, pat cover splits and through this crack, air bag emerges and deploys.

Inflator generates gas that expands air bag.

Clock spring is located between steering wheel and column. It connects SCSRM to DAB.

#### 

Never measure resistance of DAB directly, Current of measuring device may cause unexpected air bag deploy.

Dual output type airbag deploys two bags in sequence within specified time difference.

It can protect driver with less impact of gas expention force, that can reduce driver's injury

Constituent is the same as single output type airbag.

#### **DTC Detecting Condition**

ودرودرال		خ	اولین Detecting Condition تعمیرکاران	Possible cause	
DTC Strategy		•	Check Resistance		
Enable Conditions		•	Ignition "ON"	•	Short to ground in DAB harnes- s.
Threshold Value		•	DAB 2nd stage Squib line voltage is $< 0.9V$	•	Poor connection of connected
Diagnostic	Qualificati- on	•	More than 2.5s (250ms x 10)	•	part. Faulty DAB. Faulty Clock spring.
Time	De-Qualifi- cation	•	More than 5s	•	Faulty SRSCM.

#### Specification

Test Condition	Voltage	
Ignition ON	$0.9V \le Squib line Voltage \le 2.9V$	

#### **DTC Description**

The SRSCM sets DTC B1483 if there is a short to ground in DAB harness

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while

## 021-62999292

# **RT-228**

# Restraint

#### **Diagnostic Circuit Diagram**



### WWW.DIGITALKHODRO.COM

## 021-62999292

**RT-229** 

# SRSCM

3. Has a problem been found?



YES 

 Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO** • Go to "Squib Circuit Inspection" procedure.

#### Squib Circuit Inspection

- 1. Ignition "OFF"
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Remove the DAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-2G000) to DAB connector of the clock spring harness connector.

#### 

If dummy and dummy adaptor are not able to be prepared, use a known-good DAB or  $2\Omega$  resistor.

#### 

Lay Removed DAB facing upward for unexpected air bag deploy .

- 4. Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?
- YES 
  Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO** • Go to "Squib Circuit Inspection" procedure.

### Clock Spring Circuit Inspection

- 1. Ignition "OFF" .
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Remove DAB module and disconnect SRSCM connector of the clock spring harness.

#### WARNING

Lay Removed DAB facing upward for unexpected air bag deploy.

4. Measure resistance between terminal "Low.2" or "High.2"of the clock spring harness connector and chassis ground.

Specification :  $\infty$ 

- 5. Is the measured resistance within specifications?
- YES 
  Go to "Main harness circuit inspection" procedure.
- NO Substitute the Clock spring and check for proper operation. If the problem is corrected, replace Clock spring and then go to "Verification of Vehicle Repair procedure.

#### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Remove DAB module and disconnect SRSCM connector of the clock spring harness.

#### 

Lay Removed DAB facing upward for unexpected air bag deploy.

4. Measure resistance between terminal "Low.2" or "High.2"of the DAB harness connector and chassis ground.

#### Specification : $\infty$

- 5. Is the measured resistance within specifications?
- YES Substitute a known-good SRSCM, and check for proper operation.

If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.

▶ Substitute the SRSCM main harness and NO check for proper operation.

> If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

Refer to the DTC B1101 : Battery Voltage High.

# Restraint

021-62999292

### B1484 Driver Airbag Resistance Circuit Short to Battery(2nd stage)

#### **General Description**

**RT-230** 

Driver Air bag module (hereinafter referred to DAB) located at center of steering wheel protects driver by reducing impact of collision.

DAB is consist of air bag, pat cover and inflator.

There are power, circuit for ignition, gas generator and diffuser screen in inflator.

Air bag reduces impact of collision by fillied up gas.

In collision, pat cover splits and through this crack, air bag emerges and deploys.

Inflator generates gas that expands air bag.

Clock spring is located between steering wheel and column. It connects SCSRM to DAB.

#### 

Never measure resistance of DAB directly, Current of measuring device may cause unexpected air bag deploy.

Dual output type airbag deploys two bags in sequence within specified time difference.

It can protect driver with less impact of gas expention force, that can reduce driver's injury

Constituent is the same as single output type airbag.

#### **DTC Detecting Condition**

ودرو د الفان		اولین Detecting Condition تعمیرکاران خادرو		C	Possible cause
DTC Strategy		•	Check Resistance		
Enable Conditions		•	Ignition "ON"	•	Short to power in DAB harness
Threshold Value		•	DAB 2nd stage Squib line voltage is > 2.9V	•	Poor connection of connected
Diagnostic	Qualificati- on	•	More than 2.5s (250ms x 10)	•	part. Faulty DAB. Faulty Clock spring.
Time	De-Qualifi- cation	•	More than 5s	•	Faulty SRSCM.

#### Specification

Test Condition	Voltage	
Ignition ON	$0.9V \le Squib line Voltage \le 2.9V$	

#### **DTC Description**

The SRSCM sets DTC B1484 if there is a short to power in DAB harness

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

## 021-62999292

# SRSCM

**RT-231** 

#### **Diagnostic Circuit Diagram**



# 021-62999292

Restraint

# **RT-232**

#### Terminal and Connector Inspection

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

YES 

 Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO** • Go to "Squib Circuit Inspection" procedure.

#### Squib Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Remove the DAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-2G000) to DAB connector of the clock spring harness connector.

#### **WNOTICE**

If dummy and dummy adaptor are not able to be prepared, use a known-good DAB or  $2\Omega$  resistor.

#### 

Lay Removed DAB facing upward for unexpected air bag deploy .

- 4. Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?



**YES** • Go to "Clock Spring Circuit Inspection" procedure.

**NO** Substitute a known-good DAB assembly, and check for proper operation.

> If the problem is corrected, replace DAB and then go to "Verification of Vehicle Repair" procedure.

### Clock Spring Circuit Inspection

- 1. Ignition "OFF" .
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.

module and disconnect SRSCM 3. Remove DAB connector of the clock spring harness.

#### 

Lay Removed DAB facing upward for unexpected air bag deploy.

- 4. Connect the battery (-) terminal cable to the battery and Ignition "ON" & Engine "OFF".
- 5. Measure Voltage between terminal "Low.2" or "High.2" of the clock spring harness connector and chassis ground.

#### Specification: 0V

- 6. Is the measured resistance within specifications?
- YES 
  Go to "Main harness circuit inspection" procedure.
- **NO** Substitute the Clock spring and check for proper operation.

If the problem is corrected, replace Clock spring and then go to "Verification of Vehicle Repair " procedure.

#### Main harness Circuit Inspection

- 1. Ignition "OFF" and wait at least one minutes.
- 2. Remove DAB module and disconnect SRSCM connector of the main harness.
- 3. Ignition "ON" & Engine "OFF".

#### **WARNING**

Lay Removed DAB facing upward for unexpected air bag deploy.

4. Measure voltage between terminal "Low.2" or "High.2" of the DAB harness connector and chassis ground.

Specification : approx. 0V

- 5. Is the measured voltage within specifications?
- Substitute a known-good SRSCM, and chec-YES k for proper operation.

If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.

**NO** > Substitute the SRSCM main harness and check for proper operation.

> If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

Refer to the DTC B1101 : Battery Voltage High.

### WWW.DIGITALKHODRO.COM

# **RT-233**

### B1485 Passenger Airbag Resistance too High(2nd stage)

#### **General Description**

Passenger Air bag module (hereinafter referred to PAB) located at passenger side crush pad protects passenger by reducing impact of collision.

PAB is consist of air bag, pat cover and inflator.

Air bag reduces impact of collision by fillied up gas.

Inflator keeps gas and uses it to deploy air bag on collision.

#### 

Never measure resistance of PAB directly, Current of measuring device may cause unexpected air bag deploy.

Dual output type airbag deploys two bags in sequence within specified time difference.

It can protect driver with less impact of gas expention force, that can reduce driver's injury

Constituent is the same as single output type airbag.

#### DTC Detecting Condition

#### **DTC Description**

The SRSCM sets DTC B1485 if the measured resistance value of PAB circuit is more than the threshold value.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while

Item		Detecting Condition	Possible cause		
DTC S	trategy	Check Resistance			
Enable Conditions		شرکت دیجیتال خودرو س"Ignition "ON"	Poor connection of connected		
Threshold Value		• PAB 2nd stage resistance $\geq 6.4\Omega$	<ul> <li>part.</li> <li>Poor connection between shor-</li> </ul>		
Diagnostic	Qualificati- on	• More than 2.5s (250ms x 10)	<ul> <li>Four connection between one of the second second</li></ul>		
Time	De-Qualifi- cation	More than 5s	Faulty SRSCM.		

#### Specification

Test Condition	Resistance	
Ignition ON	$1.4\Omega \le$ Squib resistance $\le 6.4\Omega$	

# Restraint

#### **Diagnostic Circuit Diagram**



### WWW.DIGITALKHODRO.COM

# SRSCM

#### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO** • Go to "Squib Circuit Inspection" procedure.

#### **Squib Circuit Inspection**

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Remove the PAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-2E100) to PAB harness connector.

**WNOTICE** 

If dummy and dummy adaptor are not able to be prepared, use a known-good PAB or  $2\Omega$  resistor.

#### **WARNING**

Lay Removed PAB facing upward for unexpected air bag deploy .

- Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?

edure.

**YES** • Go to "Main harness circuit inspection" procedure.

NO ► Substitute a known-good PAB assembly, and check for proper operation. If the problem is corrected, replace PAB and then go to "Verification of Vehicle Repair" proc-

#### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect PAB connector and SRSCM main harness connector.

#### WARNING

Lay Removed PAB facing upward for unexpected air bag deploy .

4. Measure resistance between terminal "Low.2" and "High.2" of the PAB harness connector.

Specification : approx. 1  $\Omega$  below

- 5. Is the measured resistance within specifications?
- YES ► Substitute a known-good SRSCM, and check for proper operation.
   If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- NO ► Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?
- **YES** Go to the applicable troubleshooting procedure.
- NO System is performing to specification at this time.

# Restraint

### B1486 Passenger Airbag Resistance too Low(2nd stage)

#### **General Description**

Passenger Air bag module (hereinafter referred to PAB) located at passenger side crush pad protects passenger by reducing impact of collision.

PAB is consist of air bag, pat cover and inflator.

Air bag reduces impact of collision by fillied up gas.

Inflator keeps gas and uses it to deploy air bag on collision.

#### 

Never measure resistance of PAB directly, Current of measuring device may cause unexpected air bag deploy.

Dual output type airbag deploys two bags in sequence within specified time difference.

It can protect driver with less impact of gas expention force, that can reduce driver's injury

Constituent is the same as single output type airbag.

#### DTC Detecting Condition

#### **DTC Description**

The SRSCM sets DTC B1486 if the measured resistance value of PAB circuit is less than the threshold value.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

Item		Detecting Condition	Possible cause	
DTC Strategy		Check Resistance		
Enable Conditions		شرکت دیجیتال خودرو س"Ignition "ON"	Poor connection of connected	
Threshold Value		• PAB 2nd stage resistance $\leq 1.4\Omega$	<ul> <li>part.</li> <li>Poor connection between shor-</li> </ul>	
Diagnostic	Qualificati- on	• More than 2.5s (250ms x 10)	<ul> <li>ting bar and release pin.</li> <li>Faulty PAB.</li> </ul>	
Time	De-Qualifi- cation	More than 5s	Faulty SRSCM.	

#### Specification

Test Condition	Resistance
Ignition ON	$1.4\Omega \le$ Squib resistance $\le 6.4\Omega$

021-62999292

# **RT-237**

#### **Diagnostic Circuit Diagram**



### WWW.DIGITALKHODRO.COM

Restraint

# **RT-238**

### Terminal and Connector Inspection

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

YES 

 Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO** • Go to "Squib Circuit Inspection" procedure.

### Squib Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Remove the PAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-2E100) to PAB harness connector.

**WNOTICE** 

If dummy and dummy adaptor are not able to be prepared, use a known-good PAB or  $2\Omega$  resistor.

### 

Lay Removed PAB facing upward for unexpected air bag deploy .

- 4. Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?



**YES** • Go to "Main harness circuit inspection" procedure.

NO Substitute a known-good PAB assembly, and check for proper operation.

If the problem is corrected, replace PAB and then go to "Verification of Vehicle Repair" procedure.

## Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect PAB connector and SRSCM main harness connector.

### 

Lay Removed PAB facing upward for unexpected air bag deploy .

4. Measure resistance between terminal "Low.2" and "High.2" of the PAB harness connector.

Specification : approx. 1 Ω below

- 5. Is the measured resistance within specifications?
- YES 

   Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- Substitute the SRSCM main harness and NO check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present?
- **YES** Go to the applicable troubleshooting procedure.
- System is performing to specification at this NO time.

# **RT-239**

### B1487 Passenger Airbag Resistance Circuit Short to Ground(2nd stage)

#### General Description

Passenger Air bag module (hereinafter referred to PAB) located at passenger side crush pad protects passenger by reducing impact of collision.

PAB is consist of air bag, pat cover and inflator.

Air bag reduces impact of collision by fillied up gas.

Inflator keeps gas and uses it to deploy air bag on collision.

#### 

Never measure resistance of PAB directly, Current of measuring device may cause unexpected air bag deploy.

Dual output type airbag deploys two bags in sequence within specified time difference.

It can protect driver with less impact of gas expention force, that can reduce driver's injury

Constituent is the same as single output type airbag.

#### **DTC Detecting Condition**

#### **DTC Description**

The SRSCM sets DTC B1487 if there is a short to ground in PAB harness.

\*In this case, SRSCM checks if there's any fault in circuit by sending current for a while.

Item		Detecting Condition	Possible cause	
DTC Strategy		Check Resistance		
Enable Conditions		شرکت دیجیتال خودرو س"ON" •	Short to ground in PAB harnes-	
Threshold Value		<ul> <li>PAB 2nd stage Squib line voltage is &lt; 0.9V</li> </ul>	<ul> <li>s.</li> <li>Poor connection of connected</li> </ul>	
Diagnostic	Qualificati- on	• More than 2.5s (250ms x 10)	<ul><li>part.</li><li>Faulty PAB.</li></ul>	
Time	De-Qualifi- cation	More than 5s	Faulty SRSCM.	

#### Specification

Test Condition	Voltage
Ignition ON	$0.9V \le Squib line Voltage \le 2.9V$

# Restraint

#### **Diagnostic Circuit Diagram**



### WWW.DIGITALKHODRO.COM

# SRSCM

#### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO** • Go to "Squib Circuit Inspection" procedure.

#### **Squib Circuit Inspection**

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Remove the PAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-2G000) to PAB harness connector.

**WNOTICE** 

If dummy and dummy adaptor are not able to be prepared, use a known-good PAB or  $2\Omega$  resistor.

#### **WARNING**

Lay Removed PAB facing upward for unexpected air bag deploy .

- Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?
- **YES** Go to "Main harness circuit inspection" procedure.
- NO ► Substitute a known-good PAB assembly, and check for proper operation. If the problem is corrected, replace PAB and

then go to "Verification of Vehicle Repair" procedure.

#### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect PAB connector and SRSCM main harness connector.

#### 

Lay Removed PAB facing upward for unexpected air bag deploy .

4. Measure resistance between terminal "Low.2" or "High.2" of the PAB harness connector and chassis ground.

#### Specification : $\infty$

- 5. Is the measured resistance within specifications?
- YES ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- NO Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?
- **YES** Go to the applicable troubleshooting procedure.
- NO ► System is performing to specification at this time.

# Restraint

### B1488 Passenger Airbag Resistance Circuit Short to Battery(2nd stage)

#### General Description

Passenger Air bag module (hereinafter referred to PAB) located at passenger side crush pad protects passenger by reducing impact of collision.

PAB is consist of air bag, pat cover and inflator.

Air bag reduces impact of collision by fillied up gas.

Inflator keeps gas and uses it to deploy air bag on collision.

#### 

Never measure resistance of PAB directly, Current of measuring device may cause unexpected air bag deploy.

Dual output type airbag deploys two bags in sequence within specified time difference.

It can protect driver with less impact of gas expention force, that can reduce driver's injury

Constituent is the same as single output type airbag.

#### DTC Detecting Condition

#### **DTC Description**

The SRSCM sets DTC B1488 if there is a short to powerin PAB harness.\*In this case, SRSCM checks if there's any fault in circuitby sending current for a while.

Item Detecting Condition		Detecting Condition	Possible cause
DTC S	trategy	Check Resistance	
Enable Conditions		شرکت دیجیتال خودرو س"Ignition "ON"	• Short to power in PAB harness.
Threshold Value		<ul> <li>PAB 2nd stage Squib line voltage is &gt; 2.9V</li> </ul>	Poor connection of connected
Diagnostic	Qualificati- on	• More than 2.5s (250ms x 10)	Part.     Faulty PAB.     Faulty SRSCM.
Time	De-Qualifi- cation	More than 5s	

#### **DTC Detecting Condition**

lte	em		Detecting Condition	Possible cause	
DTC Strategy					
Enable Conditions • Igni		•	Ignition "ON"		Short to power in PAB harness.
Threshold Value		•	PAB 2nd stage Squib line voltage is > 2.9V	•	<ul> <li>Poor connection of connected</li> </ul>
Diagnostic	Qualificati- on	•	More than 2.5s (250ms x 10)	•	part. Faulty PAB. Faulty SRSCM.
Time	De-Qualifi- cation	•	More than 5s		

021-62999292

# **RT-243**

#### **Diagnostic Circuit Diagram**



Restraint

# RT-244

### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

- 2. Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO** • Go to "Squib Circuit Inspection" procedure.

### **Squib Circuit Inspection**

- 1. Ignition "OFF".
- 2. Disconnect (-) terminal cable from battery and wait for 1 minutes or more.
- 3. Remove the PAB module and connect the dummy (0957A-38200) and dummy adapter (0957A-2G000) to PAB harness connector.

**WNOTICE** 

If dummy and dummy adaptor are not able to be prepared, use a known-good PAB or  $2\Omega$  resistor.

### 

Lay Removed PAB facing upward for unexpected air bag deploy .

- Connect (-) terminal cable to battery and Ignition "ON" & Engine "OFF" and wait for 30 seconds or more.
- 5. Connect scantool to Data Link Connector(DLC) and clear DTC with scantool and diagnose again.
- 6. Is DTC present problem ?
- **YES** Go to "Main harness circuit inspection" procedure.

NO
 ▶ Substitute a known-good PAB assembly, and check for proper operation.
 If the problem is corrected, replace PAB and then go to "Verification of Vehicle Repair" procedure.

# Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect PAB connector and SRSCM main harness connector.

#### WARNING

# Lay Removed PAB facing upward for unexpected air bag deploy .

- 4. Connect the battery (-) terminal cable to the battery and Ignition "ON" & Engine "OFF".
- Measure voltage between terminal "Low.2" or "High.2" of the PAB harness connector and chassis ground.

#### Specification : approx. 0V

6. Is the measured voltage within specifications?

- YES ► Substitute a known-good SRSCM, and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.
- NO Substitute the SRSCM main harness and check for proper operation.

If the problem is corrected, replace SRSCM main harness and then go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?
- **YES** Go to the applicable troubleshooting procedure.
- NO ► System is performing to specification at this time.

021- 62 99 92 92

# RT-245

### B1620 Internal fault-Replace SRSCM

#### **General Description**

In collision, SRSCM sends current to pertinent air bag for deployment.

Besides SRSCM performs diagnosis of overall air bag system and light warning lamp if there's any fault in it. Main functions of SRSCM are as follows.

- 1. Collision and Passenger presence Detection.
- 2. Determination of BPT, BUPT and air bag deployment in accordane with given condition.
- 3. Internal and external diagnosis of air bag system.
- 4. Warning by warning lamp if there's any fault in airbag system.
- 5. Proffering data for scantool diagnosis.

#### **DTC Detecting Condition**

#### **Detecting Condition** Possible cause Item DTC Strategy Check SRSCM Ignition "ON" **Enable Conditions** Qualificati-SRSCM. N/A on Diagnostic Time De-Qualifi- ∞(infinite-DTC cannot be erased) cation

### Monitor Scantool Data

- Ignition "OFF", connect scantool.
   Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.





- P : Present fault

5. Is DTC present problem ?

**DTC Description** 

SRSCM.

YES ► Internal fault of SRSCM. Substitute with a SRSCM and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure

The SRSCM sets DTC B1620 if there is any fault in

#### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?

**YES** • Go to the applicable troubleshooting procedure.

NO ► System is performing to specification at this time.

021-62999292

### B1650 Crash Recorded in 1st Stage Only(Frontal-Replace SRSCM)

#### General Description

**RT-246** 

In collision, SRSCM sends current to pertinent air bag for deployment.

Besides SRSCM performs diagnosis of overall air bag system and light warning lamp if there's any fault in it. Main functions of SRSCM are as follows.

- 1. Collision and Passenger presence Detection.
- 2. Determination of BPT, BUPT and air bag deployment in accordane with given condition.
- 3. Internal and external diagnosis of air bag system.
- 4. Warning by warning lamp if there's any fault in airbag system.
- 5. Proffering data for scantool diagnosis.

#### DTC Detecting Condition

	U			
Ite	em	Detecting Condition	Possible cause	
DTC S	trategy	Check DAB or PAB deployment		
Enable C	onditions	Ignition "ON"	0	
	Qualificati-	• N/A	• SRSCM.	
Diagnostic	on		DAB or PAB deployment	
Time	De-Qualifi- cation	• ∞(infinite-DTC cannot be erased)		

#### **Monitor Scantool Data**

- 1. Ignition "OFF", connect scantool. 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.



- H : Historical fault
- P : Present fault

- 5. Is DTC present problem ?
- **YES** DTC caused by deployment of front(1ST)air bag. Substitute with a SRSCM and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.

#### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present?

**YES** • Go to the applicable troubleshooting procedure.

System is performing to specification at this NO time.

**DTC Description** 

The SRSCM sets DTC B1650 if DAB or PAB deploys.

### 021-62999292

**RT-247** 

021-62999292

## B1651 Crash Recorded in Front-Driver Side Airbag(Replace SRSCM)

### General Description

In collision, SRSCM sends current to pertinent air bag for deployment.

Besides SRSCM performs diagnosis of overall air bag system and light warning lamp if there's any fault in it. Main functions of SRSCM are as follows.

- 1. Collision and Passenger presence Detection.
- 2. Determination of BPT, BUPT and air bag deployment in accordane with given condition.
- 3. Internal and external diagnosis of air bag system.
- 4. Warning by warning lamp if there's any fault in airbag system.
- 5. Proffering data for scantool diagnosis.

### DTC Detecting Condition

	<u> </u>			
Item		Detecting Condition	Possible cause	
DTC Strategy •		Check DSAB and DCAB deployment		
Enable C	onditions	Ignition "ON"	0	
Diagnostic	Qualificati- on		SRSCM.     DSAB and DCAB deployment	
Time	De-Qualifi- cation	• ∞(infinite-DTC cannot be erased)		

### **Monitor Scantool Data**

- 1. Ignition "OFF", connect scantool. 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.





- P : Present fault

5. Is DTC present problem ?

**DTC Description** 

deploys.

YES DTC caused by deployment of front driver sab front driver sab and driver cab. Substitute with a SRSCM and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.

The SRSCM sets DTC B1651 if DSAB and DCAB

#### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?

**YES** • Go to the applicable troubleshooting procedure.

NO System is performing to specification at this time.

### 021-62999292

021-62999292

# Restraint

### B1652 Crash Recorded in Front-Passenger Side Airbag(Replace SRSCM)

**DTC Description** 

deploys.

#### **General Description**

In collision, SRSCM sends current to pertinent air bag for deployment.

Besides SRSCM performs diagnosis of overall air bag system and light warning lamp if there's any fault in it. Main functions of SRSCM are as follows.

- 1. Collision and Passenger presence Detection.
- 2. Determination of BPT, BUPT and air bag deployment in accordane with given condition.
- 3. Internal and external diagnosis of air bag system.
- 4. Warning by warning lamp if there's any fault in airbag system.
- 5. Proffering data for scantool diagnosis.

#### **DTC Detecting Condition**

			-
lte	Item Detecting Condition		Possible cause
DTC Strategy			
Enable C	onditions	Ignition "ON"	0
Diagnostic	Qualificati- on	· N/A	<ul> <li>SRSCM.</li> <li>PSAB and PCAB deployment</li> </ul>
Time	De-Qualifi- cation	• $\infty$ (infinite-DTC cannot be erased)	

### Monitor Scantool Data

- Ignition "OFF", connect scantool.
   Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.





- P : Present fault

- 5. Is DTC present problem ?
- YES ► DTC caused by deployment of front passenger sab and passenger cab. Substitute with a SRSCM and check for proper operation. If the problem is corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure

#### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?

**YES** • Go to the applicable troubleshooting procedure.

NO System is performing to specification at this time.

### 021-62999292

# Restia

The SRSCM sets DTC B1652 if PSAB and PCAB

021-62999292

# **RT-249**

## B1670 Crash recorded in full stage(Frontal-Replace SRSCM)

#### General Description

In collision, SRSCM sends current to pertinent air bag for deployment.

Besides SRSCM performs diagnosis of overall air bag system and light warning lamp if there's any fault in it. Main functions of SRSCM are as follows.

- 1. Collision and Passenger presence Detection. 2. Determination of BPT and air bag deployment in
- accordane with given condition.
- 3. Internal and external diagnosis of air bag system.

#### **DTC Detecting Condition**

- 4. Warning by warning lamp if there's any fault in airbag system.
- 5. Proffering data for scantool diagnosis.

#### **DTC Description**

When the Crash recorded in full stage in the SRS Control module.

Item Detecting Condition		Possible cause	
DTC Strategy  • Crash recorded in full stage in the SRSCM			
Enable Conditions • Ignition "ON"			
Threshold Value  • Crash recorded in the SRSCM		Crash recorded in the SRSCM	Unable to control SRS system
Diagnostic	Qualificati- on	• N/A	<ul><li>due to internal fault.</li><li>Crash recorded in full stage</li></ul>
Time	De-Qualifi- cation	• ∞(infinite-DTC cannot be erased)	

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.



SBHRT9585

- **MNOTICE**
- H : Historical fault
- P : Present fault

Monitor Scantool Data 5. Is DTC present problem ?

DTC caused by deployment of front full stag-YES e(1ST,2ND)air bag. Substitute with a SRSCM and check for proper operation. If the problem i s corrected, replace SRSCM and then go to "Verification of Vehicle Repair" procedure.

#### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?

Go to the applicable troubleshooting proced-YES ure.

System is performing to specification at this NO time.

# Restraint

021-62999292

### B2500 Warning lamp Failure

#### **General Description**

Air bag warning lamp is located at cluster

When key is in 'ignition on' position, SRSCM performs diagnosis of overall air bag system. If there's no fault, air bag.

Warning lamp in cluster flickers for a while and then goes out.

SRSCM measures voltage of out terminal of warning lamp to check if warning lamp is operated in accordance with signal SRSCM sends.

#### **DTC Description**

The SRSCM sets DTC B2500 if there is an open circuit or short to ground in air bag circuit harness.

#### **DTC Detecting Condition**



#### Diagnostic Circuit Diagram



SBHRT9618L

### WWW.DIGITALKHODRO.COM

### 021-62999292

**RT-251** 

# SRSCM

### Monitor Scantool Data

- 1. Ignition "OFF", connect scantool.
- 2. Ignition "ON"& Engine "OFF", select "Diagnostic Trouble Codes(DTC)" mode.
- 3. Monitor diagnostic trouble code and present of trouble code.
- 4. Using a scan tool, clear the DTC.

D	TC				
Ere	ise All DTC	Fiseze Frame	DTC Status	Erase Selective DTC	
	Description				State
B2500	WARNING LAMP	PFAULT			
-					
				SB	HRT9586
				00	111113000
	ΔΝΟΤΙΟ				

- P : Present fault

5. Is DTC present problem ?

**YES** • Go to "W/Harness Inspection" procedure.

NO ▷ Displaying nothing(no DTC) or DTC with label "H"(historical) shows that Fault is intermittent caused by poor contact in the part's and/or SR-SCM connector or was repaired and SRSCM memory was not cleared.

> Thoroughly check shorting bar/shorting bar release pin and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

> ▶ Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

### **Terminal and Connector Inspection**

1. Many malfunctions in the electrical system are caused by poor harness and terminals.

Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

2. Thoroughly check shorting connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

- 3. Has a problem been found?
- YES ► Repair as necessary and then go to "Verification of Vehicle Repair" procedure.
- NO ► Go to "Main harness circuit inspection" procedure.

### Main harness Circuit Inspection

- 1. Ignition "OFF".
- 2. Disconnect the battery (-) terminal cable from the battery and wait at least one minutes.
- 3. Disconnect SRSCM main harness connector.
- 4. Connect the battery (-) terminal cable to the battery and Ignition "ON" & Engine "OFF".
- 5. Measure voltage between Air bag warning lamp terminal of the SRSCM harness connector and chassis ground.

### Specification : Approx. Batt Voltage

- 6. Is the measured resistance within specifications?
- YES ► Check warning lamp and connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.
- NO ► Check airbag fuse, junction block, Warning Lamp, harness between junction block and SR-SCM . Repair as necessary and go to "Verification of Vehicle Repair" procedure.

### Verification of Vehicle Repair

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTC)" mode
- 2. Using a scan tool, clear the DTC.
- 3. Operate the vehicle within DTC Enable conditions in General information.
- 4. Are any DTC present ?
- **YES** Go to the applicable troubleshooting procedure.
- NO ► System is performing to specification at this time.

### 021- 62 99 92 92

# Restraint

### **Airbag Module**

### Driver Airbag (DAB) Module and Clock Spring

#### Description

Driver Airbag (DAB) is installed in steering wheel and electrically connected to SRSCM via clock spring. It protects the driver from danger by deploying a bag when frontal crash occurs. The SRSCM determines deployment of Driver Airbag (DAB).

#### Components

#### 

Never attempt to measure the circuit resistance of the airbag module (squib) even if you are using the specified tester. If the circuit resistance is measured with a tester, accidental airbag deployment will result in serious personal injury.



SBHRT9012N

- 1. Driver Airbag (DAB)
- 2. Steering Wheel
- 3. Clock Spring

### WWW.DIGITALKHODRO.COM

## 021-62999292

# **Airbag Module**

# RT-253

### Removal

- 1. Disconnect the battery negative cable and wait for at least three minutes before beginning work.
- 2. Remove the airbag module mounting bolts(2EA).



SBHRT8101D

A

B

3. Disconnect the horn connector(A).

5. Remove the steering wheel and steering wheel column cover. (Refer to the Steering System group-Steering Column and Shaft)



#### SBHRT8103D

SBHRT8104D

6. Disconnect the clock spring and horn connector, then remove the clock spring.



SBHRT8102D

4. Release the connector locking pin, then disconnect the driver airbag module connector(B).

#### 

The removed airbag module should be stored in aclean, dry place with the pad cover face up.

# Restraint

021-62999292

# **RT-254**

#### Inspection

#### **Driver Airbag (DAB)**

If any improper parts are found during the following inspection, replace the airbag module with a new one.

#### 

Never attempt to measure the circuit resistance of the airbag module (squib) even if you are using the specified tester. If the circuit resistance is measured with a tester, accidental airbag deployment will result in serious personal injury.

- 1. Check pad cover for dents, cracks or deformities.
- 2. Check the airbag module for denting, cracking or deformation.
- 3. Check hooks and connectors for damage, terminals for deformities, and harness for binds.
- 4. Check airbag inflator case for dents, cracks or deformities.

#### **Clock Spring**

- 1. If, as a result of the following checks, even one abnormal point is discovered, replace the clock spring with a new one.
- 2. Check connectors and protective tube for damage, and terminals for deformities.



(Front View) (Rear View)

#### SBHRT9013N

5. Install the airbag module to the steering wheel to check for fit or alignment with the wheel.

WWW.DIGITALKHODRO.COM

### 021-62999292
# **Airbag Module**

#### Installation

- 1. Remove the ignition key from the vehicle.
- 2. Disconnect the battery negative cable from battery and wait for at least three minutes before beginning work.
- 3. Connect the clock spring harness connector and horn harness connector to the clock spring.
- Set the center position by getting marks between the clock spring and the cover into line. Make an array the mark (▶ ◄) by turning the clock spring clockwise to the stop and then 3 revolutions counterclockwise.
- 5. Install the steering wheel column cover and the steering wheel. (Refer to the Steering System group-Steering Column and Shaft)
- Connect the Driver Airbag (DAB) module connector and horn connector, and then install the Driver Airbag (DAB) module on the steering wheel.
- 7. Secure the Driver Airbag (DAB) with the new mounting bolts.





SBHRT8101D

- 8. Connect the battery negative cable.
- 9. After installing the airbag, confirm proper system operation:
  - Turn the ignition switch ON; the SRS indicator light should be turned on for about six seconds and then go off.
  - Make sure horn button works.

# RT-255

# **RT-256**

# Restraint

# Passenger Airbag (PAB) Module

### Description

The passenger Airbag (PAB) is installed inside the crash pad and protects the front passenger in the event of a frontal crash. The SRSCM determines if and when to deploy the PAB.

### 

Never attempt to measure the circuit resistance of the airbag module (squib) even if you are using the specified tester. If the circuit resistance is measured with a tester, accidental airbag deployment will result in serious personal injury.

#### Components



SBHRT9015N

**RT-257** 

# Airbag Module

### Removal

- 1. Disconnect the battery negative cable and wait for at least three minutes before beginning work.
- 2. Remove the glove box. (Refer to the Body groupcrash pad).
- 3. Disconnect the PAB connector and remove the PAB mounting bolt.



SBHRT9016N

4. Remove the crash pad. (Refer to the Body groupcrash pad).

**WNOTICE** Replace the crash pad which is damaged while PAB is deployed.

- 5. Remove the heater duct from the crash pad.
- 6. Remove the mounting nuts(6EA) from the crash pad. Then remove the passenger airbag.

#### 

The removed airbag module should be stored in a clean, dry place with the airbag cushion up.

### Installation

- 1. Remove the ignition key from the vehicle.
- Disconnect the battery negative cable from battery and wait for at least three minutes before beginning work.
- 3. Place a Passenger Airbag (PAB) on the crash pad and tighten the Passenger Airbag (PAB) mounting nuts.

#### **Tightening torque**

: 5.9  $\sim$  6.9 Nm (0.6  $\sim$  0.7 kgf.m, 4.3  $\sim$  5.0 lb.ft)

- 4. Install the heater duct to the crash pad.
- 5. Install the crash pad. (Refer to the Body group- crash pad)
- 6. Tighten the PAB mounting bolt.

#### **Tightening torque**

- : 6.9  $\sim$  10.8 Nm (0.7  $\sim$  1.1 kgf.m, 5.1  $\sim$  8.0 lb.ft)
- 7. Connect the Passenger Airbag (PAB) harness connector to the SRS main harness connector.
- 8. Reinstall the glove box. (Refer to the Body groupcrash pad)
- 9. Reconnect the battery negative cable.
- 10. After installing the Passenger Airbag (PAB), confirm proper system operation:
  - Turn the ignition switch ON; the SRS indicator light should be turned on for about six seconds and then go off.

WWW.DIGITALKHODRO.COM

# **RT-258**

021-62999292

# Restraint

# Side Airbag (SAB) Module

### Description

The Side Airbags (SAB) are installed inside the front and rear seat and protect the driver and front passenger from danger when side crash occurs. The SRSCM determines deployment of side airbag by using Side Impact Sensor (SIS) signal.

### Components

#### 

Never attempt to measure the circuit resistance of the airbag module (squib) even if you are using the specified tester. If the circuit resistance is measured with a tester, accidental airbag deployment will result in serious personal injury.



SBHRT9017N

**RT-259** 

# Airbag Module

## Removal

### Front Side Airbag

- 1. Disconnect the battery negative cable and wait for at least 3 minutes before beginning work.
- 2. Remove the front seat assembly. (Refer to the Body group- Seat)
- 3. Remove the seatback cover. (Refer to the Body group- Seat)

### **WNOTICE**

When the front side airbag deployed after a collision, replace the seatback as an assembly.

4. Loosen the SAB mounting nuts and remove the SAB module.



### **WARNING**

The removed airbag module should be stored in a clean and dry place with the cushion side up.

SBHRT8301D

### Rear Side Airbag

- 1. Disconnect the battery negative cable and wait for at least 3 minutes before beginning work.
- 2. Remove the rear seat cushion. (Refer to the Body group- Seat)
- 3. Loosen the rear side seatback mounting bolt (1EA).



SBHRT8302D

4. Disconnect the rear side airbag assembly connector, and then remove the rear side seat back.



SBHRT8303D

5. Remove the rear side seatback cover.

#### 

When the rear side airbag deployed after a collision, replace the rear side seatback as an assembly.

# WWW.DIGITALKHODRO.COM

# 021-62999292

# RT-260

# **Restraint**

6. Loosen the rear side airbag module mounting nuts and remove the airbag module.

### 

The removed airbag module should be stored in a clean and dry place with the cushion side up.



### Installation

### Front Side Airbag

#### 

Be sure to install the harness wires not to be pinched or interfered with other parts.

#### **MOTICE**

- Do not open the lid of the side airbag cover.
- Use a new mounting nuts when you replace a side airbag.
- Make sure that the airbag assembly cover is installed properly. Improper installation may prevent the proper deployment.
- 1. Remove the ignition key from the vehicle.
- 2. Disconnect the battery negative cable and wait for at least three minutes.
- 3. Place a Side Airbag (SAB) on the side airbag frame and tighten the side airbag mounting nuts (2EA).

4. Install the new seatback cover. (Refer to the Body

5. Install the front seat assembly, and then connect the

6. Recline and slide the front seat forward fully, make sure the harness wires are not pinched of interfering

8. After installing the Side Airbag (SAB), confirm proper

Turn the ignition switch ON; the SRS indicator light should be turned on for about six seconds

Side Airbag (SAB) harness connector.

7. Reconnect the battery negative cable.

#### **Tightening torque**

0

group-Seat)

with other parts.

system operation:

and then go off.

: 6.8  $\sim$  8.8 Nm (0.7  $\sim$  0.9 kgf.m , 5.1  $\sim$  6.5 lb.ft)

SBHRT8304D

SBHRT8301D

# Airbag Module

# Rear Side Airbag

### 

Be sure to install the harness wires not to be pinched or interfered with other parts.

### 

- Do not open the lid of the side airbag cover.
- Use a new mounting nuts when you replace a side airbag.
- Make sure that the rear side seatback cover is installed properly. Improper installation may prevent the proper deployment.
- 1. Remove the ignition key from the vehicle.
- 2. Disconnect the battery negative cable and wait for at least three minutes.
- 3. Place a Side Airbag (SAB) on the side airbag frame and tighten the side airbag mounting nuts(2EA).

### **Tightening torque**

: 6.8  $\sim$  8.8 Nm (0.7  $\sim$  0.9 kgf.m , 5.1  $\sim$  6.5 lb.ft)

5. Connect the Side Airbag (SAB) harness connector, and then install the rear side seatback.

### Tightening torque

: 16.7  ${\sim}25.5$  Nm (1.7  ${\sim}2.6$  kgf.m, 12.3  ${\sim}$  18.8 lb.ft)



SBHRT8304D

- 6. Reconnect the battery negative cable.
- 7. After installing the Side Airbag (SAB), confirm proper system operation:
  - Turn the ignition switch ON; the SRS indicator light should be turned on for about six seconds and then go off.

#### SBHRT8301D

4. Install the new rear side seatback cover. (Refer to the Body group- Seat)

# **RT-261**

# **RT-262**

# Restraint

# Curtain Airbag (CAB) Module

### Description

Curtain airbags are installed inside the headliner (LH and RH) and protect the driver and passenger from danger when side crash occurs. The SRSCM determines deployment of curtain airbag by using side impact sensor (SIS) signal.

#### 

Never attempt to measure the circuit resistance of the airbag module even if you are using the specified tester. If the circuit resistance is measured with a tester, accidental airbag deployment will result in serious personal injury.

#### Components



SBHRT9006N

**RT-263** 

# Airbag Module

## Removal

- 1. Disconnect the battery negative cable and wait for at least 3 minutes before beginning work.
- 2. Remove the following parts. (Refer to the Body group- Interior)
  - Front pillar trim, Center pillar trim
  - Rear pillar trim, Headliner
- 3. Disconnect the Curtain Airbag harness connector.



4. After loosening the mounting bolts and nuts remove the curtain airbag.

### Installation

- 1. Remove the ignition key from the vehicle.
- 2. Disconnect the battery negative cable and wait for at least three minutes.
- 3. Tighten the Curtain Airbag (CAB) mounting bolts.

### **Tightening torque**

: 11.8  $\sim$  14.7 Nm (1.2  $\sim$  1.5 kgf.m, 8.7  $\sim$  10.9 lb.ft)

### 

- Never twist the airbag module when installing it. If the module is twisted, airbag module may operate abnormally.
- 4. Connect the CAB connector.
- 5. Install the following parts. (Refer to the Body group-Interior)
  - Headliner, Front pillar trim
  - Center pillar trim, Rear pillar trim
- 6. Reconnect the battery negative cable.
- 7. After installing the Curtain Airbag (CAB), confirm proper system operation:
  - Turn the ignition switch ON; the SRS indicator light should be turned on for about six seconds and then go off.



SBHRT8402D

Restraint

# **RT-264**

# Air bag Module Disposal

## Airbag Disposal

### Special Tool Required

Deployment tool 0957A-34100A

Before scrapping any airbags or side airbags (including those in a whole vehicle to be scrapped), the airbags or side airbags must be deployed. If the vehicle is still within the warranty period, before deploying the airbags or side airbags, the Technical Manager must give approval and/or special instruction. Only after the airbags or side airbags have been deployed (as the result of vehicle collision, for example), can they be scrapped. If the airbags or side airbags appear intact (not deployed), treat them with extreme caution. Follow this procedure.

### **Deploying Airbags In The Vehicle**

If an SRS equipped vehicle is to be entirely scrapped, its airbags or side airbags should be deployed while still in the vehicle. The airbags or side airbags should not be considered as salvageable parts and should never be installed in another vehicle.

- 1. Turn the ignition switch OFF, and disconnect the battery negative cable and wait at least three minutes.
- 2. Confirm that each airbag or side airbag is securely mounted.
- 3. Confirm that the special tool is functioning properly by following the check procedure.
  - 1) Driver's Airbag :
    - Remove the driver's airbag and install the SST (0957A-38510).
    - Install the driver's airbag on the steering wheel.
  - 2) Front Passenger's Airbag :
    - Remove the glove box, and then disconnect the 4P connector between the front passenger's airbag and SRS main harness.
    - Install the SST(0957A-2E110).
  - 3) Side Airbag :
    - Disconnect the 2P connector between the side airbag and side wire harness.
    - Install the SST (0957A-3F100).
  - 4) Curtain Airbag :
    - Disconnect the 2P connector between the curtain airbag and wire harness.
    - Install the SST (0957A-38500).

- 5) Seat Belt Pretensioner :
  - Disconnect the 2P connector from the seat belt pretensioner.
  - Install the SST (0957A-38500).
- Place the deployment tool at least thirty feet (10meters) away from the airbag.
- 5. Connect a 12 volt battery to the tool.
- Push the tool's deployment switch. The airbag should deploy (deployment is both highly audible and visible: a loud noise and rapid inflation of the bag, followed by slow deflection)
- Dispose of the complete airbag. No part of it can be reused. Place it in a sturdy plastic bag and seal it securely.

### Deploying the Airbag Out of the Vehicle

If an intact airbag has been removed from a scrapped vehicle, or has been found defective or damage during transit, storage or service, it should be deployed as follows:

- 1. Confirm that the special is functioning properly by following the check procedure on this page.
- Position the airbag face up, outdoors on flat ground at least thirty feet (10meters) from any obstacles or people.

### Disposal of Damaged Airbag

- 1. If installed in a vehicle, follow the removal procedure of driver's airbag front passenger's and side airbag.
- 2. In all cases, make a short circuit by twisting together the two airbag inflator wires.
- 3. Package the airbag in exactly the same packing that the new replacement part come in.

# WWW.DIGITALKHODRO.COM

# 021-62999292

# **Seat Belt Pretensioner**

# Seat Belt Pretensioner

# Seat Belt Pretensioner (BPT)

### Description

The Seat Belt Pretensioners (BPT) are installed inside Center Pillar (LH & RH). When a vehicle crashes with a certain degree of frontal impact, the pretensioner seat belt helps to reduce the severity of injury to the front seat occupants by retracting the seat belt webbing. This prevents the front occupants from thrusting forward and hitting the steering wheel or the instrument panel when the vehicle crashes.

### 

Never attempt to measure the circuit resistance of the Seat Belt Pretensioner (BPT) even if you are using the specified tester. If the circuit resistance is measured with a tester, the pretensioner will be ignited accidentally. This will result in serious personal injury.

#### Components



SBHRT9003L

# 021- 62 99 92 92

# **RT-265**

# WWW.DIGITALKHODRO.COM

# WWW.DIGITALKHODRO.COM

# 021- 62 99 92 92

# **RT-266**

# Restraint

### Removal

- 1. Disconnect the battery negative cable, and wait for at least three minutes before beginning work.
- 2. Remove the lower anchor bolt.
- 3. Remove the following parts. (Refer to the Body group- Seat belt)
  - Door scuff trim
  - Center pillar trim
- 4. Remove the upper anchor bolt.
- 5. Disconnect the Seat Belt Pretensioner connector.



6. Loosen the Seat Belt Pretensioner mounting bolt and



SBHRT8110D

#### Installation

- 1. Remove the ignition key from the vehicle.
- 2. Disconnect the battery negative cable and wait for at least three minutes.
- 3. Install the Seat Belt Pretensioner (BPT) with a bolt.

#### **Tightening torque**

Bolt B : 39.2  $\sim$  53.9 Nm (4.0  $\,\sim\,$  5.5 kgf.m, 28.9  $\sim$  39.8 lb.ft)



SBHRT8110D

- 4. Connect the Seat Belt Pretensioner (BPT) connector.
- 5. Install the upper anchor bolts.

#### **Tightening torque**

- : 39.2 ~ 53.9 Nm (4.0 ~ 5.5 kgf.m, 28.9 ~ 39.8 lb.ft)
- 6. Install the following parts. (Refer to the Body group-Seat belt)
  - Center pillar trim
  - Door scuff trim
- 7. Install the lower anchor bolts.

#### **Tightening torque**

: 39.2  $\sim$  53.9 Nm (4.0  $\sim$  5.5 kgf.m, 28.9  $\sim$  39.8 lb.ft)

- 8. Reconnect the battery negative cable.
- 9. After installing the Seat Belt Pretensioner (BPT), confirm proper system operation:
  - Turn the ignition switch ON; the SRS indicator light should be turned on for about six seconds and then go off.