Engine (G4KC -GSL 2.4)

GENERAL

TIMING SYSTEM

CYLINDER HEAD ASSEMBLY

ENGINE AND TRANSAXLE ASSEMBLY

ENGINE BLOCK

COOLING SYSTEM

LUBRICATION SYSTEM

INTAKE AND EXHAUST SYSTEM

حیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



WWW.DIGITALKHODRO.COM

ENGINE (G4KC - GSL 2.4)

EM -2

GENERAL

SPECIFICATIONS E925C1E3

Description	Specifications	Limit
General Type Number of cylinder Bore Stroke Total displacement Compression ratio Firing order	In-line, Double Overhead Camshaft 4 88mm (3.464in) 97mm (3.819in.) 2359cc (143.90cu.in.) 10.5 1-3-4-2	
Valve timing Intake valve Opens Closes Exhaust Opens (BBDC) Closes (ATDC)	ATDC 11° ~ BTDC 34° ABDC 22° ~ ABDC 67° 34° 10°	
Valve Valve length Intake Exhaust Stem O.D. Intake Exhaust Face angle Margin Intake Exhaust	113.18mm (4.4559in.) 105.89mm (4.1689in.) 5.465 ~ 5.480mm (0.2151 ~ 0.2157in.) 5.458 ~ 5.470mm (0.2149 ~ 0.2153in.) 45.25° ~ 45.75° 1.02mm (0.0401in.) 1.09mm (0.0429in.)	112.93mm (4.4460in) 105.74mm (4.1629in)
Valve stem to valve guide clearance Intake Exhaust	0.020 ~ 0.047mm (0.00078 ~ 0.00185in.) 0.030 ~ 0.054mm (0.00118 ~ 0.00212in.)	0.07mm (0.00275in.) 0.09mm (0.00354in.)
Valve guide Length Intake Exhaust	43.8 ~ 44.2mm (1.7244 ~ 1.7401in.) 43.8 ~ 44.2mm (1.7244 ~ 1.7401in.)	
Valve seat Width of seat contact Intake Exhaust Seat angle	1.16 ~ 1.46mm (0.0457 ~ 0.0575in.) 1.35 ~ 1.65mm (0.0531 ~ 0.0649in.) 44.75° ~ 45.10°	
Valve spring Free length Load Squarences	47.44mm (1.8677in.) 19.0 ± 0.6kg/35.0mm (41.88 ± 1.32lb/1.3779in.) 39.8 ± 1.2kg/26.0mm (87.74 ± 2.64lb/1.0236in.) 1.5° MAX.	

021-62999292

GENERAL

Description	Specifications	Limit
•		Linit
Valve clearance Cold (20°C[68°F])		
Intake	0.17 ~ 0.23mm (0.0067 ~ 0.0090in.)	0.10 ~ 0.30mm
		(0.0039 ~ 0.0118in.)
Exhaust	0.27 ~ 0.33mm (0.0106 ~ 0.0129in,)	0.20 ~ 0.40mm
		(0.0078 ~ 0.0157in.)
Cylinder head		
Flatness of gasket surface	Max. 0.05mm (0.0019in.)	
Flatness of manifold mounting surface	Max. 0.10mm (0.0039in.)	
Oversize rework dimensions of		
Cylinder block		
Cylinder bore	88.00 ~ 88.03mm (3.4645 ~ 3.4657in.)	
Out-of-round and taper of cylinder bore Clearance with piston	Less than 0.05mm (0.0019in.) 0.02 ~ 0.04mm (0.0008 ~ 0.0016in.)	
(To set limits to new parts)	0.02 ~ 0.04mm (0.0000 ~ 0.0010m.)	
Piston		
O.D (To set limits to new parts)	87.97 ~ 88.00mm (3.4634 ~ 3.4645in.)	
Ring groove width		
No.1	1.22 ~ 1.24mm (0.0480 ~ 0.0488in.)	1.26mm (0.0496in.)
No.2	1.22 ~ 1.24mm (0.0480 ~ 0.0488in.)	1.26mm (0.0496in.)
Oil ring Service oversize	2.01 ~ 2.03mm (0.0791 ~ 0.0799in.) 0.25, 0.50mm (0.010, 0.020in.) oversize	2.05mm (0.0807in.)
Piston ring Side clearance	···· ·· ·· ·· ·· ·· ·· ·· ·· ·· ·· ·· ·	
(No.1) (No.1) (No.1) (No.1)	0.03 ~ 0.07mm (0.0012 ~ 0.0027in.)	0.1mm (0.004in.)
No.2	$0.03 \sim 0.07$ mm (0.0012 ~ 0.0027in.)	0.1mm (0.004in.)
Oil ring	0.06 ~ 0.15mm (0.0024 ~ 0.0059in.)	0.2mm (0.008in.)
ں تعمیرکاران خودرو در ا <u>gap</u>	اولين سامانه ديحيتا	
NO. I	0.15 ~ 0.30mm (0.0059 ~ 0.0118in.)	0.6mm (0.0 <mark>236in</mark> .)
No.2 Oil ring side rail	0.30 ~ 0.45mm (0.0118 ~ 0.0177in.) 0.20 ~ 0.70mm (0.0078 ~ 0.0275in.)	0.7mm (0.0275in.) 0.8mm (0.0315in.)
Service oversize	0.25, 0.50mm(0.010, 0.020in.) oversize	0.011111 (0.001011.)
Connecting rod		
Bend		
Twist	0.05mm (0.0020in.) or less	
Connecting rod big end to crankshaft	0.1mm (0.004in.) or less 0.100 ~ 0.250mm (0.0039 ~ 0.010in.)	0.35mm (0.0138in.)
side clearance	0.100 ~ 0.2001111 (0.0000 ~ 0.01011.)	
Connecting rod bearing		
Oil clearance (To seat limits to new parts)	0.028 ~ 0.046mm (0.0011 ~ 0.0018in.)	0.05mm (0.0019in.)

EM -4

ENGINE (G4KC - GSL 2.4)

Description	Specifications	Limit
Camshaft		
Cam height		
Intake	43.80mm (1.7244in.)	
Exhaust	45.00mm (1.7716in.)	
Jourmal O.D.		
Intake	No.1 : 30mm (1.1811in.)	
	No.2,3,4,5 : 24mm (0.9449in.)	
Exhaust	No.1 : 40mm (1.5748in.)	
	No.2,3,4,5 : 24mm (0.9449in.)	
Bearing oil clearance	110.2,0,+,0 . 2+11111 (0.0++011.)	
-	No.1 \pm 0.020 0.057mm (0.00078 0.00224in)	0.00mm (0.003Ein.)
Intake	No.1 : 0.020 ~ 0.057mm (0.00078 ~ 0.00224in.)	0.09mm (0.0035in.)
	No.2,3,4,5 : 0.045 ~ 0.082mm	0.12mm (0.0047in.)
	(0.00177 ~ 0.00323in.)	
Exhaust	No.1,2,3,4,5 : 0.045 ~ 0.082mm	0.12mm (0.0047in.)
	(0.00177 ~ 0.00323in.)	
End play	0.1 ~ 0.22mm (0.0039 ~ 0.0086in.)	0.24mm (0.0094in.)
Crankshaft		
Pin O.D.	47.054 = 47.072 mm (1.9970 = 1.9996 m)	
-	47.954 ~ 47.972mm (1.8879 ~ 1.8886in.)	
Journal O.D.	51.942 ~ 51.960mm (2.0449 ~ 2.0456in.)	
End play	0.07 ~ 0.25mm (0.0027 ~ 0.0098in.)	
Crankshaft bearing	00	
Oil clearance	0.026 ~ 0.048mm (0.0010 ~ 0.0019in.)	
Cooling method	Water-cooled, pressurized. Forced	
cooling method	circulation with electrical fan	
و سامانه (مسئولیت م Radiator	شرکت دیجیتال خودر	
Туре	Pressurized corrugated fin type	
Radiator cap		
Main valve opening pressure	83 ~ 110kpa (12 ~ 16psi, 0.83 ~ 1.1kg/cm ²)	
Vacuum valve opening pressure	-7kpa (-100psi, -0.07kg/cm ²) or less	
Thermostat		
Туре	Wax pellet type with jiggle valve	
Valve opening temperature	82°C (177°F)	
Full-opening temperature	95°C (201°F)	
Coolant pump	Centrifugal type impeller	
Drive belt		
Туре	V-ribbed belt	
Engine coolant temperature sensor		
Туре	Heat-sensitive thermistor type	
Resistance	$2.31 \sim 2.59$ K at 20°C (68°F)	
Air cleaner		
Туре	Dry type	
Element	Unwoven cloth type	
Exhaust pipe		
Muffler	Expansion resonance type	
Suspension system	Rubber hangers	
ouspension system		

GENERAL

SERVICE STANDRDS

Standard value	
Antifreeze	Maxture ratio of anti-freeze in coolant
ETHYLENE GLYCOL BASE FOR ALUMINUM	50%

TIGHTENING TORQUE

Item	Quantity	N.m	kgf.m	lbf.ft
Ladder frame bolt (M8 x 55)	4	23.52 ~ 27.44	2.4 ~ 2.8	17.35 ~ 20.24
Ladder frame bolt (M8 x 103)	6	23.52 ~ 27.44	2.4 ~ 2.8	17.35 ~ 20.24
Balance shaft module bolt	4	$16.66 + 60^{\circ} + 60^{\circ}$	$1.7 + 60^{\circ} + 60^{\circ}$	$12.29 + 60^{\circ} + 60^{\circ}$
Timing chain cover bolt (M8)	6	18.62 ~ 22.54	1.9 ~ 2.3	13.74 ~ 16.63
Timing chain cover bolt (M6)	7	7.84 ~ 9.8	0.8 ~ 1.0	5.78 ~ 7.23
Oil pan bolt (M6 x 10)	16	9.8 ~ 11.76	1.0 ~ 1.2	7.23 ~ 8.67
Oil pan bolt (M8 x 103)	2	26.46 ~ 30.38	2.7 ~ 3.1	19.52 ~ 22.41
Engine support bracket bolt (M10 x 40)	1	39.2 ~ 44.1	4.0 ~ 4.5	28.92 ~ 32.53
Engine support bracket bolt (M10 x 45)	2	39.2 ~ 44.1	4.0 ~ 4.5	28.92 ~ 32.53
Engine support bracket bolt (M8 x 30)	1	19.6 ~ 24.5	2.0 ~ 2.5	14.46 ~ 18.07
Camshaft bearing cap bolt (M6)	16	10.78 ~ 12.74	1.1 ~ 1.3	7.95 ~ 9.39
Camshaft bearing cap bolt (M8)	4	27.44 ~ 31.36	2.8 ~ 3.2	20.24 ~ 23.14
Cylinder head bolt	جيتون حو	34.3 + 90° + 90°	3.5 + 90° +90°	25.3 + 90° + 90°
Engine hanger bolt	2	19.6 ~ 26.46	2.0 ~ 2.7	14 <mark>.46 ~ 19.52</mark>
Cylinder head cover bolt	انه 18 جيا	7.84 ~ 9.8	0.8 ~ 1.0	5.78 <mark>~ 7.2</mark> 3
Crankshaft pulley bolt	1	166.6 ~ 176.4	17 ~ 18	122.9 ~ 130.13
Flywheel bolt	7	117.6 ~ 127.4	12 ~ 13	86.75 ~ 93.98
Drive plate bolt	7	117.6 ~ 127.4	12 ~ 13	86.75 ~ 93.98
Timing chain tensioner bolt	2	9.8 ~ 11.76	1.0 ~ 1.2	7.23 ~ 8.67
Timing chain tensioner arm bolt	1	9.8 ~ 11.76	1.0 ~ 1.2	7.23 ~ 8.67
Timing chain guide bolt	3	9.8 ~ 11.76	1.0 ~ 1.2	7.23 ~ 8.67
OCV bolt	1	9.8 ~ 11.76	1.0 ~ 1.2	7.23 ~ 8.67
CVVT & camshaft sprocket bolt	1	53.9 ~ 63.7	5.5 ~ 6.5	39.7 ~ 47.0
Balance shaft chain tensioner arm bolt	1	9.8 ~ 11.76	1.0 ~ 1.2	7.23 ~ 8.67
Balance shaft chain guide bolt	2	9.8 ~ 11.76	1.0 ~ 1.2	7.23 ~ 8.67
Balance shaft chain tensioner bolt	2	9.8 ~ 11.76	1.0 ~ 1.2	7.23 ~ 8.67
Water pump bolt	5	19.6 ~ 26.46	2.0 ~ 2.7	14.46 ~ 19.52
A/C bracket bolt	4	19.6 ~ 23.52	2.0 ~ 2.4	14.46 ~ 17.35
P/S bracket bolt	2	44.1 ~ 53.9	4.5 ~ 5.5	32.53 ~ 39.70
Tensioner & idler bracket bolt	7	39.2 ~ 44.1	4.0 ~ 4.5	28.92 ~ 32.53
Water temp. control bolt	2	14.7 ~ 21.56	1.5 ~ 2.2	10.84 ~ 15.90
Water temp. control nut	1	19.6 ~ 26.46	2.0 ~ 2.7	14.46 ~ 19.52

WWW.DIGITALKHODRO.COM

EM -6

ENGINE (G4KC - GSL 2.4)

Item	Quantity	N.m	kgf.m	lbf.ft
Water inlet pipe bolt	2	19.6 ~ 26.46	2.0 ~ 2.7	14.46 ~ 19.52
Oil level gauge assembly bolt	1	7.84 ~ 11.76	0.8 ~ 1.2	5.78 ~ 8.67
Ignition coil bolt	4	3.92 ~ 5.88	0.4 ~ 0.6	2.89 ~ 4.34
Intake manifold bolt	3	18.62 ~ 27.44	1.9 ~ 2.8	13.73 ~ 20.24
Intake manifold nut	2	18.62 ~ 27.44	1.9 ~ 2.8	13.73 ~ 20.24
Intake manifold stay bolt	4	18.62 ~ 27.44	1.9 ~ 2.8	13.73 ~ 20.24
Exhaust manifold heat protector bolt	4	18.62 ~ 27.44	1.9 ~ 2.8	13.73 ~ 20.24
Exhaust manifold nut	7	39.2 ~ 44.1	4.0 ~ 4.5	28.92 ~ 32.53
Exhaust manifold stay bolt (M8)	2	18.62 ~ 27.44	1.9 ~ 2.8	13.74 ~ 20.24
Exhaust manifold stay bolt (M10)	1	51.94 ~ 57.82	5.4 ~ 5.9	38.3 ~ 42.6
Front muffler bolt	2	39.2 ~ 58.8	4.0 ~ 6.0	28.92 ~ 43.37
Engine cover nut	2	3.92 ~ 5.88	0.4 ~ 0.6	2.89 ~ 4.34
Engine cover mounting bracket bolt	2	7.84 ~ 11.76	0.8 ~ 1.2	5.78 ~ 8.67
Crankshaft position sensor bolt	1	3.92 ~ 5.88	0.4 ~ 0.6	2.89 ~ 4.34
Oxygen sensor	1	34.3 ~ 44.1	3.5 ~ 4.5	25.30 ~ 32.53
Knock sensor	1	16.66 ~ 25.48	1.7 ~ 2.6	12.29 ~ 18.79
Oil temperature sensor	1	19.6 ~ 39.2	2.0 ~ 4.0	14.46 ~ 2 <mark>8.9</mark> 2
Camshaft position sensor	1	3.92 ~ 5.88	0.4 ~ 0.6	2.89 ~ 4.34
Oil pressure switch	يتال حودر	7.84 ~ 11.76	0.8 ~ 1.2	5.78 ~ 8.67
Main bearing cap bolt	10	26.46 + 45°	2.7 + 45°	19. <mark>52 + 45</mark> °
ن تعمیرکاران خودرو در ایOil filter	نه ديجيتا	11.76 ~ 15.68	1.2 ~ 1.6	8.67 ~ <mark>11.57</mark>
Connecting rod bearing cap bolt	8	19.6 + 90°	2.0 + 90°	14.46 + 90°

021-62999292

EM -7

GENERAL

COMPRESSION E6F7C0C1

🔟 ΝΟΤΕ

If the there is lack of power, excessive oil consumption or poor fuel economy, measure the compression pressure.

- Warm up and stop engine. Allow the engine to warm up to normal operating temperature.
- 2. Remove ignition coils. (See EE group ignition)
- 3. Remove spark plugs. Using a 16mm plug wrench, remove the 4 spark plugs.
- 4. Check cylinder compression pressure.
 - a. Insert a compression gauge into the spark plug hole.

- e. If the cylinder compression in 1 or more cylinders is low, pour a small amount of engine oil into the cylinder through the spark plug hole and repeat steps (a) through (c) for cylinders with low compression.
 - If adding oil helps the compression, it is likely that the piston rings and/or cylinder bore are worn or damaged.
 - If pressure stays low, a valve may be sticking or seating is improper, or there may be leakage past the gasket.
- 5. Reinstall spark plugs.
- 6. Install ignition coils. (See EE group ignition)



KCRF134B

- b. Fully open the throttle.
- c. While cranking the engine, measure the compression pressure.

NOTE

Always use a fully charged battery to obtain engine speed of 200 rpm or more.

d. Repeat steps (a) through (c) for each cylinder.



This measurement must be done in as short a time as possible.

Compression pressure : 1,283kPa (13.0kgf/cm², 185psi) Minimum pressure : 1,135kPa (11.5kgf/cm², 164psi) Difference between each cylinder : 100kPa (1.0kgf/cm², 15psi) or less



WWW.DIGITALKHODRO.COM

ENGINE (G4KC - GSL 2.4)

EM -8

VALVE CLEARANCE INSPECTION AND ADJUSTMENT

🚺 ΝΟΤΕ

Inspect and adjust the valve clearance when the engine is cold (Engine coolant temperature : 20° C) and cylinder head is installed on the cylinder block.

1. Remove the engine cover(A).



Remove the cylinder head cover.
 a. Disconnect the ignition coil connect(A) and remove the ignition coil.



KCRF141E

c. Loosen the cylinder head cover bolts and then remove the cover(A) and gasket.



KCRF115A

- 3. Set No.1 cylinder to TDC/compression.
 - a. Turn the crankshaft pulley and align its groove with the timing mark "T" of the lower timing chain cover.



KCRF107A

021-62999292

KCRF131A

b. Disconnect the P.C.V hose(A) and the breather hose from the cylinder head cover.

WWW.DIGITALKHODRO.COM

021-62999292

GENERAL

b. Check that the mark(A) of the camshaft timing sprockets are in straight line on the cylinder head surface as shown in the illustration.
 If not, turn the crankshaft one revolution (360°)



ACRF007A

- 4. Inspect the valve clearance.
 - a. Check only the valve indicated as shown. [No. 1 cylinder : TDC/Compression] measure the valve clearance.



No1. Cylinder TDC/compression

ECRF001A

• Using a thickness gauge, measure the clearance between the tappet and the base circle of camshaft.

• Record the out-of-specification valve clearance measurements. They will be used later to determine the required replaement adjusing tappet.

Valve clearance

Specification Engine coolant temperature : $20^{\circ}C$ [68°F] Limit Intake : 0.10 ~ 0.30mm (0.0039 ~ 0.0118in.) Exhaust : 0.20 ~ 0.40mm (0.0079 ~ 0.0157in.)

EM -9

- b. Turn the crankshaft pulley one revolution (360°) and align the groove with timing mark "T" of the lower timing chain cover.
- c. Check only valves indicated as shown. [NO. 4 cylinder : TDC/compression]. Measure the valve clearance.



No4. Cylinder TDC/compression

ECRF002A

- 5. Adjust the intake and exhaust valve clearance.
 - a. Set the No.1 cylinder to the TDC/compression. (See page EM - 8)
 - b. Marks on the timing chain and camshaft timing sprockets.
 - c. Remove the service hole bolt(A) of the timing chain cover.



ACRF004A

\Lambda CAUTION

The bolt must not be reused once it has been assembled.

d. Insert a thin rod in the service hole of the timing chain cover and release the ratchet.

WWW.DIGITALKHODRO.COM

EM -10

e. Remove the front camshaft bearing cap(A).



KCRF153A

- f. Remove the exhaust camshaft sprocket.
- g. Remove the exhaust camshaft bearing cap and exhaust camshaft. (See page EM 35)
- h. Remove the intake camshaft bearing cap and intake camshaft. (See page EM - 35)

When disconnect the timing chain from the camshaft timing sprocket, holding the timing chain.

i. Tie a timing chain with a string.

Be careful not to drop anything inside timing chain cover.

j. Measure the thickness of the removed tappet using a micrometer.



EDKE889D

k. Calculate the thickness of a new tappet so that the valve clearance comes within the specificified value.

ENGINE (G4KC - GSL 2.4)

Valve clearance (Engine coolant temperature : 20°C)

- T : Thickness of removed tappet A : Measured valve clearance
- N : Thickness of new tappet
- Intake : N = T + [A 0.20mm(0.0079in.)]
- Exhaust : N = T + [A-0.30mm (0.0118in.)]
 - I. Select a new tappet with a thickness as close as possible to the caculated value.

🔟 ΝΟΤΕ

Shims are available in 47size increments of 0.015mm (0.0006in.) from 3.00mm (0.118in.) to 3.690mm (0.1452in.)

- m. Place a new tappet on the cylinder head.
- n. Hold the timing chain, and place the intake camshaft and timing sprocket assembly.
- o. Align the matchmarks on the timing chain and camshaft timing sprocket.
- Install the intake and exhaust camshaft. (See page EM 44)
- q. Install the front bearing cap. (See page EM 44)
- r. Install the sevice hole bolt.

Tightening torque

S.

12 ~ 15N.m (1.2 ~ 1.5kgf.m, 8.8 ~ 11.0lbf.ft)

Turn the crankshaft two turns in the operating direction(clockwise) and realign crankshaft sprocket and camshaft sprocket timing marks.



ACRF007A

t. Recheck the valve clearance.

Valve clearance (Engine coolant temperature : 20°C) [Specification] Intake : 0.17 ~ 0.23mm (0.0067 ~ 0.0090in.) Exhaust : 0.27 ~ 0.33mm (0.0106 ~ 0.0129in.)

WWW.DIGITALKHODRO.COM

GENERAL

TROUBLESHOOTING EA865ECE

Symption	Suspect area	Remedy (See page)
Engine misfire with abnormal internal lower engine noises.	Worn crankshaft bearings Loose or improperly engine filwheel	Replace the crankshaft and bearings as required. Repair or replace the flywheel as required.
	Worn piston rings (Oil cousnmption may or may not cause the engine to misfire.)	Inspect the cylinder for a loss of compression. Repair or replace as required.
	Worn crankshaft thrust bearings	Replace the crankshaft and bearings as required
Engine misfire with abnormal valve	Stuck valves. (Carbon buidup on the valve stem)	Repair or replace as required
train noise.	Excessive worn or mis-aligned timing chain	Replace the timing chain and sprocket as required.
	Worn camshaft lobes.	Replace the camshaft and valve lifters.
Engine misfire with coolant consumption	 Faulty cylinder head gasket and/or cranking or other damage to the cylinder head and engine block cooling system. Coolant consumption may or may not cause the engine to overheat. 	 Inspect the cylinder head and engine block for damage to the coolant passages and/or a faulty head gasket. Repair or replace as required.
Engine misfire with excessive oil	Worn valves, guides and/or valve stem oil seals.	Repair or replace as required.
consumption	Worn piston rings. (Oil consumption may or may not cause the engine to misfire)	 Inspect the cylinder for a loss of compression. Repair or replace as required.
Engine noise on start-up, but only	Incorrect oil viscosity	Drain the oil.Install the correct viscosity oil.
lasting a few seconds.	Worn crankshaft thrust bearing.	Inspect the thrust bearing and crankshaft.Repair or replace as required.
Upper engine noise,	Low oil pressure	Repair or repalce as required.
regardless of engine speed.	Broken valve spring.	Replace the valve spring.
	Worn or dirty valve lifters.	Replace the valve lifters.
	Stetched or broken timing chain and/or damaged sprocket teeth.	Replace the timing chain and sprockets.
	Worn timing chain tensioner, if applicable.	Replace the timing chain tensioner as required.
	Worn camshaft lobes.	 Inspect the camshaft lobes. Replace the timing camshaft and valve lifters as required.
	Worn valve guides or valve stems.	Inspect the valves and valve guides, then repair as required.
	Stuck valves. (Carbon on the valve stem or valve seat may cause the valve to stay open.	Inspect the valves and valve guides, then repair as required.
	Worn drive belt, idler, tensioner and bearing.	Replace as required

EM -12

ENGINE (G4KC - GSL 2.4)

Symption	Suspect area	Remedy (See page)
Lower engine noise,	Low oil pressure	Repair or required.
regardless of engine speed	Loose or damaged flywheel.	Repair or replace the flywheel.
speed	Damaged oil pan, contacting the oil pump screen.	Inspect the oil pan.Inspect the oil pump screen.Repair or replace as required.
	Oil pump screen loose, damaged or restircted.	Inspect the oil pump screen.Repair or replace as required.
	Excessive piston-to-cylinder bore clearance.	 Inspect the piston, piston pin and cylinder bore. Repair as required.
	Excessive piston pin-to-piston clearance	 Inspect the piston, piston pin and the connecting rod. Repair or replace as required.
مراحد البلن	Excessive connecting rod bearing clearance	 Inspect the following components and repair as required. The connecting rod bearings. The connecting rods. The crankshaft pin journals.
	Excessive crankshaft bearing clearance	Inspect the following components, and repair as required. • The crankshaft bearings. • The crankshaft main journals. • The cylinder block
	Incorrect piston, piston pin and connecting rod installation	 Verify the piston pins and connecting rods are installed correctly. Repair as required.
Engine noise under	Low oil pressure	Repair or replace as required.
load	Excessive connecting rod bearing clearance	Inspect the following components and repair as required : • The connecting rod bearings. • The connecting rods. • The crankshaft
	Excessive crankshaft bearing clearance	 Inspect the following components, and repair as required. The crankshaft bearings. The crankshaft main journals. The cylinder block.

GENERAL

EM -13

Symption	Suspect area	Remedy (See page)
Engine will not crank-crankshaft will not rotate	 Hydraulically locked cylinder Coolant/antifreeze in cylinder. Oil in cylinder. Fuel in cylinder 	 Remove spark plugs and check for fluid. Inspect for broken head gasket. Inspect for cracked engine block or cylinder head. Inspect for a sticking fuel injector and/or leaking fuel regulator.
	Broken timing chain and/or timing chain and/or timing chain gears.	 Inspect timing chain and gears. Repair as required.
	Material in cylinder • Broken valve • Piston material • Foreign material	 Inspect cylinder for damaged components and/or foreign materials. Repair or replace as required.
	Seized crankshaft or connecting rod bearings.	 Inspect crankshaft and connecting rod bearing. Repair as required.
	Bent or broken connecting rod.	 Inspect connecing rods. Repair as required.
	Broken crankshaft	 Inspect crankshaft. Repair as required.

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

021-62999292

EM -14

SPECIAL TOOLS E12DA3A1

ENGINE (G4KC - GSL 2.4)

Tool (Number and name)	Illustration	Use
Crankshaft front oil seal installer (09214-3K000) (09231-H1100)	B O C C C C C C C C C C C C C C C C C C	Installation of the front oil seal A : 09214-3K000 B : 09231-H1100
Flywheel stopper (09231-3K000)	ACRF002A	Removal and installation of the flywheel and crankshaft pulley.
Torque angle adapter (09221-4A000) انه (مسئولیت محدود) رکاران خودرو در ایران		Installtion of bolts & nuts needing an angular method
Valve stem oil seal installer (09222-4A000)	LCACO30D	Installation of the valve stem oil seal

021-62999292

GENERAL

EM -15

Tool (Number and name)	Illustration	Use
Valve spring compressor & holder (09222-3K000) (09222-3K100)	A B ECRF003A	Removal and installation of the intake or exhaust valve A : 09222-3K000 B : 09222-3K100 (holder)
Crankshaft rear oil seal installer (09214-3K100) (09231-H1100)	A A A CRF003A	Installation of the crankshaft rear oil seal A : 09214-3K100 B : 09231-H1100

حیجیتال خود و سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

EM -16

ENGINE (G4KC - GSL 2.4)

TIMING SYSTEM

COMPONENT EA04D90F



- 1. Cylinder head cover
- 2. Exhaust camshaft sprocket
- 3. CVVT assembly
- 4. Timing chain
- 5. Timing chain tensioner arm
- 6. Timing chain guide

- 7. Crankshafe sprocket
- 8. Oil jet
- 9. Timing chain tensioner
- 10. Timing chain cover
- 11. Oil pan

ECRF004A

WWW.DIGITALKHODRO.COM

TIMING SYSTEM



- 1. Balance shaft module
- 2. Cylinder block
- 3. Balance shaft chain

- 4. Balance shaft chain sprocket
- 5. Balance shaft chain guide
- 6. Balance shaft chain tensioner arm

ECRF005A

021-62999292

EM -18

REMOVAL EE9F0A26

Engine removal is not required for this procedure.

TIMING CHAIN

1. Remove the engine cover(A).



ñ

KCRF107A

ENGINE (G4KC - GSL 2.4)

- 5. Remove the engine mount bracket.
 - 1) Set the jack to the engine oil pan.

KCRF137A

021-62999292

EM -19

- TIMING SYSTEM
- 6. Temporarily loosen the water pump pulley bolts.
- 7. Remove drive belt(A).



8. Remove the idler pulley(A).

В

10. Remove the water pump pulley(A).



KCRF110A

- KCRF108A
- 11. Remove the crankshaft pulley(B).
- 12. Remove the engine support bracket(C).
- 13. Disconnect the ignition coil connector(A).



9. Remove the drive belt tensioner pulley and tensioner(B).

🔟 ΝΟΤΕ

6)

Tensioner pulley bolt is left - handed screw.

14. Remove the ignition coil(A).



KCRF111A

KCRF131A

021-62999292

WWW.DIGITALKHODRO.COM

021- 62 99 92 92

EM -20

15. Remove the PCV hose(A) and breather hose from the cylinder head cover.



ENGINE (G4KC - GSL 2.4)

18. Remove the compressor bracket(A).



Be careful not to damage the contact surfaces of

cylinder block and oil pan.

KCRF113A

KCRF141E

- 16. Loosen the cylinder head cover bolts and then remove the cylinder head cover(A) and gasket.
- 19. Drain the engine oil.
- 20. Remove the oil pan.



KCRF115A

17. Remove the compressor lower bolts.



KCRF112A

021-62999292

TIMING SYSTEM

21. Remove the timing chain cover(A) by prying the portions between the cylinder head and cylinder block with a screwdriver.



KCRF106A

\Lambda CAUTION

Be careful not to damage the contact surfaces of cylinder block, cylinder head and timing chain cover.

- 22. The key of crankshaft should be aligned with the mating face of main bearing cap. As a result of this, the piston of No.1 cylinder is placed at the top dead center on compression stroke.
- 23. Install a set pin after compressing the timing chain tensioner.



KCRF104A

- 25. Remove the timing chain tensioner arm(B).
- 26. Remove the timing chain.
- 27. Remove the timing chain guide(A).



KCRF103A



KCRF105A

24. Remove the timing chain tensioner(A).

28. Remove the timing chain oil jet(A).



KCRF101A

29. Remove the crankshaft chain sprocket(B).

WWW.DIGITALKHODRO.COM

021- 62 99 92 92

EM -21

EM -22

BALANCE SHAFT CHAIN

- 1. Remove the timing chain.
- 2. Install a set pin after compressing the balance shaft chain tensioner.
- 3. Remove the balance shaft chain tensioner(A).



KCRF117A

- 4. Remove the balance shaft chain tensioner arm(B).
- 5. Remove the balance shaft chain guide(C).
- 6. Remove the balance shaft module(A) and balance shaft chain(B).

ENGINE (G4KC - GSL 2.4)

INSPECTION EADD7FF9

SPOCKETS, CHAIN TENSIONER, CHAIN GUIDE, CHAIN TENSIONER ARM

- 1. Check the camshaft sprocket and crankshaft sprocket for abnormal wear, cracks, or damage. Replace as necessary.
- Inspect the tensioner arm and chain guide for abnormal wear, cracks, or damage. Replace as necessary.
- 3. Check that the tensioner piston moves smoothly when the ratchet pawl is released with thin rod.

BELT, IDLER, BELT TENSIONER, PULLEY

- Check the belt for oil or dust deposits. Replace, if necessary. Small deposits should be wiped away with a dry cloth or paper. Do not clean with solvent.
- 2. When the engine is overhauled or belt tension adjusted, check the belt carefully. If any of the following flaws are evident, replace the belt.

🔲 ΝΟΤΕ

- Do not bend, twist or turn the timing belt inside out.
- Do not allow the timing belt to come into contact with oil, water and steam.
- 3. Inspect the idler for easy and smooth rotation and check for play or noise.



KCRF165A

EM -23

TIMING SYSTEM

INSTALLATION E63EF00A

BALANCE SHAFT CHAIN

- 1. The key of crankshaft should be aligned with the mating face of main bearing cap. As a result of this, the piston of No.1 cylinder is placed at the top dead center on compression stroke.
- 2. Confirm the balance shaft module timing mark. Timing marks to be visually aligned with centers of adjacent cast timing notches.



3. Install balance shaft module that the timing mark of balance shaft module sprocket should be matched with the timing mark (color link) of balance shaft chain.

Tightening torque 16.66N.m(1.7kgf.m, 12.3lbf.ft) + 60° + 60°



4. Install the balance shaft chain guide(C).

Tightening torque 9.8 ~ 11.76N.m(1.0 ~ 1.2kgf.m, 7.23 ~ 8.67lbf.ft)



ECRF007A

5. Install the balance shaft tensioner arm(B).

Tightening torque	
9.8 ~ 11.76N.m(1.0 ~ 1.2kgf.m, 7.23 ~ 8.67lbf.ft)	

6. Install the balance shaft tensioner(A) and remove the set pin.

 Tightening
 torque

 9.8 ~ 11.76N.m(1.0 ~ 1.2kgf.m, 7.23 ~ 8.67lbf.ft)

7. Confirm the timing marks.

KCRF165B

021-62999292

EM -24

TIMING CHAIN

1. Install crankshaft chain sprocket(B).



KCRF101A

5.

2. Install timing chain oil jet(A).

Tightening torque 7.84 ~ 9.8N.m(0.8 ~ 1.0kgf.m, 5.78 ~ 7.23lbf.ft)

- 3. Set crankshaft that the key of crankshaft should be aligned with the mating surface of main bearing cap. Put the intake, exhaust camshaft assembly that the TDC mark of intake sprocket and exhast sprocket should be aligned with the top surface of cylinder head. As a result of this, place the piston on No.1 cylinder at the top dead center on compression stroke.
- 4. install timing chain guide(A).

Tightening torque 9.8 ~ 11.6N.m(1.0 ~ 1.2kgf.m, 7.23 ~ 8.67lbf.ft)



KCRF103A

ENGINE (G4KC - GSL 2.4)

Install timing chain. To install the timing chain with no slack between each shaft (cam, crank), follow the below procedure.

Crankshaft sprocket(A) -> Timing chain guide(B) -> Intake camshaft sprocket(C) -> Exhaust camshaft sprocket(D).

The timing mark of each sprockets should be matched with timing mark (color link) of timing chain at installing timing chain.



ECRF031A



KCRF104B

WWW.DIGITALKHODRO.COM

021-62999292

EM -25

TIMING SYSTEM

6. Install timing chain tensioner arm(B).

Tightening torque 9.8 ~ 11.76N.m(1.0 ~ 1.2kgf.m, 7.23 ~ 8.67lbf.ft)



KCRF104A

7. Install timing chain auto tensioner(A) and remove set pin.

Tightening torque 9.8 ~ 11.76N.m(1.0 ~ 1.2kgf.m, 7.23 ~ 8.67lbf.ft)

8. After rotating crankshaft 2 revolutions in regular direction (clockwise viewed from front), confirm the timing mark.



ACRF007A

- 9. Install timing chain cover.
 - a. The sealant locations on chain cover and on counter parts (cylinder head, cylinder block, and ladder frame) must be free of engine oil and ETC.
 - b. Before assembling the timing chain cover, the liquid sealant Loctite 5900 should be applied on the gap between cylinder head and cylinder block. The part must be assembled within 5 minutes after sealant was applied.
 Bead width : 2.5mm(0.1in.)



c. After applying liquid sealant Loctite 5900 on timing chain cover.

The part must be assembled within 5 minutes after sealant was applied.

Selant should be applied without discontinuity. Bead width : 2.5mm(0.1in.)



ECRF009A

WWW.DIGITALKHODRO.COM

021-62999292

EM -26

d. The dowel pins on the cylinder block and holes on the timing chain cover should be used as a reference in order to assemble the timing chain cover to be in exact position.

Tightening torque

M6 : 7.84 ~ 9.8N.m(0.8 ~ 1.0kgf.m, 5.78 ~ 7.23lbf.ft) M8 : 18.62 ~ 22.54N.m(1.9 ~ 2.3kgf.m, 13.74 ~ 16.63lbf.ft)



e. The firing and/or blow out test should not be performed within 30 minutes after the timing chain cover was assembled.

- 10. Install oil pan.
 - a. Using a gasket scraper, remove all the old packing material from the gasket surfaces.
 - Before assebling the oil pan, the liquid sealant Loctite 5900 should be applied on oil pan.
 The part must be assembled within 5 minutes after the sealant was applied.

Sealant : Loctite 5900 or equivalent(MS 721-40A)



KCRF179A

ENGINE (G4KC - GSL 2.4)

🗥 CAUTION

- When applying sealant gasket, sealant must not be protruded into the inside of oil pan.
- To prevent leakage of oil, apply sealant gasket ot the inner threads of the bolt holes.
- c. Install oil pan(A). Uniformly tighten the bolts in several passes.

Tightening torque M8(B) : 26.46 ~ 30.38N.m(2.7 ~ 3.1kgf.m, 19.52 ~ 22.41lbf.ft) M6(C) : 9.8 ~ 11.76N.m(1.0 ~ 1.2kgf.m, 7.23 ~ 8.67lbf.ft)



- d. After assembly, wait at least 30 minutes before filling the engine with oil.
- 11. Install air compressor bracket(A).





KCRF113A

WWW.DIGITALKHODRO.COM

021-62999292

EM -27

TIMING SYSTEM

12. Install air compressor bolt

13. Install cylinder head cover.

a.

Tightening torque

 $19.6 \sim 24.5$ N.m $(2.0 \sim 2.5$ kgf.m, $14.46 \sim 18.07$ lbf.ft)



Install the cylinder head coer bolts as following method.

Tightening torque 1st step : 3.92 ~ 5.88N.m(0.4 ~ 0.6kgf.m, 2.89 ~ 4.34lbf.ft) 2st step : 7.84 ~ 9.8N.m(0.8 ~ 1.0kgf.m, 5.78 ~ 7.23lbf.ft)



d.

Do not reuse cylinder head cover gasket.

14. Install ignition coil (See EE group-ignition)



ECRF011A

c. The firing and/or blow out test should not be performed within 30 minutes after the cylinder head cover was assembled. 15. Connect ignition coil connector(A).



KCRF131A

KCRF180A

The hardening sealant located on the upper area between timing chain cover and cylinder head should be removed before assembling cylinder

KCRF112A

b. After applying sealant, it should be assembled within 5 minutes.
Bead width : 2.5mm(0.1in.)

021-62999292

EM -28

16. Install engine support bracket(C).

Tightening torque M10 : 39.2 ~ 44.1N.m(4.0 ~ 4.5kgf.m, 28.92 ~ 32.53lbf.ft) M8 : 19.6 ~ 24.5N.m(2.0 ~ 2.5kgf.m, 14.46 ~ 18.07lbf.ft)



ENGINE (G4KC - GSL 2.4)

20. Install idler pulley(A)

Tightening torque 53.9 ~ 63.7N.m(5.5 ~ 6.5kgf.m, 39.7 ~ 47.0lbf.ft)

21. Install drive belt(A)

Crankshaft pulley -> A/C pulley -> alternator pulley -> idler pulley -> P/C pump pulley -> idler pulley -> water pump pulley -> tensioner pulley. Rotate auto tensioner arm in the counter - clockwise moving auto tensioner pulley bolt with wrench. After putting belt on auto tensioner pulley, release the auto tensioner pulley slowly.



18. Install water pump pulley(A).

Tightening torque

Tightening torque 7.84 ~ 9.8N.m(0.8 ~ 1.0kgf.m, 5.78 ~ 7.23lbf.ft)

17. Using flywheel stopper, install crankshaft pulley(B).

166.6 ~ 176.4N.m(17 ~ 18kgf.m, 122.9 ~ 130.13lbf.ft)

19. Install drive belt tensioner(B) and tensioner pulley.

Tightening torque 53.9 ~ 63.7N.m(5.5 ~ 6.5kgf.m, 39.7 ~ 47.0lbf.ft)



KCRF109A

NOTE Tensioner pulley bolt is left-handed screw. 22. Install engine mounting bracket(A).

Tightening torque 63.7 ~ 83.3N.m(6.5 ~ 8.5kgf.m, 47.0 ~ 61.4lbf.ft)



KCRF137A

WWW.DIGITALKHODRO.COM

021- 62 99 92 92

TIMING SYSTEM

- 23. Install RH side cover.
- 24. Install RH front wheel.
- 25. Install engine cover(A).

Tightening torque 3.92 ~ 5.88N.m(40 ~ 60kgf.cm, 2.89 ~ 4.34lbf.ft)

D DOHE

6





EM -30

ENGINE (G4KC - GSL 2.4)

CYLINDER HEAD ASSEMBLY

COMPONENTS EEAFB45C



- 1. Cylinder head
- 2. Cylinder head gasket
- 3. Cylinder block

ECRF013A

WWW.DIGITALKHODRO.COM

021-62999292

CYLINDER HEAD ASSEMBLY



- 5. Exhaust camshaft sprocket
- 9. Retainer
- 10. Valve spring

- 15. OTS

ECRF014A

021- 62 99 92 92

EM -32

REMOVAL EEDOAA3B

Engine removal is not required for this procedure.

A CAUTION

- Use fender covers to avoid damaging painted surfaces.
- To avoid damaging the cylinder head, wait until the engine coolant temperature drops below normal temperature before removing it.
- When handling a metal gasket, take care not to fold the gasket or damage the contact surface of the gasket.
- To avoid damage, unplug the wiring connectors carefully while holding the connector portion.

🔟 ΝΟΤΕ

- Mark all wiring and hoses to avoid misconnection.
- Turn the crankshaft pulley so that the No. 1 piston is at top dead center. (See page EM-8)
- 1. Disconnect the negative terminal from the battery.
- 2. Remove engine cover(A).



KCRF146A

3. Remove air duct.

ENGINE (G4KC - GSL 2.4)

- 4. Remove the intake air hose and air cleaner assembly.
 - 1) Disconnect the AFS connector.
 - 2) Disconnect the breather hose(B) from air cleaner hose.
 - 3) Disconnect the ECM connector. (See FL group)
 - 4) Remove the intake air hose and air cleaner assembly(A).



ACRF011A

- 5. Remove front wheels.
- 6. Remove under cover(A).



KMRE009H

EM -33

CYLINDER HEAD ASSEMBLY

- Drain the engine coolant. Remove the radiator cap to speed draining.
- 8. Remove the upper and lower radiator hose(A).



- 9. Remove the heater hoses(A).

KCRF133A

KCRF124A

 Disconnect A/C switch(A), alternator connector(B), and oil pressure switch(C).



KCRF126A

11. Disconnect OCV connector(A) and OTS connector(B).



KCRF127A





KCRF128A

13. Disconnect ETS connector(A)



ECRF032A

WWW.DIGITALKHODRO.COM

021-62999292

EM -34

ENGINE (G4KC - GSL 2.4)

14. Disconnect CMP connector(A), and knock sensor connector(B).





KCRF134A

- 18. Remove water temp control assembly(A).
- 15. Disconnect ignition coil connectors(A).

KCRF131A

 Disconnect PCSV connector(A), WTS connector(B), condenser connector(C), and CKP sensor connector(D).



KCRF132A

17. Remove delivery pipe(A), brake vacuum hose(B), and PCSV hose(C).

- 19. Remove intake manifold. (See page EM 85)
- 20. Remove exhaust manifold. (See page EM 87)
- 21. Remove timing chain. (Seepage EM 8)
- 22. Remove CVVT assembly and camshaft sprocket(A).



KCRF151A

WWW.DIGITALKHODRO.COM

CYLINDER HEAD ASSEMBLY

- 23. Remove camshaft.
 - 1) Remove front camshaft bearing cap(A).



KCRF153A

 Remove camshaft bearing cap(A), in the sequence shown.



3) Remove camshafts(A)



KCRF155A

24. Remove OCV(A) and OTS(B).



KCRF119A

- 25. Remove the cylinder head bolts, then remove the cylinder head.
 - Using triple square wrench, uniformly loosen and remove the 10 cylinder head bolts, in several passes, in the sequence shown. Remove the 10 cylinder head bolts and plate washers.



KCRF162A

\Lambda CAUTION

Head warpage or cracking could result from removing bolts in an incorrect order.

2) Lift the cylinder head from the dowels on the cylinder block and place the cylinder head on wooden blocks on a bench.

\Lambda CAUTION

Be careful not to damage the contact surfaces of the cylinder head and cylinder block.

EM -35

ENGINE (G4KC - GSL 2.4)

EM -36

DISASSEMBLY E37BB06C

NOTE

Identify MLA(Mechanical Lash Adjuster), valves, valve springs as they are removed so that each item can be reinstalled in its original position.

Remove MLAs(A). 1.

Remove valves

2.

1)

INSPECTION E8F0BC5D

CYLINDER HEAD

1. Inspect for flatness. Using a precision straight edge and feeler gauge, measure the surface the contacting the cylinder block and the manifolds for warpage.

Flatness of cylinder head gasket surface Standard : Less than 0.05mm(0.002in.)

KCRF125A Using SST(09222-3K000, 09222-3K100), compress the valve spring and remove retainer lock. C

ECKD001H

KCRF125B

2.

- 2) Remove the spring retainer.
- Remove the valve spring. 3)
- Remove the valve. 4)
- Using needle-nose pliers, remove the valve stem 5) seal.
- Inspect for cracks. Check the combustion chamber, intake ports, exhaust ports and cylinder block surface for cracks. If cracked, replace the cylinder head.
CYLINDER HEAD ASSEMBLY

VALVE AND VALVE SPRING

- 1. Inspect valve stems and valve guides.
 - 1) Using a caliper gauge, measure the inside diameter of the valve guide.

Valve guid I.D.

Intake / Exhaust : 5.500 ~ 5.512mm (0.216 ~ 0.217in.)



 Subtract the valve stem diameter measurement from the valve guide inside diameter measurement.

Valve stem-to-guide clearance [Standard]

Intake : 0.020 ~ 0.047mm (0.0008 ~ 0.0018in.) Exhaust : 0.030 ~ 0.054mm (0.0012 ~ 0.0021in.) [Limit] Intake : 0.07mm (0.0027in.) Exhaust : 0.09mm (0.0035in.)

> If the clearance is greater than maximum, replace the valve and valve guide.

- 2. Inspect valves.
 - 1) Check the valve is ground to the correct valve face angle.
 - 2) Check that the surface of the valve for wear. If the valve face is worn, replace the valve.
 - Check the valve head margin thickness. If the margin thickness is less than minimum, replace the valve.

Margin [Standard]

Intake : 1.02mm(0.0401in.) Exhaust : 1.09mm(0.0429in.)

2) Using a micrometer, measure the diameter of the valve stem.

Valve stem O.D.

Intake : 5.465 ~ 5.480mm (0.2151 ~ 0.2157in.) Exhaust : 5.458 ~ 5.470mm (0.2149 ~ 0.2153in.)





ECKD221A

ECKD220A

WWW.DIGITALKHODRO.COM

021-62999292

EM -38

ENGINE (G4KC - GSL 2.4)

- 4) Check the surface of the valve stem tip for wear. If the valve stem tip is worn, replace the valve.
- 3. Inspect valve seats

Check the valve seat for evidence of overheating and improper contact with the valve face.

Replace the seat if necessary.

Before reconditioning the seat, check the valve guide for wear. If the valve guide is worn, replace it, then recondition the seat. Recondition the valve seat with a valve seat grinder or cutter. The valve seat contact width should be within specifications and centered on the valve face.

- 4. Inspect valve springs.
 - 1) Using a steel square, measure the out-of-square of the valve spring.
 - 2) Using a vernier calipers, measure the free length of the valve spring.



MLA

 Inspect MLA. Using a micrometer, measure the MLA outside diameter.

MLA O.D.

Intake/Exhaust : 31.964 ~ 31.980mm(1.2584 ~ 1.2590in.)

2. Using a caliper gauge, measure MLA tappet bore inner diameter of cylinder head.

Tappet bore I.D.

Intake/Exhaust : 32.000 ~ 32.025mm(1.2598 ~ 1.2608in.)

3. Subtract MLA outside diameter measurement from tappet bore inside diameter measurement.

MLA to tappet bore clearance

[Standard] Intake/Exhaust : 0.020 ~ 0.061mm(0.0008 ~ 0.0024in.) [Limit] Intake/Exhaust : 0.07mm(0.0027in.)

ECKD222A

If the free length is not as specified, replace the valve spring.

021-62999292

EM -39

CYLINDER HEAD ASSEMBLY

CAMSHAFT

 Inspect cam lobes. Using a micrometer, measure the cam lobe height.

Cam height

[Standard value] Intake : 43.70 ~ 43.90mm (1.7204 ~ 1.7283in.) Exhaust : 44.90 ~ 45.10mm (1.7677 ~ 1.7756in.)

- 2. Inspect camshaft journal clearance.
 - 1) Clean the bearing caps and camshaft journals.
 - 2) Place the camshafts on the cylinder head.
 - 3) Lay a strip of plastigage across each of the camshaft journal.



021- 62 99 92 92

EM -40

ENGINE (G4KC - GSL 2.4)

- 5) Remove the bearing caps.
- 6) Measure the plastigage at its widest point.

Bearing oil clearance

[Standard value] Intake No.1 journal : 0.02 ~ 0.057mm (0.0008 ~ 0.0022in.) No.2,3,4,5, journal : 0.045 ~ 0.082mm (0.0018 ~ 0.0032in.) Exhaust : 0.045 ~ 0.082mm (0.0018 ~ 0.0032in.) [Limit] : Intake No.1 journal : 0.09mm (0.0035in.) No.2,3,4,5 journal : 0.12mm (0.0047in.) Exhaust : 0.12mm (0.0047in.)

- 3. Inspect camshaft end play.
 - 1) Install the camshafts. (See page EM 44)
 - 2) Using a dial indicator, measure the end play while moving the camshaft back and forth.

Camshaft end play

[Standard value] : 0.10 ~ 0.22mm(0.004 ~ 0.0087in.) [Limit] : 0.24mm (0.0094in.)



ECKD225A

If the oil clearance is greater than maximum, replace the camshaft. If necessary, replace cylinder head.

- 7) Completely remove the plastigage.
- 8) Remove the camshafts.

Under the condition of (3), turn the CVVT assembly to the advance angle side (the arrow marked

bly will turn to the advance side without applying force by hand. Also, under the condition that the

pressure can be hardly applied because of the

direction in the illustration) with your hand. Depending on the air pressure, the CVVT assem-

CYLINDER HEAD ASSEMBLY

CVVT ASSEMBLY

- 1. Inspect CVVT assembly.
 - 1) Check that the CVVT assembly will not turn.
 - 2) Apply vinyl tape to the retard hole except the one indicated by the arrow in the illustration.
 - air leakage from the port, there may be the case that the lock pin could be hardly released. Δ Retard Retard Advance ECRF015A ECRE016A Wind tape around the tip of the air gun and apply 3) air of approx. 150kpa(1.5kgf/cm², 21psi) to the Except the position where the lock pin meets at 5) port of the camshaft. the maximum delay angle, let the CVVT assem-(Perform this order to release the lock pin for the bly turn back and forth and check the movable maximum delay angle locking.) range and that there is no disturbance. **NOTE** Standard: Movable smoothly in the range about 22.5° When the oil splashes, wipe it off with a shop rag and the likes.

4)

6) Turn the CVVT assembly with your hand and lock it at the maximum delay angle position (counter clockwise).

REASSEMBLY ED38378A

🚺 NOTE

Thoroughly clean all parts to be assembled. Before installing the parts, apply fresh engine oil to all sliding and rotating surfaces. Replace oil seals with new ones.

- 1. Install valves.
 - 1) Using SST(09222-4A000), push in a new oil seal.

🔟 ΝΟΤΕ

Do not reuse old valve stem seals. Incorrect installation of the seal could result in oil leakage past the valve guides.

- ENGINE (G4KC GSL 2.4)
- Using the SST(09222-3K000, 09222-3K100), compress the spring and install the retainer locks. After installing the valves, ensure that the retainer locks are correctly in place before releasing the valve spring compressor.



KCRF125B

4) Lightly tap the end of each valve stem two or three times with the wooden handle of a hammer to ensure proper seating of the valve and retainer lock.

 Install MLAs. Check that the MLA rotates smoothly by hand.

- 2) Install the valve, valve spring and spring retainer.
- 🚺 ΝΟΤΕ

Place valve springs so that the side coated with enamel faces toward the valve spring retainer and then installs the retainer.

KCRF125A



CYLINDER HEAD ASSEMBLY

INSTALLATION ECAF2F73

NOTE

- Thoroughly clean all parts to be assembled.
- Always use a new head and manifold gasket.
- The cylinder head gasket is a metal gasket. Take care not to bend it.
- Rotate the crankshaft, set the No.1 piston at TDC. (See page EM - 8)
- Install OCV filter. 1.

EM -43

- 3. Place the cylinder head carefully in order not to damage the gasket with the bottom part of the end.
- 4. Install cylinder head bolts.
 - Apply a light coat if engine oil on the threads and 1) under the heads of the cylinder head bolts.
 - Using triple square hexagon wrench, install and 2) tighten the 10 cylinder head bolts and plate washers, in several passes, in the sequence shown.

Tightening torque

34.3Nm (3.5kgf.m, 25.3lbf.ft) + 90° + 90°

🛈 NOTE



KCRF162B



🔟 ΝΟΤΕ Be careful of the installation direction.

WWW.DIGITALKHODRO.COM

KCRF163A

021-62999292

EM -44

5. Install OCV(A) and OTS (B).

Tightening torque

OCV : 9.8 ~ 11.76Nm(1.0 ~ 1.2kgf.m, 7.23 ~ 8.67lbf.ft) OTS : 19.6 ~ 23.52Nm(2.0 ~ 2.4kgf.m, 14.46 ~ 17.35lbf.ft)



KCRF119A

KCRF122A

- Do not reuse the OCV when dropped.
- Keep clean the OCV.
- Do not hold the OCV sleeve during servicing.
- When the OCV is installed on the engine, do not move the engine with holding the OCV yoke.
- 6. Install the CVVT and camshaft sprocket.

Tightening torque 53.9 ~ 63.7Nm(5.5 ~ 6.5 kgf.m, 39.7 ~ 47.0lbf.ft)



- ENGINE (G4KC GSL 2.4)
- 7. Install camshafts (A).



KCRF155A

🚺 ΝΟΤΕ

Apply a light coat of engine oil on camshaft journals.

8. Install camshaft bearing caps in their proper locations. Tightening order.

Group A Group B Group C.

Tightening torque

M6 : 10.78 ~ 12.74Nm(1.1 ~ 1.3kgf.m, 7.95 ~ 9.39lbf.ft) M8 : 27.44 ~ 31.36Nm(2.8 ~ 3.2kgf.m, 20.24 ~ 23.14 lbf.ft)



ECRF017A

- 9. Install timing chain. (See page EM 23)
- 10. Check and adjust valve clearance. (See page EM 8)
- 11. Install the exhaust manifold. (See apge EM 87)
- 12. Install the intake manifold. (See page EM 87)

🔟 ΝΟΤΕ

Hold the hexagonal head wrench portion of the camshaft with a vise, and install the bolt and CVVT assembly.

WWW.DIGITALKHODRO.COM

EM -45

CYLINDER HEAD ASSEMBLY

13. Install water temp control assembly (A).

Tightening torque Bolt : 14.7 ~ 21.56Nm(1.5 ~ 2.2kgf.m, 10.84 ~ 15.90lbf.ft) Nut : 19.6 ~ 26.46Nm(2.0 ~ 2.7kgf.m, 14.46 ~ 19.52lbf.ft)



 Connect PCSV connector (A), WTS connector (B), condenser connector (C), and CKP sensor connector (D).



KCRF132A

16. Install ignition coil connector (A).



 Assemble water temp control assembly and water inlet pipe to water pump assembly before nuts for assembling of water inlet pipe to be tightened.

- Insert after wetting O-ring or inner surface of thermostat housing.
- Always use a new O-ring.
- 14. Install delivery pipe (A), brake hose(B), and PCSV hose (C).



KCRF131A



KCRF134A

17. Connect ETS connector(A)



ECRF032A

WWW.DIGITALKHODRO.COM

021-62999292

EM -46

18. Connect CMP connector (A), and knock sensor connector (B).



19. Connect injector connectors (A).

- ENGINE (G4KC GSL 2.4)
- 21. Connect A/C switch (A), alternator connect (B), and oil pressure switch (C).



KCRF126A

22. Install heater hoses(A).



KCRF128A

20. Connect OCV connector (A) and OTS connector (B).



KCRF127A

23. Install the upper radiator hose and lower radiator hose(A).



KCRF124A

CYLINDER HEAD ASSEMBLY

24. Install the intake air hose and air cleaner assembly.



KMRE009A

- 25. Install the engine cover (A).
- 26. Connect the negative terminal to the battery.
- 27. Fill with engine coolant.
- 28. Start the engine and check for leaks.
- 29. Recheck engine coolant level and oil level.

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



ENGINE AND TRANSAXLE ASSEMBLY

REMOVAL E5A225DF

- Use fender covers to avoid damaging painted surfaces.
- To avoid damage, unplug the wiring connectors carefully while holding the connector portion.

🚺 ΝΟΤΕ

- Mark all wiring and hoses to avoid misconnection.
- Inspection the timing belt before removing the cylinder head.
- Turn the crankshaft pulley so that the No.1 piston is at top dead center. (See page EM 8)
- 1. Disconnect the neagative terminal from the battery.
- 2. Remove the engine cover.
- 3. Remove the air duct.
- 4. Remove the intake air hose and air cleaner assembly.
 - 1) Disconnect the AFS connector.
 - 2) Disconnect the breather hose from air cleaner hose.
 - 3) Disconnect the ECM connector. (See FL group)
 - 4) Remove the intake air hose and air cleaner(A).



KMRE009A

5. Remove front wheels.

- ENGINE (G4KC GSL 2.4)
- 6. Remove under cover(A).



KMRE009H

- Drain the engine coolant. Remove the radiator cap to speed draining.
- 8. Remove the upper radiator hose and lower radiator hose(A).



KCRF124A

ENGINE AND TRANSAXLE ASSEMBLY

9. Remove the heater hoses(A).



12. Disconnect injector connectors(A).

13. Disconnect ETS connector(A)



KCRF128A

- 10. Disconnect A/C switch(A), alternator connector(B)
- and pressure switch(C).

KCRF126A

KCRF133A

- 11. Disconnect OCV connector(A) and OTS connector(B).

WWW.DIGITALKHODRO.COM

KCRF127A

 Disconnect CMP connector(A), and knock sensor connector(B).



ECRF029A

021- 62 99 92 92

EM -49

021-62999292

EM -50

15. Disconnect ignition coil connectors(A).



KCRF131A

 Disconnect PCSV connector(A), WTS connector(B), condenser connector(C), and CKP sensor connector(D).

- ENGINE (G4KC GSL 2.4)
- 18. Disconnect P/S pump oil pressure switch connector(A).



KCRF135A

19. Remove P/S pump hose(A).



KCRF132A

17. Remove delivery pipe(A), brake vacuum hose(B), and PCSV hose(C).



20. Remove the battery body bracket.(A).



KCRF134A

KMRE009B

WWW.DIGITALKHODRO.COM

ENGINE AND TRANSAXLE ASSEMBLY

21. Disconnect the ground cable from the transaxle.



KMRE009C

- 22. Disconnect the transaxle wire harness connector. (A/T).
 - a. Disconnect the inhibitor switch connector.
 - b. Disconnect the transaxle range connector.
 - c. Disconnect the input shaft speed connector.
 - d. Disconnect the output shaft speed connector.
 - e. Disconnect the vehicle speed sensor connector.
 - f. Remove control cable transaxle range switch.
- 23. Drain transaxle oil.
- 24. Disconnect EPS connector. (See ST group)
- 25. Remove lower arm ball joint. (SeeDS group)
- 26. Remove tile rod end ball joint. (See DS group)
- 27. Remove stabilizer link. (See SS group)

28. Remove power steering return hose(A) and drain power steering oil.



KMRE009J

- 29. Remove front roll stopper mounting bolt.
- 30. Remove rear roll stopper mounting bolt.
- 31. Remove steering u-joint mounting (See ST group)
- 32. Disconnect oxygen sensor connetor(A).



ECRF018A

021- 62 99 92 92

EM -52

- 33. Remove front exhaust pipe.
- 34. Install jack and remove sub-frame(A).



39. Jack up the vehicle.

KMRE009R

- 35. Remove drive shaft from transaxle.
- 36. Install jack for supporting engine and transaxle assembly.
- 37. Remove the engine mounting bracket(A).



KCRF137A

ENGINE (G4KC - GSL 2.4)

38. Remove the transaxle mounting bracket(A).

KMRE009T

INSTALLATION E2B2CFC8

Installation is in the reverse order of removal.

Perform the following :

- Adjust the shift cable.
- Adjust the throttle cable.
- Refill the engine with engine oil.
- Refill the transaxle with fluid.
- Refill the radiator with engine coolant.
- Bleed air from the cooling system with the heater valve open.
- Clean the battery posts and cable terminals with sandpaper assemble them, then apply grease to prevent corrosion.
- Inspect for fuel leakage.
 - After assembling the fuel line, turn on the ignition switch (do not operate the starter) so that the fuel pump runs for approximately two seconds and fuel line pressureizes.

Repeat this operation two or three times, then check for fuel leakage at any point in the fuel line.



ولین سامانه دیجیتال تعمیرکاران خودرو در ایران



021-62999292

EM -53

ENGINE (G4KC - GSL 2.4)

ENGINE BLOCK

COMPONENTS E4334AB3



- 3. Connecting rod
- 4. Connecting rod upper bearing

- 6. Connecting rod lower bearing
- 7. Connecting rod bearing cap
- 8. Ladder frame

ECRF019A

WWW.DIGITALKHODRO.COM

021-62999292

ENGINE BLOCK

EM -55



3. Crankshaft

5. Main bearing cap

ECRF020A

021-62999292

EM -56

DISASSEMBLY ECC1D070

- 1. M/T : remove flywheel.
- 2. A/T : remove drive plate.
- 3. Install engine to engine stand for disassembly.
- 4. Remove timing chain. (See page EM 18)
- 5. Remove cylinder head. (See page EM 32)
- Remove A/C compressor(A) from engine. (See HA group)

ENGINE (G4KC - GSL 2.4)

8. Remove power steering pump and bracket. (See ST group)



KCRF160A



7. Remove alternator(A) from engine. (See EE group)

Remove tensioner assembly integrated bracket(A).

KCRF161A

10. Remove oil level gauge assembly(A).

9.

KCRF159A



KCRF163B

021-62999292

WWW.DIGITALKHODRO.COM

021-62999292

EM -57

ENGINE BLOCK

11. Remove knock sensor(A).



KCRF143A

12. Remove oil pressure sensor(A).



13. Remove CKP sensor(A).



- 14. Remove water pump. (See page EM 76)
- 15. Remove balance shaft module. (See page EM 81)
- 16. Remove ladder frame(A).



KCRF167A

- Check the connecting rod end play. (See page EM -58)
- Remove the connecting rod caps and check oil clearance. (See page EM - 59)
- 19. Remove piston and connecting rod assemblies.
 - 1) Using a ridge reamer, remove all the carbon from the top of the cylinder.
 - Push the piston, connecting rod assembly and upper bearing through the top of the cylinder block.

🔟 NOTE

- Keep the bearings, connecting rod and cap together.
- Arrange the piston and connecting rod assemblies in the correct order.
- 20. Remove crankshaft bearing cap and check oil clearance. (See page EM - 61)
- 21. Check the crankshaft end play. (See page EM 63)

KCRF164A

WWW.DIGITALKHODRO.COM

EM -58

ENGINE (G4KC - GSL 2.4)

22. Lift the crankshaft(A) out of the engine, being careful not to damage journals.

🔟 ΝΟΤΕ

Arrange the main bearings and thrust bearings in the correct order.



23. Check fit between piston and piston pin.

- Try to move the piston back and forth on the piston pin. If any movement is felt, replace the piston and pin as a set.
- 24. Remove piston rings.
 - Using a piston ring expender, remove the 2 compression rings.
 - 2) Remove 2 side rails and the spacer by hand.

🔟 ΝΟΤΕ

Arrange the piston rings in the correct order only.

25. Disconnect connecting rod from piston.

INSPECTION E29CBA34

CONNECTING ROD AND CRANKSHAFT

 Check the connecting rod end play. Using a feeler gauge, measure the end play while moving the connecting rod back and forth.

Standard end play : 0.1~ 0.25mm(0.004 ~ 0.010in.) Maximum end play : 0.35mm(0.0138in.)



- If out-of-tolerance, install a new connecting rod.
 If still out-of-tolerance, replace the crankshaft.
- 2. Check the connecting road bearing oil clearance.
 - 1) Check the matchmarks on the connecting rod and cap are aligned to ensure correct reassembly.
 - 2) Remove 2 connecting rod cap bolts.
 - 3) Remove the connecting rod cap and bearing half.
 - 4) Clean the crank pin and bearing.
 - 5) Place plastigage across the crank pin.
 - 6) Reinstall the bearing half and cap, and torque the bolts.

Tightening torque

19.6Nm (2.0kgf.m, 14.46lbf.ft) + 90°

🔟 ΝΟΤΕ

Do not turn the crankshaft.

7) Remove 2 bolts, connecting rod cap and bearing half.

WWW.DIGITALKHODRO.COM

021-62999292

ENGINE BLOCK

8) Measure the plastigage at its widest point.

CONNECTING ROD MARK LOCATION

Standard oil clearance

0.028 ~ 0.046mm(0.0011 ~ 0.0018in.)



KCRF169A

9) If the plastigage measures too wide or too narrow, remove the upper half of the bearing, install a new, complete bearing with the same color mark (select the color as shown in the next column), and recheck the clearance.

یجیتال خودرو سامانه (مسئو**אסודun)**ود

Do not file, shim, or scrape the bearings or the caps to adjust clearance.

10) If the plastigage shows the clearance is still incorrect, try the next larger or smaller bearing (the color listed above or below that one), and check clearance again.



If the proper clearance cannot be obtained by using the appropriate larger or smaller bearings, replace the crankshaft and start over.

If the marks are indecipherable because of an accumulation of dirt and dust, do not scrub them with a wire brush or scraper. Clean them only with solvent or detergent.



EDQF196A

DISCRIMINATION OF CONNECTING ROD

CLASS	MARK	INSIDE DIAMETER
а	А	51.000 ~ 51.006mm (2.0079 ~ 2.0081in.)
b	вО	51.006 ~ 51.012mm (2.0081 ~ 2.0083in.)
شرکت د	С	51.012 ~ 51.018mm (2.0083 ~ 2.0085in.)

CRANKSHAFT PIN MARK LOCATION DISCRIMINATION OF CRANKSHAFT



ACGE063Z

EM -59

DISCRIMINATION OF CRANKSHAFT

CLSASS	MARK	OUTSIDE DIAMETER OF PIN
I	1	47.966 ~ 47.972mm (1.8884 ~ 1.8886in.)
II	2	47.960 ~ 47.966mm (1.8881 ~ 1.8884in.)
	3	47.954 ~ 47.960mm (1.8879 ~ 1.8881in.)

PLACE OF IDENTIFICATION MARK (CONNECTING ROD BEARING) DISCRIMINATION OF CONNECTING ROD BEARING



DISCRIMINATION OF CONNECTING ROD BEARING

CLASS	MARK	THICKNESS OF BEARING
AA	BLUE	1.514 ~ 1.517mm (0.0596 ~ 0.0597in.)
A	BLACK	1.511 ~ 1.514mm (0.0595 ~ 0.0596in.)
В	NONE	1.508 ~ 1.511mm (0.0594 ~ 0.0595in.)
С	GREEN	1.505 ~ 1.508mm (0.0593 ~ 0.0594in.)
D	YELLOW	1.502 ~ 1.505mm (0.0591 ~ 0.0593in)

ENGINE (G4KC - GSL 2.4)

11) Selection	۱
---------------	---

CRANKSHAFT INDENTIFICATION MARK	CONNECT- ING ROD IDENTIFICA- TION MARK	ASSEMBING CLASSIFI- CATION OF BEARING
	a (A)	D (YELLOW)
I (1)	b (B)	C (GREEN)
	c (C)	B (NONE)
	a (A)	C (GREEN)
II (2)	b (B)	B (NONE)
	c (C)	A (BLACK)
	a (A)	B (NONE)
III (3)	b (B)	A (BLACK)
	c (C)	AA (BLUE)

- 3. Check the crankshaft bearing oil clearance.
 - To check main bearing-to-journal oil clearance, remove the main caps and bearing halves.
 - 2) Clean each main journal and bearing half with a clean shop tower.
 - 3) Place one strip of plastigage across each main journal.
 - Reinstall the bearings and caps, then torque the bolts.

Tightening torque

ECRF021A

26.46Nm (2.7kgf.m, 19.52lbf.ft) + 45°



Do not turn the crankshaft.

ENGINE BLOCK

5) Remove the cap and bearing again, and measure the widest part of the plastigage.

Standard oil clearance

0.026 ~ 0.048mm (0.0010 ~ 0.0019in.)



KCRF170A

6) If the plastigage measures too wide or too narrow, remove the upper half of the bearing, install a new, complete bearing with the same color mark (select the color as shown in the next column), and recheck the clearance.

Do not file, shim, or scrape the bearings or the caps to adjust clearance.

7) If the plastigage shows the clearance is still incorrect, try the next larger or smaller bearing (the color listed above or below that one), and check clearance again.

🔟 ΝΟΤΕ

If the proper clearance cannot be obtained by using the appropriate larger or smaller bearings, replace the crankshaft and start over.

A CAUTION

If the marks are indecipherable because of an accumulation of dirt and dust, do not scrub them with a wire brush or scraper. Clean them only with solvent or detergent.

CONNECTING RODS

- 1. When reinstalling, make sure that cylinder numbers put on the connecting rod and cap at disassembly match. When a new connecting rod is installed, make sure that the notches for holding the bearing in place are on the same side.
- 2. Replace the connecting rod if it is damaged on the thrust faces at either end. Also if step wear or a severely rough surface of the inside diameter of the small end is apparent, the rod must be replaced as well.
- 3. Using a connecting rod aligning tool, check the rod for bend and twist. If the measured value is close to the repair limit, correct the rod by a press. Any connecting rod that has been severely bent or distorted should be replaced.

Allowable bend of connecting rod : 0.05mm / 100mm (0.0020 in./3.94 in.) or less Allowable twist of connecting rod : 0.1mm / 100mm (0.0039 in./3.94 in.) or less

Crankshaft bore mark location

Letters have been stamped on the block as a mark for the size of each of the 5 main journal bores.

Use them, and the numbers or bar stamped on the crank (marks for main journal size), to choose the correct bearings.



KCRF175C

WWW.DIGITALKHODRO.COM

DISCRIMINATION OF CYLINDER BLOCK

CALSS	MARK	INSIDE DIAMETER
а	А	56.000 ~ 56.006mm (2.2047 ~ 2.2049in.)
b	В	56.006 ~ 56.012mm (2.2049 ~ 2.2052in.)
с	С	56.012 ~ 56.018mm (2.2052 ~ 2.2054in.)

CRANKSHAFT JOURNAL MARK LOCATION DISCRIMINATION OF CRANKSHAFT

DISCRIMINATION OF CRANKSHAFT

CLASS	MARK	OUTSIDE DIAMETER OF JOURNAL
I	1	51.954 ~ 51.960mm (2.0454 ~ 2.0456in.)
II	2	51.948 ~ 51.954mm (2.0452 ~ 2.0454.)
111	3	51.942 ~ 51.948mm (2.0449 ~ 2.0452in.)

ENGINE (G4KC - GSL 2.4)

PLACE OF IDENTIFICATION MARK (CRANKSHAFT BEARING) DISCRIMINATION OF CRANKSHAFT BEARING



ECRF022A

DISCRIMINATION OF CRANKSHAFT BEARING

	CLASS	MARK	THICKNESS OF BEARING
	AA	BLUE	2.026 ~ 2.029mm (0.0797 ~ 0.0798in.)
	A	BLACK	2.023 ~ 2.026mm (0.0796 ~ 0.0797in.)
	В	NONE	2.020 ~ 2.023mm (0.0795 ~ 0.0796in.)
0	اولين سا	GREEN	2.017 ~ 2.0 <mark>20m</mark> m (0.0794 ~ 0.795in.)
	D	YELLOW	2.014 ~ 2.017mm (0.0793 ~ 0.0794in.)

SELECTION

ACGE084Z

CRANKSHAFT IDENTIFICATION MARK	CRANK- SHAFT BORE IDENTIFICA- TION MARK	ASSEM- BLING CLAS- SIFICATION OF BEARING
	a (A)	D (YELLOW)
I (1)	b (B)	C (GREEN)
	c (C)	B (NONE)
	a (A)	C (GREEN)
II (2)	b (B)	B (NONE)
	c (C)	A (BLACK)
	a (A)	B (NONE)
III (3)	b (B)	A (BLACK)
	c (C)	AA (BLUE)

ENGINE BLOCK

EM -63

4. Check crankshaft end play. Using a dial indicator, measure the thrust clearance while prying the crankshaft back and forth with a screwdriver.

Standard end play

0.07 ~ 0.25mm (0.0027 ~ 0.0098in.) Limit : 0.30mm (0.0118in.) 5. Inspect main journals and crank pins Using a micrometer, measure the diameter of each main journal and crank pin.

Main journal diameter : 51.942 ~ 51.960mm (2.0449 ~ 2.0456in.) Crank pin diameter : 47.954 ~ 47.972mm (1.8879 ~ 1.8886in.)



 $1.925 \sim 1.965$ mm($0.0758 \sim 0.07736$ in.)

ECKD001E

021-62999292

ENGINE (G4KC - GSL 2.4)

EM -64

CYLINDER BLOCK

- Remove gasket material. Using a gasket scraper, remove all the gasket material from the top surface of the cylinder block.
- Clean cylinder block Using a soft brush and solvent, thoroughly clean the cylinder block.
- 3. Inspect top surface of cylinder block for flatness. Using a precision straight edge and feeler gauge, measure the surface contacting the cylinder head gasket for warpage.

Flatness of cylinder block gasket surface Standard : Less than 0.05mm(0.0020 in.)



ECKD318A



Measure position(from the bottom of the cylinder block)

110.7mm(4.3582in.)/160mm(6.2992in.)/210mm(8.2677in.)

 Check the cylinder bore size code on the cylinder block.

ECKD001L

- Inspect cylinder bore diameter Visually check the cylinder for vertical scratchs. If deep scratches are present, replace the cylinder block.
- 5. Inspect cylinder bore diameter Using a cylinder bore gauge, measure the cylinder bore diameter at position in the thrust and axial directions.

Standard diameter

88.00 ~ 88.03mm (3.4645 ~ 3.4657in.)



KCRF175B

Class	Cylinder bore inner diameter	Size code
A	88.00 ~ 88.01mm (3.4645~ 3.4649in.)	А
В	88.01 ~ 88.02mm (3.4649~ 3.4653in.)	В
С	88.02 ~ 88.03mm (3.4653~ 3.4657in.)	С

WWW.DIGITALKHODRO.COM

ENGINE BLOCK

7. Check the piston size code on the piston top face.



🔟 ΝΟΤΕ

Stamp the grade mark of basic diameter with rubber stamp.

Class	Piston outer diameter	Size code
A	87.97 ~ 87.98mm (3.4633 ~ 3.4637in.)	A
دد ₈ د)	87.98 ~ 87.99mm (3.4637 ~ 3.4641in.)	None
C,	87.99 ~ 88.00mm (3.4641 ~ 3.4645in.)	ي 2 م

8. Select the piston related to cylinder bore class.

Clearance : 0.02 ~ 0.04mm (0.00078 ~ 0.00157in.)

Boring cylinder

1. Oversize pistons should be selected according to the largest bore cylinder.

Identification Mark	Size
0.25	0.25mm (0.010in.)
0.50	0.50mm (0.020in.)

🚺 ΝΟΤΕ

The size of piston is stamped on top of the piston.

- 2. Measure the outside diameter of the piston to be used.
- 3. According to the measured O.D., calculate the new bore size.

New bore size = Piston O.D + 0.02 to 0.04mm (0.0008 to 0.0016in.) (clearance between piston and cylinder) - 0.01mm (0.0004in.) (honing margin.)

4. Bore each of the cylinders to the calculated size.

To prevent distortion that may result from temperature rise during honing, bore the cylinder holes in the firing order.

- 5. Hone the cylinders, finishing them to the proper dimension (piston outside diameter + gap with cylinder).
- 6. Check the clearance between the piston and cylinder.

Standard : 0.02 ~ 0.04mm (0.0008 ~ 0.0016in.)

🔟 ΝΟΤΕ

When boring the cylinders, finish all of the cylinders to the same oversize. Do not bore only one cylinder to the oversize.

021-62999292

ENGINE (G4KC - GSL 2.4)

EM -66

PISTON AND RINGS

- 1. Clean piston
 - 1) Using a gasket scraper, remove the carbon from the piston top.
 - 2) Using a groove cleaning tool or broken ring, clean the piston ring grooves.
 - 3) Using solvent and a brush, thoroughly clean the piston.



Do not use a wire brush.

2. The standard measurement of the piston outside diameter is taken 47 mm (1.85 in.) from the top land of the piston.

Standard diameter

87.97 ~ 88.00mm (3.4633~ 3.4645in.)

4. Inspect the piston ring side clearance. Using a feeler gauge, measure the clearance between new piston ring and the wall of the ring groove.

Piston ring side clearance

Standard No.1 : 0.03 ~ 0.07mm (0.0012 ~ 0.0027in.) No.2 : 0.03 ~ 0.07mm (0.0012 ~ 0.0027in.) Oil ring : 0.06 ~ 0.15mm (0.0024 ~ 0.0059in.) Limit No.1 : 0.1mm (0.004in.) No.2 : 0.1mm (0.004in.) Oil ring : 0.2mm (0.008in.)



If the clearance is greater than maximum, replace the piston.

ECKD001D

3. Calculate the difference between the cylinder bore diameter and the piston diameter.

Piston-to-cylinder clearance 0.02 ~ 0.04mm(0.0008 ~ 0.0016in.) Inspect piston ring end gap.

ENGINE BLOCK

5.

To measure the piston ring end gap, insert a piston Measure the diameter of the piston pin. ring into the cylinder bore. Position the ring at right 1. angles to the cylinder wall by gently pressing it down Piston pin diameter with a piston. Measure the gap with a feeler gauge. If 21.001 ~ 21.006mm (0.8268 ~ 0.8270in.) the gap exceeds the service limit, replace the piston ring. If the gap is too large, recheck the cylinder bore diameter against the wear limits on page EM - 64 If the bore is over the service limit, the cylinder block must be rebored. (See page EM - 65) Piston ring end gap Standard No.1 : 0.15 ~ 0.30mm (0.0059 ~ 0.0118in.) No.2 : 0.30 ~ 0.45m (0.0118 ~ 0.0177in.) Oil ring : 0.20 ~ 0.70mm (0.0079 ~ 0.0275in.) Limit No.1 : 0.6mm (0.0236in.) No.2: 0.7mm (0.0275in.) Oil ring : 0.8mm (0.0315in.) ECKD001Z 2. Measure the piston pin-to-piston clearance. Piston pin-to-piston clearance 0.01 ~ 0.02mm (0.0004 ~ 0.0008in.) Check the difference between the piston pin diameter 3. and the connecting rod small end diameter. Piston pin-to-connecting rod interference 0.016 ~ 0.032mm (0.00063 ~ 0.00126in.) **OIP PRESSURE SWITCH** Check the continuity between the terminal and the 1. body with an ohmmeter. If there is no continuity, replace the oil pressure switch.

PISTON PINS

ECKD001K

EM -68

ENGINE (G4KC - GSL 2.4)

ECKD001W

- 2. Check the continuity between the terminal and the body when the fine wire is pushed. If there is continuity even when the fine wire is pushed, replace the switch.
- If there is no continuity when a 50kpa (7psi) vacuum is applied through the oil hole, the switch is operaing properly.
 Check for air leakage. If air leaks, the diaphragm is broken. Replace it.

REASSEMBLY EG11FEC0

NOTE

- Thoroughly clean all parts to assembled.
- Before installing the parts, apply fresh engine oil to all sliding and rotating surfaces.
- Replace all gaskets, O-rings and oil seals with new parts.
- 1. Assemble piston and connecting rod.
 - 1) Use a hydraulic press for installation.
 - 2) The piston front mark and the connecting rod front mark must face the timing belt side of the engine.

Install piston rings.

Α

- 1) Install the oil ring spacer and 2 side rails by hand.
- 2) Using a piston ring expander, install the 2 compression rings with the code mark facing upward.
- 3) Position the piston rings so that the ring ends are as shown.



ECKD321A

KCRF168A

ECKD001Y

air leakage. If air leaks, the diaphragm is eplace it.

021-62999292

EM -69

ENGINE BLOCK

- 3. Install connecting rod bearings.
 - Align the bearing claw with the groove of the connecting rod or connecting rod cap.
 - Install the bearings(A) in the connecting rod and connecting rod cap(B).
 - A





Install the 2 thrust bearings(A) under the No.3 journal

Install thrust bearings.



5.

4. Install main bearings.

NOTE

- Upper bearings have an oil groove of oil holes; Lower bearings do not.
 - 1) Align the bearing claw with the claw groove of the cylinder block, push in the 5 upper bearings(A).



KCRF173A

 Align the bearing claw with the claw groove of the main bearing cap, and push in the 5 lower bearings.

- ECKD324A
- 6. Place crankshaft on the cylinder block.
- 7. Place main bearing caps on cylinder block.
- 8. Install main bearing cap bolts.

Tightening torque

Main bearing cap bolt 26.46Nm (2.7kgf.m, 19.52lb.ft) + 45°

🚺 NOTE

- The main bearing cap bolts are tightened in 2 progressive steps.
- If any of the bearing cap bolts in broken or deformed, replace it.
- 1) Apply a light coat of engine oil on the threads and under the bearing cap bolts.

021-62999292

EM -70

2) Install and uniformly tighten the 10 bearing cap bolts(A), in several passes, in the sequence shown.

Tightening torque: 26.46Nm (2.7kgf.m, 19.52lbf.ft)



ENGINE (G4KC - GSL 2.4)

4) Apply engine oil to the bolt threads. Install the rod caps with bearings, and torque the bolts.

Tightening torque

19.6Nm (2.0kgf.m, 14.46lbf.ft) + 90°

NOTE

Maintain downward force on the ring compressor to prevent the rings from expanding before entering the cylinder bore.

KCRF171A Retighten the bearing cap bolts by 45° in the nu-ECKD001F Check that the crankshaft turns smoothly.

- Check crankshaft end play. (See page EM 63) 9.
- 10. Install piston and connecting rod assemblies.

merical order shown.

🛄 NOTE

3)

4)

Before installing the pistons, apply a coat of engine oil to the ring grooves and cylinder bores.

- 1) Remove the connecting rod caps, and slip short sections of rubber hose over the threaded ends of the connecting rod bolts.
- 2) Install the ring compressor, check that the bearing is securely in place, then position the piston in the cylinder, and tap it in using the wooden handle of a hammer.
- Stop after the ring compressor pops free, and 3) check the connecting rod-to-check journal alignment before pushing the piston into place.

11. Install ladder frame(A) with 10 bolts.

Tightening torque

23.52 ~ 27.44Nm (2.4 ~ 2.8kgf.m, 17.35 ~ 20.24lbf.ft)



KCRF167A

021-62999292

WWW.DIGITALKHODRO.COM

021-62999292

ENGINE BLOCK



CON A

- · Be assembling ladder frame, the liquid sealant Loctite 5900 should be applied ladder frame.
- The part must be assembled within 5 minutes after sealant was applied.
- Apply sealant to the inner threads of the bolt holes.



KCRF164A

Apply adhesive to 2 or 3 threads. 1) Adhesive : MS 721-39(B) or equivalent.

Tightening torque

ECRF023A

7.84 ~ 11.76Nm (0.8 ~ 1.2kgf.m, 5.78 ~ 8.67lbf.ft)

12. Install rear oil seal.

Sealant

Apply engine oil to a new oil seal lip. 1)

C

- Using SST(09231-H1100, 09214-3K100) and a 2) hammer, tap in the oil seal until its surface is flush with the rear oil seal retainer edge.
- 13. Install balance shaft module. (See page EM 81)
- 14. Install water pump. (See page EM 78)
- 15. Install CKP sensor(A) and sensor cover.

Tightening torque

3.92 ~ 5.88Nm (0.4 ~ 0.6kgf.m, 2.89 ~ 4.34lbf.ft)

KCRF163C



021-62999292

EM -72

17. Install knock sensor(A).

Tightening torque

16.66 ~ 25.48Nm (1.7 ~ 2.6kgf.m, 12.29 ~ 18.78lbf.ft)



KCRF143A

- 18. Install oil level gauge assembly.
 - 1) Install a new O-ring on the oil level gauge.
 - 2) Apply engine oil on the O-ring.
 - 3) Install the oil level gauge assembly(A) with the

Tightening torque

bolt.

7.84 ~ 11.76Nm (0.8 ~ 1.2kgf.m, 5.78 ~ 8.67lbf.ft)



KCRF163B

ENGINE (G4KC - GSL 2.4)

19. Install tensioner assembly integrated bracket(A).



KCRF161A

- 20. Install power steering pomp bracket and power steering pump. (See ST group)
- 21. Install alternator. (See EE group)
- 22. Install A/C compressor. (See HA group)
- 23. Install cylinder head. (See page EM 43)
- 24. Install timing chain. (See page EM 23)
- 25. Install oil pan.
 - 1) Using a razor blade and gasket scraper, remove all the old packing material from the gasket surfaces.

🔟 ΝΟΤΕ

Check that the mating surfaces are clean and dry before applying liquid gasket.
ENGINE BLOCK

 Apply liquid gasket as an even bead, centered between the edges of the mating surface. Use liquid gasket LOCTITE5900 or equivalent(MS721-40A).



KCRF179A

🔟 ΝΟΤΕ

- To prevent leakage of oil, apply liquid gasket to the inner threads of the bolt holes.
- Do not install the parts if five minutes or more have elapsed since applying the liquid gasket. Instead, reapply liquid gasket after removing the
- residue.
 After assembly, wait at least 30 minutes before filling the engine with oil.
- Install the oil pan(A).
 Uniformly tighten the bolts in several passes.

Tightening torque

M8(B) : 26.46 ~ 30.38Nm (2.7 ~ 3.1kgf.m, 19.52 ~ 22.41lbf.ft) M6(C) : 9.8 ~ 11.76Nm (1.0 ~ 1.2kgf.m, 7.23 ~ 8.67lbf.ft)



KCRF114B

- 26. Remove engine stand.
- 27. A/T : Install drive plate.

Tightening torque 117.6 ~ 127.4Nm (12 ~ 13kgf.m, 86.75 ~ 93.98lbf.ft)

28. M/T : Install flywheel.

Tightening torque

117.6 ~ 127.4Nm (12 ~ 13kgf.m, 86.75 ~ 93.98lbf.ft)

🚺 NOTE

- Always use new flywheel(drive plate) bolts.
- Install and uniformly tighten the 7 bolts, in several passes.



WWW.DIGITALKHODRO.COM

ENGINE (G4KC - GSL 2.4)

COOLING SYSTEM

COMPONENT EAD71A6B



- 1. Water pump
- 2. Water pump gasket

3. Water temp control assembly

ECRF024A

COOLING SYSTEM

ENGINE COOLANT REFILLING AND

BLEEDING EA7427B9

😵 WARNING

Never remove the radiator cap when the engine is hot. Serious scalding could be caused by hot fluid under high pressure escaping from the radiator.

\Lambda CAUTION

When pouring engine coolant, be sure to shut the relay box lid and not to let coolant spill on the electrical parts or the paint. If any coolant spills, rinse it off immediately.

- 1. Make sure the engine and radiator are cool to the touch.
- 2. Remove radiator cap.
- 3. Loosen the drain plug, and drain the coolant.
- 4. Tighten the radiator drain plug securely.
- 5. Remove, drain and reinstall the reservoir. Fill the tank halfway to the MAX mark with water, then up to the MAX mark with antifreeze.
- 6. Fill fluid mixture with coolant and water(4 : 6) slowly through the radiator cap. Push the upper/lower hoses of the radiator so as bleed air easily.

- Use only genuine antifreese/coolant.
- For best corrosion protection, the coolant concentration must be maintained year-round at 50% minimum. Coolant concentrations less than 50% may not provide sufficient protection against corrosion or freezing.
- Coolant concentrations greater then 60% will impair cooling efficiency and are not recommended.

- Do not mix different brands of antifreeze/coolants.
- Do not use additional rust inhibitors or antirust products; they may not be compatible with the coolant.

- 7. Start the engine and run coolant circulates. When the cooling fan operates and coolant curculates, refill coolant through the radiator cap.
- 8. Repeat 7 until the cooling fan 3 ~ 5times and bleed air sufficiently out of the cooling system.
- 9. Install the radiator cap and fill the reservoir tank to the "MAX" line with coolant.
- 10. Run the vehicle under idle until the cooling fan operates 2 ~ 3 times.
- 11. Stop the engine and wait coolant gets cool.
- 12. Repeat 6 to 11 until the coolant level doesn't fall any more, bleed air out of the cooling system.

🔟 ΝΟΤΕ

As it is to bleed air out to the cooling system and refill coolant when coolant gets cool completely, recheck the coolant level in the reservoir tank for 2 ~ 3 days after replacing coolant.

CAP TESTING

1. Remove the radiator cap, wet its seal with engine coolant, then install it no pressure tester.



ECKD501X

- Apply a pressure of 93 ~ 123kPa (0.95 ~ 1.25kgf/cm², 14 ~ 19psi)
- 3. Check for a drop in pressure.
- 4. If the pressure drops, replace the cap.

021-62999292

EM -75

021-62999292

ENGINE (G4KC - GSL 2.4)

EM -76

TESTING

1. Wait until engine is cool, then carefully remove the radiator cap and fill the radiator with engine coolant, then install it on the pressure tester.



KCRF184A

- Apply a pressure tester to the radiator and apply a pressure of 93 ~ 123kPa (0.95 ~ 1.25kgf/cm² 14 ~ 18psi).
- Inspect for engine coolant leaks and a drop in pressure.
- 4. Remove the tester and reinstall the radiator cap.

یامانه دیجیتال تعمیرکاران خودرو 🕅 🚺

Check for engine oil in the coolant and/or coolant in the engine oil.

REMOVAL EDFCAE62

WATER PUMP

1. Drain the engine coolant.

😵 WARNING

System is under high pressure when the engine is hot. To avoid danger of releasing scalding engine coolant, remove the cap only when the engine is cool.

- 2. Remove drive belt.
- 3. Remove exhaust manifold. (See apge EM 87)
- 4. Remove the water pump.
 - 1) Remove the 4 bolts and pump pulley.
 - 2) Remove the water pump(B) and gasket.



KCRF157A

5. Remove water inlet pipe nut.

COOLING SYSTEM

THERMOSTAT

🔟 ΝΟΤΕ

Removal of the thermostat would have an adverse effect, causing a lowering of cooling efficiency. Do not remove the thermostat, even if the engine tends to overheat.

- 1. Drain engine coolant so its level is below thermostat.
- 2. Remove water inlet(A) and thermostat(B).

INSPECTION E463BFFA

WATER PUMP

- 1. Check each part for cracks, damage or wear, and replace the coolant pump assembly if necessary.
- 2. Check the bearing for damage, abnormal noise and sluggish rotation, and replace the coolant pump assembly if necessary.
- 3. Check for coolant leakage. If coolant leaks from hole, the seal is defective. Replace the coolant pump assembly

🔟 ΝΟΤΕ

A small amount of "weeping" from the bleed hole is normal.

THERMOSTAT

1. Immerse the thermostat in water and gradually heat the water.

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران

ECKD503B

2. Check the valve opening temperature.

Valve opening temperature : 82°C (177°F) Full opening temperature : 95°C (205°F)

If the valve opening temperature is not as specified, replace the thermostat.

3. Check the valve lift.

Valve lift : 8mm (0.3in.) or more at 95°C (205°F)

If the valve lift is not as specified, replace the thermostat.

WWW.DIGITALKHODRO.COM

021-62999292



EM -77

021-62999292

KCRF123A

ENGINE (G4KC - GSL 2.4)

EM -78

INSTALLATION EF66AB7A

WATER PUMP

- 1. Install the water pump.
 - 1) Install the water pump(A) and a new gasket with the 5 bolts.

Tightening torque 19.6 ~ 26.46Nm (2.0 ~ 2.7kgf.m, 14.46 ~ 19.52lbf.ft)



- 2) Install the 4 bolts and pump pulley.
- 2. Install water inlet pipe nut.

Tightening torque 19.6 ~ 26.46Nm (2.0 ~ 2.7kgf.m, 14.46 ~ 19.52lbf.ft)

- 3. Install exhaust manifold. (See page EM 87)
- 4. Install drive belt.
- 5. Fill with engine coolant.
- 6. Start engine and check for leaks.
- 7. Recheck engine coolant level.

THERMOSTAT

- 1. Place thermostat in thermostat housing.
 - Install the thermostat with the jiggle valve upward.
 - 2) Install a new thermostat(B).



2. Install water inlet(A).

Tightening torque 14.7 ~ 21.56Nm (1.5 ~ 2.2kgf.m, 10.84 ~ 15.90lbf.ft)

- 3. Fill with engine coolant.
- 4. Start engine and check for leaks.

LUBRICATION SYSTEM

LUBRICATION SYSTEM

COMPONENT EF78887C



- 2. Cylinder block
- 3. Balance shaft chain

- 5. Balance shaft chain guide
- 6. Balance shaft chain tensioner arm

ECRF025A

OIL AND FILTER EC274EF9

🚹 CAUTION

- Prolonged and repeated contact with mineral oil will result in the removal of natural fats from the skin, leading to dryness, irritation and dermatitis. In addition, used engine oil contains potentially harmful contaminants which may cause skin cancer.
- Exercise caution in order to minimize the length and frequency of contact of your skin to used oil. Wear protective clothing and gloves. Wash your skin thoroughly with soap and water, or use water-less hand cleaner, to remove any used engine oil. Do not use gasoline, thinners, or solvents.
- In order to preserve the environment, used oil and used oil filter must be disposed of only at designated disposal sites.

1. Drain engine oil.

- a. Remove the oil filter cap.
- b. Remove the oil drain plug, and drain the oil into a container.
- 2. Replace oil filter.
 - a. Remove the oil filter.
 - b. Check and clean the oil filter installation surface.
 - c. Check the part number of the new oil filter is as same as old one.
 - d. Apply clean engine oil to the gasket of a new oil filter.
 - e. Lightly screw the oil filter into place, and tighten it until the gasket contacts the seat.

Tightening torque

11.76 ~ 15.68Nm (1.2 ~ 1.6kgf.m, 8.67 ~ 11.57lbf.ft)

- 3. Refill with engine oil filter.
 - a. Clean and install the oil drain plug with a new gasket.

Tightening torque

39.2 ~ 44.1Nm (4.0 ~ 4.5kgf.m, 28.9 ~ 32.5lbf.ft)

b. Fill with fresh engine oil

Capacity

Drain and refill W/Oil filter change : 4.0l (4.23U.S.qts, 3.52lmp qts) W/O Oil filter change : 3.7l (3.90U.S.qts, 3.26lmp qts)

- c. Install the oil filter cap.
- 4. Start engine and check for oil leaks.

ENGINE (G4KC - GSL 2.4)

5. Recheck engine oil level.

INSPECTION

- Check engine oil quality Check the oil for deterioration, entry of water, discoloring or thinning. If the quality is visibly poor, replace the oil.
- Check engine oil level. After warming up the engine and then 5 minutes after the engine stop, oil level should be between the "L" and "F" marks on the dipstick. If low, check for leakage and add oil up to the "F" mark.

🔟 ΝΟΤΕ

Do not fill with engine oil above the "F" mark.

SELECTION OF ENGINE OIL

Recommended API classification : SJ OR ABOVE

Recommended SAE viscosity grades : 5W-20

🔟 ΝΟΤΕ

For best performance and maximum protection of all types of operation, select only those lubricants whitch

- Satisfy the requirement of the API classification.
- Have proper SAE grade number for expected ambient temperature range.

Lubricants that do not have both an SAE grade number and API service classification on the container should not be used.

LUBRICATION SYSTEM

REMOVAL E7F8189A

- 1. Drain engine oil.
- 2. Remove the drive belt.
- Turn the crankshaft and align the white groove on the crankshaft pulley with the pointer on the lower cover. (See page EM - 8)
- 4. Remove the oil pan. (See page EM 20)
- 5. Remove the timing chain. (See page EM 18)
- 6. Remove balance shaft chain(B) and balance shaft module(A).

INSTALLATION E666CED4

- 1. Install balance shaft chain.
- 2. Confirm the balance shaft module timing mark. Timing marks to be visually aligned with centers of adjacent cast timing notches. (See page EM - 23)
- 3. Install balance shaft module that the timing mark of balance shaft module sprocket should be matched with the timing mark (color link) of balance shaft chain.

Tightenig torque

16.66Nm (1.7kgf.m, 12.3lbf.ft) + 60°+ 60°



KCRF165B

- 4. Install timing chain. (See page EM 24)
- 5. Install oil pan. (See apge EM 26)
- 6. Fill with engine oil.
- 7. Start engine and check for leaks.

ENGINE (G4KC - GSL 2.4)

INTAKE AND EXHAUST SYSTEM

COMPONENT EF4AF4DE

INTAKE MANIFOLD



- 1. Intake manifold gasket
- 2. Intake manifold assembly
- 3. Throttle body

ECRF026A

EXHAUST MANIFOLD



3. Exhaust manifold gasket

ECRF027A

021-62999292

021-62999292

EM -84

MUFFLER

ENGINE (G4KC - GSL 2.4)



ECRF028A

WWW.DIGITALKHODRO.COM

021-62999292

021-62999292

INTAKE AND EXHAUST SYSTEM

REMOVAL E00DFD23

INTAKE MANIFOLD

- 1. Remove the engine cover. (See page EM 18)
- 2. Disconnect ETS connector(A)



Disconnect injector connector(A).

4.



KCRF128A

5. Remove the delivery pipe(A), brake vacuum hose(B), and PCSV hose(C).



3. Disconnect CMP connector(A), and knock sensor connector(B).





KCRF134A

6. Remove coolant hose(A) from throttle body.

KCRF141B

021- 62 99 92 92

WWW.DIGITALKHODRO.COM

EM -85

021-62999292

EM -86

7. Remove oil pressure switch connector(A) from bracket.



KCRF141A

8. Remove knock sensor connector(A) from bracket.

- ENGINE (G4KC GSL 2.4)
- 10. Remove oil level gauge.
- 11. Remove intake manifold stay(A).



KCRF141D

12. Remove intake manifold(A) and gasket(B).



9. Remove PCV hose(A).

KCRF141E

KCRF142A

INTAKE AND EXHAUST SYSTEM

EXHAUST MANIFOLD

1. Remove the oxygen sensor connector.



ECRF018A

- 2. Remove the front muffler.
- 3. Remove the heat protector.



KCRF138A

- 4. Remove exhaust manifold stay bolt.
- 5. Remove exhaust manifold(A) and gasket(B).



INSTALLATION EB2ED2B1

EXHAUST MANIFOLD

1. Install gasket and exhaust manifold.

Tightening torque	
39.2 ~ 44.1N.m(4.0 ~ 4.5kgf.m, 28.92 ~ 32.53lbf.ft)

2. Install exhaust manifold stay bolt.

Tightening torque 51.94 ~ 57.82N.m(5.4 ~ 5.9kgf.m, 38.3 ~ 42.6lbf.ft)

3. Install heat protector.

Tightening torque 18.6 ~ 27.44N.m(1.9 ~ 2.8kgf.m, 13.7 ~ 20.2lbf.ft)

4. Install front muffler.

Tightening torque 39.2 ~ 58.8N.m(4.0 ~ 6.0kgf.m, 28.92 ~ 43.37lbf.ft)

5. Connect oxygen sensor connector.

INTAKE MANIFOLD

1. Install gasket and intake manifold.

 Tightening
 torque

 18.62 ~ 27.44N.m(1.9 ~ 2.8kgf.m, 13.7 ~ 20.2lbf.ft)

2. Install intake manifold stay.

Tightening torque 18.6 ~ 27.44N.m(1.9 ~ 2.8kgf.m, 13.7 ~ 20.2lbf.ft)

- 3. Install oil level gauge
- 4. Install PCV hose
- 5. Install air cleaner assembly.
- 6. Install engine cover.

KCRF140A

WWW.DIGITALKHODRO.COM