# Suspension System

**GENERAL** 

FRONT SUSPENSION SYSTEM FRONT STRUT ASSEMBLY FRONT LOWER ARM FRONT UPPER ARM

FRONT STABILIZER BAR

**REAR SUSPENSION SYSTEM** 

REAR STRUT ASSEMBLY REAR UPPER ARM REAR LOWER ARM REAR ASSIST ARM TRAILING ARM REAR STABILIZER BAR

TIRES / WHEELS WHEEL TIRE

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

#### SUSPENSION SYSTEM

# <u>SS -2</u>

# GENERAL

#### SPECIFICATIONS EBEECBBE

#### FRONT SUSPENSION SYSTEM

Items			Specification
	Туре		
	Туре		Gas
	Stroke	mm (in)	96
	Expansior	n mm (in)	424.0 ± 3
Shock Absorber	Compression mm (in)		328.0 + 3, -∞
	I.D. Color		Green
	Damping force (0.3 m/s)	Expansion N(kgf)	249 ± 34
		Compression N (kgf)	101 ± 18
		Free height mm (in)	347.1
0	3.3/3.8 GSL	I.D. Color	Yellow - Red
Spring		Free height mm (in)	353.7
	3.3/3.8 GSL (HIGH)	I.D Color	Yellow - Blue

#### REAR SUSPENSION SYSTEM

مستوليت محدود	Items	سرخت دیج	Specification
	Туре		
ن خودرو در ایران	Ty دیجیتال تعمیر طارا	pe U U P P	Gas
	Strok	e mm	160.5
	Expans	ion mm	584.6 ± 3
Shock Absorber	Compres	Compression mm	
	I.D. Color		Green
	Damping force	Expansion N(kgf)	128 ± 19
	(0.3 m/s)	Compression N (kgf)	43 ± 9
	3.3/3.8 GSL	Free height mm (in)	327.2
Spring	3.3/3.8 GSL	I.D. Color	Yellow - Pink
		Free height mm (in)	333.5
	3.3/3.8 GSL (HIGH)		Yellow - Green

SS -3

#### WHEELS AND TIRES

Items		Specification
Tire Size		225/60 R16
		235/55 R17
		6.5J×16, OFFSET=38.5
Wheel Size	Aluminium	7.0J×17, OFFSET=38.5
Tire Pressure KPa(kg/cm², psi)		210 (2.1, 30)

#### WHEEL ALIGNMENT

Items		Rear
amber	0°±30′	-0°30′±30′
to Ground	4°50′±45′	-
to Body	5°3′	-
n mm(in)	0±2(0±0.0787)	2±2(0.0787±0.0787)
King pin angle		-
d mm(in)	1565(61.61)	1550(61.02)
	amber to Ground to Body n mm(in) pin angle	amber     0°±30′       to Ground     4°50′±45′       to Body     5°3′       n mm(in)     0±2(0±0.0787)       pin angle     9°27′       d mm(in)     1565(61.61)

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

#### SUSPENSION SYSTEM

#### SS -4

#### TIGHTENING TORQUE E3FC8282

#### FRONT SUSPENSION

Items	Nm	kgf-m	lb-ft
Front strut assembly mounting nut	45 ~ 60	4.5 ~ 6.0	32.5 ~ 43.4
Front strut assembly self-locking nut	20 ~ 25	2.0 ~ 2.5	14.5 ~ 18.1
Front shock absorber to fork nut	60 ~ 80	6 ~ 8	43.4 ~ 57.8
Front lower arm ball joint self-locking nut	75 ~ 90	7.5 ~ 9.0	54.2 ~ 65.1
Front lower arm ball joint mounting bolt	100 ~ 120	10 ~ 12	72.3 ~ 86.8
Front upper arm ball joint self-locking nut	35 ~ 45	3.5 ~ 4.5	25.3 ~ 32.5
Front upper arm mounting bolt	55 ~ 65	5.5 ~ 6.5	39.8 ~ 47.0
Front lower arm bushing(A) mounting bolt	140 ~ 160	14 ~ 16	101.2 ~ 115.7
Front lower arm bushing(G) mounting bolt	140 ~ 160	14 ~ 16	101.2 ~ 115.7
Front lower arm connector nut (to fork)	140 ~ 160	14 ~ 16	101.2 ~ 115.7
Front stabilizer link self-locking nut	100 ~ 120	10 ~ 12	72.3 ~ 86.8
Front stabilizer bar bracket mounting bolt(to Subframe)	45 ~ 55	4.5 ~ 5.5	32.5 ~ 39.8
Wheel nut	90 ~ 110	9 ~ 11	65.1 ~ 79.5

#### REAR SUSPENSION

یتال خودر و سامانه (مسئولیت محدود)	شرکت دیج		
Items	Nm	kgf-m	lb-ft
Rear shock absorber self-locking nut	20 ~ 25	2.0 ~ 2.5	14.5 <mark>~ 18.1</mark>
Rear shock absorber bracket mounting bolt	50 ~ 65	5.0~ 6.5	36.2 ~ 47.0
Rear shock absorber nut (to rear axle assembly)	140 ~ 160	14 ~ 16	101.2 ~ 115.7
Rear upper arm ball joint nut (to rear axle assembly)	80 ~ 90	8 ~ 9	57.8 ~ 65.1
Rear upper arm self-locking nut (to cross member)	100 ~ 120	10 ~ 12	72.3 ~ 86.8
Rear lower arm mounting bolt (to rear axle assembly)	140 ~ 160	14 ~ 16	101.2 ~ 115.7
Rear lower arm mounting nut (to cross member)	110 ~ 120	11 ~ 12	79.5 ~ 86.8
Assist arm mounting bolt (to rear axle assembly)	140 ~ 160	14 ~ 16	101.2 ~ 115.7
Assist arm mounting nut (to cross member)	110 ~ 120	11 ~ 12	79.5 ~ 86.8
Trailing arm mounting nut (to body)	140 ~ 160	14 ~ 16	101.2 ~ 115.7
Trailing arm self-locking nut (to rear axle assembly)	140 ~ 160	14 ~ 16	101.2 ~ 115.7
Cross member mounting bolt	140~ 160	14 ~ 16	101.2 ~ 115.7
Rear stabilizer bar bracket mounting bolt	45 ~ 55	4.5 ~ 5.5	32.5 ~ 39.8
Rear stabilizer link self-locking nut	35 ~ 45	3.5 ~ 4.5	25.3 ~ 32.5
Wheel nut	90 ~ 110	9 ~ 11	65.1 ~ 79.5

# 

Replace the self-locking nuts with new ones after removal.

# WWW.DIGITALKHODRO.COM

#### GENERAL

#### LUBRICANTS

Items	The recommended	Quantity
Front upper arm ball joint	Dust cover : LUBCHEM	
Front lower arm ball joint	SB 6042M Joint boot : Varicant R2 or	As required
Rear upper arm ball joint	Polylub 801K	
Stabilizer link ball joint (Front and Rear)	BJM-2	1.2 ~ 1.7 g

#### SPECIAL SERVICE TOOLS ECA1BB92

Tool (Number and Name)	Illustration	Use
09568-4A000 Ball joint remover		Removal of Ball joint (Front upper arm/lower arm, & Rear upper arm)
C OCIO	KPRE103I	
09532-11600 Preload socket	رکت (د. جنگ) درو سا	Measurement of the front lower arm ball joint starting torque. (Use with torque wrench)
یرکاران خودرو در ایران	ولین سار و بی میتال تعد	
	EIRF001C	
09546-26000 Strut spring compressor		Compression of the coil spring
	KHRE900A	
09214-32000 Mount bushing remover and installer		Removal & installation of lower arm bushing(G) (Use with 09216-21100)
	KHRE900B	

# SUSPENSION SYSTEM

Tool (Number and Name)	Illustration	Use
09216-21100 Mount bushing remover and installer		Removal & installation of lower arm bushing(G) (Use with 09216-32000)
	KHRE900C	
09216-21600 Mount bushing remover and installer arbor		Removal and installation of trailing arm bushing (Use with 09552-38100)
	KHRE900D	
09552-38100 Rear trailing arm bushing remover and installer	لی میں المیں ا المیں المیں الم	Removal and installation of the rear trailing arm bushing (Use with 09216-21600)
	KHRE900E	

#### GENERAL

#### TROUBLESHOOTING E05DCEB0

#### **VEHICLE INSPECTION**

listed below by filling them. It serves as a place to record information as well as data from the testing to be carried out. To begin a successful diagnosis, fill out the questions.

To assist the service advisor and the technician, check the suspension and wheel/tire condition with the questions

WHEEL/TIRE/CHECK :					
Balance Check Yes /	No				
Maximum Runout Allowed	d :				
Wheel :	Radial	Lateral			
Tire :	Radial	Lateral			
Measured Runout :					
Tire/Wheel	Radial :	LF	. LR	RF	RR
	Lateral :	LF	. LR	RF	RR
Wheel Only	Radial :	LF	. LR	RF	RR
	Lateral :	LF	. LR	RF	RR
SUSPENSION INSPECT					
Can Cause	Shimmy	Clunk	Squeak	Harshness	
Suspension Bushing :	Loose	Worn	Missing	ОК	
Front stabilizer		ear stabilizer (sway bar)	Rear	trailing arm	
Front lower arm	H (می	ear suspension front	Rear	suspension rear	arm
Other				-	
خودرو در ایران					
Suspension/Components	:	Loose Worm Mis	sing OK		
Ball Joint	S	hock absorbers F/R	Spring	gs F/R	The rod ends/sleeve
					EHKE002

#### SYMPTOM CHART

Symptom	Suspect Area	Remedy (See page)
Squeak or grunt-noise from the front suspension, occurs more in cold ambient temperatures-more noticeable over rough roads or when turning	Front stabilizer bar	Under these conditions, the noise is acceptable.
Clunk-noise from the front suspension, occurs in and out of turns	Loose front struts or shocks	Inspect for loose nuts or bolts. Tighten to specifications. See page SS-26.
Clunk-noise from the rear suspension, occurs when shifting from reverse to drive	Loose rear suspension components	Inspect for loose or damaged rear suspension components. Repair or install new components as necessary. See page SS-47.

# SUSPENSION SYSTEM

Symptom	Suspect Area	Remedy (See page)
Click or pop-noise from the front suspension-more noticeable over rough roads or over bumps	Worn or damaged ball joints	Install new lower arm as necessary. See page SS-34.
Click or pop-noise occurs when vehicle is turning	Worn or damaged ball joints	Install new lower arm as necessary. See page SS-34.
Click or snap-occurs when accelerating around a corner	Damaged or worn Birfield joint	Repair or install a new Birfied joint as necessary. See DS group - driveshaft.
Front suspension noise-a squeak, creak or rattle noise-occurs mostly over bumps or rough roads	Steering components Loose or bent front struts or shock absorbers Damaged spring or spring mounts Damaged or worn arm bushings Worn or damaged stabilizer bar bushing or links	Go to detailed test A. See page SS-11.
Groaning or grinding-noise from the front strut, occurs when driving on bumpy roads or turning the vehicle	Uneven seating surface between the insulator and panel by the burrs around the strut insulator mounting bolts and the insulator boltes mounting holes	Repair or install a new parts as necessary. See page SS-29.
Rear suspension noise - a squeak, creak or rattle noise - occurs mostly over bumps or rough roads	Loose or bent rear shock absorbers Damaged spring or spring mounts Damaged or worn control arm bushings	Go to detailed test B. See page SS-12.
Shudder-occurs during acceleration from a slow speed or stop	Rear axle assembly mispositioned Damaged or worn front suspension components	Check the axle mounts and Rear suspension the rear suspension for damage or wear. Repair as necessary. Check for a loose stabilizer bar, damaged or loose strut/strut bushings or loose or worn ball joints. Inspect the steering linkage for wear or damage. Repair or Install new components as necessary.
Shimmy-most noticeable on coast/deceleration-also hard steering condition	Excessive positive caster	Check the caster alignment angle. Correct as necessary. See page SS-70.
Tire noise-hum/moan at constant speeds	Abnormal wear patterns	Spin the tire and Check for tire wear. Install a new tire as necessary. Inspect for damaged/worn suspension components. Carry out wheel alignment. See page SS-68, SS-72.
Tire noise-noise tone lowers as the vehicle speed is lowered	Out-of-balance tire	Balance the tire and road test. Install a new tire as necessary. See page SS-72.
Tire noise - ticking noise, change with speed	Nail puncture or stone in tire tread	Inspect the tire. Repair as necessary. See page SS-72.

# WWW.DIGITALKHODRO.COM

# GENERAL

SS -9

Symptom	Suspect Area	Remedy (See page)
Wheel and tire-vibration and noise concern is directly related to vehicle speed and is not affected by acceleration, coasting or decelerating	Damaged or worn tire	Go to detailed test C. See page SS-13.
Tire wobble or shudder - occurs at lower speeds	Damaged wheel bearings	Spin the tire and check for abnormal wheel bearing play or roughness. Adjust or Install new wheel bearings as necessary. See DS group - front/rear axle.
	Damaged wheel	Inspect the wheel for damage. Install a new wheel as necessary. See page SS-72.
	Damaged or worn suspension components	Inspect the suspension components for wear or damage. Repair as necessary. See page SS-26.
	Loosen wheel nuts	Check the wheel nuts. Tighten to specification. See page SS-71.
- خودرو	Damaged or uneven tire wear	Spin the tire and Check for abnormal tire wear or damage. Install a new tire as necessary. See page SS-72.
Tire shimmy or shake - occurs	Wheel/tire out of balance	See page SS-70.
at lower speeds	Uneven tire wear	Check for abnormal tire wear. Install a new tire as necessary.
همیرکاران خودرو در ایران	اولین سامانه دیجیتال ت	See page SS-72.
	Excessive radial runout of wheel or tire	Carry out a radial runout test of the wheel and tire. Install a new tire as necessary. See page SS-70.
	Worn or damaged wheel studs or elongate stud holes	Inspect the wheel studs and wheels. Install new components as necessary. See page SS-72.
	Excessive lateral runout of the wheel or tire	Carry out a lateral runout test of the wheel and tire. Check the wheel, tire and hub. Repair or Install new components as necessary. See page SS-70.
	Foreign materal between the brake disc and hub.	Clean the mounting surfaces of the brake disc and hub. See DS group - front/rear axle.
High speed shake or shimmy-occurs at high speeds	Excessive wheel hub runout Damaged or worn tires Damaged or worn wheel bearings Worn or damaged suspension or steering linkage Brake disc or drum imbalance	Go to detailed test D. See page SS-16.

# WWW.DIGITALKHODRO.COM

# <u>SS -10</u>

# SUSPENSION SYSTEM

Symptom	Suspect Area	Remedy (See page)
Drift left or right	Tires Steering linkage Alignment Base brake system	Go to detailed test E. See page SS-18.
Steering wheel	Alignment Steering linkage Front lower arm ball joint	Go to detailed test F. See page SS-19.
Tracks incorrectly	Rear suspension Caster	Go to detailed test G. See page SS-20.
Rough ride	Front strut and spring assembly Rear shock absor and spring assembly	Go to detailed test H. See page SS-20.
Excessive noise	Front or rear stabilizer bar components Springs Suspension components Shock absorbers	Go to detailed test I. See page SS-21.
Incorrect tire wear	Tire or unbalanced wheels Tire inflation Strut Alignment	Go to detailed test J. See page SS-22.
نامانه (مسئولیت محدود) میرکاران خودرو در ایران	Wheel/tire Front wheel drivshaft(s) Steering system Strut and spring assembly Spring and strut mounting Front lower arm ball joint Front lower arm mounting bolt bushing Stabilizer bar bushings Wheel hubs and bearing Rear suspension arms and bushings	Go to detailed test K. See page SS-22.
Vehicle leans	Tire/wheel Vehicle load Suspension components Incorrect ride height	Inflate tires to specification. Redistribute the load as necessary. Visually inspect the suspension system. Correct the ride height as necessary.
Poor returnability	High knuckle rotating torque Alignment	Go to detailed test E. See page SS-18.

SS -11

#### DETAILED TEST A : FRONT SUSPENSION NOISE

CONDITIONS	DETAILS/RESULTS/ACTIONS	
A1ROAD TEST THE VEHICLE		
	<ol> <li>Test drive the vehicle.</li> <li>During the road test, drive the vehicle over a rough road. Determine from which area/component the noise is originating.</li> </ol>	
	Is there a squeak, creak or rattle noise ?	
	$\Rightarrow$ YES Go toA2.	
	$\Rightarrow$ <b>NO</b> The suspension system is OK. Conduct a diagnosis on other suspect systems.	
A2INSPECT THE STEERING SY	STEM	
	<ol> <li>Check the steering system for wear or damage. Carry out a steering linkage test. Inspect the tire wear pattern. See page SS-25.</li> </ol>	
	Are the steering components worn or damaged ?	
CPCIP	⇒ YES Repair the steering system. Install new components as necessary. Test the system for normal operation.	
مانه (مسئولیت محدود)	لس ⇒ NO التعديد المالي في المالي ا Go toA3.	
A3FRONT SHOCK ABSORBER/S	STRUT CHECK	
یرکاران خودرو در ایران	<ol> <li>Check the front shock absorbers/strut mounts for loose bolts or nuts.</li> <li>Check the front shock absorbers/struts for damage. Carry out a shock absorber check.</li> </ol>	
	Are the front shock absorbers/struts loose or damaged ?	
	$\Rightarrow$ YES Tighten to specifications if loose. Install new front shock absorbers/struts if damaged. Test the system for normal operation.	
	⇒ NO Go toA4.	
A4CHECK THE FRONT SPRINGS		
	Check the front spring and front spring mounts/brackets for wear or damage	
	Are the front springs or spring mounts/brackets worn or damaged ?	
	$\Rightarrow$ YES Repair or Install new components as necessary. Test the system for normal operation.	
	⇒ NO Go toA5.	

# WWW.DIGITALKHODRO.COM

#### SUSPENSION SYSTEM

CONDITIONS	DETAILS/RESULTS/ACTIONS
A5CHECK THE STABILIZER BAR	र
	<ol> <li>Check the stabilizer bar bushing and links for damage or wear.</li> <li>Check the stabilizer bar for damage.</li> <li>Check for loose or damaged stabilizer brackets.</li> <li>● Are the stabilizer bar/track bar components loose, worn or damaged ?</li> <li>⇒ YES Repair or Install new components as necessary. Test the system for normal operation.</li> <li>⇒ NO</li> </ol>
	Suspension system is OK. Conduct diagnosis on other suspect systems.

#### DETAILED TEST B : REAR SUSPENSION NOISE

CONDITIONS	DETAILS/RESULTS/ACTIONS
B1ROAD TEST THE VEHICLE	
جەכוە	<ol> <li>Test drive the vehicle.</li> <li>During the road test, drive the vehicle over a rough road. Determine from which area/component the noise is originating.</li> <li>Is there a squeak, creak or rattle noise ?</li> </ol>
انه (مسئولیت محدود)	شرکت دیجیتال ¥ES Go to <b>B2</b> .
رکاران خودرو در ایران	⇒ NO The suspension system is OK. Conduct a diagnosis on other suspect systems.
B2REAR SHOCK ABSORBER/S	TRUT CHECK
	<ol> <li>Raise and support the vehicle. See GI group - lift support point.</li> <li>Check the rear shock absorber/strut mounts for loose bolts or nuts.</li> <li>Check the rear shock absorbers/strut for damage. Carry out a shock absorber check.</li> </ol>
	Are the rear shock absorbers/struts loose or damaged ?
	⇒ YES Tighten to specifications if loose. Install new rear shock absorbers/struts if damaged. Test the system for normal operation.
	⇒ NO Go toB3.

CONDITIONS	DETAILS/RESULTS/ACTIONS
B3CHECK THE REAR SPRINGS	5
	Check the rear springs and rear spring mounts/brackets for wear or damage.
	Are the rear springs or spring mounts/brackets worn or damaged ?
	$\Rightarrow$ YES Repair or Install new components as necessary. Test the system for normal operation.
	⇒ NO Go toB4.
<b>B4</b> CHECK THE TRAILING ARM	S
	<ol> <li>Inspect the trailing arm bushings for wear or damage. Check for loose trailing arm bolts.</li> <li>Inspect for twisted or bent trailing arms.</li> </ol>
	Are the trailing arms loose, damaged or worn ?
	<ul> <li>⇒ YES</li> <li>Repair or Install new components as necessary. Test the system for normal operation.</li> <li>⇒ NO</li> </ul>
	Suspension system is OK. Conduct diagnosis on other suspect systems.

# DETAILED TEST C : WHEEL AND TIRE

CONDITIONS	DETAILS/RESULTS/ACTIONS
C1ROAD TEST THE VEHICLE	
	<ul> <li>NOTE</li> <li>Wheel or tire vibrations felt in the steering wheel are most likely related to the front wheel or tire. Vibration felt through the seat are most likely related to the rear wheel or tire. This may not always be true, but it can help to isolate the problem to the front or rear of the vehicle. Test drive the vehicle at different speed ranges.</li> <li>During the road test, if the vibration can be eliminated by placing the vehicle in neutral or is affected by the speed of the engine, the cause is not the wheels or tires.</li> <li>Is there a vibration and noise ?</li> <li>YES Go toC2.</li> <li>NO</li> <li>The wheel and tires are OK. Conduct a diagnosis on other suspect systems.</li> </ul>

<u>SS -14</u>

# SUSPENSION SYSTEM

CONDITIONS	DETAILS/RESULTS/ACTIONS	
C2CHECK THE FRONT WHEEL BEARINGS		
	Check the front wheel bearings. Refer to Wheel Bearing Check (See DS group - front axle).	
	Are the wheel bearings OK ?	
	$\Rightarrow$ YES Go to <b>C3</b> .	
	$\Rightarrow$ NO Inspect the wheel bearings. Adjust or Repair as necessary. Test the system for normal operation.	
C3INSPECT THE TIRES		
	<ol> <li>Check the tires for missing weights.</li> <li>Check the wheels for damage.</li> <li>Inspect the tire wear pattern. See page SS-25.</li> </ol>	
	Do the tires have an abnormal wear pattern ?	
	$\Rightarrow$ YES Correct the condition that caused the abnormal wear. Install new tire(s). Test the system for normal operation.	
()0)201"	⇒ NO Go toC4.	
C4TIRE ROTATION DIAGNOSIS		
	<ol> <li>Spin the tires slowly and watch for signs of lateral runout.</li> <li>Spin the tires slowly and watch for signs of radial runout.</li> </ol>	
	Are there signs of visual runout ?	
	$\Rightarrow$ YES Go to <b>C5</b> .	
	⇒ NO Check the wheel and tire balance. Correct as necessary. Test the system for normal operation.	
C5RADIAL RUNOUT CHECK ON THE TIRE		
	Measure the radial runout of the wheel and tire assembly. A typical specification for total radial runout is 1.15mm (0.059 inch).	
	Is the radial runout within specifications ?	
	$\Rightarrow$ YES Go to <b>C8</b> .	
	$\Rightarrow$ NO Go toC6.	

CONDITIONS	DETAILS/RESULTS/ACTIONS		
C6RADIAL RUNOUT CHECK O	C6RADIAL RUNOUT CHECK ON THE WHEEL		
	Measure the radial runout of the wheel. A typical specification for total radial runout is 1.14mm (0.045 inch.).		
	Is the radial runout within specifications ?		
	$\Rightarrow$ YES Install a new tire. Test the system for normal operation.		
	$\Rightarrow$ NO Go toC7.		
C7CHECK THE HUB/BRAKE DIS	SC OR DRUM PILOT RUNOUT OR BOLT CIRCLE RUNOUT		
	Measure the pilot or bolt circle runout. A typical specification for radial runout is : <ul> <li>pilot runout - less than 0.15mm (0.006 inch.)</li> <li>bolt circle runout - less than 0.38 mm (0.015 inch.)</li> </ul>		
	Is the radial runout within specification ?		
•	$\Rightarrow$ YES Install a new wheel. Test the system for normal operation.		
CPCIP	⇒ NO Repair or Install new components as necessary. See page SS-26 for the front suspension or SS-47 for the rear suspension.		
C8LATERAL RUNOUT CHECK	شرکت دیجیتال ON THE TIRE		
رکاران خودرو در ایران	Measure the lateral runout of the wheel and tire assembly. A typical specification for total lateral runout is 2.5mm (0.098 inch).  Is the lateral runout within specifications ?		
	$\Rightarrow$ YES Wheel and tires are OK. Conduct diagnosis on other suspect systems.		
	$\Rightarrow$ NO Go to <b>C9</b> .		
C9LATERAL RUNOUT CHECK	C9LATERAL RUNOUT CHECK ON THE WHEEL		
	Measure the lateral runout of the wheel. A typical specification for total radial runout is 1.2mm (0.047 inch.)		
	Is the lateral runout within specifications ?		
	$\Rightarrow$ YES Install a new tire. Test the system for normal operation.		
	$\Rightarrow$ NO Go toC10.		

<u>SS -1</u>6

# SUSPENSION SYSTEM

CONDITIONS	DETAILS/RESULTS/ACTIONS
C10CHECK THE FLANGE FACE	LATERAL RUNOUT
	Measure the flange face lateral runout. A typical specification for lateral runout is : ● hub/brake disc - less than 0.13mm (0.005 inch)
	Is the lateral runout within specifications ?
	$\Rightarrow$ YES Install a new wheel. Test the system for normal operation.
	$\Rightarrow$ NO Repair or Install new components as necessary. See page SS-26 for the front suspension or SS-47 for the rear suspension.

#### DETAILED TEST D :

CONDITIONS	DETAILS/RESULTS/ACTIONS
D1CHECK FOR FRONT WHE	EL BEARING ROUGHNESS
	<ol> <li>Raise and support the front end of the vehicle so that the front wheel and tire assemblies can spin. See GI group - lift support point.</li> <li>Spin the front tires by hand.</li> <li>Do the wheel bearings feel rough ?</li> <li>⇒ YES         Inspect the wheel bearings. Repair as necessary. Test the system for normal operation.     </li> </ol>
	$\Rightarrow$ NO Go toD2.
D2CHECK THE END PLAY OF	THE FRONT WHEEL BEARINGS
	Check the end play of the front wheel bearings.
	● Is the end play OK ?
	$\Rightarrow$ YES Go toD3.
	$\Rightarrow$ <b>NO</b> Adjust or Repair as necessary. Test the system for normal operation.
<b>D3</b> MEASURE THE LATERAL R	UNOUT AND THE RADIAL RUNOUT OF THE FRONT WHEELS ON THE VEHICLE
	Measure the lateral runout and the radial runout of the front wheels on the vehicle. Go to detailed test C.
	Are the measurements within specifications ?
	$\Rightarrow$ YES Go toD4.
	$\Rightarrow$ NO Install new wheels as necessary and Balance the assembly. Test the system for normal operation.

# WWW.DIGITALKHODRO.COM

CONDITIONS	DETAILS/RESULTS/ACTIONS	
D4MEASURE THE LATERAL RUNOUT OF THE FRONT TIRES ON THE VEHICLE		
	Measure the lateral runout of the front tires on the vehicle. Go to detailed test C.	
	Is the runout within specifications ?	
	$\Rightarrow$ YES Go toD5.	
	⇒ NO	
	Install new tires as necessary and Balance the assembly. Test the system for normal operation.	
D5MEASURE THE RADIAL RU	NOUT OF THE FRONT TIRES ON THE VEHICLE	
	Measure the radial runout of the front tires on the vehicle. Go to detailed test C.	
	Is the runout within specifications ?	
	<ul> <li>⇒ YES</li> <li>Balance the front wheel and tire assemblies. If any tire cannot be balanced, Install a new tire. Test the system for normal operation.</li> </ul>	
<u> </u>	⇒ NO Go toD6.	
D6MATCH MOUNT THE TIRE	AND WHEEL ASSEMBLY	
انه (مسئولیت محدود)	Mark the high runout location on the tire and also on the wheel. Break the assembly down and rotate the tire 180 degrees (halfway around) on the wheel. Inflate the tire and measure the radial runout.	
رکاران خودرو در ایران	Is the runout within specifications ?	
	⇒ YES Balance the assembly. Test the system for normal operation.	
	$\Rightarrow$ <b>NO</b> If the high spot is not within 101.6mm (4 inches) of the first high spot on the tire, Go to <b>D7.</b>	
D7MEASURE THE WHEEL FLA	ANGE RUNOUT	
	Dismount the tire and mount the wheel on a wheel balancer. Measure the runout on both wheel flanges. Go to detailed test C	
	Is the runout within specifications ?	
	⇒ <b>YES</b> Locate and Mark the low spot on the wheel. Install the tire, matching the high spot on the tire with the low spot on the wheel. Balance the assembly. Test the system for normal operation. If the condition persists, Go to <b>D8.</b>	
	⇒ NO Install a new wheel. Check the runout on the new wheel. If the new wheel is within limits, locate and Mark the low spot. Install the tire, matching the high spot on the tire with the low spot on the wheel. Balance the assembly. Test the system for normal operation. If the condition persists, Go to <b>D8.</b>	

# WWW.DIGITALKHODRO.COM

# SUSPENSION SYSTEM

CONDITIONS	DETAILS/RESULTS/ACTIONS
D8CHECK FOR VIBRATION FF	ROM THE FRONT OF THE VEHICLE
	Spin the front wheel and tire assemblies with a wheel balancer while the vehicle is raised on a hoist. Feel for vibration in the front fender or while seated in the vehicle.
	● Is the vibration persent ?
	$\Rightarrow$ YES Substitute known good wheel and tire assemblies as necessary. Test the system for normal operation.
	$\Rightarrow$ NO Check the driveline components. Test the system for normal operation.

#### DETAILED TEST E : DRIFT LEFT OR RIGHT

CONDITIONS	DETAILS/RESULTS/ACTIONS
E1CHECK THE TIRES	
	Inspect the tires for excessive wear or damage.
	Are the tires excessively worn or damaged ?
	⇒ YES Install new tires.
ه (مسئولیت محدود)	⇒ NO Go toE2. شرکت دیجیتال خود
E2CHECK THE STEERING LI	NKAGE
کاران خودرو در ایران	<ol> <li>Raise and support the vehicle.</li> <li>Check the steering components for indications of excessive wear or damage. See ST group - specification.</li> <li>Is there an indication of excessive wear or damage ?</li> </ol>
	<ul> <li>⇒ YES</li> <li>Repair or Install new components as necessary.</li> <li>⇒ NO</li> </ul>
	Go to <b>E3</b> .
E3CHECK THE VEHICLE ALIO	GNMENT
	<ol> <li>Place the vehicle on an alignment rack. Check the vehicle alignmnt.</li> </ol>
	Is the alignment within specification ?
	$\Rightarrow$ YES Go toE4.
	<ul> <li>⇒ NO</li> <li>Adjust the alignment as necessary.</li> <li>See page SS-68 (wheel alignment).</li> </ul>

CONDITIONS	DETAILS/RESULTS/ACTIONS
E4BRAKE DRAG DIAGNOSIS	
	Apply the brakes while driving.
	Does drift or pull occur when the brakes are applied ?
	⇒ YES See BR group - specification.
	$\Rightarrow$ NO If the steering wheel is in the center, the vehicle is OK.
	If the steering wheel is off-center, Go to Detailed Test <b>F.</b>

#### DETAILED TEST F : STEERING WHEEL OFF-CENTER

CONDITIONS	DETAILS/RESULTS/ACTIONS
F1CHECK THE CLEAR VISIO	N
	Place the vehicle on an alignment rack.
•	Is the clear vision within specification ?
CPCIP	⇒ YES Go toF2.
نه (مسئولیت محدود)	⇒ NO Adjust the clear vision to specification.
F2INSPECT THE STEERING (	COMPONENTS
کاران خودرو در ایران	<ol> <li>Raise and support the vehicle.</li> <li>Inspect the steering components for excessive wear or damage. See ST group - specification.</li> </ol>
	Are the steering components excessively worn or damaged ?
	⇒ YES Repair or Install new components as necessary.
	$\Rightarrow$ <b>NO</b> If it tracks corectly, vehicle is OK.
	If it tracks incorrectly, Go to Detailed TestG.

#### SUSPENSION SYSTEM

#### DETAILED TEST G : TRACKS INCORRECTLY

CONDITIONS	DETAILS/RESULTS/ACTIONS
G1CHECK THE CASTER	
P	lace the vehicle on an alignment rack.
•	Is the caster within specification ?
	• YES o toG2.
	NO
	eplace bent or damaged parts.
G2CHECK THE REAR SUSPENS	SION
1. 2.	
	• Are the measurements the same ?
	$\Rightarrow$ YES
	If the ride is smooth, vehicle is OK.
	If the ride is rough, Go to Detailed TestH.
	⇒ NO
مانه (مسئوليت محدود)	Inspect the rear suspension components for wear or damage. Repair or Install new components as necessary. See page SS-47 (rear suspension).

# اولین سامانه دیجیتال تع Rough Ride : A Test H : Rough Ride

CONDITIONS	DETAILS/RESULTS/ACTIONS
H1CHECK THE FRONT SHOC	K ABSORBER
	<ol> <li>Raise support the vehicle.</li> <li>Inspect the front shock absorber for oil leaks or damage.</li> </ol>
	Are the tires excessively worn or damaged ?
	<ul> <li>⇒ YES</li> <li>Install new front shock absorbers.</li> <li>See page SS-29 (front strut assembly).</li> </ul>
	$\Rightarrow$ NO Go toH2.

CONDITIONS	DETAILS/RESULTS/ACTIONS
H2CHECK THE REAR SHOCK	ABSORBERS
	Inspect the rear shock absorbers for oil leaks or damage.
	Are the rear shock absorbers leaking ?
	⇒ YES
	Install new rear shock absorbers.
	See page SS-50 (rear strut assembly).
	⇒ NO
	The vehicle is OK. Go to TROUBLESHOOTING.

#### DETAILED TEST I : EXCESSIVE NOISE

CONDITIONS	DETAILS/RESULTS/ACTIONS
<b>11INSPECT THE SUSPENSION</b>	l I
	<ol> <li>Raise and support the vehicle.</li> <li>Inspect the shock absorber mounting bolts.</li> </ol>
- I	Are the mounting bolts loose or broken ?
	⇒ YES Tighten or Install new shock absorber mounting bolts. See page SS-29 and SS-49 (front/rear suspension)
نه (مسئولیت محدود)	Go tol2.
12INSPECT THE SPRING AND	TORSION BARS
کاران خودرو در ایران	Inspect the springs and stabilizer bars for damage.
	<ul> <li>Are the spring or stabilizer bars damaged ?</li> <li>⇒ YES</li> </ul>
	Install new spring and/or stabilizer bars. See page SS-44 and SS-67 (front/rear stabilizer bars).
	⇒ NO Go tol3.
<b>I3INSPECT THE FRONT SUSF</b>	PENSION
	Inspect the front suspension components for excessive wear or damage.
	Are the front suspension components worn or damaged ?
	⇒ YES
	Install new front suspension components. See page SS-26 (front suspension).
	$\Rightarrow$ <b>NO</b> The vehicle is OK. Go to <b>TROUBLESHOOTING.</b>

#### SUSPENSION SYSTEM

#### DETAILED TEST J : INCORRECT TIRE WEAR

CONDITIONS	DETAILS/RESULTS/ACTIONS
J1INSPECT THE TIRES	
	<ol> <li>Raise and support the vehicle.</li> <li>Inspect the tires for uneven wear on the inner or outer shoulder.</li> </ol>
	Is there uneven tire wear ?
	⇒ YES
	Align the vehicle. Install new tires if badly worn.
	⇒ NO
	Go to <b>J2.</b>
J2UNEVEN TIRE WEAR	
	Inspect the tires for a feathering pattern.
	Do the tires have a feathering pattern ?
	$\Rightarrow$ YES Align the vehicle. Install new tires if badly worn.
	⇒ NO Go toJ3.
J3CHECK FOR CUPPED TIRE	
ه (مسئولیت محدود)	Inspect the tires for cupping or dishing.
	Are the tires cupped or dished ?
کاران خودرو در ایران	اولین سامانه دیجیتال تعمیر ۲ES ♦
	Balance and Rotate the tires.
	⇒ NO
	The vehicle is OK. Go to TROUBLESHOOTING.

#### DETAILED TEST K : VIBRATION

CONDITIONS	DETAILS/RESULTS/ACTIONS
K1ROAD TEST	
	<ul> <li>Accelerate the vehicle to the speed at which the customer indicated the vibration occured.</li> <li>Is the vibration present ?</li> </ul>
	$\Rightarrow$ YES Go toK2.
	$\Rightarrow$ <b>NO</b> The vehicle is OK. Go to <b>TROUBLESHOOTING.</b>

CONDITIONS	DETAILS/RESULTS/ACTIONS
K2INSPECT THE TIRES	
	<ol> <li>Raise and support the vehicle with a frame contact hoist.</li> <li>Inspect the tires for extreme wear or damage, cupping, or flat spots.</li> </ol>
	• Are the tires OK ?
	$\Rightarrow$ YES Go toK3.
	$\Rightarrow$ <b>NO</b> Check the suspension components for misalignment, abnormal wear, or damage that may have contributed to the tire wear. Correct the suspension concerns and Install new tires.
K3INSPECT THE WHEEL BEA	RINGS
	Spin the tires by hand to check for wheel bearing rougness.
	● Is the front wheel bearing OK ?
•	⇒ YES Go toK4.
	<ul> <li>⇒ NO</li> <li>Install new front wheel bearings as necessary.</li> <li>See Ds group - front axle.</li> </ul>
K4TIRE/WHEEL BALANCE	شرکت دیجیتال خودرو ساما
کاران خودرو در ایران	Check the tire/wheel balance.  Are the tires balanced ?
	⇒ YES Go toK5.
	$\Rightarrow$ NO Balance the tires and wheels as necessary.
K5MEASURE THE RUNOUTS	
	For each wheel position measure, locate and mark the following items. See page SS-70 (wheel/tire). - High point of the tire/wheel assembly total radial runout - High point of the wheel radial runout - High point of the wheel lateral runout
	Are the runouts as specified ?
	$\Rightarrow$ YES Go toK7.
	$\Rightarrow$ NO Go toK6.

# 021-62999292

SS -24

#### SUSPENSION SYSTEM

CONDITIONS	DETAILS/RESULTS/ACTIONS
K6SUBSTITUTE THE WHEELS	S AND TIRE
	<ol> <li>Substitute a known good set of wheels and tires.</li> <li>Carry out a road test.</li> <li>If the vehicle still exhibits a shake or vibration, note the vehicle speed and/or engine rpm which it occurs.</li> <li>Is the vibration felt ?</li> <li>⇒ YES         Engine/transmission imbalance.         See the specification of TR group, EM group, FL group and EC group.     </li> <li>NO         Install the original tire/wheel assemblies one by one, Road testing at each step until the damaged tire(s)/wheel(s) as necessary. Test the system for normal operation.     </li> </ol>

Wheel /tire noise, vibration and harshness concerns are directly related to vehicle speed and are not generally affected by acceleration, coasting or decelerating. Also, out-of-balance wheel and tires can vibrate at more than one speed. A vibration that is affected by the engine rpm, or is eliminated by placing the transmission in Neutral is not related to the tire and wheel. As a general rule, tire and wheel vibrations felt in the steering wheel are related to the front tire and wheel assemblies. Vibrations felt in the seat or floor are related to the rear tire and wheel assemblies. This can initially isolate a concern to the front or rear.

Careful attention must be paid to the tire and wheels. There are several symptoms that can be caused by damaged or worn tire and wheels. Carry out a careful visual inspection of the tires and wheel assemblies. Spin the tires slowly and watch for signs of lateral or radial runout. Refer to the tire wear chart to determine the tire wear conditions and actions

SS -25

WHEEL AND TIRE DIAGNOSIS		
Rapid wear at the center	Rapid wear at both shoulders	Wear at one shoulder
AHIE002A	AHIE002B	AHIE002C
<ul> <li>Center-tread down to fabric due to excessive over inflated tires</li> <li>Lack of rotation</li> <li>Excessive toe on drive wheels</li> <li>Heavy acceleration on drive</li> </ul>	<ul> <li>Under-inflated tires</li> <li>Worn suspension components</li> <li>Excessive cornering speeds</li> <li>Lack of rotation</li> </ul>	<ul> <li>Toe adjustment out of specification</li> <li>Camber out of specification</li> <li>Damaged strut</li> <li>Damaged lower arm</li> </ul>
Partial wear	Feathered edge	Wear pattern
	AHIE002F	
Caused by irregular burrs on brake drums	<ul> <li>Toe adjustment out of specification</li> <li>Damaged or worn tie rods</li> <li>Damaged knuckle</li> </ul>	<ul> <li>Excessive toe on non-drive wheels</li> <li>Lack of rotation</li> </ul>

## SUSPENSION SYSTEM

# FRONT SUSPENSION **SYSTEM**

COMPONENTS E8C59A6B

SS -26



- 2. Front upper arm
- 3. Front subframe
- 4. Front knuckle

- 5. Front disk
- 6. Tie rod end assembly
- 7. Front lower arm
- 8. Front stabilizer bar assembly

EHBF100A

# FRONT SUSPENSION SYSTEM

# FRONT STRUT ASSEMBLY

#### COMPONENTS E96AC2DC



3. Insulator

- 6. Urethane bumper
- 9. Shock absober

EHBF100B

# WWW.DIGITALKHODRO.COM

# 021-62999292

SUSPENSION SYSTEM

#### SS -28

#### REMOVAL E051662B

- Loosen the wheel nuts slightly. Raise the front of the vehicle, and make sure it is securely supported.
- 2. Remove the front wheel and tire(A) from front hub(B).



Remove the front stabilizer link nut(B) from the fork(A).



KHBF110B

Remove the fork(A) from the front lower arm(B) connecting bolt(C).

KHBF101A

5.

# 

**Be careful not to damage the hub bolts(C) when** removing the front wheel and tire(A).

3. Remove the brake hose bracket bolt(A) and speed sensor cable mounting bolt(B) from the front axle assembly.



KHBF110C

# 

Be careful not to damage to the aluminum lower arm.

KHBF110A

4. Remove the speed sensor(C) from the knuckle.

# FRONT SUSPENSION SYSTEM

7. Remove the front strut assembly(B) bolt(C) from the fork(A).



8. Remove the strut upper mounting nuts(A).

#### DISASSEMBLY EBFDFBBD

1. Using the special tool (09546-26000), compress the coil spring(A).



KHRE111A

- 2. Remove the self-locking nut(C) from the strut assembly(B).
- 3. Remove the insulator, spring seat, coil spring and dust cover from the strut assembly.

#### INSPECTION E1E7425F

KHRE110E

- 1. Check the strut insulator for wear or damage.
- 2. Check rubber parts for damage or deterioration.
- 3. Compress and extend the piston rod(A) and check that there is no abnormal resistance or unusual sound during operation.



KHRE112A

# 021-62999292

#### SS -30

#### DISPOSAL EBA91F3B

- 1. Fully extend the piston rod.
- 2. Drill a hole on the A section to remove gas from the cylinder.



#### SUSPENSION SYSTEM

#### REASSEMBLY EB9A5E17

1. Compress coil spring using special tool (09546-26000).

Install compressed coil spring onto shock absorber.

#### **NOTE**

- a. There are two clolor marks on the coil spring. One corresponds to model option (see page SS-2), and the other corresponds to load classification. Ensure that the correct parts are being installed.
- b. Install the coil spring with the identification mark directed toward the knuckle.
- 2. After fully extending the piston rod, install the spring upper seat and insulator assembly.
- After seating the upper and lower ends of the coil spring(A) in the upper and lower spring seat grooves(B) correctly, tighten new self-locking nut temporarily.



KHRE112B

KHRE113A

- 4. Remove the special tool(09546-26000).
- 5. Tighten the self-locking nut to the specified torque.

Tightening torque Nm (kgf·m, lb-ft) : 20 ~ 25 (2.0 ~ 2.5, 14.5 ~ 18.1)



#### SS -31

#### FRONT SUSPENSION SYSTEM

#### INSTALLATION E2353C6C

1. Install the strut lower mounting bolts(A).

```
Tightening torque Nm (kgf·m, lb-ft) : 45 \sim 60 \ (4.5 \sim 6.0, \ 32.5 \sim 43.4)
```



KHRE110E

2. Install the fork(A) mounting bolt(C) to the strut assembly(B) with the I.D. mark facing outward.

**Tightening torque Nm (kgf·m, lb-ft) :** 60 ~ 80 (6.0 ~ 8.0, 43.4 ~ 57.8)



3. Install the fork(B) to the front lower arm(A) connecting bolt(C).

**Tightening torque Nm (kgf·m, lb-ft) :** 140 ~ 160 (14~16, 101.2~115.7)



KHBF110C

## 

Be careful not to damage to the aluminum lower arm.

4. Install the front stabilizer link nut(B) to the fork(A).

**Tightening torque Nm (kgf·m, lb-ft) :** 100 ~ 120 (10 ~ 12, 72.3 ~ 86.8)



KHBF110B

WWW.DIGITALKHODRO.COM

# 021-62999292

#### SS -32

#### SUSPENSION SYSTEM

5. Install the speed sensor bolt(A).



KHBF110F

- 6. Install the brake hose bracket to the fork and speed sensor cable mounting bolt(B) to the axle assembly.
- 7. Install the wheel and the tire(A) to the front hub(B).





KHBF101A

Be careful not to damage the hub bolts(C) when installing the front wheel and tire(A).

# FRONT SUSPENSION SYSTEM

# FRONT LOWER ARM

COMPONENTS E8DA8891



EHBF100C

# WWW.DIGITALKHODRO.COM

# 021-62999292

# SUSPENSION SYSTEM

#### SS -34

#### REMOVAL EDFA84B2

- Loosen the wheel nuts slightly. Raise the front of the vehicle, and make sure it is securely supported.
- 2. Remove the front wheel and tire(A) from front hub(B).



KHBF101A

# 

**Be careful not to damage the hub bolts(C) when** removing the front wheel and tire(A).

3. Remove the lower arm ball joint mounting bolts(A).



KHBF120A

4. Remove the front lower arm(B) connecting bolt(C) from the fork(A).



KHBF110C

# 

Be careful not to damage to the aluminium lower arm.

5. Remove the lower arm mounting bolts(A, B).



EHBF500A

#### INSPECTION E933436C

- 1. Check the bushing for wear and deterioration.
- 2. Check the lower arm for bending or breakage.
- 3. Check the ball joint dust cover for cracks.
- 4. Check all bolts.
- 5. Check the lower arm ball joint for rotating torque.
  - 1) If a crack is noted in the dust cover, replace the ball joint assembly.
  - 2) Move the ball joint stud several times in a circular motion.
  - 3) Measure the ball joint rotating torque.

# WWW.DIGITALKHODRO.COM

## FRONT SUSPENSION SYSTEM

#### Standard value :

0.4 ~ 2 Nm (4 ~ 20 kgf·cm, 0.29 ~ 1.45 lb-ft)

#### **NOTE**

Measure torque using the special tool(09532-11600) and torque wrench at the range of 0.5 - 2 rpm after moving the ball joint stud at degree 3° several times at room temperature.

- 4) If the rotating torque is below the lower limit of standard value, replace the ball joint assembly.
- 5) Even if the rotating toque is below the lower limit of the standard value, the ball joint may be reused unless it has drag and excessive play.

3. Using the special tools(09214-32000 & 09216-21100), install the busing on the lower arm.



KHRE123B

EHBF500C



13 ±0.5mm

#### REPLACEMENT EAE1BAD1

Using the special tools(09214-32000 & 09216-1. 211000), remove the bushing from the lower arm.



KHBF123A

- Apply soap solution to the following parts. 2.
  - Outer surface of the bushing.
  - Inner surface of the lower bushing mounting part.

# WWW.DIGITALKHODRO.COM

# 021-62999292

#### SS -36

#### **INSTALLATION** EF4DA19F

Install the lower arm mounting bolts(A, B). 1.

Tightening torque Nm (kgf·m, lb-ft) : 140 ~ 160 (14 ~ 16, 101.2 ~ 115.7)



- SUSPENSION SYSTEM
- 3. Install the lower arm ball joint mounting bolts(A).

```
Tightening torque Nm (kgf·m, lb-ft) :
100 ~ 120 (10 ~ 12, 72.3 ~ 86.8)
```



Install the wheel and the tire(A) to the front hub(B).

KHBF120A

- EHBF500A
- 2. Install the lower arm(B) connecting bolt(C) to the fork(A).



4.

# CAUTION

Be careful not to damage to the aluminium lower arm.
## FRONT UPPER ARM

#### COMPONENTS E4F2EAE6



7. Split pin

EHBF100D

## 021- 62 99 92 92

021-62999292

## WWW.DIGITALKHODRO.COM

3. Ball joint

4. Snap ring

SS -37

## 021-62999292

#### SS -38

#### REMOVAL E2CDA723

- Loosen the wheel nuts slightly. Raise the front of the vehicle, and make sure it is securely supported.
- 2. Remove the front wheel and tire(A) from front hub(B).



- SUSPENSION SYSTEM
- 4. Using the special tools(09568-4A000), disconnect the upper arm ball joint(B) from the knuckle(A).



KHBF130B

- 5. Remove the front strut assembly (Refer to SS-10).
- 6. Remove the two upper arm mounting bolts(A) from the body.

**Be careful not to damage the hub bolts(C) when** removing the front wheel and tire(A).

3. Remove the upper arm ball joint self-locking nut(A) and the split pin(B).



KHBF130A

KHBF101A



KHRE130C

#### INSPECTION E41AF84F

- 1. Check the bushing for wear and deterioration.
- 2. Check the upper arm for bending or breakage.
- 3. Check the ball joint for rotating torque.
  - 1) If there is a crack in the dust cover, replace it and add grease.
  - 2) Move the stabilizer link ball joint stud several times in a circular motion.

## FRONT SUSPENSION SYSTEM

3) Mount the self-locking nut on the ball joint, and then measure the ball joint rotating torque.

#### Standard value :

0.5 ~ 1.5 Nm (5 ~ 15 kgf·cm, 0.36 ~ 1.09 lb-ft)



#### EHRF132A

 If the rotating torque exceeds the upper limit of standard value, replace the upper arm assembly.

5) Even if the rotating toque is below the lower limit of the standard value, the ball joint may be reused unless it has drag and excessive play.

 Install the upper arm ball joint self-locking nut(A) and the split pin(B).

**Tightening torque Nm (kgf·m, lb-ft) :** 35 ~ 45 (3.5 ~ 4.5, 25.3 ~ 32.5)



KHBF130A

4. Install the wheel and the tire(A) to the front hub(B).

**Tightening torque Nm (kgf·m, lb-ft) :** 90 ~ 110 (9 ~ 11, 65.1 ~ 79.5)

#### INSTALLATION EBFBE35C

1. Install the two upper arm mounting bolts(A) to the body.

**Tightening torque Nm (kgf·m, lb-ft) :**  $55 \sim 65 (5.5 \sim 6.5, 39.8 \sim 47.0)$ 





KHBF101A

## 

Be careful not to damage the hub bolts(C) when installing the front wheel and tire(A).

KHRE130C

2. Install the front strut assembly (Refer to SS-12).

SUSPENSION SYSTEM

## FRONT STABILIZER BAR

#### COMPONENTS EFEDF04D



2. Front stabilizer link

Bushing
Bracket

EHBF100E

## FRONT SUSPENSION SYSTEM

#### REMOVAL EE28D0FF

B

- Loosen the wheel nuts slightly. Raise the front of the 1. vehicle, and make sure it is securely supported.
- Remove the front wheel and tire(A) from front hub(B). 2.
- After removing both sides of the tie rod end self-lock-4. ing nuts(A), remove the ball joint by using the special tool(09568-4A000).



n

Α

KHBF140G



KHBF110B

KHBF140D

#### 021-62999292

## WWW.DIGITALKHODRO.COM

## 021-62999292

#### SS -42

6. Remove both sides of the connecting bolts(A) between the lower arm and the fork.



SUSPENSION SYSTEM Remove the engine mounting bolts(A,B)

8.



KHBF301A

9. Remove the eight bolts and nuts of the sub frame by supporing it with a jack.

#### 

Be careful not to damage to the aluminium lower arm.

7. Remove the connecting bolt(A) between the steering universal joint assembly and the pinion assembly.





KHBF301C

10. After lowering the jack which supports the sub frame in a proper level, remove both sides of the stabilizer bar assembly mounting bolts(A).

KHBF140F

KHBF140E



KHBF140H

## 021- 62 99 92 92

## WWW.DIGITALKHODRO.COM

## FRONT SUSPENSION SYSTEM

11. Remove the stabilizer bar assembly through the gap between the body and the rear side of the sub frame.

## \land CAUTION

Be careful not to damage to the powersteering related tubes.

12. Remove the brackets(A) and the bushings(B).



#### INSPECTION EEC76BAA

- 1. Check the bushing for wear and deterioration.
- 2. Check the stabilizer bar for bending or breakage.
- 3. Check the ball joint for rotating torque.
  - 1) If there is a crack in the dust cover, replace it and add grease.
  - 2) Move the stabilizer link ball joint stud several times in a circular motion.
  - 3) Mount the self-locking nut on the ball joint, and then measure the ball joint rotating torque.

#### Standard value :

0.7 ~ 2 Nm (7 ~ 20 kgf·cm, 0.51 ~ 1.45 lb-ft)



Measure torque using the special tool(09532-11600) and torque wrench at the range of 0.5 - 2 rpm after moving the ball joint stud at degree 3 several times at room temperature.



KHBF140

EHRF142A

- 4) If the rotating torque exceeds the upper limit of standard value, replace the upper arm assembly.
- 5) Even if the rotating toque is below the lower limit of the standard value, the ball joint may be reused unless it has drag and excessive play.

## WWW.DIGITALKHODRO.COM

#### 021-62999292

SUSPENSION SYSTEM

After lifting the jack which supports the sub frame, install the eight bolts and nuts of the sub frame.

#### SS -44

#### INSTALLATION ED3F0B95

1. Install the bushing(B) on the stabilizer bar(A).



KHRE144A

5.

#### **NOTE**

Bring clamp(C) of stabilizer bar(A) into contact with bushing(B).

- 2. Install the bracket on the bushing(B).
- 3. After tightening the bolts of the bushing bracket temporarily, install the bushing bracket on the opposite side.
- 4. Install the stabilizer bar bracket mounting bolts(A) to the sub frame.

**Tightening torque Nm (kgf·m, lb-ft) :** 45 ~ 55 (4.5 ~ 5.5, 32.5 ~ 39.8)



**Tightening torque Nm (kgf⋅m, lb-ft) :** 140 ~ 160 (14 ~ 16, 101.2 ~ 115.7)

KHBF301C

6. Install the engine mounting bolts(A,B)

**Tightening torque Nm (kgf·m, lb-ft) :**  $50 \sim 65 (5 \sim 6.5, 36.2 \sim 47.0)$ 



KHBF301A

KHBF140H

## FRONT SUSPENSION SYSTEM

7. Install the connecting bolt(A) between the steering universal joint assembly and the pinion assembly.

**Tightening torque Nm (kgf·m, lb-ft) :** 15 ~ 20 (1.5 ~ 2.0, 10.8 ~ 14.5)



**Tightening torque Nm (kgf·m, lb-ft) :** 100 ~ 120 (10 ~ 12, 72.3 ~ 86.8)

Install both sides of the lower arm mounting bolts(A).



KHBF140D

KHBF140F

9.

 Install both sides of the connecting bolts(A) between the lower arm and the fork.

**Tightening torque Nm (kgf·m, lb-ft) :** 140 ~ 160 (14 ~ 16, 101.2 ~ 115.7) 10. Install both sides of the tie rod end self-locking nuts(A).

**Tightening torque Nm (kgf·m, lb-ft) :** 50 ~ 55 (5 ~ 5.5, 36.2 ~ 39.8)



KHBF140E

KHBF140G

Be careful not to damage to the aluminium lower arm.

## 021-62999292

#### SS -46

#### SUSPENSION SYSTEM

11. Install the stabilizer link(B) to the fork(A).

**Tightening torque Nm (kgf·m, lb-ft) :** 100 ~ 120 (10 ~ 12, 72.3 ~ 86.8)



KHRE110B

12. Install the wheel and the tire(A) to the front hub(B).





KHBF101A

Be careful not to damage the hub bolts(C) when installing the front wheel and tire(A).

REAR SUSPENSION SYSTEM

## REAR SUSPENSION SYSTEM

COMPONENTS EEFCF5CF



- 1. Rear shock absorber assembly
- 2. Rear cross member
- 3. Rear upper arm
- 4. Rear stabilizer bar assembly
- 5. Coil spring

- 6. Rear lower arm
- 7. Rear brake assembly
- 8. Rear knuckle
- 9. Trailing arm

EHBF200G

## WWW.DIGITALKHODRO.COM

## 021-62999292

SS -47

#### SS -48

SUSPENSION SYSTEM

## **REAR STRUT ASSEMBLY**

#### COMPONENTS E063D863



3. Dust cover

6. Upper pad

9. Rear lower arm

BHRF200A

#### WWW.DIGITALKHODRO.COM

SS -49

## **REAR SUSPENSION SYSTEM**

#### REMOVAL E976D9BC

- Loosen the wheel nuts slightly. Raise the rear of the vehicle, and make sure it is securely supported.
- 2. Remove the rear wheel and tire(A) from rear hub(B).



 Remove the rear shock absorber assembly nut(B) from the rear knuckle, then remove the shock absorber assembly(A).



KHBF210B

5. Disassembly the rubber bumper and the dust cover from the rear shock absorber.

#### INSPECTION E10EB2E3

- 1. Check the rubber parts for damage or deterioration.
- 2. Check the shock absorber for abnormal resistance or unusual sounds.



KHRE210A

KHBF201A



KHRE112A

CAUTION

Be careful not to damage the hub bolts(C) when removing the rear wheel and tire(A).

3. Remove the two rear shock absorber assembly mounting bolts(A).

## 021-62999292

SUSPENSION SYSTEM

#### SS -50

#### DISPOSAL EFABC1FD

- 1. Fully extend the shock absorber rod.
- 2. Drill a hole to remove gas from the cylinder.

## 

The gas coming out is harmless, but be careful of chips that may fly up when drilling. Be sure to use face shield and safety goggles.



3. Install the shock absorber assembly(A) nut(B) to the rear knuckle with the specified torque.

**Tightening torque Nm (kgf·m, lb-ft) :** 140 ~ 160 (14~16, 101.2~115.7)



KHBF210B

4. Install the wheel and the tire(A) to the rear hub(B).

**Tightening torque Nm (kgf-m, lb-ft) :** 90 ~ 110 (9 ~ 11, 65.1 ~ 79.5)

INSTALLATION EDF88DCF

- 1. Assembly the rubber bumper and the dust cover to the rear shock absorber, after pulling the rod of the rear shock absorber completely.
- 2. Install the two rear shock absorber mounting bolts(A).

Tightening torque Nm (kgf·m, lb-ft) :  $50 \sim 65 (5.0 \sim 6.5, 36.2 \sim 47.0)$ 





KHBF201A

## 

Be careful not to damage the hub bolts(C) when installing the rear wheel and tire(A).

KHRE210A

KHRE112B

## REAR SUSPENSION SYSTEM

## REAR UPPER ARM

COMPONENTS EADB2BA3



EHBF200B

R

## 021-62999292

SUSPENSION SYSTEM

#### SS -52

#### **REMOVAL** EE90DAFA

- 1. Loosen the wheel nuts slightly. Raise the rear of the vehicle, and make sure it is securely supported.
- 2. Remove the rear wheel and tire(A) from rear hub(B).
- 4. Remove the brake caliper mounting bolts(A), and then place the brake caliper assembly with wire as shown in the illustration.



KHBF220F



KHBF220A

R

#### **REAR SUSPENSION SYSTEM**

- 5. Remove the rear shock absorber mounting bolts(A) and the trailing arm(B) from the knuckle.
- 6. Remove the four rear muffler mounting rubbers(A,B) and the connecting bolts(C).



KHBF220B



KHBF220C

## 021- 62 99 92 92

#### SS -54

SUSPENSION SYSTEM

8. Remove the rear upper arm ball joint self-locking nut(A) and the split pin(B).



KHBF220D

9. Remove the rear upper arm ball joint(A) by using the special tool(09568-4A000).

#### INSPECTION E8B22EB7

- 1. Check the bushing for wear and deterioration.
- 2. Check the upper arm for bending or breakage.
- 3. Check the ball joint for rotating torque.
  - 1) If there is a crack in the dust cover, replace it and add grease.
  - 2) Move the stabilizer link ball joint stud several times in a circular motion.
  - 3) Mount the self-locking nut on the ball joint, and then measure the ball joint rotating torque.

#### Specified torque :

1 ~ 5 Nm (10 ~ 50 kgf·cm, 0.73 ~ 3.64 lb-ft)



Measure a torque by using the special tool(09532-11600) and torque wrench, at the range of 3 rpm at room temperature, 10 seconds after moving the ball joint stud 10 times



10. Remove the rear upper arm mounting bolts(A).



EHRF122A

- If the rotating torque exceeds the upper limit of standard value, replace the upper arm assembly.
- 5) Even if the rotating toque is below the lower limit of the standard value, the ball jointmay be reused unless it has drag and excessive play.

KHBF220I

WWW.DIGITALKHODRO.COM

## 021-62999292

## **REAR SUSPENSION SYSTEM**

#### INSTALLATION EDBED3A7

1. Install the rear upper arm mounting bolts(A).

**Tightening torque Nm (kgf·m, lb-ft) :** 100 ~ 120 (10 ~ 12, 72.3 ~ 86.8)







## WWW.DIGITALKHODRO.COM

#### 021-62999292

#### SS -56

5. Install the wheel speed sensor bolt(A) and the parking brake cable(B).

**Tightening torque Nm (kgf·m, lb-ft) :** 7 ~ 11 (0.7 ~ 1.1, 6.86 ~ 10.78)



KHBF220A

6. Install the brake caliper mounting bolts(A).

**Tightening torque Nm (kgf·m, lb-ft) :** 80 ~ 100 (8 ~ 10, 57.8 ~ 72.3)



KHBF220F

7. Install the four rear muffler mounting rubbers(A,B) and the connecting bolts(C).

**Tightening torque Nm (kgf·m, lb-ft) :**  $40 \sim 60 (4 \sim 6, 28.9 \sim 43.4)$ 

#### SUSPENSION SYSTEM





KHBF201A

#### 

Be careful not to damage the hub bolts(C) when installing the rear wheel and tire(A).

## WWW.DIGITALKHODRO.COM

## **REAR SUSPENSION SYSTEM**

## **REAR LOWER ARM**

#### COMPONENTS E4AB7E1D



EHBF200C

## 021-62999292

SUSPENSION SYSTEM

#### SS -58

#### REMOVAL E2DD05DD

- Loosen the wheel nuts slightly. Raise the rear of the vehicle, and make sure it is securely supported.
- 2. Remove the rear wheel and tire(A) from rear hub(B).



KHBF201A

## 

Be careful not to damage the hub bolts(C) when removing the rear wheel and tire(A).

3. Remove the lower arm bolt(B) from the rear knuckle, while supporting the lower arm(A) with a jack as shown in the illustration.



KHBF230D

5. Remove the lower arm mounting bolts(B) from the cross member(C).

#### INSPECTION EODOCFA8

#### REAR LOWER ARM

R

- 1. Check the bushing for wear and deterioration.
- 2. Check the center arm for bending or breakage.
- Check the bolts for damage.

#### SPRING

- 1. Check the spring for distortion, aging or damage.
- 2. Check the spring upper pad for aging or damage.



KHBF221F

 Remove the spring(A), the lower seat, and the upper pad.



## 021-62999292

SS -59

## **REAR SUSPENSION SYSTEM**

#### INSTALLATION EF155EE1

1. Install the lower arm(B) mounting bolts(C) to the cross member with a specified torque.

#### **Tightening torque Nm (kgf·m, lb-ft) :** 110 ~ 120 (11 ~ 12, 79.5 ~ 86.8)



4. Install the wheel and the tire(A) to the rear hub(B).

**Tightening torque Nm (kgf·m, lb-ft) :** 90 ~ 110 (9 ~ 11, 65.1 ~ 79.5)



KHBF201A

#### 

Be careful not to damage the hub bolts(C) when installing the rear wheel and tire(A).

- 2. Install the spring(A), the lower seat, and the upper pad.
- 3. Install the lower arm bolt(B) from the reark nuckle with a specified torque, while supporting the lower arm(A) with a jack as shown in the illustration.

**Tightening torque Nm (kgf·m, lb-ft) :** 140~160 (14 ~ 16, 101.2~115.7)



KHBF221F

KHBF230D

SUSPENSION SYSTEM

## REAR ASSIST ARM

COMPONENTS EDFFE8FE



EHBF200D

## **REAR SUSPENSION SYSTEM**

#### REMOVAL E1222C4D

- Loosen the wheel nuts slightly. Raise the rear of the vehicle, and make sure it is securely supported.
- 2. Remove the rear wheel and tire(A) from rear hub(B).



KHBF201A

#### CAUTION

**Be careful not to damage the hub bolts(C) when** removing the rear wheel and tire(A).

3. Remove the assist arm mounting bolt(A) from the rear knuckle.

#### in) ۱: امانه دیجیتال تعمیرکاران خودرو در ایران



KHBF240A

4. Remove the assist arm mounting bolt(B) from the cross member.

#### INSTALLATION E665161F

1. Install the assist arm mounting bolt(A) to the cross member.

#### **Tightening torque Nm (kgf·m, lb-ft) :** 110 ~ 120 (11 ~ 12, 79.5 ~ 86.8)



KHBF240A

- 2. Install the assist arm mounting bolt(B) from the rear knuckle.
- **Tightening torque Nm (kgf·m, lb-ft) :** 140~160 (14~16, 101.2~115.7)
- 3. Install the wheel and the tire(A) to the rear hub(B).

**Tightening torque Nm (kgf·m, lb-ft) :** 90 ~ 110 (9 ~ 11, 65.1 ~ 79.5)



KHBF201A

#### 

Be careful not to damage the hub bolts(C) when installing the rear wheel and tire(A).

## WWW.DIGITALKHODRO.COM

SUSPENSION SYSTEM

## TRAILING ARM

#### COMPONENTS E5824F6C



3. Assist arm

EHBF200E

## WWW.DIGITALKHODRO.COM

## **REAR SUSPENSION SYSTEM**

#### REMOVAL EFCC8733

1. Remove the trailing arm mounting nut(A) from the rear knuckle.



REPLACEMENT EAA9DE3F

#### TRAILING ARM BUSHING

1. Using the special tools(09216-21600, 09552-38100), press-fit the bushing.



EHRF252A



NOTE After removing the head lamp leveling link(A), remove the right trailing arm.

- 2. Remove the bushing from the trailing arm(A).
- 3. Using the special tool(09552-38000), replace the bushing.

Pull out force :over 100 kN (1000 kgf, 2204 lb)

## 

Be sure to press the bushing with the jut of the bushing aligned to the longitude of the trailing arm.

EHBF250B

- 2. Remove the trailing arm mounting nut(B) from the body.
- 3. Remove the trailing arm(C).

#### INSPECTION E951BFD3

- 1. Check the bushing for wear and deterioration.
- 2. Check the trailing arm for bending or breakage.
- 3. Check all the bolts for damage.

## 021-62999292

SS -63

## 021-62999292

#### SS -64

#### INSTALLATION E19530D8

1. Place the trailing arm(D) as shown below.



KHBF250A

2. Install the trailing arm nuts.



**Tightening torque Nm (kgf·m, lb-ft) :** 140~160 (14~16, 101.2~115.7)

#### 🚺 ΝΟΤΕ

After installing the right trailing arm, install the head lamp leveling link(A).



EHBF250B



## WWW.DIGITALKHODRO.COM

## 021-62999292

#### SUSPENSION SYSTEM

#### **REAR SUSPENSION SYSTEM**

## REAR STABILIZER BAR

#### COMPONENTS EC34B3E0



EHBF200F

021-62999292

#### SS -66

#### REMOVAL E1DD240C

- Loosen the wheel nuts slightly. Raise the rear of the vehicle, and make sure it is securely supported.
- 2. Remove the rear wheel and tire(A) from rear hub(B).



#### SUSPENSION SYSTEM

#### INSPECTION EAB1746A

- 1. Check the bushing for wear and deterioration.
- 2. Check the stabilizer bar for bending or breakage.
- 3. Check the ball joint for rotating torque.
  - 1) If there is a crack in the dust cover, replace it and add grease.
  - 2) Shake the stabilizer link ball joint stud several times.
  - 3) Mount the self-locking nut on the ball joint, and then measure the ball joint rotating torque.

#### Specified torque :

0.7 ~ 2 Nm (7 ~ 20 kgf·m, 0.51 ~ 1.45 lb-ft)

🚺 NOTE

KHBF201A

#### Measure torque using the special tool(09532-11600) and torque wrench at the range of 0.5 - 2 rpm after moving the ball joint stud at degree 3° several times at room temperature.

## 

**Be careful not to damage the hub bolts(C) when** removing the rear wheel and tire(A).

- 3. Remove the left/right nuts(A) of the rear stabilizer links.
- 4. Remove the left/right mounting nuts(B) of the rear stabilizer bar brackets.



KHRE260A

5. Remove the rear stabilizer bar(C).

KHRE262A

- If the rotating torque exceeds the upper limit of standard value, replace the upper arm assembly.
- 5) Even if the rotating toque is below the lower limit of the standard value, the ball joint may be reused unless it has drag and excessive play.

## WWW.DIGITALKHODRO.COM

## 021- 62 99 92 92

## 021-62999292

#### **REAR SUSPENSION SYSTEM**

#### INSTALLATION E8987A53

1. Install the bushing(B) on the stabilizer bar(A).



KHRE144A

#### 🛈 ΝΟΤΕ

Bring clamp(C) of stabilizer bar(A) into contact with bushing(B).

- 2. One side bracket should be temporarily tightened, and then install the bushing on the opposite side.
- 3. Install the stabilizer bracket bolt(B).

#### **Tightening torque Nm (kgf·m, lb-ft) :** 45 ~ 55 (4.5 ~ 5.5, 32.5 ~ 39.8)



Be careful not to damage the hub bolts(C) when installing the rear wheel and tire(A).

KHRE260A

SS -67

4. Install the stabilizer link mounting nut(A).

Tightening torque Nm (kgf·m, lb-ft) :  $35 \sim 45 (3.5 \sim 4.5, 25.3 \sim 32.5)$ 

- 5. Repeat step 3 and 4 for the other side.
- 6. Install the wheel and the tire(A) to the rear hub(B).

**Tightening torque Nm (kgf·m, lb-ft) :** 90 ~ 110 (9 ~ 11, 65.1 ~ 79.5)



SUSPENSION SYSTEM

SS -68

## TIRES / WHEELS

## WHEEL

#### WHEEL ALIGNMENT EAFC7A2F

When using commercially available computerized four wheel alignment equipment (caster, camber, toe) to inspect the front wheel alignment, always position the car on a level surface with the front wheels facing straight ahead.

Prior to inspection, make sure that the front suspension and steering system are in normal operating condition and that the wheels and tires face straight ahead and the tires are inflated to the specified pressure.

#### TOE

Toe is a measurement of how much the front of the wheels are turned in or out from the straight-ahead position.

change is adjusted by turning the tie rods for the right and left heels simultaneously at the same amount as follows.

#### Standard value :

Toe-in (B-A) mm (in) :  $0 \pm 2 (0 \pm 0.0787)$ 

#### 🕡 ΝΟΤΕ

- Toe-in adjustment should be made by turning the right and left tie rods at the same amount.
- When adjusting toe-in, loosen the outer bellows clip to prevent twisting the bellows.
- After the adjustment, tighten the tie rod end lock nuts firmly and reinstall the bellows clip.
- Adjust each toe-in to be the range of ±1mm.

Tie rod(A) Specified torque Nm (kgf·m, lb-ft) : 50~55 (5~5.5, 36.2~39.8)



EHRF400A

Item	Description
A - B < 0	Positive (+) toe (toe in)
A - B > 0	Negative (-) toe (toe out)

When the wheels are turned in toward the front of the vehicle, toe is positive (+) (toe in). When the wheels are turned out toward the front of the vehicle, toe is negative(-) (toe out). Toe is measured in degrees, from side to side, and totaled.

#### [FRONT]

Toe-in(B-A or angle a+b) is adjusted by turning the tie rod turnbuckles. Toe-in on the left front wheel can be reduced by turning the tie rod toward the rear of the car. Toe- in

#### [REAR]

**Standard value :** Toe-in (B-A) mm (in) : 2 ± 2 (0.0787 ± 0.0787)

Adjust the toe-in by turning the cambolt of the assist arm.

Left cambolt : Clockwise  $\rightarrow$  toe-in Right cambolt : Clockwise  $\rightarrow$  toe-out The variation of toe by a rotation of the cambolt : About 4.1 mm (0.4°)

## A CAUTION

Each toe should be within 1±1 mm (0.039 ± 0.039 in).
If the difference between right and left is not within +2mm (0.079 in), repeat adjustment.

## WWW.DIGITALKHODRO.COM

## TIRES / WHEELS

EHRF401B

• After adjusting the cambolt, tighten the nut to the specified torque.



EHRF401A

**NOTE** 

Standard value : -0°30' ± 30'

[REAR]

Cambei

#### Specified torque

110 ~ 120 Nm (11 ~ 12 kgf·m, 79.5 ~ 86.8 lb-ft)

#### CAMBER

#### [FRONT]

top.

Camber is the inward or outward tilting of the wheels at the



Adjust the camber by turning the cambolt of the rear lower arm.

Camber is pre-set at the factory and doesn't need to be adjusted. If the camber is not within the standard

value, replace the bent or damaged parts.

Difference between right and left angle is within  $0^{\circ} 30'$ 

Left cambolt : Clockwise  $\rightarrow$  camber(+) Right cambolt : Clockwise  $\rightarrow$ camber(-) The variation of camber by a rotation of the cambolt : About 0.2°

KHBF400C

Item	Description
A	Positive camber angle
В	True vertical

When the wheel tilts out at the top, then the camber is positive (+).

When the wheel tilts in at the top, then the camber is negative(-).

Standard value :  $0^{\circ} \pm 30^{\prime}$ Difference between right and left angle is within  $0^{\circ} 30^{\prime}$ 

## WWW.DIGITALKHODRO.COM

## 021-62999292

SUSPENSION SYSTEM

EA4AFE76

Jack up the vehicle and support it with jack stands.

Measure the wheel runout with a dial indicator as il-

Replace the wheel if the wheel runout exceeds the

#### SS -70

#### CASTER

Caster is the tilting of the strut axis either forward or backward from vertical. A backward tilt is positive (+) and a forward tilt is negative (-).

Caster is pre-set at the factory and doesn't need to be adjusted. If the caster is not within the standard value, replace the bent or damaged parts.



WHEEL RUNOUT

lustrated.

1.

2.

3.

KHRE402A

#### WHEEL NUT TIGHTENING EGGBFCFF

1. Tightening torque.

**Tightening torque Nm (kgf·m, lb-ft) :** 90 ~ 110 (9 ~ 11, 65.1 ~ 79.5)

## 

When using an impact gun, final tightening torque should be checked using a torque wrench.

2. Tightening order. Check the torque again after tightening the wheel nuts diagonally.







KHRE403B



## 021-62999292

SUSPENSION SYSTEM

#### SS -72

## TIRE

#### TIRE WEAR EB9DC487

1. Measure the tread depth of the tires.

Tread depth [limit] : 1.6 mm (0.063 in)

2. If the remaining tread(A) depth is less than the limit, replace the tire.

## **NOTE**

When the tread depth of the tires is less than 1.6 mm (0.063 in), the wear indicators(B) will appear.

# Rotate the tires in the pattern illustrated.

E18EB20E



TIRE ROTATION



KHRE405A

#### CHECKING FOR PULL AND WANDER

If the steering pulls to one side, rotate the tires according to the following wheel rotation procedure.

1. Rotate the front right and front left tires, and perform a road test in order to confirm vehicle stability.



B

EHRF405B

2. If the steering pulls to the opposite side, rotate the front and rear tires, and perform a road test again.

#### TIRES / WHEELS



EHRF405C

3. If the steering continues to pull to one side, rotate the front right and left tires again, and perform a road test.



EHRF405B

4. If the steering continues to pull to the opposite side, replace the front wheels with new ones.



EHRF405E