

# Heating, Ventilation and Air Conditioning

## GENERAL

### AIR CONDITIONING SYSTEM

COMPRESSOR OIL

### A/C COMPRESSOR CONTROLS (MANUAL)

AIR CONDITIONING COMPRESSOR  
CONDENSER  
A/C PRESSURE TRANSDUCER  
REFRIGERANT LINE

### HEATER

EVAPORATOR TEMPERATURE SENSOR  
HEATER UNIT  
PTC (POSITIVE TEMPERATURE COEFFICIENT)  
HEATER  
TEMPERATURE CONTROL ACTUATOR  
MODE CONTROL ACTUATOR

### A/C COMPRESSOR CONTROLS (FULL AUTO)

IN CAR SENSOR  
PHOTO SENSOR  
WATER TEMPERATURE SENSOR  
AMBIENT TEMPERATURE SENSOR  
A.Q.S (AIR QUALITY SENSOR)  
HUMIDITY SENSOR

### BLOWER CONTROLS

BLOWER UNIT  
BLOWER MOTOR  
BLOWER RELAY  
POWER MOSFET  
BLOWER RESISTOR  
A/C AIR FILTER  
INTAKE ACTUATOR

### BLOWER AND A/C CONTROLS (MANUAL)

CONTROL PANEL

### BLOWER AND A/C CONTROLS (AUTO- MATIC)

CONTROL PANEL

# دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



## GENERAL

HA -3

## GENERAL

## SPECIFICATION E56BFBD4

## AIR CONDITIONER

Item		Specification			
		$\mu$ 2.7	$\lambda$ 3.3	$\lambda$ 3.8	D 2.2
Compressor	Type	VS			
	Oil type & Capacity	FD 46XG (PAG), 150 ± 10cc			
	Pulley type	6PK-TYPE			
	Displacement	180cc/rev			
Condenser	Heat rejection	13,800 ± 5% kcal/hr			
(A/C pressure transducer)	The method to measure the pressure	Voltage = 0.00878835 * Pressure + 0.5[kgf/cm <sup>2</sup> ]			
Expansion valve	Type	Block			
Refrigerant	Type	R-134a			
	Capacity [oz.(g)]	500 ± 25			

## BLOWER UNIT

Item		Specification
Fresh and recirculation	Operating method	Actuator
Blower	Type	Sirocco
	Speed step	Auto + 8 speed (Automatic), 4 speed (Manual)
	Speed control	Power mosfet (Automatic), Blower resistor (Manual)
Air filter	Type	Particle filter

## HEATER AND EVAPORATOR UNIT

Item		Specification
Heater	Type	Pin & Tube type
	Heating capacity	4,600 ± 5% kcal/hr
	PTC heater capacity	1000W + 5%/-10%
	Mode operating method	Actuator
	Temperature operating method	Actuator
Evaporator	Temperature control type	Evaporator temperature sensor
	A/C ON/OFF [°C (°F)]	ON : 2.1 ± 0.5 (35.8 ± 32.9), OFF: 0.6 ± 0.5 (33.1 ± 32.9)

## HA -4

## HEATING, VENTILATION AND AIR CONDITIONING

TROUBLESHOOTING EDABEDD2

## PROBLEM SYMPTOMS TABLE

Before replacing or repairing air conditioning components, first determine if the malfunction is due to the refrigerant charge, air flow or compressor.

Use the table below to help you find the cause of the problem. The numbers indicate the priority of the likely cause of the problem. Check each part in order. If necessary, replace these parts.

After correcting the malfunction, check the complete system to ensure that performance is satisfactory.

## STANDARD:

Symptom	Suspect Area	See page
No blower operation	1. Blower fuse	-
	2. Blower relay	HA - 62
	3. Blower motor	HA - 71, 59
	4. Power mosfet & Blower resistor	HA - 64, 67
	5. Blower speed control switch	HA - 72, 77
	6. Wire harness	-
No air temperature control	1. Engine coolant capacity	-
	2. Heater control assembly	HA - 72, 77
No compressor operation	1. Refrigerant capacity	HA - 3
	2. A/C Fuse	-
	3. Magnetic clutch	HA - 17
	4. Compressor	HA - 16
	5. A/C pressure transducer	HA - 23
	6. A/C switch	-
	7. Evaporator temperature sensor	HA - 27
	8. Wire harness	-
No cool comes out	1. Refrigerant capacity	HA - 3
	2. Refrigerant pressure	HA - 3
	3. Drive belt	-
	4. Magnetic clutch	HA - 17
	5. Compressor	HA - 16
	6. A/C pressure transducer	HA - 23
	7. Evaporator temperature sensor	HA - 27
	8. A/C switch	-
	9. Heater control assembly	HA - 72, 77
	10. Wire harness	-

## GENERAL

HA -5


Symptom	Suspect Area	See page
Insufficient cooling	1. Refrigerant capacity	HA - 3
	2. Drive belt	-
	3. Magnetic clutch	HA - 17
	4. Compressor	HA - 16
	5. Condenser	HA - 20
	6. Expansion valve	HA - 33
	7. Evaporator	HA - 27
	8. Refrigerant lines	HA - 25
	9. A/C pressure transducer	HA - 23
	10. Heater control assembly	HA - 72, 77
No engine idle-up when A/C switch ON	1. Engine ECM	-
	2. Wire harness	-
No air inlet control	Heater control assembly	HA - 72, 77
No mode control	1. Heater control assembly	HA - 72, 77
No cooling fan operation	1. Cooling fan fuse	-
	2. Fan motor, PWM	Refer to the group "EM"
	3. Engine ECM	-
	4. Wire harness	-

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

HA -6

HEATING, VENTILATION AND AIR CONDITIONING

## SPECIAL TOOLS EA6EE9BB

Tool (Number and name)	Illustration	Use
09977-29000 Disc & hub assembly bolt remover	 <p style="text-align: right;">EQA9002A</p>	Removal and installation of disc & hub assembly

# دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



## AIR CONDITIONING SYSTEM

HA -7


## AIR CONDITIONING SYSTEM

## INSTRUCTIONS E2DCD3CC

## WHEN HANDLING REFRIGERANT

1. R-134a liquid refrigerant is highly volatile. A drop on the skin of your hand could result in localized frostbite. When handling the refrigerant, be sure to wear gloves.
2. It is standard practice to wear goggles or glasses to protect your eyes, and gloves to protect your hands. If the refrigerant splashes into your eyes, wash them with clean water immediately.
3. The R-134a container is highly pressurized. Never leave it in a hot place, and check that the storage temperature is below 52°C (126°F)
4. An electronic leak detector should be used to check the system for refrigerant leakage. Bear in mind that the R-134a, upon coming into contact with flame, produces phosgene, a highly toxic gas.
5. Use only recommended the lubricant for R-134a systems. If lubricants other than the recommended one used, system failure may occur.
6. PAG lubricant absorbs moisture from the atmosphere at a rapid rate, therefore the following precautions must be observed:
  - When removing refrigerant components from a vehicle, cap immediately the components to prevent from the entry of moisture.
  - When installing refrigerant components to a vehicle, do not remove the cap until just before connecting the components.
  - Complete the connection of all refrigerant tubes and hoses without delay to prevent the A/C system from taking on moisture.
  - Use the recommended lubricant from a sealed container only.


7. If an accidental discharge in the system occurs, ventilate the work area before resuming service.



LQAC003A

## WHEN REPLACING PARTS ON A/C SYSTEM

1. Never open or loosen a connection before discharging the system.
2. Seal the open fittings of components with a cap or plug immediately to prevent intrusion of moisture or dust.
3. Do not remove the sealing caps from a replacement component until it is ready to be installed.
4. Before connecting an open fitting, always install a new sealing ring. Coat the fitting and seal with refrigerant oil before making the connection.



LQAC003B


HA -8

HEATING, VENTILATION AND AIR CONDITIONING

WHEN INSTALLING CONNECTING PARTS

FLANGE WITH GUIDE PIN

Check the new O-ring for damage (use only the specified) and lubricate it using compressor oil. Tighten the nut to specified torque.



LQAC003C

Size	Tightening torque [ N·m (kg·m, lbf·ft) ]	
	General bolt, nut	
	4T	7T
M6	5 - 6 (0.5 - 0.6, 3.6 - 4.3)	9 - 11 (0.9 - 1.1, 6.5 - 7.9)
M8	12 - 14 (1.2 - 1.4, 8.7 - 10)	20 - 26 (2.0 - 2.6, 14 - 18)
M10	25 - 28 (2.5 - 2.8, 18 - 20)	45 - 55 (4.5 - 5.5, 32 - 39)
Size	Flange bolt, nut	
	4T	7T
M6	5 - 7 (0.5 - 0.7, 3.6 - 5.0)	8 - 12 (0.8 - 1.2, 5.8 - 8.6)
M8	10 - 15 (1.0 - 1.5, 7 - 10)	19 - 28 (1.9 - 2.8, 14 - 20)
M10	21 - 31 (2.1 - 3.1, 15 - 22)	39 - 60 (3.9 - 6.0, 28 - 43)

**NOTE**

T means tensile intensity, which is stamped on the head of bolt only numeral.

HANDLING TUBING AND FITTINGS

The internal parts of the refrigeration system will remain in a state of chemical stability as long as pure moisture-free refrigerant and refrigerant oil are used. Abnormal amounts of dirt, moisture or air can upset the chemical stability and cause problems or serious damage.


THE FOLLOWING PRECAUTIONS MUST BE OBSERVED

1. When it is necessary to open the refrigeration system, have everything you will need to service the system ready so the system will not be left open any longer than necessary.
2. Cap or plug all lines and fittings as soon as they are opened to prevent the entrance of dirt and moisture.
3. All lines and components in parts stock should be capped or sealed until they are ready to be used.
4. Never attempt to rebind formed lines to fit. Use the correct line for the installation you are servicing.
5. All tools, including the refrigerant dispensing manifold, the gauge set manifold and test hoses, should be kept clean and dry.

AIR CONDITIONING SYSTEM

HA -9

REFRIGERATION CYCLE EFAA4DA1



EQR004A

HA -10

HEATING, VENTILATION AND AIR CONDITIONING

REFRIGERANT SYSTEM SERVICE

BASICS EEA620BA

REFRIGERANT RECOVERY

Use only service equipment that is U.L.-listed and is certified to meet the requirements of SAE J2210 to remove HFC-134a(R-134a) from the air conditioning system.


**⊗ WARNING**

- Air conditioning refrigerant or lubricant vapor can irritate your eyes, nose, or throat.
- Be careful when connecting service equipment.
- Do not breathe refrigerant or vapor.


If accidental system discharge occurs, ventilate work area before resuming service.

Additional health and safety information may be obtained from the refrigerant and lubricant manufacturers.

1. Connect an R-134a refrigerant Recovery/Recycling/Charging System (A) to the high-pressure service port (B) and the low-pressure service port (C) as shown, following the equipment manufacturer's instructions.



EQBF011A



EQKE004A

2. Measure the amount of refrigerant oil removed from the A/C system after the recovery process is completed. Be sure to install the same amount of new refrigerant oil back into the A/C system before charging.

SYSTEM EVACUATION

Use only service equipment that is U.L.-listed and is certified to meet the requirements of SAE J2210 to remove HFC-134a(R-134a) from the air conditioning system.

**⚠ CAUTION**


- Air conditioning refrigerant or lubricant vapor can irritate your eyes, nose, or throat.
- Be careful when connecting service equipment.
- Do not breathe refrigerant or vapor.

If accidental system discharge occurs, ventilate work area before resuming service.

Additional health and safety information may be obtained from the refrigerant and lubricant manufacturers.

1. When an A/C System has been opened to the atmosphere, such as during installation or repair, it must be evacuated using an R-134a refrigerant Recovery/Recycling/Charging System. (If the system has been open for several days, the receiver/dryer should be replaced, and the system should be evacuated for several hours.)

2. Connect an R-134a refrigerant Recovery/Recycling/Charging System (A) to the high-pressure service port (B) and the low-pressure service port (C) as shown, following the equipment manufacturer's instructions.



EQKE004A

3. If the low-pressure does not reach more than 93.3 kPa (700 mmHg, 27.6 in.Hg) in 10 minutes, there is probably a leak in the system. Partially charge the system, and check for leaks (see Leak Test.).

## AIR CONDITIONING SYSTEM

HA -11

- Remove the low pressure valve from the low-pressure service port.

### SYSTEM CHARGING

Use only service equipment that is U.L.-listed and is certified to meet the requirements of SAE J2210 to remove HFC-134a(R-134a) from the air conditioning system.


#### CAUTION

- **Air conditioning refrigerant or lubricant vapor can irritate your eyes, nose, or throat.**
- **Be careful when connecting service equipment.**
- **Do not breathe refrigerant or vapor.**

If accidental system discharge occurs, ventilate work area before resuming service.

Additional health and safety information may be obtained from the refrigerant and lubricant manufacturers.

- Connect an R-134a refrigerant Recovery/Recycling/Charging System (A) to the high-pressure service port (B) as shown, following the equipment manufacturer's instructions.



EQKE004A

- Add the same amount of new refrigerant oil to system that was removed during recovery. Use only specified refrigerant oil. Charge the system with  $18.0 \pm 0.88$  oz. ( $510 \pm 25$ g) of R-134a refrigerant. Do not overcharge the system the compressor will be damaged.

### REFRIGERANT LEAK TEST


Always conduct a leak test with an electronic leak detector whenever leakage or refrigerant is suspected and when conducting service operations which are accompanied by disassembly or loosening or connection fittings.

#### NOTE

In order to use the leak detector properly, read the manual supplied by the manufacturer.

If a gas leak is detected, proceed as follows:

- Check the torque on the connection fittings and, if too loose, tighten to the proper torque. Check for gas leakage with a leak detector (A).
- If leakage continues even after the fitting has been tightened, discharge the refrigerant from the system, disconnect the fittings, and check their seating faces for damage. Always replace, even if the damage is slight.
- Check the compressor oil and add oil if required.
- Charge the system and recheck for gas leaks. If no leaks are found, evacuate and charge the system again.




EQKE007A

HA -12

HEATING, VENTILATION AND AIR CONDITIONING

COMPONENT LOCATION INDEX EC736D51


ENGINE ROOM



EQBF001A

AIR CONDITIONING SYSTEM

INTERIOR



EQBF001B

## HA -14

## HEATING, VENTILATION AND AIR CONDITIONING

## COMPRESSOR OIL

OIL SPECIFICATION E83D0838

1. The HFC-134a system requires synthetic (PAG) compressor oil whereas the R-12 system requires mineral compressor oil. The two oils must never be mixed.
2. Compressor (PAG) oil varies according to compressor model. Be sure to use oil specified for the model of compressor.

## HANDLING OF OIL

1. The oil should be free from moisture, dust, metal powder, etc.
2. Do not mix with other oil.
3. The water content in the oil increases when exposed to the air. After use, seal oil from air immediately. (HFC-134a Compressor Oil absorbs moisture very easily.)
4. The compressor oil must be stored in steel containers, not in plastic containers.

## COMPRESSOR OIL CHECK

The oil used to lubricate the compressor is circulating with the refrigerant. Whenever replacing any component of the system or a large amount of gas leakage occurs, add oil to maintain the original amount of oil.

---

Oil total volume in system:  
120 ± 10cc (4.05 ± 0.34 fl.oz)

---

## OIL RETURN OPERATION

There is close affinity between the oil and the refrigerant. During normal operation, part of the oil recirculates with the refrigerant in the system. When checking the amount of oil in the system, or replacing any component of the system, the compressor must be run in advance for oil return operation. The procedure is as follows:

1. Open all the doors and the engine hood.
2. Start the engine and air conditioning switch to "ON" and set the blower motor control knob at its highest position.
3. Run the compressor for more than 20 minutes between 800 and 1,000 rpm in order to operate the system.
4. Stop the engine.

## REPLACEMENT OF COMPONENT PARTS

When replacing the system component parts, supply the following amount of oil to the component parts to be installed.

Component parts to be installed	Amount of Oil
Evaporator	50 cc (1.70 fl.oz)
Condenser	30 cc (1.02 fl.oz)
Receiver/dryer	30 cc (1.02 fl.oz)
Refrigerant line (One piece)	10 cc (0.34 fl.oz)

For compressor replacement, subtract the volume of oil drained from the removed compressor from the specified volume, and drain the calculated volume of oil from the new compressor:

The specified volume - volume of removed compressor = volume to drain from the new compressor.


 **NOTE**

*Even if no oil is drained from the removed compressor, don't drain more than 50cc from new compressor.*

# A/C COMPRESSOR CONTROLS (MANUAL)

## AIR CONDITIONING COMPRESSOR

### COMPONENT LOCATION E12E246B




EQBF105A

HA -16

HEATING, VENTILATION AND AIR CONDITIONING

COMPONENTS



- 1. Bolt
- 2. Disc & hub assembly
- 3. Shim (Gap washer)
- 4. Retainer ring (Pulley)
- 5. Pulley

- 6. Retainer ring (Field coil)
- 7. Field coil
- 8. Screw
- 9. Connector bracket
- 10. Compressor assembly


EQBF105B

**A/C COMPRESSOR CONTROLS (MANUAL)**


**HA -17**

**REMOVAL** EAE581F2

1. If the compressor is marginally operable, run the engine at idle speed, and let the air conditioning work for a few minutes, then shut the engine off.
2. Disconnect the negative cable from the battery.
3. Recover the refrigerant with a recovery/charging station (Refer to HA-8).
4. Loosen the drive belt (Refer to HA-14).
5. Remove the bolts, then disconnect the suction line (A) and discharge line (B) from the compressor. Plug (C) or cap the lines immediately after disconnecting them to avoid moisture and dust contamination.




6. Disconnect the compressor clutch connector (A), and then remove 4 mounting bolts and the compressor.



**INSTALLATION** E30FCA6C

1. Make sure of the length of compressor mounting bolts, and then tighten it A→B→C→D order.

Bolt	D Engine	β Engine
A	126 mm (4.96in.)	94 mm (3.70in.)
B	126 mm (4.96in.)	108 mm (4.25in.)
C	94 mm (3.70in.)	94 mm (3.70in.)
D	94 mm (3.70in.)	94 mm (3.70in.)



**TIGHTENING TORQUE: 2.04 ~ 3.36 kgf·m**


2. Install in the reverse order of removal, and note these items.
  - If you're installing a new compressor, drain all the refrigerant oil from the removed compressor, and measure its volume, Subtract the volume of drained oil from 120cc(4.20 oz.) the result is the amount of oil you should drain from the new compressor (through the suction fitting).
  - Replace the O-rings with new ones at each fitting, and apply a thin coat of refrigerant oil before installing them. Be sure to use the right O-rings for R-134a to avoid leakage.
  - To avoid contamination, do not return the oil to the container once dispensed, and never mix it with other refrigerant oils.
  - Immediately after using the oil, replace the cap on the container and seal it to avoid moisture absorption.
  - Do not spill the refrigerant oil on the vehicle; it may damage the paint; if the refrigerant oil contacts the paint, wash it off immediately.
  - Adjust the drive belt (Refer to HA-14)
  - Charge the system and test its performance. (Refer to HA-9)

HA -18


HEATING, VENTILATION AND AIR CONDITIONING

INSPECTION E7DFDCFB

1. Check the plated parts of the disc & hub assembly (A) for color changes, peeling or other damage. If there is damage, replace the clutch set.
2. Check the pulley (B) bearing play and drag by rotating the pulley by hand. Replace the clutch set with a new one if it is noisy or has excessive play/drag.



4. Check operation of the magnetic clutch. Connect the compressor side terminals to the battery (+) terminal and the ground battery (-) terminal to the compressor body. Check the magnetic clutch operating noise to determine the condition.



EQBF105H


3. Measure the clearance between the pulley (B) and the disc & hub assembly (A) all the way around. If the clearance is not within specified limits, remove the disc & hub assembly and add or remove shim (gap washer) as needed to increase or decrease clearance.

AQJF106A

Clearance:  $0.5 \pm 0.15\text{mm}$

**NOTE**

The shims (gap washers) are available in seven thicknesses: 0.7mm, 0.8mm, 0.9mm, 1.0mm, 1.1mm, 1.2mm and 1.3mm.



KQBF105G


**A/C COMPRESSOR CONTROLS (MANUAL)**

**HA -19**

**DISASSEMBLY** EB6F1F50


1. Remove the center bolt (A) while holding the disc & hub assembly with a commercially available disc & hub assembly bolt remover; Special tool number 09977-29000.

**TORQUE: 10~15N·m (1.02~1.53kgf·m, 7.37~11lb·ft)**




KQBF105I

2. Remove the disc & hub assembly (A) and shim (gap washer) (B), taking care not to lose the shims. If the clutch needs adjustment, increase or decrease the number and thickness of shims as necessary, then reinstall the disc & hub assembly, and recheck its clearance (Refer to HA-19).




KQRE105J

3. If you removal the field coil, remove retainer ring (A) with retainer ring pliers.



EQKE103C

4. Remove the screw (A) from the field coil ground terminal. Remove the retainer ring (B) and then remove the field coil (C) from the shaft with a puller. Be careful not to damage the coil and compressor.



KQBF105L


5. Reassemble the compressor clutch in the reverse order of disassembly, and note these items :
  - Clean the pulley and compressor sliding surfaces with non-petroleum solvent.
  - Install new retainer rings, and make sure they are fully seated in the groove.
  - Make sure that the pulley turns smoothly after its reassembled.

HA -20

HEATING, VENTILATION AND AIR CONDITIONING

## CONDENSER

COMPONENT LOCATION E8FE03EB




EQBF108A

**A/C COMPRESSOR CONTROLS (MANUAL)****HA -21****INSPECTION** EC5ADDA3

1. Check the condenser fins for clogging and damage. If clogged, clean them with water, and blow them with compressed air. If bent, gently bend them using a screwdriver or pliers.
2. Check the condenser connections for leakage, and repair or replace it, if required.

**REPLACEMENT** EE626AAA**CONDENSER ASSEMBLY**

1. Recover the refrigerant with a recovery/ recycling/ charging station (Refer to HA-10).
2. Disconnect the negative (-) battery terminal.
3. Remove the air duct (A) after loosening fastener.
4. Remove the radiator bracket (B) after loosening the bolts.




KQBF108B

5. Remove the nuts, then disconnect the discharge line and condenser line from the condenser.

**NOTE**

- Plug or cap the lines immediately after disconnecting them to avoid moisture and dust contamination.

6. Remove the bolts, then remove the condenser (A) by lifting it up. Be careful not to damage the radiator and condenser fins when removing the condenser.



KQBF108D

7. Install in the reverse order of removal, and note these items :
  - If you're installing a new condenser, add refrigerant oil ND-OIL8.
  - Replace the O-rings with new ones at each fitting, and apply a thin coat of refrigerant oil before installing them. Be sure to use the right O-rings for R-134a to avoid leakage.
  - Be careful not to damage the radiator and condenser fins when installing the condenser.
  - Be sure to install the lower mount cushions of condenser securely into the holes.
  - Charge the system, and test its performance. (Refer to HA-11)


## HA -22

## HEATING, VENTILATION AND AIR CONDITIONING

## DESICCANT


1. Remove the condenser, and then remove the bottom cap (B) with L wrench (A) from the condenser.

TORQUE: 20~25N·m (2.0~2.5kgf·m, 14.5~18.2lb·ft)



KQBF108E

2. Remove the desiccant (A) from the receiver/drier tank using a long nose plier.



KQBF108F


**NOTE**

- Always replace the desiccant and bottom cap at the same time.
- Replace the O-rings with new ones at each fitting, and apply a thin coat of refrigerant oil before installing them. Be sure to use the right O-rings for R-134a to avoid leakage.
- Be careful not to damage the radiator and condenser fins when installing the condenser.
- Be sure to install the lower mount cushions of condenser securely into the holes.
- Charge the system, and test its performance. (Refer to HA-11)



A/C PRESSURE TRANSDUCER

COMPONENT LOCATION EEDD623E



EQBF116A

## HA -24


## HEATING, VENTILATION AND AIR CONDITIONING

## DESCRIPTION E25CCF46

A/C pressure transducer convert the pressure value of high pressure line into voltage value after measure it. By converted voltage value, engine ECU controls cooling fan by operating it high speed or low speed. Engine ECU stop the operation of compressor when the temperature of refrigerant line is so high or so low irregularly to optimize air conditioning system.

## INSPECTION E4FFBFAD

1. Measure the pressure of high pressure line by measuring voltage output between NO.1 and NO.2 terminals.



2. Inspect the voltage value whether it is sufficient to be regular value or not.

---


$$\text{Voltage} = 0100878835 * \text{Pressure} + 0.5[\text{kgf/cm}^2]$$


---

3. If the measured voltage value is not specification, replace the A/C pressure transducer.


---


$$\text{Error range} : + - 2.5\%$$


---

## REPLACEMENT E8E61C2A

1. Disconnect the negative (-) battery terminal
2. Disconnect A/C pressure transducer connector (3P) from wiring harness.



KQBF116C

 **NOTE**

Take care that liquid suction pipe is not bent.

3. Installation is the reverse order of removal.

A/C COMPRESSOR CONTROLS (MANUAL)


HA -25

REFRIGERANT LINE

COMPONENT LOCATION E9BE4ABD

[Gasoline]

Refrigerant Line



EQBF113A

## HA -26

## HEATING, VENTILATION AND AIR CONDITIONING

REPLACEMENT EBF856FE

1. Discharge refrigerant from refrigeration system (Refer to HA-8).
2. Replace faulty tube or hose.

**⚠ CAUTION**

**Cap the open fittings immediately to keep moisture or dirt out of the system.**

3. Tighten joint of bolt or nut to specified torque

**⚠ CAUTION**

**Connections should not be torque tighter than the specified torque.**

Part tightened	N·m	Kgf·m	lbf·ft
Condenser x Discharge hose		0.5~0.6	
Condenser x Liquid tube			
Compressor x Discharge hose			
Compressor x Suction hose			
Expansion valve x Evaporator		1.2~1.5	

4. Evacuate air in refrigeration system and charge system with refrigerant (Refer to HA-9).

Specified amount: 500 ± 25g

5. Inspect for leakage of refrigerant.  
Using a gas leak detector, check for leakage of refrigerant (Refer to HA-9).
6. Inspect A/C operation.



HEATER


HA -27

# HEATER

## EVAPORATOR TEMPERATURE SENSOR

COMPONENT EABDE649

[Manual]



EQBF161A

HA -28

HEATING, VENTILATION AND AIR CONDITIONING

**DESCRIPTION** E7527E61

The evaporator temperature sensor will detect the evaporator core temperature and interrupt compressor relay power in order to prevent evaporator freezing by excessive cooling.

It is a negative type thermistor whose resistance is inversely proportional to temperature.

**INSPECTION** EC2ADC1B

1. Ignition " ON".
2. A/C switch ON.
3. Disconnect evaporator temperature sensor connector.
4. Using the multi-tester, Measure resistance between terminal "1" and "2" of evaporator temperature sensor.

**SPECIFICATION**

Evaporator core temperature [°C(°F)]	Resistance [kΩ]
-10(14)	18.31
0(32)	11.60
10(50)	7.55
15(59)	5.04
30(86)	3.44
40(104)	2.40


5. If the measured resistance is not specification, substitute with a known-good evaporator temperature sensor and check for proper operation.
6. If the problem is corrected, replace the evaporator temperature sensor.

**REPLACEMENT** EA18C4AE

1. Remove the console assembly.
2. Remove the crush pad center low cover (A) after loosening 2 screws.

[Passenger's]


▷ : Screw, 2



EQBF203F

[Driver's]


▷ : Screw location, 2



EQBF903G


**HEATER****HA -29**

3. Remove the under cover after loosening 2 screws.
4. Disconnect the connector pin (A).




EQRE203Z


5. Remove the evaporator temperature sensor (B) by pulling it after rotating 90° in a counterclockwise direction.



EQBF961B



[RHD]



EQRE161C


6. Installation is the reverse order of removal.

HA -30

HEATING, VENTILATION AND AIR CONDITIONING

## HEATER UNIT

COMPONENT LOCATION ED0BFF14




EQBF300A

HEATER

HA -31

COMPONENTS

[LHD]




- |                                     |                                            |                                              |
|-------------------------------------|--------------------------------------------|----------------------------------------------|
| 1. Heater & Evaporator case         | 9. Mode cam                                | 17. Heater separator (Dual type)             |
| 2. Heater core                      | 10. Defrost door                           | 18. Upper case seal                          |
| 3. Heater core cover                | 11. Vent door                              | 19. Heater & Evaporator upper case           |
| 4. PTC heater (Diesel only)         | 12. Floor door                             | 20. Evaporator case seal                     |
| 5. Water temperature sensor         | 13. Temperature control door (Single type) | 21. Evaporator core                          |
| 6. Water temperature sensor stopper | 14. Insulation                             | 22. Evaporator temperature sensor            |
| 7. Temperature control actuator     | 15. Heater & Evaporator lower case         | 23. Temperature control actuator (Dual type) |
| 8. Mode control actuator            | 16. Heater separator (Single type)         | 24. Temperature control door (Dual type)     |

EQRF300B

HA -32

HEATING, VENTILATION AND AIR CONDITIONING

[RHD]



- |                                     |                                            |                                              |
|-------------------------------------|--------------------------------------------|----------------------------------------------|
| 1. Heater & Evaporator case         | 9. Mode cam                                | 17. Heater separator (Dual type)             |
| 2. Heater core                      | 10. Defrost door                           | 18. Heater & Evaporator upper case           |
| 3. Heater core cover                | 11. Vent door                              | 19. Evaporator case seal                     |
| 4. PTC heater (Diesel only)         | 12. Floor door                             | 20. Evaporator core                          |
| 5. Water temperature sensor         | 13. Temperature control door (Single type) | 21. Evaporator temperature sensor            |
| 6. Water temperature sensor stopper | 14. Insulation                             | 22. Temperature control actuator (Dual type) |
| 7. Temperature control actuator     | 15. Heater & Evaporator lower case         | 23. Temperature control door (Dual type)     |
| 8. Mode control actuator            | 16. Heater separator (Single type)         |                                              |


EQRE300B

## HEATER

HA -33


## REPLACEMENT E1BF154E

1. Disconnect the negative (-) battery terminal.
2. Recover the refrigerant with a recovery/ recycling/ charging station. (Refer to HA-10)
3. When the engine is cool, drain the engine coolant from the radiator.
4. Remove the air cleaner.
5. Remove the expansion valve cover(B) after loosening the nut (A).




KQRE300C

6. Remove the bolts (A) and the expansion valve (B) from the evaporator core. Plug or cap the lines immediately after disconnecting them to avoid moisture and dust contamination.



KQBF300D

7. Disconnect the inlet (A) and outlet (B) heater hoses from the heater unit.




EQR300E

**CAUTION**

*Engine coolant will run out when the hoses are disconnected; drain it into a clean drip pan. Be sure not to let coolant spill on electrical parts or painted surfaces. If any coolant spills, rinse it off immediately.*

8. Remove the crash pad (Refer to BD group).
9. Remove the cowl cross bar assembly. (Refer to BD group)
10. Remove the heater & blower unit after loosening 3 mounting bolts.




KQBF300F

## HA -34


## HEATING, VENTILATION AND AIR CONDITIONING

11. Remove the blower unit from heater unit(A) after loosening screws.



KQBF300G

12. Remove the heater core (B) after remove the side braket (A).



KQBF300H

13. Be careful that the inlet and outlet pipe are not bent during heater core removal, and pull out the heater core.
14. Install the heater core in the reverse order of removal.

15. Installation is the reverse order of removal, and note these items :

- If you're installing a new evaporator, add refrigerant oil (ND-OIL8).
- Replace the O-rings with new ones at each fitting, and apply a thin coat of refrigerant oil before installing them. Be sure to use the right O-rings for R-134a to avoid leakage.
- Immediately after using the oil, replace the cap on the container, and seal it to avoid moisture absorption.
- Do not spill the refrigerant oil on the vehicle ; it may damage the paint ; if the refrigerant oil contacts the paint, wash it off immediately
- Apply sealant to the grommets.
- Make sure that there is no air leakage.
- Charge the system and test its performance.
- Do not interchange the inlet and outlet heater hoses and install the hose clamps securely.
- Refill the cooling system with engine coolant


HEATER

HA -35

PTC (POSITIVE TEMPERATURE COEFFICIENT) HEATER

DESCRIPTION EA61D22B

PTC (Positive Temperature Coefficient) heater (A) is an electric heater using a PTC element as an auxiliary heating device that supplements deficiency of interior heat source in highly effective diesel engine (U engine).




AQJF301B

An electric heater heats up the interior by directly heating the air that passes through the heater.  
 PTC = positive Temperature Coefficient  
 The name itself implies that the element has a proportional resistance change sensitive to temperature. PTC heater is installed at the exit or the backside of heater core.


OPERATION PRINCIPLE

ECM outputs a PTC on signal. Operate PTC from 1st setting to 3rd setting with an interval of 15 seconds. Heat up the air, which passes through a heater core.

Connector



EQBF301C



AQJF301A

## HA -36

## HEATING, VENTILATION AND AIR CONDITIONING

## INSPECTION E064CF7F

Inspect the PTC operation by confirmation logic as below.

## 1. Entering method

- 1) Set the floor mode, maximum heating
- 2) Turn off the blower switch
- 3) Press the intake button more than 5 times.
- 4) Indicator of entire button is flashed with an interval of 0.5 seconds continuously (Manual).  
Graphics of the entire LCD display switch on and off with an interval of 0.5 seconds continuously (Automatic)
- 5) Confirm the PTC operation by operating the blower switch  
Manual: 1~4 step, Automatic: 1~8step.
- 6) Each PTC relay is operated with an interval of 3 seconds.
- 7) Execute the PTC operation by confirmation logic for 30 seconds.

## 2. Cancellation method

- 1) Select the A/C button or intake button.
- 2) IG "OFF"
- 3) Cancel the logic after 30 seconds automatically.

3. If the PTC operation is not operated, substitute with a known-good PTC and check for proper operation.  
If the problem is corrected, replace the PTC.




HEATER

HA -37

TEMPERATURE CONTROL ACTUATOR

COMPONENT LOCATION EC9B56FE



EQBF315A

HA -38


HEATING, VENTILATION AND AIR CONDITIONING

DESCRIPTION EC1BD7DC

1. Heater unit includes mode control actuator and temperature control actuator.
2. Temperature control actuator is located at the heater unit. It regulates the temperature by the procedure as follows. Signal from control unit adjusts position of temperature door by operating temperature switch and then temperature will be regulated by the hot/cold air ratio decided by position of temperature door.


INSPECTION E1E03021

1. Ignition "OFF".
2. Disconnect the connector of temperature control actuator.
3. Verify that the temperature control actuator operates to the hot position when connecting 12V to the terminal 3(RHD:4) and grounding terminal 4(RHD:3).
4. Verify that the temperature control actuator operates to the cool position when the connections in are reversed.



- |                  |                      |
|------------------|----------------------|
| 1. -             | 5. Sensor ground     |
| 2. -             | 6. Feedback signal   |
| 3. Hot position  | 7. Sensor power (5V) |
| 4. Cool position |                      |

EQRF315B



- |                  |                      |
|------------------|----------------------|
| 1. -             | 5. Sensor power (5V) |
| 2. -             | 6. Feedback signal   |
| 3. Cool position | 7. Sensor ground     |
| 4. Hot position  |                      |

EQRF315B

5. Check the voltage between terminals 5 and 6.

SPECIFICATION

Door position	Voltage (5-6) (RHD:6-7)	Error detecting
Max. cooling	0.3 ± 0.15V	Low voltage : 0.1V or less
Max. heating	4.7 ± 0.15V	High voltage : 4.9V or more

It will feedback current position of actuator to controls.

6. If the measured voltage is not within specification, substitute with a known-good temperature control actuator and check for proper operation.
7. If the problem is corrected, replace the temperature control actuator.




## HEATER

HA -39

## REPLACEMENT EB03F852


## TEMPERATURE CONTROL ACTUATOR(PASSENGER' S)

1. Remove the glove box (Refer to BD group).



## TEMPERATURE CONTROL ACTUATOR(DRIVER' S)

1. Disconnect the negative (-) battery terminal.
2. Disconnect the connector (C) of temperature control actuator.
3. Loosen the mounting screw and then remove the temperature control actuator(D).



KQBF315F


4. Installation is the reverse order of removal.

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

EQBF203G

2. Disconnect the temperature control actuator connector (A) after removing the air duct.
3. Loosen the mounting screw and then remove the temperature control actuator (B).



KQBF315D

4. Installation is the reverse order of removal.

HA -40

HEATING, VENTILATION AND AIR CONDITIONING

MODE CONTROL ACTUATOR

COMPONENT LOCATION E2D35F51



EQBF316A

**HEATER**

**HA -41**


**DESCRIPTION** ED3C2ED1

The mode control actuator is located at the heater unit. It adjusts position of mode door by operating mode control actuator based on signal of A/C control unit. Pressing mode select switch makes the mode control actuator shift in order of vent → B/L → floor → mix.

**INSPECTION** E2C0C365


1. Ignition "OFF" .
2. Disconnect the connector of mode control actuator.
3. Verify that the mode control actuator operates to the defrost position when connecting 12V to the terminal 3(RHD:4) and grounding terminal 4(RHD:3).
4. Verify that the mode control actuator operates to the vent position when connecting in the reverse.

[LHD]



- |                 |                      |
|-----------------|----------------------|
| 1. -            | 5. Sensor ground     |
| 2. -            | 6. Feedback signal   |
| 3. Defrost mode | 7. Sensor power (5V) |
| 4. Vent mode    |                      |

[RHD]



- |                 |                      |
|-----------------|----------------------|
| 1. -            | 5. Sensor power (5V) |
| 2. -            | 6. Feedback signal   |
| 3. Vent mode    | 7. Sensor ground     |
| 4. Defrost mode |                      |

EQRF316B

EQRE316B

5. Check the voltage between terminals 5 and 6.


Door position	Voltage (5-6) (RHD:6-7)	Error detecting
Vent	0.3 ± 0.15V	Low voltage : 0.1V or less
Defrost	4.7 ± 0.15V	High voltage : 4.9V or more

It will feedback current position of actuator to controls.

6. If the measured voltage is not specification, substitute with a known-good mode control actuator and check for proper operation.
7. If the problem is corrected, replace the mode control actuator.

**REPLACEMENT** ECA9BF2A

1. Disconnect the negative (-) battery terminal.
2. Remove the driver' s crush pad lower panel. (Refer to BD group)
3. Disconnect the mode control actuator connector (A) after removing the air duct.
4. Loosen the mounting screws and then remove the mode control actuator (B).



KQBF316C

5. Installation is the reverse order of removal.


HA -42

HEATING, VENTILATION AND AIR CONDITIONING

# A/C COMPRESSOR CONTROLS (FULL AUTO)

## IN CAR SENSOR

COMPONENT LOCATION E1FBD2C7




EQBF201A

**A/C COMPRESSOR CONTROLS (FULL AUTO)**

**HA -43**

**DESCRIPTION** E2CFB8F9

1. In-car air temperature sensor is located at the center facia lower panel.
2. The sensor contains a thermistor which measures the temperature of the inside. The signal decided by the resistance value which changes in accordance with perceived inside temperature, is delivered to heater control unit and according to this signal the control unit regulates incar temperature to intended value.
3. It perceives the inside temperature, changes the resistance value, and enters the corresponding voltage into the automatic temperature control module.
4. It will used for discharge temperature control, sensor failsafe, temperature door control, blower motor level control, and A/C auto control.




- 1. Motor(-)
- 2. Sensor ground (+)
- 3. Humidity sensor signal
- 4. In-car sensor temp. signal
- 5. 5V (Vcc)
- 6. Motor (+)

LQJF201C

**INSPECTION** E4BC596B

1. Ignition "OFF".
2. Remove the in car sensor connector.
3. Blow air with changing temperature to the in car sensor air inlet. Measure sensor resistance between 2 and 4 terminals.
4. In car sensor is negative type thermistor that resistance will rise with lower temperature, and reduce with higher temperature.



EQBF201E

**SPECIFICATION**

Temperature [°C(°F)]	Resistance between terminals 2and 4 (kΩ)
50 (122)	10.81 ± 2.2%
35 (95)	19.57 ± 1.6%
25 (77)	30.00 ± 1.20%
15 (59)	47.13 ± 1.7%
0 (32)	97.71 ± 2.4%
-15 (-74.2)	216.1 ± 3.2%

**NOTE**


*In car sensor is negative type thermistor that resistance will rise with lower temperature, and reduce with higher temperature.*

## HA -44

## HEATING, VENTILATION AND AIR CONDITIONING

## REPLACEMENT EBFDCFE5

1. Disconnect the negative (-) battery terminal.
2. Remove the center facia panel. (Refer to BD group).
3. Loosen the mounting 2 screws and then remove the in-car sensor (B).



4. Installation is the reverse order of removal.

KQBF201C



دیجیتال خودرو  
شرکت دیجیتال خودرو سامانه (مسئولیت محدود)


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

A/C COMPRESSOR CONTROLS (FULL AUTO)

HA -45

PHOTO SENSOR

COMPONENT LOCATION E78B62FB



EQBF202A

## HA -46

## HEATING, VENTILATION AND AIR CONDITIONING

## DESCRIPTION EB4274FB


1. The photo sensor (A) is located at the center of defrost nozzle.
2. The photo sensor contains a photovoltaic (sensitive to sunlight) diode. The solar radiation received by its light receiving portion, generates an electromotive force in proportion to the amount of radiation received which is transferred to the automatic temperature control module so that the solar radiation compensation will be performed.

## INSPECTION E5E3B4EB

1. Ignition "ON"
2. Using the scan tool.
3. Emit intensive light toward photo sensor using a lamp, and check the output voltage change.
4. The voltage will rise with higher intensive light and reduce with lower intensive light.


## REPLACEMENT EA97E66E

1. Disconnect the negative (-) battery terminal.
2. With the (-) driver, remove the photo sensor (B) from the center of defrost nozzle (A).



KQBF202C

3. Install in the reverse order of removal.



دیجیتال خودرو  
شرکت دیجیتال خودرو سامانه (مسئولیت محدود)


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

A/C COMPRESSOR CONTROLS (FULL AUTO)

HA -47

WATER TEMPERATURE SENSOR

COMPONENT LOCATION E2C49C2F




EQBF203A

HA -48

HEATING, VENTILATION AND AIR CONDITIONING

**DESCRIPTION** E4A16B77

1. Water temperature sensor is located at the heater unit.
2. It detects coolant temperature. Its signal is used for cold engine lockout control. When the driver operates the heater before the engine is warmed up, the signal from sensor causes the heater control unit to reduce blower motor speed until coolant temperature reaches the threshold value.




KQRE203B

**INSPECTION** EBAF1E08

1. Ignition "ON"
2. Using the multi-tester, Measure resistance between terminal "1" and "2" of water temperature sensor.

**SPECIFICATION**

Coolant temperature [°C (°F)]	Resistance (kΩ)
-10(14)	55.85 ± 3%
0(32)	32.91 ± 3%
20(68)	12.51 ± 3%
40(104)	5.311 ± 3%
60(140)	2.476 ± 3%
80(176)	1.246 ± 3%



1. Water Temp Sensor (+)
2. Ground (-)

EQBF203D

**NOTE**


Negative type thermistor that resistance will rise with lower temperature, and reduce with higher temperature.

## A/C COMPRESSOR CONTROLS (FULL AUTO)

HA -49


## REPLACEMENT E78DEC60

1. Disconnect the negative (-) battery terminal.
2. Remove the center lower side cover(A). (Refer to BD group)



KQBF203F

3. Pull the water temperature sensor (A) out at the heater unit with the stopper (B).



EQBF203E

4. Installation is the reverse order of removal.

 **NOTE**

Take care that wire of water temperature sensor is not to be damaged.




HA -50

HEATING, VENTILATION AND AIR CONDITIONING

## AMBIENT TEMPERATURE SENSOR

COMPONENT LOCATION E4CCFB41



EQBF204A

**A/C COMPRESSOR CONTROLS (FULL AUTO)**

**HA -51**

**DESCRIPTION** EA71DB9A

1. The ambient temperature sensor is located at the front of the condenser and detects ambient air temperature. It is a negative type thermistor; resistance will increase with lower temperature, and decrease with higher temperatures.
2. The sensor output will be used for discharge temperature control, temperature regulation door control, blower motor level control, mix mode control and in-car humidity control.

**NOTE**



If the ambient temperature is below 2.0°C (35.6°F), the A/C compressor will be stopped. The compressor will be operated by manual operating.

**INSPECTION** EE1F897D

1. Ignition "OFF"
2. Disconnect ambient temperature sensor.
3. Check the resistance of ambient temperature sensor between terminals 1 and 2 whether it is changed by changing of the ambient temperature.


**SPECIFICATION**

Ambient temperature [°C (°F)]	Resistance between terminals 1and 2 (kΩ)
-20( )	271.1 ± 3%
0 (32)	95.1 ± 3%
25( )	30.0 ± 3%
50( )	37.5 ± 3%
80( )	3.83 ± 3%



KQRE204B

KQRE204D



- 1. Ambient Temp Sensor(+)
- 2. Sensor Ground (-)
- 3. -
- 4. AQS Signal
- 5. AQS Ground (-)
- 6. IG 2 (+)

EQBF204C

**REPLACEMENT** EC1FD8E2


1. Disconnect the negative (-) battery terminal.
2. Remove the front bumper under cover. (Refer to BD group)
3. Remove the connector ambient temperature sensor.
4. Loosen the mounting bolt and then remove the ambient temperature sensor.
5. Installation is the reverse order of removal.

HA -52

HEATING, VENTILATION AND AIR CONDITIONING

**A.Q.S (AIR QUALITY SENSOR)**

**COMPONENT LOCATION** E493C739



EQBF207A

**A/C COMPRESSOR CONTROLS (FULL AUTO)**

**HA -53**

**DESCRIPTION** E4A5AF33

1. A.Q.S is located at center support in front of the engine radiator, and detects hazardous elements in ambient air providing output signal to control.
2. It will detect sulfurous acid gas, carbon dioxide, carbon monoxide, hydrocarbon and allergen.

**INSPECTION** E6D1DB0A



1. Check the output voltage of AQS between terminals 4 and 5.

**SPECIFICATION**

Condition	Output signal	Fresh/recirculation
Normal condition	4 ~ 5V	Fresh
Hazardous gas detection	0 ~ 1V	Recirculation

**REPLACEMENT** E59CA3CC

1. Disconnect the negative (-) battery terminal.
2. Remove the front bumper under cover. (Refer to BD group).
3. Remove the AQS (A) after loosening the mounting bolt.



- 1. Ambient Temp Sensor(+)
- 2. Sensor Ground (-)
- 3. -
- 4. AQS Signal
- 5. AQS Ground (-)
- 6. IG 2 (+)

EQBF204C

4. Installation is the reverse order of removal.


KQBF204E

HA -54

HEATING, VENTILATION AND AIR CONDITIONING

# HUMIDITY SENSOR

COMPONENT LOCATION EBB56AFA




EQBF201A

**A/C COMPRESSOR CONTROLS (FULL AUTO)**

**HA -55**

**DESCRIPTION** E729B284

1. Humidity sensor is located at the lower crush pad and detected in-car humidity for in-car humidity control.
2. If ambient air temperature or in-car humidity is outside certain range, it will turn on A/C to control in-car humidity preventing in car fogging.  
Air conditioner operation depends on ambient temperature and humidity.




- |                           |                               |
|---------------------------|-------------------------------|
| 1. Motor(-)               | 4. In-car sensor temp. signal |
| 2. Sensor ground (+)      | 5. 5V (Vcc)                   |
| 3. Humidity sensor signal | 6. Motor (+)                  |

LQJF201C

**REPLACEMENT** E2724A5C

1. Disconnect the negative (-) battery terminal.
2. Remove the center facia panel (A). (Refer to BD group).
3. Disconnect the humidity sensor connector (A).
4. Loosen 2 screws and then remove the humidity sensor (B).



KQBF201D

**INSPECTION** E038F490

5. Installation is the reverse order of removal.

1. Ignition "ON"
2. Using the scan tool.
3. Check the frequency of humidity sensor between terminals 2 and 3.
4. If the measured resistance is not specification, substitute with a known-good humidity sensor and check for proper operation.

Humidity (%)	Frequency between terminals 2and 3 (Hz)
0	7351 ± 10%
10	7224 ± 10%
20	7100 ± 10%
30	6979 ± 10%
40	6853 ± 10%
50	6728 ± 10%
60	6600 ± 10%
70	6468 ± 10%
80	6330 ± 10%
90	6186 ± 10%
100	6033 ± 10%


HA -56

HEATING, VENTILATION AND AIR CONDITIONING

# BLOWER CONTROLS

## BLOWER UNIT

COMPONENT LOCATION E14C3AC4




EQBF351A

**BLOWER CONTROLS**

HA -57

**COMPONENTS**



- 1. Outlet duck seal
- 2. Inlet duct case
- 3. Inlet door
- 4. Intake acuator
- 5. Air filter
- 6. Air filter housing

- 7. Blower upper case
- 8. Blower lower case
- 9. Blower seal
- 10. Blower motor
- 11. Resister(Manual)
- 12. Power mosfet(Pull auto)

EQBF351B


## HA -58

## HEATING, VENTILATION AND AIR CONDITIONING

## REPLACEMENT


E672E536

1. Disconnect the negative (-) battery terminal.
2. Remove the crush pad.(Refer to BD group)
3. Disconnect the connectors from the intake actuator, the blower motor and power mosfet.
4. Remove the cowl cross bar assembly.(Refer to BD group)
5. Remove the heater and blower unit.



KQBF300F

6. Remove the blower unit (A) from the heater unit after loosening a mounting bolt and 3 screws.



KQBF300G

**NOTE**

*Make sure that there is no air leaking out of the blower and duct joints.*


7. Installation is the reverse order of removal.

**BLOWER CONTROLS**

**HA -59**

**BLOWER MOTOR**

**COMPONENT LOCATION** E3FCF63A



EQBF352A

HA -60


HEATING, VENTILATION AND AIR CONDITIONING

INSPECTION

E9354168


1. Connect the battery voltage and check the blower motor rotation.

[LHD]



EQBF952C

[RHD]




EQRE352C

2. If the blower motor does not operate properly, substitute with a known-good blower motor and check for proper operation.
3. If the problem is corrected, replace the blower motor.

REPLACEMENT


EEFFEEA8

1. Disconnect the negative (-) battery terminal.
2. Remove the under cover after loosening 3 screws and then remove the step lamp connector (B).



KQBF352B

3. Disconnect the connector (A) of the blower motor.




AQJF352D

**BLOWER CONTROLS**

HA -61

4. Remove the blower motor (C) after loosening the mounting screws.



KQBF352C

5. Installation is the reverse order of removal.

# دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




HA -62

HEATING, VENTILATION AND AIR CONDITIONING

## BLOWER RELAY

COMPONENT LOCATION E20B508B




EQBF353A

**BLOWER CONTROLS**

**HA -63**

**INSPECTION** E52A55BE


1. Disconnect the negative (-) battery terminal.
2. Remove the passenger compartment relay box.
3. There should be continuity between the No.9 in the I/P-K and No.15 in the I/P-A terminals when power and ground are connected to the No.16 in the I/P-D and No.13 I/P-B terminals in the passenger compartment relay box.
4. There should be no continuity between the No.9 in the I/P-K and No.15 in the I/P-A terminals when power is disconnected.



KTRE323D

Terminal Position	I/P-K (9)	I/P-A (15)	I/P-D (16)	I/P-B (13)
Disconnected			○ — ○	○ — ○
Connected	○ — ○		⊖ — ⊕	

EQBF323B



KTRE323A


HA -64

HEATING, VENTILATION AND AIR CONDITIONING

POWER MOSFET

COMPONENT LOCATION EDAFEABA

[Full Auto]



EQBF355A



**BLOWER CONTROLS**

**HA -65**

**INSPECTION**

E692AAE7

1. Disconnect the negative (-) battery terminal.
2. Remove the power mosfet. Measure drain-to-sauce resistance of the power mosfet.




EQBF355B

Resistance (Drain-Sauce)		Subject	
		1	2
Power mosfet	Drain	+	-
	Sauce	-	+
Section	Normal	$\infty$	Approx 3M $\Omega$
	Short	Approx 0 ~ 300 $\Omega$	Approx 0 ~ 300 $\Omega$
	Open	$\infty$	$\infty$

3. If the measured resistance is not specification, replace the power mosfet.
4. If measured resistance is specification, install power mosfet and ignition switch ON. Measure the voltage between blower motor terminals by operating control switch manually.

5. Select the control switch to raise voltage until high speed.



EQBF355C

**SPECIFICATION**

Fan	Motor Voltage
	Manual
First speed	3.8 ± 0.5V
Second speed	5.0 ± 0.5V
Third speed	6.2 ± 0.5V
Fourth speed	7.4 ± 0.5V
Fifth speed	8.6 ± 0.5V
Sixth speed	9.8 ± 0.5V
Seventh speed	11.0 ± 0.5V
eighth speed	Battery( + )


6. If the measured voltage is not specification, substitute with a known-good power mosfet and check for proper operation.
7. If the problem is corrected, replace the power mosfet.

## HA -66

## HEATING, VENTILATION AND AIR CONDITIONING


## REPLACEMENT E1B2A46F

1. Disconnect the negative (-) battery terminal.
2. Disconnect the power mosfet connector (A) at the connecting part between heater and blower unit.



EQBF355D

3. Remove the power mosfet (B) after loosening the mounting screws.



KQBF355E

4. Installation is the reverse order of removal.


BLOWER CONTROLS

HA -67

BLOWER RESISTOR

COMPONENT LOCATION E8B8CDD4

[Manual]



EQBF357A

HA -68

HEATING, VENTILATION AND AIR CONDITIONING


INSPECTION

E668BF12

1. Measure terminal-to-terminal resistance of the blower resistor.
2. If measured resistance is not within specification, the blower resistor must be replaced. (After removing the resistor)

Resistance ohmmeter	Terminal				Resistance ( $\Omega$ )
	2	1	4	3	
Speed	MH	ML	HI	LO	
Measurement of resistance between each terminal			○	○	$2.9 \pm 5\%$
		○	○		$1.5 \pm 5\%$
	○		○		$0.5 \pm 5\%$

EQBF357B




EQBF354C

REPLACEMENT

E0B6DA8A

1. Disconnect the negative (-) battery terminal.
2. Disconnect the blower resistor connector (A) at the connecting part blower unit.
3. Remove the blower resistor after loosening the mounting screws.



KQBF357E

4. Installation is the reverse order of removal.

**BLOWER CONTROLS**


HA -69

**A/C AIR FILTER****DESCRIPTION** E5EFF93E

This has particle filter which eliminates foreign materials and odor. The particle filter includes odor filter as well as conventional dust filter to ensure comfortable interior environment.


**REPLACEMENT** E14DF2A8

1. Open the glove box (B). Lower the glove box down completely by removing the glove box stopper (A) to the glove box.




EQBF359B

2. Remove the demper from glove box.



KQBF359A

3. Remove the filter cover (A) with pushing the knob.
4. Replace the air filter (B), install it after making sure of the direction of air filter.



KQBF359C

**NOTE**

*In case of driving in an air-polluted area or rugged terrain, check and replace the air filter as frequently as possible.*


Replacement period: 15,000 km (9320 mile)

HA -70

HEATING, VENTILATION AND AIR CONDITIONING

## INTAKE ACTUATOR

COMPONENT LOCATION E527532E



EQBF501A

**BLOWER CONTROLS**

**HA -71**

**DESCRIPTION** EF525566

1. The intake actuator is located at the blower unit.
2. It regulates the intake door by signal from control unit.
3. Pressing the intake selection switch will shift between recirculation and fresh air modes.

**INSPECTION** E3A55DFA

1. Ignition "OFF".
2. Disconnect the connector of intake actuator.
3. Verify that the intake actuator operates to the recirculation position when connecting 12V to the terminal 3(RHD:4) and grounding terminal 4(RHD:3).
4. Verify that the intake actuator operates to the fresh position when the connections are reversed.


Door position	Voltage (5 - 6) (RHD:6-7)	Error detecting
Recirculation	0.3 ± 0.15V	Low voltage : 0.1V or less
Fresh	4.7 ± 0.15V	High voltage : 4.9V or more

5. If the intake actuator does not operate properly, substitute with a known-good intake actuator and check for proper operation.
6. If the problem is corrected, replace the intake actuator.

**REPLACEMENT** E4F015DB

1. Disconnect the negative (-) battery terminal.
2. Remove the glove box (Refer to BD group).
3. Disconnect the intake actuator connector.
4. Loosen the mounting screw and then remove the intake actuator (B) from the blower unit(A).


[LHD]



1. -
2. -
3. Recirculation position
4. Fresh position
5. Sensor ground
6. Feedback signal
7. Sensor power (5V)


EQRF501B

[RHD]



1. -
2. -
3. Fresh position
4. Recirculation position
5. Sensor power (5V)
6. Feedback signal
7. Sensor ground

EQRE501B



KQBF501C

5. Installation is the reverse order of removal.




HA -72

HEATING, VENTILATION AND AIR CONDITIONING


# BLOWER AND A/C CONTROLS (MANUAL)

## CONTROL PANEL

COMPONENT EE4C16E4



Connector A



Connector B

EQBF450A

**BLOWER AND A/C CONTROLS (MANUAL)**

HA -73


**CONNECTOR PIN FUNCTION**

CONNECTOR	PIN	FUNCTION
Connector (A)	1	Ground
	2	Middle high
	3	Middle low
	4	High
	5	Low
	6	-
Connector (B)	1	Tail lamp (+)
	2	Battery (+)
	3	A/C output
	4	Vent mode
	5	Defrost mode
	6	Temp actuator cool
	7	Temp actuator warm
	8	Intake (Fresh)
	9	Intake (Recirculation)
	10	Rear defogger indicator
	11	Sensor power ( + 5V)
	12	Blower ON signal
	13	IGN2
	14	Tail lamp (-) : Rheostat
	15	PTC relay 2
	16	PTC relay 3
	17	Temp actuator feedback signal
	18	Mode actuator feedback signal
	19	Intake actuator feedback signal
	20	Evaporator temperature sensor
	21	Blower ON signal
	22	A/C select signal
	23	Rear defogger switch
	24	Sensor ground
	25	PTC ON signal
	26	Ground



BLOWER AND A/C CONTROLS (MANUAL)

HA -75




EQBF450C

HA -76

HEATING, VENTILATION AND AIR CONDITIONING


REPLACEMENT E76BA7C8

1. Disconnect the negative (-) battery terminal.
2. Remove the crash pad center ganish(A).




KQBF450E

5. Loosen the screw. Remove the center facia pannel(B) and then disconnect the connectors.




3. Remove the crash pad side cover(B).

KQBF450H




6. Remove the heater & A/C controller (A) after loosening 4 screws.



KQBF450F

4. Remove the crash pad lower panel(A).

KQBF450D



KQBF450G

7. Installation is the reverse order of removal.




BLOWER AND A/C CONTROLS (AUTOMATIC)

HA -77

# BLOWER AND A/C CONTROLS (AUTOMATIC)

## CONTROL PANEL

COMPONENT E756C38B



Connector A




Connector B

EQBF500A

HA -78


HEATING, VENTILATION AND AIR CONDITIONING

[AV Control ECU]



Connector A

Connector B



EQBF500F

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -79

**CONNECTOR PIN FUNCTION**

CONNECTOR	PIN	FUNCTION
CONNECTOR (A)	1	Tail lamp (+)
	2	Battery (+)
	3	A/C output
	4	A/C select signal
	5	-
	6	Diagnostic tool
	7	-
	8	-
	9	Intake actuator (recirculation)
	10	Rear defogger switch
	11	-
	12	IGN 2
	13	IGN 2
	14	Rheostat
	15	-
	16	Temp actuator cool(Passenger's)
	17	Temp actuator warm(Passenger's)
	18	Temp actuator feedback signal(Passenger's)
	19	Vent mode
	20	Defrost mode
	21	Mode actuator feedback signal
	22	Intake fresh
	23	Intake recirculation
	24	Intake feedback signal
	25	Ground
	26	Ground

## HA -80

## HEATING, VENTILATION AND AIR CONDITIONING

CONNECTOR	PIN	FUNCTION
CONNECTOR (B)	1	Sensor voltage (5V)
	2	AQS
	3	Ambient sensor (+)
	4	Humidity sensor (+)
	5	In car sensor (+)
	6	Evaporator temperature sensor (+)
	7	Water temperature sensor
	8	Speed sensor
	9	Power mosfet (Gate)
	10	Power mosfet (Drain)
	11	Blower motor (+)
	12	Sensor ground
	13	Temp actuator cool(Driver's)
	14	Temp actuator warm(Driver's)
	15	Photo sensor (-)(Driver's)
	16	Photo sensor (+)(Passenger's)
	17	In car motor
	18	Mode actuator feedback signal(Driver's)
	19	Blower ON signal
	20	PTC ON signal
	21	PTC relay 2
	22	PTC relay 3



**BLOWER AND A/C CONTROLS (AUTOMATIC)**

**HA -81**

**SELF-DIAGNOSIS** EEE842DC

The F.A.T.C. module self test feature will detect electrical malfunction and provide error codes for system components with suspected failures.

1. Self-diagnosis process



**NOTE**

DTC data can be retrieved from the control panel directly or from the DLC using the Hi-Scan Pro.

## HA -82

## HEATING, VENTILATION AND AIR CONDITIONING

## 2. How to read self-diagnostic code

setup temperature display panel every 0.5 second and will show two figures. Codes are displayed in numerical format.

After the display panel flickers three times every 0.5 second, the corresponding fault code flickers on the


## FAULT CODE

Fault code		Fail description
Control unit	DTC	
00	-	Normal
11	B1234	In-car temperature sensor open
12	B1233	In-car temperature sensor short
13	B1238	Ambient temperature sensor open
14	B1237	Ambient temperature sensor short
15	B1202	Water temperature sensor open
16	B1203	Water temperature sensor short
17	B1242	Evaporator temperature sensor open
18	B1241	Evaporator temperature sensor short
19	B1245	Temperature control actuator feed back open (Drive's)
19	B1246	Temperature control actuator feed back short (Drive's)
20	B2406	Temperature control actuator failure
21	B1249	Mode control actuator open
21	B1250	Mode control actuator short
22	B2409	Mode control actuator failure
23	B1200	Humidity sensor open
24	B1201	Humidity sensor short
25	B1208	Intake potentiometer open
25	B1209	Intake potentiometer short
26	B2408	Intake potentiometer failure
27	B1257	AQS sensor open
28	B1258	AQS sensor short
31	B1259	AQS sensor failure
32	B1204	Temperature control actuator open (Passenger's)
32	B1205	Temperature control actuator short (Passenger's)
33	B2415	Temperature control actuator failure

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

**HA -83**

- 3. Fault code display
  - 1) Continuance operation




EQBF500Z

- 2) Step operation



EQBF500Y

- 3) STEP operation



EQBF500E

- 4. If fault codes are displayed during the check, Inspect malfunction causes by referring to fault codes.

## HA -84

## HEATING, VENTILATION AND AIR CONDITIONING

## 5. Fail safe

NO.	ITEM	FAIL SAFE
1	In-car temperature sensor	Control with the valve of 25°C (77°F)
2	Ambient temperature sensor	Control with the valve of 20°C (67°F)
3	Evaporator temperature sensor	Control with the valve of -2°C (28.4°F)
4	Temperature sensor	Control with the valve of -2°C (28.4°F)
5	Temperature control actuator	If temperature setting 17°C - 24.5°C. Fix at maximum cooling position. If temperature setting 25°C - 32°C. Fix at maximum heating position.
6	Mode control actuator	Fix vent position, while selecting vent mode. Fix defrost position, while selecting all except vent mode.
7	Intake control actuator	Fix fresh position, while selecting fresh mode. Fix recirculation position, while selecting recirculation mode.
8	AQS sensor	Intake position : The position before selecting AQS switch.
9	Humidity sensor	Control with the value of 10%
10	Photo sensor	

# دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




**BLOWER AND A/C CONTROLS (AUTOMATIC)**

**HA -85**


**REPLACEMENT** EC3FD3FC

1. Disconnect the negative (-) battery terminal.
2. Remove the crash pad center ganish(A).




KQBF450E

5. Loosen the screw. Remove the center facia panel (A) and then disconnect the connectors.




KQBF450H

3. Remove the crash pad side cover(B).




KQBF450F

6. Remove the heater & A/C controller (A) after loosening 4 screws.



KQBF500E

4. Loosening the screw then, remove the lower panel(A).



KQBF450G

7. Installation is the reverse order of removal.








**BLOWER AND A/C CONTROLS (AUTOMATIC)**

**HA -89**

**DTC B1200 HUMIDITY SENSOR OPEN (HIGH)**

**COMPONENT LOCATION** E55A86D0



EQBF510A

**GENERAL DESCRIPTION** E813CFB8

Humidity sensor located at crush pad, detects in-car humidity for in-car humidity control. If ambient air temperature or in-car humidity is outside certain range, it will turn on A/C to control in-car humidity for preventing in-car fogging. Air conditioner operation depends on ambient temperature and humidity.

**DTC DESCRIPTION** E26F8FC5

The A/C controller sets DTC B1200 if there is an open circuit in humidity sensor signal harness or the measured frequency value of sensor is more than threshold value(about 7,100Hz)

**DTC DETECTING CONDITION** E609B0DF

Item	Detecting Condition	Possible cause
DTC Strategy	• Frequency check	<ul style="list-style-type: none"> <li>• Open Circuit in signal harness</li> <li>• Faulty Humidity Sensor</li> <li>• Faulty A/C control unit</li> </ul>
Threshold value	• > 7,100 Hz	
Detecting time	• 10msec	
FAIL SAFE	• Control with the value of 10%	

**SPECIFICATION** EF7B8179

Relative humidity(%)	Frequency(Hz)	Relative humidity(%)	Frequency(Hz)
20	7,100	60	6,600
30	6,976	70	6,468
40	6,853	80	6,330
50	6,728	90	6,186

## HA -90

## HEATING, VENTILATION AND AIR CONDITIONING

MONITOR SCANTOOL DATA EA55BAF5

1. Connect scantool to data link connector(DLC).
2. Engine "ON"
3. Monitor the "Humidity Sensor" Parameter on the Scantool while drying the humidity sensor with a hair drier or heat gun adjusted to a low heat setting.

1.2 CURRENT DATA	
HUMIDITY SENSOR	10 %
HEATER WATER TEMP.SNSR	12.0 °C
IN-CAR TEMP.SENSOR	11.0 °C
AMBIENT AIR TEMP.SNS	11.5 °C
EVAPORATIVE SENSOR	12.5 °C
DRIVER PHOTO SENSOR	0.00 V
AIR MIX POPTENTIO. (DR.)	91.75 %
DIRECTION POTENIO. DR.	89.79 %

Fig. 1

Fig 1 : The current data in abnormal state.

1.1 DIAGNOSTIC TROUBLE CODES	
B1200 HUMIDITY SENSOR - OPEN(HIGH)	
NUMBER OF DTC : 1 ITEMS	

Fig. 2

Fig 2 : DTC B1200.

4. Are the DTC B1200 present and is parameter of "Humidity Sensor" fixed?  
 \* Parameter of "Humidity Sensor" will be fixed at 10%, if there is any fault in Humidity Sensor.

**YES**

Go to "Inspection" procedure.

**NO**

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION E5F388B6

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

**YES**

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -91


**NO**

Go to "Signal circuit inspection" procedure.

**SIGNAL CIRCUIT INSPECTION** EE9EA63F

1. Check for open in harness.
  - 1) Ignition "OFF"
  - 2) Disconnect Humidity Sensor.
  - 3) Measure resistance between terminal "3" of Humidity Sensor and terminal "4" of A/C Control Unit.

Specification : Approx. 0 Ω



1. Motor(-)
2. Sensor ground
3. Humidity sensor signal
4. In-car sensor temp. signal
5. Sensor power (5V)
6. Motor(+)



- 4) Is the measured resistance within specifications?

**YES**

Go to "Ground circuit Inspection " procedure.

**NO**

Check for open in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.


**GROUND CIRCUIT INSPECTION** E607AF32

1. Check for open in ground harness.
  - 1) Ignition "OFF"
  - 2) Disconnect Humidity Sensor.
  - 3) Measure resistance between terminal "2" of Humidity Sensor and terminal "12" of A/C Control Unit.

Specification :Approx. 0 Ω

HA -92

HEATING, VENTILATION AND AIR CONDITIONING



- 1. Motor(-)
- 2. **Sensor ground**
- 3. Humidity sensor signal
- 4. In-car sensor temp. signal
- 5. Sensor power (5V)
- 6. Motor(+)

EQBF510D

4) Is the measured resistance within specifications?

**YES**

Go to "Component Inspection " procedure.

**NO**


Check for open in ground harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

**COMPONENT INSPECTION** E3A920B6

1. Check Humidity Sensor. (شرکت دیجیتال خودرو سامانه (سنسوریت خودرو)

- 1) Engine "ON"
- 2) Connect Humidity Sensor. (اولین سامانه دیجیتال تعمیرکاران)
- 3) Measure Frequency between terminal "3" and "2" of Humidity sensor while increasing humidity.

Specification : Refer the specifications in fig 5.



- 1. Motor(-)
- 2. **Sensor ground**
- 3. **Humidity sensor signal**
- 4. In-car sensor temp. signal
- 5. Sensor power (5V)
- 6. Motor(+)

EQBF510E

BLOWER AND A/C CONTROLS (AUTOMATIC)

HA -93




Fig. 3




Fig. 4

Fig 3 : Signal waveform of Humidity sensor.

Fig 4 : Frequency of Humidity sensor Measured by scantool.

EQBF510F




Fig. 5

Fig 5) Specifications : Frequency value of humidity sensor as a function of Relative humidity.

EQBF510Q

4) Is the measured frequency within specifications in fig 5? (tolerance limits  $\pm 5\%$ )

**YES**

Go to "Check A/C Control Unit" procedure.

**NO**

Substitute with a known-good Humidity sensor and check for proper operation.

If the problem is corrected, replace Humidity sensor and then go to "Verification of Vehicle Repair" procedure.


2. Check A/C Control Unit

## HA -94

## HEATING, VENTILATION AND AIR CONDITIONING

- 1) Engine "ON"
- 2) Disconnect Humidity Sensor.
- 3) Measure voltage value between terminal "4" of A/C control unit and chassis ground.

Specification : 5V



## 4. Humidity sensor signal

EQBF510G

- 4) Is the measured voltage within specification?

**YES**

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO**

Substitute with a known-good A/C Control Unit and check for proper operation.

If the problem is corrected, replace A/C Control Unit and then go to "Verification of Vehicle Repair" procedure.

### VERIFICATION OF VEHICLE REPAIR E0FE9B19

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
2. Operate the vehicle and monitor the DTC on the scantool.
3. Are any DTCs present?

**YES**

Go to the applicable troubleshooting procedure.

**NO**


System is performing to specification at this time.

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

**HA -95**

**DTC B1201 HUMIDITY SENSOR SHORT (LOW)**

**COMPONENT LOCATION** E7DBA350



EQBF510A

**GENERAL DESCRIPTION** E40CCE08

Humidity sensor located at crush pad, detects in-car humidity for in-car humidity control. If ambient air temperature or in-car humidity is outside certain range, it will turn on A/C to control in-car humidity for preventing in-car fogging. Air conditioner operation depends on ambient temperature and humidity.

**DTC DESCRIPTION** ED9AB2BE

The A/C controller sets DTC B1201 if there is a short circuit in humidity sensor signal harness or the measured frequency value of sensor is less than threshold value(about 6,186Hz)

**DTC DETECTING CONDITION** ED9D02C4

Item	Detecting Condition	Possible cause
DTC Strategy	• Frequency check	<ul style="list-style-type: none"> <li>• Open Circuit in power harness</li> <li>• Short Circuit in signal harnes</li> <li>• Faulty Humidity Sensor</li> <li>• Faulty A/C control unit</li> </ul>
Threshold value	• < 6,186 Hz	
Detecting time	• 10msec	
FAIL SAFE	• Control with the value of 10%	

**SPECIFICATION** E39EABFF

Relative humidity(%)	Frequency(Hz)	Relative humidity(%)	Frequency(Hz)
20	7,100	60	6,600
30	6,976	70	6,468
40	6,853	80	6,330
50	6,728	90	6,186

## HA -96

## HEATING, VENTILATION AND AIR CONDITIONING

MONITOR SCANTOOL DATA E1282110

1. Connect scantool to data link connector(DLC).
2. Engine "ON"
3. Monitor the "Humidity Sensor" Parameter on the Scantool while drying the humidity sensor with a hair drier or heat gun adjusted to a low heat setting.

1.2 CURRENT DATA	
HUMIDITY SENSOR	10 %
HEATER WATER TEMP. SNSR	12.0 °C
IN-CAR TEMP. SENSOR	11.0 °C
AMBIENT AIR TEMP. SNS	11.5 °C
EVAPORATIVE SENSOR	12.5 °C
DRIVER PHOTO SENSOR	0.00 V
AIR MIX POENTIO. (DR.)	91.75 %
DIRECTION POTENIO. DR.	89.79 %

Fig. 1

Fig 1 : The current data in abnormal state.

1.1 DIAGNOSTIC TROUBLE CODES	
B1201 HUMIDITY SENSOR - SHORT(LOW)	
NUMBER OF DTC : 1 ITEMS	

Fig. 2

Fig 2 : DTC B1201.

4. Are the DTC B1201 present and is parameter of "Humidity Sensor" fixed?  
 ※ Parameter of "Humidity Sensor" will be fixed at 10%, if there is any fault in Humidity Sensor.

**YES**

Go to "Inspection" procedure.

**NO**

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION E46CEF9E

1. Many malfunctions in the electrical system are caused by poor harness and terminals.  
 Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

**YES**

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -97


**NO**

Go to "Signal circuit inspection" procedure.

**SIGNAL CIRCUIT INSPECTION** ECC3D1A0

1. Check for short to ground in harness.
  - 1) Ignition "OFF"
  - 2) Disconnect Humidity Sensor.
  - 3) Measure resistance between terminal "3" of Humidity Sensor and chassis ground.

Specification : Approx.  $\infty \Omega$



1. Motor(-)
2. Sensor ground
3. Humidity sensor signal
4. In-car sensor temp. signal
5. Sensor power (5V)
6. Motor(+)



- 4) Is the measured resistance within specifications?

**YES**

Go to "Power circuit Inspection " procedure.


**NO**

Check for short to ground in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

**POWER SUPPLY CIRCUIT INSPECTION** ED180193

1. Check for open in power harness.
  - 1) Ignition "ON"
  - 2) Disconnect Humidity Sensor.
  - 3) Measure voltage value between terminal "5" of Humidity Sensor and chassis ground.

Specification : 5V



1. Motor(-)
2. Sensor ground
3. Humidity sensor signal
4. In-car sensor temp. signal
5. **Sensor power (5V)**
6. Motor(+)

EQBF511C

4) Is the measured voltage within specifications?

**YES**

Go to "Component Inspection " procedure.


**NO**

Check for open in power harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

**COMPONENT INSPECTION** E21ABF1E

1. Check Humidity Sensor.
  - 1) Engine "ON"
  - 2) Connect Humidity Sensor.
  - 3) Measure Frequency between terminal "3" and "2" of Humidity sensor while increasing humidity.

Specification : Refer the specifications in fig 5.



1. Motor(-)
2. **Sensor ground**
3. **Humidity sensor signal**
4. In-car sensor temp. signal
5. Sensor power (5V)
6. Motor(+)

EQBF510E

BLOWER AND A/C CONTROLS (AUTOMATIC)

HA -99




Fig. 3

Fig 3 : Signal waveform of Humidity sensor.




Fig. 4

Fig 4 : Frequency of Humidity sensor Measured by scantool.

EQBF510F

4) Is the measured frequency within specifications in fig 5? (tolerance limits  $\pm 5\%$ )

**YES**

Go to "Check A/C Control Unit" procedure.

**NO**


Substitute with a known-good Humidity sensor and check for proper operation.

If the problem is corrected, replace Humidity sensor and then go to "Verification of Vehicle Repair" procedure.

2. Check A/C Control Unit

- 1) Engine "ON"
- 2) Disconnect Humidity Sensor.
- 3) Measure voltage value between terminal "4" of A/C control unit and chassis ground.

Specification : 5V



4. Humidity sensor signal

EQBF510G

4) Is the measured voltage within specification?

**YES**

## HA -100

## HEATING, VENTILATION AND AIR CONDITIONING

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO**

Substitute with a known-good A/C Control Unit and check for proper operation.

If the problem is corrected, replace A/C Control Unit and then go to "Verification of Vehicle Repair" procedure.

**VERIFICATION OF VEHICLE REPAIR** ECEB8038

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
2. Operate the vehicle and monitor the DTC on the scantool.
3. Are any DTCs present?

**YES**

Go to the applicable troubleshooting procedure.

**NO**

System is performing to specification at this time.

دیجیتال خودرو  
شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -101

**DTC B1202 WATER TEMPERATURE SENSOR OPEN (HIGH)**

**COMPONENT LOCATION** ECDA84B4



EQBF512A

**GENERAL DESCRIPTION** E79C5561

A water temp. sensor located at heater unit, detects coolant temperature. Its signal is used for cold engine lockout control. When the driver operates the heater before the engine is warmed up, the signal from sensor causes the heater control unit to reduce blower motor speed until coolant temperature reaches the threshold value.

**DTC DESCRIPTION** EFAC8202

The A/C controller sets DTC B1202 if there is an open circuit in water temp. sensor signal harness or the measured resistance value of the sensor is more than the threshold value(about 176.3kΩ )

**DTC DETECTING CONDITION** EDDA37B8

Item	Detecting Condition	Possible cause
DTC Strategy	• Resistance check	<ul style="list-style-type: none"> <li>• Open Circuit in harness</li> <li>• Faulty water temp. Sensor</li> <li>• Faulty A/C control unit</li> </ul>
Threshold value	• > 176.3 kΩ	
Detecting time	• 0.3 sec	
FAIL SAFE	• Control with the value of -2°C(28.4°F)	

**SPECIFICATION** EEDFF0BB

Temperature[°C(°F)]	Resistance(kΩ )	Temperature[°C(°F)]	Resistance(kΩ )
-30(-22)	176.3	25(77)	10
-15(5)	73.6	35(95)	6.5
0(32)	32.9	60(140)	2.5
15(59)	15.8	80(176)	1.2

## HA -102

## HEATING, VENTILATION AND AIR CONDITIONING

MONITOR SCANTOOL DATA E23A4490

1. Connect scantool to data link connector(DLC).
2. Engine "ON"
3. Monitor the "WATER TEMP. SENSOR" Parameter on the Scantool.

1.2 CURRENT DATA	
HEATER WATER TEMP. SNSR	-2 °C
IN-CAR TEMP. SENSOR	12.0 °C
AMBIENT AIR TEMP. SNS	11.5 °C
EVAPORATIVE SENSOR	12.5 °C
DRIVER PHOTO SENSOR	0.00 V
AIR MIX POENTIO. (DR.)	91.75 %
DIRECTION POTENIO. DR.	54.89 %
PASSENGER PHOTO SENSOR	255

Fig. 1

Fig 1 : The current data in abnormal state.

1.1 DIAGNOSTIC TROUBLE CODES	
B1202 WATER TEMP. SENS - OPEN(HIGH)	
NUMBER OF DTC : 1 ITEMS	
PART	ERAS
HELP	

Fig. 2

Fig 2 : DTC B1202.

4. Are the DTC B1202 present and is parameter of "WATER TEMP. SENSOR" fixed?  
 ※ Parameter of "WATER TEMP. SENSOR" will be fixed at -2°C (28.4°F), if there is any fault in WATER TEMP. SENSOR.

**YES**

Go to "Inspection" procedure.

**NO**

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION EC92E599

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

**YES**

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -103

**NO**

Go to "Signal circuit inspection" procedure.

**SIGNAL CIRCUIT INSPECTION** EE5CF56F

1. Check for open in harness.
  - 1) Ignition "OFF"
  - 2) Disconnect water temp. sensor.
  - 3) Measure resistance between terminal "1" of water temp. sensor and terminal "7" of A/C Control Unit.

Specification : Approx. 0 Ω



EQBF512C

- 4) Is the measured resistance within specifications?

**YES**

Go to "Ground circuit Inspection " procedure.


**NO**

Check for open in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

**GROUND CIRCUIT INSPECTION** E20A6934

1. Check for open in ground harness.
  - 1) Ignition "OFF"
  - 2) Disconnect water temp. sensor.
  - 3) Measure resistance between terminal "2" of water temp. sensor and chassis ground.

Specification : Approx. 0 Ω



1. Water temp. sensor signal
2. Sensor ground

EQBF512D

- 4) Is the measured resistance within specifications?

**YES**

Go to "Component Inspection " procedure.

**NO**


Check for open in ground harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

## COMPONENT INSPECTION E8B1ACAD

1. Check water temp. sensor.

- 1) Ignition "OFF"
- 2) Disconnect water temp. sensor.
- 3) Measure resistance between terminal "1" and "2" of water temp. sensor.

Specification : Refer the specifications in fig 3.



1. Water temp. sensor signal
2. Sensor ground

EQBF512E

- 4) Is the measured resistance within specifications in fig 3)? (tolerance limits  $\pm 3\%$ )

**YES**

Go to "Check A/C Control Unit" procedure.

**NO**

Substitute with a known-good water temp. sensor and check for proper operation.

If the problem is corrected, replace water temp. sensor and then go to "Verification of Vehicle Repair" procedure.

2. Check A/C Control Unit


**BLOWER AND A/C CONTROLS (AUTOMATIC)****HA -105**

- 1) Engine "ON"
- 2) Disconnect water temp. sensor.
- 3) Measure Voltage between terminal "7" of A/C Control Unit and chassis ground.

---

 Specification : Approx. 5V
 

---



7. Water temp. sensor signal

EQBF512F

- 4) Is the measured voltage within specifications?

**YES**

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO**

Substitute with a known-good A/C Control Unit and check for proper operation.

If the problem is corrected, replace A/C Control Unit and then go to "Verification of Vehicle Repair" procedure.

**VERIFICATION OF VEHICLE REPAIR** E60A09C9

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
2. Operate the vehicle and monitor the DTC on the scantool.
3. Are any DTCs present?

**YES**

Go to the applicable troubleshooting procedure.

**NO**


System is performing to specification at this time.

HA -106

HEATING, VENTILATION AND AIR CONDITIONING

**DTC B1203 WATER TEMPERATURE SENSOR SHORT (LOW)**

**COMPONENT LOCATION** E0E2BC32



EQBF512A

**GENERAL DESCRIPTION** EFE4C535

A water temp. sensor located at heater unit, detects coolant temperature. Its signal is used for cold engine lockout control. When the driver operates the heater before the engine is warmed up, the signal from sensor causes the heater control unit to reduce blower motor speed until coolant temperature reaches the threshold value.

**DTC DESCRIPTION** EA17C85B

The A/C controller sets DTC B1203 if there is a short circuit in water temp. sensor signal harness or the measured resistance value of sensor is less than threshold value(about 1.2kΩ )

**DTC DETECTING CONDITION** EF2E3145

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> <li>Resistance check</li> </ul>	<ul style="list-style-type: none"> <li>Short circuit in harness</li> <li>Faulty water temp. Sensor</li> <li>Faulty A/C control unit</li> </ul>
Threshold value	<ul style="list-style-type: none"> <li>&lt; 1.2 kΩ</li> </ul>	
Detecting time	<ul style="list-style-type: none"> <li>0.3 sec</li> </ul>	
FAIL SAFE	<ul style="list-style-type: none"> <li>Control with the value of -2°C(28.4°F)</li> </ul>	

**SPECIFICATION** E6B0F9BF

Temperature[°C(°F)]	Resistance(kΩ )	Temperature[°C(°F)]	Resistance(kΩ )
-30(-22)	176.3	25(77)	10
-15(5)	73.6	35(95)	6.5
0(32)	32.9	60(140)	2.5
15(59)	15.8	80(176)	1.2

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -107

**MONITOR SCANTOOL DATA** EADCD72B

1. Connect scantool to data link connector(DLC).
2. Engine "ON"
3. Monitor the "WATER TEMP. SENSOR" Parameter on the Scantool.

1.2 CURRENT DATA	
HEATER WATER TEMP. SNSR	-2 °C
IN-CAR TEMP. SENSOR	12.0 °C
AMBIENT AIR TEMP. SNS	11.5 °C
EVAPORATIVE SENSOR	12.5 °C
DRIVER PHOTO SENSOR	0.00 V
AIR MIX POENTIO. (DR.)	91.75 %
DIRECTION POTENIO. DR.	54.89 %
PASSENGER PHOTO SENSOR	255

Fig. 1

Fig 1 : The current data in abnormal state.

1.1 DIAGNOSTIC TROUBLE CODES	
B1203 WATER TEMP. SENS - SHORT(LOW)	
NUMBER OF DTC : 1 ITEMS	

Fig. 2

Fig 2 : DTC B1203.

4. Are the DTC B1203 present and is parameter of "WATER TEMP. SENSOR" fixed?  
 ※ Parameter of "WATER TEMP. SENSOR" will be fixed at -2°C (28.4°F), if there is any fault in WATER TEMP. SENSOR.

**YES**

Go to "Inspection" procedure.

**NO**

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**TERMINAL AND CONNECTOR INSPECTION** E4A5AB7F

1. Many malfunctions in the electrical system are caused by poor harness and terminals.  
 Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

**YES**

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

HA -108

HEATING, VENTILATION AND AIR CONDITIONING


**NO**

Go to "Signal circuit inspection" procedure.

**SIGNAL CIRCUIT INSPECTION** E5290ACF

1. Check for short to ground in harness.
  - 1) Ignition "OFF"
  - 2) Disconnect water temp. sensor.
  - 3) Measure resistance between terminal "1" of water temp. sensor and chassis ground.

Specification : Approx.  $\infty \Omega$



1. Water temp. sensor signal

2. Sensor ground

- 4) Is the measured resistance within specifications?

**YES**

اولین سامانه دیجیتال تعمیرکاران خودرو

Go to "Component Inspection" procedure.

**NO**

Check for short to ground in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.


**COMPONENT INSPECTION** E688EEF4

1. Check water temp. sensor.
  - 1) Ignition "OFF"
  - 2) Disconnect water temp. sensor.
  - 3) Measure resistance between terminal "1" and "2" of water temp. sensor.

Specification : Refer the specifications in fig 3.

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

**HA -109**



- 1. Water temp. sensor signal
- 2. Sensor ground

EQBF512E

4) Is the measured resistance within specifications in fig 3)? (tolerance limits  $\pm 3\%$ )

**YES**

Go to "Check A/C Control Unit" procedure.

**NO**

Substitute with a known-good water temp. sensor and check for proper operation.

If the problem is corrected, replace water temp. sensor and then go to "Verification of Vehicle Repair" procedure.


2. Check A/C Control Unit

1) Engine "ON"

2) Disconnect water temp. sensor.

3) Measure Voltage between terminal "7" of A/C Control Unit and chassis ground.

Specification : Approx. 5V



- 7. Water temp. sensor signal

EQBF512F

4) Is the measured voltage within specifications?

**YES**

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO**

Substitute with a known-good A/C Control Unit and check for proper operation.

If the problem is corrected, replace A/C Control Unit and then go to "Verification of Vehicle Repair" procedure.

## HA -110

## HEATING, VENTILATION AND AIR CONDITIONING

VERIFICATION OF VEHICLE REPAIR ED6AB445

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
2. Operate the vehicle and monitor the DTC on the scantool.
3. Are any DTCs present?

**YES**

Go to the applicable troubleshooting procedure.

**NO**

System is performing to specification at this time.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -111

**DTC B1204 AIR MIX POTENTIOMETER OPEN (LOW) - PASSENGER'S**

**COMPONENT LOCATION** ECDA6CAE



EQBF521A

**GENERAL DESCRIPTION** E6FDAF92

Temperature control actuator located at heater unit, regulates the temperature by the procedure as follows. Signal from control unit adjusts position of temp. door by operating temp. motor and then temperature will be regulated by the hot/cold air ratio decided by position of temp. door.

**DTC DESCRIPTION** E4F166A6

The A/C controller sets DTC B1204 if there is an open circuit or poor connection in the air mix potentiometer.


**DTC DETECTING CONDITION** E8DA37FC

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> <li>Voltage check</li> </ul>	<ul style="list-style-type: none"> <li>Poor connection of connected part</li> <li>Open circuit in harness</li> <li>Short circuit in harness</li> <li>Faulty driver Air Mix potentiometer</li> </ul>
Threshold value	<ul style="list-style-type: none"> <li>&lt; 0.1V</li> </ul>	
Detecting time	<ul style="list-style-type: none"> <li>0.3 sec</li> </ul>	
FAIL SAFE	<ul style="list-style-type: none"> <li>If temperature setting 17~24.5°C(63~76°F) fix at max. cooling position.</li> <li>If temperature setting 25~32°C(77~90°F) fix at max. heating position.</li> </ul>	

HA -112

HEATING, VENTILATION AND AIR CONDITIONING

SPECIFICATION E927FFAF



EQBF521B

MONITOR SCANTOOL DATA EF8DAA6E

1. Connect scantool to Data Link Connector(DLC).
2. Engine "ON"
3. Monitor the "Passenger's Air Mix Potentiometer" Parameter on the Scantool while operating temp. switch.

1.2 CURRENT DATA	
HEATER WATER TEMP.SNSR	13.0 °C ▲
IN-CAR TEMP.SENSOR	12.0 °C
AMBIENT AIR TEMP.SNS	12.0 °C
EVAPORATIVE SENSOR	12.5 °C ■
DRIVER PHOTO SENSOR	0.00 V
<b>AIR MIX POPENRIO.(PA.)</b>	<b>5.9 %</b>
DIRECTION POTENIO.DR.	90.18 %
PASSENGER PHOTO SENSOR	255 ▼

FIX | SCRN | FULL | PART | GRPH | HELP

Fig. 1

Fig 1 : The current data in abnormal state.

1.1 DIAGNOSTIC TROUBLE CODES	
<b>B1204 AIR MIX P. - LOW INPUT</b>	
NUMBER OF DTC : 1 ITEMS	

PART | ERAS | HELP

Fig. 2

Fig 2 : DTC B1204.

EQBF521K

4. Are the DTC B1204 present and is parameter of "Passenger's Air Mix Potentiometer" fixed?
  - ※ Parameter of "Passenger's Air Mix Potentiometer" will be fixed at 100%(or any value above 90%), or 0% (or any value below 10%), if there is any fault in Passenger's Air Mix potentiometer.

**YES**

Go to "Inspection" procedure.

**NO**

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

**HA -113**

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**TERMINAL AND CONNECTOR INSPECTION** E27080F9

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

**YES**

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

**NO**


Go to "Signal circuit inspection" procedure.

**SIGNAL CIRCUIT INSPECTION** EEC01ECA

1. Check for open in harness.
  - 1) Ignition "OFF"
  - 2) Disconnect Passenger's Air Mix potentiometer.
  - 3) Measure resistance between terminal "6" of Passenger's Air Mix Potentiometer and terminal "18" of A/C control unit.



Specification : Approx. 0 Ω



3. Motor
4. Motor
5. Potentiometer ground
- 6. Potentiometer signal**
7. Sensor reference voltage(+5V)

EQBF521L

- 4) Is the measured resistance within specifications?

**YES**

Go to "Check for short to ground in harness" procedure.

## HA -114

## HEATING, VENTILATION AND AIR CONDITIONING


**NO**

Check for open in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

2. Check for short to ground in harness.

- 1) Ignition "OFF"
- 2) Disconnect Passenger's Air Mix potentiometer.
- 3) Measure resistance between terminal "6" of Passenger's Air Mix Potentiometer and chassis ground.

Specification : Approx.  $\infty \Omega$



3. Motor
4. Motor
5. Potentiometer ground
- 6. Potentiometer signal**
7. Sensor reference voltage(+5V)

4) Is the measured resistance within specifications?

**YES**

Go to "Power circuit Inspection" procedure.

**NO**

Check for short to ground in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

**POWER SUPPLY CIRCUIT INSPECTION** EED3C936


1. Check for short or open in harness.

- 1) Ignition "ON"
- 2) Connect Passenger's Air Mix Potentiometer.
- 3) Measure voltage between terminal "7" of Passenger's Air Mix Potentiometer and chassis ground.

Specification : Approx. 5V

BLOWER AND A/C CONTROLS (AUTOMATIC)

HA -115



- 3. Motor
- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQBF521N

4) Is the measured voltage within specifications?

**YES**

Go to "Component inspection" procedure.

**NO**

Check for short or open in power harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION

E3EE5ADD


1. Check actuator motor.

1) Ignition "OFF"

2) Disconnect Passenger's Air Mix Potentiometer.

3) Verify that the temperature actuator operates to the hot position when connecting 12V to the terminal "3" and grounding terminal "4".

4) Verify that the temperature actuator operates to the cool position when the connections are reversed.



- 3. Motor
- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQBF521O

5) Does the actuator work properly?

**YES**

Go to "Check potentiometer" procedure.

**NO**

Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.


2. Check potentiometer

HA -116

HEATING, VENTILATION AND AIR CONDITIONING

- 1) Ignition "ON"
- 2) Connect Passenger's Air Mix potentiometer.
- 3) Measure voltage between terminal "5" and "6" of Passenger's Air Mix potentiometer while operating the temp. switch.

Specification : Refer the specifications in fig 3)



- 3. Motor
- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQBF521P

Door position	Voltage (3-4)	Error detecting
MAX. Cooling	0.3 ± 0.15V	Low voltage : 0.08V or less
MAX. Heating	4.7 ± 0.15V	High voltage : 4.9V or more



Fig. 3

Fig 3) Specifications : Voltage value of air mix potentiometer as a function of position of setting temperature.

EQBF521J

- 4) Is the measured voltage within specifications in fig3?

**YES**

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO**

Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -117

**VERIFICATION OF VEHICLE REPAIR** E960BEB

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
2. Operate the vehicle and monitor the DTC on the scantool.
3. Are any DTCs present?

**YES**

Go to the applicable troubleshooting procedure.

**NO**

System is performing to specification at this time.

# دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




HA -118

HEATING, VENTILATION AND AIR CONDITIONING

**DTC B1205 AIR MIX POTENTIOMETER SHORT (HIGH) - PASSENGER'S**

**COMPONENT LOCATION** E3CE4D5C



EQBF521A

**GENERAL DESCRIPTION** EBBBA148

Temperature control actuator located at heater unit, regulates the temperature by the procedure as follows. Signal from control unit adjusts position of temp. door by operating temp. motor and then temperature will be regulated by the hot/cold air ratio decided by position of temp. door.

**DTC DESCRIPTION** EEFEA86B

The A/C controller sets DTC B1205 if there is a short to power in the air mix potentiometer.


**DTC DETECTING CONDITION** E0C85E40

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> <li>Voltage check</li> </ul>	<ul style="list-style-type: none"> <li>Short circuit in harness</li> <li>Faulty driver Air Mix potentiometer</li> </ul>
Threshold value	<ul style="list-style-type: none"> <li>&gt; 4.9V</li> </ul>	
Detecting time	<ul style="list-style-type: none"> <li>0.3 sec</li> </ul>	
FAIL SAFE	<ul style="list-style-type: none"> <li>If temperature setting 17~24.5°C(63~76°F) fix at max. cooling position.</li> <li>If temperature setting 25~32°C(77~90°F) fix at max. heating position.</li> </ul>	

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -119

**SPECIFICATION** EE47778F



EQBF521B

**MONITOR SCANTOOL DATA** E7CFD25C

1. Connect scantool to Data Link Connector(DLC).
2. Engine "ON"
3. Monitor the "Passenger's Air Mix Potentiometer" Parameter on the Scantool while operating temp. switch.

1.2 CURRENT DATA	
HEATER WATER TEMP.SNSR	13.0 °C ▲
IN-CAR TEMP.SENSOR	12.0 °C
AMBIENT AIR TEMP.SNS	12.0 °C
EVAPORATIVE SENSOR	12.5 °C ■
DRIVER PHOTO SENSOR	0.00 V
<b>AIR MIX POPENATIO.(PA.)</b>	<b>91.75 %</b>
DIRECTION POTENIO.DR.	90.18 %
PASSENGER PHOTO SENSOR	255 ▼

FIX | SCRN | FULL | PART | GRPH | HELP

Fig. 1

1.1 DIAGNOSTIC TROUBLE CODES	
<b>B1205 AIR MIX P. - HIGH INPUT</b>	
NUMBER OF DTC : 1 ITEMS	
PART	ERAS
HELP	

Fig. 2

Fig 1 : The current data in abnormal state.  
 Fig 2 : DTC B1205.

EQBF522F

4. Are the DTC B1205 present and is parameter of "Passenger's Air Mix potentiometer" fixed?  
 ※ Parameter of "Passenger's Air Mix potentiometer" will be fixed at 100%(or any value above 90%), or 0% (or any value below 10%), if there is any fault in Passenger's Air Mix potentiometer.

**YES**

Go to "Inspection" procedure.

**NO**

## HA -120

## HEATING, VENTILATION AND AIR CONDITIONING

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION E283B9EA

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

**YES**

Repair as necessary and go to "Verification of Vehicle Repair" procedure.


**NO**

Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION E5E91EAA

1. Check for short in harness.
  - 1) Ignition "OFF"
  - 2) Disconnect Passenger's Air Mix potentiometer.
  - 3) Measure resistance between terminal "6" and "7" of Passenger's Air Mix potentiometer.

Specification : Approx.  $\infty \Omega$



3. Motor
4. Motor
5. Potentiometer ground
6. Potentiometer signal
7. Sensor reference voltage(+5V)

EQBF522G

- 4) Is the measured resistance within specifications?

**YES**

Go to "Ground circuit Inspection" procedure.

**NO**

Check for short to power harness in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.


**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -121

**GROUND CIRCUIT INSPECTION** EE38C85A

1. Check for open in harness.
  - 1) Ignition "OFF"
  - 2) Disconnect Passenger's Air Mix Potentiometer.
  - 3) Measure resistance between terminal "5" of Passenger's Air Mix Potentiometer and chassis ground.

Specification : Approx. 0 Ω



3. Motor
4. Motor
5. Potentiometer ground
6. Potentiometer signal
7. Sensor reference voltage(+5V)

EQBF522H

- 4) Is the measured resistance within specifications?

**YES**

Go to "Component Inspection" procedure.


**NO**

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Check for open in ground harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

**COMPONENT INSPECTION** EE9D88DB

1. Check actuator motor.
  - 1) Ignition "OFF"
  - 2) Disconnect Passenger's Air Mix Potentiometer.
  - 3) Verify that the temperature actuator operates to the hot position when connecting 12V to the terminal "3" and grounding terminal "4".
  - 4) Verify that the temperature actuator operates to the cool position when the connections are reversed.



3. Motor
4. Motor
5. Potentiometer ground
6. Potentiometer signal
7. Sensor reference voltage(+5V)

EQBF521O

- 5) Does the actuator work properly?

HA -122

HEATING, VENTILATION AND AIR CONDITIONING

**YES**

Go to "Check potentiometer" procedure.


**NO**

Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

2. Check potentiometer

- 1) Ignition "ON"
- 2) Connect Passenger's Air Mix potentiometer.
- 3) Measure voltage between terminal "5" and "6" of Passenger's Air Mix potentiometer while operating the temp. switch.

Specification : Refer the specifications in fig 3)




3. Motor
4. Motor
5. Potentiometer ground
6. Potentiometer signal
7. Sensor reference voltage(+5V)

شرکت دیجیتال خودرو سامانه (مبولیت محدود)  
اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

EQBF521P

Door position	Voltage (3-4)	Error detecting
MAX. Cooling	0.3 ± 0.15V	Low voltage : 0.08V or less
MAX. Heating	4.7 ± 0.15V	High voltage : 4.9V or more



**Fig. 3**

Fig 3) Specifications : Voltage value of air mix potentiometer as a function of position of setting temperature.

EQBF521J

- 4) Is the measured voltage within specifications in fig3?

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -123

**YES**

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO**

Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

**VERIFICATION OF VEHICLE REPAIR** ECF5DABA

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
2. Operate the vehicle and monitor the DTC on the scantool.
3. Are any DTCs present?

**YES**

Go to the applicable troubleshooting procedure.

**NO**

System is performing to specification at this time.



دیجیتال خودرو  
شرکت دیجیتال خودرو سامانه (مسئولیت محدود)


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

HA -124

HEATING, VENTILATION AND AIR CONDITIONING

**DTC B1208 INTAKE POTENTIOMETER OPEN**

**COMPONENT LOCATION** EF749215



EQBF527A

**GENERAL DESCRIPTION** EA50D8D5

Intake door located at heater unit controls the inlet of car. When driver operates the intake switch, A/C controller recirculation receives mode signal from intake switch and operates intake door actuator to turn intake door to intended position. (with fresh mode signal, intake door is closed and with fresh mode signal, intake door is opened).

**DTC DESCRIPTION** E6782025

The A/C controller sets DTC B1208 if there is an open circuit or poor connection in the intake potentiometer.

**DTC DETECTING CONDITION** E0CD3E1C

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> <li>Voltage check</li> </ul>	<ul style="list-style-type: none"> <li>Poor connection of connected part</li> <li>Open circuit in harness</li> <li>Short circuit in harness</li> <li>Faulty driver intake potentiometer</li> </ul>
Threshold value	<ul style="list-style-type: none"> <li>&lt; 0.1V</li> </ul>	
Detecting time	<ul style="list-style-type: none"> <li>0.3 sec</li> </ul>	
FAIL SAFE	<ul style="list-style-type: none"> <li>If temperature setting 17~24.5°C(63~76°F) fix at max. cooling position.</li> <li>Fix at fresh</li> </ul>	

**SPECIFICATION** E6D66101

※ Voltage value of Intake potentiometer as a function of position of Intake door

Door position	Voltage	Threshold value
Fresh	0.3±0.15V	Voltage value &< 0.08V
Recirculation	4.7±0.15V	Voltage value &> 4.9V

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -125

**MONITOR SCANTOOL DATA** EBF0EE9F

1. Connect scantool to Data Link Connector(DLC).
2. Engine "ON"
3. Monitor the "Intake Potentiometer" Parameter on the Scantool while operating intake switch.

1.2 CURRENT DATA	
HEATER WATER TEMP.SNSR	14.0 °C
IN-CAR TEMP.SENSOR	12.0 °C
AMBIENT AIR TEMP.SNS	12.0 °C
EVAPORATIVE SENSOR	13.0 °C
DRIVER PHOTO SENSOR	0.00 V
AIR MIX POPENATIO.(DR.)	84.69 %
DIRECTION POTENIO.DR.	51.76 %
PASSENGER PHOTO SENSOR	255
<b>INTAKE SENSOR</b>	<b>6.3 %</b>

Fig. 1

Fig 1 : The current data in abnormal state.

Fig 2 : DTC B1208.

1.1 DIAGNOSTIC TROUBLE CODES	
<b>B1208 INTAKE P. - LOW INPUT</b>	
NUMBER OF DTC : 1 ITEMS	

Fig. 2

4. Are the DTC B1208 present and is parameter of "Intake Potentiometer" fixed?  
 ※ Parameter of "Intake Potentiometer" will be fixed at 100%(or any value above 90%), or 0% (or any value below 10%), if there is any fault in Intake potentiometer.

**YES**

Go to "Inspection" procedure.

**NO**

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**TERMINAL AND CONNECTOR INSPECTION** E0353933

1. Many malfunctions in the electrical system are caused by poor harness and terminals.  
Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

**YES**

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

HA -126

HEATING, VENTILATION AND AIR CONDITIONING

**NO**


Go to "Signal circuit inspection" procedure.

**SIGNAL CIRCUIT INSPECTION** E9A2AB82



1. Check for open in harness.
  - 1) Ignition "OFF"
  - 2) Disconnect Intake potentiometer.
  - 3) Measure resistance between terminal "6" of Intake Potentiometer and terminal "24" of A/C control unit.

Specification : Approx. 0 Ω

[LHD]




3. Motor
4. Motor
5. Potentiometer ground
- 6. Potentiometer signal**
7. Sensor reference voltage(+5V)




EQBF827D

[RHD]



3. Motor
4. Motor
5. Sensor reference voltage(+5V)
- 6. Potentiometer signal**
7. Potentiometer ground



EQBF827D

- 4) Is the measured resistance within specifications?

**YES**

Go to "Check for short to ground in harness" procedure.

**NO**

Check for open in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

2. Check for short to ground in harness.

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -127


- 1) Ignition "OFF"
- 2) Disconnect Intake potentiometer.
- 3) Measure resistance between terminal "6" of Intake Potentiometer and chassis ground.

---

 Specification : Approx.  $\infty \Omega$ 


---


[LHD]



3. Motor
4. Motor
5. Potentiometer ground
6. Potentiometer signal
7. Sensor reference voltage(+5V)

EQBF827E

[RHD]



3. Motor
4. Motor
5. Sensor reference voltage(+5V)
6. Potentiometer signal
7. Potentiometer ground

EQBF927E

4) اولین سامانه؟ آیا مقاومت اندازه گیری شده در محدوده مشخصات است؟

**YES**

Go to "Power circuit Inspection" procedure.

**NO**

Check for short to ground in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

**POWER SUPPLY CIRCUIT INSPECTION**

E638022A

1. Check for short or open in harness.
  - 1) Ignition "ON"
  - 2) Connect Intake Potentiometer.
  - 3) Measure voltage between terminal "7"(RHD:5) of Intake Potentiometer and chassis ground.

---


 Specification : Approx. 5V
 

---

HA -128

HEATING, VENTILATION AND AIR CONDITIONING


[LHD]



- 3. Motor
- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQBF827F

[RHD]



- 3. Motor
- 4. Motor
- 5. Sensor reference voltage(+5V)
- 6. Potentiometer signal
- 7. Potentiometer ground

EQBF927F

4) Is the measured voltage within specifications?

**YES**

Go to "Component inspection" procedure.

**NO**


Check for short or open in power harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

**COMPONENT INSPECTION** E4DCDE12

1. Check actuator motor.

- 1) Ignition "OFF"
- 2) Disconnect Intake Potentiometer.
- 3) Verify that the temperature actuator operates to the fresh position when connecting 12V to the terminal "3"(RHD:4) and grounding terminal "4"(RHD:3).
- 4) Verify that the temperature actuator operates to the recirculation position when the connections are reversed.

[LHD]




- 3. Motor
- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQBF827H

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -129

[RHD]



- 3. Motor
- 4. Motor
- 5. Sensor reference voltage(+5V)
- 6. Potentiometer signal
- 7. Potentiometer ground

EQBF927H

5) Does the actuator work properly?

**YES**

Go to "Check potentiometer" procedure.

**NO**


Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

2. Check potentiometer

- 1) Ignition "ON"
- 2) Connect Intake potentiometer.
- 3) Measure voltage between terminal "5"(RHD:7) and "6" of Intake potentiometer while operating Intake switch.

Specification : Refer to the specifications


[LHD]



- 3. Motor
- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQBF827I

[RHD]



- 3. Motor
- 4. Motor
- 5. Sensor reference voltage(+5V)
- 6. Potentiometer signal
- 7. Potentiometer ground

EQBF927I

Door position	Voltage (5-6)	Error detecting
Fresh	0.3 ± 0.15V	Low voltage : 0.08V or less
Recirculation	4.7 ± 0.15V	High voltage : 4.9V or more

## HA -130

## HEATING, VENTILATION AND AIR CONDITIONING

Specifications : Voltage value of Intake potentiometer as a function of position of Intake.

- 4) Is the measured voltage within specifications?

**YES**

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO**

Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

**VERIFICATION OF VEHICLE REPAIR** E5797203

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
2. Operate the vehicle and monitor the DTC on the scantool.
3. Are any DTCs present?

**YES**

Go to the applicable troubleshooting procedure.

**NO**

System is performing to specification at this time.




**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -131

**DTC B1209 INTAKE POTENTIOMETER SHORT**

**COMPONENT LOCATION** E093235F



EQBF527A

**GENERAL DESCRIPTION** EE9BD028

Intake door located at heater unit controls the inlet of car. When driver operates the intake switch, A/C controller recirculation receives mode signal from intake switch and operates intake door actuator to turn intake door to intended position. (with fresh mode signal, intake door is closed and with fresh mode signal, intake door is opened).

**DTC DESCRIPTION** E2770B43

The A/C controller sets DTC B1209 if there is a short to power in the Intake potentiometer.

**DTC DETECTING CONDITION** EEE85217

Item	Detecting Condition	Possible cause
DTC Strategy	• Voltage check	<ul style="list-style-type: none"> <li>• Short circuit in harness</li> <li>• Faulty Intake potentiometer</li> <li>• Open circuit in harness</li> </ul>
Threshold value	• > 4.9V	
Detecting time	• 0.3 sec	
FAIL SAFE	• Fix at fresh	

**SPECIFICATION** E39D5040

※ Voltage value of Intake potentiometer as a function of position of Intake door

Door position	Voltage	Threshold value
Fresh	0.3 ± 0.15V	Voltage value & < 0.08V
Recirculation	4.7 ± 0.15V	Voltage value & > 4.9V

## HA -132

## HEATING, VENTILATION AND AIR CONDITIONING

MONITOR SCANTOOL DATA E43084A0

1. Connect scantool to Data Link Connector(DLC).
2. Engine "ON"
3. Monitor the "Intake Potentiometer" Parameter on the Scantool while operating Intake switch.

1.2 CURRENT DATA	
HEATER WATER TEMP.SNSR	14.0 °C
IN-CAR TEMP.SENSOR	12.0 °C
AMBIENT AIR TEMP.SNS	12.0 °C
EVAPORATIVE SENSOR	13.0 °C
DRIVER PHOTO SENSOR	0.00 V
AIR MIX POPENIO.(DR.)	84.69 %
DIRECTION POTENIO.DR.	51.76 %
PASSENGER PHOTO SENSOR	255
<b>INTAKE SENSOR</b>	<b>100.0 %</b>

Fig. 1

Fig 1 : The current data in abnormal state.

Fig 2 : DTC B1209.

1.1 DIAGNOSTIC TROUBLE CODES	
<b>B1209 INTAKE P. - HIGH INPUT</b>	
NUMBER OF DTC : 1 ITEMS	

Fig. 2

4. Are the DTC B1209 present and is parameter of "Intake potentiometer" fixed?  
 ※ Parameter of "Intake potentiometer" will be fixed at 100%(or any value above 90%), or 0% (or any value below 10%), if there is any fault in Intake potentiometer.

**YES**

Go to "Inspection" procedure.

**NO**

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION E38A07A2

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

**YES**

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

## BLOWER AND A/C CONTROLS (AUTOMATIC)

HA -133

**NO**


Go to "Signal circuit inspection" procedure.

**SIGNAL CIRCUIT INSPECTION** E7CCC554

1. Check for short in harness.
  - 1) Ignition "OFF"
  - 2) Disconnect Intake potentiometer.
  - 3) Measure resistance between terminal "6" and "7"(RHD:5) of Intake potentiometer.


Specification : Approx.  $\infty \Omega$

[LHD]



3. Motor
4. Motor
5. Potentiometer ground
6. Potentiometer signal
7. Sensor reference voltage(+5V)

[RHD]



3. Motor
4. Motor
5. Sensor reference voltage(+5V)
6. Potentiometer signal
7. Potentiometer ground

EQBF828B

EQBF928B

- 4) Is the measured resistance within specifications?

**YES**

Go to "Ground circuit Inspection" procedure.

**NO**

Check for short to power harness in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

**GROUND CIRCUIT INSPECTION** E226B4E7


1. Check for open in harness.
  - 1) Ignition "OFF"
  - 2) Disconnect Intake Potentiometer.
  - 3) Measure resistance between terminal "5"(RHD:7) of Intake Potentiometer and chassis ground.

## HA -134

## HEATING, VENTILATION AND AIR CONDITIONING

Specification : Approx. 0 Ω


[LHD]



- 3. Motor
- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQBF827G

[RHD]



- 3. Motor
- 4. Motor
- 5. Sensor reference voltage(+5V)
- 6. Potentiometer signal
- 7. Potentiometer ground

EQBF927G

4) Is the measured resistance within specifications?

**YES**

Go to "Component Inspection" procedure.

**NO**

Check for open in ground harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

## COMPONENT INSPECTION


EF55F62B

1. Check actuator motor.
  - 1) Ignition "OFF"
  - 2) Disconnect Intake Potentiometer.
  - 3) Verify that the temperature actuator operates to the fresh position when connecting 12V to the terminal "3"(RHD:4) and grounding terminal "4"(RHD:3).
  - 4) Verify that the temperature actuator operates to the recirculation position when the connections are reversed.

BLOWER AND A/C CONTROLS (AUTOMATIC)

HA -135


[LHD]



- 3. Motor
- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQBF827H

[RHD]



- 3. Motor
- 4. Motor
- 5. Sensor reference voltage(+5V)
- 6. Potentiometer signal
- 7. Potentiometer ground

EQBF827H

5) Does the actuator work properly?

**YES**

Go to "Check potentiometer" procedure.

**NO**


Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

2. Check potentiometer

- 1) Ignition "ON"
- 2) Connect Intake potentiometer.
- 3) Measure voltage between terminal "5"(RHD:7) and "6" of Intake potentiometer while operating Intake switch.

Specification : Refer to the specifications

[LHD]




- 3. Motor
- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQBF827I

## HA -136

## HEATING, VENTILATION AND AIR CONDITIONING

[RHD]



- 3. Motor
- 4. Motor
- 5. Sensor reference voltage(+5V)
- 6. Potentiometer signal
- 7. Potentiometer ground

EQBF9271

Door position	Voltage (5-6)	Error detecting
Fresh	$0.3 \pm 0.15V$	Low voltage : 0.08V or less
Recirculation	$4.7 \pm 0.15V$	High voltage : 4.9V or more

Specifications : Voltage value of Intake potentiometer as a function of position of Intake.

- 4) Is the measured voltage within specifications?

**YES**

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO**

Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

### VERIFICATION OF VEHICLE REPAIR

E43701D1

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
2. Operate the vehicle and monitor the DTC on the scantool.
3. Are any DTCs present?

**YES**

Go to the applicable troubleshooting procedure.

**NO**


System is performing to specification at this time.

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -137

**DTC B1233 IN-CAR TEMPERATURE SENSOR SHORT (LOW)**

**COMPONENT LOCATION** EB57D004



EQBF514E

**GENERAL DESCRIPTION** EC43DDF5

The incar temperature sensor located at crush pad, control unit contains a thermistor which measures the temperature of the inside. The signal, decided by the resistance value which changes in accordance with perceived inside temperature, is delivered to heater control unit and according to this signal, the control unit regulates incar temperature to intended value.

**DTC DESCRIPTION** EB63EFE3

The A/C controller sets DTC B1233 if there is a short circuit in incar temp. sensor signal harness or the measured resistance value of sensor is less than threshold value(about 7.46kΩ )

**DTC DETECTING CONDITION** E1046384

Item	Detecting Condition	Possible cause
DTC Strategy	• Resistance check	<ul style="list-style-type: none"> <li>• Short circuit in harness</li> <li>• Faulty incar temp. Sensor</li> <li>• Faulty A/C control unit</li> </ul>
Threshold value	• < 7.46 kΩ	
Detecting time	• 0.3 sec	
FAIL SAFE	• Control with the value of 25°C(77°F)	

**SPECIFICATION** E4823648

Temperature[°C(°F)]	Resistance(kΩ )	Temperature[°C(°F)]	Resistance(kΩ )
-30(-22)	509.57	25(77)	30
-15(5)	216.07	35(95)	15.59
0(32)	97.71	50(122)	10.81
15(59)	47.13	60(140)	7.46

## HA -138

## HEATING, VENTILATION AND AIR CONDITIONING

MONITOR SCANTOOL DATA E2472961

1. Connect scantool to data link connector(DLC).
2. Engine "ON"
3. Monitor the "INCAR TEMP. SENSOR" Parameter on the Scantool.

1.2 CURRENT DATA	
HEATER WATER TEMP. SNSR	13.0 °C
<b>IN-CAR TEMP. SENSOR</b>	<b>25.0 °C</b>
AMBIENT AIR TEMP. SNS	11.5 °C
EVAPORATIVE SENSOR	12.5 °C
DRIVER PHOTO SENSOR	0.00 V
AIR MIX POPENATIO. (DR.)	75.68 %
DIRECTION POTENIO. DR.	89.79 %
PASSENGER PHOTO SENSOR	255

FIX | SCRN | FULL | PART | GRPH | HELP

Fig. 1

Fig 1 : The current data in abnormal state.

1.1 DIAGNOSTIC TROUBLE CODES	
<b>B1233 IN-CAR TEMP. SNSR LOW</b>	
NUMBER OF DTC : 1 ITEMS	
PART   ERAS   HELP	

Fig. 2

Fig 2 : DTC B1233.

4. Are the DTC B1233 present and is parameter of "INCAR TEMP. SENSOR" fixed?  
 \* Parameter of "INCAR TEMP. SENSOR" will be fixed at 25°C (77°F), if there is any fault in INCAR TEMP. SENSOR.

**YES**

Go to "Inspection" procedure.

**NO**

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION EB821E5B

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

**YES**

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -139


**NO**

Go to "Signal circuit inspection" procedure.

**SIGNAL CIRCUIT INSPECTION** EBF88FB5

1. Check for short to ground in harness.
  - 1) Ignition "OFF"
  - 2) Disconnect incar sensor.
  - 3) Measure resistance between terminal "4" of incar sensor and chassis ground.

Specification : Approx.  $\infty \Omega$



1. Motor(-)
2. Sensor ground
3. Humidity sensor signal
4. In-car sensor temp. signal
5. Sensor power (5V)
6. Motor(+)

- 4) Is the measured resistance within specifications?

**YES**

Go to "Component Inspection" procedure.

**NO**


Check for short to ground in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

**COMPONENT INSPECTION** E6BB9B31

1. Check incar temp. sensor.
  - 1) Ignition "OFF"
  - 2) Disconnect incar sensor.
  - 3) Measure resistance between terminal "4" and "2" of incar sensor.

Specification : Refer the specifications in fig 3.





- 1. Motor(-)
- 2. Sensor ground
- 3. Humidity sensor signal
- 4. In-car sensor temp. signal
- 5. Sensor power (5V)
- 6. Motor(+)

EQBF514F




Fig. 3

Fig 3) Specifications : Resistance value of incar temp. sensor as a function of temperature.

4) Is the measured resistance within specifications in fig3? (tolerance limits  $\pm 3\%$ )

**YES**

Go to "Check A/C Control Unit" procedure.

**NO**

Substitute with a known-good incar sensor and check for proper operation.

If the problem is corrected, replace incar sensor and then go to "Verification of Vehicle Repair" procedure.

2. Check A/C Control Unit


- 1) Engine "ON"
- 2) Disconnect incar sensor.
- 3) Measure Voltage between terminal "5" of A/C Control Unit and chassis ground.

Specification : Approx. 5V

EQBF514G

## BLOWER AND A/C CONTROLS (AUTOMATIC)

HA -141



## 5. Incar sensor temp. signal

EQBF514C

4) Is the measured voltage within specifications?

**YES**

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO**

Substitute with a known-good A/C Control Unit and check for proper operation.

If the problem is corrected, replace A/C Control Unit and then go to "Verification of Vehicle Repair" procedure.

## VERIFICATION OF VEHICLE REPAIR E5F6DCB4

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
2. Operate the vehicle and monitor the DTC on the scantool.
3. Are any DTCs present?

**YES**

Go to the applicable troubleshooting procedure.

**NO**


System is performing to specification at this time.

HA -142

HEATING, VENTILATION AND AIR CONDITIONING

**DTC B1234 IN-CAR TEMPERATURE SENSOR OPEN (HIGH)**

**COMPONENT LOCATION** EE9B6B17



EQBF514E

**GENERAL DESCRIPTION** E9F794B3

The incar temperature sensor located at crush pad, control unit contains a thermistor which measures the temperature of the inside. The signal, decided by the resistance value which changes in accordance with perceived inside temperature, is delivered to heater control unit and according to this signal, the control unit regulates incar temperature to intended value.

**DTC DESCRIPTION** E11DE569

The A/C controller sets DTC B1234 if there is an open circuit in incar temp. sensor signal harness or the measured resistance value of sensor is more than threshold value(about 509.57kΩ )

**DTC DETECTING CONDITION** E854B0E4

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> <li>Resistance check</li> </ul>	<ul style="list-style-type: none"> <li>Open Circuit in harness</li> <li>Faulty incar temp. Sensor</li> <li>Faulty A/C control unit</li> </ul>
Threshold value	<ul style="list-style-type: none"> <li>&gt; 509.57 kΩ</li> </ul>	
Detecting time	<ul style="list-style-type: none"> <li>0.3 sec</li> </ul>	
FAIL SAFE	<ul style="list-style-type: none"> <li>Control with the value of 25°C(77°F)</li> </ul>	

**SPECIFICATION** E1AB1CCB

Temperature[°C(°F)]	Resistance(kΩ )	Temperature[°C(°F)]	Resistance(kΩ )
-30(-22)	509.57	25(77)	30
-15(5)	216.07	35(95)	15.59
0(32)	97.71	50(122)	10.81
15(59)	47.13	60(140)	7.46

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -143

**MONITOR SCANTOOL DATA** E60EDB2F

1. Connect scantool to data link connector(DLC).
2. Engine "ON"
3. Monitor the "INCAR TEMP. SENSOR" Parameter on the Scantool.

1.2 CURRENT DATA	
HEATER WATER TEMP. SNSR	13.0 °C
<b>IN-CAR TEMP. SENSOR</b>	<b>25.0 °C</b>
AMBIENT AIR TEMP. SNS	11.5 °C
EVAPORATIVE SENSOR	12.5 °C
DRIVER PHOTO SENSOR	0.00 V
AIR MIX POPENIO. (DR.)	75.68 %
DIRECTION POTENIO. DR.	89.79 %
PASSENGER PHOTO SENSOR	255

Fig. 1

Fig 1 : The current data in abnormal state.

Fig 2 : DTC B1234.

1.1 DIAGNOSTIC TROUBLE CODES	
<b>B1234 IN-CAR TEMP. SNSR HIGH</b>	
NUMBER OF DTC : 1 ITEMS	

Fig. 2

4. Are the DTC B1234 present and is parameter of "INCAR TEMP. SENSOR" fixed?  
 ※ Parameter of "INCAR TEMP. SENSOR" will be fixed at 25°C (77°F), if there is any fault in INCAR TEMP. SENSOR.

**YES**

Go to "Inspection" procedure.

**NO**

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**TERMINAL AND CONNECTOR INSPECTION** E941866C

1. Many malfunctions in the electrical system are caused by poor harness and terminals.  
 Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

**YES**

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

## HA -144

## HEATING, VENTILATION AND AIR CONDITIONING


**NO**

Go to "Signal circuit inspection" procedure.

**SIGNAL CIRCUIT INSPECTION** E1781154

1. Check for open in harness.
  - 1) Ignition "OFF"
  - 2) Disconnect incar temp. sensor.
  - 3) Measure resistance between terminal "4" of incar temp. sensor and terminal "5" of A/C Control Unit..

Specification : Approx. 0 Ω



1. Motor(-)
2. Sensor ground
3. Humidity sensor signal
4. In-car sensor temp. signal
5. Sensor power (5V)
6. Motor(+)

- 4) Is the measured resistance within specifications?

**YES**

Go to "Ground circuit Inspection " procedure.

**NO**

Check for open in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.


**GROUND CIRCUIT INSPECTION** EF779270

1. Check for open in ground harness.
  - 1) Ignition "OFF"
  - 2) Disconnect incar temp. sensor.
  - 3) Measure resistance between terminal "2" of incar temp. sensor and terminal "12" of A/C Control Unit.

Specification : Approx. 0 Ω

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

**HA -145**



- 1. Motor(-)
- 2. **Sensor ground**
- 3. Humidity sensor signal
- 4. In-car sensor temp. signal
- 5. Sensor power (5V)
- 6. Motor(+)

EQBF515C

4) Is the measured resistance within specifications?

**YES**

Go to "Component Inspection " procedure.

**NO**


Check for open in ground harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

**COMPONENT INSPECTION** EB9720FD

1. Check incar temp. sensor.
  - 1) Ignition "OFF"
  - 2) Disconnect incar sensor.
  - 3) Measure resistance between terminal "4" and "2" of incar sensor.



Specification : Refer the specifications in fig 3.



- 1. Motor(-)
- 2. **Sensor ground**
- 3. Humidity sensor signal
- 4. **In-car sensor temp. signal**
- 5. Sensor power (5V)
- 6. Motor(+)

EQBF514F




Fig. 3

Fig 3) Specifications : Resistance value of incar temp. sensor as a function of temperature.

EQBF514G

4) Is the measured resistance within specifications in fig3? (tolerance limits  $\pm 3\%$ )

**YES**

Go to "Check A/C Control Unit" procedure.

**NO**


Substitute with a known-good incar sensor and check for proper operation.

If the problem is corrected, replace incar sensor and then go to "Verification of Vehicle Repair" procedure.

2. Check A/C Control Unit

- 1) Engine "ON"
- 2) Disconnect incar sensor.
- 3) Measure Voltage between terminal "5" of A/C Control Unit and chassis ground.

Specification : Approx. 5V



5. Incar sensor temp. signal

EQBF514C

4) Is the measured voltage within specifications?

**YES**

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -147

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO**

Substitute with a known-good A/C Control Unit and check for proper operation. If the problem is corrected, replace A/C Control Unit and then go to "Verification of Vehicle Repair" procedure.

**VERIFICATION OF VEHICLE REPAIR** E10F3C2D

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
2. Operate the vehicle and monitor the DTC on the scantool.
3. Are any DTCs present?

**YES**

Go to the applicable troubleshooting procedure.

**NO**

System is performing to specification at this time.

دیجیتال خودرو  
شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




HA -148

HEATING, VENTILATION AND AIR CONDITIONING

**DTC B1237 AMBIENT TEMPERATURE SENSOR SHORT (LOW)**

**COMPONENT LOCATION** ED485BBE



EQBF516A

**GENERAL DESCRIPTION** E2ABCF83

The ambient temperature sensor located at the center stay of the condenser, detects ambient air temperature. It is a negative type thermistor whose resistance is inversely proportional to temperature. Its output is used for discharge temperature sensor, sensor fail-safe, temperature regulation door lock, blower motor level control, mix mode control and in-car humidity control.

**DTC DESCRIPTION** EF007347

The A/C controller sets DTC B1237 if there is a short circuit in ambient temp. sensor signal harness or the measured resistance value of sensor is less than threshold value (about 7.48kΩ )

**DTC DETECTING CONDITION** E76C2039

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> <li>Resistance check</li> </ul>	<ul style="list-style-type: none"> <li>Short circuit in harness</li> <li>Faulty ambient temp. Sensor</li> <li>Faulty A/C control unit</li> </ul>
Threshold value	<ul style="list-style-type: none"> <li>&lt; 7.48kΩ</li> </ul>	
Detecting time	<ul style="list-style-type: none"> <li>0.3 sec</li> </ul>	
FAIL SAFE	<ul style="list-style-type: none"> <li>Control with the value of 20°C(68°F)</li> </ul>	

**SPECIFICATION** EA51C1AC

Temperature[°C(°F)]	Resistance(kΩ )	Temperature[°C(°F)]	Resistance(kΩ )
-30(-22)	527.99	25(77)	30
-15(5)	218.21	35(95)	19.6
0(32)	97.83	50(122)	10.82
15(59)	47.12	60(140)	7.48

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -149

**MONITOR SCANTOOL DATA** E30FCFE7

1. Connect scantool to data link connector(DLC).
2. Engine "ON"
3. Monitor the "AMBIENT TEMP. SENSOR" Parameter on the Scantool.  
\* Parameter of "AMBIENT TEMP. SENSOR" will be fixed at 20°C, if there is any fault in AMBIENT TEMP. SENSOR.

1.2 CURRENT DATA	
HEATER WATER TEMP. SNSR	17.0 °C
IN-CAR TEMP. SENSOR	12.0 °C
<b>AMBIENT AIR TEMP. SNS</b>	<b>20.0 °C</b>
EVAPORATIVE SENSOR	13.0 °C
DRIVER PHOTO SENSOR	0.00 V
AIR MIX POPENIO. (DR.)	91.75 %
DIRECTION POTENIO. DR.	90.18 %
PASSENGER PHOTO SENSOR	255

Fig. 1

Fig 1 : The current data in abnormal state.

1.1 DIAGNOSTIC TROUBLE CODES	
<b>B1237 AMBIENT TEMP. SNSR LOW</b>	
NUMBER OF DTC : 1 ITEMS	

Fig. 2

Fig 2 : DTC B1237.

4. Are the DTC B1237 present and is parameter of "AMBIENT TEMP. SENSOR" fixed?

**YES**

Go to "Inspection" procedure.

**NO**

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**TERMINAL AND CONNECTOR INSPECTION** E20274CA

1. Many malfunctions in the electrical system are caused by poor harness and terminals.  
Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

**YES**

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

## HA -150

## HEATING, VENTILATION AND AIR CONDITIONING


**NO**

Go to "Signal circuit inspection" procedure.

**SIGNAL CIRCUIT INSPECTION** EC50D358

1. Check for short to ground in harness.
  - 1) Ignition "OFF"
  - 2) Disconnect ambient temp. sensor.
  - 3) Measure resistance between terminal "1" of ambient temp. sensor and chassis ground.

Specification : Approx.  $\infty \Omega$



1. Ambient temp. sensor signal(+)
2. Ambient temp. sensor ground
4. AQS signal input
5. AQS ground
6. AQS power



(4) Is the measured resistance within specifications?

**YES**

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران  
Go to "Component Inspection" procedure.

**NO**

Check for short to ground in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.


**COMPONENT INSPECTION** E3B39A1B

1. Check Ambient temp. sensor.
  - 1) Ignition "OFF"
  - 2) Disconnect ambient temp. sensor.
  - 3) Measure resistance between terminal "1" and "2" of ambient temp. sensor.

Specification : Refer the specifications in fig 3.

## BLOWER AND A/C CONTROLS (AUTOMATIC)

HA -151



1. Ambient temp. sensor signal
2. Ambient temp. sensor ground
4. AQS signal input
5. AQS ground
6. AQS power

EQBF516D




Fig 3) Specifications : Resistance value of ambient temp. sensor as a function of temperature.

EQBF516F

- 4) Is the measured resistance within specifications in fig3? (tolerance limits  $\pm 3\%$ )

**YES**

Go to "Check A/C Control Unit" procedure.

**NO**


Substitute with a known-good ambient temp. sensor and check for proper operation.

If the problem is corrected, replace ambient temp. sensor and then go to "Verification of Vehicle Repair" procedure.

2. Check A/C Control Unit

- 1) Engine "ON"
- 2) Disconnect ambient temp. sensor.
- 3) Measure voltage between terminal "3" of A/C Control Unit and chassis ground.

Specification : Approx. 5V



## 3. Ambient temp. sensor signal

EQBF516E

4) Is the measured voltage within specifications?

**YES**

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO**

Substitute with a known-good A/C Control Unit and check for proper operation.

If the problem is corrected, replace A/C Control Unit and then go to "Verification of Vehicle Repair" procedure.

**VERIFICATION OF VEHICLE REPAIR** EC81091E

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
2. Operate the vehicle and monitor the DTC on the scantool.
3. Are any DTCs present?

**YES**

Go to the applicable troubleshooting procedure.

**NO**


System is performing to specification at this time.

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -153

**DTC B1238 AMBIENT TEMPERATURE SENSOR OPEN (HIGH)**

**COMPONENT LOCATION** EDF1649A



EQBF516A

**GENERAL DESCRIPTION** E4951473

The ambient temperature sensor located at the center stay of the condenser, detects ambient air temperature. It is a negative type thermistor whose resistance is inversely proportional to temperature. Its output is used for discharge temperature sensor, sensor fail-safe, temperature regulation door lock, blower motor level control, mix mode control and in-car humidity control.

**DTC DESCRIPTION** EBEAF741

The A/C controller sets DTC B1238 if there is an open circuit in ambient temp. sensor signal harness or the measured resistance value of sensor is more than threshold value(about 527kΩ )

**DTC DETECTING CONDITION** ECC7468F

Item	Detecting Condition	Possible cause
DTC Strategy	• Resistance check	<ul style="list-style-type: none"> <li>• Open Circuit in harness</li> <li>• Faulty ambient temp. Sensor</li> <li>• Faulty A/C control unit</li> </ul>
Threshold value	• > 527kΩ	
Detecting time	• 0.3 sec	
FAIL SAFE	• Control with the value of 20°C(67°F)	

**SPECIFICATION** E611C585

Temperature[°C(°F)]	Resistance(kΩ )	Temperature[°C(°F)]	Resistance(kΩ )
-30(-22)	527.99	25(77)	30
-15(5)	218.21	35(95)	19.6
0(32)	97.83	50(122)	10.82
15(59)	47.12	60(140)	7.48

## HA -154

## HEATING, VENTILATION AND AIR CONDITIONING

MONITOR SCANTOOL DATA E1C87A66

1. Connect scantool to Data Link Connector(DLC).
2. Engine "ON"
3. Monitor the "AMBIENT TEMP. SENSOR" Parameter on the Scantool.  
 ※ Parameter of "AMBIENT TEMP. SENSOR" will be fixed at 20°C(67°F), if there is any fault in AMBIENT TEMP. SENSOR.

1.2 CURRENT DATA	
HEATER WATER TEMP. SNSR	17.0 °C
IN-CAR TEMP. SENSOR	12.0 °C
<b>AMBIENT AIR TEMP. SNS</b>	<b>20.0 °C</b>
EVAPORATIVE SENSOR	13.0 °C
DRIVER PHOTO SENSOR	0.00 V
AIR MIX POPENATIO. (DR.)	91.75 %
DIRECTION POTENIO. DR.	90.18 %
PASSENGER PHOTO SENSOR	255

Fig. 1

1.1 DIAGNOSTIC TROUBLE CODES	
<b>B1238 AMBIENT TEMP. SNSR HIGH</b>	
NUMBER OF DTC : 1 ITEMS	
PART	ERAS
HELP	

Fig. 2

Fig 1 : The current data in abnormal state.

Fig 2 : DTC B1238.

4. Are the DTC B1238 present and is parameter of "AMBIENT TEMP. SENSOR" fixed?

**YES**

Go to "Inspection" procedure.

**NO**

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION E7F0FB77

1. Many malfunctions in the electrical system are caused by poor harness and terminals.  
Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

**YES**

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -155

**NO**


Go to "Signal circuit inspection" procedure.

**SIGNAL CIRCUIT INSPECTION** E124C6B6

1. Check for open in harness.

- 1) Ignition "OFF"
- 2) Disconnect ambient temp. sensor.
- 3) Measure resistance between terminal "1" of ambient temp. sensor and terminal "3" of A/C Control Unit.

Specification : Approx. 0  $\Omega$



4) Is the measured resistance within specifications?

**YES**

Go to "Ground circuit Inspection " procedure.

**NO**


Check for open in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

**GROUND CIRCUIT INSPECTION** EA9F4A89

1. Check for open in ground harness.

- 1) Ignition "OFF"
- 2) Disconnect ambient temp. sensor.
- 3) Measure resistance between terminal "2" of ambient temp. sensor and chassis ground.

Specification : Approx. 0  $\Omega$



- 1. Ambient temp. sensor signal(+)
- 2. Ambient temp. sensor ground
- 4. AQS signal input
- 5. AQS ground
- 6. AQS power

EQBF518B

4) Is the measured resistance within specifications?

**YES**

Go to "Component Inspection " procedure.


**NO**

Check for open in ground harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

**COMPONENT INSPECTION** E513CAB3

1. Check Ambient temp. sensor.
  - 1) Ignition "OFF"
  - 2) Disconnect ambient temp. sensor.
  - 3) Measure resistance between terminal "1" and "2" of ambient temp. sensor.

Specification : Refer the specifications in fig 3.



- 1. Ambient temp. sensor signal
- 2. Ambient temp. sensor ground
- 4. AQS signal input
- 5. AQS ground
- 6. AQS power

EQBF516D

BLOWER AND A/C CONTROLS (AUTOMATIC)




Fig. 3

Fig 3) Specifications : Resistance value of ambient temp. sensor as a function of temperature.

EQBF516F

4) Is the measured resistance within specifications in fig3? (tolerance limits ±3%)

**YES**

Go to "Check A/C Control Unit" procedure.

**NO**


Substitute with a known-good ambient temp. sensor and check for proper operation.

If the problem is corrected, replace ambient temp. sensor and then go to "Verification of Vehicle Repair" procedure.

2. Check A/C Control Unit

- 1) Engine "ON"
- 2) Disconnect ambient temp. sensor.
- 3) Measure voltage between terminal "3" of A/C Control Unit and chassis ground.

Specification : Approx. 5V



3. Ambient temp. sensor signal

EQBF516E

4) Is the measured voltage within specifications?

**YES**

## HA -158

## HEATING, VENTILATION AND AIR CONDITIONING

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO**

Substitute with a known-good A/C Control Unit and check for proper operation.

If the problem is corrected, replace A/C Control Unit and then go to "Verification of Vehicle Repair" procedure.

**VERIFICATION OF VEHICLE REPAIR** E58CEDF6

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
2. Operate the vehicle and monitor the DTC on the scantool.
3. Are any DTCs present?

**YES**

Go to the applicable troubleshooting procedure.

**NO**

System is performing to specification at this time.

دیجیتال خودرو  
شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -159

**DTC B1241 EVAPORATOR TEMPERATURE SENSOR SHORT (LOW)**

**COMPONENT LOCATION** E486BCF6



EQBF519A

**GENERAL DESCRIPTION** E8813265

The Evaporator temperature sensor located on heater unit, detects the core temperature and interrupts compressor relay power, in order to prevent evaporator freezing by excessive cooling. It is a negative type thermistor whose resistance is inversely proportional to temperature.

**DTC DESCRIPTION** E059C248

The A/C controller sets DTC B1241 if there is a short circuit in evaporator temp. sensor signal harness or the measured resistance value of sensor is less than threshold value(about 0.9kΩ )

**DTC DETECTING CONDITION** E71F012F

Item	Detecting Condition	Possible cause
DTC Strategy	• Resistance check	<ul style="list-style-type: none"> <li>• Short circuit in harness</li> <li>• Faulty Evaporator temp. Sensor</li> <li>• Faulty A/C control unit</li> </ul>
Threshold value	• < 0.9kΩ	
Detecting time	• 0.3 sec	
FAIL SAFE	• Control with the value of -2°C(28.4°F)	

**SPECIFICATION** E8C0ABD9

※ Resistance value of evaporator sensor as a function of temperature.

Temperature[°C(°F)]	Resistance(kΩ )	Temperature[°C(°F)]	Resistance(kΩ )
-10(14)	13.6	15(59)	3.9
0(32)	8	30(86)	2
5(41)	6.2	40(104)	1.3
10(50)	4.9	50(122)	0.9

## HA -160

## HEATING, VENTILATION AND AIR CONDITIONING

MONITOR SCANTOOL DATA E6823FFB

1. Connect scantool to Data Link Connector(DLC).
2. Engine "ON"
3. Monitor the "EVAPORATIVE SENSOR" Parameter on the Scantool.

1.2 CURRENT DATA	
HEATER WATER TEMP. SNSR	13.0 °C
IN-CAR TEMP. SENSOR	12.0 °C
AMBIENT AIR TEMP. SNS	12.0 °C
<b>EVAPORATIVE SENSOR</b>	<b>-2.0 °C</b>
DRIVER PHOTO SENSOR	0.00 V
AIR MIX POENTIO. (DR.)	91.75 %
DIRECTION POTENIO. DR.	90.18 %
PASSENGER PHOTO SENSOR	255

FIX | SCRN | FULL | PART | GRPH | HELP

Fig. 1

Fig 1 : The current data in abnormal state.

Fig 2 : DTC B1241.

1.1 DIAGNOSTIC TROUBLE CODES	
<b>B1241 EVAP. SENSOR - LOW INPUT</b>	
NUMBER OF DTC : 1 ITEMS	
PART   ERAS   HELP	

Fig. 2

4. Are the DTC B1241 present and is parameter of "EVAPORATIVE SENSOR" fixed?  
 ※ Parameter of "EVAPORATIVE SENSOR" will be fixed at -2°C (28.4°F), if there is any fault in EVAPORATIVE SENSOR.

**YES**

Go to "Inspection" procedure.

**NO**

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION EAF84DC8

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

**YES**

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -161


**NO**

Go to "Signal circuit inspection" procedure.

**SIGNAL CIRCUIT INSPECTION** EAF42A6E

1. Check for short to ground in harness.
  - 1) Ignition "OFF"
  - 2) Disconnect evaporator temp. sensor.
  - 3) Measure resistance between terminal "1" of evaporator temp. sensor and chassis ground.

Specification : Approx.  $\infty \Omega$



1. Evaporator temp. sensor signal
2. Evaporator temp. sensor ground

- 4) Is the measured resistance within specifications?

**YES**

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Go to "Component Inspection" procedure.

**NO**


Check for short to ground in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

**COMPONENT INSPECTION** EB45B875

1. Check evaporator temp. sensor.
  - 1) Ignition "OFF"
  - 2) Disconnect evaporator temp. sensor.
  - 3) Measure resistance between terminal "1" and "2" of evaporator temp. sensor.

Specification : Refer the specifications in fig 3.





1. Evaporator temp. sensor signal
2. Evaporator temp. sensor ground

EQBF519D




Fig. 3

Fig 3) Specifications : Resistance value of evaporator temp. sensor as a function of temperature.

EQBF519F

- 4) Is the measured resistance within specifications in fig3? (tolerance limits  $\pm 3\%$ )

**YES**

Go to "Check A/C Control Unit" procedure.

**NO**

Substitute with a known-good evaporator temp. sensor and check for proper operation.

If the problem is corrected, replace evaporator temp. sensor and then go to "Verification of Vehicle Repair" procedure.


## 2. Check A/C Control Unit

- 1) Engine "ON"
- 2) Disconnect evaporator temp. sensor.
- 3) Measure voltage between terminal "6" of A/C Control Unit and chassis ground.

Specification : Approx. 5V

## BLOWER AND A/C CONTROLS (AUTOMATIC)

HA -163



## 6. Evaporator temp. sensor signal

EQBF519E

4) Is the measured voltage within specifications?

**YES**

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO**

Substitute with a known-good A/C Control Unit and check for proper operation.

If the problem is corrected, replace A/C Control Unit and then go to "Verification of Vehicle Repair" procedure.

## VERIFICATION OF VEHICLE REPAIR E32624E3

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
2. Operate the vehicle and monitor the DTC on the scantool.
3. Are any DTCs present?

**YES**

Go to the applicable troubleshooting procedure.

**NO**


System is performing to specification at this time.

HA -164

HEATING, VENTILATION AND AIR CONDITIONING

**DTC B1242 EVAPORATOR TEMPERATURE SENSOR OPEN (HIGH)**

**COMPONENT LOCATION** EB9F7C1F



EQBF519A

**GENERAL DESCRIPTION** E073E679

The Evaporator temperature sensor located on heater unit, detects the core temperature and interrupts compressor relay power, in order to prevent evaporator freezing by excessive cooling. It is a negative type thermistor whose resistance is inversely proportional to temperature.

**DTC DESCRIPTION** E9354B2A

The A/C controller sets DTC B1242 if there is an open circuit in evaporator temp. sensor signal harness or the measured resistance value of sensor is more than threshold value(about 13.6kΩ )

**DTC DETECTING CONDITION** E61B9B78

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> <li>Resistance check</li> </ul>	<ul style="list-style-type: none"> <li>Open Circuit in harness</li> <li>Faulty Evaporator temp. Sensor</li> <li>Faulty A/C control unit</li> </ul>
Threshold value	<ul style="list-style-type: none"> <li>&gt; 13.6kΩ</li> </ul>	
Detecting time	<ul style="list-style-type: none"> <li>0.3 sec</li> </ul>	
FAIL SAFE	<ul style="list-style-type: none"> <li>Control with the value of -2°C(28.4°F)</li> </ul>	

**SPECIFICATION** E70F7716

Temperature[°C(°F)]	Resistance(kΩ )	Temperature[°C(°F)]	Resistance(kΩ )
-10(14)	13.6	15(59)	3.9
0(32)	8	30(86)	2
5(41)	6.2	40(104)	1.3
10(50)	4.9	50(122)	0.9

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -165

**MONITOR SCANTOOL DATA** E1C7971C

1. Connect scantool to Data Link Connector(DLC).
2. Engine "ON"
3. Monitor the "EVAPORATIVE SENSOR" Parameter on the Scantool.

1.2 CURRENT DATA	
HEATER WATER TEMP. SNSR	13.0 °C
IN-CAR TEMP. SENSOR	12.0 °C
AMBIENT AIR TEMP. SNS	12.0 °C
<b>EVAPORATIVE SENSOR</b>	<b>-2.0 °C</b>
DRIVER PHOTO SENSOR	0.00 V
AIR MIX POENTIO. (DR.)	91.75 %
DIRECTION POTENIO. DR.	90.18 %
PASSENGER PHOTO SENSOR	255

Fig. 1

Fig 1 : The current data in abnormal state.

1.1 DIAGNOSTIC TROUBLE CODES	
<b>B1242 EVAP. SENSOR - HIGH INPUT</b>	
NUMBER OF DTC : 1 ITEMS	

Fig. 2

Fig 2 : DTC B1242.

4. Are the DTC B1242 present and is parameter of "EVAPORATIVE SENSOR" fixed?  
 ※ Parameter of "EVAPORATIVE SENSOR" will be fixed at -2°C (28.4°F), if there is any fault in EVAPORATIVE SENSOR.

**YES**

Go to "Inspection" procedure.

**NO**

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**TERMINAL AND CONNECTOR INSPECTION** E2790250

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

**YES**

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

HA -166

HEATING, VENTILATION AND AIR CONDITIONING

**NO**

Go to "Signal circuit inspection" procedure.

**SIGNAL CIRCUIT INSPECTION** EE8145E7

1. Check for open in harness.
  - 1) Ignition "OFF"
  - 2) Disconnect evaporator temp. sensor.
  - 3) Measure resistance between terminal "1" of evaporator temp. sensor and terminal "6" of A/C Control Unit.

Specification : Approx. 0  $\Omega$



- 4) Is the measured resistance within specifications?

**YES**

Go to "Ground circuit Inspection " procedure.

**NO**

Check for open in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.


**GROUND CIRCUIT INSPECTION** ED7ACE72

1. Check for open in ground harness.
  - 1) Ignition "OFF"
  - 2) Disconnect evaporator temp. sensor.
  - 3) Measure resistance between terminal "2" of evaporator temp. sensor and chassis ground.

Specification : Approx. 0  $\Omega$

## BLOWER AND A/C CONTROLS (AUTOMATIC)

HA -167



1. Evaporator temp. sensor signal
2. Evaporator temp. sensor ground

EQBF520C

4) Is the measured resistance within specifications?

**YES**

Go to "Component Inspection " procedure.

**NO**

Check for open in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

### COMPONENT INSPECTION EAB63ADA


1. Check evaporator temp. sensor.

1) Ignition "OFF"

2) Disconnect evaporator temp. sensor.

3) Measure resistance between terminal "1" and "2" of evaporator temp. sensor.

Specification : Refer the specifications in fig 3.



1. Evaporator temp. sensor signal
2. Evaporator temp. sensor ground

EQBF519D




Fig. 3

Fig 3) Specifications : Resistance value of evaporator temp. sensor as a function of temperature.

EQBF519F

4) Is the measured resistance within specifications in fig3? (tolerance limits  $\pm 3\%$ )

**YES**

Go to "Check A/C Control Unit" procedure.

**NO**


Substitute with a known-good evaporator temp. sensor and check for proper operation.

If the problem is corrected, replace evaporator temp. sensor and then go to "Verification of Vehicle Repair" procedure.

2. Check A/C Control Unit

- 1) Engine "ON"
- 2) Disconnect evaporator temp. sensor.
- 3) Measure voltage between terminal "6" of A/C Control Unit and chassis ground.

Specification : Approx. 5V



6. Evaporator temp. sensor signal

EQBF519E

4) Is the measured voltage within specifications?

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -169

**YES**

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO**

Substitute with a known-good A/C Control Unit and check for proper operation. If the problem is corrected, replace A/C Control Unit and then go to "Verification of Vehicle Repair" procedure.

**VERIFICATION OF VEHICLE REPAIR** E70127E7

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
2. Operate the vehicle and monitor the DTC on the scantool.
3. Are any DTCs present?

**YES**

Go to the applicable troubleshooting procedure.

**NO**

System is performing to specification at this time.



دیجیتال خودرو  
شرکت دیجیتال خودرو سامانه (مسئولیت محدود)


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

HA -170

HEATING, VENTILATION AND AIR CONDITIONING

**DTC B1245 AIR MIX POTENTIOMETER OPEN (LOW) - DRIVER**

**COMPONENT LOCATION** E719A3CD



EQBF522E

**GENERAL DESCRIPTION** E1CAAD32

Temperature control actuator located at heater unit, regulates the temperature by the procedure as follows. Signal from control unit adjusts position of temp. door by operating temp. motor and then temperature will be regulated by the hot/cold air ratio decided by position of temp. door.

**DTC DESCRIPTION** E60167C1

The A/C controller sets DTC B1245 if there is an open circuit or poor connection in the air mix potentiometer.


**DTC DETECTING CONDITION** E5EC5C4F

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> <li>Voltage check</li> </ul>	<ul style="list-style-type: none"> <li>Poor connection of connected part</li> <li>Open circuit in harness</li> <li>Short circuit in harness</li> <li>Faulty driver Air Mix potentiometer</li> </ul>
Threshold value	<ul style="list-style-type: none"> <li>&lt; 0.1V</li> </ul>	
Detecting time	<ul style="list-style-type: none"> <li>0.3 sec</li> </ul>	
FAIL SAFE	<ul style="list-style-type: none"> <li>If temperature setting 17~24.5°C(63~76°F) fix at max. cooling position.</li> <li>If temperature setting 25~32°C(77~90°F) fix at max. heating position.</li> </ul>	

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -171

**SPECIFICATION** E0B2DE0B



EQBF521B

**MONITOR SCANTOOL DATA** ED7CC1EA

1. Connect scantool to Data Link Connector(DLC).
2. Engine "ON"
3. Monitor the "Driver Air Mix Potentiometer" Parameter on the Scantool while operating temp. switch.

1.2 CURRENT DATA	
HEATER WATER TEMP.SNSR	13.0 °C
IN-CAR TEMP.SENSOR	12.0 °C
AMBIENT AIR TEMP.SNS	12.0 °C
EVAPORATIVE SENSOR	12.5 °C
DRIVER PHOTO SENSOR	0.00 V
<b>AIR MIX POPENIO.(DR.)</b>	<b>5.9 %</b>
DIRECTION POTENIO.DR.	90.18 %
PASSENGER PHOTO SENSOR	255

Fig. 1

1.1 DIAGNOSTIC TROUBLE CODES	
<b>B1245 AIR MIX P. - LOW INPUT</b>	
NUMBER OF DTC : 1 ITEMS	

Fig. 2

Fig 1 : The current data in abnormal state.

Fig 2 : DTC B1245.

EQBF521C

4. Are the DTC B1245 present and is parameter of "Driver Air Mix Potentiometer" fixed?  
 ※ Parameter of "Driver Air Mix Potentiometer" will be fixed at 100%(or any value above 90%), or 0% (or any value below 10%), if there is any fault in Driver Air Mix potentiometer.

**YES**

Go to "Inspection" procedure.

**NO**

HA -172

HEATING, VENTILATION AND AIR CONDITIONING

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**TERMINAL AND CONNECTOR INSPECTION** E3032942

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

**YES**

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

**NO**


Go to "Signal circuit inspection" procedure.

**SIGNAL CIRCUIT INSPECTION** EC98F659

1. Check for open in harness.
  - 1) Ignition "OFF"
  - 2) Disconnect Driver Air Mix potentiometer.
  - 3) Measure resistance between terminal "6" of Driver Air Mix Potentiometer and terminal "18" of A/C control unit.

Specification : Approx. 0 Ω

[LHD]




- 3. Motor
- 4. Motor
- 5. Sensor reference voltage(+5V)
- 6. Potentiometer signal**
- 7. Potentiometer ground

EQBF821D

BLOWER AND A/C CONTROLS (AUTOMATIC)

HA -173

[RHD]



- 3. Motor
- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQBF921D

4) Is the measured resistance within specifications?

**YES**

Go to "Check for short to ground in harness" procedure.

**NO**


Check for open in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

2. Check for short to ground in harness.

- 1) Ignition "OFF"
- 2) Disconnect Driver Air Mix potentiometer.
- 3) Measure resistance between terminal "6" of Driver Air Mix Potentiometer and chassis ground.

Specification : Approx.  $\infty \Omega$


[LHD]



- 3. Motor
- 4. Motor
- 5. Sensor reference voltage(+5V)
- 6. Potentiometer signal
- 7. Potentiometer ground

EQBF821E

[RHD]



- 3. Motor
- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQBF921E

4) Is the measured resistance within specifications?

HA -174

HEATING, VENTILATION AND AIR CONDITIONING

**YES**

Go to "Power circuit Inspection" procedure.

**NO**

Check for short to ground in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.


**POWER SUPPLY CIRCUIT INSPECTION** E2387022

1. Check for short or open in harness.

- 1) Ignition "ON"
- 2) Connect Driver Air Mix Potentiometer.
- 3) Measure voltage between terminal "7"(RHD:5) of Driver Air Mix Potentiometer and chassis ground.

Specification : Approx. 5V


[LHD]



3. Motor
4. Motor
5. Sensor reference voltage(+5V)
6. Potentiometer signal
7. Potentiometer ground

EQBF821F

[RHD]



3. Motor
4. Motor
5. Potentiometer ground
6. Potentiometer signal
7. Sensor reference voltage(+5V)

EQBF921F

4) Is the measured voltage within specifications?

**YES**

Go to "Component inspection" procedure.

**NO**

Check for short or open in power harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -175


**COMPONENT INSPECTION**

EFB9A59D

## 1. Check actuator motor.


- 1) Ignition "OFF"
- 2) Disconnect Driver Air Mix Potentiometer.
- 3) Verify that the temperature actuator operates to the hot position when connecting 12V to the terminal "3"(RHD:4) and grounding terminal "4"(RHD:3).
- 4) Verify that the temperature actuator operates to the cool position when the connections are reversed.

[LHD]



3. Motor
4. Motor
5. Sensor reference voltage(+5V)
6. Potentiometer signal
7. Potentiometer ground

[RHD]



3. Motor
4. Motor
5. Potentiometer ground
6. Potentiometer signal
7. Sensor reference voltage(+5V)

EQBF821H

EQBF921H

## 5) Does the actuator work properly?

**YES**

Go to "Check potentiometer" procedure.

**NO**

Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

## 2. Check potentiometer


- 1) Ignition "ON"
- 2) Connect Driver Air Mix potentiometer.
- 3) Measure voltage between terminal "6" and "7" of Driver Air Mix potentiometer while operating the temp. switch.

Specification : Refer the specifications in fig 3)

HA -176

HEATING, VENTILATION AND AIR CONDITIONING


[LHD]



- 3. Motor
- 4. Motor
- 5. Sensor reference voltage(+5V)
- 6. Potentiometer signal
- 7. Potentiometer ground

EQBF8211

[RHD]



- 3. Motor
- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQBF9211

Door position	Voltage (3-4)	Error detecting
MAX. Cooling	0.3 ± 0.15V	Low voltage : 0.08V or less
MAX. Heating	4.7 ± 0.15V	High voltage : 4.9V or more



Fig. 3

Fig 3) Specifications : Voltage value of air mix potentiometer as a function of position of setting temperature.

EQBF521J

4) Is the measured voltage within specifications in fig3?

**YES**

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO**

Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -177

**VERIFICATION OF VEHICLE REPAIR** E883B840

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
2. Operate the vehicle and monitor the DTC on the scantool.
3. Are any DTCs present?

**YES**

Go to the applicable troubleshooting procedure.

**NO**

System is performing to specification at this time.

# دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




HA -178

HEATING, VENTILATION AND AIR CONDITIONING

**DTC B1246 AIR MIX POTENTIOMETER SHORT (HIGH) - DRIVER**

**COMPONENT LOCATION** E3948C9B



EQBF522E

**GENERAL DESCRIPTION** E8B15D5D

Temperature control actuator located at heater unit, regulates the temperature by the procedure as follows. Signal from control unit adjusts position of temp. door by operating temp. motor and then temperature will be regulated by the hot/cold air ratio decided by position of temp. door.

**DTC DESCRIPTION** ECABD6D9

The A/C controller sets DTC B1246 if there is a short to power in the air mix potentiometer.


**DTC DETECTING CONDITION** E946FDCA

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> <li>Voltage check</li> </ul>	<ul style="list-style-type: none"> <li>Short circuit in harness</li> <li>Faulty driver Air Mix potentiometer</li> </ul>
Threshold value	<ul style="list-style-type: none"> <li>&gt; 4.9V</li> </ul>	
Detecting time	<ul style="list-style-type: none"> <li>0.3 sec</li> </ul>	
FAIL SAFE	<ul style="list-style-type: none"> <li>If temperature setting 17~24.5°C(63~76°F) fix at max. cooling position.</li> <li>If temperature setting 25~32°C(77~90°F) fix at max. heating position.</li> </ul>	

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -179

**SPECIFICATION** ED6C5BE4



EQBF521B

**MONITOR SCANTOOL DATA** E0F5D9A1

1. Connect scantool to Data Link Connector(DLC).
2. Engine "ON"
3. Monitor the "Driver Air Mix Potentiometer" Parameter on the Scantool while operating temp. switch.

1.2 CURRENT DATA	
HEATER WATER TEMP.SNSR	13.0 °C ▲
IN-CAR TEMP.SENSOR	12.0 °C
AMBIENT AIR TEMP.SNS	12.0 °C
EVAPORATIVE SENSOR	12.5 °C ■
DRIVER PHOTO SENSOR	0.00 V
<b>AIR MIX POPENIO.(DR.)</b>	<b>91.75 %</b>
DIRECTION POTENIO.DR.	90.18 %
PASSENGER PHOTO SENSOR	255

FIX | SCRN | FULL | PART | GRPH | HELP

Fig. 1

1.1 DIAGNOSTIC TROUBLE CODES	
<b>B1246 AIR MIX P. - HIGH INPUT</b>	
NUMBER OF DTC : 1 ITEMS	

PART | ERAS | HELP

Fig. 2

Fig 1 : The current data in abnormal state.  
Fig 2 : DTC B1246.

EQBF522A

4. Are the DTC B1246 present and is parameter of "Driver Air Mix potentiometer" fixed?  
 ※ Parameter of "Driver Air Mix potentiometer" will be fixed at 100%(or any value above 90%), or 0% (or any value below 10%), if there is any fault in Driver Air Mix potentiometer.

**YES**

Go to "Inspection" procedure.

**NO**

HA -180

HEATING, VENTILATION AND AIR CONDITIONING

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION EFE9FA90

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

**YES**

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

**NO**

Go to "Signal circuit inspection" procedure.


SIGNAL CIRCUIT INSPECTION EC608CD7

1. Check for short in harness.
  - 1) Ignition "OFF"
  - 2) Disconnect Driver Air Mix potentiometer.
  - 3) Measure resistance between terminal "6" and "5" of Driver Air Mix potentiometer.



Specification : Approx.  $\infty \Omega$


[LHD]



- 3. Motor
- 4. Motor
- 5. Sensor reference voltage(+5V)
- 6. Potentiometer signal
- 7. Potentiometer ground

EQBF822B

[RHD]



- 3. Motor
- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQBF922B

- 4) Is the measured resistance within specifications?

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -181

**YES**

Go to "Ground circuit Inspection" procedure.

**NO**


Check for short to power harness in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

**GROUND CIRCUIT INSPECTION** E4163DA5

1. Check for open in harness.
  - 1) Ignition "OFF"
  - 2) Disconnect Driver Air Mix Potentiometer.
  - 3) Measure resistance between terminal "7"(RHD:5) of Driver Air Mix Potentiometer and chassis ground.

Specification : Approx. 0 Ω

[LHD]




3. Motor
4. Motor
5. Sensor reference voltage(+5V)
6. Potentiometer signal
7. Potentiometer ground



EQBF821G

[LHD]



3. Motor
4. Motor
5. Potentiometer ground
6. Potentiometer signal
7. Sensor reference voltage(+5V)

EQBF921G

- 4) Is the measured resistance within specifications?

**YES**

Go to "Component Inspection" procedure.

**NO**

Check for open in ground harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

**COMPONENT INSPECTION** E74FBEDE


1. Check actuator motor.

HA -182

HEATING, VENTILATION AND AIR CONDITIONING

- 1) Ignition "OFF"
- 2) Disconnect Driver Air Mix Potentiometer.
- 3) Verify that the temperature actuator operates to the hot position when connecting 12V to the terminal "3"(RHD:4) and grounding terminal "4"(RHD:3).
- 4) Verify that the temperature actuator operates to the cool position when the connections are reversed.


[LHD]



- 3. Motor
- 4. Motor
- 5. Sensor reference voltage(+5V)
- 6. Potentiometer signal
- 7. Potentiometer ground

EQBF821H

[RHD]



- 3. Motor
- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQBF921H



اولین سامانه دیجیتال آیا درست کار می کند؟

5) Does the actuator work properly?

**YES**

Go to "Check potentiometer" procedure.

**NO**

Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

2. Check potentiometer


- 1) Ignition "ON"
- 2) Connect Driver Air Mix potentiometer.
- 3) Measure voltage between terminal "6" and "7" of Driver Air Mix potentiometer while operating the temp. switch.

Specification : Refer the specifications in fig 3)

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

**HA -183**


[LHD]



- 3. Motor
- 4. Motor
- 5. Sensor reference voltage(+5V)
- 6. Potentiometer signal
- 7. Potentiometer ground

EQBF821I


[RHD]



- 3. Motor
- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQBF921I

Door position	Voltage (3-4)	Error detecting
MAX. Cooling	0.3 ± 0.15V	Low voltage : 0.08V or less
MAX. Heating	4.7 ± 0.15V	High voltage : 4.9V or more



**Fig. 3**

Fig 3) Specifications : Voltage value of air mix potentiometer as a function of position of setting temperature.

EQBF521J

4) Is the measured voltage within specifications in fig3?

**YES**

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO**

Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

## HA -184

## HEATING, VENTILATION AND AIR CONDITIONING

VERIFICATION OF VEHICLE REPAIR EB8C6BA5

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
2. Operate the vehicle and monitor the DTC on the scantool.
3. Are any DTCs present?

**YES**

Go to the applicable troubleshooting procedure.

**NO**

System is performing to specification at this time.

# دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -185

**DTC B1249 DIRECTION POTENTIOMETER OPEN (LOW) - DRIVER**

**COMPONENT LOCATION** E1A16B4D



EQBF523A

**GENERAL DESCRIPTION** E25C3DBB

The mode control actuator mounted on heater unit, adjusts position of mode door by operating Direction Motor based on signal of A/C control unit. Pressing mode select switch makes the mode control actuator shift in order of vent → B/L → floor → mix.

**DTC DESCRIPTION** E2F32A26

The A/C controller sets DTC B1249 if there is an open circuit or poor connection in the Direction potentiometer.


**DTC DETECTING CONDITION** E699D917

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> <li>Voltage check</li> </ul>	<ul style="list-style-type: none"> <li>Poor connection of connected part</li> <li>Open circuit in harness</li> <li>Short circuit in harness</li> <li>Faulty driver direction potentiometer</li> </ul>
Threshold value	<ul style="list-style-type: none"> <li>&lt; 0.1V</li> </ul>	
Detecting time	<ul style="list-style-type: none"> <li>0.3 sec</li> </ul>	
FAIL SAFE	<ul style="list-style-type: none"> <li>Fix vent position, while selecting vent mode.</li> <li>Fix defrost position while selecting except vent mode.</li> </ul>	

HA -186

HEATING, VENTILATION AND AIR CONDITIONING

SPECIFICATION E0101031



EQBF523B

MONITOR SCANTOOL DATA E63388EE

1. Connect scantool to Data Link Connector(DLC).
2. Engine "ON"
3. Monitor the "DR. DIRECTION POTENTIO." parameter on the scantool while operating mode switch.

1.2 CURRENT DATA	
HEATER WATER TEMP.SNSR	13.0 °C
IN-CAR TEMP.SENSOR	11.5 °C
AMBIENT AIR TEMP.SNS	12.0 °C
EVAPORATIVE SENSOR	13.0 °C
DRIVER PHOTO SENSOR	0.00 V
AIR MIX POSENTIO.(DR.)	92.54 %
<b>DIRECTION POTENIO.DR.</b>	<b>1.96 %</b>
PASSENGER PHOTO SENSOR	255

Fig. 1

Fig 1 : The current data in abnormal state.

1.1 DIAGNOSTIC TROUBLE CODES	
<b>B1249 DIRECTION P. - LOW INPUT</b>	
NUMBER OF DTC : 1 ITEMS	

Fig. 2

Fig 2 : DTC B1249.

EQBF523C

4. Are the DTC B1249 present and is parameter of "DR. DIRECTION POTENTIO." fixed?  
 ※ Parameter of "DR. DIRECTION POTENTIO." will be fixed at 100%(or any value above 90%), or 0% (or any value below 10%), if there is any fault in Driver Direction potentiometer.

**YES**

Go to "Inspection" procedure.

**NO**

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

**HA -187**

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**TERMINAL AND CONNECTOR INSPECTION** E3E72485

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

**YES**

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

**NO**

Go to "Signal circuit inspection" procedure.


**SIGNAL CIRCUIT INSPECTION** EEDADDD6

1. Check for open in harness.
  - 1) Ignition "OFF"
  - 2) Disconnect Driver mode Actuator.
  - 3) Measure resistance between terminal "6" of Driver Direction potentiometer and terminal "21" of A/C control unit.



Specification : Approx. 0 Ω

[LHD]




3. Motor
4. Motor
5. Potentiometer ground
- 6. Potentiometer signal**
7. Sensor reference voltage(+5V)

EQBF823D


HA -188

HEATING, VENTILATION AND AIR CONDITIONING

[RHD]



- 3. Motor
- 4. Motor
- 5. Sensor reference voltage(+5V)
- 6. Potentiometer signal**
- 7. Potentiometer ground



EQBF923D

4) Is the measured resistance within specifications?

**YES**

Go to "Check for short to ground in harness" procedure.

**NO**


Check for open in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

2. Check for short to ground in harness.

- 1) Ignition "OFF"
- 2) Disconnect Driver mode Actuator.
- 3) Measure resistance between terminal "6" of Driver Direction potentiometer and chassis ground.

Specification : Approx.  $\infty \Omega$


[LHD]



- 3. Motor
- 4. Motor
- 5. Potentiometer GND
- 6. Potentiometer signal**
- 7. Sensor REF +5V

EQBF823E

[RHD]



- 3. Motor
- 4. Motor
- 5. Sensor REF +5V
- 6. Potentiometer signal**
- 7. Potentiometer GND

EQBF923E

4) Is the measured resistance within specifications?

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -189

**YES**

Go to "Power circuit Inspection" procedure.

**NO**

Check for short to ground in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

**POWER SUPPLY CIRCUIT INSPECTION**


E7CE5F7A

1. Check for short or open in harness.

- 1) Ignition "ON"
- 2) Connect Driver Direction potentiometer.
- 3) Measure voltage between terminal "7"(RHD:5) of Driver Direction potentiometer and chassis ground.

Specification : Approx. 5V

[LHD]




3. Motor
4. Motor
5. Potentiometer GND
6. Potentiometer signal
7. Sensor REF +5V



EQBF823F

[RHD]



3. Motor
4. Motor
5. Sensor REF +5V
6. Potentiometer signal
7. Potentiometer GND

EQBF923F

4) Is the measured voltage within specifications?

**YES**

Go to "Component Inspection" procedure.

**NO**

Check for short or open in power harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

HA -190


HEATING, VENTILATION AND AIR CONDITIONING

COMPONENT INSPECTION E1CC0BF4

1. Check actuator.


- 1) Ignition "OFF"
- 2) Disconnect Driver Direction potentiometer.
- 3) Verify that the mode actuator operates to the vent mode when connecting 12V to the terminal "3"(RHD:4) and grounding terminal "4"(RHD:3).
- 4) Verify that the mode actuator operates to the def mode when the connections are reversed.

[LHD]



- 3. Motor
- 4. **Motor**
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

[RHD]



- 3. Motor
- 4. **Motor**
- 5. Sensor reference voltage(+5V)
- 6. Potentiometer signal
- 7. Potentiometer ground

EQBF823H

EQBF923H

5) Does the actuator work properly?

**YES**

Go to "Check potentiometer" procedure.

**NO**

Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

2. Check potentiometer


- 1) Ignition "ON"
- 2) Connect Driver Direction potentiometer.
- 3) Measure voltage between terminal "5"(RHD:7) and "6" of Driver Direction potentiometer as the mode switch is operated.

Specification : Refer the specifications in fig 3

BLOWER AND A/C CONTROLS (AUTOMATIC)

HA -191


[LHD]



- 3. Motor
- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQBF823I

[RHD]



- 3. Motor
- 4. Motor
- 5. Sensor reference voltage(+5V)
- 6. Potentiometer signal
- 7. Potentiometer ground

EQBF923I

Door position	Voltage (3-4)	Error detecting
VENT	0.3 ± 0.15V	Under voltage : 0.08V or less Over voltage : 4.92V or more
BI-LEVEL(1)	1.35 ± 0.4V	
BI-LEVEL(2)	2.25 ± 0.4V	
FLOOR	3.0 ± 0.4V	
MIX	3.6 ± 0.4V	
DEF	4.7 ± 0.15V	




Fig. 3

Fig 3) Specifications : Voltage value as a function of position of direction potentiometer.

EQBF523J

4) Is the measured voltage within specifications in fig3?

**YES**

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

HA -192

HEATING, VENTILATION AND AIR CONDITIONING

**NO**

Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

**VERIFICATION OF VEHICLE REPAIR** E17B27B5

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
2. Operate the vehicle and monitor the DTC on the scantool.
3. Are any DTCs present?

**YES**

Go to the applicable troubleshooting procedure.

**NO**

System is performing to specification at this time.

# دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




**BLOWER AND A/C CONTROLS (AUTOMATIC)**

**HA -193**

**DTC B1250 DIRECTION POTENTIOMETER SHORT (HIGH) - DRIVER**

**COMPONENT LOCATION** EAAF06F7



EQBF523A

**GENERAL DESCRIPTION** E42DB595

The mode control actuator mounted on heater unit, adjusts position of mode door by operating Direction Motor based on signal of A/C control unit. Pressing mode select switch makes the mode control actuator shift in order of vent → B/L → floor → mix.

**DTC DESCRIPTION** E506ACD5

The A/C controller sets DTC B1250 if there is a short to power in the Direction potentiometer.


**DTC DETECTING CONDITION** E6521921

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> <li>Voltage check</li> </ul>	<ul style="list-style-type: none"> <li>Short circuit in harness</li> <li>Faulty driver direction potentiometer</li> <li>Open circuit in harness</li> </ul>
Threshold value	<ul style="list-style-type: none"> <li>&gt; 4.9V</li> </ul>	
Detecting time	<ul style="list-style-type: none"> <li>0.3 sec</li> </ul>	
FAIL SAFE	<ul style="list-style-type: none"> <li>Fix vent position</li> </ul>	

HA -194

HEATING, VENTILATION AND AIR CONDITIONING

SPECIFICATION E80F0A06



EQBF523B

MONITOR SCANTOOL DATA E6C26D12

1. Connect scantool to Data Link Connector(DLC).
2. Engine "ON"
3. Monitor the "DR. DIRECTION POTENTIO." parameter on the scantool while operating mode switch.

1.2 CURRENT DATA	
HEATER WATER TEMP.SNSR	13.0 °C ▲
IN-CAR TEMP.SENSOR	11.5 °C
AMBIENT AIR TEMP.SNS	12.0 °C
EVAPORATIVE SENSOR	13.0 °C ■
DRIVER PHOTO SENSOR	0.00 V
AIR MIX POPENTIO.(DR.)	92.54 %
<b>DIRECTION POTENIO.DR.</b>	<b>100 %</b>
PASSENGER PHOTO SENSOR	255 ▼

FIX | SCRN | FULL | PART | GRPH | HELP

Fig. 1

1.1 DIAGNOSTIC TROUBLE CODES	
<b>B1250 DIRECTION P. - HIGH INPUT</b>	
NUMBER OF DTC : 1 ITEMS	

PART | ERAS | HELP

Fig. 2

Fig 1 : The current data in abnormal state.  
Fig 2 : DTC B1250.

EQBF524A

4. Are the DTC B1250 present and is parameter of "DR. DIRECTION POTENTIO." fixed?  
 ※ Parameter of "DR. DIRECTION POTENTIO." will be fixed at 100%(or any value above 90%), or 0% (or any value below 10%), if there is any fault in Driver Direction potentiometer.

**YES**

Go to "Inspection" procedure.

**NO**

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -195

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**TERMINAL AND CONNECTOR INSPECTION** E7C9EC9A

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

**YES**

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

**NO**

Go to "Signal circuit inspection" procedure.


**SIGNAL CIRCUIT INSPECTION** EBA6FBEC

1. Check for short in harness.
  - 1) Ignition "OFF"
  - 2) Disconnect Driver mode Actuator.
  - 3) Measure resistance between terminal "6" and "7"(RHD:5)of Driver Direction potentiometer.



Specification : Approx.  $\infty \Omega$


[LHD]



- 3. Motor
- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQBF824B

[RHD]



- 3. Motor
- 4. Motor
- 5. Sensor reference voltage(+5V)
- 6. Potentiometer signal
- 7. Potentiometer ground

EQBF924B

- 4) Is the measured resistance within specifications?

HA -196

HEATING, VENTILATION AND AIR CONDITIONING

**YES**

Go to "Ground circuit inspection" procedure.

**NO**

Check for open in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.


**GROUND CIRCUIT INSPECTION** E64B7078

1. Check for open in ground harness.

- 1) Ignition "OFF"
- 2) Disconnect Driver mode Actuator.
- 3) Measure resistance between terminal "5"(RHD:7) of evaporator sensor and chassis ground.

Specification :Approx. 0  $\Omega$ 

[LHD]




3. Motor
4. Motor
5. Potentiometer GND
6. Potentiometer signal
7. Sensor REF +5V



EQBF823G

[RHD]



3. Motor
4. Motor
5. Sensor REF +5V
6. Potentiometer signal
7. Potentiometer GND

EQBF923G

4) Is the measured resistance within specifications?

**YES**

Go to "Component Inspection " procedure.

**NO**

Check for open in ground harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

**COMPONENT INSPECTION** E48D945D


1. Check actuator.

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

**HA -197**

- 1) Ignition "OFF"
- 2) Disconnect Driver Direction potentiometer.
- 3) Verify that the mode actuator operates to the vent mode when connecting 12V to the terminal "3"(RHD:4) and grounding terminal "4"(RHD:3).
- 4) Verify that the mode actuator operates to the def mode when the connections are reversed.


[LHD]



3. Motor
4. **Motor**
5. Potentiometer ground
6. Potentiometer signal
7. Sensor reference voltage(+5V)

EQBF823H

[RHD]



3. Motor
4. **Motor**
5. Sensor reference voltage(+5V)
6. Potentiometer signal
7. Potentiometer ground

EQBF923H



5) اولین سامانه دیجیتال آیا ایراد می‌گیرد؟  
 Does the actuator work properly?

**YES**

Go to "Check potentiometer" procedure.

**NO**

Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.


2. Check potentiometer
  - 1) Ignition "ON"
  - 2) Connect Driver Direction potentiometer.
  - 3) Measure voltage between terminal "5"(RHD:7) and "6" of Driver Direction potentiometer as the mode switch is operated.

Specification : Refer the specifications in fig 3

HA -198

HEATING, VENTILATION AND AIR CONDITIONING


[LHD]



- 3. Motor
- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQBF823I

[RHD]



- 3. Motor
- 4. Motor
- 5. Sensor reference voltage(+5V)
- 6. Potentiometer signal
- 7. Potentiometer ground

EQBF923I

Door position	Voltage (3-4)	Error detecting
VENT	0.3 ± 0.15V	Under voltage : 0.08V or less Over voltage : 4.92V or more
BI-LEVEL(1)	1.35 ± 0.4V	
BI-LEVEL(2)	2.25 ± 0.4V	
FLOOR	3.0 ± 0.4V	
MIX	3.6 ± 0.4V	
DEF	4.7 ± 0.15V	




Fig. 3

Fig 3) Specifications : Voltage value as a function of position of direction potentiometer.

EQBF523J

4) Is the measured voltage within specifications in fig3?

**YES**

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -199

**NO**

Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

**VERIFICATION OF VEHICLE REPAIR** E41A230A

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
2. Operate the vehicle and monitor the DTC on the scantool.
3. Are any DTCs present?

**YES**

Go to the applicable troubleshooting procedure.

**NO**

System is performing to specification at this time.

# دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




HA -200

HEATING, VENTILATION AND AIR CONDITIONING

**DTC B1257 AQS OPEN**

**COMPONENT LOCATION** EF8D2F76



EQBF530A

**GENERAL DESCRIPTION** ED4DF3B0

AQS(Air Quality System) keeps air inside in the most suitable state for driver. In polluted area AQS detects hazardous gas and intercepts inflow automatically, Inversely, In freshsh area it allows the inflow of air to prevent the shortage of air and the accumulation of carbon dioxide. AQS sensor is located at front side of condensor and once hazardous gas is detected, it delivers the voltage signal to A/C controller for closing intake door.

**DTC DESCRIPTION** E12FB0BD

The A/C controller sets DTC B1257 if there is an open circuit in AQS sensor signal harness or the measured voltage value of sensor is more than threshold value.

**DTC DETECTING CONDITION** EB1B1045

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> <li>Voltage check</li> </ul>	<ul style="list-style-type: none"> <li>Open Circuit in power harness</li> <li>Open circuit in ground harness</li> <li>Faulty AQS Sensor</li> <li>Poor connection of connected part</li> </ul>
Threshold value	<ul style="list-style-type: none"> <li>&gt; 4.9V</li> </ul>	
Detecting time	<ul style="list-style-type: none"> <li>1 sec</li> </ul>	
FAIL SAFE	<ul style="list-style-type: none"> <li>AQS function OFF</li> <li>Intake door : return to previous state</li> </ul>	

**SPECIFICATION** ECC6418A

※ Voltage value of AQS sensor as a function of position of operating condition.

Operating condition	Voltage	Note
Right after IGN "ON"	2.5V ± 0.3V	preheating(35 ± 2sec)



## HA -202

## HEATING, VENTILATION AND AIR CONDITIONING

**YES**

Repair as necessary and go to "Verification of Vehicle Repair" procedure.


**NO**

Go to "Signal circuit inspection" procedure.

**SIGNAL CIRCUIT INSPECTION** EF29F40C

1. Check for open in harness.
  - 1) Ignition "OFF"
  - 2) Disconnect AQS sensor.
  - 3) Measure resistance between terminal "4" of AQS sensor and terminal "2" of A/C Control Unit.

Specification : Approx. 0  $\Omega$



EQBF531B

- 4) Is the measured resistance within specifications?

**YES**

Go to "Ground circuit Inspection " procedure.

**NO**

Check for open in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.


**GROUND CIRCUIT INSPECTION** E60583A8

1. Check for open in ground harness.
  - 1) Ignition "OFF"
  - 2) Disconnect AQS sensor.
  - 3) Measure resistance between terminal "5" of AQS sensor and chassis ground.

Specification : Approx. 0  $\Omega$

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

**HA -203**



- 1. Ambient temp. sensor(+)
- 2. Ambient temp. sensor ground
- 4. AQS signal input
- 5. AQS ground**
- 6. AQS power

EQBF531C

4) Is the measured resistance within specifications?

**YES**

Go to "Component Inspection " procedure.

**NO**

Check for open in ground harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.


**COMPONENT INSPECTION** E0F5764B

1. Check AQS sensor.


1) Engine "ON"

2) Connect AQS sensor.

3) Measure voltage between terminal "4" and "5" of AQS sensor.



Specification : Refer to the specifications.



- 1. Ambient temp. sensor(+)
- 2. Ambient temp. sensor ground
- 4. AQS signal input**
- 5. AQS ground**
- 6. AQS power

EQBF530D

Operating condition	Voltage	Note
Right after IGN "ON"	2.5V ± 0.3V	preheating(35 ± 2sec)
Normal	4.3V ± 0.3V	Intake door : Fresh
Gas detected	0.9V ± 0.3V	Intake door : Recirculation

Specifications : Voltage value of AQS sensor as a function of position of operating condition.

4) Is the measured voltage within specifications?

**YES**

## HA -204

## HEATING, VENTILATION AND AIR CONDITIONING

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO**

Substitute with AQS sensor and check for proper operation.

If the problem is corrected, replace AQS sensor and then go to "Verification of Vehicle Repair" procedure.

**VERIFICATION OF VEHICLE REPAIR** EF0A99CE

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
2. Operate the vehicle and monitor the DTC on the scantool.
3. Are any DTCs present?

**YES**

Go to the applicable troubleshooting procedure.

**NO**

System is performing to specification at this time.




دیجیتال خودرو  
شرکت دیجیتال خودرو سامانه (مسئولیت محدود)  
اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

**HA -205**

**DTC B1258 AQS SHORT**

**COMPONENT LOCATION** E1AE9C53



EQBF530A

**GENERAL DESCRIPTION** E78FDD65

AQS(Air Quality System) keeps air inside in the most suitable state for driver. In polluted area AQS detects hazardous gas and intercepts inflow automatically, Inversely, In freshsh area it allows the inflow of air to prevent the shortage of air and the accumulation of carbon dioxide. AQS sensor is located at front side of condensor and once hazardous gas is detected, it delivers the voltage signal to A/C controller for closing intake door.

**DTC DESCRIPTION** E65E21A7

The A/C controller sets DTC B1258 if there is a short circuit in AQS sensor signal harness or the measured voltage value of the sensor is less than the threshold value.

**DTC DETECTING CONDITION** E862F7F5

Item	Detecting Condition	Possible cause
DTC Strategy	• Voltage check	<ul style="list-style-type: none"> <li>• Short circuit in harness</li> <li>• Faulty AQS Sensor</li> <li>• Fault A/C Control Unit</li> </ul>
Threshold value	• < 0.1V	
Detecting time	• 1 sec	
FAIL SAFE	<ul style="list-style-type: none"> <li>• AQS function OFF</li> <li>• Intake door : return to previous state</li> </ul>	

**SPECIFICATION** EBC31DE0

※ Voltage value of AQS sensor as a function of position of operating condition.

Operating condition	Voltage	Note
Right after IGN "ON"	2.5V ± 0.3V	preheating(35 ± 2sec)
Normal	4.3V ± 0.3V	Intake door : Fresh
Gas detected	0.9V ± 0.3V	Intake door : Recirculation

## HA -206

## HEATING, VENTILATION AND AIR CONDITIONING

## MONITOR SCANTOOL DATA

EB72B2D9

1. Connect scantool to Data Link Connector(DLC).
2. Engine "ON"
3. Monitor the "AQS sensor" Parameter on the Scantool. While making hazardous gas such as tobacco fumes around the AQS sensor.

1.2 CURRENT DATA	
HEATER WATER TEMP. SNSR	14.0 °C
IN-CAR TEMP. SENSOR	12.0 °C
AMBIENT AIR TEMP. SNS	12.0 °C
EVAPORATIVE SENSOR	13.0 °C
DRIVER PHOTO SENSOR	0.00 V
AIR MIX POPENATIO. (DR.)	84.69 %
DIRECTION POTENIO. DR.	51.76 %
PASSENGER PHOTO SENSOR	255
<b>AQS SENSOR</b>	<b>0.0 V</b>

Fig. 1

Fig 1 : The current data in abnormal state.

1.1 DIAGNOSTIC TROUBLE CODES	
<b>B1258 AQS SENSOR-SHORT(LOW)</b>	
NUMBER OF DTC : 1 ITEMS	

Fig. 2

Fig 2 : DTC B1258.

4. Are the DTC B1258 present and is parameter of "AQS SENSOR" fixed?

**YES**

Go to "Inspection" procedure.

**NO**

Fault is intermittent caused by poor contact in the sensor's and/or A/C control unit's connector or was repaired and A/C control unit memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

## TERMINAL AND CONNECTOR INSPECTION

EA2C2E51

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

**YES**

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -207


**NO**

Go to "Signal circuit inspection" procedure.

**SIGNAL CIRCUIT INSPECTION** E0460C72

1. Check for open in harness.
  - 1) Ignition "OFF"
  - 2) Disconnect AQS sensor.
  - 3) Measure resistance between terminal "4" of AQS sensor and terminal chassis ground.

Specification : Approx. 0  $\Omega$



1. Ambient temp. sensor(+)
2. Ambient temp. sensor ground
4. AQS signal input
5. AQS ground
6. AQS power

- 4) Is the measured resistance within specifications?

**YES**

Go to "Component inspection" procedure.


**NO**

Check for open in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

**COMPONENT INSPECTION** E2A85239

1. Check AQS sensor.
  - 1) Engine "ON"
  - 2) Connect AQS sensor.
  - 3) Measure voltage between terminal "4" and "5" of AQS sensor.

Specification : Refer the specifications.



- 1. Ambient temp. sensor(+)
- 2. Ambient temp. sensor ground
- 4. AQS signal input
- 5. AQS ground
- 6. AQS power

EQBF530D

Operating condition	Voltage	Note
Right after IGN "ON"	2.5V ± 0.3V	preheating(35 ± 2sec)
Normal	4.3V ± 0.3V	Intake door : Fresh
Gas detected	0.9V ± 0.3V	Intake door : Recirculation

Specifications : Voltage value of AQS sensor as a function of position of operating condition.

4) Is the measured voltage within specifications?

**YES**

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO**


Substitute with a AQS sensor and check for proper operation.

If the problem is corrected, replace AQS sensor and then go to "Verification of Vehicle Repair" procedure.

2. Check A/C Control Unit

- 1) Engine : "ON"
- 2) Disconnect AQS sensor.
- 3) Measure voltage between terminal "2" of A/C Control Unit and chassis ground.

Specification :Approx. 5V



M21-1 2. AQS sensor signal input

EQBF530E

4) Is the measured voltage within specifications?

**YES**

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -209

**NO**

Substitute with a known-good A/C Control Unit and check for proper operation.  
If the problem is recirculated, replace A/C Control Unit and then go to "Verification of Vehicle Repair" procedure.

**VERIFICATION OF VEHICLE REPAIR** E37705AF

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
2. Operate the vehicle and monitor the DTC on the scantool.
3. Are any DTCs present?

**YES**


Go to the applicable troubleshooting procedure.

**NO**

System is performing to specification at this time.

دیجیتال خودرو  
شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




HA -210

HEATING, VENTILATION AND AIR CONDITIONING

**DTC B1259 AQS FAILURE**

**COMPONENT LOCATION** E898B5F4



EQBF530A

**GENERAL DESCRIPTION** EB944E6D

AQS(Air Quality System) keeps air inside in the most suitable state for driver. In polluted area AQS detects hazardous gas and intercepts inflow automatically, Inversely, In freshsh area it allows the inflow of air to prevent the shortage of air and the accumulation of carbon dioxide. AQS sensor is located at front side of condensor and once hazardous gas is detected, it delivers the voltage signal to A/C controller for closing intake door.

**DTC DESCRIPTION** E1DFB9E8

The A/C controller sets DTC B1259 if preheating time of AQS sensor is over 40sec or signal from AQS sensor is not within specifications.

**DTC DETECTING CONDITION** E734CCDD

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> <li>Voltage/time check</li> </ul>	<ul style="list-style-type: none"> <li>Faulty AQS Sensor</li> <li>Poor connection of connected part</li> </ul>
Threshold value	<ul style="list-style-type: none"> <li>Voltage : Preheating - 2.5V±0.3V Normal - 4.3V±0.3V Gas detected - 0.9V±0.3V</li> <li>Preheating time &gt; 40sec</li> </ul>	
Detecting time	-	
FAIL SAFE	<ul style="list-style-type: none"> <li>AQS function OFF</li> <li>Intake door : return to previous state</li> </ul>	

**SPECIFICATION** E441620B

※ Voltage value of AQS sensor as a function of position of operating condition.



## HA -212

## HEATING, VENTILATION AND AIR CONDITIONING

3. Has a problem been found?

**YES**

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

**NO**

Go to "Signal circuit inspection" procedure.

### SIGNAL CIRCUIT INSPECTION E3C76BFD

1. Check for open in harness.

- 1) Ignition "ON"
- 2) Disconnect AQS sensor.
- 3) Measure voltage value between terminal "6" of AQS sensor and chassis ground.

Specification : Approx. 12V



EQBF532C

4) Is the measured resistance within specifications?

**YES**

Go to "Component inspection " procedure.

**NO**

Check for open in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

### COMPONENT INSPECTION E81F882D


1. Check AQS sensor.

- 1) Engine "ON"
- 2) Connect AQS sensor.
- 3) Measure voltage between terminal "4" and "5" of AQS sensor.

Specification : Refer the specifications.

## BLOWER AND A/C CONTROLS (AUTOMATIC)

HA -213



1. Ambient temp. sensor(+)
2. Ambient temp. sensor ground
4. AQS signal input
5. AQS ground
6. AQS power

EQBF530D

Operating condition	Voltage	Note
Right after IGN "ON"	2.5V ± 0.3V	preheating(35 ± 2sec)
Normal	4.3V ± 0.3V	Intake door : Fresh
Gas detected	0.9V ± 0.3V	Intake door : Recirculation

Specifications : Voltage value of AQS sensor as a function of position of operating condition.

- 4) Is the measured voltage within specifications?

**YES**

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO**

Substitute with a AQS sensor and check for proper operation.

If the problem is corrected, replace AQS sensor and then go to "Verification of Vehicle Repair" procedure.

### VERIFICATION OF VEHICLE REPAIR E5CA9EEA

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
2. Operate the vehicle and monitor the DTC on the scantool.
3. Are any DTCs present?

**YES**

Go to the applicable troubleshooting procedure.

**NO**


System is performing to specification at this time.

HA -214

HEATING, VENTILATION AND AIR CONDITIONING

**DTC B2406 AIR MIX MOTOR (DRIVER)**

**COMPONENT LOCATION** EFE0376F



EQBF521A

**GENERAL DESCRIPTION** E64AC948

Temperature control actuator located at heater unit, regulates the temperature by the procedure as follows. Signal from control unit adjusts position of temp. door by operating temp. motor and then temperature will be regulated by the hot/cold air ratio decided by position of temp. door.

**DTC DESCRIPTION** E2ABFEF5

The A/C controller sets DTC B2406 if the air mix actuator doesn't move to intended position within 40sec (In this case, A/C controller try to move temp. door for 2sec. 3 times, every 20 sec. before setting DTC).


**DTC DETECTING CONDITION** EA8F2B90

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> <li>Voltage check</li> </ul>	<ul style="list-style-type: none"> <li>Poor connection of connected part</li> <li>Open circuit in harness</li> <li>Short circuit in harness</li> <li>Faulty driver Air Mix potentiometer</li> <li>Fault A/C Control Unit</li> </ul>
Threshold value	<ul style="list-style-type: none"> <li>&lt; 0.1V</li> </ul>	
Detecting time	<ul style="list-style-type: none"> <li>0.3 sec</li> </ul>	
FAIL SAFE	-	

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -215

**SPECIFICATION** EC47D91F



EQBF521B

**MONITOR SCANTOOL DATA** E41751B0

1. Connect scantool to Data Link Connector(DLC).
2. Engine "ON"
3. Monitor the "Driver Air Mix Potentiometer" Parameter on the Scantool while operating temp. switch.

1.2 CURRENT DATA	
HEATER WATER TEMP.SNSR	14.0 °C ▲
IN-CAR TEMP.SENSOR	12.0 °C
AMBIENT AIR TEMP.SNS	12.0 °C
EVAPORATIVE SENSOR	13.0 °C ■
DRIVER PHOTO SENSOR	0.00 V
<b>AIR MIX POPENIO.(DR.)</b>	<b>22.7 %</b>
DIRECTION POTENIO.DR.	51.76 %
PASSENGER PHOTO SENSOR	255

FIX | SCRN | FULL | PART | GRPH | HELP

Fig. 1

1.1 DIAGNOSTIC TROUBLE CODES	
<b>B2406 DRIVER AIR MIX MOTOR</b>	
NUMBER OF DTC : 1 ITEMS	

PART | ERAS | HELP

Fig. 2

Fig 1 : The current data in abnormal state.

Fig 2 : DTC B2406.

EQBF525A

4. Are the DTC B2406 present and is parameter of "Driver AIR MIX Potentiometer" fixed?
  - ※ There is any fault in Driver AIR MIX Motor. If the parameter of "Driver AIR MIX DOOR" is 30% or less when the actuator operates to the hot position, or If the parameter is 60% and more when the actuator operates to the cold position.

**YES**

Go to "Inspection" procedure.

**NO**

HA -216

HEATING, VENTILATION AND AIR CONDITIONING

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION E7F42C7B

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

**YES**

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

**NO**


Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION EAE92A03

1. Check for open in harness.
  - 1) Ignition "OFF"
  - 2) Disconnect Driver Air Mix potentiometer.
  - 3) Measure resistance between terminal "3,4" of Driver Air Mix Motor and terminal "16,17" of A/C control unit.

Specification : Approx. 0 Ω

[LHD]




- 3. Motor
- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQBF825B

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

**HA -217**

[RHD]



- 3. Motor
- 4. Motor
- 5. Sensor reference voltage(+5V)
- 6. Potentiometer signal
- 7. Potentiometer ground

EQBF925B

4) Is the measured resistance within specifications?

**YES**

Go to "Check for short to ground in harness" procedure.

**NO**


Check for open in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

2. Check for short to ground in harness.

- 1) Ignition "OFF"
- 2) Disconnect Driver Air Mix Actuator.
- 3) Measure resistance between terminal "3,4" of Driver Air Mix Motor and chassis ground.

Specification : Approx.  $\infty \Omega$


[LHD]



- 3. Motor
- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQBF825C

[RHD]



- 3. Motor
- 4. Motor
- 5. Sensor reference voltage(+5V)
- 6. Potentiometer signal
- 7. Potentiometer ground

EQBF925C

## HA -218

## HEATING, VENTILATION AND AIR CONDITIONING

- 4) Is the measured resistance within specifications?

**YES**

Go to "Visual/Physical Inspection " procedure.

**NO**

Check for short to ground in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

### VISUAL/PHYSICAL INSPECTION E991C1F7

1. Check actuator.
  - ※ Check if Driver Air Mix Actuator works properly through ACTUATION TEST.
- 1) Ignition : ON
- 2) Connect Scantool and select " ACTUATION TEST" mode and press [F1]

1.3 ACTUATION TEST	
DRIVER AIR MIX DOOR - DRIVE 50%	
DURATION	UNTIL STOP KEY
METHOD	ACTIVATION
CONDITION	IG. KEY ON ENGINE RUNNING
PRESS [STRT], IF YOU ARE READY!	
STRT	STOP

**Fig. 3**

Fig 3 : Selecting "ACTUATION TEST" mode.

EQBF525D

- 3) Does Driver Air Mix Actuator work properly?

**YES**

Go to "Component Inspection" procedure.

**NO**

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

### COMPONENT INSPECTION E076DD0D


1. Check actuator motor.
  - 1) Ignition "OFF"

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

**HA -219**

- 2) Disconnect Driver Air Mix Potentiometer.
- 3) Verify that the temperature actuator operates to the hot position when connecting 12V to the terminal "3"(RHD:4) and grounding terminal "4"(RHD:3).
- 4) Verify that the temperature actuator operates to the cool position when the connections are reversed.


[LHD]



- 3. Motor
- 4. Motor
- 5. Sensor reference voltage(+5V)
- 6. Potentiometer signal
- 7. Potentiometer ground

EQBF821H


[RHD]



- 3. Motor
- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQBF921H

دیجیتال خودرو  
شرکت دیجیتال خودرو سامانه (مسئولیت محدود)



5) Does the actuator work properly?

اولین سامانه دیجیتال تعمیرکاران خود را **YES** بیان

Go to "Check potentiometer" procedure.

**NO**

Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.


2. Check potentiometer
  - 1) Ignition "ON"
  - 2) Connect Driver Air Mix potentiometer.
  - 3) Measure voltage between terminal "5" and "6" of Driver Air Mix potentiometer while operating the temp. switch.

Specification : Refer the specifications in fig 3)

HA -220

HEATING, VENTILATION AND AIR CONDITIONING


[LHD]



- 3. Motor
- 4. Motor
- 5. Sensor reference voltage(+5V)
- 6. Potentiometer signal
- 7. Potentiometer ground

EQBF8211

[RHD]



- 3. Motor
- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQBF9211

Door position	Voltage (3-4)	Error detecting
MAX. Cooling	0.3 ± 0.15V	Low voltage : 0.08V or less
MAX. Heating	4.7 ± 0.15V	High voltage : 4.9V or more

شرکت دیجیتال خودرو (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




Fig. 3

Fig 3) Specifications : Voltage value of air mix potentiometer as a function of position of setting temperature.

EQBF521J

4) Is the measured voltage within specifications in fig3?

**YES**

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO**

Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.


**BLOWER AND A/C CONTROLS (AUTOMATIC)****HA -221**

3. Check A/C Control Unit.
  - 1) Engine "ON"
  - 2) Connect A/C Control Unit.
  - 3) Measure voltage between terminal "16" and "17" of A/C Control Unit while operating the temp. switch.

---

 Specification :Approx. 12V
 

---



EQBF525E

- 4) Is the measured voltage within specifications?

**YES**

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO**

Substitute with a known-good A/C Control Unit and check for proper operation.

If the problem is corrected, replace A/C Control Unit and then go to "Verification of Vehicle Repair" procedure.

**VERIFICATION OF VEHICLE REPAIR** E9F02EC4

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
2. Operate the vehicle and monitor the DTC on the scantool.
3. Are any DTCs present?

**YES**

Go to the applicable troubleshooting procedure.

**NO**


System is performing to specification at this time.

HA -222

HEATING, VENTILATION AND AIR CONDITIONING

**DTC B2408 INTAKE MOTOR FAILURE**

**COMPONENT LOCATION** EF1AEBEF



EQBF527A

**GENERAL DESCRIPTION** EBF43D13

Intake door located at heater unit controls the inlet of car. When driver operates the intake switch, A/C controller recirculationeives mode signal from intake switch and operates intake door actuator to turn intake door to intended position. (with fresh mode signal, intake door is closed and with fresh mode signal, intake door is opened.

**DTC DESCRIPTION** EDEFA576

The A/C controller sets DTC B2408 if the intake motor Doesn't move to intended position within 40sec(The A/C controller attempts to move the intake door for a 2 second duration at a freshquency of 3 times every 20 seconds before storing a DTC.)

**DTC DETECTING CONDITION** E70DC6B0

Item	Detecting Condition	Possible cause
DTC Strategy	• Voltage check	<ul style="list-style-type: none"> <li>• Poor connection of connected part</li> <li>• Open circuit in harness</li> <li>• Short circuit in harness</li> <li>• Faulty Intake potentiometer</li> </ul>
Threshold value	• < 0.1V	
Detecting time	• 0.3 sec	
FAIL SAFE	-	

**SPECIFICATION** E6B3190E

※ Voltage value of Intake potentiometer as a function of position of Intake door

Door position	Voltage	Threshold value
Fresh	0.3±0.15V	Voltage value 0.08V or less
Recirculation	4.7±0.15V	Voltage value 4.9V or more

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -223

**MONITOR SCANTOOL DATA** E73BFCC6

1. Connect scantool to Data Link Connector(DLC).
2. Engine "ON"
3. Monitor the "Intake Potentiometer" Parameter on the Scantool while operating Intake switch.

1.2 CURRENT DATA	
HEATER WATER TEMP.SNSR	14.0 °C
IN-CAR TEMP.SENSOR	12.0 °C
AMBIENT AIR TEMP.SNS	12.0 °C
EVAPORATIVE SENSOR	13.0 °C
DRIVER PHOTO SENSOR	0.00 V
AIR MIX POPENIO.(DR.)	84.69 %
DIRECTION POTENIO.DR.	51.76 %
PASSENGER PHOTO SENSOR	255
<b>INTAKE SENSOR</b>	<b>22.7 %</b>

FIX | SCRN | FULL | PART | GRPH | HELP

Fig. 1

Fig 1 : The current data in abnormal state.

1.1 DIAGNOSTIC TROUBLE CODES	
<b>B2408 INTAKE MOTOR</b>	
NUMBER OF DTC : 1 ITEMS	
PART	ERAS
HELP	

Fig. 2

Fig 2 : DTC B2408.

4. Are the DTC B2408 present and is parameter of "Intake Potentiometer" fixed?
  - ✳ There is any fault in Intake potentiometer. If the parameter of "Intake potentiometer" is 30% or less when the actuator operates to the fresh position, or If the parameter is 60% and more when the actuator operates to the recirculation position.

**YES**

Go to "Inspection" procedure.

**NO**

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**TERMINAL AND CONNECTOR INSPECTION** EOCEF15E

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

**YES**

HA -224

HEATING, VENTILATION AND AIR CONDITIONING

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

**NO**


Go to "Signal circuit inspection" procedure.

**SIGNAL CIRCUIT INSPECTION** E0DD314B

1. Check for open in harness.
  - 1) Ignition "OFF"
  - 2) Disconnect Intake potentiometer.
  - 3) Measure resistance between terminal "3,4" of Intake potentiometer and terminal "22,23" of A/C control unit.


Specification : Approx. 0 Ω

[LHD]



EQBF829B

[RHD]



EQBF829B

- 4) Is the measured resistance within specifications?

**YES**

Go to "Check for short to ground in harness" procedure.

**NO**

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -225


Check for open in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

2. Check for short to ground in harness.

- 1) Ignition "OFF"
- 2) Disconnect Driver Air Mix Actuator.
- 3) Measure resistance between terminal "3,4" of Driver Air Mix Motor and chassis ground.


Specification : Approx.  $\infty \Omega$

[LHD]



3. Motor
4. Motor
5. Potentiometer ground
6. Potentiometer signal
7. Sensor reference voltage(+5V)

[RHD]



3. Motor
4. Motor
5. Sensor reference voltage(+5V)
6. Potentiometer signal
7. Potentiometer ground

EQBF829C

EQBF929C

4) Is the measured resistance within specifications?

**YES**

Go to "Visual/Physical Inspection " procedure.

**NO**

Check for short to ground in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

**VISUAL/PHYSICAL INSPECTION** E43EAB6A

1. Check actuator.
  - ※ Check if Driver Air Mix Actuator works properly through ACTUATION TEST.
- 1) Ignition : ON
- 2) Connect Scantool and select " ACTUATION TEST" mode and press [F1]

1.3 ACTUATION TEST	
DRIVER AIR MIX DOOR - DRIVE 50%	
DURATION	UNTIL STOP KEY
METHOD	ACTIVATION
CONDITION	IG. KEY ON ENGINE RUNNING
PRESS [STRT], IF YOU ARE READY!	
[STRT]	[STOP]

Fig. 3

Fig 3 : Selecting "ACTUATION TEST" mode.

EQBF525D

3) Does Intake Actuator work properly?

**YES**

Go to "Component Inspection" procedure.

**NO**


Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**COMPONENT INSPECTION** EC3D4A88

1. Check actuator motor.

- 1) Ignition "OFF"
- 2) Disconnect Intake Potentiometer.
- 3) Verify that the temperature actuator operates to the fresh position when connecting 12V to the terminal "3"(RHD:4) and grounding terminal "4"(RHD:3).
- 4) Verify that the temperature actuator operates to the recirculation position when the connections are reversed.

[LHD]




- 3. Motor
- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQBF827H

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

**HA -227**

[RHD]



- 3. Motor
- 4. Motor
- 5. Sensor reference voltage(+5V)
- 6. Potentiometer signal
- 7. Potentiometer ground

EQBF927H

5) Does the actuator work properly?

**YES**

Go to "Check potentiometer" procedure.

**NO**


Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

2. Check potentiometer

- 1) Ignition "ON"
- 2) Connect Intake potentiometer.
- 3) Measure voltage between terminal "5" and "6" of Intake potentiometer while operating Intake switch.

Specification : Refer the specifications اولین سامانه دیجیتال


[LHD]



- 3. Motor
- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQBF827I

[RHD]



- 3. Motor
- 4. Motor
- 5. Sensor reference voltage(+5V)
- 6. Potentiometer signal
- 7. Potentiometer ground

EQBF927I

Door position	Voltage (5-6)	Error detecting
Fresh	0.3 ± 0.15V	Low voltage : 0.08V or less
Recirculation	4.7 ± 0.15V	High voltage : 4.9V or more

## HA -228

## HEATING, VENTILATION AND AIR CONDITIONING

Specifications : Voltage value of Intake potentiometer as a function of position of Intake.

- 4) Is the measured voltage within specifications?

**YES**

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.


**NO**

Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

3. Check A/C Control Unit.

- 1) Engine "ON"
- 2) Connect A/C Control Unit.
- 3) Measure voltage between terminal "22" and "23" of A/C Control Unit while operating the Intake switch.

Specification :Approx. 12V



EQBF529E

- 4) Is the measured voltage within specifications?

**YES**

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO**

Substitute with a known-good A/C Control Unit and check for proper operation.

If the problem is corrected, replace A/C Control Unit and then go to "Verification of Vehicle Repair" procedure.

## VERIFICATION OF VEHICLE REPAIR E0DD17DE

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
2. Operate the vehicle and monitor the DTC on the scantool.
3. Are any DTCs present?

**YES**

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -229

Go to the applicable troubleshooting procedure.

**NO**

System is performing to specification at this time.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




HA -230

HEATING, VENTILATION AND AIR CONDITIONING

**DTC B2409 DIRECTION CONTROL MOTOR (DRIVER)**

**COMPONENT LOCATION** E106240B



EQBF523A

**GENERAL DESCRIPTION** EF5781CF

The mode control actuator mounted on heater unit, adjusts position of mode door by operating Direction Motor based on signal of A/C control unit. Pressing mode select switch makes the mode control actuator shift in order of vent → B/L → floor → mix.

**DTC DESCRIPTION** EC2E4DF8

The A/C controller sets DTC B2409 if the direction motor doesn't move to intended position within 40sec(In this case, A/C controller try to move mode door for 2sec. 3 times, every 20 sec. before setting DTC).


**DTC DETECTING CONDITION** EC90DC02

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> <li>Voltage check</li> </ul>	<ul style="list-style-type: none"> <li>Poor connection of connected part</li> <li>Open circuit in harness</li> <li>Short circuit in harness</li> <li>Faulty driver direction potentiometer</li> <li>Fault A/C Control Unit.</li> </ul>
Threshold value	<ul style="list-style-type: none"> <li>&lt; 0.1V</li> </ul>	
Detecting time	<ul style="list-style-type: none"> <li>0.3 sec</li> </ul>	
FAIL SAFE	-	

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -231

**SPECIFICATION** E463272E



EQBF523B

**MONITOR SCANTOOL DATA** E65417DD

1. Connect scantool to Data Link Connector(DLC).
2. Engine "ON"
3. Monitor the "DR DIRECTION POTENTIO" parameter on the scantool while operating mode switch.

1.2 CURRENT DATA	
HEATER WATER TEMP.SNSR	14.0 °C
IN-CAR TEMP.SENSOR	12.0 °C
AMBIENT AIR TEMP.SNS	12.0 °C
EVAPORATIVE SENSOR	13.0 °C
DRIVER PHOTO SENSOR	0.00 V
AIR MIX POPENATIO.(DR.)	84.69 %
<b>DIRECTION POTENIO.DR.</b>	<b>32.5 %</b>
PASSENGER PHOTO SENSOR	255

Fig. 1

1.1 DIAGNOSTIC TROUBLE CODES	
<b>B2409 DRIVER DIRECTION MOTOR</b>	
NUMBER OF DTC : 1 ITEMS	

Fig. 2

Fig 1 : The current data in abnormal state.  
Fig 2 : DTC B2409.

EQBF526A

4. Are the DTC B2409 present and is parameter of "Driver DIRECTION POTENTIO." fixed?  
 \* There is any fault in Driver Direction Motor. If the parameter of "Driver DIRECTION POTENTIO." is 10% or less on "VENT" mode, or If the parameter is 90% or more on "DEF" mode.

**YES**

Go to "Inspection" procedure.


**NO**



**BLOWER AND A/C CONTROLS (AUTOMATIC)**

**HA -233**

[RHD]



- 3. Motor
- 4. Motor
- 5. Sensor reference voltage(+5V)
- 6. Potentiometer signal
- 7. Potentiometer ground

EQBF926B

4) Is the measured resistance within specifications?

**YES**

Go to "Check for short to ground in harness" procedure.

**NO**


Check for open in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

2. Check for short to ground in harness.

- 1) Ignition "OFF"
- 2) Disconnect Driver mode Actuator.
- 3) Measure resistance between terminal "3,4" of Driver Direction Motor and chassis ground.

Specification : Approx. ∞ Ω


[LHD]



- 3. Motor
- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQBF826C

[RHD]



- 3. Motor
- 4. Motor
- 5. Sensor reference voltage(+5V)
- 6. Potentiometer signal
- 7. Potentiometer ground

EQBF926C

## HA -234

## HEATING, VENTILATION AND AIR CONDITIONING

- 4) Is the measured resistance within specifications?

**YES**

Go to "Visual/Physical Inspection " procedure.

**NO**

Check for short to ground in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

### VISUAL/PHYSICAL INSPECTION E50E56B6

1. Check actuator.
  - ※ Check if Driver Direction Actuator works properly through ACTUATION TEST.
- 1) Ignition : ON
- 2) Connect Scantool and select " ACTUATION TEST" mode and press [F1]

1.3 ACTUATION TEST	
DRIVER AIR OUTLET MODE-DRIVE FOOT	
DURATION	UNTIL STOP KEY
METHOD	ACTIVATION
CONDITION	IG. KEY ON ENGINE RUNNING
PRESS [STRT], IF YOU ARE READY!	
STRT	STOP

**Fig. 3**

Fig 3 : Selecting "ACTUATION TEST" mode.

EQBF526D

- 3) Does Driver Direction Actuator work properly?

**YES**

Go to "Component Inspection" procedure.

**NO**

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.


### COMPONENT INSPECTION E2354556

1. Check actuator.
  - 1) Ignition "OFF"

**BLOWER AND A/C CONTROLS (AUTOMATIC)****HA -235**

- 2) Disconnect Driver Direction potentiometer.
- 3) Verify that the mode actuator operates to the vent mode when connecting 12V to the terminal "3"(RHD:4) and grounding terminal "4"(RHD:3).
- 4) Verify that the mode actuator operates to the def mode when the connections are reversed.


[LHD]



3. Motor
4. **Motor**
5. Potentiometer ground
6. Potentiometer signal
7. Sensor reference voltage(+5V)

EQBF823H

[RHD]



3. Motor
4. **Motor**
5. Sensor reference voltage(+5V)
6. Potentiometer signal
7. Potentiometer ground

EQBF823H

شرکت دیجیتال خودرو (مسئولیت محدود)

- 5) Does the actuator work properly?

اولین سامانه دیجیتال تعمیرکاران خود را **YES** بیان

Go to "Check potentiometer" procedure.

**NO**

Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

## 2. Check potentiometer


- 1) Ignition "ON"
- 2) Connect Driver Direction potentiometer.
- 3) Measure voltage between terminal "5" and "6" of Driver Direction potentiometer as the mode switch is operated.

Specification : Refer the specifications in fig 3

HA -236

HEATING, VENTILATION AND AIR CONDITIONING


[LHD]



- 3. Motor
- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQBF823I

[RHD]



- 3. Motor
- 4. Motor
- 5. Sensor reference voltage(+5V)
- 6. Potentiometer signal
- 7. Potentiometer ground

EQBF923I

Door position	Voltage (3-4)	Error detecting
VENT	$0.3 \pm 0.15V$	Under voltage : 0.08V or less Over voltage : 4.92V or more
BI-LEVEL(1)	$1.35 \pm 0.4V$	
BI-LEVEL(2)	$2.25 \pm 0.4V$	
FLOOR	$3.0 \pm 0.4V$	
MIX	$3.6 \pm 0.4V$	
DEF	$4.7 \pm 0.15V$	




Fig. 3

Fig 3) Specifications : Voltage value as a function of position of direction potentiometer.

EQBF523J

4) Is the measured voltage within specifications in fig3?

**YES**

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**BLOWER AND A/C CONTROLS (AUTOMATIC)**

HA -237


**NO**

Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

## 3. Check A/C Control Unit.

- 1) Engine : "ON"
- 2) Connect A/C Control Unit.
- 3) Measure voltage between terminal "19" and "20" of A/C Control Unit while operating the mode switch.

Specification :Approx. 12V



## 4) Is the measured voltage within specifications?

**YES**

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

**NO**

Substitute with a known-good A/C Control Unit and check for proper operation.

If the problem is corrected, replace A/C Control Unit and then go to "Verification of Vehicle Repair" procedure.

**VERIFICATION OF VEHICLE REPAIR** ED389E33

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
2. Operate the vehicle and monitor the DTC on the scantool.
3. Are any DTCs present?

**YES**

Go to the applicable troubleshooting procedure.

**NO**

System is performing to specification at this time.