# Engine Electrical System

**GENERAL** 

**IGNITION SYSTEM** 

CHARGING SYSTEM
ALTERNATOR
BATTERY

STARTING SYSTEM STARTER STARTER RELAY

CRUISE CONTROL SYSTEM
CRUISE CONTROL MAIN SWITCH





# **GENERAL**

# **SPECIFICATIONS**

E2C310C0

# **IGNITION SYSTRM**

| Items         |                      |     | Specification                      |
|---------------|----------------------|-----|------------------------------------|
| Ignition goil | Primary resistance   |     | 0.62 ± 10 %                        |
| Ignition coil | Secondary resistance |     | $7.0$ k $\Omega$ ± 15 %            |
| Unleaded      | Liningdod            | NGK | IFR5G-11                           |
|               | Unleaded             | Gap | 1.0 ~ 1.1 mm (0.0394 ~ 0.0433 in.) |
| Spark plugs   | Leaed NGK            | NGK | BKR5ES                             |
|               |                      | Gap | 0.8 ~ 0.9 mm (0.0315 ~ 0.0354 in)  |

#### STARTING SYSTEM

| Items   |                         |              | Specification  |
|---------|-------------------------|--------------|----------------|
|         | Rated volt              | 12 V, 1.4 kW |                |
|         | No. of pinion teeth     |              | 8              |
| Starter |                         | Voltage      | 11.5 V         |
|         | No-load characteristics | Ampere       | 85A, MAX       |
|         | \ a !   .   !   ! !!    | Speed        | 2,600 rpm, MIN |

#### **CHARGING SYSTEM**

| اولین سامانه دیجیتال Itemsرکاران خودرو در ایران |   | Specification                      |
|---|---|------------------------------------|
|   | Rate voltage                              | 13.5 V, 130A                       |
| Alternator                                      | Speed in use                              | 1,000 ~ 18,000 rpm                 |
| Alternator                                      | Voltage regulator                         | IC regulator built-in type         |
|   | Regulator setting voltage                 | 14.2 ~ 14.8 V (500 RPM, 10A, 25°C) |
|   | Туре                                      | CMF 80AH                           |
| Battery -                                       | Cold cranking amperage [at -18°C(-0.4°F)] | 660 A                              |
|   | Reserve capacity                          | 145 min                            |
|   | Specific gravity [at 25°C(77°F)]          | 1.280 ± 0.01                       |

# **NOTE**

- COLD CRANKING AMPERAGE is the amperage a battery can deliver for 30 seconds and maintain a terminal voltage of 7.2V or greater at a specified temperature.
- RESERVE CAPACITY RATING is amount of time a battery can deliver 25A and maintain a minimum terminal voltage of 10.5V at 26.7°C(80.1°F).

**GENERAL EE -3** 

# TROUBLESHOOTING EB8238FF

# **IGNITION SYSTEM**

| Symptom   | Suspect area  | Remedy   |
|---|---|--|
| Engine will not start<br>or is hard to start<br>(Cranks OK) | Ignition lock switch Ignition coil Spark plugs Ignition wiring disconnected or broken | Inspect ignition lock switch, or replace as required Inspect ignition coil, or replace as required Inspect spark plugs, or replace as required Repair wiring, or replace as required |
| Rough idle or stalls  | Ignition wiring<br>Ignition coil  | Repair wiring, or replace as required Inspect ignition coil, or replace as required  |
| Engine hesitates/poor acceleration                          | Spark plugs and spark plug cables Ignition wiring                                     | Inspect spark plugs / cable, or replace as required Repair wiring, or replace as required  |
| Poor mileage  | Spark plugs and spark plug cables   | Inspect spark plugs / cable, or replace as required  |

# **CHARGING SYSTEM**

| Symptom  | Suspect area   | Remedy   |
|--|--|--|
| Charging warning indicator does not light with ignition switch "ON" and engine off.                    | Fuse blown Light burned out Wiring connection loose Electronic voltage regulator   | Check fuses Replace light Tighten loose connection Replace voltage regulator   |
| Charging warning indicator does not go out with engine running. (Battery requires frequent recharging) | Drive belt loose or worn Battery cable loose, corroded or worn Electronic voltage regulator or alternator Wiring                         | Adjust belt tension or replace belt Inspect cable connection, repair or replace cable Replace voltage regulator or alternator Repair or replace wiring                   |
| Overcharge   | Electronic voltage regulator Voltage sensing wire  | Replace voltage regulator<br>Repair or replace wiring  |
| Discharge  | Drive belt loose or worn Wiring connection loose or short circuit Electronic voltage regulator or alternator Poor grounding Worn battery | Adjust belt tension or replace belt Inspect wiring connection, repair or replace wiring Replace voltage regulator or alternator Inspect ground or repair Replace battery |

# EE -4

# **ENGINE ELECTRICAL SYSTEM**

# STARTING SYSTEM

| Symptom                                 | Suspect area  | Remedy  |
|---|---|---|
| Engine will not crank                   | Battery charge low Battery cables loose, corroded or worn out Transaxle range switch (Vehicle with automatic transaxle only) Fuse blown Starter motor faulty Ignition switch faulty | Charge or replace battery Repair or replace cables Refer to TR group-automatic transaxle Replace fuse Replace Replace Replace |
| Engine cranks slowly                    | Battery charge low Battery cables loose, corroded or worn out Starter motor faulty  | Charge or replace battery<br>Repair or replace cables<br>Replace  |
| Starter keeps running                   | Starter motor<br>Ignition switch  | Replace<br>Replace  |
| Starter spins but engine will not crank | Short in wiring Pinion gear teeth broken or starter motor Ring gear teeth broken  | Repair wiring Replace Replace fly wheel or torque converter   |





IGNITION SYSTEM EE -5

# **IGNITION SYSTEM**

# **DESCRITION** EDD5F497


Ignition timing is controlled by the electronic control ignition timing system. The standard reference ignition timing data for the engine operating conditions are preprogrammed in the memory of the PCM (Power Control Module).

The engine operating conditions (speed, load, warm-up condition, etc.) are detected by the various sensors. Based on these sensor signals and the ignition timing data, signals to interrupt the primary current are sent to the PCM. The ignition coil is activated, and timing is controlled.





# COMPONENTS EA2AD0E3



- 1. Spark plug
- 2. Ignition coil
- 3. Condenser


SGHEE7001N

IGNITION SYSTEM EE -7

# ON-VEHICLE INSPECTION E63242EF

# **SPARK TEST**

1. Remove the ignition coil connector(A).



SGHEE7002N


- 2. Remove the ignition coil(B).
- 3. Using a spark plug socket, remove the spark plug.
- 4. Install the spark plug to the ignition coil.
- 5. Ground the spark plug to the engine.

6. Check if spark occurs while engine is being cranked.




To prevent fuel being injected from injectors while the engine is being cranked, remove the fuel pump(A) relay from the fuse box.

Crank the engine for no more than 5 ~ 10 seconds.




SGHEE7003N

- 7. Inspect all the spark plugs.
- 8. Using a spark plug socket, install the spark plug.
- 9. Install the ignition coil.
- 10. Reconnect the ignition coil connector.



ABGE001A




SGHEE7009N


**IGNITION SYSTEM EE-9** 

## SPARK PLUG

Remove the ignition coil connector(A).



Inspect the electrodes (A) and ceramic insulator (B).




EBKD002K

SGHEE7002N

# MOTE

When removing the ignition coil connector, pull the lock pin(A) and push the clip(B).



# **INSPECTION OF ELECTRODES**

| Condition   | Dark deposits   | White deposits   |
|-------------|---|--|
| Description | <ul> <li>Fuel mixture too rich</li> <li>Low air intake</li> </ul> | <ul> <li>Fuel mixture         too lean</li> <li>Advanced         ignition         timing</li> <li>Insufficient         plug         tightening         torque</li> </ul> |

Check the electrode gap (A).

# Standard:

1.0 ~ 1.1 mm (0.0394 ~ 0.0433 in.) - Unleaded  $0.8 \sim 0.9 \text{ mm} (0.0315 \sim 0.0354 \text{ in})$  - Leaded


ABGE003A

- Remove the ignition coil(B).
- Using a spark plug socket, remove the spark plug. 3.



# (A) CAUTION

Be careful that no contaminates enter through the spark plug holes.




EBKE002L

# EE -10 ENGINE ELECTRICAL SYSTEM

## **IGNITION COIL**

1. Measure the primary coil resistance between terminals (+) and (-).




ABGE004A

Standard value: 0.62 ± 10%

# REMOVAL E56FAFD7

- 1. Remove the engine cover.
- 2. Disconnect the ignition coil connector(A).




SGHEE7002N

# **NOTE**

When removing the ignition coil connector, pull the lock pin(A) and push the clip(B).

ىركت ديجيتال خودرو سامانه (مسئوليت محدود

سامانه دیجیتال تعمیرکاران خودرو در ایران



ABGE003A

- 3. Remove the ignition coil (B).
- 4. Installation is the reverse of removal.

**CHARGING SYSTEM EE-11** 

# **CHARGING SYSTEM**

#### **DESCRIPTION** EC071E4B

The charging system includes a battery, an alternator with a built-in regulator, and the charging indicator light and wire.

The Alternator has built-in diodes, each rectifying AC current to DC current.

Therefore, DC current appears at alternator "B" terminal. In addition, the charging voltage of this alternator is regulated by the battery voltage detection system.

The main components of the alternator are the rotor, stator, rectifier, capacitor brushes, bearings and V-ribbed belt pulley. The brush holder contains a built-in electronic voltage regulator.

# **ON-VEHICLE INSPECTION**

#### CAUTION

- · Check that the battery cables are connected to the correct terminals.
- Disconnect the battery cables when the battery is given a guick charge.
- · Never disconnect the battery while the engine is running.

#### CHECK THE BATTERY TERMINALS AND FUSES

- Check that the battery terminals are not loose or corroded.
- Check the fuses for continuity.

#### **INSPECT DRIVE BELT**


Visually check the belt for excessive wear, frayed cords

If any defect has been found, replace the drive belt.





Cracks on the rib side of a belt are considered acceptable. If the belt has chunks missing from the ribs, it should be replaced.



EBKD004B

#### VISUALLY CHECK ALTERNATOR WIRING AND LISTEN FOR ABNORMAL NOISES

- Check that the wiring is in good condition.
- Check that there is no abnormal noise from the alternator while the engine is running.

## CHECK DISCHARGE WARNING LIGHT CIRCUIT

- 1. Warm up the engine and then turn it off.
- 2. Turn off all accessories.
- 3. Turn the ignition switch "ON". Check that the discharge warning light is lit.
- 4. Start the engine. Check that the light is lit.
  If the light does not go off as specified, troubleshoot the discharge light circuit.

# VOLTAGE DROP TEST OF ALTERNATOR OUTPUT WIRE

This test determines whether or not the wiring between the alternator "B" terminal and the battery (+) terminal is good by the voltage drop method.

#### **PREPARATION**


- 1. Turn the ignition switch to "OFF".
- 2. Disconnect the output wire from the alternator "B" terminal. Connect the (+) lead wire of ammeter to the "B" terminal of alternator and the (-) lead wire of ammeter to the output wire. Connect the (+) lead wire of voltmeter to the "B" terminal of alternator and the (-) lead wire of voltmeter to the (+) terminal of battery.

## **RESULT**

1. The voltmeter may indicate the standard value.

Standard value: 0.2V max

- 2. If the value of the voltmeter is higher than expected (above 0.2V max.), poor wiring is suspected. In this case check the wiring from the alternator "B" terminal to the battery (+) terminal. Check for loose connections, color change due to an over-heated harness, etc. Correct them before testing again.
- Upon completion of the test, set the engine speed at idle.
  - Turn off the headlamps, blower motor and the ignition switch.



BBGE002A

#### **TEST**

- 1. Start the engine.
- Turn on the headlamps and blower motor, and set the engine speed until the ammeter indicates 20A.
   And then, read the voltmeter at this time.



CHARGING SYSTEM EE -13

## **OUTPUT CURRENT TEST**

This test determines whether or not the alternator gives an output current that is equivalent to the normal output.

#### **PREPARATION**

1. Prior to the test, check the following items and correct as necessary.

Check the battery installed in the vehicle to ensure that it is in good condition. The battery checking method is described in the section "Battery".

The battery that is used to test the output current should be one that has been partially discharged. With a fully charged battery, the test may not be conducted correctly due to an insufficient load.


Check the tension of the alternator drive belt. The belt tension check method is described in the section "Inspect drive belt".

- 2. Turn off the ignition switch.
- 3. Disconnect the battery ground cable.
- 4. Disconnect the alternator output wire from the alternator "B" terminal.
- Connect a DC ammeter (0 to 150A) in series between the "B" terminal and the disconnected output wire. Be sure to connect the (-) lead wire of the ammeter to the disconnected output wire.

# ولین سامانه دیجیتال تعمیرکاران خودر 😈 🔟

Tighten each connection securely, as a heavy current will flow. Do not rely on clips.

- Connect a voltmeter (0 to 20V) between the "B" terminal and ground. Connect the (+) lead wire to the alternator "B" terminal and (-) lead wire to a good ground.
- 7. Attach an engine tachometer and connect the battery ground cable.
- 8. Leave the engine hood open.



#### SCMEE6022N

#### **TEST**

- Check to see that the voltmeter reads as the same value as the battery voltage. If the voltmeter reads 0V, and the open circuit in the wire between alternator "B" terminal and battery (-) terminal or poor grounding is suspected.
- 2. Start the engine and turn on the headlamps.
- Set the headlamps to high beam and the heater blower switch to HIGH, quickly increase the engine speed to 2,500 rpm and read the maximum output current value indicated by the ammeter.

# NOTE

After the engine start up, the charging current quickly drops.

Therefore, the above operation must be done quickly to read the maximum current value correctly.



## **RESULT**

The ammeter reading must be higher than the limit value. If it is lower but the alternator output wire is in good condition, remove the alternator from the vehicle and test it.

Limit value: 65A min.

## III NOTE

- The nominal output current value is shown on the nameplate affixed to the alternator body.
- The output current value changes with the electrical load and the temperature of the alternator itself.

Therefore, the nominal output current may not be obtained. If such is the case, keep the headlamps on the cause discharge of the battery, or use the lights of another vehicle to increase the electrical load.

The nominal output current may not be obtained if the temperature of the alternator itself or ambient temperature is too high.

In such a case, reduce the temperature before testing again.


- Upon completion of the output current test, lower the engine speed to idle and turn off the ignition switch.
- Disconnect the battery ground cable.
- Remove the ammeter and voltmeter and the engine tachometer.
- Connect the alternator output wire to the alternator 5. "B" terminal.
- Connect the battery ground cable.

#### REGULATED VOLTAGE TEST

The purpose of this test is to check that the electronic voltage regulator controls voltage correctly.

#### **PREPARATION**

- 1. Prior to the test, check the following items and correct if necessary.
  - Check that the battery installed on the vehicle is fully charged. The battery checking method is described in the section "Battery".
  - Check the alternator drive belt tension. The belt tension check method is described in the section "Inspect drive belt".
- Turn ignition switch to "OFF".
- Disconnect the battery ground cable. 3.
- Connect a digital voltmeter between the "B" terminal of the alternator and ground. Connect the (+) lead of the voltmeter to the "B" terminal of the alternator. Connect the (-) lead to good ground or the battery (-) terminal.
- Disconnect the alternator output wire from the alternator "B" terminal.
- 6. Connect a DC ammeter (0 to 150A) in series between the "B" terminal and the disconnected output wire. Connect the (-) lead wire of the ammeter to the disconnected output wire.
- Attach the engine tachometer and connect the battery ground cable.



SCMEE6023N

CHARGING SYSTEM EE -15

#### **TEST**

 Turn on the ignition switch and check to see that the voltmeter indicates the following value.

Voltage: Battery voltage

If it reads 0V, there is an open circuit in the wire between the alternator "B" terminal and the battery and the battery (-) terminal.

- 2. Start the engine. Keep all lights and accessories off.
- 3. Run the engine at a speed of about 2,500 rpm and read the voltmeter when the alternator output current drops to 10A or less

### **RESULT**

 If the voltmeter reading agrees with the value listed in the regulating voltage table below, the voltage regulator is functioning correctly. If the reading is other than the standard value, the voltage regulator or the alternator is faulty.

# REGULATING VOLTAGE TABLE


| Voltage regulator ambient temperature °C (°F) | Regulating voltage (V) | ~          |
|---|------------------------|------------|
| -30 (-22)                                     | 14.2 ~ 15.3            | رىت دىب    |
| 25 (77)                                       | 14.2 ~ 14.8            |            |
| 135 (275)                                     | 13.3 ~ 14.8            | ولين سامان |
|   |                        |            |

- 2. Upon completion of the test, reduce the engine speed to idle, and turn off the ignition switch.
- 3. Disconnect the battery ground cable.
- 4. Remove the voltmeter and ammeter and the engine tachometer.
- Connect the alternator output wire to the alternator "B" terminal.
- Connect the battery ground cable.

# **EE** -16

# **ALTERNATOR**

# COMPONENTS ECA2A444



- 1. Generator front frame assembly
- 2. Bolt
- 3. Rotor assembly


- 4. Stator assembly
- 5. Rear bracket assembly
- 6. Regulator assembly

SGHEE7008N

CHARGING SYSTEM EE -17

# REMOVAL E5D43CDB

- 1. Disconnect the battery negative terminal first, then the positive terminal.
- 2. Disconnect the alternator connector, and remove the cable from alternator "B" terminal.
- 3. Remove the drive belt.
- 4. Pull out the through bolt and then remove the alternator(A).




Installation is the reverse of removal.

SGHEE7004N

بتال حود

DISASSEMBLY E17973D4


- 1. If the front bearing needs replacing, remove the pulley with a hexagonal wrench.
- 2. Remove the generator cover(A) after removing the three nuts(B).



SCMEE6009N

3. Remove the brush holder(A).

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




SCMEE6010N

# **EE** -18


# **ENGINE ELECTRICAL SYSTEM**

4. Remove the four screws, the rectifier(B) and the rubber seal(C).




SCMEE6011N


6. Remvoe the rear bracket assembly(A) and washer(B).



SCMEE6014N

5. Remove the four nuts(A) and insulators(B).





A B SCMEE6015N


SCMEE6013N

CHARGING SYSTEM EE -19

# INSPECTION E2A74301

## **ROTOR**

 Check that there is continuity between the slip rings(A). If there is no continuity, replace the generator.




SCMEE6016N


#### STATOR

 Check that there is continuity between each pair of leads(A). If there is no continuity, repalce the generator.

## **RECTIFIER**

1. Check for continuity in each direction, between the B terminal(A) and P terminals(B), between the E terminal(C) and P terminals(B) of each diode pair. All diodes should have continuity in only one direction. Because the rectifier diodes are designed to allow current to pass in one direction, and the rectifier is made up of eight diodes(four pairs), you must test each diode in both directions for continuity with an ohmmeter that has diode checking capability: a total of 16 checks. If any diode failed, replace the rectifier assembly.






SCMEE6020N


# **REASSEMBLY**

**NOTE** 


Becareful not to get any grease or oil on the slip rings.


Insert the rotor(A) in the stator and front frame assembly(B).













SCMEE6014N


Tighten the four nuts and insulators(B).



SCMEE6024N




Install the rectifier(B) and the rubber seal(C) by tightening the four screws(A),



SCMEE6011N


CHARGING SYSTEM EE -21

5. Install the brush holder(A).



SCMEE6010N

6. Install the generator cover(A) by tightening the three nuts(B).



7. Install the pulley with a hexagonal wrench.

# **ENGINE ELECTRICAL SYSTEM**

# **EE -22**

# **BATTERY**

## **DESCRIPTION**

E7B98282

- The maintenance-free battery is, as the name implies, totally maintenance free and has no removable battery cell caps.
- 2. Water never needs to be added to the maintenance-free battery.
- 3. The battery is completely sealed, except for small vent holes in the cover.






CHARGING SYSTEM EE -23

# INSPECTION E2C813

## **BATTERY DIAGNOSTIC FLOW**



SGHEE7001L

## **LOAD TEST**

- 1. Perform the following steps to complete the load test procedure for maintenance free batteries.
- 2. Connect the load tester clamps to the terminals and proceed with the test as follow:
  - If the battery has been on charge, remove the surface charge by connecting a 300ampere load for 15 seconds.
  - 2) Connect the voltmeter and apply the specified load.
  - 3) Read the voltage after the load has been applied for 15 seconds.
  - 4) Disconnect the load.
  - Compare the voltage reading with the minimum and replace the battery if battery test voltage is below that shown in the voltage table.

| Voltage | Temperature             |
|---------|-------------------------|
| 9.6V    | 20°C (68.0°F) and above |
| 9.5V    | 16°C (60.8°F)           |
| 9.4V    | 10°C (50.0°F)           |
| 9.3V    | 4°C (39.2°F)            |
| 9.1V    | -1°C (30.2°F)           |
| 8.9V    | -7°C (19.4°F)           |
| 8.7V    | -12°C (10.4°F)          |
| 8.5V    | -18°C (-0.4°F)          |

# **NOTE**

- If the voltage is greater than shown in the table, the battery is good.
- If the voltage is less than shown in the table, replace the battery.


# CLEANING EDF5094

- 1. Make sure the ignition switch and all accessories are in the OFF position.
- 2. Disconnect the battery cables (negative first).
- 3. Remove the battery from the vehicle.



Care should be taken in the event the battery case is cracked or leaking, to protect your skin from the electrolyte.

Heavy rubber gloves (not the household type) should be worn when removing the battery.



- 4. Inspect the battery tray for damage caused by the loss of electrolyte. If acid damage is present, it will be necessary to clean the area with a solution of clean warm water and baking soda. Scrub the area with a stiff brush and wipe off with a cloth moistened with baking soda and water.
- 5. Clean the top of the battery with the same solution as described above.
- Inspect the battery case and cover for cracks. If cracks are present, the battery must be replaced.
- 7. Clean the battery posts with a suitable battery post tool.
- 8. Clean the inside surface of the terminal clamps with a suitable battery cleaning tool. Replace damaged or frayed cables and broken terminal clamps.
- 9. Install the battery in the vehicle.
- Connect the cable terminals to the battery post, making sure tops of the terminals are flush with the tops of the posts.

**CHARGING SYSTEM** EE -25

- 11. Tighten the terminal nuts securely.
- 12. Coat all connections with light mineral grease after tightening.



# ( CAUTION

When batteries are being charged, an explosive gas forms beneath the cover of each cell. Do not smoke near batteries being charged or which have recently been charged. Do not break live circuit at the terminals of batteries being charged. A spark will occur when the circuit is broken. Keep open flames away from battery.





# STARTING SYSTEM

# **DESCRIPTION** EBD6AA2E

The starting system includes the battery, starter, solenoid switch, ignition switch, inhibitor switch (A/T), ignition lock switch, connection wires and the battery cable.

When the ignition key is turned to the start position, current flows and energizes the starter motor's solenoid coil.

The solenoid plunger and clutch shift lever are activated, and the clutch pinion engages the ring gear.

The contacts close and the starter motor cranks. In order to prevent damage caused by excessive rotation of the starter armature when the engine starts, the clutch pinion gear overruns.

#### TROUBLESHOOTING FD641D7C


## STARTER CIRCUIT



# III NOTE

The battery must be in good condition and fully charged.

Remove the fuel pump relay(A) from the fuse box.



SGHEE7003N

With the shift lever in N or P (A/T) or clutch pedal pressed (M/T), turn the ignition switch to "START"

If the starter normally cranks the engine, starting system is OK. If the starter will not crank the engine at all, go to next step.

If it won't disengage from the ring gear when you release key, check for the following until you find the cause.

- Solenoid plunger and switch malfunction.
- Dirty pinion gear or damaged overrunning clutch.
- 3. Check the battery condition. Check electrical connections at the battery, battery negative cable connected to the body, engine ground cables, and the starter for looseness and corrosion. Then try starting the engine again.

If the starter cranks normally the engine, repairing the loose connection repaired the problem. The starting system is now OK.

If the starter still does not crank the engine, go to next step.

STARTING SYSTEM EE -27


 Disconnect the connector from the S-terminal of solenoid. Connect a jumper wire from the B-terminal of solenoid to the S-terminal of solenoid.

If the starter cranks the engine, go to next step. If the starter still does not crank the engine, remove the starter, and repair or replace as necessary.

- 5. Check the following items in the order listed until you find the open circuit.
  - Check the wire and connectors between the driver's under-dash fuse/relay box and the ignition switch, and between the driver's under-dash fuse/relay box and the starter.
  - Check the ignition switch (Refer to ignition system in BE Group).
  - Check the transaxle range switch connector or ignition lock switch connector.
  - · Inspect the starter relay.

#### STARTER SOLENOID TEST

- Disconnect the field coil wire from the M-terminal of solenoid switch.
- Connect the battery as shown. If the starter pinion pops out, it is working properly. To avoid damaging the starter, do not leave the battery connected for more than 10 seconds.




KBSE203D

Disconnect the battery from the M terminal.


If the pinion does not retract, the hold-in coil is working properly. To avoid damaging the starter, do not leave the battery connected for more than 10 seconds.

ر سامانه دیجیتال تعمیرکاران خودرو در ایران



KBSE203E


 Disconnect the battery also from the body. If the pinion retracts immediately, it is working properly. To avoid damaging the starter, do not leave the battery connected for more than 10 seconds.



KBSE203F

## **FREE RUNNING TEST**

- Place the starter motor in a vise equipped with soft jaws and connect a fully-charged 12-volt battery to starter motor as follows.
- Connect a test ammeter (100-ampere scale) and carbon pile rheostats as shown in the illustration.
- 3. Connect a voltmeter (15-volt scale) across starter motor.



# ديجيتال خودرو


BBGE005A

- ں خودرو سامانہ (مسئولیت محدود
  - ه دیجیتال تعمیرکاران خودر و در ایران
- 4. Rotate carbon pile to the off position.
- Connect the battery cable from battery's negative post to the starter motor body.
- Adjust until battery voltage shown on the voltmeter reads 11volts.
- 7. Confirm that the maximum amperage is within the specifications and that the starter motor turns smoothly and freely.

Current: 85A MAX Speed: 2,600 rpm MIN STARTING SYSTEM EE -29

# **STARTER**

# COMPONENTS E7B5C89E



- 1. Front bracket
- 2. Stop ring
- 3. Stopper
- 4. Overrun clutch assembly
- 5. Internal gear assembly
- 6. Lever
- 7. Lever packing
- 8. Magnet switch assembly

- 9. Planet shaft assembly
- 10. Planetary gear assembly
- 11. Packing
- 12. Shield
- 13. Armature assembly
- 14. Yoke assembly
- 15. Brush holder assembly
- 16. Through bolt

EBRF003A


# REMOVAL E62E99CD

- 1. Disconnect the starter cable from the B terminal on the solenoid, and the connector from the S terminal.
- 2. Remove the 2 bolts (D) holding the starter, then remove the starter (E).

## TROQUE:

 $49.0 \sim 63.7 \text{ Nm} (5.0 \sim 6.5 \text{ kgf.m}, 36.2 \sim 47.0$ 

lb-ft) - starter mounting(D)




SBLEA6003L

- Installation is the reverse of removal.
- 4. Connect the battery negative cable to the battery.




- Disconnect the M-terminal on the magnet switch assembly.
- 2. After loosening the 3 screws (A), detach the magnet switch assembly (B).



KBRF010A


. Loosen the through bolts (A)




KBRF011A

STARTING SYSTEM EE -31

4. Remove the brush holder assembly (A), yoke (b) and armature (C).



7. Disconnect the planet gear (A).




EBKD011I

KBRF012A


Remove the shield (A) and packing (B).

Disconnect the planet shaft assembly (A) and lever (B).




SBLEA6012L SBLEA6014L

6. Remove the lever plate (A) and lever packing (B).




9. Press the stop ring (A) using a socket (B).



SBLEA6013L

# **ENGINE ELECTRICAL SYSTEM**

10. After removing the stopper (A) using stopper pliers



EBKD011L


11. Disconnect the stop ring (A), overrunning clutch (B), internal gear (C) and planet shaft (D).

12. Reassembly is the reverse of disassembly.



**NOTE** 

Using a suitable pulling tool (A), pull the overrunning clutch stop ring (B) over the stopper (C).



EBKD0110





EBKD011M

STARTING SYSTEM EE -33

# INSPECTION E2E

#### **ARMATURE**


- Remove the starter.
- 2. Disassemble the starter as shown at the beginning of this procedure.
- Inspect the armature for wear or damage from contact with the permanent magnet. If there is wear or damage, replace the armature.

- 5. Measure the commutator (A) runout.
  - If the commutator runout is within the service limit, check the commutator for carbon dust or brass chips between the segments.
  - If the commutator run out is not within the service limit, replace the armature.


Commutator runout


Standard (New): 0.02mm (0.0008in.) max

Service limit: 0.05mm (0.0020in.)










EBKD012D

6. Check the mica depth (A). If the mica is too high (B), undercut the mica with a hacksaw blade to the proper depth. Cut away all the mica (C) between the commutator segments. The undercut should not be too shallow, too narrow, or v-shaped (D).


Commutator mica depth

Standard (New): 0.5 mm (0.0197 in.)

Limit: 0.2mm (0.0079 in.)




EBKD012B



EBKD012E

7. Check for continuity between the segments of the commutator. If an open circuit exists between any segments, replace the armature.




EBKD012F

Check with an ohmmeter that no continuity exists between the commutator (A) and armature coil core (B), and between the commutator and armature shaft (C).
 If continuity exists, replace the armature.

## STARTER BRUSH


Brushes that are worm out, or oil-soaked, should be replaced.




EBRF022A

#### STARTER BRUSH HOLDER

 Check that there is no continuity between the (+) brush holder (A) and (-) brush holder (B). If there is no continuity, replace the brush holder assembly.




EBKD012G



EBBD330A

STARTING SYSTEM EE -35

Pry back each brush spring (A) with a screwdriver, then position the brush (B) about halfway out of its holder, and release the spring to hold it there.



EBKD012K


 Install the armature in the housing, and install the brush holder. Next, pry back each brush spring again, and push the brush down until it seats against the commutator, then release the spring against the end of the brush.



To seat new brushes, slip a strip of #500 or #600 sandpaper, with the grit side up, between the commutator and each brush, and smoothly rotate the armature. The contact surface of the brushes will be sanded to the same contour as the commutator.

## **OVERRUNNING CLUTCH**

- Slide the overrunning clutch along the shaft. Replace it if does not slide smoothly.
- Rotate the overrunning clutch both ways.
   Does it lock in one direction and rotate smoothly in reverse? If it does not lock in either direction or it locks in both directions, replace it.



EBKD012J

 If the starter drive gear is worn or damaged, replace the overrunning clutch assembly. (the gear is not available separately).
 Check the condition of the flywheel or torque converter ring gear if the starter drive gear teeth are dam-


# CLEANING E936CE3C

- Do not immerse parts in cleaning solvent. Immersing the yoke assembly and/or armature will damage the insulation. Wipe these parts with a cloth only.
- Do not immerse the drive unit in cleaning solvent. The overrun clutch is pre-lubricated at the factory and solvent will wash lubrication from the clutch.
- 3. The drive unit may be cleaned with a brush moistened with cleaning solvent and wiped dry with a cloth.

# STARTER RELAY

# **INSPECTION** E3FF7813

- 1. Remove the fuse box cover.
- 2. Remove the starter relay (A).




SGHEE7005N

 Using an ohmmeter, check that there is continuity between each terminal.

| (Sossa Terminal | Continuity    |
|-----------------|---------------|
| 30 - 87         | NO            |
| 85 - 86         | YESI TO STATE |

 Apply 12V to terminal 85 and ground to terminal 86. Check for continuity between terminals 30 and 87.





LDAD510B


- 5. If there is no continuity, replace the starter relay.
- 6. Install the starter relay.
- 7. Install the fuse box cover.

**EE -37** 

# **CRUISE CONTROL SYSTEM**

### TROUBLE SYMPTOM CHARTS E0B03761

#### **TROUBLE SYMPTOM 1**



CC: Cruise Control

ECM: Engine Control Module

SCMEE6006N

### **ENGINE ELECTRICAL SYSTEM**

### TROUBLE SYMPTOM 2

EE -38

| Trouble symptom   | Probable cause                                  | Remedy  |
|---|---|---|
| The set vehicle speed varies greatly upward or downward                             | Malfunction of the vehicle speed sensor circuit | Repair the vehicle speed sensor system, or replace the part |
| "Surging" (repeated alternating acceleration and deceleration) occurs after setting | Malfunction of PCM                              | Check input and output signals at PCM                       |

#### **TROUBLE SYMPTOM 3**

| Trouble symptom   | Probable cause   | Remedy   |
|---|--|--|
| The CC system is not canceled when the brake pedal is depressed | Damaged or disconnected wiring of the brake pedal switch | Repair the harness or replace the brake pedal switch |
|   | Malfunction of the PCM signals                           | Check input and output signals at PCM                |

### **TROUBLE SYMPTOM 4**

| Trouble symptom   | Probable cause   | Remedy   |
|---|--|--|
| The CC system is not canceled when the shift lever is moved to the "N" position (It is canceled, however, when the brake pedal is depressed | Damaged or disconnected wiring of inhibitor switch input circuit | Repair the harness or repair or replace the inhibitor switch |
|   | Improper adjustment of inhibitor switch                          |  |
|   | Malfunction of the PCM signals                                   | Check input and output signals at PCM                        |

# TROUBLE SYMPTOM's اولین سامانه دیجیتال تعمیرکاران

| Trouble symptom                                   | Probable cause   | Remedy                                       |
|---|--|--|
| Cannot decelerate (coast) by using the SET switch | Temporary damaged or disconnected wiring of SET switch input circuit | Repair the harness or replace the SET switch |
|   | Malfunction of the PCM signals                                       | Check input and output signals at PCM        |

### **TROUBLE SYMPTOM 6**

| Trouble symptom  | Probable cause   | Remedy  |
|--|--|---|
| Cannot accelerate or resume speed by using the RESUME switch | Damaged or disconnected wiring, or short circuit, or RESUME switch input circuit | Repair the harness or replace the RESUME switch |
|  | Malfunction of the PCM signals   | Check input and output signals at PCM           |

### **TROUBLE SYMPTOM 7**

| Trouble symptom   | Probable cause                                  | Remedy  |
|---|---|---|
| CC system can be set while driving at a vehicle speed of less than 40km/h | Malfunction of the vehicle-speed sensor circuit | Repair the vehicle speed sensor system, or replace the part |
| (25mph), or there is no automatic cancellation at that speed              | Malfunction of the PCM signals                  | Check input and output signals at PCM                       |

EE -39


### **TROUBLE SYMPTOM 8**

| Trouble symptom   | Probable cause  | Remedy                                  |
|---|---|---|
| The cruise main switch indicator lamp does not illuminate (But CC | Damaged or disconnected bulb of cruise main switch indicator lamp | Repair the harness or replace the part. |
| system is normal)   | Harness damaged or disconnected                                   |   |





### SYSTEM BLOCK DIAGRAM EOB505AA



### COMPONENT PARTS AND FUNCTION OUTLINE

| Component part           |  | Function  |  |
|--------------------------|--|---|--|
| Vehicle-speed sensor     | speed sensor Converts vehicle speed to pulse.    |   |  |
| Power control module (PC | M)   | Receives signals from sensor and control switches;            |  |
| Cruise control indicator |  | Illuminate when CRUISE main switch is ON (Built into cluster) |  |
| Cruise Control switches  | CRUISE main switch                               | Switch for automatic speed control power supply.              |  |
|                          | Resume/Accel switch                              | Controls automatic speed control functions by                 |  |
|                          | Set/Coast switch                                 | Resume/Accel switch (Set/Coast switch)                        |  |
| Cancel switch            | Cancel switch                                    | Sends cancel signals to PCM                                   |  |
|                          | Brake-pedal switch                               |   |  |
|                          | Transaxle range switch (A/T) Clutch switch (M/T) |   |  |
| ETS motor                |  | Regulates the throttle valve to the set opening by PCM.       |  |

<sup>\*</sup> ETS: Electronic Throttle System

EE -41

#### **CRUISE CONTROL**

Cruise control system is engaged by "ON/OFF" main switch located on right of steering wheel column. System has the capability to cruise, coast, resume speed, and accelerate, and raise "tab-up" or lower "tab-down" set speed.

It also has a safety interrupt, engaged upon depressing brake or shifting select lever.

PCM is a speed control system that maintains a required vehicle speed at normal driving conditions.

The main components of cruise control system are mode control switches, transaxle range switch, brake switch, vehicle speed sensor, ECM and ETS motor that connect throttle body.

PCM contains a low speed limit which will prevent system engagement below a minimum speed of 40km/h (25mph). The operation of the controller is controlled by mode control switches located on steering wheel.

Transaxle range switch and brake switch are provided to disengage the cruise control system. The switches are on brake pedal bracket and transaxle. When the brake pedal is depressed or select lever shifted, the cruise control system is electrically disengaged and the throttle is returned to the idle position.

#### Cruise main switch

Cruise control system is engaged by pressing "ON/OFF" push button. Releasing "ON/OFF" push button release throttle, clears cruise memory speed, and puts vehicle in a non-cruise mode.

#### Coast/Set switch

COAST/SET switch located on right of steering wheel column has two positions - "Normal" and "Depressed". The set position - With COAST/SET switch depressed and then released the cruise speed will be set at the speed the vehicle was going when COAST/SET switch was released. The coast position - With COAST/SET switch fully depressed, driver can lower cruise speed. To decrease cruise speed, COAST/SET switch is held in, disengaging cruise control system. When vehicle has slowed to required cruise speed, releasing COAST/SET switch will re-engage system at new selected speed.

The tab down - To lower vehicle speed, cruise must be engaged and operating. Tab down is done by quickly pressing and releasing COAST/SET switch. Do not hold COAST/SET switch in depressed position.

Tab down is a function in which vehicle speed is decrease by 1 mph (1.6km/h)

#### Resume/Accel switch

RES/ACCEL switch located on right of steering wheel column has two positions - "Normal" and "Depressed".

The resume position - With RES/ACCEL switch depressed and then release, this switch also returns cruise control operation to last speed (Which is temporarily disengaged by Cancel switch or Brake pedal), setting when momentarily operating RES/ACCEL switch by constant acceleration.

The accel position - With RES/ACCEL switch depressed and held in, disengaging cruise control system, when vehicle has accelerated to required cruise speed, releasing RES/ACCEL switch will re-engage speed at new selected speed.

The tab up - To increase vehicle speed, the cruise must be engaged and operating.

Tab up is done by quickly pressing and releasing RES/AC-CEL switch less than 0.5 second. Do not hold RES/AC-CEL switch in depressed position. Tab up is a function in which cruise speed can be increased by 1mph (1.6km/h).

#### Cancel switch


Cruise control system is temporarily disengaged by pressing "CANCEL" switch.

Cruise speed canceled by this switch will be recovered by RES/ACCEL switch

#### **EE -42**

## DTC P0564 CRUISE CONTROL MULTI-FUNCTION INPUT "A" CIRCUIT

#### COMPONENT LOCATION E9DC6E9D



SGHEE7200L

### GENERAL DESCRIPTION E79BA8FE

The cruise control system keeps the vehicle running at a fixed speed until a signal canceling this fixed speed is received. When the main switch is turned on with vehicle in the running mode, the battery voltage is applied to the PCM. When a signal from the control switch is input to the PCM while the vehicle is in state, the PCM controls the ETS motor to make a car go at a steady speed you want. Also, while the system is operating, "CRUISE" indicator lamp in the meter assembly lights up.

### DTC DESCRIPTION E92229EA

If the swich signal's voltage is not within the calibrated ranges when PCM checks the switch signal under detecting condition, PCM sets P0564.

### DTC DETECTING CONDITION EF99DEC9

| Item              | Detecting Condition   | Possible Cause   |
|-------------------|---|--|
| DTC Strategy      | <ul> <li>Monitors the status of the invalid input when the input<br/>voltage is converted to the switch input signals.</li> </ul> | <ul><li>Poor connection</li><li>Open or short in cruise</li></ul>                |
| Enable Conditions | <ul><li>Engine is running</li><li>Ignition voltage 9V</li><li>Cruise control system type is learned</li></ul>                     | <ul><li>switch circuit</li><li>Faulty cruise switch</li><li>Faulty PCM</li></ul> |
| Threshold Value   | Invalid switch signal is monitored  |  |
| Diagnosis Time    | More than 7.8 seconds failure for 9.36 seconds test   |  |
| MIL On Condition  | NO MIL ON(DTC only)   |  |

**EE -43** 

### SPECIFICATION


| Item          | Resistance( ) |
|---------------|---------------|
| ON/OFF switch | 3.9 k ± 5 %   |
| SET switch    | 220 ± 5%      |
| RESUME switch | 910 ± 5%      |
| CANCEL switch | 0 ± 5%        |





#### **EE-44**

### SCHEMATIC DIAGRAM ECF8EAF8




SGHEE7201L

**EE-45** 

#### MONITOR DTC STATUS ESE

- 1. Connect scantool to Data Link Connector(DLC).
- 2. IG "ON".
- 3. Select "Diagnostic Trouble Codes(DTCs)" mode, and then Press F5(INFO) to check DTC's information from the DTCs menu.
- 4. Read "DTC Status" parameter.



SGHEE7202L

Is parameter displayed "Present fault"?



Go to "Terminal and Connector inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/ or PCM's connector or was repaired and PCM memory was not cleared.

Thoroughly check connectors for looseness, poor connection, ending, corrosion, contamination, deterioration, or damage. Repair or eplace as necessary and go to "Verification of vehicle Repair" procedure.

### TERMINAL AND CONNECTOR INSPECTION EBF25B80

- Many malfunctions in the electrical system are caused by poor harness and terminals.
   Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?



Repair as necessary and go to "Verification of Vehicle Repair" procedure .

NO

Go to " Power Circuit Inspection " procedure.

#### **EE-46**


### **ENGINE ELECTRICAL SYSTEM**

### POWER CIRCUIT INSPECTION EA4I

- 1. IG "OFF" and disconnect Cruise remocon connector.
- 2. IG "ON" and ENG "OFF".
- 3. Measure voltage between terminal 7 of Cruise remocon harness connector and chassis ground.

Specification: Approx. B+





2.Ground

7.Power supply

8.Cruise switch signal

SGHEE7203L

4. Is the measured voltage within specification?

YES

Go to "Signal Circuit Inspection" procedure.

NO


Repair open or short to ground in harness, and go to "Verification of Vehicle Repair" procedure.

### SIGNAL CIRCUIT INSPECTION ECOB2F99

- 1. Check voltage.
  - 1) IG "OFF" and disconnect Cruise remocon connector.
  - 2) IG "ON" and ENG "OFF".
  - 3) Measure voltage between terminal 8 of Cruise remocon harness connector and chassis ground.

Specification: Approx. 5V

M79



2.Ground

7. Power supply

8. Cruise switch signal

SGHEE7204L

**EE-47** 

4) Is the measured voltage within specification?




Go to "Component Inspection" procedure.



Go to "Check short in harness" as follows.

- 2. Check short in harness.
  - 1) IG "OFF" and disconnect Cruise remocon connector and PCM connector.
  - 2) Measure resistance between terminals 8 and 7 of Cruise remocon harness connector.
  - 3) Measure resistance between terminals 8 and 2 of Cruise remocon harness connector.

Specification: Infinite



Go to "Check open in harness' as follows.


NO

Repair short in harness, and go to "Verification of Vehicle Repair" procedure.

### **ENGINE ELECTRICAL SYSTEM**

- **EE-48**
- Check open in harness.
  - 1) IG "OFF" and disconnect Cruise remocon connector and PCM connector.
  - 2) Measure resistance between terminal 8 of Cruise remocon harness connector and terminal 25 of PCM harness connector.

Specification: Below 1



SGHEE7206L

3) Is the measured resistance within specification?



Go to "Component Inspection" procedure.



Repair open in harness, and go to "Verification of Vehicle Repair" procedure.


**EE-49** 

### COMPONENT INSPECTION

- 1. Check auto cruise switch.
  - 1) IG "OFF" and disconnect Cruise remocon connector.
  - 2) Measure resistance between terminals 8 and 7 of Cruise remocon connector with each switch depressed.(Component side).
  - 3) Measure resistance between terminals 8 and 2 of Cruise remocon connector with each switch depressed.(Component side).

#### Specification:

| Item          | Resistance( )                        |
|---------------|--------------------------------------|
| ON/OFF switch | 3.9 k ± 5% between terminals 8 and 7 |
| SET switch    | 220 ± 5% between terminals 8 and 2   |
| RESUME switch | 910 ± 5% between terminals 8 and 2   |
| CANCEL switch | 0 ± 5% between terminals 8 and 2     |



4) Is the measured resistance within specification?

## YES

Substitute with a known - good PCM and check for proper operation.

If the problem is corrected, replace PCM and go to "Verification of Vehicle Repair" procedure.

## NO

Substitute with a known - good auto cruise switch and check for proper operation.

If the problem is corrected, replace auto cruise switch and go to "Verification of Vehicle Repair" procedure.

## **NOTE**

There is a memory reset function on scantool that can erase optional parts automatically detected and memorized by PCM.

After testing PCM on the vehicle, use this function to reuse the PCM on the others.

### **ENGINE ELECTRICAL SYSTEM**

### **EE-50**

### VERIFICATION OF VEHICLE REPAIR ED9D201B

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F5(INFO) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 3. Read "DTC Status" parameter.
- 4. Is parameter displayed "History(Not Present) fault"?



System performing to specification at this time. Clear the DTC.

NO

Go to the applicable troubleshooting procedure.



EE -51

## DTC P0565 CRUISE CONTROL "ON" SIGNAL

COMPONENT LOCATION EFE096B0

Refer to DTC P0564.

GENERAL DESCRIPTION E51F2B44

Refer to DTC P0564.

DTC DESCRIPTION EDE7D1D7

If the main swich signal is switching too frequently or stuck for too long, PCM sets P0565.

### DTC DETECTING CONDITION ED4F12AC

| Item              | Detecting Condition  | Possible Cause   |
|-------------------|--|--|
| DTC Strategy      | <ul> <li>Monitors the switch is switching too frequently<br/>or stuck for too long.</li> </ul>   | <ul><li>Poor connection</li><li>Faulty cruise switch</li></ul> |
| Enable Conditions | <ul> <li>Engine is running</li> <li>Ignition voltage 9V</li> <li>Cruise control system type is learned</li> </ul>                                | Faulty PCM   |
| Threshold Value   | Input switch signal is switching too frequently or stuck   |  |
| Diagnosis Time    | <ul> <li>Switching: more than 1 second failure for 300 seconds test</li> <li>Stuck: more than 75 seconds failure for 300 seconds test</li> </ul> |  |
| MIL On Condition  | NO MIL ON(DTC only)  |  |

### **SPECIFICATION** E1A44FB2

Refer to DTC P0564.

SCHEMATIC DIAGRAM E823B53D

Refer to DTC P0564.

MONITOR DTC STATUS EBA88898

Refer to DTC P0564.

#### **EE-52**

### **ENGINE ELECTRICAL SYSTEM**

### TERMINAL AND CONNECTOR INSPECTION ECB69CE

- 1. Many malfunctions in the electrical system are caused by poor harness and terminals.

  Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?



Repair as necessary and go to "Verification of Vehicle Repair" procedure.




Go to "Component Inspection" procedure.

#### COMPONENT INSPECTION EFCA6FAG

- 1. Check auto cruise switch.
  - 1) IG "OFF" and disconnect Cruise remocon connector.
  - 2) Measure resistance between terminals 7 and 8 of Cruise remocon connector with "ON" switch depressed. (Component side).

#### Specification:

| ltem          | Resistance( )                        |
|---------------|--------------------------------------|
| ON/OFF switch | 3.9 k ± 5% between terminals 7 and 8 |



2.Ground

7.Power supply

8. Cruise switch signal

SGHEE7207L

**EE-53** 

3) Is the measured resistance within specification?



Substitute with a known - good PCM and check for proper operation.

If the problem is corrected, replace PCM and go to "Verification of Vehicle Repair" procedure.



Substitute with a known - good auto cruise switch and check for proper operation.

If the problem is corrected, replace auto cruise switch and go to "Verification of Vehicle Repair" procedure.



There is a memory reset function on scantool that can erase optional parts automatically detected and memorized by PCM.

After testing PCM on the vehicle, use this function to reuse the PCM on the others.

### VERIFICATION OF VEHICLE REPAIR EBDB132

Refer to DTC P0564.



### EE -54

### **ENGINE ELECTRICAL SYSTEM**

### DTC P0566 CRUISE CONTROL "CANCEL" SIGNAL

COMPONENT LOCATION EF65F096

Refer to DTC P0564.

GENERAL DESCRIPTION ECFASBE7

Refer to DTC P0564.

DTC DESCRIPTION E56F5ED5

If the cancel swich signal is switching too frequently or stuck for too long, PCM sets P0566.

### DTC DETECTING CONDITION EAA8BC56

| Item              | Detecting Condition  | Possible Cause   |
|-------------------|--|--|
| DTC Strategy      | <ul> <li>Monitors the switch is switching too frequently<br/>or stuck for too long.</li> </ul>   | <ul><li>Poor connection</li><li>Faulty cruise switch</li></ul> |
| Enable Conditions | <ul> <li>Engine is running</li> <li>Ignition voltage 9V</li> <li>Cruise control system type is learned</li> </ul>                                | Faulty PCM   |
| Threshold Value   | Input switch signal is switching too frequently or stuck   |  |
| Diagnosis Time    | <ul> <li>Switching: more than 1 second failure for 300 seconds test</li> <li>Stuck: more than 75 seconds failure for 300 seconds test</li> </ul> |  |
| MIL On Condition  | NO MIL ON(DTC only)  |  |

SPECIFICATION EFB9E506

Refer to DTC P0564.

SCHEMATIC DIAGRAM E4E769E3

Refer to DTC P0564.

MONITOR DTC STATUS E9C22CEF

Refer to DTC P0564.

TERMINAL AND CONNECTOR INSPECTION EEC4D161

Refer to DTC P0565.

**EE-55** 

### COMPONENT INSPECTION

- 1. Check auto cruise switch.
  - 1) IG "OFF" and disconnect Cruise remocon connector.
  - 2) Measure resistance between terminals 8 and 2 of Cruise remocon connector with "CANCEL" switch depressed.(Component side).

#### Specification:

| Item          | Resistance( )                    |
|---------------|----------------------------------|
| CANCEL switch | 0 ± 5% between terminals 8 and 2 |



SGHEE7208L

3) Is the measured resistance within specification?

YES

Substitute with a known - good PCM and check for proper operation.

If the problem is corrected, replace PCM and go to "Verification of Vehicle Repair" procedure.



Substitute with a known - good auto cruise switch and check for proper operation.

If the problem is corrected, replace auto cruise switch and go to "Verification of Vehicle Repair" procedure.



There is a memory reset function on scantool that can erase optional parts automatically detected and memorized by PCM.

After testing PCM on the vehicle, use this function to reuse the PCM on the others.

#### VERIFICATION OF VEHICLE REPAIR EF96DDB7

Refer to DTC P0564.

## EE -56

### **ENGINE ELECTRICAL SYSTEM**

## DTC P0567 CRUISE CONTROL "RESUME" SIGNAL

COMPONENT LOCATION E98A4F26

Refer to DTC P0564.

GENERAL DESCRIPTION E54910D8

Refer to DTC P0564.

DTC DESCRIPTION EADE9CEF

If the RESUME swich signal is switching too frequently or stuck for too long, PCM sets P0567.

### DTC DETECTING CONDITION EE6EBE39

| Item              | Detecting Condition  | Possible Cause   |
|-------------------|--|--|
| DTC Strategy      | <ul> <li>Monitors the switch is switching too frequently<br/>or stuck for too long.</li> </ul>   | <ul><li>Poor connection</li><li>Faulty cruise switch</li></ul> |
| Enable Conditions | <ul> <li>Engine is running</li> <li>Ignition voltage 9V</li> <li>Cruise control system type is learned</li> </ul>                                | Faulty PCM   |
| Threshold Value   | Input switch signal is switching too frequently or stuck   |  |
| Diagnosis Time    | <ul> <li>Switching: more than 1 second failure for 300 seconds test</li> <li>Stuck: more than 75 seconds failure for 300 seconds test</li> </ul> |  |
| MIL On Condition  | NO MIL ON(DTC only)  |  |

SPECIFICATION E4ABBOEE

Refer to DTC P0564.

SCHEMATIC DIAGRAM ECCCA753

Refer to DTC P0564.

MONITOR DTC STATUS EDA129C2

Refer to DTC P0564.

TERMINAL AND CONNECTOR INSPECTION EE56BC6F

Refer to DTC P0565.

**EE-57** 

### **COMPONENT INSPECTION**

- 1. Check auto cruise switch.
  - 1) IG "OFF" and disconnect Cruise remocon connector.
  - 2) Measure resistance between terminals 8 and 2 of Cruise remocon connector with "RESUME" switch depressed.(Component side).

#### Specification:

| Item          | Resistance( )                      |
|---------------|------------------------------------|
| RESUME switch | 910 ± 5% between terminals 8 and 2 |



SGHEE7208L

3) Is the measured resistance within specification?

YES

Substitute with a known - good PCM and check for proper operation.

If the problem is corrected, replace PCM and go to "Verification of Vehicle Repair" procedure.



Substitute with a known - good auto cruise switch and check for proper operation.

If the problem is corrected, replace auto cruise switch and go to "Verification of Vehicle Repair" procedure.



There is a memory reset function on scantool that can erase optional parts automatically detected and memorized by PCM.

After testing PCM on the vehicle, use this function to reuse the PCM on the others.

#### VERIFICATION OF VEHICLE REPAIR E7644B92

Refer to DTC P0564.

## EE -58 ENGINE ELECTRICAL SYSTEM

### DTC P0568 CRUISE CONTROL "SET" SIGNAL

COMPONENT LOCATION E6E4BACC

Refer to DTC P0564.

GENERAL DESCRIPTION E9B5D13F

Refer to DTC P0564.

DTC DESCRIPTION E1ED61CF

If the SET swich signal is switching too frequently or stuck for too long, PCM sets P0568.

### DTC DETECTING CONDITION ECD12425

| Item              | Detecting Condition  | Possible Cause   |
|-------------------|--|--|
| DTC Strategy      | <ul> <li>Monitors the switch is switching too frequently<br/>or stuck for too long.</li> </ul>   | <ul><li>Poor connection</li><li>Faulty cruise switch</li></ul> |
| Enable Conditions | <ul> <li>Engine is running</li> <li>Ignition voltage 9V</li> <li>Cruise control system type is learned</li> </ul>                                | Faulty PCM   |
| Threshold Value   | Input switch signal is switching too frequently or stuck   |  |
| Diagnosis Time    | <ul> <li>Switching: more than 1 second failure for 300 seconds test</li> <li>Stuck: more than 75 seconds failure for 300 seconds test</li> </ul> |  |
| MIL On Condition  | NO MIL ON(DTC only)  |  |

SPECIFICATION EA1FE46C

Refer to DTC P0564.

SCHEMATIC DIAGRAM E3167C61

Refer to DTC P0564.

MONITOR DTC STATUS EA49939A

Refer to DTC P0564.

TERMINAL AND CONNECTOR INSPECTION E102AF3F

Refer to DTC P0565

**EE-59** 

### **COMPONENT INSPECTION**

- 1. Check auto cruise switch
  - 1) IG "OFF" and disconnect Cruise remocon connector.
  - 2) Measure resistance between terminals 8 and 2 of Cruise remocon connector with "SET" switch depressed.(Component side)

#### Specification:

| Item       | Resistance( )                      |
|------------|------------------------------------|
| SET switch | 220 ± 5% between terminals 8 and 2 |



SGHEE7208L

3) Is the measured resistance within specification?

YES

Substitute with a known - good PCM and check for proper operation.

If the problem is corrected, replace PCM and go to "Verification of Vehicle Repair" procedure.

NO

Substitute with a known - good auto cruise switch and check for proper operation.

If the problem is corrected, replace auto cruise switch and go to "Verification of Vehicle Repair" procedure.



There is a memory reset function on scantool that can erase optional parts automatically detected and memorized by PCM.

After testing PCM on the vehicle, use this function to reuse the PCM on the others


#### VERIFICATION OF VEHICLE REPAIR E51C8DA0

Refer to DTC P0564.

### **EE-60**

## **CRUISE CONTROL MAIN SWITCH**

### CIRCUIT DIAGRAM EF4DDF0C



SGHEE7006N

EE -61

REMOVAL EB14E8F7

- 1. Disconnect the battery (-) terminal.
- 2. Remove the driver side air bag module.
- 3. Disconnect the cruise control switch connector and then remove the cruise control switch with two screws.
- 4. Installation is the reverse of removal.

### INSPECTION EE6C0D38

#### **MEASURING RESISTANCE**

 Disconnect the cruise control switch connector from the control switch.



SGHEE7007N

حیتال خودرو سامانه (مسئولیت محدود) مانه دیجیتال تعمیرکاران خودرو در ایران

 Measure resistance between terminals on the control switch when each function switch is ON (switch is depressed).


| Function switch | Terminal | Resistance |
|-----------------|----------|------------|
| Cruise Main     | 7-8      | 3.9k ± 1%  |
| Cancel          | 8-2      | 0 ± 1%     |
| Set/Coast       | 8-2      | 220 ± 1%   |
| Resume/Accel    | 8-2      | 910 ± 1%   |

3. If not within specification, replace switch.

### **EE-62**

#### **MEASURING VOLTAGE**

 Connect the cruise control switch connector to the control switch.



SGHEE7007N

2. Measure voltage between terminals on the harness side connector when each function switch is ON (switch is depressed).

| Function switch | Terminal | Voltage      |
|-----------------|----------|--------------|
| Cruise Main     | 7-8      |              |
| Cancel          | 8-2      | 0.0V ± 0.22V |
| Set/Coast       | 8-2      | 1.5V ± 0.22V |
| Resume/Accel    | 8-2      | 3.0V ± 0.22V |



