Brake System

GENERAL

BRAKE SYSTEM

BRAKE BOOSTER BRAKE LINE BRAKE PEDAL FRONT DISC BRAKE MASTER CYLINDER PROPORTIONING VALVE REAR DISC BRAKE REAR DRUM BRAKE

PARKING BRAKE SYSTEM

PARKING BRAKE PARKING BRAKE SWITCH

ABS (ANTI-LOCK BRAKE SYSTEM)

ANTI-LOCK BRAKING SYSTEM CONTROL MODULE FRONT WHEEL SPEED SENSOR REAR WHEEL SPEED SENSOR

EBD (ELECTRONIC BRAKE-FORCE DIS-TRIBUTION)

ESP(ELECTRONIC STABILITY PROGRAM) SYSTEM

YAW-RATE SENSOR ESP SWITCH STEERING WHEEL ANGLE SPEED SENSOR

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

ولين سامانه ديجيتال تعميركاران خودرو در ايران

GENERAL

SPECIFICATIONS EA11CB1B

Item	Specification
Master cylinder • Type • I.D. mm(in) • Piston stroke mm(in) • Output port(ABS/ESP) • Fluid level warning sensor	Tandem type 25.4/(1.0) 31(1.22) 2port Provided
Brake booster · Type · Effective dia. mm(in.) · Boosting ratio	Vacuum 8+9 in 9:1
Front brake(Disc) Type Disc O.D. Disc 1.D. Disc thickness Pad thickness Cylinder type Cylinder 1.D. 	Floating type with ventilated disc 280 mm (11.02 in) 172 mm (6.77 in.) 26 mm (1.02 in) 11 mm (0.43 in) single piston 57.2 mm (2.25 in.)
Rear brake(Drum) · Type · Drum I.D. · Lining width · Brake offset	Leading trailing drum 228.6 mm (9.0 in.) 42 mm (1.65 in.) 29.6 mm (1.17 in)
Rear brake(Disc) • Type • Disc O.D. • Parking Brake Drum I.D • Disc thickness • Pad thickness • Cylinder type • Cylinder I.D	Floating type with solid disc 262 mm (10.31 in.) 168 mm (6.61 in.) 10 mm (0.39 in.) 10 mm (0.39 in.) single piston 34 mm (1.34 in.)
Parking brake Actuation Cable arrangement 	Mechanical brake acting on rear wheels Lever

O.D=Outer Diameter I.D=Inner Diameter



ABS : Anti-lock Brake System ESP : Electronic Stability Program

BRAKE SYSTEM

GENERAL

SPECIFICATION (ABS) E6F779E2

Part	Item	Standard value	Remark
	System	4 channel 4 sensor (Solenoid)	
HECU(Hydraulic and Electronic Control Unit)	Туре	Motor, valve relay intergrated type	•ABS system:ABS & EBD control
	Operating voltage	10 V~16 V(DC)	
	Operating temperature	-40~120 °C(-40~248 °F)	
Warning lamp	Operating voltage	12 V	·ABS W/L:ABS failure ·Brake W/L:Parking, brake oil, EBD failure
	Current consumption	80 mA	
	Supply voltage	DC 4.5~2.0 V	
	Output current low	5.9~8.4 mA	Typ.7 mA
	Output current High	11.8~16.8 mA	Typ.14 mA
Acitve wheel speed	Frequency range	1~2500 HZ	0
sensor(ABS)	Air gap	0.4~1.0 mm (0.0157~0.04 in.)	
	Tone wheel	47 teeth	
مسئولیت محدود)	Output duty	30~70 %	

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

SPECIFICATION(ESP)

Part	Item	Standard value	Remark
	System	4 channel 4 sensor(Solenoid)	
HECU(Hydraulic and Electronic Control Unit)	Туре	Motor, valve relay intergrated type	•Total control(ABS, EBD, TCS, ESP)
	Operating voltage	10 V~16 V(DC)	
	Operating temperature	-40~120 °C(-40~248 °F)	
	Operating voltage	12 V	·ESP Operating
Warning lamp	Current consumption	80 mA	Lamp ·ESP Warning Lamp
	Supply voltage	DC 4.5~20 V	
	Output current low	5.9~8. mA	
Active wheel aread	Output current high	11.8~16.8 mA	
Active wheel speed sensor	Tone wheel	47 teeth	
	Frequency range	1~2500 HZ	
	Airgap	0.4~1.0 mm (0.02~0.04 in)	0
	Op <mark>er</mark> ating Voltage	8 V~16 V	
Steering Wheel Angle Sensor	Current Consumption	Max 150 mA	
سئوليت محدود)	Operating Angular velocity	Max ±2000 °/sec	
	Operating Voltage	8 V~16 V	
ترجمد رمدر ابدان	Current Consumption	Max. 120 mA	
Yaw-rate & Lateral	Output Voltage	0.35 V~4.65 V	
G sensor	Yaw Sensor Operating Range	±100 ° /s	
	G Sensor Operating Range	±1.8 G	
	Reference voltage output	2.464~2.536 V	Typ. 2.5 V

BRAKE SYSTEM

GENERAL

SERVICE STANDARD E9E4D54D

BR	-5
----	----

	Standard value	Service limit
Brake pedal height	184.5 mm(7.264 in.)	
Brake pedal full stroke	128 mm (5.04 in.)	
Adjust Brake pedal full stroke	76.2 mm(3 in.)	
Brake pedal free play	3~8 mm(0.11~0.31 in.)	
Stop lamp switch outer case to pedal stopper clearance	0.5~1.0 mm (0.02~0.04 in.)	
Booster push rod to master cylinder piston clearance	0 (at 500 mmHg vacuum)	
Parking brake lever stroke when lever assembly is pulled with 196N (20Kgf, 44lb force)	7 clicks	
Front disc brake pad thickness	11 mm (0.43 in.)	2 mm (0.079 in.)
Front disc thickness	26 mm (1.024 in.)	24.4 mm (0.961 in.)
Front disc runout		Max.0.03 mm (0.001 in.)
Front disc thickness variation		Max.0.005 mm (0.0002 in.)
Rear drum brake lining width	42 mm (1.65 in.)	
Rear drum brake drum I.D.	228.6 mm (9 in.)	Max.230.6mm (9.079 in.)
Rear disc brake pad thickness	10 mm (0.394 in.)	2 mm (0.079 in.)
Rear disc brake disc thickness	10 mm (0.394 in.)	8 mm (0.315 in.)
Rear disc runout		Max.0.03 mm (0.001 in.)
Rear disc thickness variation	اولين سامانه ديجيا	Max.0.01 mm (0.0004 in.)

TIGHTENING TORQUE

	Nm	Kgf-cm	lb-ft
Master cylinder to booster mounting nut	7.84~11.76	80~120	5.9~8.9
Brake booster mounting nut	12.74~15.68	130~160	9.6~11.8
Bleeder screw	6.86~12.74	70~130	5.2~9.6
Brake tube nut, brake hose	13.72~16.66 (M10) 18.62~22.54 (M12)	140~170 (M10) 190~230 (M12)	10.326~12.54 (M10) 14.01~16.964 (M12)
Caliper assembly to knuckle	78.4~98	800~1000	59.0~73.8
Brake hose to front caliper	24.5~29.4	250~300	18.4~22.1
Brake hub flange nut	196~254.8	2000~2600	147.5~191.8
Push rod locking nut	15.68~21.56	160~220	11.8~16.2
Caliper guide rod bolt	21.56~31.36	220~320	16.2~23.6
Stop lamp switch mounting nut	7.84~9.8	80~100	5.9~7.38

BRAKE SYSTEM

TIGHTENING TORQUE (ABS)

BR -6

Item	Nm	kgf⋅cm	lb-ft
Active wheel speed sensor mounting bolt on the brake plate	7.84~8.82	80~90	5.9~6.54
Hydraulic & electronic control unit mounting bolt	13.72~17.64	140~180	10.326~13.276
Hydraulic & electronic control unit mounting bracket bolt	16.66~25.48	170~260	12.54~19.177
Brake tubes nut	13.72~16.66	140~170	10.326~12.54
Air bleeder screw	6.86~12.74	70~130	5~9.6

TIGHTENING TORQUE (ESP)

Item	Nm	kgf⋅cm	lb-ft
Yaw rate & lateral acceleration sensor Nut	4.9~7.84	50~80	3.69~5.9
Brake tube nut	13.72~16.66 (M10) 18.62~22.54(M12)	140~170 (M10) 190~230(M12)	10.326~12.54 (M10) 14.01~16.964 (M12)

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

GENERAL

SPECIAL TOOL EF2DDBAE

Tool(Number and Name)	Illustration	Use
09581-11000 Piston expander	EJDA043A	Spreading the front disc brake piston

TROUBLESHOOTING E8F58C98

PROBLEM SYMPTOMS TABLE

Use the table below to help you find the cause of the problem. The numbers indicate the priority of the like cause of the problem. Check each part in order. If necessary, replace these parts

Symptom	Suspect Area	Reference
Lower pedal or spongy pedal	 Brake system (Fluid leaks) Brake system (Air in) Piston seals (Worn or damaged) Rear brake shoe clearance(Out of adjustment) Master cylinder (Faulty) 	repair air-bleed replace adjust replace
Brake drag	 Brake pedal freeplay (Minimum) Parking brake lever travel (Out of adjustment) Parking brake wire (Sticking) Rear brake shoe clearance(Out of adjustment) Pad or lining (Cracked or distorted) Piston (Stuck) Piston (Frozen) Anchor or Return spring (Faulty) Booster system (Vacuum leaks) Master cylinder (Faulty) 	adjust adjust repair adjust replace replace replace replace replace replace
Brake pull	 Piston (Sticking) Pad or lining (Oily) Piston (Frozen) Disc (Scored) Pad or lining (Cracked or distorted) 	replace replace replace replace replace
Hard pedal but brake inefficient	 Brake system (Fluid leaks) Brake system (Air in) Pad or lining (Worn) Pad or lining (Cracked or distorted) Rear brake shoe clearance(Out of adjustment) Pad or lining (Oily) Pad or lining (Glazed) Disc (Scored) Booster system (Vacuum leaks) 	repair air.bleed replace replace adjust adjust replace replace replace

021-62999292

BR -8

BRAKE SYSTEM

Symptom	Suspect Area	Reference
Noise from brake	1. Pad or lining (Cracked or distorted)	replace
	2. Installation bolt (Loosen)	adjust
	3. Disc (Scored)	replace
	4. Sliding pin (Worn)	replace
	5. Pad or lining (Dirty)	clean
	6. Pad or lining (Glazed)	replace
	7. Anchor or Return spring (Faulty)	replace
	8. Brake pad shim (Damage)	replace
	9. Shoe hold-down spring (Damage)	replace
Brake fades	1. master cylinder	replace
Brake vibration,	1. brake booster	replace
pulsation	2. pedal free play	adjust
	3. master cylinder	replace
	4. caliper	replace
	5. master cylinder cap seal	replace
	6. damaged brake lines	replace
Brake Chatter	Brake chatter is usually caused by loose or worn components, or glazed or burnt linings. Rotors with hard spots can also contribute to brake chatter. Additional causes of chatter are out-of-tolerance rotors, brake lining not securely attached to the shoes, loose wheel bearings and contaminated brake lining.	

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

BRAKE SYSTEM

OPERATION AND LEAKAGE

CHECK ECC7DE4E

CHECK ALL OF THE FOLLOWING ITEMS:

Component	Procedure
Brake Booster (A)	Check brake operation by applying the brakes during a test drive. If the brakes do not work properly, check the brake booster. Replace the brake booster as an assembly if it does not work properly or if there are signs of leakage.
Piston cup and pressure cup inspection (B)	 Check brake operation by applying the brakes. Look for damage or signs of fluid leakage. Replace the master cylinder as an assembly if the pedal does not work properly or if there is damage or signs of fluid leakage. Check for a difference in brake pedal stroke between quick and slow brake applications. Replace the master cylinder if there is a difference in pedal stroke.
Brake hoses (C)	Look for damage or signs of fluid leakage. Replace the brake hose with a new one if it is damaged or leaking.
Caliper piston seal and piston boots (D)	Check brake operation by applying the brakes. Look for damage or signs of fluid leakage. If the pedal does not work properly, the brakes drag, or there is damage or signs of fluid leakage, disassemble and inspect the brake caliper. Replace the boots and seals with new ones whenever thebrake caliper is disassembled.



EJRF500A

021-62999292

WWW.DIGITALKHODRO.COM

021-62999292

BRAKE SYSTEM

BR -10

BRAKE BOOSTER OPERATING TEST

For simple checking of the brake booster operation, carry out the following tests

- Run the engine for one or two minutes, and then stop it. If the pedal depresses fully the first time but gradually becomes higher when depressed succeeding times, the booster is operating properly, if the pedal height remains unchanged, thebooster is defective.
- With the engine running, step on the brake pedal and then stop the engine.
 Hold the pedal depressed for 30 seconds. If the pedal height does not change, the booster is in good condition, if the pedal rises, the booster is defective.
 If the above three tests are okay, the booster performance can be determined as good.
 Even if one of the above three tests is not okay, check the check valve, vacuum hose and booster for defect.



When engine is stopped

When engine is started



EGGB700B

BRAKE SYSTEM

VACUUM HOSE (CHECK VALVE)

INSPECTION

- 1. Disconnect the brake booster vacuum hose (check valve built in) (A) at the booster (B).
- 2. Start the engine and let it idle. There should be vacuum available. If no vacuum is available, the check valve is not working properly. Replace the brake booster vacuum hose and check valve and retest.

BRAKE PEDAL BRAKE SWITCH ADJUSTMENT

PEDAL HEIGHET

- Disconnect the brake switch connector, loosen the brake switch locknut (A), and brake off the brake switch (B) until it is no longer touching the brake pedal.
- 2. Lift up the carpet. At the insulator cutout, measure the pedal height (C) from the middle of the left-side center of the pedal pad (D).

Standard pedal height(with carpet removed): 184.5 mm(7.26 in.)

EJRF500D

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

EJKE001A

BRAKE SYSTEM

3. Loosen the pushrod locknut (A), and screw the pushrod in or out with pliers until the standard pedal height from the floor is reached. After adjustment, tighten the locknut firmly. Do not adjust the pedal height with the pushrod depressed.



EJRF500E

BRAKE SWITCH CLEARANCE

Screw in the brake switch until its plunger is fully depressed (threded end (A) touching the pad (B) on the pedal arm) then brake off the switch 3/4 turn to make 0.5~1.0mm(0.0197~0.0394 in.) of clearance between the brake switch connector. Make sure that the brake lights go off when the pedal is released.

رسامانه دیجیتال تعمیرکاران خودرو در ایران

PEDAL FREE PLAY

1. With the engine off, inspect the pedal free play (A) on the pedal pad (B) by pushing the pedal by hand.

Free play: 3~8 mm (0.12~0.31 in.)



 If the pedal free play is out of specification, adjust the brake switch (C). If the pedal free play is insufficient, it may result in brake drag.



EJKE001C

BRAKE SYSTEM

INSPECTION OF FRONT DISC BRAKE PAD

1. Check the brake pad thickness through the caliper body inspection hole.

Pad thickness

Standard value : 11.0 mm (0.43 in.) Service limit : 2.0 mm (0.0787 in.)

INSPECTION OF REAR DISC BRAKE PAD

1. Check the rear disk brake pad thickness through the caliper body inspection hole.

Pad thickness Standard value : 10.0 mm (0.39 in.) Service limit : 2.0 mm (0.0787 in.)

EGGE700M

BR -13

- If the pad thickness is out of specification, left and right pads must be replaced as a complete set.
- When the thickness difference between the left pad and right pad is large, check the slid-ing condition of the piston and the guide rod.

• If the pad lining thickness is out of specilfication, left and right pads must be replaced as a complete set.

KJQE050H

 When the thickness difference between the left pad and right pad is large, check the sliding condition of the piston and the guide rod.



BRAKE SYSTEM

BR -14

BRAKE BOOSTER

COMPONENTS E7AF580C



- 2. Check valve
- 3. Snap pin
- 4. Seal

- 6. Brake booster
- 7. Master cylinder
- 8. Washer

EJRF500F

021-62999292

BR -15

BRAKE SYSTEM

REMOVAL EDB5B296

- 1. Remove the master cylinder.
- 2. Disconnect the vacuum hose (A) from the brake booster (B).
- LIFEOU LIFEOU

EJRF500G



5. Remove the brake booster (A).

021- 62 99 92 92

BRAKE SYSTEM

BR -16

INSTALLATION E50AF6FE

1. Adjust push rod length of the booster, and then install the seal on the booster assembly.

Standard length (A): 108 ± 0.5 mm (4.25 ± 0.019 in.)

- 4. Install the master cylinder.
- 5. Connect the vacuum hose to the brake booster.
- 6. After filling the brake reservoir with brake fluid, bleed the system.
- 7. Check for fluid leakage.
- 8. Check and adjust the brake pedal for proper operation.

2. Insert the booster and tighten the nuts (C).



ΠD

A

EJRF500H

KJQE050C

3. Connect the booster push rod and brake pedal with a pin (B) and install a snap clevis pin (A) to the clevis pin (B).

Grease the pin before installing the snap pin. Always use a new snap pin.

021-62999292

BRAKE SYSTEM

BRAKE LINE

COMPONENT EFDAF8C6



EJRF500I

021-62999292

BR -18

BRAKE SYSTEM

REMOVAL EB13C0C5

 Disconnect the brake hose(C) from the brake line(A) using a flare-nut wrench(B).



KJRE050A

2. Remove the bracket mounting bolt(A), and then remove the brake hose(B).

INSTALLATION E654E9E8

- 1. Install a brake hose on the caliper with tightening brake hose bolt.
- 2. Install the bracket and the brake hose mounting bolt.



EJRF500J

- 3. Connect the brake hose(A) to the brake line.
- 4. After installing the brake hose, bleed the brake system.

KJRE050B

3. Remove the connector bolt from the caliper, and disconnect the brake hose from the caliper.

BRAKE SYSTEM

INSPECTION E0905EE1

- Check the brake tubes for cracks, crimps and corrosion.
- Check the brake hoses for cracks, damaged and oil leakage.
- Check the brake tube flare nuts for damage and oil leakage.

BRAKE SYSTEM BLEEDING EGD5BODF

🔟 ΝΟΤΕ

- Do not reuse the drained fluid.
- Always use Genuine DOT3 or DOT 4 Brake Fluid. Using a non-Genuine DOT or 4 brake fluid can cause corrosion and decrease the life of the system.
- Make sure no dirt of other foreign matter is allowed to contaminate the brake fluid.
- Do not spill brake fluid on the vehicle, it may damage the paint; if brake fluid does contact the paint, wash it off immediately with water.
- The reservoir on the master cylinder must be at the MAX (upper) level mark at the start of bleeding procedure and checked after bleeding each brake caliper. Add fluid as required.

1. Make sure the brake fluid in the reservoir is at the MAX (upper) level line (A).

اولین سامانه دیجیتال تعمیرکاران خودرو در ایرار

- 2. Have someone slowly pump the brake pedal several times, then apply pressure.
- 3. Lossen the right-rear brake bleed screw to allow air to escape from the system. Then tighten the bleed screw securely.
- 4. Repeat the procedure for wheel in the sequence shown below unit air bubbles no longer appear in the fluid.
- 5. Refill the master cylinder reservoir to MAX(upper) level line.





EJQE003A

BR -19

BRAKE SYSTEM

FRONT DISC BRAKE

6.86~12.74 Nm (70~130 kgf cm, 5.09~9.45 lb-ft)



EJRF500K

REAR DRUM BRAKE



EJRF500L

WWW.DIGITALKHODRO.COM

BRAKE SYSTEM

BRAKE PEDAL

COMPONENTS EE12FE0E



- 2. Return spring
- 3. Stop lamp switch

5. Brake pedal

EJRF500M

WWW.DIGITALKHODRO.COM

BR -21

BRAKE SYSTEM

COMPONENTS (ADJUSTABLE PEDAL)



- 2. Bushing
- 3. Return spring

- 5. Shaft bolt
- 6. Brake pedal

EJRF500N

021-62999292

BR -23

EJQE008R

BRAKE SYSTEM

REMOVAL ECDCEE5C

- 1. Remove the lower crash pad.(Refer to BD-"crash pad")
- 2. Pull down steering column shaft after removing 4 bolts.
- 3. Remove the stop lamp switch connector (A).
- 4. Remove the shift lock cable (A/T).

INSTALLATION EE9A8E5E

1. Installation is the reverse of removal.

Coat the inner surface of the bushings with the specified grease.

Specified grease : SAE J310

2. Before inserting the pin, apply the specified grease to the joint pin.

- 5. Remove the pin and snap pin.
- 6. Loosen the brake pedal member assembly mounting nuts and then remove the brake pedal assembly.
- 3. Install the snap pin.
- 4. Install the nuts with specified torque, when installing the brake pedal.

TORQUE : Nm(kgf·cm,lb-ft); 12.74~15.68(130~160, 9.45~11.63)

- 5. Adjust the brake pedal height and free play.
- 6. Install the stop lamp switch.

021- 62 99 92 92

BR -24

INSPECTION EE61AEE1

- 1. Check the bushing for wear.
- 2. Check the brake pedal for bending or twisting.
- 3. Check the brake pedal return spring for damage.
- 4. Check the stop lamp switch.
 - Connect a circuit tester to the connector of stop lamp switch, and check whether or not there is continuity when the plunger of the stop lamp switch is pushed in and when it is released.
 - 2) The stop lamp switch is in good condition if there is no continuity when plunger(A) is pushed.



BRAKE SYSTEM

BRAKE SYSTEM

FRONT DISC BRAKE

COMPONENTS EAA0A1CD



- 2. Brake disc
- 3. Pad retainers
- 4. Guide rod bolt

- 5. Indicator
- 6. Brake pads
- 7. Brake pad shims

EJRF500P

BR -26

BRAKE SYSTEM



- 2. Bleeder screw
- 3. Guide rod
- 4. Boot
- 5. Caliper mounting bolt

- 7. Caliper bracket
- 8. Caliper body
- 9. Piston seal
- 10. Piston

- 12. Inner shim
- 13. Brake pad
- 14. Pad retainer
- 15. Outer shim

EJRF500Q

BRAKE SYSTEM

REMOVAL EBFCF815

🗥 CAUTION

3.

Frequent inhalation of brake pad dust, regardless of material composition, could be hazardous to your health.

- Avoid breathing dust particles.
- Never use on air hose or brush to clean brake assemblies.
- Lossen the front wheel nuts slightly. Raise the front of the vehicle, and make sure it is securely supported. Remove the front wheels.
- 2. Remove the guide rod bolt(B), After raise the caliper assembly(A), support it with a wire.



Remove pad shim(A), pad retainer(B) and pad as-

EFDB65AB

Install the pad retainers (A) on the caliper bracket.

ARJE501M

2. Check the foreign material at the pad shims (A) and the back of the pads (B).

Contaminated brake discs or pads reduce stopping ability. Keep grease off the discs and pads.



ARJE501N



sembly(C) in the caliper bracket.

ARJE501L

ean brake

1.

INSTALLATION

021-62999292

BR -28

BRAKE SYSTEM

3. Install the brake pads (B) and pad shims (A) correctly. Install the pad with the wear indicator (C) on the inside.

If you are reusing the pads, always reinstall the brake pads in their original positions to prevent a momentary loss of braking efficiency.

- 4. Push in the piston (A) so that the caliper will fit over the pads. Make sure that the piston boot is in position to prevent damaging it when pivoting the caliper down.
- Pivot the caliper down into position. Being careful not 5. to damage the pin boot, install the guide rod bolt (B) and torque it to proper specification.



Insert the piston in the cylinder using the special tool (09581-11000).



EGGE700L

Depress the brake pedal several times to make sure the brakes work, then test-drive.

NOTE

7.

Engagement of the brake may require a greater pedal stroke immediately after the brake pads have been replaced as a set. Several applications of the brake will restore the normal pedal stroke. Be sure to do this before driving the vehicle.

After installation, check for leaks at hose and line joints or connections, and retighten if necessary.

BRAKE SYSTEM

INSPECTION E1355021

FRONT BRAKE DISC THICKNESS CHECK

1. Remove all rust and contramination from the surface, and measure the disc thickness at 8 points, at least, of same distance (5 mm) front the brake disc outer circle.

Front brake disc thickness Standard value : 26.0 mm(1.024 in.) Limit : 24.4 mm(0.961 in.)

- 2. Thickness variation should not exceed 0.005 mm (0.0002 in.) (circumference) and 0.01 mm (in.)(radius) at any directions.
- 3. If wear exceeds the limit, replace the discs and pad assembly left and right of the vehicle.

5 mm (0.2 in.)

Ø

FRONT BRAKE PAD CHECK

1. Check the pad wear. Measure the pad thickness and replace it, if it is less than the specified value.

Pad thickness Standard value : 11 mm (0.43 in.) Service limit : 2.0 mm (0.0787 in.)



2. Check that grease is applied, to sliding contact points and the pad and backing metal for damage.

EJRF502O

BR -29

BRAKE SYSTEM

BR -30

FRONT BRAKE DISC RUN OUT CHECK

1. Place a dial gauge about 5mm (0.2 in.) from the outer circumference of the brake disc, and measure the run out of the disc.

Brake disc run out
Limit : 0.04 mm (0.0016 in.) or less (new one)

- 2. If the run out of the brake disc exceeds the limit specification, replace the disc, and then measure the run out again.
- 3. If the run out does not exceed the limit specification, install the brake disc after turning it 180° and then check the run out of the brake disc again.
- 4. If the run out cannot be corrected by changing the position of the brake disc, replace the brake disc.

SEIZE OF FRONT BRAKE DISC

1. Remove the brake disc from hub using M8 screw(A) if the brake disc has been seized with the hub due to corrosion or overheat.



Be careful not to use the hammer. The disc can be damaged if you remove the disc from the hub by hammer.





EJRF500T

EJRF502R

MASTER CYLINDER

COMPONENTS EE7F52A0



- 3. Reservoir
- 4. Grommet
- 5. Cylinder pin

- 7. Primary piston assembly
- 8. Secondary piston assembly
- 9. Master cylinder body
- 10. Proportioning valve

EJRF500U

BR -31

WWW.DIGITALKHODRO.COM

021-62999292

BRAKE SYSTEM

BR -32

REMOVAL ED2AAABE

🔟 ΝΟΤΕ

Do not spill brake fluid on the vehicle; it may damage the paint; if brake fluid does contact the paint, wash it off immediately with water.

- 1. Remove air cleaner mounting bolts (B) from the air cleaner mounting bracket and air cleaner body (A).
- 3. Remove the brake fluid from the master cylinder reservoir (C) with a syringe.
- 4. Disconnect the brake lines (A) from the master cylinder. To prevent spills, cover the hose joints with rags or shop towels.



- 5. Remove the master cylinder mounting nuts (B) and washers.
- Remove the master cylinder(C) from the brake booster (D). Be careful not to bend or damage the brake lines when removing the master cylinder.



2. Disconnect the brake fluid level switch connectors (A), and remove the reservoir cap (B).



ARJE500Y

BRAKE SYSTEM

INSTALLATION E4C7D3AC

- 1. Install the master cylinder on the brake booster with 2 nuts.
- 2. Connect 2 brake tubes and the brake fluid level sensor connector.

DISASSEMBLY EFGEABAC

- 1. Remove the reservoir cap and drain the brake fluid into a suitable container.
- 2. Remove the fluid level sensor.
- 3. Remove the reservoir from the master cylinder, after remove mounting screw (A).





EJRF500W

021-62999292

BR -34

6.

BRAKE SYSTEM

5. Remove the retainer ring by using the snap ring pliers then remove the primary piston assembly.

INSPECTION E47CBB11

- 1. Check the master cylinder bore for rust or scratch.
- 2. Check the master cylinder for wear or damage. If necessary, clean or replace the cylinder.

- If the cylinder bore is damaged, replace the master cylinder assembly.
- Wash the contaminated parts in alcohol.

REASSEMBLY E2A58FE6

- 1. Apply genuine brake fluid to the rubber parts of the cylinder kit and grommets.
- 2. Carefully insert the springs and pistons in the proper direction.



EJA9009C

KJQE014B

🔟 ΝΟΤΕ

Do not disassemble the primary and secondary piston assembly.

WWW.DIGITALKHODRO.COM



EGGE700F

021-62999292



Remove the pin with the secondary piston pushed

completely using a screwdriver. Remove the sec-

BRAKE SYSTEM

4. Press the piston with a screwdriver and install the retainer ring.





WWW.DIGITALKHODRO.COM

BR -35

PROPORTIONING VALVE

DESCRIPTION E7D9C04E

Do not disassemble the proportioning valve. The proportioning valve makes the ideal distribution of fluid pressure to the front and rear brakes to prevent the brakes from skidding in the event of rear wheel lock up and to obtain a higher brake efficiency within the range of service brake application.

INSPECTION EFA58D2B

- Remove the front brake tube (B) and rear brake tube (C) from the master cylinder (A).
- 2. Connect two pressure gauges (D); one to the output valve of the front (B) and rear (C) brake.

BRAKE SYSTEM

3. With the brake applied, measure the front pressure and the rear pressure.

If the measured pressures are within the specified range as illustrated, the proportioning valve is good.



EJRF500Y

. Reconnect the brake lines in their original positions and bleed the system.

ΝΟΤΕ

EJRF500X

This table shows characteristics of the proportioning valve as the pressure increases.

Input Pressure	Output Pressure
A : 35 kg/cm ²	A': 35 kg/cm ²
B : 80 kg/cm ²	B': 49.4 kg/cm ²

🔟 ΝΟΤΕ

Be sure to bleed the system after connecting the pressure gauges.
BRAKE SYSTEM

REAR DISC BRAKE

COMPONENTS EA4DDEDD



- 3. Guide rod
- 4. Boot
- 5. Piston

- 8. Pad retainer
- 9. Caliper mounting bolt
- 10. Washer

- 13. Brake Pad
- 14. Outer shim
- 15. Caliper bracket

EJRF500Z

WWW.DIGITALKHODRO.COM

021-62999292

021-62999292

BRAKE SYSTEM

BR -38

REMOVAL ECB86F4F

- 1. Raise the rear of the vehicle and make sure it is securely supported. Remove the rear wheel.
- 2. Remove the guide rod bolt(B), After raise the caliper assembly(A), support it with a wire.



ARJE501U

INSTALLATION EDC5ADC4

1. Install the pad retainers(A) on the caliper bracket.



ARJE501M

2. Check the foreign material at the pad shim (A) and the back of the pads (B).



ARJE501V

- . Contaminated brake discs or pads reduce stopping ability. Keep grease off the discs and pads.
- 4. Install the brake pads (B) and pad shims (A) correctly. Install the pad with the wear indicator (C) on the inside.

If you are reusing the pads, always reinstall the brake pads in their original position to prevent a momentary loss of braking efficiency.

5. Push in the piston (A) so that the caliper will fit over the pads. Make sure that the piston boot is in position to prevent damaging it when pivoting the caliper down.

BRAKE SYSTEM

6. Pivot caliper down into position. Being careful not to damage the pin boot, install the guide rod bolt (B) and torque it to proper specification



INSPECTION EAE7DA7F

REAR BRAKE DISC THICKNESS CHECK

1. Remove all rust and contamination from the disc surface, and then measure the disc thickness at 8 points, al least, of the same distance (5mm) from the brake disk outer circle.

Rear brake disc thickness Standard value : 10.0 mm (0.39 in.) Limit : 8.0 mm (0.315 in.)

- Thickness variation should not exceed
 0.01 mm(0.0004 in.) (circumference) and
 0.01 mm(0.0004 in.) (radius) at any directions.
- 3. If wear exceeds the limit, replace the discs and pad assembly for left and right of the vehicle.

EJRF501A



EGGE700L

7. Depress the brake pedal several time to make sure the brakes work, then test-drive.

🔟 ΝΟΤΕ

Engagement of the brake may require a greater pedal stroke immediately after the brake pads have been replaced as a set. Several applications of the brake will restore the normal pedal stroke.

8. After installaion, check for leaks at hose and line joints or connections, and retighten if necessary.

WWW.DIGITALKHODRO.COM

021-62999292

REAR BRAKE PAD CHECK

1. Check the pad wear. Measure the pad thickness and replace it, if it is less than the specified value.

Pad thickness

Standard value : 10.0 mm (0.39 in.) Service limit : 2.0 mm (0.0787 in.)

BRAKE SYSTEM

REAR BRAKE DISC RUN OUT CHECK

1. Place a dial gauge about 5 mm (0.2 in.) from the outer circumference of the brake disc, and measure the run out of the disc.

Brake disc run out Limit : 0.05 mm (0.002 in.) or less (new one)



2.

- 2. Check that grease is applied, and the pad and backing metal for damage.
- If the run out of the brake disc exceeds the limit specification, replace the disc, and then measure the run out again.
- If the run out does not exceed the limit specification, install the brake disc after turning it 180° and then check the run out of the brake disc again.
- 4. If the run out cannot be corrected by changing the position of the brake disc, replace the brake disc.

BRAKE SYSTEM

SEIZE OF REAR BRAKE DISC

1. Remove the brake disc from hub using M8 screw(A) if the brake disc has been seized with the hub due to corrosion or overheat.

NOTE

Be careful not to use the hammer. The disc can be damaged if you remove the disc from the hub by hammer.



EJRF502R

BRAKE SYSTEM

BR -42

REAR DRUM BRAKE

COMPONENTS E04DCF1B



- 2. Bleeder screw
- 3. Wheel cylinder
- 4. Shoe adjuster lever 5. Shoe adjuster
- 6. Shoe & lining assembly
- 7. Shoe hold down spring

- 8. Cup washer
- 9. Brake drum
- 10. Rear hub
- 11. Rear brake backing plate
- 12. Upper shoe return spring
- 13. Lower shoe return spring

EJRF501B

WWW.DIGITALKHODRO.COM

021-62999292

BRAKE SYSTEM

REMOVAL EBBBD1A2

🗥 CAUTION

Frequent inhalation of brake pad dust, regardless of material composition, could be hazardous to your health.

- Avoid breathing dust particles.
- Never use an air hose or brush to clean brake assemblies.
- 1. Remove the shoe hold down pins (B) by pushing the shoe hold cup washer (C) and turning them.
- 2. Disengage the upper return spring (A).

6. Remove shoe adjuster (B) and lever (C) from the brake shoes.



ARJE502H

- 7. Disconnect the brake tube (A) from the wheel cylinder.
- 8. Remove the bolt (C) and the wheel cylinder from the backing plate(D).

Α

R

12.74~16.66 Nm

(130~170 kgf cm, 9.45~12.36 lb-ft)

4.9~10.78 Nm

3.64~8 lb-ft)

(50~110 kgf cm,

- Remove the lower shoe return spring (B) as removing the brake shoe assembly(A). Make sure not to damage the dust cover on the wheel cylinder.
- 4. Disconnect the parking brake cable from the parking brake lever.
- 5. Remove the brake shoe assembly.

EJRF501C

BRAKE SYSTEM

BR -44

INSTALLATION E70DA3AC

🔟 ΝΟΤΕ

- Do not spill brake fluid on the vehicle: it may damage the paint; if brake fluid does contact the paint. Wash it off immediately with water.
- To prevent spills, cover the hose joints with rags or shop towels.
- Use only a genuine wheel cylinder special bolt.
- 1. Apply sealant (C) between the wheel cylinder (A) and backing plate (B), and install the wheel cylinder.

- 5. Hook the shoe adjuster then install to the brake shoe.
- Install the shoe adjuster assembly and upper return spring (D), noting the installation direction. Be careful not to damage the wheel cylinder dust covers.
- 7. Install the lower return spring (E).
- 8. Grease brake cylinder to the sliding surfaces as shown below. Wipe off any excess. Don't get grease on the brake linings.



LJIF501Y

- 4. Clean the threaded portions of adjuster sleeve (A) and push rod female (B). Grease the threads of the adjuster assembly,turn the adjuster bolt (C), adjusting the length of the shoe adjuster assembly.
- Grease brake cylinder to the brake shoe ends and opposite edges of the as shoes as shown below.
 Wipe off any excess. Don't get grease on the brake linings.





EGGE700W

WWW.DIGITALKHODRO.COM

021-62999292

BRAKE SYSTEM

- 10. Grease brake shoes (A) onto the backing plate. Be careful not to damage the wheel cylinder dust covers.
- 11. Install the shoe hold down pins (B), shoe hold down spring and the shoe hold down cup (C).



- 12. Install the brake drum.
- 13. Bleed the brake system,after refilling the brake fluid.
- 14. Depress the brake pedal several times to set the selfadjusting brake.
- 15. Adjust the parking brake.

INSPECTION EC923F30

🗥 CAUTION

Frequent inhalation of brake pad dust, regardless of material composition, could be hazardous to your health.

- Avoid breathing dust particles.
- Never use an air hose or brush to clean brake assemblies.

🔟 ΝΟΤΕ

- Contaminated brake linings or drums reduce stopping ability.
- Block the front wheels before jacking up the rear of the vehicle.
- 1. Raise the rear of the vehicle, and make sure it is securely supported.
- 2. Release the parking brake, and remove the rear brake drum.
- 3. Check the wheel cylinder (A) for leakage.
- 4. Check the brake linings (B) for cracking, glazing, wear, and contamination.
- 5. Measure the brake lining thickness (C). Measurement does not include brake shoe thickness.

Brake lining thickness Standard : 4.5 mm (0.177 in.) Service limit : 1.0 mm (0.039 in.)



EGGE700R

WWW.DIGITALKHODRO.COM

021-62999292

021-62999292

BR -46

BRAKE SYSTEM

- 6. If the brake lining thickness is less than the service limit, replace the brake shoes as a set.
- 7. Check the bearings in the hub unit for smooth operation. If it requires servicing, replace it.
- 8. Measure the inside diameter of the brake drum with inside vernier calipers.

Drum inside diameter: Standard : 228.6 mm (9 in.) Service limit : 230.6 mm (9.079 in.) Drum roundness Service limit : 0.06 mm (0.00236 in.)





EGGE700S

- 9. If the inside diameter of the brake drum is more than the service limit, replace the brake drum.
- 10. Check the brake drum for scoring, grooves, and cracks.

PARKING BRAKE SYSTEM

PARKING BRAKE SYSTEM

PARKING BRAKE

COMPONENTS EBD134D3



9. Lower spring

10. Adjuster

13. Shoe hold down pin

EJRF501E

WWW.DIGITALKHODRO.COM

4. Parking brake cable

5. Backing plate

021-62999292

BR -47

021-62999292

BRAKE SYSTEM

BR -48

REMOVAL ED2E63F7

🚺 NOTE

The parking brake cables must not be bent or distorted.

This will lead to stiff operation and premature failure.

- 1. Remove the floor console.
- 2. Loosen the adjusting nut (A) and remove the parking brake cables.

- 4. Remove the bolts and parking brake lever assembly(A).
- 5. Remove the wheel and tire.
- 6. Remove the brake disc and the brake shoe (Refer to the rear disc brake).
- 7. Remove the parking brake hook(A).



ولین سامانه_{دهاد}عیتال تعمیرکاران خودرو در ایران

3. Disconnect the connector(A) of the parking brake switch connector.



EGGE700X

PARKING BRAKE SYSTEM

INSTALLATION E445CBA2

- Install the removed parts in the reverse order of re-1. moval.
- Apply the specified grease to each sliding parts of the 2. ratchet plate or the ratchet pawl.

Specified grease :	
Multi purpose grease SAE J310, NLGI No.2	

3. After installing the parking brake cable adjuster, adjust the parking brake lever stroke (Refer to the parking brake check and adjustment).

INSPECTION EE4EA48E

1. Pull the parking brake lever (A) with 196 N (20 kgf, 44 lb) force to fully apply the parking brake. The parking brake lever should be locked within the specified number of clicks.

Lever locked clicks:7

Pulled up with 196 N (20 kgf, 44 lb) EJRF501F 2. Adjust the parking brake if the lever clicks are out of specification.

021-62999292

BRAKE SYSTEM

BR -50

ADJUSTMENT EE4EA49E

NOTE

ing brake adjusting nut, start the engine and depress the brake pedal several times to set the self-adjusting brake before adjusting the parking brake.

- 1. Block the front wheels, then raise the rear of the vehicle and make sure it is securely supported.
- 2. Pull the parking brake lever up one click.

4. Tighten the adjusting nut (A) until the parking brakes are dragged slightly when the rear wheels are turned.



EJKE002D

- 5. Release the parking brake lever completely, and check if parking brakes are not dragged when the rear wheels are turned. Readjust if necessary.
- 6. Make sure that the parking brakes are fully applied when the parking brake lever is pulled up completly.

Reinstall the floor console.

7.

EJKE002C

3. Remove the floor console.

After rear brake caliper servicing, loosen the park-

WWW.DIGITALKHODRO.COM

PARKING BRAKE SWITCH

INSPECTION ED3E4A76

1. Remove the floor console and the connector(B) from the switch(A).



- 2. Inspect the continuity between (-) terminal and the ground.
 - When the brake lever is pulled, there should be the continuity between them.
 - When the brake lever is released, there should be no continuity between them.

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

BR -51

KJRE501C

<u>BR -52</u>

BRAKE SYSTEM

ABS (ANTI-LOCK BRAKE SYSTEM)

COMPONENTS E7ECFFCA



- 1. Front left wheel speed sensor
- 2. ABS control module(HECU)
- 3. Front right wheel speed sensor

- 4. Hydrauric line
- 5. Rear right wheel speed sensor
- 6. Rear left wheel speed sensor

EJRF501G

WWW.DIGITALKHODRO.COM

ABS (ANTI-LOCK BRAKE SYSTEM)

DESCRIPTION E87D629D

This specification applies to HCU(Hydraulic Control Unit) and ECU(Electronic Control Unit) of the HECU.(Hydraulic and Electronic Control Unit)

This specification is for the wiring design and installation of ABS/TCS/ESP ECU.

This unit has the functions as follows.

- Input of signal from Pressure sensor, Steering angle sensor, Yaw & Lateral G sensor, the wheel speed sensors attached to each wheel.
- Control of braking force / traction force/ yaw moment.
- Failsafe function.
- Self diagnosis function.
- Interface with the external diagnosis tester.

Installation position : engine compartment

- Brake tube length from Master cylinder port to HECU inlet port should be max. 1m
- The position should not be close to the engine block and not lower than the wheel.

OPERATION

The ECU shall be put into operation by switching on the operating voltage (IGN).

On completion of the initialization phase, the ECU shall be ready for operation.

In the operating condition, the ECU shall be ready, within the specified limits (voltage and temperature), to process the signals offered by the various sensors and switches in accordance with the control algorithm defined by the software and to control the hydraulic and electrical actuators.

WHEEL SENSOR SIGNAL PROCESSING

The ECU shall receive wheel speed signal from the four active wheel sensors.

The wheel signals are converted to voltage signal by the signal conditioning circuit after receiving current signal from active wheel sensors and given as input to the MCU.

SOLENOID VALVE CONTROL

When one side of the valve coil is connected to the positive voltage that is provided through the valve relay and the other side is connected to the ground by the semiconductor circuit, the solenoid valve goes into operation. The electrical function of the coils are always monitored by the valve test pulse under normal operation conditions.

VOLTAGE LIMITS

Overvoltage When overvoltage is detected(above 16V), the ECU switches off the valve relay and shuts down the system.

When voltage is returned to operating range, the system goes back to the normal condition after the initialization phase.

- Undervoltage

In the event of undervoltage(below 10V), ABS control shall be inhibited and the warning lamp shall be turned on.

When voltage is returned to operating range, the warning lamp is switched off and ECU returns to normal operating mode.

PUMP MOTOR CHECKING

The ECU performs a pump motor test at a speed of 12km/h once after IGN is switched on.

DIAGNOSTIC INTERFACE

Failures detected by the ECU are encoded on the ECU, stored in a EEPROM and read out by diagnostic equipment when the ignition switch is turned on.

The diagnosis interface can also be used for testing the ECU during production of the ECU and for actuating the HCU in the test line of manufactories (Air-bleeding line or Roll and Brake Test line).

BRAKE SYSTEM

WARNING LAMP MODULE



EJRF501I

1. ABS WARNING LAMP MODULE

The active ABS warning lamp module indicates the selftest and failure status of the ABS.The ABS warning lamp shall be on:

- During the initialization phase after IGN ON. (continuously 3 seconds).
- In the event of inhibition of ABS functions by failure.
- During diagnostic mode.
- When the ECU Connector is seperated from
- .رکت دیجیتال خودر و سامانه (مسئولیتECU دود

2. PARKING/EBD WARNING LAMP MODULE

The active EBD warning lamp module indicates the selftest and failure status of the EBD.However, in case the Parking Brake Switch is turned on, the EBD warning lamp is always turned on regardless of EBD functions.The EBD warning lamp shall be on:

- During the initialization phase after IGN ON. (continuously 3 seconds).
- When the Parking Brake Switch is ON or brake fluid level is low.
- When the EBD function is out of order.
- During diagnostic mode.
- When the ECU Connector is seperated from ECU.



ABS (ANTI-LOCK BRAKE SYSTEM)

ABS CONTROL EFC9BCEA

1. NORMAL BRAKING without ABS

	Inlet valve(EV)	Outlet valve(AV)	Pump motor
Operation	Open	Close	OFF



KJRE501E

BR -55

021-62999292

BR -56

BRAKE SYSTEM

2. DECREASE MODE

	Inlet valve(EV)	Outlet valve(AV)	Pump motor
Operation	Close	Open	ON(Motor speed control)



ABS (ANTI-LOCK BRAKE SYSTEM)

<u>BR -57</u>

3. HOLD MODE

	Inlet valve(EV)	Outlet valve(AV)	Pump motor
Operation	Close	Close	OFF
			-
			RR
	بانه دیجیتال تعمیرکا		KJRE501G

BR -58

BRAKE SYSTEM

4. INCREASE MODE

	Inlet valve(EV)	Outlet valve(AV)	Pump motor
Operation	Open	Close	OFF
ان خودرو در ایران	انه ديجيتال تعميركار	اولین ساما	KJRE501H

WWW.DIGITALKHODRO.COM

021-62 99 92 92

ABS (ANTI-LOCK BRAKE SYSTEM)

ABS CIRCUIT DIAGRAM(1) E9B2028F



EJRF502S

BR -60

ABS CIRCUIT DIAGRAM(2)



BRAKE SYSTEM

WWW.DIGITALKHODRO.COM

ABS (ANTI-LOCK BRAKE SYSTEM)

HECU CONNECTOR INPUT/OUTPUT(ABS) E3E3DCA2



		Cur	rent	max.permissible	min.leakage	
Wire No.	Designation	max	min	wire resistance R_L (m)	resistance R_P (k)	
1	Ground for recirculation pump	20~39 A	10 A	10		
4	Ground for solenoid valves and ECU	5~15 A	2.5 A	10		
2	Voltage supply for pump motor	20~39 A	10 A	10	200	
3	Voltage supply for solenoid valves	5~15 A	2 A	10	200	
18	Voltage for hybrid ECU	1 A	500 mA	60	200	
5,10,17,19	signal wheel speed sensor FL, FR, RL,RR	6 mA	16 mA	250	200 to ground 1.5M to bat	
16,9,6,8	Voltage supply for the active wheel speed sensor FL,FR, RL, RR	6 mA	16 mA	250	200 to ground 1.5M to bat	
14,24	wheel speed sensor output (FR, RL)	20 mA	10 mA	250	200	
11	Diagnostic wire K	6 mA	3 mA	250	200	
22	ABS-warning lamp actuation	30 mA	5 mA	250	200	
12	EBD-warning lamp actuation	30 mA	5 mA	250	200	
20	brake light switch	10 mA	5 mA	250	200	

KJRE502O

BR -61

WWW.DIGITALKHODRO.COM

BRAKE SYSTEM

ABS HECU CONNECTOR

	Connector terminal	Cresting	Condition	
Number	Description	Specification	Condition	
1	Ground for recirculation pump	Current range: Min.10A Max.20~39A	Always	
4	Ground for solenoid valves and ECU	Current range: Min.2.5A Max.5~15A	Always	
2	Voltage supply for pump motor	Pottory voltage	Alwaya	
3	Voltage supply for solenoid valves	Battery voltage	Always	
16				
9	Voltage supply for the active wheel	Battery voltage	IG ON	
6	speed sensor FL,FR, RL, RR	Ballery vollage	IG ON	
8				
5				
10	signal wheel speed sensor	signal wheel speed sensor Voltage(High) : 0.89~1.26 V	On driving	
17	FL, FR, RL,RR	Voltage (Low) : 0.44~0.63 V	On driving	
19				
11	Diagnostic wire K	Voltage (High) 0.8 * IG ON Voltage (Low) 0.2 * IG ON	On HI-SCAN commu- nication	
18	Voltage for hybrid ECU	Battery voltage	KEY ON/OFF	
20	Brake light switch	Voltage (High) 0.8 * IG ON Voltage (Low) 0.3 * IG ON	BRAKE ON/OFF	

ABS (ANTI-LOCK BRAKE SYSTEM)

BR -63

SENSOR OUTPUT ON HI-SCAN(ABS)

	Description	Abbreviation	Unit	Remarks
1	Vehicle speed sensor	VEH. SPD	Km/h	
2	Battery voltage	BATT. VOL	V	
3	FL Wheel speed sensor	FL WHEEL	Km/h	
4	FR Wheel speed sensor	FR WHEEL	Km/h	
5	RL Wheel speed sensor	RL WHEEL	Km/h	
6	RR Wheel speed sensor	RR WHEEL	Km/h	
7	ABS Warning lamp	ABS LAMP	-	
8	EBD Warning lamp	EBD LAMP	-	
9	Brake Lamp	B/LAMP	-	
10	Pump relay state	PUMP RLY	-	
11	Valve relay state	VALVE RLY	-	
12	Motor	MOTOR	-	
13	Front Left valve(IN)	FL INLET	-	
14	Front Right valve (IN)	FR INLET	-	
15	Rear Left valve (IN)	RL INLET	0	
16	Rear Right valve (IN)	RR INLET	-	3
17	Front Left valve (OUT)	FL OUTLET	-	
18	Front Right valve (OUT)	FR OUTLET		
19	Rear Left valve(OUT)	RL OUTLET		
20	Rear Right valve (OUT)	RR OUTLET	-	

021- 62 99 92 92

BRAKE SYSTEM

BR -64

HI-SCAN (PRO) CHECK EAD7B9E7

- 1. Turn the ignition switch OFF.
- 2. Connector the Hi-scan(pro) to the 16P data link connector located the driver's side kick panel.



- 3. Turn the ignition switch ON.
- 4. Check for diagnostic trouble using the Hi-scan(pro)
- 5. After completion trouble of the repair or correction of the problem, erase the stored fault codes the clear key on the Hi-scan(pro).
- 6. Disconnect the Hi-scan(pro) from the 16P data link connector.



ABS (ANTI-LOCK BRAKE SYSTEM)

BR -65

STANDARD FLOW OF DIAGNSTIC TROUBLESHOOTING



possible about the problem.

EJKB055A

NOTES WITH REGARD TO DIAGNOSIS

The phenomena listed in the following table are not abnormal.

Explanation
When starting the engine, a thudding sound can sometimes be heard coming from inside the engine compartment. This is because the system operation check is being performed.
 Sound of the motor inside the ABS hydraulic unit operation (whine). Sound is generated along with vibration of the brake pedal (scraping). When ABS operates, sound is generated from the vehicle chassis due to repeated brake application and release (Thump : suspension; squeak: tires)
For road surfaces such as snow-covered and gravel roads, the braking distance for vehicles with ABS can sometimes be longer than that for other vehicles. Accordingly, advise the customer to drive safely on such roads by lowering the vehicle speed.
-

after the diagnosis code has been erased, ensure that the requirements listed in "Comment" are met.

BR -66

BRAKE SYSTEM

ABS (CHECK	SHEET
-------	-------	-------

	AI	ABS Check Sheet			Inspector's Name	
			Desistantion			
Customer's Name			Registration Registration			
			VIN.			
Date Vehicle Brought In	/	/	Odometer			Km Miles
Date the Problem F	irst Occurred	•	/		/	
Frequency of Occu	rence <mark>o</mark> f Problem	Cont	inuous	🗆 Inte	ermittent (times a	day)
		••		0-		
سئوليت محد	ABS does not		شرکت دیجی			
خودرsymptoms	ABS does not	operate ef	ficiently. 0.99	🗆 Inte	ermittent (times a	day)
	ABS Warning Light Abnormal	🗆 Rem	ains ON		es not light up	
Diagnostic Trouble Code	1st Time	□ Norn	nal Code	🗆 Ma	Ifunction Code (Code)
Check	2nd Time	🗆 Norr	nal Code	🗆 Ma	Ifunction Code (Code)
						_

ABS (ANTI-LOCK BRAKE SYSTEM)

PROBLEM SYMPTOMS TABLE

If a normal code is displayed during the DTC check but the problem still occurs, check the circuits for each problem symptom in the order given in the table below and proceed to the relevant troubleshooting page.

Symptom	Suspect Area	See page
ABS does not operate.	 Only when 14. are all normal and the problem is still occurring, replace the HECU. 1. Check the DTC reconfirming that the normal code is output. 2. Power source circuit. 3. Speed sensor circuit. 4. Check the hydraulic circuit for leakage. 	BR - 68
ABS does not operate intermittently.	 Only when 14. are all normal and the problem is still occurring, replace the ABS actuator assembly. 1. Check the DTC reconfirming that the normal code is output. 2. Wheel speed sensor circuit. 3. Stop lamp switch circuit. 4. Check the hydraulic circuit for leakage. 	BR - 70
Communication with Hi-scan (pro) is not possible. (Communication with any system is not possible)	 Power source circuit Diagnosis line 	BR - 71
Communication with Hi-scan (pro) is not possible. (Communication with ABS only is not possible)	 Power source circuit Diagnosis line HECU 	BR - 72
When ignition key is turned ON (engine OFF), the ABS warning lamp does not light up.	 ABS warning lamp circuit HECU 	BR - 73
Even after the engine is started, the ABS warning lamp remains ON.	 ABS warning lamp circuit HECU 	BR - 74

During ABS operation, the brake pedal may vibrate or may not be able to be depressed. Such phenomena are due to intermittent changes in hydraulic pressure inside the brake line to prevent the wheels from locking and is not an abnormality.

BRAKE SYSTEM

BR -68

ABS Does Not Operate

DETECTING CONDITION

Trouble Symptoms	Possible Cause
Brake operation varies depending on driving conditions and road surface conditions, so diagnosis can be difficult.However if a normal DTC is displayed, check the following probable cause. When the problem is still occurring, replace the ABS control module.	 Faulty power source circuit Faulty wheel speed sensor circuit Faulty hydraulic circuit for leakage Faulty HECU

NO

ON

INSPECTION PROCEDURES

DTC INSPECTION

- 1. Connect the Hi-Scan (pro) with the data link connector and turn the ignition switch ON.
- 2. Verify that the normal code is output. Is the normal code output?

NO

Check the power source circuit.

YES

Erase the DTC and recheck using Hi-Scan (pro).

CHECK THE POWER SOURCE CIRCUIT.

- 1. Disconnect the connector from the ABS control module.
- 2. Turn the ignition switch ON, measure the voltage between terminal 18 of the ABS control module harness side connector and body ground.

Specification: approximately B+

Is the voltage within specification?

YES

Check the ground circuit.

CHECK THE GROUND CIRCUIT.

18

(5)(4)(3)(2)(1)(0)(9)(0)(5)

26 25 24 23 22 21 20 19 0 17 16

1. Disconnect the connector from the ABS control module.

Check the harness or connector between the fuse (10A) in the engine compartment junction block and

(4)(3)(2)(1)

KJRE500H

the ABS control module. Repair if necessary.

(+)

 Check for continuity between terminals 1,4 of the ABS control module harness side connector and ground point.
 Is there continuity?

Is there continuity?

YES

Check the wheel speed sensor circuit.

NO

Repair an open in the wire and ground point.



KJRE501D

CHECK THE WHEEL SPEED SENSOR CIRCUIT.

Refer to the DTC troubleshooting procedures. Is it normal?

YES

Check the hydraulic circuit for leakage.

NO

Repair or replace the wheel speed sensor.

CHECK THE HYDRAULIC CIRCUIT FOR LEAKAGE.

Refer to the hydraulic lines. Inspect leakage of the hydraulic lines. Is it normal?

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران YES

The problem is still occurring, replace the ABS control module.

NO

Repair the hydraulic lines for leakage.



021-62999292

BRAKE SYSTEM

ABS Does Not Operate Intermittently.

DETECTING CONDITION

BR -70

Trouble Symptoms	Possible Cause
Brake operation varies depending on driving conditions and road surface conditions, so diagnosis can be difficult.However if a normal DTC is displayed, check the following probable cause. When the problem is still occurring, replace the ABS control module.	 Faulty power source circuit Faulty wheel speed sensor circuit Faulty hydraulic circuit for leakage Faulty HECU

INSPECTION PROCEDURES

DTC INSPECTION

- 1. Connect the Hi-Scan (pro) with the data link connector and turn the ignition switch ON.
- 2. Verify that the normal code is output. Is the normal code output?

Check the hydraulic circuit for leakage.

NO

Repair the stop lamp switch. Repair an open in the wire between the ABS control module and the stop lamp switch.



YES

Check the stop lamp switch circuit.

NO

Repair or replace the wheel speed sensor.

CHECK THE STOP LAMP SWITCH CIRCUIT.

- 1. Check that stop lamp lights up when brake pedal is depressed and turns off when brake pedal is released.
- 2. Measure the voltage between terminal 20 of the ABS control module harness side connector and body ground when brake pedal is depressed.

Specification: approximately B+

Is the voltage within specification?



CHECK THE HYDRAULIC CIRCUIT FOR LEAKAGE.

Refer to the hydraulic lines. Inspect leakage of the hydraulic lines. Is it normal?



The problem is still occurring, replace the ABS control module.



Repair the hydraulic lines for leakage.

ABS (ANTI-LOCK BRAKE SYSTEM)

Communication With Hi-Scan (pro) Is Not Possible. (Communication With Any System Is Not Possible)

DETECTING CONDITION

Trouble Symptoms	Possible Cause
Possible defect in the power supply system (including ground) for the diagnosis line.	An open in the wirePoor groundFaulty power source circuit

INSPECTION PROCEDURES

CHECK THE POWER SUPPLY CIRCUIT FOR THE DI-AGNOSIS

Measure the voltage between terminal 9 of the data link connector and body ground.

Specification: approximately B+

Is voltage within specification?

CHECK THE GROUND CIRCUIT FOR THE DIAGNOSIS

Check for continuity between terminal 5 of the data link connector and body ground. Is there continuity?

NO

Π

Repair an open in the wire between terminal 5 of the data link connector and ground point.

5

YES

Check the ground circuit for the diagnosis.

NO

Repair an open in the wire. Check and replace fuse (15A) from the engine compartment junction block.



KJQE900E

KJQE900D

WWW.DIGITALKHODRO.COM

BRAKE SYSTEM

Communication With Hi-Scan (pro) Is Not Possible. (Communication With ABS Only Is Not Possible)

DETECTING CONDITION

BR -72

Trouble Symptoms	Possible Cause
When communication with Hi-Scan (pro) is not possible, the cause may be probably an open in the HECU power circuit or an open in the diagnosis output circuit.	An open in the wireFaulty HECUFaulty power source circuit

INSPECTION PROCEDURES

CHECK FOR CONTINUITY IN THE DIAGNOSIS LINE

- 1. Disconnect the connector from the ABS control module.
- Check for continuity between terminals 11 of the ABS control module connector and 1 of the data link connector. Is there continuity?

YES

NO

Check the power source of ABS control module.

Repair an open in the wire

CHECK THE POWER SOURCE OF ABS CONTROL MODULE

- 1. Disconnect the connector from the ABS control module.
- 2. Turn the ignition switch ON, measure the voltage between terminal 18 of the ABS control module harness side connector and body ground.

Specification: approximately B+

Is voltage within specification?

YES

Check for poor ground.

NO

Check the harness or connector between the fuse (10A) in the engine compartment junction block and the ABS control module.Repair if necessary.



CHECK FOR POOR GROUND

Check for continuity between terminal 5 of the data link connector and ground point.

YES

Replace the ABS control module and recheck.

NO

Repair an open in the wire or poor ground.



KJQE900E

KJRE501J

WWW.DIGITALKHODRO.COM

021-62999292
BR -73

When Ignition Key Is Turned ON (Engine OFF), The ABS Warning Lamp Does Not Light Up.

DETECTING CONDITION

Trouble Symptoms	Possible Cause
When current flows in the HECU the ABS warning lamp turns from ON to OFF as the initial check.Therefore if the lamp does not light up, the cause may be an open in the lamp power supply circuit, a blown bulb, an open in the both circuits between the ABS warning lamp and the HECU, and the faulty HECU.	 Faulty ABS warning lamp bulb Blown No.2 fuse (10A) in the engine compartment junction block Faulty ABS warning lamp module Faulty HECU

INSPECTION PROCEDURES

PROBLEM VERIFICATION

Disconnect the connector from the ABS control module and turn the ignition switch ON. Does the ABS warning lamp light up?

NO

It is normal. Recheck the ABS control module.

YES

Check the power source for the ABS warning lamp.

CHECK THE POWER SOURCE FOR THE ABS

- 1. Disconnect the instrument cluster connector and turn the ignition switch ON.
- 2. Measure the voltage between terminal 5 of the cluster harness side connector and body ground.

Specification: approximately B+

Is voltage within specification?



Repair bulb or instrument cluster assembly.

YES

Check for blown fuse.



KJRE501K

CHECK FOR BLOWN FUSE.

Check continuity of fuse (10A) from the engine compartment junction block. Is there continuity?

NO

Repair an open in the wire between ABS fuse and 1 of cluster connector.



Replace the blown fuse.

BRAKE SYSTEM

Even After The Engine Is Started, The ABS Warning Lamp Remains ON.

DETECTING CONDITION

Trouble Symptoms	Possible Cause
If the HECU detects trouble, it lights the ABS warning lamp while at the same time prohibiting ABS control. At this time, the HECU records a DTC in memory.Even though the normal code is output, the ABS warning lamp remains ON, then the cause may be probably an open or short in the ABS warning lamp circuit.	 An open in the wire Faulty instrument cluster assembly Faulty ABS warning lamp module Faulty HECU

INSPECTION PROCEDURES

CHECK DTC OUTPUT

- 1. Connect the Hi-Scan (pro) to the 16P data link connector located behind the driver's side kick panel.
- 2. Check the DTC output using Hi-Scan (pro). Is DTC output?





NO

Check instrument cluster.

CHECK INSTRUMENT CLUSTER

Disconnect the cluster connector and turn the ignition switch ON. Does the ABS warning lamp remains ON?

YES

Replace the instrument cluster.

NO

Check for open the wire.

CHECK FOR OPEN IN THE WIRE

Check for continuity in the wire between cluster and ABS control module. Is there continuity?

YES

Replace the ABS control module and recheck.

NO

Repair an open in the wire between cluster and ABS control module.



WWW.DIGITALKHODRO.COM

BLEEDING OF BRAKE SYSTEM

This procedure should be followed to ensure adequate bleeding of air and filling of the ABS unit, brake lines and master cylinder with brake fluid.

1. Remove the reservoir cap and fill the brake reservoir with brake fluid.

If there is any brake fluid on any painted surface, wash it off immediately.

NOTE

When pressure bleeding, do not depress the brake pedal. Recommended fluid...... DOT3 or DOT4

2. Connect a clear plastic tube to the wheel cylinder bleeder plug and insert the other end of the tube into a half filled clear plastic bottle.

4. Select and operate according to the instructions on the hi-scan (Pro) screen.

/ CAUTION

You must obey the maximum operating time of the ABS motor with the hi-scan (Pro) to prevent the motor pump from burning.

- Select hyundai vehicle diagnosis. 1)
- 2) Select vehicle name.
- 3) Select Anti-Lock Brake system.
- 4) Select air bleeding mode.

01. SOLENOID VALVE STATUS

TIME : AUTOMATIC COUNT (1-60 SEC.)

02. MOTOR PUMP STATUS

5) Press "YES" to operate motor pump and solenoid valve.



EJRF501H

Connect the hi-scan (pro) to the data link connector 3. located underneath the dash panel.



ARJE503N

WWW.DIGITALKHODRO.COM

021-62999292

BR -75

EJDA014F

F.IDA014G

OPEN

ON

BR -76

021-62999292

BRAKE SYSTEM

- 5. Pump the brake pedal several times, and then loosen the bleeder screw until fluid starts to run out without bubbles. Then close the bleeder screw.
- 6. Repeat step 5 until there are no more bubbles in the fluid for each wheel.



KJKE003B

7. Tighten the bleeder screw.

Bleed screw tightening torque: 6.86~12.74 Nm (70 ~ 130 kgf·cm, 5.09 ~ 9.45 lb-ft)



BR -77

DIAGNOSTIC TROUBLE CODE CHART(DTC)

DTO	DECODIDITION	WARNING LAMP			SEE	
DTC	DESCRIPTION	ABS	EBD	ESP	REMARK	PAGE
C1101	BATTERY VOLTAGE HIGH					BR - 79
C1102	BATTERY VOLTAGE LOW					BR - 79
C1200	FL WHEEL SPEED SENSOR- OPEN/SHORT					BR - 84
C1201	FL WHEEL SPEED SENSOR- RANGE/ PERFORMANCE					BR - 88
C1202	FL WHEEL SPEED SENSOR-NO SIGNAL					BR - 91
C1203	FR WHEEL SPEED SENSOR- OPEN/SHORT					BR - 84
C1204	FR WHEEL SPEED SENSOR- RANGE/ PERFORMANCE					BR - 88
C1205	FR WHEEL SPEED WHEEL SPEED SENSOR-NO SIGNAL					BR - 91
C1206	RL WHEEL SPEED SENSOR- OPEN/SHORT					BR - 84
C1207	RL WHEEL SPEED SENSOR- RANGE/				0	BR - 88
C1208	RL WHEEL SPEED WHEEL SPEED SENSOR-NO SIGNAL		0			BR - 91
C1209	RR WHEEL SPEED SENSOR- OPEN/SHORT	شركت		d		BR - <mark>84</mark>
C1210	RR WHEEL SPEED SENSOR- RANGE/ PERFORMANCE			5		BR - 88
C1211	RR WHEEL SPEED SENSOR-NO SIGNAL	اوين		0		BR - 91
C1213	WHEEL SPEED FREQUENCY ERROR					BR - 95
C1235	PRESSURE SENSOR-ELECTRICAL				ESP	BR - 97
C1237	PRESSURE SENSOR-SIGNAL FAULT				ESP	BR - 97
C1260	STEERING ANGLE SENSOR-SIGNAL				ESP	BR - 100
C1261	STEERING ANGLE SENSOR IS NOT CALIBRATED				ESP	BR - 100
C1282	YAW RATE & LATERAL G SENSOR- ELECTRICAL				ESP	BR - 103
C1283	YAW RATE & LATERAL G SENSOR-SIGNAL				ESP	BR - 107
C1503	ESP SWITCH ERROR				ESP	BR - 110
C1513	BRAKE LIGHT SWITCH MAL.					BR - 113
C1604	ECU HARDWARE ERROR					BR - 115
C1605	CAN CONTROL HARDWARE ERROR				ESP	BR - 117
C1611	CAN TIME OUT-ECM				ESP	BR - 119
C1612	CAN TIME OUT-TCU				ESP	BR - 119
C1616	CAN BUS OFF				ESP	BR - 121

WWW.DIGITALKHODRO.COM

BR -78

BRAKE SYSTEM

DTO	DESCRIPTION	WARNING LAMP			SEE	
DTC	DESCRIPTION	ABS	EBD	ESP	REMARK	PAGE
C1623	CAN TIMEOUT STEERING ANGLE SENSOR				ESP	BR - 119
C1625	CAN TIME OUT-ESP				ESP	BR - 123
C1626	IMPLAUSIBLE CONTROL				ESP	BR - 125
C1702	VARIANT CODING				ESP	BR - 127
C2112	VALVE RELAY MAL.					BR - 128
C2308	FL INLET VALVE MAL.					BR - 131
C2312	FL OUTLET VALVE MAL.					BR - 131
C2316	FR INLET VALVE MAL.					BR - 131
C2320	FR OUTLET VALVE MAL.					BR - 131
C2324	RL INLET VALVE MAL.					BR - 131
C2328	RL OUTLET VALVE MAL.					BR - 131
C2332	RR INLET VALVE MAL.					BR - 131
C2336	RR OUTLET VALVE MAL.				-0-	BR - 131
C2366	TC VALVE PRIMARY(USV1) ERROR		0		ESP	BR - 134
C2370	TC VALVE SECONDARY (USV2) ERROR				ESP	BR - 134
C2372	ESP VALVE 1(HSV1) ERROR	ىرىپ ،		0	ESP	BR - 134
C2374	ESP VALVE 2 (HSV2) ERROR	اەلىت ب			ESP	BR - 134
C2402	MOTOR-ELECTRICAL			C		BR - 135

ABS (ANTI-LOCK BRAKE SYSTEM)

DTC C1101 BATTERY VOLTAGE HIGH DTC C1102 BATTERY VOLTAGE LOW

COMPONENT LOCATION EBC713EC



KJRE760C

GENERAL DESCRIPTION E9BEF58E

DTC DESCRIPTION

The ABS ECU(Electronic Control Unit) checks the battery voltage to determine, as a safety issue, whether the ABS system can operate normally or not. The normal battery voltage range is essential for controlling the ABS system as intended.

شرکت دیجیتال خودرو سام E8E06CCF

The ABS ECU monitors battery voltage by reading the value of voltage.

- 1. When the voltage is higher than the expected normal value, this code is set, and the ABS/EBD/TCS/ESP functions are prohibited. If the voltage recovers, to within normal operating ranges, then the controller returns to normal operation as well.
- When the voltage is lower than the expected normal value, this code is set. The ABS/TCS/ESP functions are prohibited and the EBD function is allowed on LOW VOLTAGE CONDITION 1, the ABS/EBD/TCS/ESP functions are prohibited on UNDER VOLTAGE CONDITION.
- 3. If the voltage recovers, to within normal operating ranges, then the controller returns to normal operations as well.

BRAKE SYSTEM

DTC DETECTING CONDITION E3FDDE1E

Item	Detecting Condition	Possible cause
DTC Strategy	Battery Voltage Monitoring	
	C1101 High voltage problem will be monitored if filtered Ignition Voltage is > 16.8 V. It will be reset if filtered Ignition Voltage < 16.7 V.	
Enable Conditions	 C1102 1. Ignition Voltage is monitored for a level of filtered Ignition Voltage < 9.3 V outside control, or a level of filtered Ignition Voltage < 9.2 V during control. 2. Hard under voltage due to low voltage glitches is detected if unfiltered Ignition Voltage < = 8.2 V for t >= 20 ms. 3. A hard under voltage problem will be detected if the filtered UZ < 7.7 V. The system remains in this condition until filtered UZ > 7.8 V. Image NOTE All under voltage failures will only be saved in EEPROM if vehicle speed is > 6 km/h(3 MPH). This prevents false failure entries due to a bad battery at ignition on. 	 Poor connection in power supply circuit (IGN+) Faulty Alternator Faulty HECU
Monitoring period	Continuous. Under voltage faults are only entered in the EEPROM if the vehicle speed is $v > 6$ km/h (3 MPH). Over voltage faults will be always stored.	
Effect	The proper function of valves and return pump is not guaranteed.	
Fail Safe	 System down. The ABS/EBD/TCS/ESP functions are inhibited. The valve relay and all solenoids are prevented from being switched on. The ABS/EBD/TCS/ESP warning lamps are activated. 	

SPECIFICATION EED630FA

|--|--|

TERMINAL & CONNECTOR INSPECTION ECOFEACE

- 1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

YES

Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

Go to the next step.

WWW.DIGITALKHODRO.COM

POWER SUPPLY CIRCUIT INSPECTION EEAABFE2

- 1. ALTERNATOR OUTPUT VOLTAGE INSPECTION
 - 1) Engine "ON".
 - 2) Measure voltage between the battery terminal(+) and the battery terminal(-).

```
Specification : Approx. 14.4 \pm 0.3 V (20 °C)
```



EJRF501K

021-62999292

BR -81

WWW.DIGITALKHODRO.COM

Battery

021-62999292

021-62999292

BR -82

BRAKE SYSTEM

Is the measured voltage within specifications?

YES

Go to "Ground Circuit Inspection" procedure.



Check for damaged harness and poor connection between the battery terminal(+) and terminal "18(28:ESP)" of the HECU harness connector. Repair as necessary and then go to "Verification of vehicle Repair" procedure.

GROUND CIRCUIT INSPECTION K1A7AC8E

- 1. Ignition "OFF".
- 2. Disconnect HECU connector.
- 3. Measure resistance between terminal "1,4" of the HECU harness connector and chassis ground.

Specification : Approx. below 1



KJRE501R

Is the measured resistance within specifications?

NO

Check for damaged harness and poor connection between terminal "1,4" of the HECU harness connector and chassis ground. Repair as necessary and then go to "Verification of vehicle Repair" procedure.

YES

Go to "Component Inspection" procedure.

ABS (ANTI-LOCK BRAKE SYSTEM)

COMPONENT INSPECTION EC4594E7

- 1. Ignition "OFF".
- 2. Engine "ON". Does warning lamp remain On?



Substitute with a known-good HECU and check for proper operation. If problem is corrected, replace HECU and then go to "Verification of Vehicle Repair" procedure.



NO

Fault is intermittent caused by poor connection in power harness (IGN+), faulty Alternator and/or faulty HECU or was repaired and HECU memory was not cleared. Go to the applicable troubleshooting procedure.

VERIFICATION OF VEHICLE REPAIR EBBCF62B

After a repair, it is essential to verify that the fault has been corrected..

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Using a scantool, Clear DTC.
- 3. Operate the vehicle within DTC Detecting Condition in General Information. Are any DTCs present?

رکت دیجیتال خودرو سامانه (مستولیت <mark>YES</mark> ود

Go to the applicable troubleshooting procedure.

A system performs normally at this time.

BRAKE SYSTEM

KJRE502M

DTC C1200 FL SENSOR-OPEN/SHORT DTC C1203 FR SENSOR-OPEN/SHORT DTC C1206 RL SENSOR-OPEN/SHORT DTC C1209 RR SENSOR-OPEN/SHORT

COMPONENT LOCATION E2AC644A



GENERAL DESCRIPTION ETEC844A

The wheel speed sensor is the essential component the ABS ECU uses to calculate vehicle speed and to determine whether wheel lock occurs. For example, rear wheel speed signal is used as a reference value, for vehicle speed, in front wheel drive vehicles, and if a difference between front and rear wheel speed occurs, then ABS control is performed. Wheel speed sensor is an active hall-sensor type and good at temperature and noise charicteristic. Digital wave is produced as tone wheel rotate according as hall sensor principle. Frequency of duty wave is changed in proportion to rotation of tone wheel and HECU calculate vehicle speed by this frequency.

DTC DESCRIPTION K3A0FE9D

The ABS ECU monitors the wheel speed sensor circuit continuously. If the sensor signal current is continuously out of the specified range for 200msec, then the HECU determines that the circuit is open/short, and sets this code. Warning lamp is turned OFF if the detected fault is not more than when the IG KEY is turned to ON again, and wheel speeds are more than 10 Km/h(6 MPH).

WWW.DIGITALKHODRO.COM

ABS (ANTI-LOCK BRAKE SYSTEM)

DTC DETECTING CONDITION E3AD2BA0

Item		Detecting Condition	Possible cause
DTC Strat- egy	Current Monitoring		
	Monitoring period	Once after power up.	
CASE 1	Enable Conditions	Wheel speed sensor test starts immediate after power. Especially shorts between WSS(Wheel speed sensor) lines and shorts to UZ(ECU voltage supply) can be detected by switching single WSS channels in sequence. After end of test only the channels with no fault are switched on.	 Open or short of Wheel speed sensor circuit Faulty Wheel speed
	Monitoring period	Continuous	sensor
CASE 2	Enable Conditions	The sensor circuitry has two current levels I = 7mA and I= 14mA. If the sensor line is broken, shorted to ground or shorted to supply voltage a faulty current level will be detected.WSS line faults are detected, if the fault condition exists uninterrupted for t $>$ = 200ms.	 Faulty HECU
Effect	is no longer possible	nal can be generated. Control of the corresponding wheel b. If a sensor fault occurs on a front wheel, pressure is wheel, pressure is decreased (until switch off).	0

TERMINAL & CONNECTOR INSPECTION EBEA9B88

Refer to DTC C1101.

POWER SUPPLY CIRCUIT INSPECTION ECBF51BA

- 1. Ignition "ON" & Engine "OFF".
- 2. Measure voltage between terminal "2" of the wheel speed sensor harness connector and chassis ground.

Specification : approx. B+



EJRF501L

BR -86

BRAKE SYSTEM

Is the measured voltage within specifications?

YES

Go to "Signal Circuit Inspection" procedure.

NO

Check for open or short to GND in wheel speed sensor harness between terminal "16(ESP:26),9,6,8" of the HECU harness connector and terminal "2" of the Wheel speed sensor harness connector. Repair as necessary and then go to "Verification of vehicle Repair" procedure.

SIGNAL CIRCUIT INSPECTION EDF71F93

- 1. Ignition "ON" & Engine "OFF".
- 2. By turning the wheel with hand.
- Measure voltage between terminal "5,10,17(ESP:27),19(ESP:29)" of the HECU harness connector and chassis ground.



KJRE501Y

Is the measured voltage within specifications?

YES

Go to "Component Inspection" procedure.

NO

Check for open or short to GND in wheel speed sensor harness between terminal "1" of the wheel speed sensor harness connector and terminal "5,10,17(ESP:27),19(ESP:29)" of the HECU harness connector. Repair as necessary and then go to "Verification of vehicle Repair" procedure.

WWW.DIGITALKHODRO.COM

021-62999292

COMPONENT INSPECTION EEFOD679

- 1. Ignition "OFF".
- 2. Engine "ON".
- 3. Start and drive vehicle in gear and maintain vehicle speed is approx. 10km/h or more(6mph or more). Does warning lamp remain On?

YES

Substitute with a known-good HECU and check for proper operation. If problem is corrected, replace HECU and then go to "Verification of Vehicle Repair" procedure.

NO

Fault is intermittent caused by open or short of wheel speed sensor harness, faulty wheel speed sensor and/or faulty HECU or was repaired and HECU memory was not cleared. Go to the applicable troubleshooting procedure.

VERIFICATION OF VEHICLE REPAIR K8BFAC21

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Using a scantool, Clear DTC.
- 3. Operate the vehicle within DTC Detecting Condition in General Information.(Start and drive vehicle in gear and maintain vehicle speed is approx. 10km/h or more(6mph or more)) Are any DTCs present?

ولین سامانه دیجیتال تعمیرکاران خودرو د <mark>Yes</mark>

Go to the applicable troubleshooting procedure.

NO

A system performs normally at this time.

BRAKE SYSTEM

KJRE502M

DTC C1201 FL SENSOR-RANGE/PERFORMANCE DTC C1204 FR SENSOR-RANGE/PERFORMANCE DTC C1207 RL SENSOR-RANGE/PERFORMANCE DTC C1210 RR SENSOR-RANGE/PERFORMANCE

COMPONENT LOCATION EF53B644



GENERAL DESCRIPTION E99BF177

The wheel speed sensor is the essential component the ABS ECU uses to calculate vehicle speed and to determine whether wheel lock occurs. For example, rear wheel speed signal is used as a reference value, for vehicle speed, in front wheel drive vehicles, and if a difference between front and rear wheel speed occurs, then ABS control is performed. Wheel speed sensor is an active hall-sensor type and good at temperature and noise charicteristic. Digital wave is produced as tone wheel rotate according as hall sensor principle. Frequency of duty wave is changed in proportion to rotation of tone wheel and HECU calculate vehicle speed by this frequency.

DTC DESCRIPTION EA98CDAF

The ABS ECU monitors the wheel speed sensor signal continuously. This code is set if an abnormal speed change ratio is detected while the vehicle speed is 10~80 Km/h(6~50 MPH). Warning lamp is turned OFF if the detected fault is not more than when the IG KEY is turned to ON again, and wheel speeds are more than 12 Km/h(7 MPH).

WWW.DIGITALKHODRO.COM

021-62999292

BR -89

DTC DETECTING CONDITION E1B722FB

Item		Detecting Condition		
DTC Strategy	Current Monitoring	I		
	Monitoring period	The monitoring is active from 10 km/h to 80km/h(6~50 MPH) and if no ABS-control is active at a front wheel and a rear wheel.		
CASE 1	EnableConditions	Every time, if a gap in the wheel speed sensor signal occurs cyclically with one wheel rotation, a fault counter is increased by one. If the fault counter exceeds its limit of 10, a wheel specific fault is stored in the EEPROM.	 Improper installation of wheel speed sensor Abnormal Rotor and 	
	Monitoring period	Continuous if V_Vehicle > 12 m/s	wheel bearingFaulty Wheel speed	
CASE 2	EnableConditions	No wheel speed signals within 10 ms to 20 ms at a vehicle speed> 12 m/s (43.2 km/h, 27 MPH). If the dynamic sensor monitor responses, the failures will be stored into failure memory immediately after a waiting period of 60ms.	sensor • Faulty HECU	
Effect	Due to faulty wheel speed information the control of the corre- sponding wheel is no longer possible. reaction of the controller: If a sensor fault occurs on a front wheel, pressure is increased; on a rear wheel, pressure is decreased.		2	

MONITOR SCANTOOL DATA E701AC41

1. Connect scantool to Data Link Connector(DLC).

3. Start and drive vehicle in gear and maintain vehicle speed is approx. 40km/h or more(24 mph or more) Monitor the "Wheel speed sensor" parameter on the Scantool.

Specification : Approx. 12 km/h or more(7 mph or more)

Is it normal?

YES

Fault is intermittent caused by faulty wheel speed sensor and/or faulty HECU or was repaired and HECU memory was not cleared. Repair or replace as necessary and then go to "Component Inspection" procedure.

NO

- 1) Check for improper installation of wheel speed sensor. If NG, repair as necessary and then go to "Verification of vehicle Repair" procedure.
- 2) Check for damage of rotor teeth or wheel bearing. If NG, repair as necessary and then go to "Verification of vehicle Repair" procedure.
- 3) Substitute with a known-good Wheel speed sensor and check for proper operation. If problem is corrected, replace Wheel speed sensor and then go to "Verification of Vehicle Repair" procedure.

WWW.DIGITALKHODRO.COM

021-62999292

^{2.} Engine "ON".

021-62999292

BRAKE SYSTEM

BR -90

COMPONENT INSPECTION EDF75AF5

- 1. Ignition "OFF".
- 2. Engine "ON".
- 3. Start and drive vehicle in gear and maintain vehicle speed is approx. 12 km/h or more(7 mph or more). Does warning lamp remain On?

YES

Substitute with a known-good HECU and check for proper operation. If problem is corrected, replace HECU and then go to "Verification of Vehicle Repair" procedure.

NO

Fault is intermittent caused by open or short of wheel speed sensor harness, faulty wheel speed sensor and/or faulty HECU or was repaired and HECU memory was not cleared. Go to the applicable troubleshooting procedure.

VERIFICATION OF VEHICLE REPAIR EE24FA21

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Using a scantool, Clear DTC.
- 3. Operate the vehicle within DTC Detecting Condition in General Information.(Start and drive vehicle in gear and maintain vehicle speed is approx. 12 km/h or more(7 mph or more)) Are any DTCs present ?

ولین سامانه دیجیتال تعمیرکاران خودرو در YES

Go to the applicable troubleshooting procedure.

NO

A system performs normally at this time.

BR -91

DTC C1202	FL WHEEL SPEED SENSOR-NO SIGNAL
DTC C1205	FR WHEEL SPEED SENSOR-NO SIGNAL
DTC C1208	RL WHEEL SPEED SENSOR-NO SIGNAL
DTC C1211	RR WHEEL SPEED SENSOR-NO SIGNAL

COMPONENT LOCATION E547F2AF



KJRE502M

GENERAL DESCRIPTION EA259C69

The wheel speed sensor is the essential component the ABS ECU uses to calculate vehicle speed and to determine whether wheel lock occurs. For example, rear wheel speed signal is used as a reference value, for vehicle speed, in front wheel drive vehicles, and if a difference between front and rear wheel speed occurs, then ABS control is performed. Wheel speed sensor is an active hall-sensor type and good at temperature and noise charicteristic. Digital wave is produced as tone wheel rotate according as hall sensor principle. Frequency of duty wave is changed in proportion to rotation of tone wheel and HECU calculate vehicle speed by this frequency.

DTC DESCRIPTION EFAECF2E

The ABS ECU monitors the wheel speed sensor signal continuously. This code is set when the sensor air gap is out of specified range or when No wheel speed signals within 10 ms to 20 ms at a vehicle speed > 43.2 km/h(26 MPH). Warning lamp is turned OFF if the detected fault is not more than when the IG KEY is turned to ON again, and wheel speeds are more than 12 Km/h(7MPH).

BRAKE SYSTEM

DTC DETECTING CONDITION E454E88F

ltem		Possible cause	
DTC Strategy	Signal monitoring		
	Monitoring period	Continuous except no under voltage is detected.	
CASE 1	Enable Conditions	The test detects a failure if one (or two) wheel are at Vmin(2.75 km/h ;1.7 MPH) and the other wheels are above 12 km/h for longer than 1s.A fault could also be set during driving, if the vehicle accelerates 18 km/h after a particular wheel speed gets to vmin(2.75 km/h ;1.7 MPH) and stays there. This monitoring could only detect singular faults.	
	Monitoring period	Continuous except no under voltage is detected.	
CASE 2	Enable Conditions	No wheel speed signals within 10 ms to 20 ms at a vehicle speed > 12 m/s (43.2 km/h). If the dynamic sensor monitor responses, the failures will be stored into failure memory immediately after a waiting period of 60ms.	
	Monitoring period	 The main monitor (5) needs additional information of the ESP-sensors and is active for a velocity > 20 km/h(12 MPH) and no under voltage(9.2 V) is detected. The backup monitor (6) manages with the wheel speeds alone. 	 Improper installation of wheel speed sensor Abnormal Rotor and wheel bearing Faulty Wheel speed sensor
ایران CASE 3	کاران خودرو در	• The main monitor (5): If the maximum difference of wheel speeds related to maximum wheel speed exceeds 5% a wheel specific wheel speed sensor fault is set.	• Faulty HECU
	EnableConditions	 the above conditions apply for 20s for 1 defective WSS. the above conditions apply for 40s for 2 defective WSS. The backup monitor (6):If the velocity is higher than 50 km/h(31 MPH), the deviation between the fastest and the slowest wheel must exceeds 6% related to the fastest wheel. If the velocity is below 50 km/h(31 MPH), the deviation must exceed an absolute value of 3km/h(1.8 MPH). detection filter time : normally 20s 	
Effect	corresponding whee reaction of the contr	speed information the control of the I is no longer possible. oller: If a sensor fault occurs on a front wheel, d; on a rear wheel, pressure is decreased	

BR -93

MONITOR SCANTOOL DATA E7A7DC54

- 1. Connect scantool to Data Link Connector(DLC).
- 2. Engine "ON".
- 3. Start and drive vehicle in gear and maintain vehicle speed is approx. 50 km/h or more(31 mph or more) Monitor the "Wheel speed sensor" parameter on the Scantool.

Specification : Approx. 50 km/h or more(31 mph or more)

Is it normal?



Fault is intermittent caused by faulty wheel speed sensor and/or faulty HECU or was repaired and HECU memory was not cleared. Repair or replace as necessary and then go to "Component Inspection" procedure.

NO

- 1) Check for improper installation of wheel speed sensor. If NG, repair as necessary and then go to "Verification of vehicle Repair" procedure.
- 2) Check for damage of rotor teeth or wheel bearing. If NG, repair as necessary and then go to "Verification of vehicle Repair" procedure.
 - 3) Substitute with a known-good Wheel speed sensor and check for proper operation. If problem is corrected, replace Wheel speed sensor and then go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION EDA02C6B

- 1. Ignition "OFF".
- 2. Engine "ON".
- 3. Start and drive vehicle in gear and maintain vehicle speed is approx. 50 km/h or more(31 mph or more). Does warning lamp remain On?

YES

Substitute with a known-good HECU and check for proper operation. If problem is corrected, replace HECU and then go to "Verification of Vehicle Repair" procedure.

NO

Fault is intermittent caused by open or short of wheel speed sensor harness, faulty wheel speed sensor and/or faulty HECU or was repaired and HECU memory was not cleared. Go to the applicable troubleshooting procedure.

021-62999292

BR -94

BRAKE SYSTEM

VERIFICATION OF VEHICLE REPAIR E7CB563D

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Using a scantool, Clear DTC.
- Operate the vehicle within DTC Detecting Condition in General Information.(Start and drive vehicle in gear and maintain vehicle speed is approx. 50km/h or more(31mph or more)).
 Are any DTCs present ?

YES

Go to the applicable troubleshooting procedure.



A system performs normally at this time.





BR -95

DTC C1213 WHEEL SPEED FREQUENCY ERROR

COMPONENT LOCATION E88FFEF1



KJRE502M

GENERAL DESCRIPTION EOB1D280

The wheel speed sensor is the essential component the ABS ECU uses to calculate vehicle speed and to determine whether wheel lock occurs. For example, rear wheel speed signal is used as a reference value, for vehicle speed, in front wheel drive vehicles, and if a difference between front and rear wheel speed occurs, then ABS control is performed. Wheel speed sensor is an active hall-sensor type and good at temperature and noise charicteristic. Digital wave is produced as tone wheel rotate according as hall sensor principle. Frequency of duty wave is changed in proportion to rotation of tone wheel and HECU calculate vehicle speed by this frequency.

DTC DESCRIPTION DEDEDDD4A DEDIDDEDDD4A DEDIDDEDDD4A

The ABS ECU monitors the wheel speed sensor signal continuously. The monitoring reports a failure if the ABS target slip breaks out.

DTC DETECTING CONDITION E8E24EBB

ltem	Detecting Condition	Possible cause
DTC Strategy	Signal monitoring	
Enable Conditions		
Monitoring period	Continuous	 Faulty Wheel speed sensor Faulty HECU
Effect	Reduced function of the ESP system.	

BRAKE SYSTEM

MONITOR SCANTOOL DATA E0945DFA

- 1. Connect scantool to Data Link Connector(DLC).
- 2. Engine "ON".
- 3. Start and drive vehicle in gear and maintain vehicle speed is approx. 10k m/h or more(6 mph or more). Monitor the "Wheel speed sensor" parameter on the Scantool.

Specification : Approx.10 km/h or more(6 mph or more)

Is it normal?

YES

Fault is intermittent caused by faulty wheel speed sensor and/or faulty HECU or was repaired and HECU memory was not cleared. Repair or replace as necessary and then go to "Component Inspection" procedure.

NO

- 1) Check for improper installation of wheel speed sensor. If NG, repair as necessary and then go to "Verification of vehicle Repair" procedure.
- 2) Check for damage of rotor teeth or wheel bearing. If NG, repair as necessary and then go to "Verification of vehicle Repair" procedure.
- 3) Substitute with a known-good Wheel speed sensor and check for proper operation. If problem is corrected, replace Wheel speed sensor and then go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION EA4CCCB9

- 1. Ignition "OFF".
- 2. Engine "ON".
- 3. Start and drive vehicle in gear and maintain vehicle speed is approx. 10k m/h or more(6 mph or more). Does warning lamp remain On?

YES

Substitute with a known-good HECU and check for proper operation. If problem is corrected, replace HECU and then go to "Verification of Vehicle Repair" procedure.

NO

Fault is intermittent caused by open or short of wheel speed sensor harness, faulty wheel speed sensor and/or faulty HECU or was repaired and HECU memory was not cleared. Go to the applicable troubleshooting procedure.

VERIFICATION OF VEHICLE REPAIR EEA9B1EE

Refer to DTC C1200.

DTC C1235 PRESSURE SENSOR-ELECTRICAL DTC C1237 PRESSURE SENSOR-SIGNAL FAULT

COMPONENT LOCATION EE83DBEF



GENERAL DESCRIPTION EB4F41D4

The pressure sensor senses the brake oil pressure to judge driver's brake intention when ESP is operating.

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

WWW.DIGITALKHODRO.COM

BR -97

KJRE423B

BRAKE SYSTEM

DTC DETECTING CONDITION EFA08C77

	Item	Detecting Condition	Possible cause
DTC	Strategy	Signal monitoring 1. Sensor supply voltage is continuous monitored (except power	
C1235	Enable Conditions	 bensor supply voltage is continuous monitored (except power on). A sensor supply failure is detected if Sensor Supply Voltage > 5.3 V OR Sensor Supply Voltage < 4.7 V for 60 ms. Pressure signal 1 (DSO: original pressure value) is continuous monitored (except power on). Line faults like open, short to GND or short to UZ are detected. A Fault is set if the DSO signal is U DSO > 4.7 V OR U DSO < 0.3 V for a time t > = 100 ms. Pressure signal 2 (DSI: inverted pressure value) is continuous monitored (except power on). Line faults like open, short to GND or short to UZ are detected. A Fault is set if the DSI signal isU DSI > 4.7 V OR U DSI < 0.3 V for a time t > = 100 ms. Plausibility of DSO and DSI pressure lines are continuous monitored.Internal DS5 faults (amplification-, bridge-, analog-digital converter malfunction, etc.) are detected if DSO+DSI < 4.5 V OR DSO+DSI > 5.5 V is present longer than >= 100 ms . POS(Power On Selftest) detects internal sensor malfunctions. sensor element, amplification, etc.) The test phase is divided in two 60 ms parts. DSO signal must be < 0.5 V for 30 ms. In phase 2 DSO signal must be between 1.9 V and 3.1 V for also 30 ms then the POS Test is passed. The test phase is divided in two 60 ms parts. DSO and DSI signal must be < 0.5 V for 30 ms. In phase 2 DSO 	
	ىتوتىت مە	and DSI signal must be between 1.9 V and 3.1 V for also 30 ms then the POS Test is passed.	
ران	Monitoring period	1~4 : Continuous 5 : Once during Power Up	Faulty HECU
C1237	Enable Conditions	 The DS(Pressure sensor)-offset value must be in the range of 15 bar. A failure is detected if this range is exceeded. There are three monitoring which have different thresholds concerning the allowed pressure and the detection time. a) Plausibility 1 : For redundancy reasons an additional hardware-BLS signal is created by the pressure sensor signal. If the pressure sensor is compensated, the threshold for generating the hardware-BLS signal is 10 bar. If the pressure sensor is not compensated, the threshold is increased by 15 bar. If this signal is set without any hardware-BLS-signals being set, and if no pump is operated during that time, a fault is set after the braking. b) Plausibility 2 : If the pressure signal is higher than 30 bar and not both of the hardware-BLS are set, a fault is stored after 2s. c) Plausibility 3: If the pressure signal is higher than 80 bar and not both of the hardware-BLS are set, a fault is stored after 1s. 	
	Monitoring period Effect	 After DS-initialization, no under voltage, no pumps are running and no BLS-signal is set. Continuous in the normal operating voltage range. No Pressure Signal available. 	

WWW.DIGITALKHODRO.COM

COMPONENT INSPECTION ERDDBBA

- 1. Ignition "OFF".
- 2. Engine "ON". Does warning lamp remain On?



Substitute with a known-good HECU and check for proper operation. If problem is corrected, replace HECU and then go to "Verification of Vehicle Repair" procedure.



Fault is intermittent caused by faulty HECU or was repaired and HECU memory was not cleared. Go to the applicable troubleshooting procedure.

VERIFICATION OF VEHICLE REPAIR ECADBEBA

Refer to DTC C1101.







021-62999292

BR -100

BRAKE SYSTEM

KJRE342A

DTC C1260 STEERING ANGLE SNSR-SIGNAL DTC C1261 STEERING ANGLE SENSOR IS NOT CALIBRATED

COMPONENT LOCATION EABB4863



DTC DESCRIPTION E410EEFA

The Steering wheel angle sensor determines the direction of the rotation.

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



DTC DETECTING CONDITION E015A95F

Item	Detecting Condition	Possible cause
DTC Strategy	Signal monitoring	
Enable Conditions	 LWS(steering angle sensor) offset monitoring : If the offset value exceeds a threshold of approximately 15 deg a LWS-fault is determined. LWS Gradient monitoring : signal gradient (steering angle velocity) from one 20 ms-cycle to another is higher than 40° or change of this gradient (steering angle acceleration) is higher than 15° LWS range monitoring : If value is higher than possible range for more than 300 ms a fault is determined. LWS Plausibility monitoring : Dependent on the driving conditions failures in size of [10 + 60 m/s / FZREF(reference speed)] deg at steering angle are recognized within 400 4800 ms . LWS Constant Signal Monitoring : If there is no change in the signal, but a right AND left cornering has been recognized, a fault is determined. (lateral acceleration > 2 m/s² in combination with a yaw rate > 6 °/s in both directions). LWS Wrong Sign Monitoring : If the signals don't fit and forwards driving is detected, a fault is determined. LWS Message counter monitoring : If the message counter shows an increase higher than 3 or lower than 1 in one 20 ms-cyle, a fault is stored after 160 ms. 	• Faulty steering wheel sensor
Monitoring period	 Continuous during driving. no under voltage and at least one LWS-message was sent in the current 20 ms-cycle. After initialization and no under voltage detected. Continuous during driving. Initialization once in every ignition cycle. Continuous during driving. 	
Effect	Reduced controller function caused by faulty LWS signal.	

COMPONENT INSPECTION EACD 1983

1. CHECK INSTALLATION OF STEERING ANGLE SENSOR Check if the steering angle sensor is properly installed. Is the installation proper?

YES

Check power of steering angle sensor.



Reinstall the steering angle sensor properly.

021- 62 99 92 92

BR -102

BRAKE SYSTEM

POWER SUPPLY CIRCUIT INSPECTION E4BAAF7C

- 1. Disconnect the steering angle sensor connector, and measure the voltage between terminal 3 and 4 of the steering angle sensor connector.
- 2. Measure the voltage between terminal 1 and 2 of the steering angle sensor connector.



KJRE502X

Is the voltage within 8~16V?

YES

Clear the DTC, and then drive a vehicle over 40 Km/h(24 MPH) .If ESP warning lamp turn on, replace the steering wheel sensor. Then go to "Verification of Vehicle Repair" procedure.

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Check harness and connector between the HECU and the steering angle sensor. If NG ,replace the steering wheel sensor.

VERIFICATION OF VEHICLE REPAIR E31B84FE

Refer to DTC C1101.

BR -103

DTC C1282 YAW RATE & LATERAL G SENSOR-ELECTRICAL

COMPONENT LOCATION E9D8B46C



KJRE422A

GENERAL DESCRIPTION EA24B68C

The yaw-rate & Lateral G sensor are used for the stability of a vehicle. The yaw-rate is used to measure angular velocity while the Lateral G is to measure the force that moves the vehicle away from the center, when a vehicle is cornering.

DTC DESCRIPTION E4B82741

This code sets when there is an open or short in the circuit of the yaw-rate & lateral G sensor.

DTC DETECTING CONDITION EAF30E39

ltem	Detecting Condition	Possible cause
DTC Strategy	Signal monitoring	 Open or short of Yaw Rate & Lateral G sensor circuit Faulty Yaw Rate & Lateral G sensor Faulty HECU
Enable Conditions	 The AY(Acceleration Sensor) sensor voltage is monitored for a is out of range value. A line fault is detected if AY < 0.3 V OR AY > 4.7 V for a time t > = 100 ms Open line, short to GND and short to UZ are detected. The DRS sensor voltage is monitored for a is out of range value. A line fault is detected, if DRSS < 0.225 V OR DRSS > 4.774 V for a time t > = 100 ms. DRSR < 2.1 V OR DRSR > 2.9 V for a time t > 200 ms. DRSS (Yaw sensor reference), DRS(yaw sensor), DRSR(Yaw sensor signal) 	
Monitoring period	Continuous	
Effect	Reduced controller function caused by faulty DRS and AY signal.	

TERMINAL & CONNECTOR INSPECTION EAF9C4BD

Refer to DTC C1101.

WWW.DIGITALKHODRO.COM

021-62999292

BR -104

BRAKE SYSTEM

POWER SUPPLY CIRCUIT INSPECTION EBEB60C9

- 1. Ignition "ON" & Engine "ON".
- 2. Measure voltage between terminal "3" of the Yaw Rate & Lateral G sensor harness connector and chassis ground.

Specification : 11.75 ~ 12.25 V



Check for open or short to GND in the Yaw Rate & Lateral G sensor harness between terminal "3" of the Yaw Rate & Lateral G sensor harness connector and terminal "16,20" of the HECU harness connector. Repair as necessary and then go to "Verification of vehicle Repair" procedure.

GROUND CIRCUIT INSPECTION E25CODCE

- 1. Ignition "OFF".
- 2. Disconnect Yaw Rate & Lateral G sensor connector.
- 3. Measure resistance between terminal "6" of the Yaw Rate & Lateral G sensor harness connector and chassis ground.

Specification : Approx. below 1

021-62999292

ABS (ANTI-LOCK BRAKE SYSTEM)

Go to "Component Inspection" procedure.

WWW.DIGITALKHODRO.COM

Is the measured voltage within specifications?

Specification : Approx. 2.5V

3 2 1 5 4 6

SIGNAL CIRCUIT INSPECTION E1412AE8 Ignition "OFF" & Engine "OFF". 1

"Verification of vehicle Repair" procedure.

2. Measure voltage between terminal "4, 5" of the Yaw Rate & Lateral G sensor harness connector and chassis ground.

Check for open or short in the Yaw Rate & Lateral G sensor harness between terminal "6" of the Yaw Rate & Lateral G sensor harness connector and terminal "15" of the HECU harness connector. Repair as necessary and then go to

YES







EJRF501O

021-62999292

BR -105

EJRF501N

021-62999292

BRAKE SYSTEM

BR -106

NO

Check for open or short in the Yaw Rate & Lateral G sensor harness between terminal "4, 5" of the Yaw Rate & Lateral G sensor harness connector and terminal "16, 20" of the HECU harness connector. Repair as necessary and then go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION EE25C98B

- 1. Ignition "OFF".
- 2. Engine "ON". Does warning lamp remain On?

YES

Substitute with a known-good Yaw Rate & Lateral G sensor and check for proper operation. If problem is corrected, replace Yaw Rate & Lateral G sensor and then go to "Verification of Vehicle Repair" procedure.

NO

Fault is intermittent caused by open or short of Yaw Rate & Lateral G sensor harness and/or faulty Yaw Rate & Lateral G sensor or was repaired and HECU memory was not cleared. Go to the applicable troubleshooting procedure.

VERIFICATION OF VEHICLE REPAIR E1B7FC62

Refer to DTC C1101.

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران

021-62 99 92 92

ABS (ANTI-LOCK BRAKE SYSTEM)

BR -107

DTC C1283 YAW RATE & LATERAL G SENSOR-SIGNAL

COMPONENT LOCATION EE9FBC63



KJRE422A

GENERAL DESCRIPTION EAB70386

The yaw-rate & Lateral G sensor are used for the stability of a vehicle. The yaw-rate is used to measure angular velocity while the Lateral G is to measure the force that moves the vehicle away from the center, when a vehicle is cornering.

DTC DESCRIPTION E9BABEC5

This code sets when there is an open or short in the circuit of the yaw-rate & lateral G sensor.

اولین سامانه دیجیتال تعمیرکاران خودرو در ایرار

BRAKE SYSTEM

DTC DETECTING CONDITION E3EAF5E4

ltem	Detecting Condition	Possible cause
DTC Strategy	 Signal monitoring This test detects internal AY(Acceleration sensor) sensor malfunctions. 1. During the POS measure window (t = 100 ms) the AY signal must be for at least t = 60 ms between 0.2 V < AY < 0.8 V 2. If during stable vehicle behavior an AY-Failure larger than approximately 2.5 m/s occurs, the ESP controller will disregard the AY sensor information so that a false ESP intervention is prevented. A fault is recognized after 1.6 s during model validity. 3. If the offset value exceeds a threshold of approximately 2.25 m/s² an AY fault is determined. 4. During standstill the plausible range of AY is below 7 m/s². If the filtered value of AY is larger than 7 m/s² for more than 400 m/s a fault is set. 5. If the lateral acceleration is higher than 15 m/s² for more than 800 ms a suspected failure bit is set. After 1,6 s a fault is detected. 6. Standstill compensation: Failure threshold is 7,5 °/s.Long-term ("normal") compensation (during driving after succeeded standstill or fast offset compensation): Failure threshold is 7,5 °/s. Long-term ("normal") compensation (during driving after succeeded standstill or fast offset compensation): Failure threshold is 7,5 °/s. 7. The fault criteria is approx. 25 % sensitivity failure. 8. If the measured yaw rate deviates more than 2.5 °/s plus a dynamicthreshold from the reference yaw rate during model validity, a failure isrecognized after 1.6 s. The dynamic threshold is between 2.5 °/s and more than 5 °/s. A typical value is 3 °/s. 9. The measured yaw rate and the model yaw rates, calculated from theWSS and LWS are compared. If the signals doesn.t fit and forward driving is recognized, a fault is determined. 10. In case of a YRS-failure, the YRS will send an abnormal yaw rate signal. 1. Once after power up and no low voltage. 2,3,8. Continuous during stable driving. 4. Continuous, if no under voltage is detected. 	 Possible cause Faulty Lateral Acceleration Sensor Faulty Yaw Rate Sensor Faulty HECU
Monitoring period Effect	5	
Ellect	Reduced controller function caused by faulty DRS(yaw SellSOI) Signal.	

TERMINAL & CONNECTOR INSPECTION EDB6E09E

Refer to DTC C1101.
COMPONENT INSPECTION E18FD52E

- 1. Ignition "OFF".
- 2. Engine "ON".
- 3. Start and drive vehicle in gear and maintain vehicle speed is approx. 20 km/h or more(12 mph or more) Does warning lamp remain On?

YES

Substitute with a known-good Yaw Rate & Lateral G sensor and check for proper operation. If problem is corrected, replace Yaw Rate & Lateral G sensor and then go to "Verification of Vehicle Repair" procedure.

NO

Fault is intermittent caused by open or short of Yaw Rate & Lateral G sensor harness and/or faulty Yaw Rate & Lateral G sensor or was repaired and HECU memory was not cleared. Go to the applicable troubleshooting procedure.

VERIFICATION OF VEHICLE REPAIR E6DABD15

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Using a scantool, Clear DTC.
- Operate the vehicle within DTC Detecting Condition in General Information.(Start and drive vehicle in gear and maintain vehicle speed is approx. 20 km/h or more(12 mph or more)) Are any DTCs present?

Go to the applicable troubleshooting procedure.



YES

A system performs normally at this time.

BR -110

BRAKE SYSTEM

DTC C1503 ESP SWITCH ERROR

COMPONENT LOCATION EA9ED8EF



EJRF501P

GENERAL DESCRIPTION ED874ED2

Driver can inhibit the ESP control by ESP switch. When switch signal send into HECU, ESP warning lamp go ON and ESP control is stopped and if next switch signal is inputted again, ESP control is ready. This function is used for sporty driving or vehicle inspection.

DTC DESCRIPTION EFC1B5B7

Trouble code is set when the condition that the level of ESP switch is high is continued for 60sec. When the ESP switch failure is set there is no signal in the warning lamp and HECU inhibit the ESP control and allow the ABS/EBD control.

DTC DETECTING CONDITION E8F05D2F

ltem	Detecting Condition	Possible cause
DTC Strategy	Short circuit monitoring	
Enable Conditions	Trouble code is set when the condition that the level of ESP switch is high is continued for 60 sec.	 Open or short ESP switch
Monitoring period	Continuous	

TERMINAL & CONNECTOR INSPECTION E4134BE7

Refer to DTC C1101.

SIGNAL CIRCUIT INSPECTION E22AB445

- 1. Ignition "ON" & Engine "OFF" & ESP Switch"ON".
- 2. Measure voltage between terminal "31" of the HECU harness connector and chassis ground.

Specification : Approx B+

BR -111



EJRF501Q

Is the measured voltage within specifications?

YES

Fault is intermittent caused by open or short in ESP switch line, faulty ESP switch or was repaired and HECU memory was not cleared. Go to the applicable troubleshooting procedure.

NO

Check for damaged harness and poor connection in the power harness between the battery terminal(+) and the terminal "31" of the HECU harness connector. Check for open or blown 10A fuse referring to "Circuit Diagram". Repair as necessary and then go to "Verification of vehicle Repair" procedure.

COMPONENT INSPECTION E31CC225

- 1. Ignition "OFF".
- 2. Disconnect ESP switch connector.
- 3. Press the ESP switch.
- 4. Measure resistance between terminal "2" of the ESP switch harness connector and terminal "5" of the ESP switch harness connector.

Specification : Approx below 1



EJRF501R

WWW.DIGITALKHODRO.COM

021-62999292

BR -112

BRAKE SYSTEM

Is the measured resistance within specifications?

YES

Fault is intermittent caused by faulty ESP switch or was repaired and HECU memory was not cleared. Go to the applicable troubleshooting procedure.

NO

Substitute with a known-good ESP switch and check for proper operation. If problem is corrected, replace ESP switch and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR E7626E6B

Refer to DTC C1101.



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

DTC C1513 BRAKE LIGHT SWITCH MAL.

COMPONENT LOCATION ED9CFA35

KJRE433C

GENERAL DESCRIPTION ECB9AA2D

The brake light switch indicates brake pedal status to the ABS control unit. The switch is turned on when brake is depressed. The brake light switch is a normally-open contact which runs to battery voltage when active (brake depressed). When passive (brake not depressed), the cable is grounded via the break light bulbs.

DTC DESCRIPTION EF4392B0

The brake light signal is a reference to judge driver's will for braking. ABS ECU monitor open circuit of brake light switch for normal ABS control.

DTC DETECTING CONDITION EEACDAB7

ltem	Detecting Condition	Possible cause	
DTC Strategy	Open circuit monitoring	Open circuit in	
Enable Conditions	If the BLS-signals is high for 60 s, while the gas pedal is stepped, with vehicle speed > 3 m/s, offset compensated pVor < 5 bar and no control is active, a fault is set.	 Open circuit in brake switch line Faulty brake light switch 	
Monitoring period	Continuous, if no under voltage is detected.	Faulty input	
Effect	Reduced function caused by a faulty brake light switch.	stage in HECU	

TERMINAL & CONNECTOR INSPECTION E50ECDE6

Refer to DTC C1101.

SIGNAL CIRCUIT INSPECTION E5481F09

- Ignition "ON" & Engine "OFF". 1.
- 2. Press the brake pedal.
- Measure voltage between the terminal "30" of the HECU harness connector and chassis ground. 3.

WWW.DIGITALKHODRO.COM

021-62999292

021-62999292



021-62999292

BR -114

BRAKE SYSTEM

Specification : Brake Light Switch - Approx. B+

EJRF501S

Is the measured voltage within specifications?

YES

Fault is intermittent caused by open harness in brake lamp switch and brake switch line, faulty brake lamp switch was repaired and HECU memory was not cleared. Go to the applicable troubleshooting procedure.

NO

Check for damaged harness and poor connection in the power harness between the battery terminal(+) and the terminal "30" of the HECU harness connector. Check for open or blown 15A STOP fuse. Repair as necessary and then go to "Verification of vehicle Repair" procedure.

COMPONENT INSPECTION E439AA5C

- Connect a ohmmeter to the connector of brake light switch, and check whether or not there is continuity when the plunger of the brake light switch is pushed in and when it is released. The switch is in good condition if there is no continuity when the plunger is pushed.
- 2. Is there no continuity when the plunger is pushed?

YES

Fault is intermittent caused by open harness in brake light switch line, faulty brake lamp switch or was repaired and HECU memory was not cleared. Go to the applicable troubleshooting procedure.

NO

Substitute with a known-good brake lamp switch and check for proper operation. If problem is corrected, replace brake lamp switch and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR EA44DFDB

Refer to DTC C1101.

WWW.DIGITALKHODRO.COM

DTC C1604 ECU HARDWARE ERROR

COMPONENT LOCATION E9484A4E

GENERAL DESCRIPTION E84ADDAF

The HECU is composed of a ECU (Electronic Control Unit) and a HCU(Hydraulic Control Unit), so the HECU hardware includes all solenoid valves inside the unit as well as the ECU.

DTC DESCRIPTION ED7C74DB

The HECU monitors the operation of the IC components such as memory, register, A/D converter and so on. The HECU sets this code when the EEPROM data read by the master processor is different than prior data writed, or when the master/slave processor detects abnormal operation in RAM, Status Register, Interrupt, Timer, A/D converter or cycle time.

DTC DETECTING CONDITION EBC1164B

ltem	Detecting Condition	Possible cause
DTC Strategy	Internal monitoring	
Enable Conditions	 Internal control unit failures of the Micro controller and peripheral integrated circuits will be continuous monitored for proper function. After EEPROM-values have been read from EEPROM, the values are monitored for corrupt data. Failure is set if: a) Checksum not correct or b) PSW-EEPROM-Handler reported unknown failure during EEPROM-value reading. Evaluate EEPROM reading sequence. If EEPROM reading sequence take longer then 3 s, a failure is set. 	• Faulty HECU
Monitoring period	1.Continuos 2,3.directly after ignition on, during reading of EEPROM-values.	
Effect	No control is available.	

021- 62 99 92 92

BR -115

KJRE423B

BRAKE SYSTEM

BR -116

COMPONENT INSPECTION EF8AB42E

- 1. Ignition "OFF".
- 2. Engine "ON". Does warning lamp remain On?



Substitute with a known-good HECU and check for proper operation. If problem is corrected, replace HECU and then go to "Verification of Vehicle Repair" procedure.

NO

Fault is intermittent caused by faulty HECU or was repaired and HECU memory was not cleared. Go to the applicable troubleshooting procedure.

VERIFICATION OF VEHICLE REPAIR EAF3BOAF

Refer to DTC C1101.





DTC C1605 CAN CONTROL HARDWARE ERROR

COMPONENT LOCATION E155180B

GENERAL DESCRIPTION EFCEE06D

The CAN is for sending and receiving the information for TCS(ESP) control, between the HECU and EMS/TCU.

DTC DESCRIPTION EBECBESE

This code shows in case that there is an error on the CAN hardware. In this case, replace the HECU and check.

DTC DETECTING CONDITION ECA9F9D9

ltem	Detecting Condition	Possible cause
DTC Strategy	CAN RAM monitoring	
Enable Conditions	 Monitoring whether the initialization software has write access to the configuration registers of the CAN-controller module.Faults are detected immediately. Monitoring includes line short to ground, line short to supply voltage and mutual line short. Line interruptions are detected by CAN message monitor.After detecting a BUSOFF failure the transmission is reinitialized. A BUSOFF fault is established if re-initialization is tried for 15 times in sequence without success. 	• Faulty HECU
Monitoring period	 immediate during start up. Continuous 	
Effect	 CAN-Controller is not initialized correctly. Possibly no reception or transmission of messages. CAN messages can not be processed. BLS is not controlled. 	



BR -117

KJRE423B

BRAKE SYSTEM

BR -118

COMPONENT INSPECTION EF616370

- 1. Ignition "OFF".
- 2. Engine "ON". Does warning lamp remain On?



Substitute with a known-good HECU and check for proper operation. If problem is corrected, replace HECU and then go to "Verification of Vehicle Repair" procedure.

NO

Fault is intermittent caused by short harness in CAN line and/or faulty HECU or was repaired and HECU memory was not cleared. Go to the applicable troubleshooting procedure.

VERIFICATION OF VEHICLE REPAIR EFCF02FE

Refer to DTC C1101.





DTC C1611 CAN TIME OUT-ECM DTC C1612 CAN TIME OUT-TCU DTC C1623 CAN TIMEOUT STEERING ANGLE SENSOR

COMPONENT LOCATION E6626A8C



GENERAL DESCRIPTION EFAC4B05

The CAN is for sending and receiving the information for TCS(ESP) control, between the HECU and EMS/TCU.

DTC DESCRIPTION ECE364A4

This code shows in case that there is an error on the CAN hardware. In this case, replace the HECU and check.

DTC DETECTING CONDITION ED088F49

ltem	Detecting Condition	Possible cause
DTC Strategy	CAN RAM monitoring	
Enable Conditions	 Purpose is to monitor if transmitted message was not transmitted by CAN controller of ABS8/ESP8 ECU.Faults are detected after filtering. Filtering has to be customized. Purpose is to monitor if transmitted message has the expected data length.Actually the monitoring is reduced the check for too short messages.A message with oversized data length causes no fault. Faults are detected immediate. 	 Faulty HECU Faulty ECM Faulty TCU Faulty Steering angle sensor
Monitoring period	Continuous	angle sensor
Effect	 CAN messages are not correct sent. CAN messages are not according to what was expected at compile time of the software. 	

WWW.DIGITALKHODRO.COM

021-62999292

BR -119

KJRE423B



BR -120

COMPONENT INSPECTION EFF1B327

- 1. Ignition "OFF".
- 2. Engine "ON". Does warning lamp remain On?

YES

Substitute with a known-good ECM(C1611)[TCU(C1612)/Steering angle sensor(C1623)] and check for proper operation. If problem is corrected, replace ECM(C1611)[TCU(C1612)/Steering angle sensor(C1623)] and then go to "Verification of Vehicle Repair" procedure. If NG, replace HECU and then go to "Verification of Vehicle Repair" procedure.

NO

Fault is intermittent caused by faulty ECM(C1611)[TCU(C1612)/Steering angle sensor(C1623)] and/or faulty HECU or was repaired and HECU memory was not cleared. Go to the applicable troubleshooting procedure.

VERIFICATION OF VEHICLE REPAIR EBAAFADO

Refer to DTC C1101.

Cیجیال حمد مسئولیت محدود) شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



BRAKE SYSTEM

BR -121

ABS (ANTI-LOCK BRAKE SYSTEM)

DTC C1616 CAN BUS OFF

COMPONENT LOCATION E7B1A03A



KJRE423B

GENERAL DESCRIPTION EFFAB1E9

The CAN is for sending and receiving the information for TCS(ESP) control, between the HECU and EMS/TCU.

DTC DESCRIPTION E7246BC3

The HECU checks the CAN communication lines for normal TCS control, and sets this code if CAN BUS OFF status is detected for more than 100 ms.

DTC DETECTING CONDITION E084C50D

ltem	Detecting Condition	Possible cause
DTC Strategy	Open or short circuit monitoring	
Enable Conditions	Monitoring includes line short to ground, line short to supply voltage and mutual line short. Line interruptions are detected by CAN message monitor. After detecting a BUSOFF failure the transmission is reinitialized. A BUSOFF fault is established if re-initialization is tried for 15 times in sequence without success.	 Open or short circuit in CAN line
Monitoring period	Continuous	
Effect	CAN messages can not be processed. BLS(Brake light switch) is not controlled.	

TERMINAL & CONNECTOR INSPECTION ED5BFE2E

Refer to DTC C1101.

021-62999292

BR -122

BRAKE SYSTEM

SIGNAL CIRCUIT INSPECTION EEAC2FA0

- 1. Ignition "OFF".
- 2. Measure resistance between terminal "35" of the HECU harness connector and terminal "14" of the HECU harness connector.

Specification : Approx. 60



Check for open or short in CAN signal harness between terminal "35" of the HECU harness connector and terminal "14" of the HECU harness connector. Repair as necessary and then go to "Verification of vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR ETADCEEC

Refer to DTC C1101.

DTC C1625 CAN TIME OUT-ESP

COMPONENT LOCATION E2B091EE

GENERAL DESCRIPTION EEDACICA

The CAN is for sending and receiving the information for TCS(ESP) control, between the HECU and EMS/TCU.

DTC DETECTING CONDITION EEEC52A7

ىئوليىت _{item} حدود)	Detecting Condition	Possible cause
DTC Strategy	Open or short circuit monitoring	
Enable Conditions	Purpose is to monitor if receive message was not received on time by the CAN controller of ABS8/ESP8 ECU. Faults are detected after filtering.	 Open or short circuit in CAN line
Monitoring period	Continuous	 Faulty HECU
Effect	CAN messages are not received on time.	

TERMINAL & CONNECTOR INSPECTION ECC97A5D

Refer to DTC C1101.

SIGNAL CIRCUIT INSPECTION EEBEB7CE

- 1. Check for open or short in CAN signal harness between terminal "35" of the HECU harness connector and PCM harness connector.
- Check for open or short in CAN signal harness between terminal "14" of the HECU harness connector and PCM harness connector. Is it normal?

Replace the HECU. Then go to "Verification of vehicle Repair" procedure.

WWW.DIGITALKHODRO.COM

021-62999292



KJRE423B



021-62999292

BR -124

NO

Repair or replace harness and connector.

VERIFICATION OF VEHICLE REPAIR E4CD4A94

Refer to DTC C1101.



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

BRAKE SYSTEM

DTC C1626 IMPLAUSIBLE CONTROL

COMPONENT LOCATION EFAEE38F

DTC DETECTING CONDITION E61B09FE

Item	Detecting Condition	Possible cause
DTC Strategy	Internal error	
Enable Conditions	 Under normal conditions, the inlet valves of all four wheels are not closed during control for longer than 1.28 s. If the controller requests pressure-hold or pressure-decrease for longer than 1.28 s, a fault is stored. The monitoring reports a failure if continuous ESP control occurs for a time period > = 10 s. A continuous ESP control for longer than 10 s is not possible under normal conditions. 	• Faulty HECU
Monitoring period	 Continuous detected under voltage and a fault is not already detected. 	
Effect	 Reduced function as all wheel valves will remain in pressure build-up position. Reduced function of the ESP system, no more ESP, no more ABS. 	



BR -125

KJRE423B

021-62999292

BR -126

BRAKE SYSTEM

COMPONENT INSPECTION E8DAF5C2

- 1. Ignition "OFF".
- 2. Engine "ON". Does warning lamp remain On?



Replace the HECU. Then go to "Verification of vehicle Repair" procedure.



Fault is intermittent caused by faulty HECU or was repaired and HECU memory was not cleared. Go to the applicable troubleshooting procedure.

VERIFICATION OF VEHICLE REPAIR E5BA8CD9

Refer to DTC C1101.





<u>BR -127</u>

DTC C1702 VARIANT CODING

GENERAL DESCRIPTION EC5EBC2F

A hardware difference of ECU does not exist according to the specification of the vehicle, but a software changes according to deference of vehicle parameter. The ESP stores variant code (data of engine, displacement volume, T/M) at the ECU memory. Since then a ESP uses the stored data.

COMPONENT INSPECTION EC91556F

*Variant Coding

- 1. Install a EMS/TCU/ESP normally.
- 2. Connect a scanner to the vehicle.
- 3. IGN On
- 4. Scanner On
- 5. Select a brake mode.
- 6. Push the Variant Coding button.
- 7. Scanner Off
- 8. IGN Off
- 9. Remove the scanner.
- 10. IGN On
- 11. Finish the Variant Coding.



BR -128

BRAKE SYSTEM

DTC C2112 VALVE RELAY MAL.

COMPONENT LOCATION E9CA651C



KJRE423B

GENERAL DESCRIPTION EB7E53C7

The ABS ECU supplies battery power to all solenoid valves by way of a valve relay which is controlled by the Electronic Control UNIT(ECU). The valve relay and all solenoid valves are installed inside the HECU (Hydraulic and Electronic Control Unit).

شرکت دیجیتال خودرو سام EFD5C8B1

ABS ECU monitors voltage of the valve relay to check if ABS ECU can perform ABS control normally. When the valve relay is switched to ON, the HECU will set this code if the solenoid drive voltage is below permissible voltage ranges for a period of time. When the valve relay is switched to OFF, the HECU sets this code if the solenoid drive voltage is over the permissible voltage range for a period of time.

DTC DETECTING CONDITION EA202C60

Item	Detecting Condition	Possible cause
DTC Strategy	Battery Voltage Monitoring	
Enable Conditions	 Watchdog and VR(valve relay) function is tested during startup.FSA test(Fail Save Circuit test) detects if the VR/Enable remains in off position when it is turned on and vice versa. Reason could be short to GND or UZ(ECU voltage supply), interrupted lines or a defective output stage etc. A Fault is detected if UVR(valve relay voltage) < 0.8 * UZ for a time t > 500 ms. This test evaluates the function of the VR (vale relay) periodically. The VR is switched off and back on. VR malfunction and UVR short to UZ or UBVR(supply solenoid valves) and medium or high ohmic short of UVR (or a valve) to UZ, UBVR(supply solenoid valves) or GND are detected. 	 Open or short of power supply circuit Faulty HECU
Monitoring period	1.Once during startup. 2,3.Continuous	
Effect	No valve actuation possible.	

WWW.DIGITALKHODRO.COM

TERMINAL & CONNECTOR INSPECTION ED71DA3F

Refer to DTC C1101.

POWER SUPPLY CIRCUIT INSPECTION EE72AFE6

- 1. Ignition "OFF"
- 2. Disconnect HECU connector.
- 3. Ignition "ON" & Engine "OFF".
- 4. Measure voltage between terminal "3" of the HECU harness connector and chassis ground.

Specification :Approx. B+



Go to "Ground Circuit Inspection" procedure.

NO

Check for open or short in power harness between battery terminal(+) and terminal "3" of the HECU harness connector. Check for open or blown 20A fuse . Repair as necessary and then go to "Verification of vehicle Repair" procedure.

BR -129

BR -130

BRAKE SYSTEM

GROUND CIRCUIT INSPECTION E25CODCE

- 1. Ignition "OFF".
- 2. Disconnect HECU connector.
- 3. Measure resistance between terminal "4" of the HECU harness connector and chassis ground.

Specification : Approx.below 1

Is the measured resistance within specifications?

YES

Go to "Component Inspection" procedure.

NO

Check for damaged harness and poor connection between terminal "4" of the HECU harness connector and chassis ground. Repair as necessary and then go to "Verification of vehicle Repair" procedure.

COMPONENT INSPECTION E97DF095



NO

Fault is intermittent caused by open or short of power harness and/or faulty HECU or was repaired and HECU memory was not cleared. Go to the applicable troubleshooting procedure.

VERIFICATION OF VEHICLE REPAIR EB6A1AAF

Refer to DTC C1101.

DTC	C2308	FL INLET VALVE MAL.	
DTC	C2312	FL OUTLET VALVE MAL.	
DTC	C2316	FR INLET VALVE MAL.	
DTC	C2320	FR OUTLET VALVE MAL.	
DTC	C2324	RL INLET VALVE MAL.	
		RL OUTLET VALVE MAL.	
DTC	C2332	RR INLET VALVE MAL.	
		RR OUTLET VALVE MAL.	

COMPONENT LOCATION E46C9B59



GENERAL DESCRIPTION E59AFBE4

The ABS HECU is composed of an ECU (Electronic Control Unit) and a HCU(Hydraulic Control Unit), so the HECU hardware includes all solenoid valves inside the unit as well as the ECU. Solenoid valves are switched to ON, OFF by HECU when the ABS is activated. Solenoid valves function is to increase, decrease or maintain the hydraulic pressure supplied to a wheel cylinder.

DTC DESCRIPTION EEDCOE1D

The HECU monitors the operation of the valves by checking the drive circuit of the solenoid valves, and then sets this code when the unexpcted drive voltage is detected. For example, the HECU sets the DTC if an unexpected high drive voltage is detected when the valve relay is switched to OFF.

BR -131

BRAKE SYSTEM

BR -132

DTC DETECTING CONDITION EEAB5B72

ltem	Detecting Condition	Possible cause
DTC Strategy	Battery Voltage Monitoring	
Enable Conditions	 The electrical feedback signal does not match the actuation signal for the corresponding valve: Actuation Signal != Feedback Signal Fault filter time is t = 30 ms (for current controlled valves and under voltage conditions: t =80 ms) Cyclic Valve and Relay Test (CVRT): A Fault is found if UVR(Valve relay voltage) is not within 0.1 * UZ(Ignition voltage) < UVR < 0.8 * UZ A Fault is found if UVR is not UVR < 0.2 * UZ and the Valve Feedback is not act. Valve = = FALSE, not act. Valve = = TRUE At least VR is switched on again. The valve and pump motor test detects electrical actuation malfunction of ABS valves. The test actuates all valves in series (to detect short cuts or shunts between the valve lines). Faults are detected by monitoring the valve response signals. 	• Faulty HECU
Monitoring period	 Continuous CVRT is executed immediately after power on and then periodic every t =20 s. The Test is canceled if any control/valve actuation takes place or if the Vehicle is in motion and the BLS is on. The Valve and Pump motor Test is performed once after ignition on if vehicle speed is >= 15 km/h(9 MPH). 	
Effect 91-94	Valve cannot be actuated or valve is incorrectly actuated. This may result in locked wheels or wheels without pressure.	

COMPONENT INSPECTION E4AFF464

- 1. Ignition "OFF".
- 2. Engine "ON".
- 3. Start and drive vehicle in gear and maintain vehicle speed is approx. 15 km/h or more(9 mph or more) Does warning lamp remain On?

YES

Substitute with a known-good HECU and check for proper operation. If problem is corrected, replace HECU and then go to "Verification of Vehicle Repair" procedure.

NO

Fault is intermittent caused by faulty HECU or was repaired and HECU memory was not cleared. Go to the applicable troubleshooting procedure.

VERIFICATION OF VEHICLE REPAIR E6DABD16

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Using a scantool, Clear DTC.
- 3. Operate the vehicle within DTC Detecting Condition in General Information. (Start and drive vehicle in gear and maintain vehicle speed is approx. 15 km/h or more(9 mph or more)) Are any DTCs present ?



Go to the applicable troubleshooting procedure.



A system performs normally at this time.







BR -134

BRAKE SYSTEM

KJRF423B

DTC C2366 TC VALVE PRIMARY(USV1) ERROR DTC C2370 TC VALVE SECONDARY(USV2) ERROR DTC C2372 ESP VALVE 1(HSV1) ERROR DTC C2374 ESP VALVE 2(HSV2) ERROR

COMPONENT LOCATION EF6AF078



GENERAL DESCRIPTION E1FF760A

The ESP HECU is composed of an ECU (Electronic Control Unit) and a HCU(Hydraulic Control Unit), so the HECU hardware includes all solenoid valves inside the unit as well as the ECU. Solenoid valves are switched to ON, OFF by HECU when the ABS/ESP is activated. Solenoid valves function is to increase, decrease or maintain the hydraulic pressure supplied to a wheel cylinder.

DTC DETECTING CONDITION EDF0C317

ltem	Detecting Condition	Possible cause
DTC Strategy	Battery Voltage Monitoring	
Enable Conditions	The valve and pump motor test detects electrical actuation malfunction of USV and HSV valves. The test actuates all valves in series (to detect shorts or shunts between the valve lines). Faults are detected by monitoring the valve response signals.	• Faulty HECU
Monitoring period	The USV Test is performed once after ignition on at standstill if the BLS is off and at vehicle speed is $v \ge 15 \text{ km/h}(9 \text{ MPH})$ if the BLS is on.	
Effect	Valve cannot be actuated or valve is incorrectly actuated. This may result in locked wheels or wheels without pressure.	

COMPONENT INSPECTION EFCEA1F9

Refer to DTC C2308.

VERIFICATION OF VEHICLE REPAIR EAEBFBB6

Refer to DTC C2308.

WWW.DIGITALKHODRO.COM

DTC C2402 MOTOR-ELECTRICAL

COMPONENT LOCATION EFC48FCB

GENERAL DESCRIPTION EGCFFA87

The ABS ECU supplies battery power to the electric motor by way of a motor relay which is controlled by the Electronic Control Unit(ECU). The electric motor pump supplies hydraulic pressure to all wheel brake calipers by operating the piston inside the pump.

The ABS/ESP ECU monitors the pump motor relay or fuse open, open or short in motor or motor lock and then sets this code if a malfunction is detected.

WWW.DIGITALKHODRO.COM



BR -135

KJRE423B



DTC DESCRIPTION EBDEB5B2



BR -136

BRAKE SYSTEM

DTC DETECTING CONDITION ETADBDCB

ltem	Detecting Condition	Possible cause
DTC Strategy	Battery Voltage Monitoring	
Enable Conditions	 A failure is detected if the voltage UM (Pump motor voltage) > 2.0 V for a time t > = 1 s. A failure is detected if the voltage UM (Pump motor voltage) < (UZ(battery voltage) - 4.0 V) for a time t > = 100 ms. After the end of the actuation of the motor relay has, the pump motor is still in motion and is generating a Voltage during it.s slowdown. The generated UM is monitored for a certain time on high level. The time depends on the supply voltage and is in the range of t = 30 ms to t = 125 ms.If the slow down condition isn.t met, the pump is activated again (see actuation times below) and the slowdown time is measured again. This is repeated for maximum n = 3 times. If, after the last pump activation, the pump motor slowdown time is still to short, a failure is detected.Actuation times: 1st actuation: 200 ms 2nd actuation: 3000 ms 	 Open or short of power supply circuit Faulty HECU
Monitoring period	1. Stop monitor is active if the pump is off i.e. not	0
	 actuation and no Slowdown. 2. The monitor is active if the pump is switched on . 3. Monitor is always active in the transition "pump on -> pump off". 	
ئولیت محدود) Effect فودرو در ایران	 The return pump does not work correct. Pressure decrease (outlet valve) is no longer possible (wheels block). Pressure decrease (outlet valve) is no longer possible (wheels lock). 	

TERMINAL & CONNECTOR INSPECTION E105DC30

Refer to DTC C1101.

POWER SUPPLY CIRCUIT INSPECTION ED01E6CB

- 1. Ignition "OFF"
- 2. Disconnect HECU connector.
- 3. Ignition "ON" & Engine "OFF".
- 4. Measure voltage between terminal "2" of the HECU harness connector and chassis ground.

Specification :Approx. B+

15(4)(3)(2)(1)(1)(9)(8)(7)(6)(5)

26 25 24 23 22 21 20 19 18 17 16

Is the measured voltage within specifications?

(4)(3)(2)(1)

YES

Go to "Ground Circuit Inspection" procedure.

NO

Check for open or short in power harness between battery terminal(+) and terminal "2" of the HECU harness connector. Check for open or blown 40A fuse . Repair as necessary and then go to "Verification of vehicle Repair" procedure.

GROUND CIRCUIT INSPECTION EC5BCE5F

Ignition "OFF". 1.

- **Disconnect HECU connector.** 2.
- Measure resistance between terminal "1" of the HECU harness connector and chassis ground. 3.

Specification : Approx.below 1

Is the measured resistance within specifications?

YES

Go to "Component Inspection" procedure.



EJRF501V

EJRF501W

021-62999292

021-62999292

BR -138

NO

BRAKE SYSTEM

Check for damaged harness and poor connection between terminal "1" of the HECU harness connector and chassis ground. Repair as necessary and then go to "Verification of vehicle Repair" procedure.

COMPONENT INSPECTION EC1BFE7C

Refer to DTC C2308.

VERIFICATION OF VEHICLE REPAIR ECD40451

Refer to DTC C2308.



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

ANTI-LOCK BRAKING SYSTEM CONTROL MODULE

COMPONENTS E4BF16F7



- 2. Front-right tube
- 3. Rear-left tube
- 4. Rear-right tube
- 5. MC2

- 7. ABS control module connector(26P)
- 8. ABS control module(HECU)
- 9. Damper
- 10. Bracket

EJRF501X

WWW.DIGITALKHODRO.COM

021-62999292

BR -139

021-62999292

BRAKE SYSTEM

BR -140

REMOVAL EBAC4A3F

1. Disconnect the brake tube from the HECU by unlocking the nuts counterclockwise with a spanner.



INSTALLATION EEB5ADBE

- 1. Installation is the reverse of removal.
- 2. Tighten the HECU mounting bolts and brake tube nuts to the specified torque.

Tighterning torque

HECU mounting nut : 5.88~9.8 Nm (60~100 kgf·cm, 4.36~7.27 lb-ft) HECU bracket mounting bolt: 16.66~25.48 Nm (170~260 kgf·cm, 12.36~18.9 lb-ft)

KJRE502T

- 2. Lift up the vehicle.
- 3. Disconnect the connector(A) from the HECU.





KJRE503S

4. Remove the two HECU brake mounting bolts(B) , and then disassemble the HECU with the bracket.

- 1. Never attempt to disassemble the HECU.
- 2. The HECU must be transported and stored in
- 3. Never shock to the HECU.
- 5. Remove the two HECU mounting nuts and washer, and then remove the bracket.

WWW.DIGITALKHODRO.COM

021-62999292

FRONT WHEEL SPEED SENSOR

COMPONENTS E9BA1C3F



- 1. Front wheel speed sensor connector
- 2. Front wheel speed sensor

EJRF501Y

021-62999292

BR -141

021-62999292

BRAKE SYSTEM

BR -142

REMOVAL EA8CB8C7

1. Remove the front wheel speed sensor mounting bolt(A).



KJRE504J

KJRE503V

- 2. Remove the front wheel guard.
- 3. Remove the front wheel speed sensor after disconnecting the wheel speed sensor connector(A).

6

Ø

INSPECTION EA0FA5F9

1. Measure the output voltage between the terminal of the wheel speed sensor and the body ground.

In order to protect the wheel speed sensor, when measuring output voltage, a 75 resister must be used as shown.



2. Compare the change of the output voltage of the wheel speed sensor to the normal change of the output voltage as shown below.



KJQE260B

- V_low : 0.44 V ~ 0.63 V
- V_high : 0.885 V ~ 1.26 V
- Frequency range : 1~2,500 Hz

WWW.DIGITALKHODRO.COM

021-62999292

REAR WHEEL SPEED SENSOR

COMPONENTS E53F460A



- 1. Rear wheel speed sensor connector
- 2. Rear wheel speed sensor

EJRF502A

021-62999292

BR -144

REMOVAL EAE1450B

1. Remove the rear wheel speed sensor mounting bolt(A).



KJRE503W

KJRE503X

2. Remove the rear seat side pad then disconnect the rear wheel speed sensor connector(A).

Ω

INSPECTION EC85D750

1. Measure the output voltage between the terminal of the wheel speed sensor and the body ground.

In order to protect the wheel speed sensor, when measuring output voltage, a 75 resister must be used as shown.



2. Compare the change of the output voltage of the wheel speed sensor to the normal change of the output voltage as shown below.



KJQE260B

- V_low : 0.44 V ~ 0.63 V
- V_high : 0.885 V ~ 1.26 V
- Frequency range : 1~2,500 Hz

WWW.DIGITALKHODRO.COM

021-62999292

BRAKE SYSTEM
021-62999292

EBD (ELECTRONIC BRAKE-FORCE DISTRIBUTION)

BR -145

EBD (ELECTRONIC BRAKE-FORCE DISTRIBUTION)

DESCRIPTION ECEEDFAE

The EBD system (Electronic Brake force Distribution) as a sub-system of the ABS system is to control the effective adhesion utilization by the rear wheels.

It further utilizes the efficiency of highly developed ABS equipment by controlling the slip of the rear wheels in the partial braking range.

The brake force is moved even closer to the optimum and controlled electronically, thus dispensing with the need for the proportioning valve.

The proportioning valve, because of a mechanical device, has limitations to achieve an ideal brake force distribution to the rear wheels as well as to carry out the flexible brake force distribution proportioning to the vehicle load or weight increasing. And in the event of malfunctioning, driver cannot notice whether it fails or not.

EBD controlled by the ABS Control Module, calculates the slip ratio of each wheel at all times and controls the brake pressure of the rear wheels not to exceed that of the front wheels.

If the EBD fails, the EBD warning lamp (Parking brake lamp) lights up.

ADVANTAGES

- Function improvement of the base-brake system.
- Compensation for the different friction coefficients.
- Elimination of the proportioning valve.
- Failure recognition by the warning lamp.

COMPARISON BETWEEN PROPORTIONING VALVE AND EBD



EJA0032A

BRAKE SYSTEM

ESP(ELECTRONIC STABILITY PROGRAM) SYSTEM

DESCRIPTION OF ESP EAEE26D8

Optimum driving safety now has a name : ESP, the Electronic Stability Program.

ESP recognizes critical driving conditions, such as panic reactions in dangerous situations, and stabilizes the vehicle by wheel-individual braking and engine control intervention with no needfor actuating the brake or the gas pedal.

ESP adds a further function known as Active Yaw Control (AYC) to the ABS, TCS, EBD and ESP functions. Whereas the ABS/TCS function controls wheel slip during braking

and acceleration and, thus, mainly intervenes in the longitudinal dynamics of the vehicle, active yaw control stabilizes the vehicle about its vertical axis.

This is achieved by wheel individual brake intervention and adaptation of the momentary engine torque with no need for any action to be taken by the driver.

ESP essentially consists of three assemblies : the sensors, the electronic control unit and the actuators.

Of course, the stability control feature works under all driving and operating conditions. Under certain driving conditions, the ABS/TCS function can be activated simultaneously with the ESP function in response to a command by the driver.

In the event of a failure of the stability control function, the basic safety function, ABS, is still maintained.



ESP(ELECTRONIC STABILITY PROGRAM) SYSTEM

DESCRIPTION OF ESP CONTROL

ESP system includes ABS/EBD, TCS and AYC function.

ABS/EBD function The ECU changes the active sensor signal (current shift) coming from the four wheel sensors to the square wave.By using the input of above signals, the ECU calculates the vehicle speed and the acceleration & amp; amp; deceleration of the four wheels.And, the ECU judges whether the ABS/EBD should be actuated or not.

TCS function prevents the wheel slip of drive direction by adding the brake pressure and engine torque reduction via CAN communication.TCS function uses the wheel speed sensor signal to determine the wheel slip as far as ABS function. AYC function prevents unstable maneuver of the vehicle. To determine the vehicle maneuver, AYC function uses the maneuver sensor signals(Yaw Rate Sensor, Lateral Acceleration Sensor, Steering Wheel Angle Sensor). If vehicle maneuver is unstable (Over Steer or Under Steer), AYC function applies the brake pressure on certain wheel, and send engine torque reduction signal by CAN.

After the key-on, the ECU continually diagnoses the system failure. (self-diagnosis)If the system failure is detected, the ECU informs driver of the system failure through the BRAKE/ABS/ESP warning lamp. (fail-safe warning)



EJRF502K

BRAKE SYSTEM

BR -148

VARIANT CODING

A hardware difference of ECU does not exist according to the specification of the vehicle, but a software changes according to deference of vehicle parameter. The ESP stores variant code (data of engine, displacement volume , T/M) at the ECU memory. Since then an ESP uses the stored data.



- 2. Connect a scanner to the vehicle.
- 3. IGN On
- 4. Scanner On
- 5. Select a brake mode.
- 6. Push the Variant Coding button.
- 7. Scanner Off
- 8. IGN Off
- 9. Remove the scanner.
- 10. IGN On
- 11. Finish the Variant Coding.

ESP(ELECTRONIC STABILITY PROGRAM) SYSTEM

INPUT AND OUTPUT DIAGRAM



BR -149

WWW.DIGITALKHODRO.COM

BRAKE SYSTEM

BR -150

ESP OPERATION MODE E9D3CE94 1. STEP 1 The ESP analyzes the intention of the driver. Position of steering wheel + Vehicle speed ECU decides the intention of the driver. + Acceleration pedal EJRE502B 2. STEP 2 It analyzes the movement of the ESP vehicle. Vehicle rotation speed ECU decides movement of the ESP vehicle. + Operated power to the side EJRF502C 3. STEP 3 It controls a vehicle posture control through the ESP braking power. The ECU calculates the needed countermeasure. The hydraulic unit controls Independently the braking power of an each wheel. • The ESP adjusts an engine output through an engine and communication line to be connected.

WWW.DIGITALKHODRO.COM

021-62999292

ESP(ELECTRONIC STABILITY PROGRAM) SYSTEM

ESP OPERATION MODE

1. ESP Non-operation-Normal braking.

	Inlet valve(EV)	Outlet valve(AV)	Pilot valve(USV)	High pressure switch valve(HSV)	Pump motor
Normal braking	Open	Close	Open	Close	OFF



KJRE501L

WWW.DIGITALKHODRO.COM

021-62999292

BR -151

BRAKE SYSTEM

2. ESP INCREASE MODE

	Inlet valve(EV)	Outlet valve(AV)	Pilot valve(USV)	High pressure switch valve(HSV)	Pump motor
Normal braking	Open	Close	Close(Partial)	Open	ON(Motor speed control)



KJRE501M

ESP(ELECTRONIC STABILITY PROGRAM) SYSTEM

3. ESP HOLD MODE (FR is only controlled.)

	Inlet valve(EV)	Outlet valve(AV)	Pilot valve(USV)	High pressure switch valve(HSV)	Pump motor
Normal braking	Close	Close	Close(Partial)	Open	ON(Motor low speed control)



KJRE501N

BRAKE SYSTEM

4. ESP DECREASE MODE (FR is only controlled)

	Inlet valve(EV)	Outlet valve(AV)	Pilot valve(USV)	High pressure switch valve(HSV)	Pump motor
Normal braking	Close	Open	Close(Partial)	Open	ON(Motor low speed control)



KJRE501O

ESP(ELECTRONIC STABILITY PROGRAM) SYSTEM

BR -155

COMPONENTS E4CFAAFE



BRAKE SYSTEM

ESP CIRCUIT DIAGRAM(1) EB7C81E2

BR -156



EJRF502U

WWW.DIGITALKHODRO.COM

ESP CIRCUIT DIAGRAM(2)



BR -157

BRAKE SYSTEM

ESP CIRCUIT DIAGRAM(3)



ESP HECU CONNECTOR INPUT /

OUTPUT E603C607

Connector Terminal		0		Conditions
No	Description	Signal name	Specifications	Conditions
1	Ground(Pump)	GND	Current range : Min-10 A Max-20~39 A	Always
4	Ground(Valve,ECU)	GND	Current range:Min-2.5A Max-5~15A	Always
2	Supply voltage(Pump)	Vb MOTOR	Battery voltage	Always
3	Supply voltage(Valve)	Vb VALVE	Ballery Vollage	Always
26	Wheel sensor voltage(FL)	WP FL		
9	Wheel sensor voltage(FR)	WP FR	Battery voltage	IG ON
6	Wheel sensor voltage(RL)	WP RL	Ballery Vollage	
8	Wheel sensor voltage(RR)	WP RR		0
5	Wheel sensor signal(FL)	WS FL		
10	Wheel sensor signal(FR)	WS FR Voltage(High) : 0.89~1.26 V		RUNNING
27	Wheel sensor signal(RL)	WS RL		
29	Wheel sensor signal(RR)	WS RR	اولین ساما	
11	Diagnosis Input/oupput	DIAG'K'	Voltage(High) : 0.8 * IG ON more Voltage(Low) : 0.2 * IG ON lower	HI-SCAN Communication
28	Ignition	IG.KEY	Battery voltage	KEY ON/OFF
31	ESP Passive switch	ESP Passive switch	Voltage(High) : 0.6 * IG ON more Voltage(Low) : 0.4 * IG ON lower	Switch ON/OFF
36	Hand brake switch	Hand brake switch	Voltage(High) : 0.7 * IG ON more Voltage(Low) : 0.3 * IG ON lower	Switch ON/OFF
37	Yaw Rate Sensor Test	Yaw Rate Sensor Test	Voltage(High) : 4.1 V more Voltage(Low) : 1 V lower	IG ON
18	Yaw Rate Sensor Reference	Yaw Rate Sensor Reference	2.464 V ~ 2.536 V	IG ON
16	Yaw Rate Sensor Signal	Yaw Rate Sensor Signal	Offset voltage :2.5 Vrange : 0.35 V ~ 4.65 V(-100~100 ° /s)	IG ON
20	Acceleration Sensor Signal	Acceleration Sensor Signal	Offset voltage :2.5 Vrange : 0.35 V ~ 4.65 V(-1.8g ~ 1.8g)	IG ON
15	Yaw Rate Sensor Ground	Yaw Rate Sensor Ground	GND LEVEL	Always

BR -159

WWW.DIGITALKHODRO.COM

021-62999292

BR -160

BRAKE SYSTEM

Connector Terminal				Conditions
No	Description	Signal name	Specifications	Conditions
35	CAN High	CAN High	not communication:2.5 ± 0.5 V	
14	CAN Low	CAN Low	Communication : Bus Level [Volts] CAN L recessive dominant recessive EJRF502L	IG ON
30	BRAKE LIGHT SWITCH	BRAKE LIGHT SWITCH	voltage(High) : 0.8 * IG ON more voltage(Low) : 0.3 * IG ON lower	BRAKE ON/OFF

حیت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

NF ABS/ESP SENSOR OUTPUT LIST

	DISPLAY(Hi-DS Scanner)	Abbreviation	Unit	Remarks
1	ENGINE SPEED	ENG. SPD	RPM	ESP ONLY
2	VEHICLE SPEED	VEH. SPD	Km/h	
3	THROTTLE P. SNESOR	TP. SNSR	%	ESP ONLY
4	SHIFT LEVER POSITION	SHIFT POSI.	-	ESP ONLY
5	BATTERY VOLTAGE	BATT. VOL	V	
6	WHEEL SPEED SNSR-FL	FL WHEEL	Km/h	
7	WHEEL SPEED SNSR-FR	FR WHEEL	Km/h	
8	WHEEL SPEED SNSR-RL	RL WHEEL	Km/h	
9	WHEEL SPEED SNSR-RR	RR WHEEL	Km/h	
10	ABS WARNING LAMP	ABS LAMP	-	
11	EBD WARNING LAMP	EBD LAMP	-	
12	ESP FUNCTION LAMP	ESP LAMP	-	ESP ONLY
13	ESP OFF LAMP	ESP OFF	-	ESP ONLY
14	ESP OFF SWITCH	ESP SW	-	ESP ONLY
15	BRAKE LAMP SWITCH	B/LAMP	-	
16	PUMP RELAY STATE	PUMP RLY	0-	
17	VALVE RELAY STATE	VALVE RLY	-	
18	MOTOR	MOTOR	- (
19	FL VALVE (IN)	FL INLET	0	
20	FR VALVE (IN)	FR INLET	-	
21	RL VALVE (IN)	RL INLET	-	
22	RR VALVE (IN)	RR INLET	-	
23	FL VALVE (OUT)	FL OUTLET	-	
24	FR VALVE (OUT)	FR OUTLET	-	
25	RL VALVE (OUT)	RL OUTLET	-	
26	RR VALVE (OUT)	RR OUTLET	-	
27	TCS VALVE(USV)1	USV1	-	ESP ONLY
28	TCS VALVE(USV)1	USV2	-	ESP ONLY
29	ESP VALVE(HSV1)	HSV1	-	ESP ONLY
30	ESP VALVE(HSV2)	HSV2	-	ESP ONLY
31	STEERING ANGLE SNSR	SAS	deg	-720 ~ 720 °(ESP ONLY)
32	YAW RATE SNSR-LATERAL	LATERAL	g	-1.8 ~ 1.8 G(ESP ONLY)
33	YAW RATE SNSR-YAW	YAW	deg/S	-200 ~ 200 deg/s(ESP ONLY)
34	PRESSURE SENSOR	PRES. SNSR	bar	-42.5 ~ 425 bar(ESP ONLY)
35	PARKING BRAKE SIGNAL	P/BRAKE	-	ESP ONLY
37	SAS CALIBRATED	SAS CALI.	-	ESP ONLY
38	YAW RATE SENSOR TEST PASSED	YAW TEST	-	ESP ONLY

021-62 99 92 92

BR -161

021- 62 99 92 92

BRAKE SYSTEM

BR -162

FAILURE DIAGNOSIS EC4E4E4C

- 1. In principle, ESP and TCS controls are prohibited in case of ABS failure.
- 2. When ESP or TCS fails, only the failed system control is prohibited.
- 3. However, when the solenoid valve relay should be turned off in case of ESP failure, refer to the ABS fail-safe.
- 4. Information on ABS fail-safe is identical to the fail-safe in systems where ESP is not installed.

MEMORY OF FAIL CODE

- 1. It keeps the code as far as the backup lamp power is connected. (O)
- 2. It keeps the code as far as the HCU power is on. (X)

FAILURE CHECKUP

- 1. Initial checkup is performed immediately after the HECU power on.
- 2. Valve relay checkup is performed immediately after the IG2 ON.
- 3. It executes the checkup all the time while the IG2 power is on.
- 4. Initial checkup is made in the following cases.
 - 1) When the failure is not detected now
 - 2) When ABS and ESP are not in control.
 - 3) Initial checkup is not made after ECU power on.
 - 4) If the vehicle speed is over 5 mph(8 km/h) when the brake lamp switch is off.
 - 5) When the vehicle speed is over 24.8 mph(40 km/h).
- 5. Though, it keeps on checkup even if the brake lamp switch is on.
- 6. When performing ABS or ESP control before the initial checkup, stop the initial checkup and wait for the HECU power input again.
- 7. Judge failure in the following cases.
 - 1) When the power is normal.
 - 2) From the point in which the vehicle speed reaches 4.9 mph(8 km/h) after HECU power on.

COUNTERMEASURES IN FAIL

- 1. Turn the system down and perform the following actions and wait for HECU power OFF.
- 2. Turn the valve relay off.
- 3. Stop the control during the operation and do not execute any until the normal condition recovers.

WARNING LAMP ON

- 1. ABS warning lamp turns on when ABS is fail.
- 2. ESP operation lamp turns on when ESP is fail.

When power voltage and valve relay voltage are abnormal, input/output related failure judgment is not made.



021-62999292

ESP(ELECTRONIC STABILITY PROGRAM) SYSTEM

YAW-RATE SENSOR

DESCRIPTION EE9CB3F8

- 1. The yaw-rate & lateral G sensor is applied for the ESP system.
- 2. The yaw-rate is the angular velocity, when a vehicle turns a corner, and the lateral G is the acceleration to move a vehicle out of the way when cornering.
- 3. The sensor is located in the crash pad lower floor on vehicle.



KJRE504E

SPECIFICATION

	DESCRIPTION	SPECIFICATION	REMARKS	
	Nominal supply voltage	11.5 ~ 12.5 V		
	Supply voltage range		8 ~ 16 V	
	Supply current		Max. 120 mA	Typ. 75 mA
	Reference Voltage Outp	out	2.464 ~ 2.536 V	Typ. 2.5 V
424	Operating temperature ra	-40 ~ 85		
Yaw-late sensor	Measurement range	+w direction, left turn	Min.100 °/s	Typ. 111°/S
		-w direction, right turn	Min.100 °/s	Typ. 111°/S
		inearity	-1 ~ 1 %	
	Offset (within life, within	operating temperature)	3.75 °/S	
	Upper cut-	off frequency	Min. 45 Hz	Typ. 60 Hz
Lateral G sensor		+y direction, left turn	Min.1.8 g	Тур. 2 д
	Measurement range	-y direction, right turn	Min1.8 g	Тур. 2 д
	Non-I	inearity	-4 ~ 4 %	
	Offset (within life,withir	n operating temperature)	-0.09 ~ 0.09 g	
	Upper cut-off frequency			Typ. 40 Hz

BRAKE SYSTEM

OUTPUT CHARACTERISTIC



CIRCUIT DIAGRAM (YAW-RATE & LATERAL G SENSOR)



EJRF502F

ESP(ELECTRONIC STABILITY PROGRAM) SYSTEM

ESP SWITCH

DESCRIPTION EATAEFA9

- 1. The ESP OFF switch is for the user to turn off the ESP system.
- 2. The ESP OFF lamp is on when ESP OFF switch is engaged.

INSPECTION EC146ABF

1. Remove the ESP OFF switch from the switch panel on the crushpad of the driver's side.



EJRF502G

2. Check the continuity between the switch terminals as the ESP OFF switch is engaged.

Terminal Position	2	5	3	4
ON	0—	—0	9	9
OFF				

EJRF502H

021-62 99 92 92

BR -165

BRAKE SYSTEM

BR -166

STEERING WHEEL ANGLE SPEED SENSOR

DESCRIPTION EC8A2BA9

GENERAL DATA

The steering angle speed sensor detects the angle of the steering wheel in order to which direction a user chooses.The sensor is detached on the MPS(Mutil-Function Switch) under the steering wheel.

SPECIFICATION

MEASUREING PRINCIPLE

A non contact, analog angle sensor carrying out absolute measuring by the use of the Anisotropic-Magneto-Resistive effect (AMR).Measuring of the absolute angle by means of a toothed measuring gear with magnetic properties in combination with different ratios. Corresponding AMR elements that change their electrical resistance according to the magnetic field direction detect the angle position of the measuring gears.A micro-controller decodes the measured voltage signals after A/D converting with the help of a mathematical function. Output of the digital angle value and velocity via CAN-interface.

DESCR	SPECIFICATION			
Operating	8 ~ 16 V			
Operating t	emperature	-40 ~ 85		
Current co	onsumption	Max.150 mA		
Steering an	Max. ±2000 °/sec			
Connection	Connection delay time			
Reverse	voltage	-13.5 V		
Measuring range	Angle •• •	-780 ° ~ 779 °		
	Angular velocity	0 ~ 1016 °/s		
Nonlinea	-2.5° ~ +2.5 °			
Hysteres	sis angle the state but the	0 ° ~ 5 °		
Rotational friction	torque measuring	10 °/s		

CIRCUIT DIAGRAM(STEERING WHEEL SPEED ANGLE SENSOR)



EJRF502I

STEERING ANGLE SENSOR (SAS) CALCULATION

- 1. PURPOSE OF CALCULATION
 - On vehicle control, a ESP analyzes the intention of the driver.
 - A ESP recognizes a steering angle which a driver rotates through the steering angle sensor.
 - A steering angle sensor used in ESP8 adjusts 0° setting of steering wheel through K-line or CAN communication.
- 2. STEERING ANGLE SENSOR (SAS) CALIBRATION METHOD





- Align the wheel to the straight line. (steering wheel < ± 5°)
 ex) Perform the wheel alignment first. Align the wheel to the straight line. A driver moves the vehicle to the front and back about 5 meters twice or three times.
- 2) Connect Hi-scan to the vehicle.
- 3) Select Brake system.
- 4) Select Steering angle sensor(SAS) calculation.
- 5) Perform the Steering angle sensor(SAS) calculation.
- 6) Scanner OFF.
- 7) Remove the scanner from the vehicle.
- 8) Confirm the Steering angle sensor(SAS) calculation as driving the vehicle. (turn left once, turn right once)

BR -167