Heating, Ventilation and Air Conditioning

GENERAL

HUMIDITY SENSOR

COMPRESSOR OIL

A/C COMPRESSOR CONTROLS (MANUAL)

COMPRESSOR CONDENSER RECEIVER / DRIER A/C PRESSURE TRANSDUCER REFRIGERANT LINE EVAPORATOR TEMPERATURE SENSOR

A/C COMPRESSOR CONTROLS (FULL

AUTO)

IN CAR SENSOR PHOTO SENSOR WATER TEMPERATURE SENSOR AMBIENT TEMPERATURE SENSOR EVAPORATOR TEMPERATURE SENSOR A.Q.S (AIR QUALITY SENSOR)

HEATER

HEATER UNIT TEMPERATURE CONTROL ACTUATOR MODE CONTROL ACTUATOR

BLOWER CONTROLS

BLOWER UNIT BLOWER MOTOR BLOWER RELAY POWER TRANSISTOR BLOWER RESISTOR A/C AIR FILTER INTAKE ACTUATOR

BLOWER AND A/C CONTROLS (MANUAL) CONTROL PANEL

BLOWER AND A/C CONTROLS (AUTO-MATIC) CONTROL PANEL

WWW.DIGITALKHODRO.COM

021-62 99 92 92

HEATING, VENTILATION AND AIR CONDITIONING



WWW.DIGITALKHODRO.COM

021-62999292

GENERAL

GENERAL

SPECIFICATION EED1CB3D

AIR CONDITIONER

lte	em	Specification
Compressor	Туре	VS (Variable capacity)
	Oil type & Capacity	FD 46 XG(PAG)150±10cc
	Pulley type	6PK-TYPE
	Displacement	180cc/rev
Condenser	Heat rejection	14,000 ±5% kcal/hr
APT (A/C pressure transducer)	The method to measure the pressure	Voltage = 0.00878835 * Pressure (psig) + 0.5
Expansion valve	Туре	Block
Refrigerant	Туре	R-134a
	Capacity [oz.(g)]	$19.4 \pm 0.88 (550 \pm 25)$

BLOWER UNIT

424	Item	Specification	
Intake	Operating method	Actuator	
Blower	جیتال خودرو سا _{قار (مس}	Sirocco	
	Speed step	Auto + 8 speed (Automatic), 4 speed (Manual)	
	Speed control	Resistor (Manual)	
Air filter	Туре	Particle filter	

HEATER AND EVAPORATOR UNIT

Item		Specification	
Heater	Туре	Pin & Tube type	
	Heating capacity	4,600 ± 5% kcal/hr	
	Mode operating method	Actuator	
	Temperature operating method	Actuator	
Evaporator	Temperature control type	Evaporator temperature sensor	
	A/C ON/OFF [°C(°F)]	ON : 2.5 ± 0.5(35.8 ± 32.9), OFF: 0.6 ± 0.5(33.0 ± 32.9)	

WWW.DIGITALKHODRO.COM

TROUBLESHOOTING E5984368

PROBLEM SYMPTOMS TABLE

Before replacing or repairing air conditioning components, first determine if the malfunction is due to the refrigerant charge, air flow or compressor.

STANDARD :

HEATING, VENTILATION AND AIR CONDITIONING

Use the table below to help you find the cause of the problem. The numbers indicate the priority of the likely cause of the problem. Check each part in order. If necessary, replace these parts.

After correcting the malfunction, check the complete system to ensure that performance is satisfactory.

Symptom	Suspect Area	See page
No blower operation	1. Blower fuse	-
	2. Blower relay	HA - 63
	3. Blower motor	HA - 61
	4. Power transistor / Resistor	HA - 65, 67
	5. Blower speed control switch	HA - 72, 77
	6. Wire harness	-
No air temperature control	1. Engine coolant capacity	-
	2. Heater control assembly	HA - 72, 77
No compressor operation	1. Refrigerant capacity	HA - 3
	2. A/C fuse	
	3. Magnetic clutch	HA - 23
(4. Compressor	HA - 21
نه (مسئولیت محدود)	5. APT (A/C pressure transducer)	HA - 29
	6. A/C switch	
	7. Evaporator temperature sensor	HA - 33, <mark>44</mark>
	8. Wire harness	-
No cool comes out	1. Refrigerant capacity	HA - 3
	2. Refrigerant pressure	HA - 13
	3. Drive belt	-
	4. Magnetic clutch	HA - 23
	5. Compressor	HA - 21
	6. APT (A/C pressure transducer)	HA - 29
	7. Evaporator temperature sensor	HA - 33, 44
	8. A/C switch	-
	9. Heater control assembly	HA - 72, 77
	10. Wire harness	-

GENERAL

Symptom	Suspect Area	See page
Insufficient cooling	1. Refrigerant capacity	HA - 3
	2. Drive belt	-
	3. Magnetic clutch	HA - 23
	4. Compressor	HA - 21
	5. Condenser	HA - 26
	6. Expansion valve	HA - 52
	7. Evaporator	HA - 51
	8. Refrigerant lines	HA - 31
	9. APT (A/C pressure transducer)	HA - 29
	10. Heater control assembly	HA - 72, 77
No engine idle-up when A/C	1. Engine ECU	-
switch ON	2. Wire harness	-
No air inlet control	1. Heater control assembly	HA - 72, 77
No mode control	1. Heater control assembly	HA - 72, 77
	2. Mode actuator	HA - 56
No cooling fan operation	1. Cooling fan fuse	0
	2. Fan motor	
	3. Engine ECU	
	4. Wire harness	

اولین سامانه دیجیتال تعمیر معادد SPECIAL TOOLS

Tool (Number and name)	Illustration	Use
09977-29000 Disc & hub assembly bolt remover	EQA9002A	Removal and installation of the disc & hub assembly bolt

AIR CONDITIONING SYSTEM

INSTRUCTIONS E4731052

WHEN HANDLING REFRIGERANT

- 1. R-134a liquid refrigerant is highly volatile. A drop on the skin of your hand could result in localized frostbite. When handling the refrigerant, be sure to wear gloves.
- 2. It is standard practice to wear goggles or glasses to protect your eyes, and gloves to protect your hands. If the refrigerant splashes into your eyes, wash them with clean water immediately.
- The R-134a container is highly pressurized. Never leave it in a hot place, and check that the storage temperature is below 52°C (126°F)
- 4. An electronic leak detector should be used to check the system for refrigerant leakage. Bear in mind that the R-134a, upon coming into contact with flame, produces phosgene, a highly toxic gas.
- 5. Use only recommended the lubricant for R-134a systems. If lubricants other than the recommended one used, system failure may occur.
- 6. PAG lubricant absorbs moisture from the atmosphere at a rapid rate, therefore the following precautions must be observed:
 - When removing refrigerant components from a vehicle, cap immediately the components to prevent from the entry of moisture.
 - When installing refrigerant components to a vehicle, do not remove the cap until just before connecting the components.
 - Complete the connection of all refrigerant tubes and hoses without delay to prevent the A/C system from taking on moisture.
 - Use the recommended lubricant from a sealed container only.
- 7. If an accidental discharge in the system occurs, ventilate the work area before resuming service.

HEATING, VENTILATION AND AIR CONDITIONING

WHEN REPLACING PARTS ON A/C SYSTEM

- 1. Never open or loosen a connection before discharging the system.
- Seal the open fittings of components with a cap or plug immediately to prevent intrusion of moisture or dust.
- 3. Do not remove the sealing caps from a replacement component until it is ready to be installed.
- 4. Before connecting an open fitting, always install a new sealing ring. Coat the fitting and seal with refrigerant oil before making the connection.



AIR CONDITIONING SYSTEM

WHEN INSTALLING CONNECTING PARTS

FLANGE WITH GUIDE PIN

Check the new O-ring for damage (use only the specified) and lubricate it using compressor oil. Tighten the nut to specified torque.



	Tightening torque (N.m (kg.m, lb-ft))		
Size	General bolt, nut		
	4T	7T	
M6	5~6 (0.5~0.6, 3.6~4.3)	9~11 (0.9~1.1, 6.5~7.9)	
M8	12~14 (1.2~1.4, 8.7~10)	20~26 (2.0~2.6, 14~18)	
M10	25~28 (2.5~2.8, 18~20) 45~55 (4.5~5.5, 32~39)		
S:	Flange bolt, nut		
Size	4T	7T	
M6	5~7 (0.5~0.7, 3.6~5.0)	8~12 (0.8~1.2, 5.8~8.6)	
M8	10~15 (1.0~1.5, 7~10)	19~28 (1.9~2.8, 14~20)	
M10	21~31 (2.1~3.1, 15~22)	39~60 (3.9~6.0, 28~43)	

LQAC003C

NOTE

T means tensile intensity, which is stamped on the head of bolt only numeral.

HANDLING TUBING AND FITTINGS

The internal parts of the refrigeration system will remain in a state of chemical stability as long as pure moisture-free refrigerant and refrigerant oil are used. Abnormal amounts of dirt, moisture or air can upset the chemical stability and cause problems or serious damage.

THE FOLLOWING PRECAUTIONS MUST BE OBSERVED

- 1. When it is necessary to open the refrigeration system, have everything you will need to service the system ready so the system will not be left open any longer than necessary.
- 2. Cap or plug all lines and fittings as soon as they are opened to prevent the entrance of dirt and moisture.
- 3. All lines and components in parts stock should be capped or sealed until they are ready to be used.
- 4. Never attempt to rebind formed lines to fit. Use the correct line for the installation you are servicing.
- 5. All tools, including the refrigerant dispensing manifold, the gauge set manifold and test hoses, should be kept clean and dry.

HEATING, VENTILATION AND AIR CONDITIONING

REFRIGERATION CYCLE EC68FD3E



AIR CONDITIONING SYSTEM

REFRIGERANT SYSTEM SERVICE

BASICS E1A04FF2

REFRIGERANT RECOVERY

Use only service equipment that is U.L-listed and is certified to meet the requirements of SAE J2210 to remove HFC-134a(R-134a) from the air conditioning system.

- Air conditioning refrigerant or lubricant vapor can irritate your eyes, nose, or throat.
- Be careful when connecting service equipment.
- Do not breathe refrigerant or vapor.

If accidental system discharge occurs, ventilate work area before resuming service.

Additional health and safety information may be obtained from the refrigerant and lubricant manufacturers.

- 1. Connect an R-134a refrigerant.
 - Recovery/Recycling/Charging System (A) to the highpressure service port (B) and the low-pressure service port (C) as shown, following the equipment manufacturer's instructions.



KQRE011A





EQKE004A

 Measure the amount of refrigerant oil removed from the A/C system after the recovery process is completed. Be sure to install the same amount of new refrigerant oil back into the A/C system before charging.

SYSTEM EVACUATION

Use only service equipment that is U.L-listed and is certified to meet the requirements of SAE J2210 to remove HFC-134a(R-134a) from the air conditioning system.

CAUTION

- Air conditioning refrigerant or lubricant vapor can irritate your eyes, nose, or throat. Be careful when connecting service equipment.
- Do not breathe refrigerant or vapor.

If accidental system discharge occurs, ventilate work area before resuming service.

Additional health and safety information may be obtained from the refrigerant and lubricant manufacturers.

When an A/C System has been opened to the atmosphere, such as during installation or repair, it must be evacuated using an R-134a refrigerant Recovery/Recycling/Charging System. (If the system has been open for several days, the receiver/dryer should be replaced, and the system should be evacuated for several hours.)

KQRE011B

WWW.DIGITALKHODRO.COM

HA -9

HA -10

 Connect an R-134a refrigerant. Recovery/Recycling/Charging System (A) to the highpressure service port (B) and the low-pressure service port (C) as shown, following the equipment manufacturer's instructions.



EQKE004A

- 3. If the low-pressure does not reach more than 93.3 kPa (700 mmHg, 27.6 in.Hg) in 10 minutes, there is probably a leak in the system. Partially charge the system, and check for leaks (Refer to Leak Test.).
- 4. Remove the low pressure valve from the low-pressure service port.

SYSTEM CHARGING

Use only service equipment that is U.L-listed and is certified to meet the requirements of SAE J2210 to remove HFC-134a(R-134a) from the air conditioning system.

\Lambda CAUTION

- Air conditioning refrigerant or lubricant vapor can irritate your eyes, nose, or throat.
- Be careful when connecting service equipment.
- Do not breathe refrigerant or vapor.

If accidental system discharge occurs, ventilate work area before resuming service.

Additional health and safety information may be obtained from the refrigerant and lubricant manufacturers.

HEATING, VENTILATION AND AIR CONDITIONING

1. Connect an R-134a refrigerant.

Recovery/Recycling/Charging System (A) to the high-pressure service port (B) as shown, following the equipment manufacturer's instructions.



EQKE004A

2. Add the same amount of new refrigerant oil to system that was removed during recovery. Use only specified refrigerant oil. Charge the system with 19.4 ± 0.88 oz. $(550 \pm 25g)$ of R-134a refrigerant. Do not overcharge the system the compressor will be damaged.

REFRIGERANT LEAK TEST

Always conduct a leak test with an electronic leak detector whenever leakage of refrigerant is suspected and when conducting service operations which are accompanied by disassembly or loosening or connection fittings.

🕕 NOTE

In order to use the leak detector properly, read the manual supplied by the manufacturer.

If a gas leak is detected, proceed as follows:

- 1. Check the torque on the connection fittings and, if too loose, tighten to the proper torque. Check for gas leakage with a leak detector.
- 2. If leakage continues even after the fitting has been tightened, discharge the refrigerant from the system, disconnect the fittings, and check their seating faces for damage. Always replace, even if the damage is slight.
- 3. Check the compressor oil and add oil if required.

AIR CONDITIONING SYSTEM

4. Charge the system and recheck for gas leaks. If no leaks are found, evacuate and charge the system again.



LQAC013A

A/C SYSTEM PERFORMANCE TESTS

- 1. Connect an R-134a refrigerant. Recovery/Recycling/Charging System to the high-pressure service port and the low-pressure service port, following the equipment manufacturer's instructions.
- 2. Determine the relative humidity and air temperature.
- 3. Remove the glove box stopper and tension code and let the glove box hang down.
- 4. Insert a thermometer in the cool air outlet.
- 5. Place a thermometer near the blower unit inlet.

- Avoid direct sunlight.
- Open hood.

6.

- Open front doors.
- Set the temperature control dial to Max cool, the mode control switch to Vent, and the recirculation control switch to Recirculation.
- Turn the A/C switch in and the fan switch to Max.
- Run the engine at 1,500 rpm.
- No driver or passenger in vehicle.
- 7. After running the air conditioning for 10 minutes under the above test conditions, read the delivery temperature from the thermometer in the cool air outlet, the intake temperature near the blower unit inlet, and the high and low system pressure from the A/C gauges.
- 8. To complete the chart
 - Mark the delivery temperature along the vertical line
 - Mark the intake temperature along the bottom line
 - Draw a line straight up from the air temperature to the humidity
 - Mark a point 10% above and 10% below the humidity level
 - From each point
 - Draw a horizontal line across the delivery tem-
 - The delivery temperature should fall between the two lines
 - Complete the low side pressure test and high side pressure test in the same way
 - Any measurements outside the line may indicate the near for more further inspection



KQQE003A

WWW.DIGITALKHODRO.COM

021-62999292

HA -11



HEATING, VENTILATION AND AIR CONDITIONING



021-62999292

HA -13

AIR CONDITIONING SYSTEM

ON-VEHICLE INSPECTION EA9864CB

This is a method in which the trouble is located by using a gauge set. Read the gauge pressure when these conditions are established.

TEST CONDITIONS

Temperature at the air inlet with the switch set at recirculation is 30~35°C (86~95°F).

Low pressure side : 0.15~0.25MPa (1.5~2.5 kg/cm², 21.8~36.3psi)

Engine running at 1,500rpm. _

- Blower speed control knob on "4" position.
- Temperature control knob on "COOL" position.

NOTE

It should be noted that the gauge indications may vary slightly due to ambient temperature conditions.

Normally functioning refrigeration system. 1.



EQKE006B

Symptom seen in refrigeration system	Probable cause	Diagnosis	Remedy
During operation, pressure on low pressure side sometimes becomes a vacuum and sometimes normal	Moisture entered in refrigeration system freezes at expansion valve orifice and temporarily stops cycle, but normal state is restored after a time when the ice melts	 Drier in over saturated state Moisture in refrigeration system freezes at expansion valve orifice and blocks circulation of refrigerant 	 Replace drier Remove moisture in cycle through repeatedly evacuating the system Evacuate the system and charge new refrigerant to specified amount

WWW.DIGITALKHODRO.COM

021-62999292

HEATING, VENTILATION AND AIR CONDITIONING

3. Insufficient cooling

Condition : Insufficient cooling	Low pressure	High pressure	
	9 60 70 90 9 40 70 90 9 40 70 70 90 8 40 70 70 90 8 40 70 70 70 70	20 20 40 50 50 50 50 50 50 50 50 50 5	

EQKE006C

Symptom seen in refrigeration system	Probable cause	Diagnosis	Remedy
	Gas leakage at some place in refrigeration system		 Check for gas leakage with gas leak detector and repair if necessary Evacuate the system and charge new refrigerant to specified amount If indicated pressure value is near 0 when connected to gauge, create the vacuum after inspecting and repairing the location of the leak

AIR CONDITIONING SYSTEM

4. Poor circulation of refrigerant



EQKE006D

Symptom seen in refrigeration system	Probable cause	Diagnosis	Remedy
 Pressure low in both low and high pressure sides Frost on tube from receiver to unit 	Refrigerant flow obstructed by dirt in drier	Condenser clogged	Replace drier
(مسئولیت محدود)	جيتال خودرو سامانه		

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

HEATING, VENTILATION AND AIR CONDITIONING

5. Refrigerant does not circulate



Symptom seen in refrigeration system	Probable cause	Diagnosis	Remedy
 Vacuum indicated on low pressure side, very low pressure indicated on high pressure side Frost or dew seen on piping before and after receiver/drier or expansion valve 	 Refrigerant flow obstructed by moisture or dirt in refrigeration system Refrigerant flow obstructed by gas leakage from expansion valve 	Refrigerant does not circulate	 Check expansion valve Clean out dirt in expansion valve by blowing with air Replace drier Evacuate the system and charge new refrigerant to specified amount For gas leakage from expansion valve, replace expansion valve

AIR CONDITIONING SYSTEM

6. Refrigerant overcharged or insufficient cooling of condenser



EQKE006F

Symptom seen in refrigeration system	Probable cause	Diagnosis	Remedy
Pressure too high on both low and high pressure sides	 Unable to develop sufficient performance due to excessive refrigerant Insufficient cooling of condenser 	 Excessive refrigerant in cycle refrigerant overcharged Condenser cooling condenser fins clogged or condenser fan faulty 	 (1) Clean condenser (2) Check cooling fan with fluid coupling operation. (3) If (1) and (2) are in normal state, check amount of refrigerant Evacuate the system and charge new refrigerant to specified amount

HEATING, VENTILATION AND AIR CONDITIONING

7. Air present in refrigeration system



EQKE006G

Symptom seen in refrigeration system	Probable cause	Diagnosis	Remedy
 Pressure too high on both low and high pressure sides The low pressure piping hot to the touch 	Air entered in refrigeration system	 Air present in refrigeration system Insufficient vacuum purging 	 Check compressor oil to see if it is dirty or insufficient Evacuate the system and charge new refrigerant to specified amount

8. Expansion valve functions improperly

Condition : Insufficient cooling	

EQKE006G

Symptom seen in refrigeration system	Probable cause	Diagnosis	Remedy
 Pressure too high on both low and high pressure sides Frost or large amount of dew on piping on low pressure side 	Trouble in expansion valve	 Excessive refrigerant in low pressure piping Expansion valve opened too wide 	 Check expansion valve Replace if defective

AIR CONDITIONING SYSTEM

9. Defective compression compressor



EQKE006H

Symptom seen in refrigeration system	Probable cause	Diagnosis	Remedy
 Pressure too high on low pressure side Pressure too low on high pressure side 	Internal leak in compressor	 Compression defective Valve leaking or broken sliding parts 	Repair or replace compressor
(مسئولیت محدود)	جيتال خودرو سامانه		

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

<u>HA -20</u>

HEATING, VENTILATION AND AIR CONDITIONING

COMPONENT LOCATION INDEX EADF7118

ENGINE ROOM



021-62999292

AIR CONDITIONING SYSTEM

INTERIOR

HA -21



EQRF001B

COMPRESSOR OIL

OIL SPECIFICATION EE9BC57D

- The HFC-134a system requires synthetic (PAG) compressor oil whereas the R-12 system requires mineral compressor oil. The two oils must never be mixed.
- Compressor (PAG) oil varies according to compressor model. Be sure to use oil specified for the model of compressor.

HANDLING OF OIL

- The oil should be free from moisture, dust, metal powder, etc.
- Do not mix with other oil.
- The water content in the oil increases when exposed to the air. After use, seal oil from air immediately. (HFC-134a Compressor Oil absorbs moisture very easily.)
- The compressor oil must be stored in steel containers, not in plastic containers.

COMPRESSOR OIL CHECK

The oil used to lubricate the compressor is circulating with the refrigerant.

Whenever replacing any component of the system or a large amount of gas leakage occurs, add oil to maintain the original amount of oil.

Oil total volume in system: PAG 150cc (5.07 fl.oz)

OIL RETURN OPERATION

There is close affinity between the oil and the refrigerant. During normal operation, part of the oil recirculates with the refrigerant in the system. When checking the amount of oil in the system, or replacing any component of the system, the compressor must be run in advance for oil return operation. The procedure is as follows:

- 1. Open all the doors and the engine hood.
- 2. Start the engine and air conditioning switch to "ON" and set the blower motor control knob at its highest position.
- 3. Run the compressor for more than 20 minutes between 800 and 1,000 rpm in order to operate the system.
- 4. Stop the engine.

HEATING, VENTILATION AND AIR CONDITIONING

REPLACEMENT OF COMPONENT PARTS

When replacing the system component parts, supply the following amount of oil to the component parts to be installed.

Component parts to be installed	Amount of Oil
Evaporator	50 cc (1.70 fl.oz)
Condenser	30 cc (1.02 fl.oz)
Receiver/dryer	30 cc (1.02 fl.oz)
Refrigerant line(One piece)	10 cc (0.34 fl.oz)

For compressor replacement, subtract the volume of oil drained from the removed compressor from the specified volume, and drain the calculated volume of oil from the new compressor:

The specified volume - volume of removed compressor = volume to drain from the new compressor.

NOTE

Even if no oil is drained from the removed compressor, don't drain more than 50cc from new compressor.

A/C COMPRESSOR CONTROLS (MANUAL)

A/C COMPRESSOR **CONTROLS (MANUAL)**

COMPRESSOR

COMPONENT LOCATION EFFCEBAD



EQRF105A

WWW.DIGITALKHODRO.COM

021-62999292

HA -24

HEATING, VENTILATION AND AIR CONDITIONING

COMPONENTS



- 2. Disc & hub assembly
- 3. Shim
- 4. Retainer ring
- 5. Pulley

- 7. Field coil
- 8. Screw
- 9. Connector bracket
- 10. Compressor assembly

EQRF105B

A/C COMPRESSOR CONTROLS (MANUAL)

REMOVAL EDB3EDCD

- 1. If the compressor is marginally operable, run the engine at idle speed, and let the air conditioning work for a few minutes, then shut the engine off.
- 2. Disconnect the negative cable from the battery.
- 3. Recover the refrigerant with a recovery/charging station (Refer to page HA-9).
- 4. Loosen the drive belt (Refer to the EM-Timing).
- 5. Remove the bolts, then disconnect the suction line (A) and discharge line (B) from the compressor. Plug or cap the lines immediately after disconnecting them to avoid moisture and dust contamination.

عامان ودر ایران خودرو در ایران KORE1050

6. Disconnect the compressor clutch connector (A), then remove the mounting bolts and the compressor (B).



KQRE105D

B

KQRE105J

DISASSEMBLY EA7DE4BF

 Remove the center bolt (A) while holding the disc & hub assembly with a commercially available disc & hub assembly bolt remover; Special tool number 09977-29000.

TORQUE : 10~15N.m (1.02~1.53 kgf.m, 7.5~11.3 lb-ft)



EQKE103A

Remove the disc & hub assembly (A) and shim (B), taking care not to lose the shims. If the clutch needs adjustment, increase or decrease the number and thickness of shims as necessary, then reinstall the disc & hub assembly, and recheck its clearance (Refer to page HA-24).

HA -26

3. If you removal the field coil, remove retainer ring (A) with retainer ring pliers.

🚺 ΝΟΤΕ

- Be careful not to damage the pulley (B) and compressor during removal/installation.
- Once retainer ring (A) is removed, replace it with a new one.

HEATING, VENTILATION AND AIR CONDITIONING

INSPECTION ESDCBCCA

- 1. Check the plated parts of the disc & hub assembly for color changes, peeling or other damage. If there is damage, replace the clutch set.
- 2. Check the pulley bearing play and drag by rotating the pulley by hand. Replace the clutch set with a new one if it is noisy or has excessive play/drag.



4. Remove the screw (A) from the field coil ground terminal and then remove the field coil (B) and retainer ring (C).

مانه دیجیتال تعمیرکاران خودرو در ایران



KQRE105L

KORE105K

- 5. Reassemble the compressor clutch in the reverse order of disassembly, and note these items :
 - Clean the pulley and compressor sliding surfaces with non-petroleum solvent.
 - Install new retainer rings, and make sure they are fully seated in the groove.
 - Make sure that the pulley turns smoothly after its reassembled.



KQRE105F

3. Measure the clearance between the pulley (A) and the disc & hub assembly (B) all the way around. If the clearance is not within specified limits, remove the disc & hub assembly (Refer to page HA-23) and add or remove shims as needed to increase or decrease clearance.

Clearance: 0.5 ± 0.15 mm (0.020 ± 0.006 in.)

🚺 ΝΟΤΕ

The shims are available in eight thicknesses: 0.7mm, 0.8mm, 0.9mm, 1.0mm, 1.1mm, 1.2mm, 1.3mm and 1.4mm



KQRE105G

WWW.DIGITALKHODRO.COM

021-62999292

A/C COMPRESSOR CONTROLS (MANUAL)

 Check operation of the magnetic clutch. Connect the compressor side terminals to the battery (+) terminal and the ground battery (-) terminal to the compressor body.

Check the magnetic clutch operating noise to determine the condition.

KQRE105H



INSTALLATION E9E09758

1. Make sure of the length of compressor mounting bolts, and then tighten it A B C D order.

TORQUE : 20~33N.m (2.04 ~ 3.36 kgf.m, 14.7~24.3lb-ft)



KQRE105E

- 2. Install in the reverse order of removal, and note these items.
 - If you're installing a new compressor, drain all the refrigerant oil from the removed compressor, and measure its volume, Subtract the volume of drained oil from 150cc the result is the amount of oil you should drain from the new compressor (through the suction fitting).
 - Replace the O-rings with new ones at each fitting, and apply a thin coat of refrigerant oil before installing them. Be sure to use the right O-rings for R-134a to avoid leakage.
 - To avoid contamination, do not return the oil to the container once dispensed, and never mix it with other refrigerant oils.
 - Immediately after using the oil, replace the cap on the container and seal it to avoid moisture absorption.
 - Do not spill the refrigerant oil on the vehicle; it may damage the paint; if the refrigerant oil contacts the paint, wash it off immediately.
 - Adjust the drive belt (Refer to the EM-Timing) Charge the system and test its performance.

HEATING, VENTILATION AND AIR CONDITIONING

CONDENSER

COMPONENT LOCATION E84866E5



WWW.DIGITALKHODRO.COM

A/C COMPRESSOR CONTROLS (MANUAL)

INSPECTION EDD70B30

- 1. Check the condenser fins for clogging and damage. If clogged, clean them with water, and blow them with compressed air. If bent, gently bend them using a screwdriver or pliers.
- 2. Check the condenser connections for leakage, and repair or replace it, if required.

REPLACEMENT EFC6CCE6

- 1. Recover the refrigerant with a recovery/ recycling/ charging station (Refer to page HA-9).
- 2. Disconnect the negative (-) battery terminal.
- 3. Remove the air duct (A).
- 4. Remove the radiator bracket (B) after loosening the bolts.



KQRE108B

 Remove the nuts (A), then disconnect the discharge line and condenser line from the condenser.
 Plug or cap the lines immediately after disconnecting them to avoid moisture and dust contamination.



KQRE113B

6. Remove the bolts (A), then remove the condenser (B) by lifting it up. Be careful not to damage the radiator and condenser fins when removing the condenser.



KQRE108C

- 7. Install in the reverse order of removal, and note these items :
 - If you're installing a new condenser, add refrigerant oil.
 - Replace the O-rings with new ones at each fitting, and apply a thin coat of refrigerant oil before installing them. Be sure to use the right O-rings for R-134a to avoid leakage.
 - Be careful not to damage the radiator and condenser fins when installing the condenser.
 - Be sure to install the lower mount cushions of condenser securely into the holes.
 - Charge the system, and test its performance. (Refer to HA-11)

RECEIVER / DRIER

REPLACEMENT E256C8CB

1. Remove the condenser, and then remove the bottom cap (B) from the receiver/drier tank (A).

TORQUE : 20~25N.m (2.0~2.5kgf·m, 14.5~18.2lb-ft)

😵 WARNING

Use of impact wrench may cause cracking on the receiver/drier tank connecting pipe to the condenser.

B

HEATING, VENTILATION AND AIR CONDITIONING

- 5. Insert the new desiccant into the receiver drier tank. The desiccant must be sealed in vacuum before it is exposed to air for use.
- 6. Install the new bottom cap to the receiver drier tank.

🚺 ΝΟΤΕ

- Always replace the desiccant and bottom cap at the same time.
- If you're installing a new receiver/drier, add refrigerant oil.
- Replace the O-rings with new ones at each fitting, and apply a thin coat of refrigerant oil before installing them. Be sure to use the right O-rings for R-134a to avoid leakage.
- Be careful not to damage the radiator and condenser fins when installing the condenser.
- Be sure to install the lower mount cushions of condenser securely into the holes.
- Charge the system, and test its performance. (Refer to HA-11)







KQRE108E

KQRE108D

- 3. Check for crumbled desiccant and clogged bottom cap filter.
- 4. Apply air conditioning compressor oil along the O-rings and threads of the new bottom cap.

A/C PRESSURE TRANSDUCER

COMPONENT LOCATION EB9D9D38



HA -31

HA -32

DESCRIPTION E084BE42

A/C pressure transducer (A) convert the pressure value of high pressure line into voltage value after measure it. By converted voltage value, engine ECU controls cooling fan by operating it high speed or low speed. Engine ECU stop the operation of compressor when the temperature of refrigerant line is so high or so low irregularly to optimize air conditioning system.

INSPECTION EE16AAB1

(1) Ground

 Measure the pressure of high pressure line by measuring voltage output between NO.1and NO.2 terminals.

③ Power(5V)

HEATING, VENTILATION AND AIR CONDITIONING

REPLACEMENT EDA9C7E1

- 1. Disconnect negative (-) battery terminal.
- 2. Disconnect A/C pressure transducer connector (3P) from wiring harness.



KQRE116C

3. Remove the A/C pressure transducer.

CAUTION

Take care that liquid suction pipe is not bent.

TORQUE : 10~12 N.m (1.02~1.22 kgf.m, 7.4~8.8 lb-ft)

Installation is the reverse order of removal.

_EQRF116B تعمیرکاران خودرو در ایران

2 Voltage

2. Inspection the voltage value whether it is sufficient to be regular value or not.

Voltage = 0.00878835 * Pressure (psig) + 0.5

3. If the measured voltage value is not specification, replace the A/C pressure transducer.

REFRIGERANT LINE

COMPONENT LOCATION E4C40E5B



HA -33

HA -34

HEATING, VENTILATION AND AIR CONDITIONING

REPLACEMENT ECTAECA0

- 1. Discharge refrigerant from refrigeration system (Refer to page HA-9).
- 2. Replace faulty tube or hose.

Cap the open fittings immediately to keep moisture or dirt out of the system.

3. Tighten joint of bolt or nut to specified torque.

Connections should not be torque tighter than the specified torque.

Part tightened	N.m	kgf.m	lb-ft	
Condenser x Discharge hose	5 ~ 7	0.5 ~ 0.6	27 50	
Condenser x Liquid tube	5~7	0.5 ~ 0.6	5.7 ~ 5.2	
Compressor x Discharge hose	5~7	0.5 ~ 0.6	27 52	
Compressor x Suction hose	نه (مسا		3.7 ~ 5.2 بتال خود	شركت ديجي
Expansion valve x Evaporator	12 ~ 15	1.2 ~ 1.5	8.7 ~ 10.8	اولین سامان

4. Evacuate air in refrigeration system and charge system with refrigerant (Refer to page HA-9).

Specified amount: $550 \pm 25g (19.4 \pm 0.88 \text{ oz.})$

- 5. Inspect for leakage of refrigerant. Using a gas leak detector, check for leakage of refrigerant (Refer to page HA-10).
- 6. Inspect A/C operation.



A/C COMPRESSOR CONTROLS (MANUAL)

EVAPORATOR TEMPERATURE SENSOR

COMPONENT LOCATION EA4AB247



EQRF161A

WWW.DIGITALKHODRO.COM

DESCRIPTION EC03DC25

The evaporator temperature sensor will detect the evaporator core temperature and interrupt compressor relay power in order to prevent evaporator freezing by excessive cooling.

It is a negative type thermistor whose resistance is inversely proportional to temperature.

INSPECTION E1F5D600

- 1. Ignition "OFF".
- 2. Disconnect evaporator temperature sensor.
- 3. Using the multi-tester, Measure resistance between terminal "1" and "2" of evaporator temperature sensor.



نه دیچیتال تعمیرکاران خودرو در ایران

AQGE116C

SPECIFICATION

Evaporator core temperature [°C(°F)]	Resistance [K]
-10 (14)	18.31
0 (32)	11.60
10 (50)	7.55
15 (59)	5.04
30 (86)	3.44
40 (104)	2.40

- 4. If the measured resistance is not specification, substitute with a known-good evaporator temperature sensor and check for proper operation.
- 5. If the problem is corrected, replace the evaporator temperature sensor.

HEATING, VENTILATION AND AIR CONDITIONING

REPLACEMENT EBF2B272

 Remove the passenger's crush pad center low cover (A) after loosening 2 screws.



EQRF203F

- 2. Remove the under cover after loosening 2 screws.
- 3. Disconnect the connector pin (A).
 - Remove the evaporator temperature sensor (B) by pulling it after rotating 90° in a counterclockwise direction.



KQRE161B

5. Installation is the reverse order of removal.

021-62999292
A/C COMPRESSOR CONTROLS (FULL AUTO)

A/C COMPRESSOR CONTROLS (FULL AUTO)

IN CAR SENSOR

COMPONENT LOCATION E22A5D60



EQRF201A

HA -38

DESCRIPTION E9FE38EA

- 1. In-car air temperature sensor is located at the lower crush pad.
- 2. The sensor contains a thermistor which measures the temperature of the inside. The signal, decided by the resistance value which changes in accordance with perceived inside temperature, is delivered to heater control unit and according to this signal the control unit regulates incar temperature to intended value.



2. Sensor ground (-) 5. Sensor power (+) 3. Humidity sensor signal 6. Motor (+)

INSPECTION E41D0F98

- Ignition "OFF". 1.
- 2. Disconnect in-car sensor.
- Using the multi-tester, Measure resistance between 3. terminal "2" and "4" of in-car sensor.



Resistance between Temperature [°C(°F)] terminals 2 and 4 (K) -15 (5) 216.1 ± 3.2% 0 (32) 97.71 ± 2.4% 15 (59) 47.13 ± 1.7% 25 (77) 30.00 ± 1.2% 19.59 ± 1.6% 35 (95) 10.81 ± 2.2% 50 (122)

HEATING, VENTILATION AND AIR CONDITIONING

REPLACEMENT E5FABC1F

- Disconnect the negative (-) battery terminal. 1.
- Remove the lower crush panel (A) (Refer to the Body 2. group).
- Disconnect the connector of in-car sensor. 3.
- Loosen the mounting screws (B) and then remove the 4. in-car sensor (C).



KORE201C

Installation is the reverse order of removal. 5



EQRF201E

PHOTO SENSOR

COMPONENT LOCATION EC142FAB



EQRF202A

HA -39

WWW.DIGITALKHODRO.COM

HA -40

DESCRIPTION EFCA8B8E

- 1. The photo sensor is located at the right part of defrost nozzle.
- 2. The photo sensor contains a photovoltaic (sensitive to sunlight) diode. The solar radiation received by its light receiving portion, generates an electromotive force in proportion to the amount of radiation received which is transferred to the automatic temperature control module so that the solar radiation compensation will be performed.

INSPECTION E6E3D136

- 1. Ignition "ON".
- 2. Using the scan tool.
- 3. Emit intensive light toward photo sensor using sunshine, and check the output absolute voltage change.
- 4. The absolute voltage will rise with higher intensive light and reduce with lower intensive light.

When checking photo sensor, select a place where is exposed to sunshine directly.

1.2 CURRENT DATA		
برکاران خودرو در ایران	تال تعم	
HEATER WATER TEMP.SNSR	13.0 °C	
IN-CAR AIR TEMP.SNSR	31.0 °C	
AMBIENT AIR TEMP.SNS	-7.0 °C	
EVAPORATIVE SENSOR	31.0 °C	
PHOTO SNSR.	2.0 V	
AIR MIX POTENTIOMET.	10.59 %	
DIRECTION POTENT.	8.23 %	
HUMIDITY SENSOR	255 %	
FIX PART FULL HELP G		
FIX PART FULL HELP G	RPH RCRE	<u>/</u>
		E

HEATING, VENTILATION AND AIR CONDITIONING

REPLACEMENT EDECA3E9

- 1. Disconnect the negative (-) battery terminal.
- 2. Using the (-) driver, Remove the photo sensor (B) from the right part of defrost nozzle (A).



KQRE202C

3. Installation is the reverse order of removal.

A/C COMPRESSOR CONTROLS (FULL AUTO)

WATER TEMPERATURE SENSOR

COMPONENT LOCATION E772BFC3



EQRF203A

DESCRIPTION E0784670

- 1. Water temperature sensor(A) is located at the heater unit.
- 2. It detects coolant temperature. Its signal is used for cold engine lockout control. When the driver operates the heater before the engine is warmed up, the signal from sensor causes the heater control unit to reduce blower motor speed until coolant temperature reaches the threshold value.



KQRE203B

WWW.DIGITALKHODRO.COM

021-62999292

HA -41

INSPECTION E3A3363A

- 1. Ignition "OFF".
- 2. Disconnect water temperature sensor.
- 3. Using the multi-tester, Measure resistance between terminal "1" and "2" of water temperature sensor.

SPECIFICATION

Coolant temperature [°C(°F)]	Resistance between terminals 1 and 2 (K)
-10 (14)	55.27
0 (32)	32.61
20 (68)	12.48
40 (104)	5.33
60 (140)	2.50
80 (176)	1.27

- 4. If the measured resistance is not specification, substitute with a known-good water temperature sensor and check for proper operation.
- 5. If the problem is corrected, replace the water temperature sensor.



HEATING, VENTILATION AND AIR CONDITIONING

EQRF203F

- 3. Remove the under cover after loosening 2 screws.
- 4. Disconnect the connector (A) of water temperature sensor.
- 5. Pull the water temperature sensor(B) out at the heater unit with the stopper (C).



KQRE203E

6. Install in the reverse order of removal.



Take care that wire of water temperature sensor is not to be damaged.

Remove the passenger's crush pad center low cover (A) after loosening 2 screws.

E41336B3

Disconnect the negative (-) battery terminal.

REPLACEMENT

1.

WWW.DIGITALKHODRO.COM

021-62999292

A/C COMPRESSOR CONTROLS (FULL AUTO)

AMBIENT TEMPERATURE SENSOR

COMPONENT LOCATION E2E64D02



DESCRIPTION EEC2DABC

- The ambient temperature sensor is located at the front 1. of the condenser and detects ambient air temperature. It is a negative type thermistor; resistance will increase with lower temperature, and decrease with higher temperatures.
- 2. The sensor output will be used for discharge temperature control, temperature regulation door control, blower motor level control, mix mode control and in-car humidity control.

NOTE

If the ambient temperature is below 2.0°C (35.6°F), the A/C compressor will be stopped.

The compressor will be operated by manual operating.

HEATING, VENTILATION AND AIR CONDITIONING

INSPECTION EF8CCCBF

- Ignition "OFF". 1.
- 2. Disconnect ambient temperature sensor.
- 3. Check the resistance of ambient temperature sensor between terminals 1 and 2 whether it is changed by changing temperature of the ambient temperature sensor.

SPECIFICATION

Ambient temperature [°C(°F)]	Resistance between terminals 1 and 2 (K ±3%)
-20 (-4)	271.1
0 (32)	95.1
25 (77)	30.0
50 (122)	10.9
80 (176)	3.83

- 4. If the measured resistance is not specification, substitute with a known-good ambient temperature sensor heck for proper operation.
- problem is corrected, replace the ambient temire sensor.



1.	Ambient temperature sensor (+)	4.	AQS signal
2.	Ambient temperature sensor ground (-)	5.	AQS ground (-)
3.	-	6.	IG 2 (+)

6. IG 2 (+)

EQRF204C

		and ch
A G	ع • •• يجيتال خور	i. If the p peratu
	KQRE204B	

KORE204D

 $(\mathbf{\Omega})$

021-62999292

A/C COMPRESSOR CONTROLS (FULL AUTO)

REPLACEMENT E23F036F

- 1. Disconnect the negative (-) battery terminal.
- 2. Remove the front bumper (Refer to the Body group).
- 3. Remove the ambient temperature sensor(A) after loosening the mounting screws.

د بالمحمد المحمد لمحمد المحمد المحم

WWW.DIGITALKHODRO.COM

HEATING, VENTILATION AND AIR CONDITIONING

EVAPORATOR TEMPERATURE SENSOR

COMPONENT LOCATION E9F5A2B5



EQRF260A

A/C COMPRESSOR CONTROLS (FULL AUTO)

DESCRIPTION EC67D4BE

The evaporator temperature sensor will detect the evaporator core temperature and interrupt compressor relay power in order to prevent evaporator freezing by excessive cooling.

It is a negative type thermistor whose resistance is inversely proportional to temperature.

INSPECTION E9F8EF21

Ignition "OFF". 1.

SPECIFICATION

- Disconnect evaporator temperature sensor. 2.
- 3. Using the multi-tester, Measure resistance between terminal "1" and "2" of evaporator temperature sensor.



AQGE116C

- **Evaporator core** Resistance [K] temperature [°C(°F)] -10 (14) 18.31 0 (32) 11.60 7.55 10 (50) 5.04 15 (59) 30 (86) 3.44 2.40 40 (104)
- 4. If the measured resistance is not specification, substitute with a known-good evaporator temperature sensor and check for proper operation.
- 5. If the problem is corrected, replace the evaporator temperature sensor.

REPLACEMENT E11BC86D

Remove the passenger's crush pad center low cover 1. (A) after loosening 2 screws.



EQRF203F

- 2. Remove the under cover after loosening 2 screws.
- Disconnect the connector pin (A). 3.
- Remove the evaporator temperature sensor (B) by pulling it after rotating 90° in a counterclockwise direction.



KORE161B

5. Installation is the reverse order of removal.

WWW.DIGITALKHODRO.COM

021-62999292

HA -47

HEATING, VENTILATION AND AIR CONDITIONING

A.Q.S (AIR QUALITY SENSOR)

COMPONENT LOCATION E685DB67



A/C COMPRESSOR CONTROLS (FULL AUTO)

DESCRIPTION EA92AFEA

- A.Q.S is located at center support in front of the en-1. gine radiator, and detects hazardous elements in ambient air providing output signal to control.
- 2. It will detect sulfurous acid gas, carbon dioxide, carbon monoxide, hydrocarbon and allergen.

INSPECTION E9BBBDA8

- Ignition "ON". 1.
- Using the scan tool. 2.
- 3. Check the output voltage of AQS between terminals 4 and 5.

SPECIFICATION

Output signal	Intake
4 ~ 5V	Fresh
0 ~ 1V	Recirculation
	4 ~ 5V

REPLACEMENT EC4857AD

- 1. Disconnect the negative (-) battery terminal.
- 2. Remove the front bumper (Refer to the Body group).
- Remove the AQS sensor (A) after loosening the 3. mounting screws.



KQRE204E

Install in the reverse order of removal. 4.



- 1. Ambient temperature sensor (+) 4. AQS signal
- 5. AQS ground (-) 2. Ambient temperature sensor ground (-) 3. -6. IG 2 (+)

EQRF204C

HA -49

HEATING, VENTILATION AND AIR CONDITIONING

HUMIDITY SENSOR

COMPONENT LOCATION EGCFCBE0



A/C COMPRESSOR CONTROLS (FULL AUTO)

DESCRIPTION E1D4EF2E

- Humidity sensor is located at the lower crush pad and 1. detects in-car humidity for in-car humidity control.
- If ambient air temperature or in-car humidity is outside 2. certain range, it will turn on A/C to control in-car humidity preventing in car fogging.

Air conditioner operation depends on ambient temperature and humidity.

5. If the problem is corrected, replace the Humidity sensor.

REPLACEMENT EA3C7838

- 1. Disconnect the negative (-) battery terminal.
- 2. Remove the lower crush panel (A) (Refer to the Body group).
- Disconnect the connector of humidity sensor. 3.
- 4. Loosen the mounting screws (B) and then remove the humidity sensor (C).



- Ignition "ON". 1.
- 5. Installation is the reverse order of removal. Using the scan tool. 2.
- 3. Check the frequency of humidity sensor between terminals 2 and 3.

Humidity (%)	Frequency between terminals 2 and 3(Hz)
0	7351± 10%
10	7224± 10%
20	7100± 10%
30	6976 ± 10%
50	6728 ± 10%
60	6600 ± 10%
70	6468 ± 10%
80	6330 ± 10%
90	6186 ± 10%
100	6033 ± 10%

4. If the measured resistance is not specification, substitute with a known-good humidity sensor and check for proper operation.

WWW.DIGITALKHODRO.COM

HEATING, VENTILATION AND AIR CONDITIONING

HEATER

HEATER UNIT

COMPONENT LOCATION EE61D715



WWW.DIGITALKHODRO.COM

HEATER

COMPONENTS

021-62999292



- 1. Heater & Evaporator case
- 2. Heater core
- 3. Heater core cover
- 4. PTC heater (Diesel only)
- 5. Water temperature sensor
- 6. Water temperature sensor stopper
- 7. Temperature control actuator
- 8. Mode control actuator

- 9. Mode cam
- 10. Defrost door
- 11. Vent door
- 12. Floor door
- 13. Temperature control door (Single type)
- 14. Insulation
- 15. Heater & Evaporator lower case
- 16. Heater separator (Single type)
- 17. Heater separator (Dual type)
- 18. Upper case seal
- 19. Heater & Evaporator upper case
- 20. Evaporator case seal
- 21. Evaporator core
- 22. Evaporator temperature sensor
- 23. Temperature control actuator (Dual type)
- 24. Temperature control door (Dual type)

EQRF300B

WWW.DIGITALKHODRO.COM

021-62999292

HA -54

REPLACEMENT EDF1CFA1

- 1. Disconnect the negative (-) battery terminal.
- 2. Recover the refrigerant with a recovery/ recycling/ charging station.
- 3. When the engine is cool, drain the engine coolant from the radiator.
- 4. Remove the expansion valve cover after loosening the nut (A).



5. Remove the expansion valve (B) from evaporator core after loosening nuts (A). Plug or cap the lines immediately after disconnecting them to avoid moisture and dust contamination.



KQRE300D

Disconnect the inlet (C) and outlet (D) heater hoses from the heater unit.

HEATING, VENTILATION AND AIR CONDITIONING



KQRE300E

8.

9.

Engine coolant will run out when the hoses are disconnected; drain it into a clean drip pan. Be sure not to let coolant spill on electrical parts or painted surfaces. If any coolant spills, rinse it off immediately.

- 7. Remove the crush pad (Refer to the Body group).
 - Remove the cross member. (Refer to the Body group).
 - Disconnect the connectors from the temperature control actuator, the mode control actuator and the evaporator temperature sensor, then remove the mounting nut and the mounting bolts.
- 10. Remove the heater & evaporator unit after loosening the mounting bolts.



KQRE300F

WWW.DIGITALKHODRO.COM

021-62999292

021- 62 99 92 92

HA -55

HEATER

11. Remove the blower unit from heater unit after loosening fixing screws on the connected part.



KQRE300G

12. Remove the side bracket (A) and heater core (B).

- 15. Install in the reverse order of removal, and note these items :
 - If you're installing a new evaporator, add refrigerant oil.
 - Replace the O-rings with new ones at each fitting, and apply a thin coat of refrigerant oil before installing them. Be sure to use the right O-rings for R-134a to avoid leakage.
 - Immediately after using the oil, replace the cap on the container, and seal it to avoid moisture absorption.
 - Do not spill the refrigerant oil on the vehicle ; it may damage the paint ; if the refrigerant oil contacts the paint, wash it off immediately.
 - Apply sealant to the grommets.
 - Make sure that there is no air leakage.
 - Charge the system and test its performance.
 - Do not interchange the inlet and outlet heater hoses and install the hose clamps securely.
 - Refill the cooling system with engine coolant.



KQRE300H

- 13. Be careful not to bend the inlet and outlet pipes during heater core removal, and pull out the heater core.
- 14. Install the heater core in the reverse order of removal.

HEATING, VENTILATION AND AIR CONDITIONING

TEMPERATURE CONTROL ACTUATOR

COMPONENT LOCATION EC24C965



EQRF315A

HEATER

DESCRIPTION E83F0C5B

- 1. Heater unit includes mode control actuator and temperature control actuator.
- 2. Temperature control actuator is located at the heater unit. Signal from control unit adjusts position of temperature door by operating temperature switch and then temperature will be regulated by the hot/cold air ratio determined by position of temperature door.

INSPECTION E656A419

- 1. Ignition "OFF".
- 2. Disconnect the connector of temperature control actuator.
- 3. Verify that the temperature control actuator operates to the hot position when connecting 12V to the terminal 3 and grounding terminal 4.
- 4. Verify that the temperature control actuator operates to the cool position when the connections are reversed.

3

5. Sensor ground

6. Feedback signal

7. Sensor power (5V)

3

5

2

EQRF315B

7. If the problem is corrected, replace the temperature control actuator.

REPLACEMENT E1BC6FDF

- 1. Disconnect the negative (-) battery terminal.
- 2. Remove the passenger's crush pad center lower cover (A). (Refer to the Body group).

⊳ : Screw, 2	



- 3. Disconnect the connector (A) of temperature control actuator after removing the air duct.
- 4. Loosen the mounting screw and then remove the temperature control actuator (B).



KQRE315C

5. Install in the reverse order of removal.

5. Check the voltage between terminals 5 and 6.

SPECIFICATION

5

6

3. Hot position

4. Cool position

7

1.

2.

Door position	Voltage (5-6)	Error detecting
Max. cooling	0.3 ± 0.15V	Low voltage : 0.1V or less
Max. heating	4.7 ± 0.15V	High voltage : 4.9V or more

It will feedback current position of actuator to controls.

6. If the measured voltage is not within specification, substitute with a known-good temperature control actuator and check for proper operation.

WWW.DIGITALKHODRO.COM

021-62999292

HEATING, VENTILATION AND AIR CONDITIONING

MODE CONTROL ACTUATOR

COMPONENT LOCATION E85AA0FD



HEATER

DESCRIPTION E7B1EDEA

The mode control actuator is located at the heater unit.

It adjusts position of mode door by operating mode control actuator based on signal of A/C control unit. Pressing mode select switch makes the mode control actuator shift in order of vent BI/LEVEL floor mix.

INSPECTION EDF50D8B

- 1. Ignition "OFF" .
- 2. Disconnect the connector of mode control actuator.
- Verify that the mode control actuator operates to the defrost position when connecting 12V to the terminal 3 and grounding terminal 4.
- 4. Verify that the mode control actuator operates to the vent position when connecting in the reverse.



EQRF316B

5. Check the voltage between terminals 5 and 6.

Door position	Voltage (5-6)	Error detecting
Vent	0.3 ± 0.15V	Low voltage : 0.1V or less
Defrost	4.7 ± 0.15V	High voltage : 4.9V or more

It will feedback current position of actuator to controls.

- 6. If the measured voltage is not specification, substitute with a known-good mode control actuator and check for proper operation.
- 7. If the problem is corrected, replace the mode control actuator.

REPLACEMENT E0F5BF29

- 1. Disconnect the negative (-) battery terminal.
- Remove the driver's crush pad center lower cover (A). (Refer to the Body group).





EQRF316D

- Disconnect the connector (A) of mode control actuator after removing the air duct.
- Loosen the mounting screws and then remove the mode control actuator (B).



KQRE316C

5. Install in the reverse order of removal.

HEATING, VENTILATION AND AIR CONDITIONING

BLOWER CONTROLS

BLOWER UNIT

COMPONENT LOCATION E7160638



EQRF351A

BLOWER CONTROLS

HA -61

COMPONENTS



- 1. Outlet duct seal
- 2. Inlet duct case
- 3. Inlet door
- 4. Intake actuator
- 5. Air filter
- 6. Air filter housing
- 7. Blower upper case

- 8. Blower lower case
- 9. Blower seal
- 10. Blower motor
- 11. Hi-blower relay (AUTOMATIC)
- 12. Resistor (MANUAL)
- 13. Power transistor (AUTOMATIC)

EQRF351B

WWW.DIGITALKHODRO.COM

HA -62

HEATING, VENTILATION AND AIR CONDITIONING

REPLACEMENT E76B02D3

- 1. Disconnect the negative (-) battery terminal.
- 2. Remove the heater unit (Refer to page HA-52)
- 3. Disconnect the connectors from the intake actuator, hi-blower relay, the blower motor, resistor (MANUAL) and power transistor (AUTOMATIC).
- 4. Remove the self-tapping screws (A) and the blower unit (B).





5. Install in the reverse order of removal.

BLOWER CONTROLS

BLOWER MOTOR

COMPONENT LOCATION EEE1B14C



HA -64

HEATING, VENTILATION AND AIR CONDITIONING

INSPECTION E22D2C89

1. Connect the battery voltage and check the blower motor rotation.



AQIE352C

- 2. If the blower motor does not operate properly, substitute with a known-good blower motor and check for proper operation.
- 3. If the problem is corrected, replace the blower motor.

REPLACEMENT E8E2E96A

- 1. Disconnect the negative (-) battery terminal.
- 2. Remove the under cover after loosening 2 screws.
- 3. Disconnect the connector of the blower motor.
- 4. Remove the blower motor (A) after loosening the mounting screws.





KQRE352B

5. Install in the reverse order of removal.

BLOWER CONTROLS

HA -65

BLOWER RELAY

COMPONENT LOCATION ESEA1D98



EQRF353A

INSPECTION E93988FD

- 1. Disconnect the negative (-) battery terminal.
- 2. Remove the passenger compartment relay box.

Check for continuity between the terminals.

- There should be continuity between the No.9 in the I/P-K and No.15 in the I/P-A terminals when power and ground are connected to the No.16 in the I/P-D and No.13 I/P-B terminals in the passenger compartment relay box.
- 4. There should be no continuity between the No.9 in the I/P-K and No.15 in the I/P-A terminals when power is disconnected.



KTRE323A

WWW.DIGITALKHODRO.COM

021-62999292

HA -66

Terminal Position	I/P-K (9)	I/P-A (15)	I/P-D (16)	l/P-B (13)
Disconnected			0	———————————————————————————————————————
Connected	0	-0	Θ	

ETRF323B



HEATING, VENTILATION AND AIR CONDITIONING



EQRF353C

REPLACEMENT E4C53243

- 1. Disconnect the negative (-) battery terminal.
- 2. Disconnect the connector of the hi-blower relay at the below blower unit.
- Remove the hi-blower relay (A) after loosening the 3. mounting screw.

If the blower motor voltage does not operate properly, 5. substitute with a known-good blower relay and check for proper operation.

6. If the problem is corrected, replace the blower relay.

HI-BLOWER RELAY INSPECTION

- There should be continuity between the No.3 and 1. No.4 terminals when power and ground are connected to the No.1 and No.2 terminals.
- 2. There should be no continuity between the No.3 and No.4 terminals when power is disconnected.



KORE353B

WWW.DIGITALKHODRO.COM

KQRE353D

Install in the reverse order of removal. 4

KTRE323D



POWER TRANSISTOR

COMPONENT LOCATION E843EC6B



EQRF355A

HA -67

WWW.DIGITALKHODRO.COM

INSPECTION E7411DAA

- 1. Ignition "ON".
- 2. Manually operate the control switch and measure the voltage between pin 1 and 2 of blower motor.
- 3. Select the control switch to raise voltage until high relay operates.

HEATING, VENTILATION AND AIR CONDITIONING

REPLACEMENT E2D5D14D

- 1. Disconnect the negative (-) battery terminal.
- 2. Disconnect the connector (A) of the power transistor at the below blower unit.



- 4. Install in the reverse order of removal.
- 4. If the measured voltage is not within specification, substitute with a known-good power transistor and check for proper operation.

Battery (+)

Eighth speed

5. If the problem is corrected, replace the power transistor.

BLOWER CONTROLS

BLOWER RESISTOR

COMPONENT LOCATION EACOBA25



HA -70

INSPECTION EB2AD440

Resistor

1

3

2

4

- 1. Measure terminal-to-terminal resistance of the blower resistor.
- 2. If measured resistance is not within specification, the blower resistor must be replaced. (After removing the resistor)

Terminal	2	1	4	3	Basistanas (0)	
Resistance Speed ohmmeter	ΜΗ	ML	Н	LO	Resistance (Ω)	
Measurement of			0	-0	2.9 ± 5%	
resistance between		0	$-\circ$		1.5 ± 5%	
each terminal	0		—0		0.5 ± 5%	

Ω

EQRF357B

LQGE354C

HEATING, VENTILATION AND AIR CONDITIONING

REPLACEMENT EAE623A2

- 1. Disconnect the negative (-) battery terminal.
- 2. Disconnect the connector (A) of the blower resistor at the below blower unit.



KQRE357C

- 3. Remove the blower resistor after loosening the mounting screws.
- 4. Install in the reverse order of removal.

BLOWER CONTROLS

A/C AIR FILTER

DESCRIPTION E934EDB6

This has particle filter which eliminates foreign materials and odor. The particle filter includes odor filter as well as conventional dust filter to ensure comfortable interior environment.

REPLACEMENT E9686BAD

1. Remove the damper (A) from the glove box after removing side cover by using scraper. 4. Replace the air filter (B), install it after making sure of the direction of air filter.



KQRE359C



In case of driving in an air-polluted area or rugged terrain, check and replace the air filter as frequently as possible.

Replacement period : 15,000 km (9320 mile)

2. Open the glove box (A). Lower the glove box down completely by removing the glove box stopper (B) to the glove box.



KQRE359B

KQRE359A

3. Remove the filter cover (A) with pushing the knob.

WWW.DIGITALKHODRO.COM

HEATING, VENTILATION AND AIR CONDITIONING

INTAKE ACTUATOR

COMPONENT LOCATION EC31376D


BLOWER CONTROLS

DESCRIPTION EE43E001

- 1. The intake actuator is located at the blower unit.
- 2. It regulates the intake door by signal from control unit.
- 3. Pressing the intake selection switch will shift between recirculation and fresh air modes.

INSPECTION E5EBA916

- 1. Ignition "OFF".
- 2. Disconnect the connector of intake actuator.
- 3. Verify that the intake actuator actuator operates to the recirculation position when connecting 12V to the terminal 3 and grounding terminal 4.

REPLACEMENT EBB3DAC0

В

- 1. Disconnect the negative (-) battery terminal.
- 2. Remove the glove box (Refer to the Body group).
- 3. Disconnect the intake actuator connector.
- 4. Loosen the mounting screw and then remove the intake actuator (B) from the blower unit (A).



EQRE	501B

Door position	Voltage (5 - 6)	Error detecting
Recirculation	0.3 ± 0.15V	Low voltage : 0.1V or less
Fresh	4.7 ± 0.15V	High voltage : 4.9V or more

- 5. If the intake actuator does not operate properly, substitute with a known-good intake actuator and check for proper operation.
- 6. If the problem is corrected, replace the intake actuator.

HEATING, VENTILATION AND AIR CONDITIONING

BLOWER AND A/C CONTROLS (MANUAL)

CONTROL PANEL

COMPONENTS ED5CE431



WWW.DIGITALKHODRO.COM

021-62999292

BLOWER AND A/C CONTROLS (MANUAL)

CONNECTOR PIN FUNCTION

CONNECTOR	PIN	FUNCTION	
	1	IG2	
	2	Middle high	
Connector (A)	3	Middle low	
Connector (A)	4	High	
	5	Low	
	6	-	
	1	Tail lamp (+)	
	2	Battery	
	3	A/C output	
	4	Mode vent	
	5	Mode defrost	
	6	Temp actuator cool	
	7	Temp actuator warm	
	8	Intake (Fresh)	
	9	Intake (Recirculation)	
	10	Rear defogger indicator	
	11	Sensor power (+5V)	
	12/2010	Blower ON signal	
Connector (D)	13	IG2	
Connector (B)	یرک (44) خود	Tail lamp (-) : Rheostat	
	15		
	16	-	
	17	Temp actuator feedback signal	
	18	Mode actuator feedback signal	
	19	Intake actuator feedback signal	
	20	Evaporator temperature sensor	
	21	Blower ON signal to ECU	
	22	A/C select signal	
	23	Rear defogger switch	
	24	Sensor ground	
	25	-	
	26	Ground	

HA -75

HEATING, VENTILATION AND AIR CONDITIONING

CIRCUIT DIAGRAM ECFD97BE



WWW.DIGITALKHODRO.COM



HA -77

021-62999292

HA -78

REPLACEMENT E4F1F782

- 1. Disconnect the negative (-) battery terminal.
- 2. Remove the center facia panel (A) after pulling it by using a regular screwdriver (-).



HEATING, VENTILATION AND AIR CONDITIONING

Remove the blower and A/C control unit (C).

KTRE071F

4.

> : Screw, 4

3. Disconnect the connectors (B) from the center facia.

C

TI

EQRF170N

5. Install in the reverse order of removal.



WWW.DIGITALKHODRO.COM

021-62999292

BLOWER AND A/C CONTROLS (AUTOMATIC)

CONTROL PANEL

COMPONENTS EB6C4D71



WWW.DIGITALKHODRO.COM

021-62999292

HEATING, VENTILATION AND AIR CONDITIONING

CONNECTOR PIN FUNCTION

CONNECTOR	PIN	FUNCTION	CONNECTOR	PIN	FUNCTION
	1	Tail lamp (+)		1	Sensor power (5V)
	2	Battery (+)		2	AQS
	3	A/C output	ut		Ambient sensor (+)
	4	A/C select signal			Humidity sensor (+)
	5	-		5	In car sensor (+)
	6	Diagnostic tool		6	Evaporator temperature sensor (+)
	7	-		7	Water temperature sensor
	8	-		8	Speed sensor
	9	Rear defogger indicator		9	Power transistor (B)
	10	Rear defogger switch		10	Power transistor (C)
	11	-		11	Blower motor (+)
	12	IG2		12	Sensor ground
CONNECTOR	13	IG2	CONNECTOR	13	-
(A)	14	Rheostat	(B)	14	0-
	15	Hi-blower relay		15	Photo sensor (+)
	16	Temp actuator cool	••	16	·
ت محدود)	مس ت ولي	Temp actuator warm	شرکت دیج	17	In car motor
ودر ایران	18	Temp actuator feedback signal	اولىن سام	18	
0.05% 50 5	19	Mode vent		19	Blower ON signal
	20	Mode defrost		20	
	21	Mode actuator feedback signal		21	
	22	Intake fresh		22	
	23	Intake recirculation	Intake recirculation		
	24	Intake feedback signal			
	25	Ground			
	26	Ground			

CIRCUIT DIAGRAM E8CBC91D



HA -81

021-62999292

HA -82

HEATING, VENTILATION AND AIR CONDITIONING



WWW.DIGITALKHODRO.COM

021-62999292

BLOWER AND A/C CONTROLS (AUTOMATIC)





HEATING, VENTILATION AND AIR CONDITIONING

SELF-DIAGNOSIS E3E3EBBC

SELF-DIAGNOSIS PROCESS

The F.A.T.C. module self test feature will detect electrical malfunction and provide error codes for system components with suspected failures.



NOTE

Turn off the A/C system during the DTC check.

HOW TO READ SELF-DIAGNOSTIC CODE

1. After the display panel flickers three times every 0.5 second, the corresponding fault code flickers on the setup temperature display panel every 0.5 second and will show two figures.

2. Fault code

Fault	code	Fail description	
Control unit	Scan tool (DTC)		
00	-	Normal	
11	B1234	In-car temperature sensor open (High)	
12	B1233	In-car temperature sensor short (Low)	
13	B1238	Ambient temperature sensor open (High)	
14	B1237	Ambient temperature sensor short (Low)	
15	B1202	Water temperature sensor open (High)	
16	B1203	Water temperature sensor short (Low)	
17	B1242	Evaporator temperature sensor open (High)	
18	B1241	Evaporator temperature sensor short (Low)	
19	B1245	Air mix potentiometer open (Low) - Driver	
19	B1246	Air mix potentiometer short (High) - Driver	
20	B2406	Air mix motor failure (Driver)	
21	B1249	Direction potentiometer open (Low) - Driver	
21	B1250	Direction potentiometer short (High) - Driver	
22	B2409	Direction control motor failure (Driver)	
يت ₂₃ دود)	B1200	Humidity sensor open (High)	
24	B1201	Humidity sensor short (Low)	
رو در 25 ان	B1208	Intake potentiometer open (Low)	
25	B1209	Intake potentiometer short (High)	
26	B2408	Intake motor	
27	B1257	AQS sensor open (High)	
28	B1258	AQS sensor short (Low)	
31	B1259	AQS sensor failure	

HA -85

021-62999292

HA -86

3. Fault code display

HEATING, VENTILATION AND AIR CONDITIONING

1) Continuance operation



2) Step operation



8)

، دیجیتال خودرو سامانه (مسئولیت محدود)

- If a fault code is displayed during the DTC check, Inspect a malfunction cause by referring to the DTC code.
- 5. Fail safe
 - 1) In-car temperature sensor: Control with the value of 25 (77)
 - 2) Ambient temperature sensor: Control with the value of 20 (67)
 - 3) Evaporator temperature sensor: Control with the value of -2 (28.4)
 - 4) Humidity sensor: Control with the value of 10%
 - 5) Temperature sensor : Control with the value of -2 (28.4)
 - 6) Temperature control actuator (Air mix potentiometer):
 If temperature setting 17 -24.5 , fix at maximum cooling position.
 If temperature setting 25 -32 , fix at maximum heating position.
 - Mode control actuator (Direction potentiometer): Fix vent position, while selecting vent mode.
 Fix defrost position, while selecting all except vent mode.

- Intake control actuator : Fix fresh position, while selecting fresh mode. Fix recirculation position, while selecting recirculation mode.
- 9) AQS sensor : AQS operation OFF.
 - Intake position : The position before selecting AQS switch.

WWW.DIGITALKHODRO.COM

021-62999292

BLOWER AND A/C CONTROLS (AUTOMATIC)

REPLACEMENT E7F5A3FD

- 1. Disconnect the negative (-) battery terminal.
- 2. Remove the center facia panel (A) after pulling it by using a regular screw driver(-).



4. Remove the blower And A/C control unit (A).



KTRE071F

3. Disconnect the connectors(B) from the center facia.

EQRF170N

5. Install in the reverse order of removal.



KSRE170L

HA -87

HEATING, VENTILATION AND AIR CONDITIONING

DTC B1200 HUMIDITY SENSOR OPEN (HIGH)

COMPONENT LOCATION E1A6A05F



GENERAL DESCRIPTION EC4DA0E4

Humidity sensor located at crush pad, detects in-car humidity for in-car humidity control. If ambient air temperature or in-car humidity is outside certain range, it will turn on A/C to control in-car humidity for preventing in-car fogging. Air conditioner operation depends on ambient temperature and humidity.

DTC DESCRIPTION E678D738 LOLE ULIDEU ALLOLU ULIDE

The A/C controller sets DTC B1200 if there is an open circuit in humidity sensor signal harness or the measured frequency value of sensor is more than threshold value(about 7,100Hz)

DTC DETECTING CONDITION E6BBDF5A

Item	Detecting Condition	Possible cause
DTC Strategy	Frequency check	Open Circuit in signal harness
Threshold value	• > 7,100 Hz	 Faulty Humidity Sensor Faulty A/C control unit
Detecting time	• 0.01 sec	
FAIL SAFE	Control with the value of 10%	

BLOWER AND A/C CONTROLS (AUTOMATIC)

SPECIFICATION EEBB2DAD

Relative humidity(%)	Frequency(Hz)	Relative humidity(%)	Frequency(Hz)
10	7,224	55	6,664
15	7,162	60	6,600
20	7,100	65	6,534
25	7,038	70	6,468
30	6,976	75	6,399
35	6,915	80	6,330
40	6,853	85	6,258
45	6,791	90	6,186
50	6,728	95	6,110

MONITOR SCANTOOL DATA E0AFCDCB

- 1. Connect scantool to data link connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "Humidity Sensor" Parameter on the Scantool while drying the humidity sensor with a hair drier or heat gun adjusted to a low heat setting.



Fig 1 : The current data in abnormal state. Fig 2 : DTC B1200.

LQIE510B

HEATING, VENTILATION AND AIR CONDITIONING

4. Are the DTC B1200 present and is parameter of "Humidity Sensor" fixed? Parameter of "Humidity Sensor" will be fixed at 10%, if there is any fault in Humidity Sensor.

YES

Go to "Inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION EA71DCFA

- 1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?



NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION EAF61F7E

- 1. Check for open in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect Humidity Sensor.

3) Measure resistance between terminal "3" of Humidity Sensor and terminal "4" of A/C Control Unit.

Specification : Approx. 0



- 4. In-car sensor temp. signal
- 5. Sensor power (5V)
- 6. Motor(+)

EQRE510D

WWW.DIGITALKHODRO.COM

8 7 6 5

9

20 19

11 10

22 21

3 2

*

12

M21-2

4

15

*

17

*

021-62999292

HA -91

HA -92

HEATING, VENTILATION AND AIR CONDITIONING

4) Is the measured resistance within specifications?



Go to "Component Inspection " procedure.



Check for open in ground harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION EGASFEDC

- 1. Check Humidity Sensor.
 - 1) Engine "ON"
 - 2) Connect Humidity Sensor.
 - 3) Measure Frequency between terminal "3" and "2" of Humidity sensor while increasing humidity.

Specification : Refer the specifications in fig 5.



EQRE510E



Fig 3 : Signal waveform of Humidity sensor.

Fig 4 : Frequency of Humidity sensor Measured by scantool.

LQIE510F

WWW.DIGITALKHODRO.COM

021-62999292

BLOWER AND A/C CONTROLS (AUTOMATIC)



- 2. Check A/C Control Unit
 - 1) Engine "ON"
 - 2) Disconnect Humidity Sensor.

021-62999292

HA -94

HEATING, VENTILATION AND AIR CONDITIONING

3) Measure voltage value between terminal "4" of A/C control unit and chassis ground.

Specification : 5V



4. Humidity sensor signal

EQRE510G

4) Is the measured voltage within specification?



VERIFICATION OF VEHICLE REPAIR ED15C0E6

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
- 2. Operate the vehicle and monitor the DTC on the scantool.
- 3. Are any DTCs present?

YES

Go to the applicable troubleshooting procedure.

NO

System is performing to specification at this time.

021-62999292

BLOWER AND A/C CONTROLS (AUTOMATIC)

HA -95

DTC B1201 HUMIDITY SENSOR SHORT (LOW)

COMPONENT LOCATION EEIFABED



Refer to DTC B1200.

DTC DESCRIPTION ED021BD7

The A/C controller sets DTC B1201 if there is a short circuit in humidity sensor signal harness or the measured frequency value of sensor is less than threshold value(about 6,186Hz)

DTC DETECTING CONDITION EA13B70D

Item	Detecting Condition	Possible cause
DTC Strategy	Frequency check	Open Circuit in power harness
Threshold value	• < 6,186 Hz	Short Circuit in signal harnesFaulty Humidity Sensor
Detecting time	• 10msec	 Faulty A/C control unit
FAIL SAFE	Control with the value of 10%	

SPECIFICATION EACEDEFA

Refer to DTC B1200.

HA -96

HEATING, VENTILATION AND AIR CONDITIONING

MONITOR SCANTOOL DATA EC00801D

- 1. Connect scantool to data link connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "Humidity Sensor" Parameter on the Scantool while drying the humidity sensor with a hair drier or heat gun adjusted to a low heat setting.



Parameter of "Humidity Sensor" will be fixed at 10%, if there is any fault in Humidity Sensor.

YES

Go to "Inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION EFE57B49

Refer to DTC B1200.

SIGNAL CIRCUIT INSPECTION E47D8DB5

- 1. Check for short to ground in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect Humidity Sensor.
 - 3) Measure resistance between terminal "3" of Humidity Sensor and chassis ground.

Specification : Approx.



Check for short to ground in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

HEATING, VENTILATION AND AIR CONDITIONING

POWER SUPPLY CIRCUIT INSPECTION ECA7349E

- 1. Check for open in power harness.
 - 1) Ignition "ON"
 - 2) Disconnect Humidity Sensor.
 - 3) Measure voltage value between terminal "5" of Humidity Sensor and chassis ground.

Specification: 5V



Check for open in power harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION EA86913D

Refer to DTC B1200.

VERIFICATION OF VEHICLE REPAIR E009FE5D

Refer to DTC B1200.

<u>HA</u> -99

DTC B1202 WATER TEMPERATURE SENSOR OPEN (HIGH)

COMPONENT LOCATION E7200D89



GENERAL DESCRIPTION

A water temp. sensor located at heater unit, detects coolant temperature. Its signal is used for cold engine lockout control. When the driver operates the heater before the engine is warmed up, the signal from sensor causes the heater control unit to reduce blower motor speed until coolant temperature reaches the threshold value.

DTC DESCRIPTION E93BE7A5 LEADER IN DESCRIPTION

E547C1C5

The A/C controller sets DTC B1202 if there is an open circuit in water temp. sensor signal harness or the measured resistance value of the sensor is more than the threshold value(about 176.3k)

DTC DETECTING CONDITION EB7BE1EE

Item	Detecting Condition	Possible cause	
DTC Strategy	Resistance check	Open Circuit in harness	
Threshold value	• > 176.3 k	Faulty water temp. SensorFaulty A/C control unit	
Detecting time	• 0.3 sec		
FAIL SAFE	 Control with the value of -2°C(28.4°F) 		

SPECIFICATION EABF5ADA

Temperature[°C(°F)]	Resistance(k)	Temperature[°C(°F)]	Resistance(k)
-30(-22)	176.3	25(77)	10
-15(5)	73.6	35(95)	6.5
0(32)	32.9	60(140)	2.5
15(59)	15.8	80(176)	1.2

WWW.DIGITALKHODRO.COM

021-62999292

HA -100

HEATING, VENTILATION AND AIR CONDITIONING

MONITOR SCANTOOL DATA EEAE6153

- 1. Connect scantool to data link connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "WATER TEMP. SENSOR" Parameter on the Scantool.



 Are the DTC B1202 present and is parameter of "WATER TEMP. SENSOR" fixed? Parameter of "WATER TEMP. SENSOR" will be fixed at -2 (28.4°F), if there is any fault in WATER TEMP. SENSOR.

YES

Go to "Inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION EC6C991B

- Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure.



1)

Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION E17AE5CE

1. Check for open in harness.

Ignition "OFF"

- 2) Disconnect water temp. sensor.
- 3) Measure resistance between terminal "1" of water temp. sensor and terminal "7" of A/C Control Unit.

Specification : Approx. 0



- 1. Water temp. sensor signal
- 2. Sensor ground

EQRE512C

4) Is the measured resistance within specifications?

YES

Go to "Ground circuit Inspection " procedure.

NO

Check for open in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

WWW.DIGITALKHODRO.COM

021-62999292

HA -102

HEATING, VENTILATION AND AIR CONDITIONING

GROUND CIRCUIT INSPECTION E708CBA1

- 1. Check for open in ground harness.
 - 1) Ignition "OFF"
 - 2) Disconnect water temp. sensor.
 - 3) Measure resistance between terminal "2" of water temp. sensor and chassis ground.

Specification : Approx. 0 1. Water temp. sensor signal 2. Sensor ground 4) Is the measured resistance within specifications? YES Go to "Component Inspection " procedure.

Check for open in ground harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION EF405FC8

- 1. Check water temp. sensor.
 - 1) Ignition "OFF"
 - 2) Disconnect water temp. sensor.

BLOWER AND A/C CONTROLS (AUTOMATIC)

3) Measure resistance between terminal "1" and "2" of water temp. sensor.

Specification : Refer the specifications in fig 3.



Fig 3) Specifications : Resistance value of water temp. sensor as a function of temperature.

LQIE512G

4) Is the measured resistance within specifications in fig 3)? (tolerance limits \pm 3%)

YES

Go to "Check A/C Control Unit" procedure.



Substitute with a known-good water temp. sensor and check for proper operation. If the problem is corrected, replace water temp. sensor and then go to "Verification of Vehicle Repair" procedure.

021-62999292

HA -103

WWW.DIGITALKHODRO.COM

HA -104

HEATING, VENTILATION AND AIR CONDITIONING

- 2. Check A/C Control Unit
 - 1) Engine "ON"
 - 2) Disconnect water temp. sensor.
 - 3) Measure Voltage between terminal "7" of A/C Control Unit and chassis ground.

Specification : Approx. 5V



NU

Substitute with a known-good A/C Control Unit and check for proper operation. If the problem is corrected, replace A/C Control Unit and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR E4AC2289

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
- 2. Operate the vehicle and monitor the DTC on the scantool.
- 3. Are any DTCs present?



Go to the applicable troubleshooting procedure.

NO

System is performing to specification at this time.

<u>HA -</u>105

DTC B1203 WATER TEMPERATURE SENSOR SHORT (LOW)

COMPONENT LOCATION EASTACE



DTC DESCRIPTION E04DCBCD

The A/C controller sets DTC B1203 if there is a short circuit in water temp. sensor signal harness or the measured resistance value of sensor is less than threshold value(about 1.2k)

DTC DETECTING CONDITION E9F4635F

Item	Detecting Condition	Possible cause	
DTC Strategy	Resistance check	Short circuit in harness	
Threshold value	• < 1.2 k	Faulty water temp. SensorFaulty A/C control unit	
Detecting time	• 0.3 sec		
FAIL SAFE	 Control with the value of -2°C(28.4°F) 		

SPECIFICATION E60633EE

Refer to DTC B1202.

HA -106

HEATING, VENTILATION AND AIR CONDITIONING

MONITOR SCANTOOL DATA E49E8DF3

- 1. Connect scantool to data link connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "WATER TEMP. SENSOR" Parameter on the Scantool.



 Are the DTC B1203 present and is parameter of "WATER TEMP. SENSOR" fixed? Parameter of "WATER TEMP. SENSOR" will be fixed at -2 (28.4°F), if there is any fault in WATER TEMP. SENSOR.

YES

Go to "Inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION E4FFBD3C

Refer to DTC B1202.

SIGNAL CIRCUIT INSPECTION E9012BEF

- 1. Check for short to ground in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect water temp. sensor.
 - 3) Measure resistance between terminal "1" of water temp. sensor and chassis ground.

Specification : Approx.



Check for short to ground in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION ECTACC13

Refer to DTC B1202.

VERIFICATION OF VEHICLE REPAIR EE5647BB

Refer to DTC B1202.

<u>HA -1</u>07

HEATING, VENTILATION AND AIR CONDITIONING

DTC B1208 INTAKE POTENTIOMETER OPEN (LOW)

COMPONENT LOCATION ECBD83EA



Intake door located at heater unit controls the inlet of car. When driver operates the intake switch, A/C controller recirculationeives mode signal from intake switch and operates intake door actuator to turn intake door to intended position. (with fresh mode signal, intake door is closed and with fresh mode signal, intake door is opened).

DTC DESCRIPTION EA22AC4B

The A/C controller sets DTC B1208 if there is an open circuit or poor connection in the intake potentiometer.

DTC DETECTING CONDITION EFEC790E

Item	Detecting Condition	Possible cause
DTC Strategy	Voltage check	 Poor connection of connected part Open circuit in harness Short circuit in harness Faulty driver intake potentiometer
Threshold value	• < 0.1V	
Detecting time	• 0.3 sec	
FAIL SAFE	 If temperature setting 17~24.5°C(63~76°F) fix at max. cooling position. Fix at fresh 	

SPECIFICATION EB6B27DB

Voltage value of Intake potentiometer as a function of position of Intake door

Door position	Voltage	Threshold value
Fresh	0.3±0.15V	Voltage value < 0.08V
Recirculation	4.7±0.15V	Voltage value > 4.9V

WWW.DIGITALKHODRO.COM

021-62999292
MONITOR SCANTOOL DATA E2432EFB

- 1. Connect scantool to Data Link Connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "Intake Potentiometer" Parameter on the Scantool while operating intake switch.

	1.2 CURRENT DATA			1.1 DIAGNOSTIC TROUBLE COD)ES]
	HEATER WATER TEMP.SNSR	14.0 °C		B1208 INTAKE P LOW INPUT		
	IN-CAR TEMP.SENSOR	12.0 °C				
	AMBIENT AIR TEMP.SNS	12.0 °C				
	EVAPORATIVE SENSOR	13.0 °C				
	DRIVER PHOTO SENSOR	0.00 V				
	AIR MIX POPENTIO.(DR.)	84.69 %				
	DIRECTION POTENIO.DR.	51.76 %				
	PASSENGER PHOTO SENSOR	255				
	INTAKE SENSOR	6.3 %		NUMBER OF DTC : 1 ITEMS		
			▼			
	FIX SCRN FULL PART GF	RPH HELP	'	PART ERAS	HELP	
Fig	g 1			Fig 2		
Fig	1 : The current data in abnormal state					
	2 : DTC B12 <mark>0</mark> 8.					
	ر وسامانه (مسئولیت ه	تال خود				EQRE521

4. Are the DTC B1208 present and is parameter of "Intake Potentiometer" fixed? Parameter of "Intake Potentiometer" will be fixed at 100%(or any value above 90%), or 0% (or any value below 10%), if there is any fault in Intake potentiometer.

YES

Go to "Inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

HEATING, VENTILATION AND AIR CONDITIONING

TERMINAL AND CONNECTOR INSPECTION E322CCB8

- 1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION EE0773F6

- 1. Check for open in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect Intake potentiometer.

3) Measure resistance between terminal "6" of Intake Potentiometer and terminal "24" of A/C control unit.

Specification : Approx. 0



4) Is the measured resistance within specifications?

YES

Go to "Check for short to ground in harness" procedure.

NO

Check for open in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

WWW.DIGITALKHODRO.COM

EORE527D

BLOWER AND A/C CONTROLS (AUTOMATIC)

- 2. Check for short to ground in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect Intake potentiometer.
 - 3) Measure resistance between terminal "6" of Intake Potentiometer and chassis ground.

Specification : Approx.



Check for short to ground in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

HEATING, VENTILATION AND AIR CONDITIONING

POWER SUPPLY CIRCUIT INSPECTION E78A9AED

- 1. Check for short or open in harness.
 - 1) Ignition "ON"
 - 2) Connect Intake Potentiometer.
 - 3) Measure voltage between terminal "7" of Intake Potentiometer and chassis ground.

Specification : Approx. 5V



Check for short or open in power harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION EOCD7396

- 1. Check actuator motor.
 - 1) Ignition "OFF"
 - 2) Disconnect Intake Potentiometer.
 - 3) Verify that the temperature actuator operates to the fresh position when connecting 12V to the terminal "3" and grounding terminal "4".
 - 4) Verify that the temperature actuator operates to the recirculation position when the connections are reversed.



Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

- 2. Check potentiometer
 - 1) Ignition "ON"
 - 2) Connect Intake potentiometer.

HEATING, VENTILATION AND AIR CONDITIONING

3) Measure voltage between terminal "5" and "6" of Intake potentiometer while operating Intake switch.

Specification : Refer to the specifications



3. Motor

- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQRE527I

Door position	Voltage (5-6)	Error detecting
Fresh	0.3 ± 0.15V	Low voltage : 0.08V or less
Recirculation	4.7 ± 0.15V	High voltage : 4.9V or more

Specifications : Voltage value of Intake potentiometer as a function of position of Intake.

⁴⁾ Is the measured voltage within specifications?



Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR ED73C5A2

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
- 2. Operate the vehicle and monitor the DTC on the scantool.
- 3. Are any DTCs present?



Go to the applicable troubleshooting procedure.

NO

System is performing to specification at this time.

WWW.DIGITALKHODRO.COM

HA -115

DTC B1209 INTAKE POTENTIOMETER SHORT (HIGH)

COMPONENT LOCATION E38A4D83



DTC DETECTING CONDITION E0D2C2D0

Item	Detecting Condition	Possible cause
DTC Strategy	Voltage check	 Short circuit in harness Faulty Intake potentiometer Open circuit in harness
Threshold value	• > 4.9V	
Detecting time	• 0.3 sec	
FAIL SAFE	Fix at fresh	

SPECIFICATION EFC13106

Refer to DTC B1208.

HA -116

HEATING, VENTILATION AND AIR CONDITIONING

MONITOR SCANTOOL DATA E4D9B27C

- 1. Connect scantool to Data Link Connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "Intake Potentiometer" Parameter on the Scantool while operating Intake switch.

1.2 CURRENT DATA			1.1 DIAGNOSTIC TROUBLE CODE	S
HEATER WATER TEMP.SNSR	14.0 °C		B1209 INTAKE P HIGH INPUT	
IN-CAR TEMP.SENSOR	12.0 °C			
AMBIENT AIR TEMP.SNS	12.0 °C			
EVAPORATIVE SENSOR	13.0 °C			
DRIVER PHOTO SENSOR	0.00 V			
AIR MIX POPENTIO.(DR.)	84.69 %			
DIRECTION POTENIO.DR.	51.76 %			
PASSENGER PHOTO SENSOR	255			
INTAKE SENSOR	100.0 %		NUMBER OF DTC : 1 ITEMS	
		▼		
FIX SCRN FULL PART GF	RPH HELF)	PART ERAS	HELP
Fig 1			Fig 2	
Fig 1 : The current data in abnormal state				
Fig 2 : DTC B1209.				
و سامانه (مسئولیت محد				EQRE522A

Are the DTC B1209 present and is parameter of "Intake potentiometer" fixed?
 Parameter of "Intake potentiometer" will be fixed at 100% (or any value above 90%), or 0% (or any value below 10%), if there is any fault in Intake potentiometer.

YES

Go to "Inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION ED7A063F

Refer to DTC B1208.

BLOWER AND A/C CONTROLS (AUTOMATIC)

SIGNAL CIRCUIT INSPECTION E86C2E4B

- 1. Check for short in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect Intake potentiometer.
 - 3) Measure resistance between terminal "6" and "7" of Intake potentiometer.

Specification : Approx.



Check for short to power harness in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

HEATING, VENTILATION AND AIR CONDITIONING

GROUND CIRCUIT INSPECTION E2C3FCCF

- 1. Check for open in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect Intake Potentiometer.
 - 3) Measure resistance between terminal "5" of Intake Potentiometer and chassis ground.

Specification : Approx. 0 M37 3. Motor 7 3 6 4 4. Motor 5. Potentiometer ground 6. Potentiometer signal 7. Sensor reference voltage(+5V) EQRE527G Is the measured resistance within specifications? YES Go to "Component Inspection" procedure. NO

Check for open in ground harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION EAB6908C

Refer to DTC B1208.

VERIFICATION OF VEHICLE REPAIR E4363609

Refer to DTC B1208.

<u>HA</u> -119

DTC B1233 IN-CAR TEMPERATURE SENSOR SHORT (LOW)

COMPONENT LOCATION EAC6BF8C



GENERAL DESCRIPTION E7D85F05

The incar temperature sensor located at crush pad, control unit contains a thermistor which measures the temperature of the inside. The signal, decided by the resistance value which changes in accordance with perceived inside temperature, is delivered to heater control unit and according to this signal, the control unit regulates incar temperature to intended value.

DTC DESCRIPTION E55AF8E5

The A/C controller sets DTC B1233 if there is a short circuit in incar temp. sensor signal harness or the measured resistance value of sensor is less than threshold value(about 7.46k)

DTC DETECTING CONDITION EACD9A64

Item	Detecting Condition	Possible cause
DTC Strategy	Resistance check	Short circuit in harness
Threshold value	• < 7.46 k	 Faulty incar temp. Sensor Faulty A/C control unit
Detecting time	• 0.3 sec	
FAIL SAFE	 Control with the value of 25°C(77°F) 	

SPECIFICATION E28AFD61

Temperature[°C(°F)]	Resistance(k)	Temperature[°C(°F)]	Resistance(k)
-30(-22)	509.57	25(77)	30
-15(5)	216.07	35(95)	15.59
0(32)	97.71	50(122)	10.81
15(59)	47.13	60(140)	7.46

WWW.DIGITALKHODRO.COM

021-62999292

HA -120

HEATING, VENTILATION AND AIR CONDITIONING

MONITOR SCANTOOL DATA E7B28007

- 1. Connect scantool to data link connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "INCAR TEMP. SENSOR" Parameter on the Scantool.



 Are the DTC B1233 present and is parameter of "INCAR TEMP. SENSOR" fixed? Parameter of "INCAR TEMP. SENSOR" will be fixed at 25 (77), if there is any fault in INCAR TEMP. SENSOR.

YES

Go to "Inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION EDFAG9DA

- 1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

BLOWER AND A/C CONTROLS (AUTOMATIC)

3. Has a problem been found?



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION EDDD5E2B

- 1. Check for short to ground in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect incar sensor.
 - 3) Measure resistance between terminal "4" of incar sensor and chassis ground.



EQRE514B

4) Is the measured resistance within specifications?

YES

Go to "Component Inspection" procedure.

NO

Check for short to ground in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION E1F67BD7

- 1. Check incar temp. sensor.
 - 1) Ignition "OFF"
 - 2) Disconnect incar sensor.

WWW.DIGITALKHODRO.COM

021-62999292

HA -122

HEATING, VENTILATION AND AIR CONDITIONING

3) Measure resistance between terminal "4" and "2" of incar sensor.

Specification : Refer the specifications in fig 3.



Fig 3) Specifications : Resistance value of incar temp. sensor as a function of temperature.

EQRE514G

4) Is the measured resistance within specifications in fig3? (tolerance limits \pm 3%)

YES

Go to "Check A/C Control Unit" procedure.



Substitute with a known-good incar sensor and check for proper operation. If the problem is corrected, replace incar sensor and then go to "Verification of Vehicle Repair" procedure.

BLOWER AND A/C CONTROLS (AUTOMATIC)

- 2. Check A/C Control Unit
 - 1) Engine "ON"
 - 2) Disconnect incar sensor.
 - 3) Measure Voltage between terminal "5" of A/C Control Unit and chassis ground.

Specification : Approx. 5V



Substitute with a known-good A/C Control Unit and check for proper operation. If the problem is corrected, replace A/C Control Unit and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR EC230316

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
- 2. Operate the vehicle and monitor the DTC on the scantool.
- 3. Are any DTCs present?



Go to the applicable troubleshooting procedure.



System is performing to specification at this time.

021-62999292

HEATING, VENTILATION AND AIR CONDITIONING

DTC B1234 IN-CAR TEMPERATURE SENSOR OPEN (HIGH)

COMPONENT LOCATION ED2CFCE8



Refer to DTC B1233.

DTC DESCRIPTION E4A3E4FA

The A/C controller sets DTC B1234 if there is an open circuit in incar temp. sensor signal harness or the measured resistance value of sensor is more than threshold value(about 509.57k)

DTC DETECTING CONDITION E1AD2DD3

Item	Detecting Condition	Possible cause
DTC Strategy	Resistance check	Open Circuit in harness
Threshold value	• > 509.57 k	Faulty incar temp. SensorFaulty A/C control unit
Detecting time	• 0.3 sec	-
FAIL SAFE	 Control with the value of 25°C(77°F) 	

SPECIFICATION EB94B45F

Refer to DTC B1233.

MONITOR SCANTOOL DATA E3AA8147

- 1. Connect scantool to data link connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "INCAR TEMP. SENSOR" Parameter on the Scantool.



4. Are the DTC B1234 present and is parameter of "INCAR TEMP. SENSOR" fixed? Parameter of "INCAR TEMP. SENSOR" will be fixed at 25 (77), if there is any fault in INCAR TEMP. SENSOR.

YES

Go to "Inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION EBDBDEB1

Refer to DTC B1233.

HA -125

HEATING, VENTILATION AND AIR CONDITIONING

SIGNAL CIRCUIT INSPECTION E52FAD51

- 1. Check for open in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect incar temp. sensor.
 - 3) Measure resistance between terminal "4" of incar temp. sensor and terminal "5" of A/C Control Unit..

Specification : Approx. 0



Check for open in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

BLOWER AND A/C CONTROLS (AUTOMATIC)

GROUND CIRCUIT INSPECTION E04C40CB

- 1. Check for open in ground harness.
 - 1) Ignition "OFF"
 - 2) Disconnect incar temp. sensor.
 - 3) Measure resistance between terminal "2" of incar temp. sensor and terminal "12" of A/C Control Unit.

Specification : Approx. 0



Check for open in ground harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION E3D83299

Refer to DTC B1233.

VERIFICATION OF VEHICLE REPAIR EB3E7FCD

Refer to DTC B1233.

HEATING, VENTILATION AND AIR CONDITIONING

DTC B1237 AMBIENT TEMPERATURE SENSOR SHORT (LOW)

COMPONENT LOCATION E7FAC5A7



GENERAL DESCRIPTION EB112197

The ambient temperature senor located at the center stay of the condenser, detects ambient air temperature. It is a negative type thermistor whose resistance is inversely proportional to temperature. Its output is used for discharge temperature sensor, sensor fail-safe, temperature regulation door lock, blower motor level control, mix mode control and in-car humidity control.

DTC DESCRIPTION ED52FE7D

The A/C controller sets DTC B1237 if there is a short circuit in ambient temp. sensor signal harness or the measured resistance value of sensor is less than threshold value(about 7.48k)

DTC DETECTING CONDITION E593BC65

Item	Detecting Condition	Possible cause	
DTC Strategy • Resistance check		Short circuit in harness	
Threshold value	• < 7.48k	Faulty ambient temp. SensorFaulty A/C control unit	
Detecting time	• 0.3 sec		
FAIL SAFE	 Control with the value of 20°C(68°F) 		

SPECIFICATION E6F6E4ED

Temperature[°C(°F)]	Resistance(k)	Temperature[°C(°F)]	Resistance(k)
-30(-22)	527.99	25(77)	30
-15(5)	218.21	35(95)	19.6
0(32)	97.83	50(122)	10.82
15(59)	47.12	60(140)	7.48

WWW.DIGITALKHODRO.COM

021-62999292

MONITOR SCANTOOL DATA E3443894

- 1. Connect scantool to data link connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "AMBIENT TEMP. SENSOR" Parameter on the Scantool. Parameter of "AMBIENT TEMP. SENSOR" will be fixed at 20°C, if there is any fault in AMBIENT TEMP. SENSOR.



YES

Go to "Inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION E1AF6B6A

- Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

021-62999292

HA -130

HEATING, VENTILATION AND AIR CONDITIONING

3. Has a problem been found?

YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION EFO9EAD1

- 1. Check for short to ground in harness.
 - 1) Ignition "OFF"

Specification : Approx.

- 2) Disconnect ambient temp. sensor.
- 3) Measure resistance between terminal "1" of ambient temp. sensor and chassis ground.

E72 1. Ambient temp. sensor signal(+) 2. Ambient temp. sensor ground 4. AQS signal input 5. AQS ground 6. AQS power

EQRE516C

4) Is the measured resistance within specifications?

YES

Go to "Component Inspection" procedure.

NO

Check for short to ground in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION E4F6BB93

- 1. Check Ambient temp. sensor.
 - 1) Ignition "OFF"
 - 2) Disconnect ambient temp. sensor.

WWW.DIGITALKHODRO.COM

BLOWER AND A/C CONTROLS (AUTOMATIC)

3) Measure resistance between terminal "1" and "2" of ambient temp. sensor.

Specification : Refer the specifications in fig 3.



Fig 3) Specifications : Resistance value of ambient temp. sensor as a function of temperature.

EQRE516F

4) Is the measured resistance within specifications in fig3? (tolerance limits \pm 3%)

YES

Go to "Check A/C Control Unit" procedure.

NO

Substitute with a known-good ambient temp. sensor and check for proper operation. If the problem is corrected, replace ambient temp. sensor and then go to "Verification of Vehicle Repair" procedure.

021-62999292

021- 62 99 92 92

WWW.DIGITALKHODRO.COM

HA -131

HA -132

HEATING, VENTILATION AND AIR CONDITIONING

- 2. Check A/C Control Unit
 - 1) Engine "ON"
 - 2) Disconnect ambient temp. sensor.
 - 3) Measure voltage between terminal "3" of A/C Control Unit and chassis ground.

Specification : Approx. 5V



NU

Substitute with a known-good A/C Control Unit and check for proper operation. If the problem is corrected, replace A/C Control Unit and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR EDB3124D

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
- 2. Operate the vehicle and monitor the DTC on the scantool.
- 3. Are any DTCs present?



Go to the applicable troubleshooting procedure.

NO

System is performing to specification at this time.

<u>HA -</u>133

DTC B1238 AMBIENT TEMPERATURE SENSOR OPEN (HIGH)

COMPONENT LOCATION E47E41BA



DTC DESCRIPTION E784EC44

The A/C controller sets DTC B1238 if there is an open circuit in ambient temp. sensor signal harness or the measured resistance value of sensor is more than threshold value(about 527k)

DTC DETECTING CONDITION E257EDA9

Item	Detecting Condition	Possible cause
DTC Strategy	Resistance check	 Open Circuit in harness Faulty ambient temp. Sensor
Threshold value	reshold value • > 527k	
Detecting time	• 0.3 sec	
FAIL SAFE	 Control with the value of 20°C(67°F) 	

SPECIFICATION EE2EBEFC

Refer to DTC B1237.

HEATING, VENTILATION AND AIR CONDITIONING

MONITOR SCANTOOL DATA EC27CEAB

- 1. Connect scantool to data link connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "AMBIENT TEMP. SENSOR" Parameter on the Scantool.

Parameter of "AMBIENT TEMP. SENSOR" will be fixed at 20 (67), if there is any fault in AMBIENT TEMP. SENSOR.

1.2 CURRENT DATA		1	1.1 DIAGNOSTIC TROUBLE CODES	
HEATER WATER TEMP. SNSR	17.0 °C		B1238 AMBIENT TEMP. SNSR HIGH	
IN-CAR TEMP. SENSOR	12.0 °C			
AMBIENT AIR TEMP. SNS	20.0 °C			
EVAPORATIVE SENSOR	13.0 °C			
DRIVER PHOTO SENSOR	0.00 V			
AIR MIX POPENTIO. (DR.)	91.75 %			
DIRECTION POTENIO. DR.	90.18 %			
PASSENGER PHOTO SENSOR	255			
			NUMBER OF DTC : 1 ITEMS	
Fig 1	RPH HELP	2	PART ERAS HELP Fig 2	
g 1 : The current data in abnormal state g 2 : DTC B1238.			مرکت دیج	
				E517A

Are the DTC B1238 present and is parameter of "AMBIENT TEMP. SENSOR" fixed?

YES

4.

Go to "Inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION E3CD9EEE

Refer to DTC B1237.

BLOWER AND A/C CONTROLS (AUTOMATIC)

SIGNAL CIRCUIT INSPECTION EB7BE386

- 1. Check for open in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect ambient temp. sensor.
 - 3) Measure resistance between terminal "1" of ambient temp. sensor and terminal "3" of A/C Control Unit.

Specification : Approx. 0



Check for open in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

HEATING, VENTILATION AND AIR CONDITIONING

GROUND CIRCUIT INSPECTION E3DD06B9

- 1. Check for open in ground harness.
 - 1) Ignition "OFF"
 - 2) Disconnect ambient temp. sensor.
 - 3) Measure resistance between terminal "2" of ambient temp. sensor and chassis ground.

Specification : Approx. 0



Check for open in ground harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION EDDDBOBA

Refer to DTC B1237.

VERIFICATION OF VEHICLE REPAIR E39C67CD

Refer to DTC B1237.

<u>HA -</u>137

DTC B1241 EVAPORATOR TEMPERATURE SENSOR SHORT (LOW)

COMPONENT LOCATION E2D9BE91



GENERAL DESCRIPTION EA4B0598

The Evaporator temperature sensor located on heater unit, detects the core temperature and interrupts compressor relay power, in order to prevent evaporator freezing by excessive cooling. It is a negative type thermistor whose resistance is inversely proportional to temperature.

DTC DESCRIPTION EC6ED22F and in the based of ited to the based of ited t

The A/C controller sets DTC B1241 if there is a short circuit in evaporator temp. sensor signal harness or the measured resistance value of sensor is less than threshold value(about 0.9k)

DTC DETECTING CONDITION EF9E2420

Item	Detecting Condition	Possible cause
DTC Strategy	Resistance check	 Short circuit in harness
Threshold value	• < 0.9k	 Faulty Evaporator temp. Sensor Faulty A/C control unit
Detecting time	• 0.3 sec	
FAIL SAFE	 Control with the value of -2°C(28.4°F) 	

HA -138

HEATING, VENTILATION AND AIR CONDITIONING

SPECIFICATION EE70CB3D

Temperature[°C(°F)]	Resistance(k)	Temperature[°C(°F)]	Resistance(k)
-10(14)	13.6	15(59)	3.9
0(32)	8	30(86)	2
5(41)	6.2	40(104)	1.3
10(50)	4.9	50(122)	0.9

Resistence value of evaporator sensor as a function of temperature.

MONITOR SCANTOOL DATA E2249A3D

- 1. Connect scantool to data link connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "EVAPORATIVE SENSOR" Parameter on the Scantool.



Fig 1 : The current data in abnormal state. Fig 2 : DTC B1241.

LQIE519B

 Are the DTC B1241 present and is parameter of "EVAPORATIVE SENSOR" fixed? Parameter of "EVAPORATIVE SENSOR" will be fixed at -2 (28.4), if there is any fault in EVAPORATIVE SENSOR.



Go to "Inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

WWW.DIGITALKHODRO.COM

BLOWER AND A/C CONTROLS (AUTOMATIC)

TERMINAL AND CONNECTOR INSPECTION ESCEFBID

- Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure.



Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION EFFE7FA3

- 1. Check for short to ground in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect evaporator temp. sensor.
- 3) Measure resistance between terminal "1" of evaporator temp. sensor and chassis ground.

Specification : Approx.

EQRE519C

4) Is the measured resistance within specifications?

M32

YES

Go to "Component Inspection" procedure.

NO

Check for short to ground in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

Evaporator temp. sensor signal
 Evaporator temp. sensor ground

WWW.DIGITALKHODRO.COM

021-62999292

HA -140

HEATING, VENTILATION AND AIR CONDITIONING

COMPONENT INSPECTION ECD7CA04

- 1. Check evaporator temp. sensor.
 - 1) Ignition "OFF"
 - 2) Disconnect evaporator temp. sensor.
 - 3) Measure resistance between terminal "1" and "2" of evaporator temp. sensor.

Specification : Refer the specifications in fig 3.



Fig 3) Specifications : Resistance value of evaporator temp. sensor as a function of temperature.

LQIE519F

BLOWER AND A/C CONTROLS (AUTOMATIC)

4) Is the measured resistance within specifications in fig3? (tolerance limits ±3%)

YES

Go to "Check A/C Control Unit" procedure.

NO

Substitute with a known-good evaporator temp. sensor and check for proper operation. If the problem is corrected, replace evaporator temp. sensor and then go to "Verification of Vehicle Repair" procedure.

- 2. Check A/C Control Unit
 - 1) Engine "ON"
 - 2) Disconnect evaporator temp. sensor.
 - 3) Measure voltage between terminal "6" of A/C Control Unit and chassis ground.

Specification : Approx. 5V



EQRE519E

4) Is the measured voltage within specifications?

YES

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.



Substitute with a known-good A/C Control Unit and check for proper operation. If the problem is corrected, replace A/C Control Unit and then go to "Verification of Vehicle Repair" procedure.

HA -142

HEATING, VENTILATION AND AIR CONDITIONING

VERIFICATION OF VEHICLE REPAIR E9D2E69C

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
- 2. Operate the vehicle and monitor the DTC on the scantool.
- 3. Are any DTCs present?

YES

Go to the applicable troubleshooting procedure.

NO

System is performing to specification at this time.





HA -143

DTC B1242 EVAPORATOR TEMPERATURE SENSOR OPEN (HIGH)

COMPONENT LOCATION E91ECC83





DTC DESCRIPTION EAF2485

The A/C controller sets DTC B1242 if there is an open circuit in evaporator temp. sensor signal harness or the measured resistance value of sensor is more than threshold value(about 13.6k)

DTC DETECTING CONDITION EA7CA474

Item	Detecting Condition	Possible cause
DTC Strategy	Resistance check	 Open Circuit in harness Faulty Evaporator temp. Sensor Faulty A/C control unit
Threshold value	• > 13.6k	
Detecting time	• 0.3 sec	
FAIL SAFE	 Control with the value of -2°C(28.4°F) 	

SPECIFICATION E3415325

Refer to DTC B1241.

HA -144

HEATING, VENTILATION AND AIR CONDITIONING

MONITOR SCANTOOL DATA EFOE0B48

- 1. Connect scantool to Data Link Connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "EVAPORATIVE SENSOR" Parameter on the Scantool.



 Are the DTC B1242 present and is parameter of "EVAPORATIVE SENSOR" fixed? Parameter of "EVAPORATIVE SENSOR" will be fixed at -2 (28.4), if there is any fault in EVAPORATIVE SENSOR.

YES

Go to "Inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION ED4ACC35

Refer to DTC B1241.
SIGNAL CIRCUIT INSPECTION EC556DAB

- 1. Check for open in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect evaporator temp. sensor.
 - 3) Measure resistance between terminal "1" of evaporator temp. sensor and terminal "6" of A/C Control Unit.

Specification : Approx. 0



Check for open in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

HA -146

HEATING, VENTILATION AND AIR CONDITIONING

GROUND CIRCUIT INSPECTION EB24CCBB

- 1. Check for open in ground harness.
 - 1) Ignition "OFF"
 - 2) Disconnect evaporator temp. sensor.
 - 3) Measure resistance between terminal "2" of evaporator temp. sensor and chassis ground.

Specification : Approx. 0



Check for open in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION EC4BACFB

Refer to DTC B1241.

VERIFICATION OF VEHICLE REPAIR EAEDEBC4

Refer to DTC B1241.

<u>HA -</u>147

DTC B1245 AIR MIX POTENTIOMETER OPEN (LOW) - DRIVER

COMPONENT LOCATION EE159CD3



GENERAL DESCRIPTION E11EA5B6

Temperature control actuator located at heater unit, regulates the temperature by the procedure as follows. Signal from control unit adjusts position of temp. door by operating temp. motor and then temperature will be regulated by the hot/cold air ratio decided by position of temp. door.

DTC DESCRIPTION ED991178 ED991178

The A/C controller sets DTC B1245 if there is an open circuit or poor connection in the air mix potentiometer.

DTC DETECTING CONDITION EEA20D7B

Item	Detecting Condition	Possible cause		
DTC Strategy	Voltage check	 Poor connection of connected part Open circuit in harness 		
Threshold value	• < 0.1V			
Detecting time	• 0.3 sec	 Short circuit in harness 		
FAIL SAFE	 If temperature setting 17~24.5°C(63~76°F) fix at max. cooling position. If temperature setting 25~32°C(77~90°F) fix at max. heating position. 	 Faulty driver Air Mix potentiometer 		

HA -148

HEATING, VENTILATION AND AIR CONDITIONING

SPECIFICATION E0DF0BD2



LQIE521B

MONITOR SCANTOOL DATA E8F291C9

- Connect scantool to Data Link Connector(DLC). 1.
- Engine "ON" 2.
- Monitor the "Driver Air Mix Potentiometer" Parameter on the Scantool while operating temp. switch. 3.



Fig 1 : The current data in abnormal state. Fig 2 : DTC B1245.

LQIE521C

HA -149

 Are the DTC B1245 present and is parameter of "Driver Air Mix Potentiometer" fixed? Parameter of "Driver Air Mix Potentiometer" will be fixed at 100% (or any value above 90%), or 0% (or any value below 10%), if there is any fault in Driver Air Mix potentiometer.



Go to "Inspection" procedure.



Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION ED352E86

- Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.



SIGNAL CIRCUIT INSPECTION EFGADC9F

- 1. Check for open in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect Driver Air Mix potentiometer.

HA -150

HEATING, VENTILATION AND AIR CONDITIONING

3) Measure resistance between terminal "6" of Driver Air Mix Potentiometer and terminal "18" of A/C control unit.

Specification : Approx. 0





- 3. Motor
- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQRE521E

BLOWER AND A/C CONTROLS (AUTOMATIC)

4) Is the measured resistance within specifications?



Go to "Power circuit Inspection" procedure.



Check for short to ground in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

POWER SUPPLY CIRCUIT INSPECTION E85689CE

- 1. Check for short or open in harness.
 - 1) Ignition "ON"
 - 2) Connect Driver Air Mix Potentiometer.
 - 3) Measure voltage between terminal "7" of Driver Air Mix Potentiometer and chassis ground.



EQRE521F

4) Is the measured voltage within specifications?



Go to "Component inspection" procedure.



Check for short or open in power harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

HEATING, VENTILATION AND AIR CONDITIONING

COMPONENT INSPECTION E5513CEC

- 1. Check actuator motor.
 - 1) Ignition "OFF"
 - 2) Disconnect Driver Air Mix Potentiometer.
 - 3) Verify that the temperature actuator operates to the hot position when connecting 12V to the terminal "3" and grounding terminal "4".
 - 4) Verify that the temperature actuator operates to the cool position when the connections are reversed.



Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

- 2. Check potentiometer
 - 1) Ignition "ON"
 - 2) Connect Driver Air Mix potentiometer.
 - 3) Measure voltage between terminal "5" and "6" of Driver Air Mix potentiometer while operating the temp. switch.

Specification : Refer the specifications in fig 3)



Fig 3) Specifications : Voltage value of air mix potentiometer as a function of position of setting temperature.

LQIE521J

HA -153

021-62999292

WWW.DIGITALKHODRO.COM

HA -154

HEATING, VENTILATION AND AIR CONDITIONING

4) Is the measured voltage within specifications in fig3?



Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.



Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR EB87AC3A

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
- 2. Operate the vehicle and monitor the DTC on the scantool.
- 3. Are any DTCs present?

YES

Go to the applicable troubleshooting procedure.

NO

System is performing to specification at this time.

ولين سامانه ديجيتال تعميركاران خودرو در ايران



<u>HA -</u>155

DTC B1246 AIR MIX POTENTIOMETER SHORT (HIGH) - DRIVER

COMPONENT LOCATION E9A515E8



DTC DETECTING CONDITION EA32F0CB

Item	Detecting Condition	Possible cause			
DTC Strategy	Voltage check	Short circuit in harness			
Threshold value	• > 4.9V	Faulty driver Air Mix potentiometer			
Detecting time	• 0.3 sec				
FAIL SAFE	 If temperature setting 17~24.5°C(63~76°F) fix at max. cooling position. If temperature setting 25~32°C(77~90°F) fix at max. heating position. 				

SPECIFICATION E2F8B08E

Refer to DTC B1245.

HA -156

HEATING, VENTILATION AND AIR CONDITIONING

MONITOR SCANTOOL DATA E2B8EB37

- 1. Connect scantool to Data Link Connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "Driver Air Mix Potentiometer" Parameter on the Scantool while operating temp. switch.

1.2 CURRENT DATA			1.1 DIAGNOSTIC TROUBLE CODES	
HEATER WATER TEMP.SNSR	13.0 °C		B1246 AIR MIX P HIGH INPUT	
IN-CAR TEMP.SENSOR	12.0 °C			
AMBIENT AIR TEMP.SNS	12.0 °C			
EVAPORATIVE SENSOR	12.5 °C			
DRIVER PHOTO SENSOR	0.00 V			
AIR MIX POPENTIO.(DR.)	91.75 %			
DIRECTION POTENIO.DR.	90.18 %			
PASSENGER PHOTO SENSOR	255			
			NUMBER OF DTC : 1 ITEMS	
	RPH HELF	D	PART ERAS HELP	
Fig 1			Fig 2	
i <mark>g 1 : The</mark> current data in abnormal state				
ig 2 : DTC B124 <mark>6.</mark>				
و سامانه (مسئولیت مح	No.			DIE522A
				(ILJZZA

4. Are the DTC B1246 present and is parameter of "Driver Air Mix potentiometer" fixed? Parameter of "Driver Air Mix potentiometer" will be fixed at 100%(or any value above 90%), or 0% (or any value below 10%), if there is any fault in Driver Air Mix potentiometer.

YES

Go to "Inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION EEBC844B

Refer to DTC B1245.

BLOWER AND A/C CONTROLS (AUTOMATIC)

SIGNAL CIRCUIT INSPECTION ECCE319F

- 1. Check for short in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect Driver Air Mix potentiometer.
 - 3) Measure resistance between terminal "6" and "7" of Driver Air Mix potentiometer.

Specification : Approx.



Check for short to power harness in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

HEATING, VENTILATION AND AIR CONDITIONING

GROUND CIRCUIT INSPECTION EA4B39E1

- 1. Check for open in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect Driver Air Mix Potentiometer.
 - 3) Measure resistance between terminal "5" of Driver Air Mix Potentiometer and chassis ground.

Specification : Approx. 0



Check for open in ground harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION EDDB34AF

Refer to DTC B1245.

VERIFICATION OF VEHICLE REPAIR EFADDE2A

Refer to DTC B1245.

<u>HA -</u>159

DTC B1249 DIRECTION POTENTIOMETER OPEN (LOW) - DRIVER

COMPONENT LOCATION EF27E511



GENERAL DESCRIPTION E1C6CBDA

The mode control actuator mounted on heater unit, adjusts position of mode door by operating Direction Motor based on signal of A/C control unit. Pressing mode select switch makes the mode control actuator shift in order of vent B/L floor mix.

DTC DESCRIPTION EAGBREOF OR I LINE AND A LINE UND

The A/C controller sets DTC B1249 if there is an open circuit or poor connection in the Direction potentiometer.

DTC DETECTING CONDITION EFA3C9A5

Item	Detecting Condition	Possible cause		
DTC Strategy	Voltage check	Poor connection of connected		
Threshold value	• < 0.1V	partOpen circuit in harness		
Detecting time	• 0.3 sec	Short circuit in harness		
FAIL SAFE	 Fix vent position, while selecting vent mode. Fix defrost position while selecting except vent mode. 	 Faulty driver direction potentiometer 		

HA -160

HEATING, VENTILATION AND AIR CONDITIONING





LQIE523B

MONITOR SCANTOOL DATA EED52D3E

- Connect scantool to Data Link Connector(DLC). 1.
- Engine "ON" 2.
- Monitor the "DR. DIRECTION POTENTIO." parameter on the scantool while operating mode switch. 3.



Fig 1 : The current data in abnormal state. Fig 2 : DTC B1249.

LQIE523C

HA -161

 Are the DTC B1249 present and is parameter of "DR. DIRECTION POTENTIO." fixed? Parameter of "DR. DIRECTION POTENTIO." will be fixed at 100% (or any value above 90%), or 0% (or any value below 10%), if there is any fault in Driver Direction potentiometer.



Go to "Inspection" procedure.



Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION EDF45C9A

- Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.



SIGNAL CIRCUIT INSPECTION EAAE0F3C

- 1. Check for open in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect Driver mode Actuator.

021-62999292

HA -162

HEATING, VENTILATION AND AIR CONDITIONING

3) Measure resistance between terminal "6" of Driver Direction potentiometer and terminal "21" of A/C control unit.

Specification : Approx. 0





EQRE523E

BLOWER AND A/C CONTROLS (AUTOMATIC)

4) Is the measured resistance within specifications?



Go to "Power circuit Inspection" procedure.



Check for short to ground in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

POWER SUPPLY CIRCUIT INSPECTION E7EF9AFF

- 1. Check for short or open in harness.
 - 1) Ignition "ON"
 - 2) Connect Driver Direction potentiometer.
 - 3) Measure voltage between terminal "7" of Driver Direction potentiometer and chassis ground.



EQRE523F

4) Is the measured voltage within specifications?



Go to "Component Inspection" procedure.



Check for short or open in power harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

HEATING, VENTILATION AND AIR CONDITIONING

COMPONENT INSPECTION E05E82B7

- 1. Check actuator.
 - 1) Ignition "OFF"
 - 2) Disconnect Driver Direction potentiometer.
 - 3) Verify that the mode actuator operates to the vent mode when connecting 12V to the terminal "3" and grounding terminal "4".
 - 4) Verify that the mode actuator operates to the def mode when the connections are reversed.



Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

- 2. Check potentiometer
 - 1) Ignition "ON"
 - 2) Connect Driver Direction potentiometer.
 - 3) Measure voltage between terminal "5" and "6" of Driver Direction potentiometer as the mode switch is operated.

Specification : Refer the specifications in fig 3





Fig 3

Fig 3) Specifications : Voltage value as a function of position of direction potentiometer.

LQIE523J

WWW.DIGITALKHODRO.COM

021-62999292

HA -166

HEATING, VENTILATION AND AIR CONDITIONING

4) Is the measured voltage within specifications in fig3?



Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.



Substitute with a known-good actuator and check for proper operation. If the problem is corrected, replace actuator and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR E0CE7511

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
- 2. Operate the vehicle and monitor the DTC on the scantool.
- 3. Are any DTCs present?

YES

Go to the applicable troubleshooting procedure.

NO

System is performing to specification at this time.

ولين سامانه ديجيتال تعميركاران خودرو در ايران



<u>HA -</u>167

DTC B1250 DIRECTION POTENTIOMETER SHORT (HIGH) - DRIVER

COMPONENT LOCATION EA42BAD0



DTC DETECTING CONDITION EBC426F4

Item	Detecting Condition	Possible cause	
DTC Strategy	Voltage check	 Short circuit in harness Faulty driver direction potentiometer 	
Threshold value	• > 4.9V		
Detecting time	• 0.3 sec	Open circuit in harness	
FAIL SAFE	Fix vent position		

SPECIFICATION E4E11504

Refer to DTC B1249.

HA -168

HEATING, VENTILATION AND AIR CONDITIONING

MONITOR SCANTOOL DATA E4D3C602

- 1. Connect scantool to Data Link Connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "DR. DIRECTION POTENTIO." parameter on the scantool while operating mode switch.

1.2 CURRENT DATA		1.1 DIAGNOSTIC TROUBLE CO	DES
HEATER WATER TEMP.SNSR	13.0 °C	B1250 DIRECTION P HIGH INPUT	
IN-CAR TEMP.SENSOR	11.5 °C		
AMBIENT AIR TEMP.SNS	12.0 °C		
EVAPORATIVE SENSOR	13.0 °C		
DRIVER PHOTO SENSOR	0.00 V		
AIR MIX POPENTIO.(DR.)	92.54 %		
DIRECTION POTENIO.DR.	100 %		
PASSENGER PHOTO SENSOR	255		
		NUMBER OF DTC : 1 ITEMS	
	RPH HELP	PART ERAS	HELP
Fig 1		Fig 2	
ig 1 : The current data in abnormal state			
ig 2 : DTC B1250.			
و سامانه (مسئولیت مح	Nois II		
		سردت دیج	LQIE524A

4. Are the DTC B1250 present and is parameter of "DR. DIRECTION POTENTIO." fixed? Parameter of "DR. DIRECTION POTENTIO." will be fixed at 100% (or any value above 90%), or 0% (or any value below 10%), if there is any fault in Driver Direction potentiometer.

YES

Go to "Inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION E53E57EA

Refer to DTC B1249.

BLOWER AND A/C CONTROLS (AUTOMATIC)

SIGNAL CIRCUIT INSPECTION EBC89BCE

- 1. Check for short in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect Driver mode Actuator.
 - 3) Measure resistance between terminal "6" and "7" of Driver Direction potentiometer.

Specification : Approx.



Check for open in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

HEATING, VENTILATION AND AIR CONDITIONING

GROUND CIRCUIT INSPECTION E8C728FF

- 1. Check for open in ground harnesS.
 - 1) Ignition "OFF"
 - 2) Disconnect Driver mode Actuator.
 - 3) Measure resistance between terminal "5" of evaporator sensor and chassis ground.

Specification :Approx. 0



Check for open in ground harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION E9E967A5

Refer to DTC B1249.

VERIFICATION OF VEHICLE REPAIR E06EEDOE

Refer to DTC B1249.

DTC B1257 AQS SENSOR OPEN (HIGH)

COMPONENT LOCATION EOFOBEE1

AQS(Air Quality System) keeps air inside in the most suitable state for driver. In polluted area AQS detects hazardous gas and intercepts inflow automatically, Inversely, In freshsh area it allows the inflow of air to prevent the shortage of air and the accumulation of carbon dioxide. AQS sensor is located at front side of condensor and once hazardous day is

E5EE0BAB

and the accumulation of carbon dioxide. AQS sensor is located at front side of condensor and once hazardous gas is detected, it delivers the voltage signal to A/C controller for closing intake door.

DTC DESCRIPTION EB4D82AD

GENERAL DESCRIPTION

The A/C controller sets DTC B1257 if there is an open circuit in AQS sensor signal harness or the measured voltage value of sensor is more than threshold value.

DTC DETECTING CONDITION EDCB5BC5

Item	Detecting Condition	Possible cause		
DTC Strategy	Voltage check	Open Circuit in power harness		
Threshold value	• > 4.9V	Open circuit in ground harnessFaulty AQS Sensor		
Detecting time	• 1 sec	Poor connection of connected		
FAIL SAFE	 AQS function OFF Intake door : return to previous state 	part		



HA -171

HA -172

HEATING, VENTILATION AND AIR CONDITIONING

SPECIFICATION EAB6DF34

Voltage value of AQS sensor as a function of position of operating condition.

Operating condition	Voltage	Note
Right after IGN "ON"	2.5V ± 0.3V	preheating($35 \pm 2sec$)
Normal	4.3V ± 0.3V	Intake door : Fresh
Gas detected	0.9V ± 0.3V	Intake door : Recirculation

MONITOR SCANTOOL DATA EEFFB9FA

- 1. Connect scantool to Data Link Connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "AQS sensor " Parameter on the Scantool. While making hazardous gas such as tobacco fumes around the AQS sensor.

	1.2 CURRENT DATA			1.1 DIAGNOSTIC TROUBLE CODES	
	HEATER WATER TEMP. SNSR	14.0 °C		B1257 AQS SENSOR-OPEN(HIGH)	
	IN-CAR TEMP. SENSOR	12.0 °C	-		
	AMBIENT AIR TEMP. SNS	12.0 °C			
	EVAPORATIVE SENSOR	13.0 °C			
	DRIVER PHOTO SENSOR	0.00 V	ï.	🕒 🚽 👘 شرکت دید	
	AIR MIX POPENTIO. (DR.)	84.69 %			
	DIRECTION POTENIO. DR.	51.76 %			
	PASSENGER PHOTO SENSOR	255	-		
	AQS SENSOR	4.3 V		NUMBER OF DTC : 1 ITEMS	
		PH HELP		PART ERAS HELP	
Fi	g 1			Fig 2	

Fig 1 : The current data in abnormal state. Fig 2 : DTC B1257.

EQRE517A

4. Are the DTC B1257 present and is parameter of "AQS SENSOR" fixed?

YES

Go to "Inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

WWW.DIGITALKHODRO.COM

021-62999292

TERMINAL AND CONNECTOR INSPECTION E6A481D0

- Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure.



Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION E8C0D6F7

- 1. Check for open in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect AQS sensor.
 - 3) Measure resistance between terminal "4" of AQS sensor and terminal "2" of A/C Control Unit.

Specification : Approx. 0



- 1. Ambient temp. sensor(+)
- 2. Ambient temp. sensor ground
- 4. AQS signal input
- 5. AQS ground
- 6. AQS power

EQRE531B

4) Is the measured resistance within specifications?

YES

Go to "Ground circuit Inspection " procedure.

NO

Check for open in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

WWW.DIGITALKHODRO.COM

021-62999292

HA -174

HEATING, VENTILATION AND AIR CONDITIONING

GROUND CIRCUIT INSPECTION E8C75C60

- 1. Check for open in ground harness.
 - 1) Ignition "OFF"
 - 2) Disconnect AQS sensor.
 - 3) Measure resistance between terminal "5" of AQS sensor and chassis ground.

Specification : Approx. 0



Check for open in ground harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION E8D083E3

- 1. Check AQS sensor.
 - 1) Engine "ON"
 - 2) Connect AQS sensor.

3) Measure voltage between terminal "4" and "5" of AQS sensor.

Specification : Refer to the specifications.

€72 (6) 5) 4 (6) 5) 4 (7) 2 (7)

1. Ambient temp. sensor(+)

- 2. Ambient temp. sensor ground
- 4. AQS signal input
- 5. AQS ground
- 6. AQS power

EQRE530D

Operating condition	Voltage	Note
Right after IGN "ON"	2.5V ± 0.3V	preheating(35 ± 2sec)
Normal	4.3V ± 0.3V	Intake door : Fresh
Gas detected	0.9V ± 0.3V	Intake door : Recirculation

Specifications : Voltage value of AQS sensor as a function of position of operating condition.

4) Is the measured voltage within specifications?

ا اولین سامانه دیجیتال تعمیر کاران خودر _{YES} ی

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

Substitute with AQS sensor and check for proper operation. If the problem is corrected, replace AQS sensor and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR EE6DFC8A

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode and then clear DTC.
- 2. Operate the vehicle and monitor the DTC on the scantool.
- 3. Are any DTCs present?

YES

Go to the applicable troubleshooting procedure.

NO

System is performing to specification at this time.

WWW.DIGITALKHODRO.COM

021-62999292

HA -175

HEATING, VENTILATION AND AIR CONDITIONING

DTC B1258 AQS SENSOR SHORT (LOW)

COMPONENT LOCATION EF99AB04



Refer to DTC B1257.

DTC DESCRIPTION E9E59E1C

The A/C controller sets DTC B1258 if there is a short circuit in AQS sensor signal harness or the measured voltage value of the sensor is less than the threshold value.

DTC DETECTING CONDITION ED51A900

Item	Detecting Condition	Possible cause
DTC Strategy	Voltage check	Short circuit in harness
Threshold value	• < 0.1V	 Faulty AQS Sensor Fault A/C Control Unit
Detecting time	• 1 sec	
FAIL SAFE	 AQS function OFF Intake door : return to previous state 	

SPECIFICATION EA7C1CBF

Refer to DTC B1257.

MONITOR SCANTOOL DATA E5CD1D31

- 1. Connect scantool to Data Link Connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "AQS sensor" Parameter on the Scantool. While making hazardous gas such as tobacco fumes around the AQS sensor.



YES

Go to "Inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/or A/C control unit's connector or was repaired and A/C control unit memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION ECEA3EC4

Refer to DTC B1257.

HA -177

HEATING, VENTILATION AND AIR CONDITIONING

SIGNAL CIRCUIT INSPECTION E5F494FE

- 1. Check for open in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect AQS sensor.
 - 3) Measure resistance between terminal "4" of AQS sensor and terminal chassis ground.

Specification : Approx. 0



Check for open in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

BLOWER AND A/C CONTROLS (AUTOMATIC)

COMPONENT INSPECTION E7F9BE24

- 1. Check AQS sensor.
 - 1) Engine "ON"
 - 2) Connect AQS sensor.
 - 3) Measure voltage between terminal "4" and "5" of AQS sensor.

Specification : Refer the specifications.



Specifications : Voltage value of AQS sensor as a function of position of operating condition.

4) Is the measured voltage within specifications?



Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

Substitute with a AQS sensor and check for proper operation. If the problem is corrected, replace AQS sensor and then go to "Verification of Vehicle Repair" procedure.

HA -180

HEATING, VENTILATION AND AIR CONDITIONING

- 2. Check A/C Control Unit
 - 1) Engine : "ON"
 - 2) Disconnect AQS sensor.
 - 3) Measure voltage between terminal "2" of A/C Control Unit and chassis ground.

Specification : Approx. 5V



Substitute with a known-good A/C Control Unit and check for proper operation. If the problem is correcirculationted, replace A/C Control Unit and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR E3C958DB

Refer to DTC B1257.
DTC B1259 AQS SENSOR FAULT

COMPONENT LOCATION EF2ECF5F



GENERAL DESCRIPTION E5982CAA

Refer to DTC B1257.

DTC DESCRIPTION EC8D3F37

The A/C controller sets DTC B1259 if preheating time of AQS sensor is over 40sec or signal from AQS sensor is not within specifications.

DTC DETECTING CONDITION EOF5DDD5

Item	Detecting Condition	Possible cause	
DTC Strategy	Voltage/time check	Faulty AQS Sensor	
Threshold value	 Voltage : Preheating - 2.5V±0.3V Normal - 4.3V±0.3V Gas detected - 0.9V±0.3V Preheating time > 40sec 	Poor connection of connected part	
Detecting time	-		
FAIL SAFE	 AQS function OFF Intake door : return to previous state 		

SPECIFICATION E7DEFC5C

Refer to DTC B1257.

HA -182

HEATING, VENTILATION AND AIR CONDITIONING

MONITOR SCANTOOL DATA EA39EE35

- 1. Connect scantool to Data Link Connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "AQS sensor " Parameter on the Scantool. While making hazardous gas such as tobacco fumes around the AQS sensor.

1.2 CURRENT DATA		1.1 DIAGNOSTIC TROUBLE CODES	
HEATER WATER TEMP. SNSR	14.0 °C	B1259 AQS SENSOR FAULT	
IN-CAR TEMP. SENSOR AMBIENT AIR TEMP. SNS	12.0 °C 12.0 °C		
EVAPORATIVE SENSOR DRIVER PHOTO SENSOR	13.0 °C 0.00 V		
AIR MIX POPENTIO. (DR.) DIRECTION POTENIO. DR.	84.69 % 51.76 %		
PASSENGER PHOTO SENSOR AQS SENSOR	255 2.6 V	NUMBER OF DTC : 1 ITEMS	
	RPH HELP	PART ERAS HELP	
Fig 1 : The current data in abnormal state.		Fig 2	
و سامانه (مسئولیت محدود)			RE517B
4. Are the DTC B1259 present and is para	meter of "AQS	S SENSOR" fixed?	

YES

Go to "Inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION E1BD9DA4

Refer to DTC B1257.

WWW.DIGITALKHODRO.COM

SIGNAL CIRCUIT INSPECTION EEABBB2E

- 1. Check for open in harness.
 - 1) Ignition "ON"
 - 2) Disconnect AQS sensor.
 - 3) Measure voltage value between terminal "6" of AQS sensor and chassis ground.

Specification : Approx. 12V



Check for open in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION E3EE9C85

Refer to DTC B1257.

VERIFICATION OF VEHICLE REPAIR E91C2B30

Refer to DTC B1257.

HEATING, VENTILATION AND AIR CONDITIONING

DTC B2406 AIR MIX MOTOR (DRIVER)

COMPONENT LOCATION ECBB4E90



GENERAL DESCRIPTION E2DE3A74

Temperature control actuator located at heater unit, regulates the temperature by the procedure as follows. Signal from control unit adjusts position of temp. door by operating temp. motor and then temperature will be regulated by the hot/cold air ratio decided by position of temp. door.

The A/C controller sets DTC B2406 if the air mix actuator doesn't move to intended position within 40sec (In this case, A/C controller try to move temp. door for 2sec. 3 times, every 20 sec. before setting DTC).

DTC DETECTING CONDITION E400FA99

Item	Detecting Condition	Possible cause	
DTC Strategy	 Voltage check 	Poor connection of connected	
Threshold value	• < 0.1V	partOpen circuit in harness	
Detecting time	• 0.3 sec	 Short circuit in harness 	
FAIL SAFE	-	 Faulty driver Air Mix potentiometer Fault A/C Control Unit 	

BLOWER AND A/C CONTROLS (AUTOMATIC)

SPECIFICATION ED34A19E



LQIE521B

MONITOR SCANTOOL DATA ECD1E58C

- 1. Connect scantool to Data Link Connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "Driver Air Mix Potentiometer" Parameter on the Scantool while operating temp. switch.



Fig 1 : The current data in abnormal state. Fig 2 : DTC B2406.

EQRE525A

021-62999292

HA -185

WWW.DIGITALKHODRO.COM

HEATING, VENTILATION AND AIR CONDITIONING

4. Are the DTC B2406 present and is parameter of "Driver AIR MIX Potentiometer" fixed?

There is any fault in Driver AIR MIX Motor. If the parameter of "Driver AIR MIX DOOR" is 30% or less when the actuator operates to the hot position, or If the parameter is 60% and more when the actuator operates to the cold position.

YES

Go to "Inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION E1EB2FE3

Refer to DTC 1245.

SIGNAL CIRCUIT INSPECTION ECD850DF

1. Check for open in harness.

- 1) Ignition "OFF"
- 2) Disconnect Driver Air Mix potentiometer.
- 3) Measure resistance between terminal "3,4" of Driver Air Mix Motor and terminal "16,17" of A/C control unit.

Specification : Approx. 0



- 3. Motor
- 4. Motor
- 5. Potentiometer ground
- 6. Potentiometer signal
- 7. Sensor reference voltage(+5V)

EQRE525B

4) Is the measured resistance within specifications?

YES

Go to "Check for short to ground in harness" procedure.

NO

Check for open in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

WWW.DIGITALKHODRO.COM

021-62999292

BLOWER AND A/C CONTROLS (AUTOMATIC)

- 2. Check for short to ground in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect Driver Air Mix Actuator.
 - 3) Measure resistance between terminal "3,4" of Driver Air Mix Motor and chassis ground.

Specification : Approx.



Check for short to ground in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

HA -188

HEATING, VENTILATION AND AIR CONDITIONING

VISUAL/PHYSICAL INSPECTION EFEA33B3

- 1. Check actuator. Check if Driver Air Mix Actuator works properly through ACTUATION TEST.
 - 1) Ignition : ON
 - 2) Connect Scantool and select " ACTUATION TEST" mode and press [F1]

	1.3 ACTUATION TEST]	
DRIVER	AIR MIX DOOR - DRIVE 50%		
DURATION	UNTIL STOP KEY		
METHOD	ACTIVATION		
CONDITION	IG. KEY ON ENGINE RUNNING		
PRESS [S	TRT], IF YOU ARE READY!		
STRT STO	Р		
Fig 3			
Fig 3 : Selecting	"ACTUATION TEST" mode.		LQIE525D
3) Does D YES	river Air Mix Actuator work prope	شرکت دیجیتال ^ج	
U Go to "	Component Inspection" procedur	اولين سامانه ديج	
NO			

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION E4D92E5E

Refer to DTC 1245.

- 1. Check A/C Control Unit.
 - 1) Engine "ON"
 - 2) Connect A/C Control Unit.
 - 3) Measure voltage between terminal "16" and "17" of A/C Control Unit while operating the temp. switch.

Specification :Approx. 12V



Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

Substitute with a known-good A/C Control Unit and check for proper operation. If the problem is corrected, replace A/C Control Unit and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR EFF2F0F2

Refer to DTC 1245.

HEATING, VENTILATION AND AIR CONDITIONING

DTC B2408 INTAKE MOTOR

COMPONENT LOCATION EFF31BF2



DTC DESCRIPTION EEBCEE70

The A/C controller sets DTC B2408 if the intake motor Doesn't move to intended position within 40sec(The A/C controller attempts to move the intake door for a 2 second duration at a freshquency of 3 times every 20 seconds before storing a DTC.)

DTC DETECTING CONDITION EFF3BBBC

Item	Detecting Condition	Possible cause	
DTC Strategy	Voltage check	Poor connection of connected	
Threshold value	• < 0.1V	partOpen circuit in harness	
Detecting time	• 0.3 sec	Short circuit in harness	
FAIL SAFE	-	 Faulty Intake potentiometer 	

SPECIFICATION EFIDAOCF

Refer to DTC B1208.

MONITOR SCANTOOL DATA E00AF4A4

- 1. Connect scantool to Data Link Connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "Intake Potentiometer" Parameter on the Scantool while operating Intake switch.

[1.2 CURRENT DATA			1.1 DIAGNOSTIC TROUBLE CO	DES	
	HEATER WATER TEMP.SNSR	14.0 °C		B2408 INTAKE MOTOR		
	IN-CAR TEMP.SENSOR	12.0 °C				
	AMBIENT AIR TEMP.SNS	12.0 °C				
	EVAPORATIVE SENSOR	13.0 °C				
	DRIVER PHOTO SENSOR	0.00 V				
	AIR MIX POPENTIO.(DR.)	84.69 %				
	DIRECTION POTENIO.DR.	51.76 %				
	PASSENGER PHOTO SENSOR	255				
	INTAKE SENSOR	22.7 %		NUMBER OF DTC : 1 ITEMS		
			▼			
_	FIX SCRN FULL PART G	RPH HELP]	PART ERAS	HELP	
	Fig 1			Fig 2		
E F	ig 1 : The current data in abnormal state					
F	ig 2 : DTC B2408.					
	رو سامانه (مسئولیت مح	لتال خود			E	EQRE529A

4. Are the DTC B2408 present and is parameter of "Intake Potentiometer" fixed? There is any fault in Intake potentiometer. If the parameter of "Intake potentiometer" is 30% or less when the actuator operates to the fresh position, or If the parameter is 60% and more when the actuator operates to the recirculation position.



Go to "Inspection" procedure.



Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION EDB5AEA3

Refer to DTC B1208.

HEATING, VENTILATION AND AIR CONDITIONING

SIGNAL CIRCUIT INSPECTION ECEDEF6D

- 1. Check for open in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect Intake potentiometer.
 - 3) Measure resistance between terminal "3,4" of Intake potentiometer and terminal "22,23" of A/C control unit.

Specification : Approx. 0



Check for open in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

BLOWER AND A/C CONTROLS (AUTOMATIC)

- 2. Check for short to ground in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect Driver Air Mix Actuator.
 - 3) Measure resistance between terminal "3,4" of Driver Air Mix Motor and chassis ground.

Specification : Approx.



Check for short to ground in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

HA -194

HEATING, VENTILATION AND AIR CONDITIONING

VISUAL/PHYSICAL INSPECTION EESFB3CA

- 1. Check actuator. Check if Driver Air Mix Actuator works properly through ACTUATION TEST.
 - 1) Ignition : ON
 - 2) Connect Scantool and select " ACTUATION TEST" mode and press [F1]

		7	
	1.3 ACTUATION TEST	-	
DRIVER AIR	ROUTLET MODE - DRIVE FOOT		
DURATION	UNTIL STOP KEY		
METHOD	ACTIVATION		
CONDITION	IG. KEY ON ENGINE RUNNING		
PRESS [S	TRT], IF YOU ARE READY!		
STRT STOP	2		
Fig 3		-	
Fig 3 : Selecting	"ACTUATION TEST" mode.		EQRE525D
3) Does In YES	take Actuator work properly?	شرکت دیجیتال خ	
⊖ Go to`"(Component Inspection" procedur	اولين سامانه ديج	
NO			

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION E7F85ECE

Refer to DTC 1208.

- 1. Check A/C Control Unit.
 - 1) Engine "ON"
 - 2) Connect A/C Control Unit.
 - 3) Measure voltage between terminal "22" and "23" of A/C Control Unit while operating the Intake switch.

Specification :Approx. 12V



Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

Substitute with a known-good A/C Control Unit and check for proper operation. If the problem is corrected, replace A/C Control Unit and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR EBAA7A2F

Refer to DTC B1208.

HEATING, VENTILATION AND AIR CONDITIONING

DTC B2409 DIRECTION CONTROL MOTOR (DRIVER)

COMPONENT LOCATION E6C9B607



The A/C controller sets DTC B2409 if the direction motor doesn't move to intended position within 40sec(In this case, A/C controller try to move mode door for 2sec. 3 times, every 20 sec. before setting DTC).

DTC DETECTING CONDITION ED5DDB3A

Item	Detecting Condition	Possible cause	
DTC Strategy	Voltage check	Poor connection of connected	
Threshold value	• < 0.1V	partOpen circuit in harness	
Detecting time	• 0.3 sec	 Short circuit in harness 	
FAIL SAFE	-	 Faulty driver direction potentiometer Fault A/C Control Unit. 	

SPECIFICATION E7A5F0BC

Refer to DTC B1249.

MONITOR SCANTOOL DATA ED43EEEF

- 1. Connect scantool to Data Link Connector(DLC).
- 2. Engine "ON"
- 3. Monitor the "DR DIRECTION POTENTIO" parameter on the scantool while operating mode switch.

				1
1.2 CURRENT DATA			1.1 DIAGNOSTIC TROUBLE CODES	4
HEATER WATER TEMP.SNSR	14.0 °C		B2409 DRIVER DIRECTION MOTOR	
IN-CAR TEMP.SENSOR	12.0 °C			
AMBIENT AIR TEMP.SNS	12.0 °C			
EVAPORATIVE SENSOR	13.0 °C			
DRIVER PHOTO SENSOR	0.00 V			
AIR MIX POPENTIO.(DR.)	84.69 %			
DIRECTION POTENIO.DR.	32.5 %			
PASSENGER PHOTO SENSOR	255			
			NUMBER OF DTC : 1 ITEMS	
		▼		
FIX SCRN FULL PART G	RPH HELP]	PART ERAS HELP	_
Fig 1			Fig 2	
Fig 1 : The current data in abnormal state				
Fig 2 : DTC B2409.				
-				
رو سامانه (مسئولیت مح				LQIE526

4. Are the DTC B2409 present and is parameter of "Driver DIRECTION POTENTIO." fixed? There is any fault in Driver Direction Motor. If the parameter of "Driver DIRECTION POTENTIO." is 10% or less on "VENT" mode, or If the parameter is 90% or more on "DEF" mode.

YES

Go to "Inspection" procedure.

NO

Fault is intermittent caused by poor contact in the sensor's and/or A/C controller's connector or was repaired and A/C controller memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

TERMINAL AND CONNECTOR INSPECTION ECFE3D11

Refer to DTC B1249.

HEATING, VENTILATION AND AIR CONDITIONING

SIGNAL CIRCUIT INSPECTION EB9D13E3

- 1. Check for open in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect Driver mode Actuator.
 - 3) Measure resistance between terminal "3,4" of Driver Direction Motor and terminal "19,20" of A/C control unit.

Specification : Approx. 0



Check for open in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

BLOWER AND A/C CONTROLS (AUTOMATIC)

- 2. Check for short to ground in harness.
 - 1) Ignition "OFF"
 - 2) Disconnect Driver mode Actuator.
 - 3) Measure resistance between terminal "3,4" of Driver Direction Motor and chassis ground.

Specification : Approx.



Check for short to ground in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

HA -200

HEATING, VENTILATION AND AIR CONDITIONING

VISUAL/PHYSICAL INSPECTION EFC8F9FF

- 1. Check actuator. Check if Driver Direction Actuator works properly through ACTUATION TEST.
 - 1) Ignition : ON
 - 2) Connect Scantool and select " ACTUATION TEST" mode and press [F1]

	1.3 ACTUATION TEST		
DRIVER AIF	R OUTLET MODE-DRIVE FOOT		
DURATION	UNTIL STOP KEY		
METHOD	ACTIVATION		
CONDITION	IG. KEY ON ENGINE RUNNING		
PRESS [S	TRT], IF YOU ARE READY!		
STRT STO	P	-	
Fig 3		_	
Fig 3 : Selecting	"ACTUATION TEST" mode.		LQIE526D
3) Does D YES	river Direction Actuator work pro	شرکت دیجیاں <	
j Go to "	Component Inspection" procedur	اولين سامانه ديج	
NO			

Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION E1F3DB22

Refer to DTC 1249.

- 1. Check A/C Control Unit.
 - 1) Engine : "ON"
 - 2) Connect A/C Control Unit.
 - 3) Measure voltage between terminal "19" and "20" of A/C Control Unit while operating the mode switch.

Specification :Approx. 12V



Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

Substitute with a known-good A/C Control Unit and check for proper operation. If the problem is corrected, replace A/C Control Unit and then go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR E0EF14BE

Refer to DTC B1249.