# **Fuel System**

GENERAL

GASOLINE ENGINE CONTROL SYSTEM ENGINE CONTROL MODULE (ECM)

DTC TROUBLESHOOTING PROCEDURES

#### FUEL DELIVERY SYSTEM

FUEL LINE AND VAPOR LINE INJECTOR FUEL TANK FUEL PUMP (FP)



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



**FUEL SYSTEM** 



#### GENERAL

### GENERAL

#### SPECIFICATIONS EAC6D3D9

#### FUEL DELIVERY SYSTEM

Items	Specification	
Fuel Tank	Capacity	58 L
Fuel Retrun System	Туре	Returnless
Fuel Filter	Туре	High pressure type (built in Fuel Pump Assembly)
	Туре	Built in fuel pump assembly
Fuel Pressure Regulator	Regulated Fuel Pressure	350 kpa (3.5 kg/cm2, 49.8 psi)
Fuel Pump	Туре	Electrical, in-tank type

#### **INPUT SENSORS**

#### MASS AIR FLOW SENSOR (MAFS)

Type: Hot film type	
Specification	

Test Condition	MAFS Output Voltage	Mass Air Flow
Idle	0.6 ~ 1.0 V	11.66 ~ 19.85 kg/h
3000 rpm	1.7 ~2.0 V	43.84 ~58.79 kg/h

#### THROTTLE POSITION SENSOR (TPS)

Type: Variable resistor type Specification

Test Condition	Signal Voltage	Throttle Angle
C.T	0.2 ~ 0.8 V	0 ~ 0.5°
W.O.T	4.3 ~ 4.8 V	86°

Test Condition	Resistance (Terminal 1 and 2)	Resistance (Terminal 2 and 3)
C.T	0.71 ~ 1.38 k at all temperature	1.6 ~ 2.4 k at all throttle
W.O.T	2.7 k at all temperature	position

#### HEATED OXYGEN SENSOR (HO2S)

WWW.DIGITALKHODRO.COM

Type: Zirconia Sensor

#### Specificiation

#### Output Voltage: 0 ~ 1 V

Tomporatura	Heater Resistance	
Temperature	Front HO2S	Rear HO2S
20 (68)°C (°F)	9.2	9.2
100 (212)°C (°F)	10.7	10.7
200 (392)°C (°F)	13.1	13.1
300 (572)°C (°F)	14.6	14.6
400 (752)°C (°F)	17.7	17.7
500 (932)°C (°F)	19.2	19.2
600 (1112)°C (°F)	20.7	20.7
700 (1292)°C (°F)	22.5	22.5

#### INTAKE AIR TEMPERATURE SENSOR (IATS)

Type: Thermistor type (built in MAFS) Specificiation

Temperature	Sensor Resistance
-20 (-4) °C (°F)	14.26 ~ 16.02 k
0 (32) °C (°F)	5.50 ~ 6.05 k
20 (68) °C (°F)	2.35 ~ 2.54 k
40 (104) °C (°F)	1.11 ~ 1.19 k
60 (140) °C (°F)	0.57 ~ 0.60 k
80 (176) °C (°F)	0.31 ~ 0.32 k

**FUEL SYSTEM** 

#### FLA -4

### ENGINE COOLANT TEMPERATURE SENSOR (ECTS)

Type: Thermistor type Specificiation

Temperature	Sensor Resistance
-20 (-4) °C (°F)	14.13 ~ 16.83 k
0 (32) °C (°F)	5.79 k
20 (68) °C (°F)	2.31 ~ 2.59 k
40 (104) °C (°F)	1.15 k
60 (140) °C (°F)	0.59 k
80 (176) °C (°F)	0.32 k

#### CVVT OIL TEMPERATURE SENSOR (OTS)

Type: Thermistor type Specificiation

Temperature	Sensor Resistance
-20 (-4) °C (°F)	16.52 k
0 (32) °C (°F)	6.00 k
20 (68) °C (°F)	تال خود <sub>2.45</sub> مانه (۱
40 (104) °C (°F)	1.11 k
60 (140) °C (°F)	0.54 k
80 (176) °C (°F)	0.29 k

#### **KNOCK SENSOR**

Type: Piezoelectric type

#### **VEHICLE (WHEEL) SPEED SENSOR**

Type: Inductive type

#### CAMSHAFT POSITION SENSOR (CMPS)

Type: Hall Effect Sensor Output Voltage (V): 0~5

#### **CRANKSHAFT POSITION SENSOR (CKPS)**

Type: Hall Effect Sensor Output Voltage (V): 0~5

#### OUTPUT ACTUATORS

#### IDLE SPEED CONTROL ACTUATOR (ISCA)

Type: Double coil type Control Frequency: 100Hz Specificiation

#### ISCA ()

Tomporaturo	ISCA Resistance	
Temperature	Coil #1 (CLOSE)	Coil #2 (OPEN)
-20 (-4) °C (°F)	12.1 ~ 13.7	9.2 ~ 10.8
0 (32) °C (°F)	13.4 ~ 15.0	10.2 ~ 11.8
20 (68) °C (°F)	14.5 ~ 16.1	11.1 ~ 12.7
40 (104) °C (°F)	15.7 ~ 17.3	12.0 ~ 13.6
60 (140) °C (°F)	16.9 ~ 18.5	12.9 ~ 14.5
80 (176) °C (°F)	18.0 ~ 19.6	13.8 ~ 15.4

#### CVVT OIL CONTROL VALVE (OCV) [WITH CVVT]

Specificiation

Temperature	OCV Resistance
0 (32) °C (°F)	6.2 ~ 7.4
20 (68) °C (°F)	6.8 ~ 8.0
40 (104) °C (°F)	7.4 ~ 8.6
60 (140) °C (°F)	8.0 ~ 9.2
80 (176) °C (°F)	8.6 ~ 9.8

#### INJECTOR

Type: Electromagnetic type Number: 4 Specificiation

Temperature	Injector Resistance
-20 (-4) °C (°F)	12.2 ~ 12.3
0 (32) °C (°F)	13.3 ~ 13.5
20 (68) °C (°F)	14.4 ~ 14.6
40 (104) °C (°F)	15.5 ~ 15.7
60 (140) °C (°F)	16.6 ~ 16.8
80 (176) °C (°F)	17.7 ~ 17.9

#### WWW.DIGITALKHODRO.COM

#### GENERAL

#### PURGE CONTROL SOLENOID VALVE (PCSV)

Type: Duty Control type Specificiation

Temperature	PCSV Resistance
-20 (-4) °C (°F)	20 ~ 24
0 (32) °C (°F)	22 ~ 26
20 (68) °C (°F)	24 ~ 28
40 (104) °C (°F)	25 ~ 29
60 (140) °C (°F)	27 ~ 31
80 (176) °C (°F)	29 ~ 33

#### **IGNITION COIL**

#### Specificiation

Tomporatura	Ignition Coil		
Temperature	Prima <b>r</b> y Coil	Secondary Coil	
-20 (-4) °C (°F)	0.5	7.7k	
0 (32) °C (°F)	0.54	8.4k	••
20 (68) °C (°F)	ىامانە0.58 سئو	یتال <9.1k رو س	نىركت ديج
40 (104) °C (°F)	0.62	9.8k	
60 (140) °C (°F)	ىميركـ66 خوا	له د ب 10.5k تع	اولين ساماز
80 (176) °C (°F)	0.71	11.2k	

FLA -5



FLA -6

#### FUEL SYSTEM

#### SERVICE STANDARD

Basic Idle rpm (After warm up)	A/C OFF	700±100 rpm	
	A/C ON	850±100 rpm	
Ignition Timing(After warm up, at idle)	BTDC 8°±5°		

#### SEALANTS

Engine Coolant Temperature Sensor (ECTS) assemby	LOCTITE 962T or equivalent
--------------------------------------------------	----------------------------

#### **TIGHTENING TORQUES**

#### ENGINE CONTROL SYSTEM

Items	N∙m	kg∙m	lb•ft
ECU Bracket	4 ~ 6	0.4 ~ 0.6	2.9 ~ 4.3
Heated Oxygen Sensor (HO2S, Sensor 1)	50 ~ 60	5.0 ~ 6.0	36.2 ~ 43.4
Heated Oxygen Sensor (HO2S, Sensor 2)	50 ~ 60	5.0 ~ 6.0	36.2 ~ 43.4
Knock Sensor	17 ~ 27	1.7 ~ 2.7	12.3 ~ 19.5
Oil Temperature Sensor (OTS)	20 ~ 40	2.0 ~ 4.0	14.5 ~ 28.9
Crankshaft Position Sensor (CKPS)	4 ~ 6	0.4 ~ 0.6	2.9 ~ 4.3
Camshaft Position Sensor (CMPS)	4 ~ 6	0.4 ~ 0.6	2.9 ~ 4.3
Engine Coolant Temperature Sensor (ECTS)	15 ~ 20	1.5 ~ 2.0	10.8 ~ 14.5
Throttle Position Sensor (TPS)	كت 2.5 ~ 1.5 ل <	0.15 ~ 0.25	1.1 ~ 1.8
Manifold Absolute Pressure Sensor (MAPS)	4 ~ 6	0.4 ~ 0.6	2.9 ~ 4.3

#### FUEL DELIVERY SYSTEM

Items	N∙m	kg∙m	lb-ft
Fuel tank band installation bolt	40 ~ 55	4.0 ~ 5.5	28.9 ~ 39.8
High pressure hose to delivery pipe	25 ~ 34	2.5 ~ 3.4	18.1 ~ 24.6
Delivery pipe installation	10 ~ 13	1.0 ~ 1.3	7.2 ~ 9.4

#### GENERAL

#### FLA -7

SPECIAL SERVICE TOOLS ED4EAA6C

Tool (Number and name)	Illustration	Application
09353-24100 Fuel Pressure Gauge		Measuring the fuel line pressure
	EFDA003A	
09353-38000 Fuel Pressure Gauge Adapter		Connection between the delivery pipe and fuel feed line
	BF1A025D	
09353-24000 Fuel Pressure Gauge Connector		Connection between Fuel Pressure Gauge (09353-24100) and Fuel Pressure Gauge Adapter (09353-38000)
اران خودرو در ایران	erDA003C و المحمير	

#### FLA -8

3

FUEL SYSTEM

#### BASIC TROUBLESHOOTING EF071F71

#### **BASIC TROUBLESHOOTING GUIDE**

1 Bring Vehicle to Workshop 2 Analyze Customer's Problem Ask the customer about the conditions and environment relative to the issue (Use CUS-٠ TOMER PROBLEM ANALYSIS SHEET).

Verify Symptom, and then Check DTC and Freeze Frame Data

• Connect Hi-Scan (Pro) to Diagnostic Link Connector (DLC).

• Record the DTC and freeze frame data.

#### **NOTE**

To erase DTC and freeze frame data, refer to Step 5.

4	Confirm the Inspection Procedure for the System or Part
•	Using the SYMPTOM TROUBLESHOOTING GUIDE CHART, choose the correct inspection
	procedure for the system or part to be checked.

5 Erase the DTC and Freeze Frame Data

6 Inspect Vehicle Visually

Go to Step 11, if you recognize the problem.

7 Recreate (Simulate) Symptoms the DTC

- Try to recreate or simulate the symptoms and conditions of the malfunction as described by customer.
- If DTC(s) is/are displayed, simulate the condition according to troubleshooting procedure for the DTC.

8 Confirm Symptoms of Problem If DTC(s) is/are not displayed, go to Step 9. If DTC(s) is/are displayed, go to Step 11.

9 Recreate (Simulate) Symptom

Try to recreate or simulate the condition of the malfunction as described by the customer.

#### 10 Check the DTC If DTC(s) does(do) not occur, refer to BASIC INSPECTION in INTERMITTENT PROBLEM PROCEDURE. If DTC(s) occur(s), go to Step 11.

11 Perform troubleshooting procedure for DTC

12 Adjust or repair the vehicle

13 Confirmation test

#### WWW.DIGITALKHODRO.COM

#### GENERAL

END

14

FLA -9

#### CUSTOMER PROBLEM ANALYSIS SHEET

#### 1. VEHICLE INFORMATION

(I) VIN:
(II) Production Date:
(III) Odometer Reading: (km)

#### 2. SYMPTOMS

Unable to start	Engine does not turn over Incomplete combustion Initial combustion does not occur	
Difficult to start	Engine turns over slowly Other	
Poor idling	Rough idling Incorrect idling Unstable idling (High: rpm, Low:rpm) Other	
Engine stall	Soon after starting After accelerator pedal depressed After accelerator pedal released During A/C ON Shifting from N to D-range Other	
مانه (مسئولیت Others	Poor driving (Surge) Knocking Poor fuel economy Back fire After fire Other	

#### 3. ENVIRONMENT اولین سامانه دیجیتال تعمیر کاران خو

Problem frequency	Constant Sometimes () Once only Other
Weather	Fine Cloudy Rainy Snowy Other
Outdoor temperature	Approx °C/°F
Place	Highway Suburbs Inner City Uphill Downhill Rough road Other
Engine temperature	Cold Warming up After warming up Any temperature
Engine operation	Starting Just after starting ( min) Idling Racing Driving Constant speed Acceleration Deceleration A/C switch ON/OFF Other

#### 4. MIL/DTC

MIL (Malfunction Indicator Lamp)	Remains ON	Sometimes lights up	Does not light	
DTC	Normal DTC Freeze Frame	·		)

**FUEL SYSTEM** 

#### FLA -10

#### BASIC INSPECTION PROCEDURE

### MEASURING CONDITION OF ELECTRONIC PARTS' RESISTANCE

The measured resistance at high temperature after vehicle running may be high or low. So all resistance must be measured at ambient temperature (20, 68), unless there is any notice.

#### 🔟 ΝΟΤΕ

The measured resistance in except for ambient temperature (20 , 68 ) is reference value.

### INTERMITTENT PROBLEM INSPECTION PROCEDURE

Sometimes the most difficult case in troubleshooting is when a problem symptom occurs but does not occur again during testing. An example would be if a problem appears only when the vehicle is cold but has not appeared when warm. In this case, technician should thoroughly make out a "CUSTOMER PROBLEM ANALYSIS SHEET" and recreate (simulate) the environment and condition which occurred when the vehicle was having the issue.

- 1. Clear Diagnostic Trouble Code (DTC).
- Inspect connector connection, and check terminal for poor connections, loose wires, bent, broken or corroded pins, and then verify that the connectors are always securely fastened.

5. Verify that the problem has disappeared with the road test.

#### SIMULATING VIBRATION

 a. Sensors and Actuators
 : Slightly vibrate sensors, actuators or relays with finger.

#### 😵 WARNING

Strong vibration may break sensors, actuators or relays

b. Connectors and Harness: Lightly shake the connector and wiring harness vertically and then horizontally.

#### SIMULATING HEAT

a. Heat components suspected of causing the malfunction with a hair dryer or other heat sourre.

#### 😵 WARNING

- DO NOT heat components to the point where they may be damaged.
- DO NOT heat the ECM directly.
- SIMULATING WATER SPRINKLING
- Sprinkle water onto vehicle to simulate a rainy day or a high humidity condition.

#### 😵 WARNING

а.

**DO NOT** sprinkle water directly into the engine compartment or electronic components.

#### SIMULATING ELECTRICAL LOAD

a. Turn on all electrical systems to simulate excessive electrical loads (Radios, fans, lights, etc.).

EGQE601B

- 3. Slightly shake the connector and wiring harness vertically and horizontally.
- 4. Repair or replace the component that has a problem.



#### 021-62999292

FLA -11

#### GENERAL

b.

#### CONNECTOR INSPECTION PROCEDURE

- 1. Handling of Connector
  - a. Never pull on the wiring harness when disconnecting connectors.
- .CLICK

c.

Listen for a click when locking connectors. This

sound indicates that they are securely locked.

EGQE601E

- d. When a tester is used to check for continuity, or to measure voltage, always insert tester probe from wire harness side.
- ولین سامانه دیجیتال تعمیرکاران خودرو در ایران

When removing the connector with a lock, press

or pull locking lever. تال خودرو سامانه

EGQE601F

EGQE601D

EGQE601C

WWW.DIGITALKHODRO.COM

#### 021-62999292

**FUEL SYSTEM** 

#### <u>FLA</u> -12

- e. Check waterproof connector terminals from the connector side. Waterproof connectors cannot be accessed from harness side.
- d. Pull lightly on individual wires to ensure that each wire is secured in the terminal.





EGQE601H

EGQE601G



- Use a fine wire to prevent damage to the terminal.
- Do not damage the terminal when inserting the tester lead.

#### 2. Checking Point for Connector

- a. While the connector is connected: Hold the connector, check connecting condition and locking efficiency.
- When the connector is disconnected: Check missed terminal, crimped terminal or broken core wire by slightly pulling the wire harness. Visually check for rust, contamination, deformation and bend.
- c. Check terminal tightening condition: Insert a spare male terminal into a female terminal, and then check terminal tightening conditions.

3. Repair Method of Connector Terminal

a. Clean the contact points using air gun and/or shop rag.

**NOTE** 

Never use sand paper when polishing the contact points, otherwise the contact point may be damaged.

b. In case of abnormal contact pressure, replace the female terminal.

#### WIRE HARNESS INSPECTION PROCEDURE

- 1. Before removing the wire harness, check the wire harness position and crimping in order to restore it correctly.
- 2. Check whether the wire harness is twisted, pulled or loosened.
- 3. Check whether the temperature of the wire harness is abnormally high.
- 4. Check whether the wire harness is rotating, moving or vibrating against the sharp edge of a part.
- 5. Check the connection between the wire harness and any installed part.
- 6. If the covering of wire harness is damaged; secure, repair or replace the harness.

#### 021-62999292

FLA -13

#### GENERAL

#### ELECTRICAL CIRCUIT INSPECTION PROCEDURE

#### CHECK OPEN CIRCUIT

- 1. Procedures for Open Circuit
  - Continuity Check
  - Voltage Check

If an open circuit occurs (as seen in [FIG. 1]), it can be found by performing Step 2 (Continuity Check Method) or Step 3 (Voltage Check Method) as shown below. In [FIG.2.] the measured resistance of line 1 and 2 is higher than  $1M\Omega$  and below 1 respectively. Specifically the open circuit is line 1 (Line 2 is normal). To find exact break point, check sub line of line 1 as described in next step.





When measuring for resistance, lightly shake the wire harness above and below or from side to side.

Specification (Resistance)1 or lessNormal Circuit1 MΩ or HigherOpen Circuit

a. Disconnect connectors (A), (C) and measure resistance between connector (A) and (C) as shown in [FIG. 2].

#### 021-62999292

**FUEL SYSTEM** 

#### FLA -14

3.

b. Disconnect connector (B), and measure for resistance between connector (C) and (B1) and between (B2) and (A) as shown in [FIG. 3].

In this case the measured resistance between connector (C) and (B1) is higher than  $1M\Omega$  and the open circuit is between terminal 1 of connector (C) and terminal 1 of connector (B1).

The measured voltage of each connector is 5V, 5V and 0V respectively. So the open circuit is between connector (C) and (B).



a. With each connector still connected, measure the voltage between the chassis ground and terminal 1 of each connectors (A), (B) and (C) as shown in [FIG. 4].

If short to ground circuit occurs as shown in [FIG. 5], the broken point can be found by performing below Step 2 (Continuity Check Method with Chassis Ground) as shown below.

FIG. 5



EGQE600L

**FLA -15** 

#### GENERAL

2. Continuity Check Method (with Chassis Ground)

#### 🔟 ΝΟΤΕ

Lightly shake the wire harness above and below, or from side to side when measuring the resistance.

Specification (Resistance) 1 or less Short to Ground Circuit 1M or Higher Normal Circuit

a. Disconnect connectors (A), (C) and measure for resistance between connector (A) and Chassis Ground as shown in [FIG. 6].

The measured resistance of line 1 and 2 in this example is below 1 and higher than 1M respectively. Specifically the short to ground circuit is line 1 (Line 2 is normal). To find exact broken point, check the sub line of line 1 as described in the following step. The measured resistance between connector (B1) and chassis ground is 1 or less. The short to ground circuit is between terminal 1 of connector (C) and terminal 1 of connector (B1).





EGQE600M

Disconnect connector (B), and measure the resistance between connector (A) and chassis ground, and between (B1) and chassis ground as shown in [FIG. 7].

#### FLA -16

#### FUEL SYSTEM

#### SYMPTOM TROUBLESHOOTING GUIDE CHART

MAIN SYMPTOM	DIAGNOSTIC PROCEDURE	ALSO CHECK FOR
Unable to start (Engine does not turn over)	<ol> <li>Test the battery</li> <li>Test the starter</li> <li>Inhibitor switch (A/T) or clutch start switch (M/T)</li> </ol>	
Unable to start (Incomplete combustion)	<ol> <li>Test the battery</li> <li>Check the fuel pressure</li> <li>Check the ignition circuit</li> <li>Troubleshooting the immobilizer system (In case of immobilizer lamp ON)</li> </ol>	<ul> <li>DTC</li> <li>Low compression</li> <li>Intake air leaks</li> <li>Slipped or broken timing belt</li> <li>Contaminated fuel</li> </ul>
Difficult to start	<ol> <li>Test the battery</li> <li>Check the fuel pressure</li> <li>Check the ECT sensor and circuit (Check DTC)</li> <li>Check the ignition circuit</li> </ol>	<ul> <li>DTC</li> <li>Low compression</li> <li>Intake air leaks</li> <li>Contaminated fuel</li> <li>Weak ignition spark</li> </ul>
Poor idling (Rough, unstable or incorrect Idle)	<ol> <li>Check the fuel pressure</li> <li>Check the Injector</li> <li>Check the long term fuel trim and short term fuel trim (Refer to CUSTOMER DATASTREAM)</li> <li>Check the ISCA and ISCA circuit (Check DTC)</li> <li>Inspect and test the Throttle Body</li> <li>Check the ECT sensor and circuit (Check DTC)</li> </ol>	<ul> <li>DTC</li> <li>Low compression</li> <li>Intake air leaks</li> <li>Contaminated fuel</li> <li>Weak ignition spark</li> </ul>
Engine stall	<ol> <li>Test the Battery</li> <li>Check the fuel pressure</li> <li>Check the ISCA and ISCA circuit (Check DTC)</li> <li>Check the ignition circuit</li> <li>Check the CKPS Circuit (Check DTC)</li> </ol>	<ul> <li>DTC</li> <li>Intake air leaks</li> <li>Contaminated fuel</li> <li>Weak ignition spark</li> </ul>
ودرو در ایران Poor driving (Surge)	<ol> <li>Check the fuel pressure of the larged by the second second</li></ol>	<ul> <li>DTC</li> <li>Low compression</li> <li>Intake air leaks</li> <li>Contaminated fuel</li> <li>Weak ignition spark</li> </ul>
Knocking	<ol> <li>Check the fuel pressure</li> <li>Inspect the engine coolant</li> <li>Inspect the radiator and the electric cooling fan</li> <li>Check the spark plugs</li> </ol>	<ul><li>DTC</li><li>Contaminated fuel</li></ul>

#### GENERAL

FLA -17

MAIN SYMPTOM	DIAGNOSTIC PROCEDURE	ALSO CHECK FOR
Poor fuel economy	<ol> <li>Check customer's driving habits         <ul> <li>Is A/C on full time or the defroster mode on?</li> <li>Are tires at correct pressure?</li> <li>Is excessively heavy load being carried?</li> <li>Is acceleration too much, too often?</li> </ul> </li> <li>Check the fuel pressure</li> <li>Check the injector</li> <li>Test the exhaust system for a possible restriction</li> <li>Check the ECT sensor and circuit</li> </ol>	<ul> <li>DTC</li> <li>Low compression</li> <li>Intake air leaks</li> <li>Contaminated fuel</li> <li>Weak ignition spark</li> </ul>
Hard to refueling (Overflow during refueling)	<ol> <li>Inspect the fuel filler hose/pipe         <ul> <li>Pinched, kinked or blocked?</li> <li>Filler hose is torn</li> </ul> </li> <li>Inspect the fuel tank vapor vent hose between the EVAP. canister and air filter</li> <li>Check the EVAP. canister</li> </ol>	<ul> <li>Malfunctioning gas station filling nozzle (If this problem occurs at a specific gas station during refueling)</li> </ul>

**حیجیتال خودرو س**امانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

**FUEL SYSTEM** 

#### FLA -18

### GASOLINE ENGINE CONTROL SYSTEM

## ENGINE CONTROL MODULE (ECM)

#### DESCRIPTION E5FAF6EE

If the Gasoline Engine Control system components (sensors, ECM, injector, etc.) fail, interruption to the fuel supply or failure to supply the proper amount of fuel for various engine operating conditions will result. The following situations may be encountered.

- 1. Engine is hard to start or does not start at all.
- 2. Unstable idle.
- 3. Poor driveability

If any of the above conditions are noted, first perform a routine diagnosis that includes basic engine checks (ignition system malfunction, incorrect engine adjustment, etc.). Then, inspect the Gasoline Engine Control system components with the HI-SCAN (Pro).

#### **NOTE**

- Before removing or installing any part, read the diagnostic trouble codes and then disconnect the battery negative (-) terminal.
- Before disconnecting the cable from battery terminal, turn the ignition switch to OFF. Removal or connection of the battery cable during engine operation or while the ignition switch is ON could cause damage to the ECM.
- The control harnesses between the ECM and heated oxygen sensor are shielded with the shielded ground wires to the body in order to prevent the influence of ignition noises and radio interference. When the shielded wire is faulty, the control harness must be replaced.
- When checking the generator for the charging state, do not disconnect the battery '+' terminal to prevent the ECM from damage due to the voltage.
- When charging the battery with the external charger, disconnect the vehicle side battery terminals to prevent damage to the ECM.

#### MALFUNCTION INDICATOR LAMP (MIL)

#### [EOBD]

A malfunction indicator lamp illuminates to notify the driver that there is a problem with the vehicle. However, the MIL

will go off automatically after 3 subsequent sequential driving cycles without the same malfunction. Immediately after the ignition switch is turned on (ON position - do not start), the MIL will illuminate continuously to indicate that the MIL operates normally.

Faults with the following items will illuminate the MIL.

- Catalyst
- Fuel system
- Mass Air Flow Sensor (MAFS)
- Intake Air Temperature Sensor (IATS)
- Engine Coolant Temperature Sensor (ECTS)
- Throttle Position Sensor (TPS)
- Upstream Oxygen Sensor
- Upstream Oxygen Sensor Heater
- Downstream Oxygen Sensor
- Downstream Oxygen Sensor Heater
- Injector
- Misfire
- Crankshaft Position Sensor (CKPS)
- Camshaft Position Sensor (CMPS)
- Evaporative Emission Control System
- Vehicle Speed Sensor (VSS)
- Idle Speed Control Actuator (ISCA)
- Power Supply
- ECM
- MT/AT Encoding
- Acceleration Sensor
- MIL-on Request Signal
- Power Stage

Refer to "INSPECTION CHART FOR DIAGNOSTIC TROUBLE CODES (DTC)" for more information.



EGQE601P

### WWW.DIGITALKHODRO.COM

#### 021- 62 99 92 92

#### [NON-EOBD]

A malfunction indicator lamp illuminates to notify the driver that there is a problem with the vehicle. However, the MIL will go off automatically after 3 subsequent sequential driving cycles without the same malfunction. Immediately after the ignition switch is turned on (ON position - do not start), the MIL will illuminate continuously to indicate that the MIL operates normally.

Faults with the following items will illuminate the MIL

- Heated oxygen sensor (HO2S)
- Mass Air Flow sensor (MAFS)
- Throttle position sensor (TPS)
- Engine coolant temperature sensor (ECTS)
- Idle speed control actuator (ISCA)
- Injectors
- ECM

#### 🔟 ΝΟΤΕ

Refer to "INSPECTION CHART FOR DIAGNOSTIC TROUBLE CODES (DTC)" for more information.

MIL or HI-SCAN (Pro). Diagnostic Trouble Codes (DTC) will remain in the ECM as long as battery power is maintained. The diagnostic trouble codes will, however, be erased when the battery terminal or ECM connector is disconnected, or by the HI-SCAN (Pro).



If a sensor connector is disconnected with the ignition switch turned on, the diagnostic trouble code (DTC) is recorded. In this case, disconnect the battery negative terminal (-) for 15 seconds or more, and the diagnosis memory will be erased.





EGQE601P

#### [INSPECTION]

- 1. After turning ON the ignition key, ensure that the light illuminates for about 5 seconds and then goes out.
- 2. If the light does not illuminate, check for an open circuit in the harness, a blown fuse or a blown bulb.

#### SELF-DIAGNOSIS

The ECM monitors the input/output signals (some signals at all times and the others under specified conditions). When the ECM detects an irregularity, it records the diagnostic trouble code, and outputs the signal to the Data Link connector. The diagnosis results can be read with the

#### FLA -19

#### FLA -20

**FUEL SYSTEM** 

#### THE RELATION BETWEEN DTC AND DRIVING PATTERN IN EOBD SYSTEM



- 1. When the same malfunction is detected and maintained during two sequential driving cycles, the MIL will automatically illuminate.
- 2. The MIL will go off automatically if no fault is detected after 3 sequential driving cycles.
- 3. A Diagnostic Trouble Code(DTC) is recorded in ECM memory when a malfunction is detected after two sequential driving cycles. The MIL will illuminate when the malfunction is detected on the second driving cycle.

If a misfire is detected, a DTC will be recorded, and the MIL will illuminate, immediately after a fault is first detected.

4. A Diagnostic Trouble Code(DTC) will automatically erase from ECM memory if the same malfunction is not detected for 40 driving cycles.



 A "warm-up cycle" means sufficient vehicle operation such that the coolant temperature has risen by at least 40 degrees Fahrenheit from engine starting and reaches a minimum temperature of 160 degress Fahrenheit. • A "driving cycle" consists of engine startup, vehicle operation beyond the beginning of closed loop operation.

#### FLA -21

#### COMPONENTS LOCATION E9AC348E



EGQE601R

### 021- 62 99 92 92

#### FLA -22

#### FUEL SYSTEM



#### WWW.DIGITALKHODRO.COM

FLA -23



#### FLA -24

#### **FUEL SYSTEM**

021-62999292



**Cپچیپال حورو** سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

#### WWW.DIGITALKHODRO.COM

#### 1. ECM HARNESS CONNECTOR ECB5E1FB

																								G					
	1	2	81	80	79	78	77	76	75	74	73	72	71	70	69	68	67	66	65	64	63	1	K	51°				ĥ	
1 7			62	61	60	59	58	57	56	55	54	53	52	51	50	49	48	47	46	45	44	1						IЬ	
	3	3	43	42	41	40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25		K	기倂	_			Ϋ́O	1
ГП	4	5	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6			/6/				[/]9	
-							ECN	ИΗ	arne	ss (	Side	Со	nne	ctor								-			4r	è			

LGGE010A

#### 2. ECM TERMINAL FUNCTION

Pin No.	Description	Connected to	Remark
1	ECM ground	Chassis ground	
2	Power stage ground	Chassis ground	
3	Direct battery voltage supply	Battery	
4	Ignition coil output 1,4	Ignition Coil #1, 4	
5	Ignition coil output 2,3	Ignition Coil #2, 3	
6	CAN LOW	Other control modules (TCM, ABS, etc.)	
7	CAN HIGH	Other control modules (TCM, ABS, etc.)	
(28)2	HO2S Heater (B1/S1)	HO2S (B1/S1)	Except for LEADED
9	HO2S Heater (B1/S2)	HO2S (B1/S2)	EOBD ONLY
10	Knock Sensor Input	Knock Sensor	
11	CVVT Oil Control Valve output	CVVT Oil Control Valve	
12	Not connected	-	
13	Not connected	-	
14	Battery Voltage Supply after Main Relay	Main Relay	
15	Not connected	-	
16	Not connected	-	
17	Wheel Speed Sensor (-)	Wheel Speed Sensor	
18	Wheel Speed Sensor (+)	Wheel Speed Sensor	
19	Not connected	-	
20	Not connected	-	
21	Battery Voltage Supply after Main Relay	Main Relay	
22	Battery Voltage Supply after Ignition Key	Ignition Key	
23	Injector output (cyl. 4)	Injector (cyl. 4)	
24	Injector output (cyl. 1)	Injector (cyl. 1)	
25	Spare Sensor supply	Sensors	
26	Purge Control Solenoid Valve (PCSV) PWM output	Purge Control Solenoid Valve (PCSV)	

#### WWW.DIGITALKHODRO.COM

FLA -25

021-62 99 92 92

FLA -26

FUEL SYSTEM

Pin No.	Description	Connected to	Remark
27	Crankshaft Position Sensor ground	Crankshaft Position Sensor	
28	Not connected	-	
29	Crankshaft Position Sensor input	Crankshaft Position Sensor	
30	Camshaft Position Sensor ground	Camshaft Position Sensor	
31	Engine Coolant Temperature Sensor input	Engine Coolant Temperature Sensor	
32	Throttle Position Sensor input	Throttle Position Sensor	
33	Not connected	-	
34	Not connected	-	
35	Not connected	-	
36	Not connected	-	
37	HO2S (B1/S2) ground	HO2S (B1/S2)	
38	Throttle Position Sensor ground	Throttle Position Sensor	
	Vehicle Speed Sensor input	Vehicle Speed Sensor	Without ABS
39	Wheel Speed Sensor input	Wheel Speed Sensor	With ABS
40	Not connected		
41	Not connected		
42	HO2S (B1/S2) input	HO2S (B1/S2)	EOBD ONLY
43	HO2S (B1/S1) input	HO2S (B1/S1)	Except for LEADED
44	MAFS, IATS supply	MAFS, IATS	
45	Throttle Position Sensor supply	Throttle Position Sensor	
46	Spare Sensor supply 2	Sensors	
47	Immobilizer Data Line	Immobilizer	With Immobilizer
48	MAFS, IATS ground	MAFS, IATS	
49	Not connected	-	
50	Air Conditioner Compressor Switch input	Triple Switch	
51	Air Conditioner Pressure switch input	Triple Switch	
52	Oil Temperature Sensor input	Oil Temperature Sensor	
53	Not connected	-	
54	Knock Sensor ground	Knock Sensor	
55	Ignition shield ground	Ignition Coil	
56	Intake Air Temperature Sensor input	MAFS, IATS	
57	Not connected	-	
58	Air Conditioner Request Switch input	Air Conditioner Request Switch	
59	HO2S (B1/S1) ground	HO2S (B1/S1)	Except for LEADED
60	Mass Air Flow Sensor signal input	MAFS	
61	Injector output (cyl.3)	Injector (cyl.3)	

#### WWW.DIGITALKHODRO.COM

FLA -27

Pin No.	Description	Connected to	Remark
62	Injector output (cyl.2)	Injector (cyl.2)	
63	Not connected	-	
64	Cooling Fan Relay - High control output	Cooling Fan Relay	
65	Cooling Fan Relay - Low control output	Cooling Fan Relay	
66	Engine Speed signal output	Tachometer	
67	Main Relay control output	Main Relay	
68	Air Conditioner Compressor Relay control output	Air Conditioner Compressor Relay	
69	Electric Fuel Pump Relay control output	Electric Fuel Pump Relay	
70	Malfunction Indicating Lamp (MIL) output	Malfunction Indicating Lamp (MIL)	
71	Immobilizer ground	Immobilizer	With Immobilizer
72	Camshaft Position Sensor input	Camshaft Position Sensor	
73	Engine Coolant Temperature Sensor ground	Engine Coolant Temperature Sensor	
74	Throttle Position PWM output		
75	Fuel Consumption signal output	Trip Computer	
76	Oil Temperature Sensor ground	Oil Temperature Sensor	
77	Diagnostic Data Line (k-Line)	Data Link Conector (DLC)	
78	Idle Speed Control Actuator PWM output 2 (CLOSE)	Idle Speed Control Actuator	
79	Not connected a literation	اولىن سامانە	
80	Idle Speed Control Actuator PWM output 1 (OPEN)	Idle Speed Control Actuator	
81	Immobilizer Lamp output	Immobilizer	With Immobilizer

#### 3. ECM TERMINAL INPUT/OUTPUT SIGNAL

Pin	Description	Inp	out, Output Value	Vehicle State	Test Result
No.	Description	Туре	Range	venicie State	lest Result
1	ECM ground	Static Signal	0 ~ 0.5V	Always	0.3V
2	Power stage ground	Static Signal	0 ~ 0.5V	Always	0.3V
3	Direct battery voltage Static vbatt		Others	12.5 V (Vbatt Level)	
3			Running	13.7 V (Vbatt Level)	

#### 021-62 99 92 92

FLA -28

FUEL SYSTEM

Pin	Description	Inp	out, Output Value	Vehicle State	Test Result
No.	Description	Туре	Range		
4	Ignition coil output 1,4	Pulse	Above 350 V Vbatt Below 1.6 V BFGE501M	Engine run	High: 14.03V Low: 0.78~1.13V Peak voltage: 348V Idle : 17.2Hz
5	Ignition coil output 2,3	Pulse	Above 350 V Vbatt Below 1.6 V BFGE501M	Engine run	High: 14.03V Low: 0.78~1.13V Peak voltage: 348V Idle : 17.2Hz
			2.0 ~ 3.0V	Recessive	
6	CAN LOW	DC (PWM)	0.5 ~ 2.25V	Dominant	2.5 V 1.5 V BFGE501U
(20	(مسئوليت محدر	رو سامانه	2.0 ~ 3.0V	Recessive	
7	CAN HIGH	DC (PWM)	اولين 2.75-4.5v بحينا	Dominant	2.5 V 1.5 V BFGE501U
8	HO2S Heater (B1/S1)	PWM	Ubatt 0 ~ 0.5 V BFGE501N	Engine run	High: 14.01V Low: 0.4V Frequency:10Hz
9	HO2S Heater (B1/S2)	PWM	Ubatt 0 ~ 0.5 V BFGE501N	Engine run	High: 14.01V Low: 0.4V Frequency:10Hz
			-0.5 ~ 0.7V	Knocking	0.3V
10	Knock Sensor Input	Frequency		5	

#### WWW.DIGITALKHODRO.COM

FLA -29

Pin	Description	Inp	out, Output Value	Vehicle State	Test Result
No.	Decemption	Туре	Range		
11	CVVT Oil Control Valve output	PWM	Ubatt 0 ~ 0.5 V BFGE501N	Engine run	High: 14.01V Low: 0.4V Frequency: 300Hz
12	Not connected				
13	Not connected				
14	Battery Voltage Supply after Main Relay	DC	Vbatt	IG ON	12.7V
	-		0 ~ 0.5V	IG OFF	0.3V
15	Not connected				
16	Not connected				
17	Wheel Speed Sensor(-)	Sensor signal	Approximately 50rpm: 37Hz, 236mV (Peak to Peak) 100rpm: 76Hz, 376mV (Peak to Peak) 1000rpm: 769Hz, 1.64V (Peak to Peak)	Vehicle run	BFGE501W
18	Wheel Speed Sensor(+)	Sensor signal	Approximately 50rpm: 37Hz, 236mV (Peak to Peak) 100rpm: 76Hz, 376mV (Peak to Peak) 1000rpm: 769Hz, 1.64V (Peak to Peak)	Vehicle run	BFGE501X
19	Not connected				
20	Not connected				
21	Battery Voltage Supply after Main Relay	Static Signal	Vbatt 0 ~ 0.5V	IG ON IG OFF	12.7V 0.3V
22	Battery Voltage Supply	Static	Vbatt	IG ON	12.7V
	after Ignition Key	Signal	0 ~ 0.5V	IG OFF	0.3V
23	Injector output (cyl. 4)	Frequency	Below 1 V BFGE5010	ldle: 6.25Hz 3000rpm: 12.6Hz	High: 14.01V Low: 0.3V Peak voltage: 58V

#### 021-62999292

FLA -30

FUEL SYSTEM

Pin	Description	Inp	out, Output Value	Vehicle State	Test Result
No.	Description	Туре	Range	Venicle State	Test Result
24	Injector output (cyl. 1)	Frequency	Below 1 V BFGE5010	ldle: 6.25Hz 3000rpm: 12.6Hz	High: 14.01V Low: 0.3V Peak voltage: 58V
		Ctatia	Vcc	IG ON	5V
25	Spare Sensor supply	Static Signal	0 ~ 0.5V	IG OFF	0.3V
26	Purge Control Solenoid Valve (PCSV) PWM output	PWM Pulse	0 ~ 1 V BFGE501P	Inactive Active (after warm up & racing)	High: 14.01V Low: 0.3V Frequency: 20Hz
	Crankshaft Position	Static			0
27	Sensor ground	Signal	0 ~ 0.5V	Always	0.2 V
28	Not connected				
(20	(مستوليت محدر	روسمانه	سرخت دیجیتان خود	Idle: 740Hz	5V
29	Crankshaft Position Sensor input	Frequency	Below 0.5 V	3000rpm: 3126Hz	0.3V
30	Camshaft Position	Static		Always	
31	Sensor ground Engine Coolant Temperature Sensor input	Signal Analog	-40 ~ 145 4.9V ~ 0.322V	80 [176 ]	1.25V
32	Throttle Position Sensor input	Analog	0.25 ~ 0.8V	Idle	0.3V
22		-	4.15 ~ 4.7V	W.O.T	4.16V
33	Not connected				
34	Not connected				
35	Not connected				
36	Not connected	<b>0</b> (1)			
37	HO2S (B1/S2) ground	Static Signal	0 ~ 0.5V	Always	0.3V
38	Throttle Position Sensor ground	Static Signal	0 ~ 0.5V	Always	0.3V

#### WWW.DIGITALKHODRO.COM

FLA -31

Pin	Description	Inp	out, Output Value	Vehicle State	Test Result
No.	Description	Туре	Range		
39	Vehicle Speed Sensor input	Pulse	BFGE501Q	Vehicle run	High : 5V Low : 0.9V
40	Not connected				
41	Not connected				
42	HO2S (B1/S2) input	Analog Pulse	0.8 V 0.1 V BFGE501R	3000rpm After warm up	0.8V 0.1V Frequency: 1.1Hz
		Analog	RICH : 0.6 ~ 1.0 V		0.746 V
43	HO2S (B1/S1) input	Pulse	LEAN : Max. 0.4 V	Engine run	0.081 V
44	Not connected		•• • ••		
45	Throttle Position	Static	شرکت د <sub>5</sub> ۷ بیتال خود	IG ON	4.9V
40	Sensor supply	Signal	0 ~ 0.5V	IG OFF	0.4V
46	Spare Sensor supply 2	Static	اولین سا <sub>5</sub> ۷ نه دیجیت	IG ON	5V
-10		Signal	0 ~ 0.5V	IG OFF	0.3V
47	Immobilizer Data Line	Pulse	High : Min. 8.5 V Low : Max. 3.5 V	When communicating after IG ON.	11.625 V 0.187 V
48	MAFS, IATS ground	Static Signal	0 ~ 0.5V	Always	0.4 V
49	Not connected				
	Air Conditioner		Vbatt	SW ON	13V
50	Compressor Switch input	DC	0 ~ 0.5V	SW OFF	0.3V
51	Air Conditioner	DC	Vbatt	SW ON	12.9V
51	Pressure switch input		0 ~ 0.5V	SW OFF	0.4V
52	Oil Temperature Sensor input	Analog	-40 ~ 130 4.9V ~ 0.4V	84 [183.2 ]	1.29V
53	Not connected				
54	Knock Sensor ground	Static Signal	0 ~ 0.5V	Always	0.3V
55	Ignition shield ground	Static Signal	0 ~ 0.5V	Always	0.3V

#### WWW.DIGITALKHODRO.COM

FLA -32

#### FUEL SYSTEM

Pin	Description	Ing	out, Output Value	Vehicle State	Test Result
No.		Туре	Range	venicie State	IESI NESUIL
56	Intake Air Temperature Sensor input	Analog	-40 ~ 266 4.9V ~ 0.34 V	Idle	3.26 V (33 [91.4 ])
57	Not connected				
58	Air Conditioner	DC	Vbatt	SW ON	12.9V
50	Request Switch input	DC	0 ~ 0.5 V	SW OFF	0.4V
59	HO2S (B1/S1) ground	DC	Max. 50 mV	ldle	2.5 mV
60	Mass Air Flow Sensor	Analog	0 ~ 2.0 V	ldle	1.0V
00	signal input	Analog	1.0 ~ 4.5 V	3000 rpm	2.3V
61	Injector output (cyl.3)	Frequency	Below 1 V BFGE5010	Idle: 6.25Hz 3000rpm: 12.6Hz	High: 14.01V Low: 0.3V Peak voltage: 58V
-			BrGESUIO		0
9					2 .
62	Injector output (cyl.2)	Frequency	Below 1 V	Idle: 6.25Hz 3000rpm: 12.6Hz	High: 14.01V Low: 0.3V Peak voltage: 58V
	ر <mark>ان خودرو در</mark> ایران	ں تعمیر کا	BFGE5010	0-0	
63	Not connected				
64	Cooling Fan Relay -	DC	Vbatt	SW OFF	12.9V
04	High control output	DC		SW ON	0.4V
65	Cooling Fan Relay -	DC	Vbatt	SW OFF	13V
00	Low control output	DC		SW ON	0.5V
66	Engine Speed signal output	Frequency	BFGE501S	Engine run	High: 10.5V Low: 0.4V Idle: 24.7Hz 3000 rpm: 104.6Hz
07	Main Relay control	D2	0 ~ 1V	IG ON	0.9V
67	output	DC	Vbatt	IG OFF	13.5V
	Air Conditioner		0 ~ 0.5V	A/C ON	0.2V
68	Compressor Relay control output	DC	Vbatt	A/C OFF	12.5V
69	Fuel Pump Relay	DC	Vbatt	IG ON	13.08V
09	control output		0 ~ 0.5V	ldle	0.3V
70	Malfunction Indicator	DC	0 ~ 0.5V	IG ON	0.4V
70 Lamp (MIL) output			Vbatt	Vbatt	13.6V

#### WWW.DIGITALKHODRO.COM

FLA -33

Pin	Description	Input, Output Value		Vehicle State	Test Result
No.		Туре	Range	venicie State	lest Result
71	Immobilizer ground	Static Signal	0 ~ 0.5V	Always	0.4V
72	Camshaft Position Sensor input	Frequency	4.5~5.5 V 0 ~ 0.5 V BFGE501T	Idle: 6.3 Hz 3000 rpm: 25 Hz	High: 5V Low: 0.6V
73	Engine Coolant Temperature Sensor ground	Static Signal	0 ~ 0.5V	Always	0.4V
74	Throttle Position PWM output	PWM	BFGE501S	Engine run	High: 12.75V Low: 0.5V Frequency: 100Hz C.T: 5% duty W.O.T : 90% duty
75	Fuel Consumption signal output	PWM	Below 0.5 V	Engine run	High: 12.75V Low: 0.5V Frequency: 100Hz
76	Oil Temperature Sensor ground	Static Signal	0 ~ 0.5V	Always	0.4V
L C	ناران خودرو در ایرا	ال تعميره	Vbatt	0	
77	Diagnosis line (k-line)	Pulse	0 ~ 0.5 V	IG ON	High: 14V Low: 0.5V
			BFGE501N		
78	Idle Speed Control Actuator PWM output2	PWM	BFGE501S	ldle	High : 15V Low : 0.3V Frequency: 250Hz
79	Not connected				
80	Idle Speed Control Actuator PWM output1	PWM	BFGE501S	Idle	High : 15V Low : 0.3V Frequency: 250Hz
	Immobilizer Lamp		0 ~ 0.5V	IG ON	0.4V
81	output	DC	Vbatt	Cranking	13.6V

#### WWW.DIGITALKHODRO.COM

#### 021-62999292

FUEL SYSTEM

#### FLA -34

CIRCUIT DIAGRAM EOB25FA2



EGQE401J

#### WWW.DIGITALKHODRO.COM

FLA -35



EGQE401K

#### 021-62999292

FLA -36

#### **FUEL SYSTEM**



#### WWW.DIGITALKHODRO.COM
EFUE521

### GASOLINE ENGINE CONTROL SYSTEM

#### ECM PROBLEM INSPECTION PROCEDURE

1. TEST ECM GROUND CIRCUIT: Measure resistance between ECM and chassis ground using the backside of ECM harness connector as ECM side check point. If the problem is found, repair it.

Specification (Resistance)
Between terminal 1 of C230-1 connector and
chassis ground : 1 or less
Between terminal 2 of C230-1 connector and
chassis ground : 1 or less



ECM Harness Side Connector

- 2. TEST ECM CONNECTOR: Disconnect the ECM connector and visually check the ground terminals on ECM side and harness side for bent pins or poor contact contact pressure. If the problem is found, repair
- بیتال خودرو سامانه (مسئولیت محد<sup>ا</sup>ود)
- 3. If problem is not found in Step 1 and 2, the ECM could be faulty. If so, replace the ECM with a new one, and then check the vehicle again. If the vehicle operates normally then the problem was likely with the ECM.
- RE-TEST THE ORIGINAL ECM : Install the original ECM (may be broken) into a known-good vehicle and check the vehicle. If the problem occurs again, replace the original ECM with a new one. If problem does not occur, this is intermittent problem (Refer to INTERMITTENT PROBLEM PROCEDURE in BASIC INSPECTION PROCEDURE)

#### FUEL SYSTEM

# DTC TROUBLESHOOTING PROCEDURES

#### **INSPECTION CHART FOR DIAGNOSTIC**

TROUBLE CODES(DTC) E4DB765B

P-Code	Description		MIL	
F-Code	Description	EURO-II	EURO-III	LEADED
P0011	Camshaft Position-Timing Over-Advanced or System Performance(Bank 1)			
P0016	Crankshaft Position-Camshaft Position Correlation(Bank 1)			
P0030	O2 Sensor Heater - Heater Control Circuit (Bank 1 / Sensor 1)			-
P0031	O2 Sensor Heater Circuit low (Bank 1 / Sensor 1)			-
P0032	O2 Sensor Heater Circuit high (Bank 1 / Sensor 1)			-
P0036	O2 Sensor Heater - Heater Control Circuit (Bank 1 / Sensor 2)	-		-
P0037	O2 Sensor Heater Circuit low (Bank 1 / Sensor 2)	-		-
P0038	O2 Sensor Heater Circuit high (Bank 1 / Sensor 2)	-	0	-
P0076	Intake Valve Control Solenoid Circuit Low (Bank1)			
P0077	Intake Valve Control Solenoid Circuit High (Bank1)			
P0101	Mass or Volume Air Flow Circuit Range / Performance Problem	0		
P0102	Mass or Volume Air Flow Circuit Low Input			
P0103	Mass or Volume Air Flow Circuit high Input	0		
P0112	Intake Air Temperature Circuit Low Input			
P0113	Intake Air Temperature Circuit High Input			
P0116	Engine Coolant Temperature Circuit Range / Performance			
P0117	Engine Coolant Temperature Circuit Low Input			
P0118	Engine Coolant Temperature Circuit High Input			
P0121	Throttle / Pedal Position Circuit Range/Performance Problem			
P0122	Throttle / Pedal Position Circuit Low Input			
P0123	Throttle / Pedal Position Circuit High Input			
P0125	Insufficient Coolant Temperature for Closed Loop Fuel Control	-		-
P0130	O2 Sensor Circuit(Bank 1/ Sensor 1)			-
P0131	O2 Sensor Circuit Low Input(Bank 1 / Sensor 1)			-
P0132	O2 Sensor Circuit High Input(Bank 1 / Sensor 1)			-
P0133	O2 Sensor Circuit Slow Response (Bank 1 / Sensor 1)			-
P0134	O2 Sensor Circuit No Activity Detected (Bank 1 / Sensor 1)			-

FLA -39

P0136     O2 Sensor Circuit Malfunction(Bank 1 / Sensor 2)     -     -       P0137     O2 Sensor Circuit Low Input (Bank 1 / Sensor 2)     -     -       P0138     O2 Sensor Circuit Blow Response (Bank 1 / Sensor 2)     -     -       P0139     O2 Sensor Circuit Slow Response (Bank 1 / Sensor 2)     -     -       P0140     O2 Sensor Circuit No Activity Detected (Bank 1 / Sensor 2)     -     -       P0141     Fuel Trim Malfunction - System Too Rich (Bank 1)     -     -       P0172     Fuel Trim Malfunction - System Too Rich (Bank 1)     -     -       P0198     Engine Oil Temp. Sensor Low Input     -     -       P0197     Engine Oil Temp. Sensor Low Input     -     -       P0188     Engine Oil Temp. Sensor Low Input     -     -       P0261     Cylinder 1 - Injector Circuit Low     -     -       P0262     Cylinder 2 - Injector Circuit Low     -     -       P02630     Cylinder 3 - Injector Circuit High     -     -       P02641     Cylinder 4 - Injector Circuit High     -     -       P02700     Cylinder 4 - Injector Circuit High					
P0138   O2 Sensor Circuit High Input (Bank 1 / Sensor 2)   -   -     P0139   O2 Sensor Circuit Slow Response (Bank 1 / Sensor 2)   -   -     P0140   O2 Sensor Circuit No Activity Detected (Bank 1 / Sensor 2)   -   -     P0171   Fuel Trim Malfunction - System Too Lean (Bank 1)   -   -     P0172   Fuel Trim Malfunction - System Too Lean (Bank 1)   -   -     P0196   Engine Oil Temp. Sensor Range / Performance   -   -     P0197   Engine Oil Temp. Sensor High Input   -   -     P0198   Engine Oil Temp. Sensor High Input   -   -     P02030   Fuel Pump Circuit Malfunction   -   -     P0231   Cylinder 1 - Injector Circuit Low   -   -     P0262   Cylinder 2 - Injector Circuit High   -   -     P0263   Cylinder 3 - Injector Circuit How   -   -     P0264   Cylinder 4 - Injector Circuit How   -   -     P0270   Cylinder 4 - Injector Circuit How   -   -     P0302   Cylinder 4 - Injector Circuit High	P0136	O2 Sensor Circuit Malfunction(Bank 1 / Sensor 2)	-		-
P0139   Q2 Sensor Circuit Slow Response (Bank 1 / Sensor 2)   -   -     P0140   Q2 Sensor Circuit No Activity Detected (Bank 1 / Sensor 2)   -   -     P0171   Fuel Trim Malfunction - System Too Lean (Bank 1)   -   -     P0172   Fuel Trim Malfunction - System Too Rich (Bank 1)   -   -     P0186   Engine Oil Temp. Sensor Range / Performance   -   -     P0197   Engine Oil Temp. Sensor Low Input   -   -     P0230   Fuel Pump Circuit Malfunction   -   -     P0231   Cylinder 1 - Injector Circuit Low   -   -     P0262   Cylinder 1 - Injector Circuit High   -   -     P0263   Cylinder 3 - Injector Circuit High   -   -     P0264   Cylinder 3 - Injector Circuit High   -   -     P0265   Cylinder 3 - Injector Circuit High   -   -     P0266   Cylinder 3 - Injector Circuit High   -   -     P0270   Cylinder 4 - Injector Circuit High   -   -     P0271   Cylinder Misfire Detected   -   -     P0301   Cylinder 1 - Misfire detected   -   -	P0137	O2 Sensor Circuit Low Input (Bank 1 / Sensor 2)	-		-
P0140   Q2 Sensor Circuit No Activity Detected (Bank 1 / Sensor 2)   -   -     P0171   Fuel Trim Malfunction - System Too Lean (Bank 1)   -   -     P0172   Fuel Trim Malfunction - System Too Rich (Bank 1)   -   -     P0186   Engine Oil Temp. Sensor Range / Performance   -   -     P0197   Engine Oil Temp. Sensor Low Input   -   -     P0188   Engine Oil Temp. Sensor Low Input   -   -     P0230   Fuel Pump Circuit Malfunction   -   -     P0261   Cylinder 1 - Injector Circuit Low   -   -     P0262   Cylinder 2 - Injector Circuit High   -   -     P0263   Cylinder 3 - Injector Circuit High   -   -     P0264   Cylinder 3 - Injector Circuit High   -   -     P0265   Cylinder 3 - Injector Circuit High   -   -     P0270   Cylinder 4 - Injector Circuit High   -   -     P0271   Cylinder 4 - Injector Circuit High   -   -     P0300   Multiple Cylinder Misfre Detected   -   -     P0301   Cylinder 1 - Misfire detected   -   -	P0138	O2 Sensor Circuit High Input (Bank 1 / Sensor 2)	-		-
P0171   Fuel Trim Malfunction - System Too Lean (Bank 1)   -   -     P0172   Fuel Trim Malfunction - System Too Rich (Bank 1)   -   -     P0196   Engine Oil Temp. Sensor Range / Performance   -   -     P0197   Engine Oil Temp. Sensor Low Input   -   -     P0198   Engine Oil Temp. Sensor High Input   -   -     P0230   Fuel Pump Circuit Malfunction   -   -     P0261   Cylinder 1 - Injector Circuit Low   -   -     P0262   Cylinder 2 - Injector Circuit High   -   -     P0263   Cylinder 2 - Injector Circuit Low   -   -     P0264   Cylinder 3 - Injector Circuit Low   -   -     P0265   Cylinder 3 - Injector Circuit Low   -   -     P0265   Cylinder 4 - Injector Circuit Low   -   -     P0270   Cylinder 4 - Injector Circuit Low   -   -     P0300   Multiple Cylinder Misfire Detected   -   -     P0301   Cylinder 4 - Injector Circuit High   -   -     P0302   Cylinder 1 - Misfire detected   -   -     P0303	P0139	O2 Sensor Circuit Slow Response (Bank 1 / Sensor 2)	-		-
P0172   Fuel Trim Malfunction - System Too Rich (Bank 1)   -   -     P0186   Engine Oil Temp. Sensor Range / Performance   -   -     P0197   Engine Oil Temp. Sensor Low Input   -   -     P0198   Engine Oil Temp. Sensor High Input   -   -     P0230   Fuel Pump Circuit Malfunction   -   -     P0261   Cylinder 1 - Injector Circuit Low   -   -     P0262   Cylinder 2 - Injector Circuit High   -   -     P0263   Oglinder 2 - Injector Circuit High   -   -     P0264   Cylinder 3 - Injector Circuit Low   -   -     P0265   Cylinder 3 - Injector Circuit High   -   -   -     P0266   Cylinder 3 - Injector Circuit Low   -   -   -     P0270   Cylinder 4 - Injector Circuit Low   -   -   -     P0270   Cylinder 4 - Injector Circuit Low   -   -   -     P0300   Multiple Cylinder Misfire Detected   -   -   -     P0301   Cylinder 1 - Misfire detected   -   -   -     P0302   Cylinder 3 - Misfire dete	P0140	O2 Sensor Circuit No Activity Detected (Bank 1 / Sensor 2)	-		-
P0196   Engine Oil Temp. Sensor Range / Performance   Image: Construct Sensor Low Input     P0197   Engine Oil Temp. Sensor Low Input   Image: Construct Sensor High Input     P0280   Fuel Pump Circuit Malfunction   Image: Construct Sensor High Input     P0281   Cylinder 1 - Injector Circuit Low   Image: Construct Sensor High Input     P0282   Cylinder 1 - Injector Circuit Low   Image: Construct Sensor High Input     P0282   Cylinder 2 - Injector Circuit Low   Image: Construct Sensor High Input     P0285   Cylinder 3 - Injector Circuit Low   Image: Construct Sensor High Input     P0286   Cylinder 3 - Injector Circuit Low   Image: Construct Sensor High Input     P0287   Cylinder 3 - Injector Circuit Low   Image: Construct High Image: Construct Sensor High Image: Construct High Image: Construct Sensor High Image: Construct Sensor High Image: Construct Sensor High Image: Construct Sensor High Image: Construct High Image: Construct Sensor High Image: Construct High Image: Construct Sensor High Image: Construct High Image: Co	P0171	Fuel Trim Malfunction - System Too Lean (Bank 1)	-		-
P0197   Engine Oil Temp. Sensor Low Input   Image: Constraint of the sensor High Input     P0198   Engine Oil Temp. Sensor High Input   Image: Constraint of the sensor High Input     P0280   Fuel Pump Circuit Malfunction   Image: Constraint of the sensor High Input     P0281   Cylinder 1 - Injector Circuit Low   Image: Constraint of the sensor High Input     P0282   Cylinder 2 - Injector Circuit Low   Image: Constraint of the sensor High Input     P0285   Cylinder 2 - Injector Circuit Low   Image: Constraint of the sensor High Input     P0286   Cylinder 3 - Injector Circuit High   Image: Constraint of the sensor High Input     P0270   Cylinder 4 - Injector Circuit Low   Image: Constraint of the sensor High Input   Image: Constraint of the sensor High Input     P0271   Cylinder 4 - Injector Circuit Low   Image: Constraint of the sensor High Input Input   Image: Constraint of the sensor High Input Input     P0271   Cylinder 4 - Injector Circuit Low   Image: Constraint One   Image: Constraint One   Image: Constraint One     P0271   Cylinder 4 - Injector Circuit High Input Input   Image: Constraint One   Image: Constraint One <td>P0172</td> <td>Fuel Trim Malfunction - System Too Rich (Bank 1)</td> <td>-</td> <td></td> <td>-</td>	P0172	Fuel Trim Malfunction - System Too Rich (Bank 1)	-		-
P0198   Engine Oil Temp. Sensor High Input     P0230   Fuel Pump Circuit Malfunction     P0261   Cylinder 1 - Injector Circuit Low     P0262   Cylinder 1 - Injector Circuit High     P0263   Cylinder 2 - Injector Circuit High     P0264   Cylinder 3 - Injector Circuit Low     P0265   Cylinder 3 - Injector Circuit High     P0266   Cylinder 3 - Injector Circuit High     P0267   Cylinder 3 - Injector Circuit High     P0270   Cylinder 4 - Injector Circuit High     P0271   Cylinder 4 - Injector Circuit High     P0300   Multiple Cylinder Misfire Detected     P0301   Cylinder 1 - Misfire detected     P0302   Cylinder 1 - Misfire detected     P0303   Cylinder 3 - Misfire detected     P0304   Cylinder 4 - Misfire detected     P0305   Crankshaft Position Sensor A Circuit     P0335   Crankshaft Position Sensor A Circuit     P0335   Crankshaft Position Sensor Circuit Malfunction     P0340   Camshaft Position Sensor Circuit Malfunction     P0341   Cashshaft Position Sensor Circuit Malfunction     P0342   Catalyst System Efficiency below Threshold (Bank 1)     P0444 <td>P0196</td> <td>Engine Oil Temp. Sensor Range / Performance</td> <td></td> <td></td> <td></td>	P0196	Engine Oil Temp. Sensor Range / Performance			
P0230   Fuel Pump Circuit Malfunction   Image: Control of Contro	P0197	Engine Oil Temp. Sensor Low Input			
P0261   Cylinder 1 - Injector Circuit Low   Image: Cylinder 1 - Injector Circuit High     P0262   Cylinder 2 - Injector Circuit Low   Image: Cylinder 2 - Injector Circuit Low     P0265   Cylinder 3 - Injector Circuit High   Image: Cylinder 3 - Injector Circuit Low     P0268   Cylinder 3 - Injector Circuit Low   Image: Cylinder 3 - Injector Circuit Low     P0268   Cylinder 4 - Injector Circuit Low   Image: Cylinder 4 - Injector Circuit High     P0270   Cylinder 4 - Injector Circuit High   Image: Cylinder 4 - Injector Circuit High     P0271   Cylinder 4 - Injector Circuit High   Image: Cylinder 4 - Injector Circuit High     P0271   Cylinder 1 - Misfire Detected   Image: Cylinder 1 - Misfire detected     P0300   Multiple Cylinder Misfire Detected   Image: Cylinder 2 - Misfire detected   Image: Cylinder 3 - Misfire detected     P0302   Cylinder 1 - Misfire detected   Image: Cylinder 3 - Misfire detected   Image: Cylinder 4 - Misf	P0198	Engine Oil Temp. Sensor High Input			
P0262Cylinder 1 - Injector Circuit HighImage: Constraint of the system - Purge Ctrl. Valve Circuit SortedP0264Cylinder 2 - Injector Circuit LowImage: Constraint of the system - Purge Ctrl. Valve Circuit SortedP0265Cylinder 3 - Injector Circuit LowImage: Constraint of the system - Purge Ctrl. Valve Circuit SortedP0268Cylinder 3 - Injector Circuit HighImage: Constraint of the system - Purge Ctrl. Valve Circuit SortedP0270Cylinder 4 - Injector Circuit HighImage: Constraint of the system - Purge Ctrl. Valve Circuit SortedP0271Cylinder 4 - Injector Circuit HighImage: Constraint of the system - Purge Ctrl. Valve Circuit SortedP0300Multiple Cylinder Misfire DetectedImage: Constraint of the system - Purge Ctrl. Valve Circuit Constraint of the system - Purge Ctrl. Valve Circuit SortedP0303Cylinder 3 - Misfire detectedImage: Constraint Circuit SortedP0304Cylinder 4 - Misfire detectedImage: Constraint Circuit MalfunctionP0305Crankshaft Position Sensor A CircuitImage: Constraint Circuit MalfunctionP0340Catalyst System Efficiency below Threshold (Bank 1)Image: Constraint Circuit SortedP0444Evap. Emission Ctrl. System - Purge Ctrl. Valve Circuit SortedImage: Constraint Circuit SortedP0506Idle Control System - RPM lower than expectedImage: Constraint Circuit SortedP0507Idle Control System - RPM higher than expectedImage: Constraint Circuit SortedP0507Idle Control System - RPM higher than expectedImage: Constraint Circuit SortedP0507Idle Control System - RPM higher than ex	P0230	Fuel Pump Circuit Malfunction			
P0264   Cylinder 2 - Injector Circuit Low     P0265   Cylinder 2 - Injector Circuit High     P0267   Cylinder 3 - Injector Circuit Low     P0268   Cylinder 3 - Injector Circuit High     P0270   Cylinder 4 - Injector Circuit High     P0271   Cylinder 4 - Injector Circuit High     P0300   Multiple Cylinder Misfire Detected     P0301   Cylinder 1 - Misfire detected     P0302   Cylinder 3 - Misfire detected     P0303   Cylinder 3 - Misfire detected     P0304   Cylinder 4 - Misfire detected     P0305   Knock Sensor 1 Circuit Malfunction     P0336   Crankshaft Position Sensor A Circuit     P0340   Camshaft Position Sensor Circuit Malfunction     P0340   Castalyst System Efficiency below Threshold (Bank 1)     P0444   Evap. Emission Ctrl. System - Purge Ctrl. Valve Circuit Open     P0445   Evap. Emission Ctrl. System - Purge Ctrl. Valve Circuit Shorted     P0506   Idle Control System - RPM lower than expected     P0507   Idle Control System - RPM lowe	P0261	Cylinder 1 - Injector Circuit Low			
P0265Cylinder 2 - Injector Circuit HighImage: Control of Control	P0262	Cylinder 1 - Injector Circuit High			
P0267   Cylinder 3 - Injector Circuit Low   Image: Cylinder 3 - Injector Circuit High   Image: Cylinder 3 - Injector Circuit Low     P0270   Cylinder 4 - Injector Circuit Low   Image: Cylinder 4 - Injector Circuit High   Image: Cylinder 4 - Injector Circuit High     P0271   Cylinder 4 - Injector Circuit High   Image: Cylinder 4 - Injector Circuit High   Image: Cylinder 4 - Injector Circuit High     P0300   Multiple Cylinder Misfire Detected   -   -     P0301   Cylinder 1 - Misfire detected   -   -     P0302   Cylinder 3 - Misfire detected   -   -     P0303   Cylinder 3 - Misfire detected   -   -     P0304   Cylinder 4 - Misfire detected   -   -     P0325   Knock Sensor 1 Circuit Malfunction   Image: Circuit Malfunction   Image: Circuit Malfunction     P0335   Crankshaft Position Sensor A Circuit   Image: Circuit Malfunction   Image: Circuit Malfunction   Image: Circuit Malfunction     P0340   Catalyst System Efficiency below Threshold (Bank 1)   -   -   -     P0444   Evap. Emission Ctrl. System - Purge Ctrl. Valve Circuit Shorted   -   -   -     P0444   Evap. Emission Ctrl. System - Purge Ctrl. Valve Circuit Shorted </td <td>P0264</td> <td>Cylinder 2 - Injector Circuit Low</td> <td></td> <td></td> <td></td>	P0264	Cylinder 2 - Injector Circuit Low			
P0268   Cylinder 3 - Injector Circuit High   Image: Constraint of the second s	P0265	Cylinder 2 - Injector Circuit High		0	
P0270   Cylinder 4 - Injector Circuit Low   Image: Comparison of Compar	P0267	Cylinder 3 - Injector Circuit Low			
P0271   Cylinder 4 - Injector Circuit High Cools di lolue (1991)     P0300   Multiple Cylinder Misfire Detected   -   -     P0301   Cylinder 1 - Misfire detected   -   -     P0302   Cylinder 2 - Misfire detected   -   -     P0303   Cylinder 3 - Misfire detected   -   -     P0304   Cylinder 4 - Misfire detected   -   -     P0305   Knock Sensor 1 Circuit Malfunction   -   -     P0335   Crankshaft Position Sensor A Circuit   -   -     P0340   Camshaft Position Sensor Circuit Malfunction (Bank1 or Single Sensor)   -   -     P0420   Catalyst System Efficiency below Threshold (Bank 1)   -   -     P0444   Evap. Emission Ctrl. System - Purge Ctrl. Valve Circuit Open   -   -     P0501   Vehicle Speed Sensor Range / Performance   -   -   -     P0506   Idle Control System - RPM lower than expected   -   -   -     P0507   Idle Control System - RPM higher than expected   -   -   -	P0268	Cylinder 3 - Injector Circuit High			
P0300Multiple Cylinder Misfire DetectedP0301Cylinder 1 - Misfire detectedP0302Cylinder 2 - Misfire detectedP0303Cylinder 3 - Misfire detectedP0304Cylinder 4 - Misfire detectedP0325Knock Sensor 1 Circuit MalfunctionP0336Crankshaft Position Sensor A CircuitP0340Camshaft Position Sensor Circuit Malfunction (Bank1 or Single Sensor)P0420Catalyst System Efficiency below Threshold (Bank 1)P0444Evap. Emission Ctrl. System - Purge Ctrl. Valve Circuit Open P0501P0506Idle Control System - RPM lower than expectedP0507Idle Control System - RPM higher than expected	P0270	Cylinder 4 - Injector Circuit Low			
P0301Cylinder 1 - Misfire detectedP0302Cylinder 2 - Misfire detectedP0303Cylinder 3 - Misfire detectedP0304Cylinder 4 - Misfire detectedP0325Knock Sensor 1 Circuit MalfunctionP0335Crankshaft Position Sensor A CircuitP0340Camshaft Position Sensor Circuit Malfunction (Bank1 or Single Sensor)P0420Catalyst System Efficiency below Threshold (Bank 1)P0444Evap. Emission Ctrl. System - Purge Ctrl. Valve Circuit ShortedP0501Vehicle Speed Sensor Range / PerformanceP0506Idle Control System - RPM lower than expectedP0507Idle Control System - RPM higher than expected	P0271	Cylinder 4 - Injector Circuit High			
P0302Cylinder 2 - Misfire detectedP0303Cylinder 3 - Misfire detectedP0304Cylinder 4 - Misfire detectedP0325Knock Sensor 1 Circuit MalfunctionP0335Crankshaft Position Sensor A CircuitP0340Camshaft Position Sensor Circuit Malfunction (Bank1 or Single Sensor)P0420Catalyst System Efficiency below Threshold (Bank 1)P0444Evap. Emission Ctrl. System - Purge Ctrl. Valve Circuit OpenP0445Evap. Emission Ctrl. System - Purge Ctrl. Valve Circuit ShortedP0501Vehicle Speed Sensor Range / PerformanceP0506Idle Control System - RPM lower than expectedP0507Idle Control System - RPM higher than expected	P0300	Multiple Cylinder Misfire Detected			-
P0303Cylinder 3 - Misfire detectedP0304Cylinder 4 - Misfire detectedP0325Knock Sensor 1 Circuit MalfunctionP0335Crankshaft Position Sensor A CircuitP0340Camshaft Position Sensor Circuit Malfunction (Bank1 or Single Sensor)P0420Catalyst System Efficiency below Threshold (Bank 1)P0444Evap. Emission Ctrl. System - Purge Ctrl. Valve Circuit OpenP0445Evap. Emission Ctrl. System - Purge Ctrl. Valve Circuit ShortedP0501Vehicle Speed Sensor Range / PerformanceP0506Idle Control System - RPM lower than expectedP0507Idle Control System - RPM higher than expected	P0301	Cylinder 1 - Misfire detected	-		-
P0304Cylinder 4 - Misfire detectedP0325Knock Sensor 1 Circuit MalfunctionP0335Crankshaft Position Sensor A CircuitP0340Camshaft Position Sensor Circuit Malfunction (Bank1 or Single Sensor)P0420Catalyst System Efficiency below Threshold (Bank 1)P0444Evap. Emission Ctrl. System - Purge Ctrl. Valve Circuit OpenP0445Evap. Emission Ctrl. System - Purge Ctrl. Valve Circuit ShortedP0501Vehicle Speed Sensor Range / PerformanceP0506Idle Control System - RPM lower than expectedP0507Idle Control System - RPM higher than expected	P0302	Cylinder 2 - Misfire detected	-		-
P0325Knock Sensor 1 Circuit MalfunctionImage: Circuit MalfunctionP0335Crankshaft Position Sensor A CircuitImage: Circuit Malfunction (Bank1 or Single Sensor)Image: Circuit Malfunction (Bank1 or Single Sensor)P0420Catalyst System Efficiency below Threshold (Bank 1)-Image: Circuit OpenP0444Evap. Emission Ctrl. System - Purge Ctrl. Valve Circuit OpenP0445Evap. Emission Ctrl. System - Purge Ctrl. Valve Circuit ShortedP0501Vehicle Speed Sensor Range / PerformanceImage: Circuit ShortedP0506Idle Control System - RPM lower than expectedImage: Circuit OpenImage: Circuit Open-P0507Idle Control System - RPM higher than expectedImage: Circuit ShortedImage: Circuit ShortedImage: Circuit ShortedP0507Idle Control System - RPM higher than expectedImage: Circuit ShortedImage: Circuit ShortedImage: Circuit Shorted	P0303	Cylinder 3 - Misfire detected	-		-
P0335Crankshaft Position Sensor A CircuitImage: Camshaft Position Sensor Circuit Malfunction (Bank1 or Single Sensor)Image: Camshaft Position Sensor Circuit Sensor (Bank 1)Image: Camshaft Position Sensor Porter (Bank 1)Image: Camshaft Position Sensor Porter (Position Sensor Circuit System - Purge Ctrl. Valve Circuit Open (Posor Position Sensor Ctrl. System - Purge Ctrl. Valve Circuit Shorted (Posor Posor Position Sensor Range / PerformanceImage: Camshaft Position Sensor Porter (Posor Posor Position System - RPM lower than expectedImage: Camshaft Position Sensor Porter (Posor Posor Position System - RPM higher than expectedImage: Camshaft Position	P0304	Cylinder 4 - Misfire detected	-		-
P0340Camshaft Position Sensor Circuit Malfunction (Bank1 or Single Sensor)Image: Camshaft Position Sensor Circuit Malfunction (Bank1 or Single Sensor)P0420Catalyst System Efficiency below Threshold (Bank 1)P0444Evap. Emission Ctrl. System - Purge Ctrl. Valve Circuit OpenP0445Evap. Emission Ctrl. System - Purge Ctrl. Valve Circuit ShortedP0501Vehicle Speed Sensor Range / PerformanceImage: Control System - RPM lower than expectedImage: Control System - RPM higher than expectedP0507Idle Control System - RPM higher than expectedImage: Control System - RPM higher than expectedImage: Control System - RPM higher than expected	P0325	Knock Sensor 1 Circuit Malfunction			
P0340(Bank1 or Single Sensor)Image: Catalyst System Efficiency below Threshold (Bank 1)Image: Catalystem Efficiency below Thr	P0335	Crankshaft Position Sensor A Circuit			
P0444Evap. Emission Ctrl. System - Purge Ctrl. Valve Circuit OpenP0445Evap. Emission Ctrl. System - Purge Ctrl. Valve Circuit ShortedP0501Vehicle Speed Sensor Range / PerformanceP0506Idle Control System - RPM lower than expectedP0507Idle Control System - RPM higher than expected	P0340				
P0445   Evap. Emission Ctrl. System - Purge Ctrl. Valve Circuit Shorted   -   -     P0501   Vehicle Speed Sensor Range / Performance   -   -     P0506   Idle Control System - RPM lower than expected   -   -     P0507   Idle Control System - RPM higher than expected   -   -	P0420	Catalyst System Efficiency below Threshold (Bank 1)	-		-
P0501   Vehicle Speed Sensor Range / Performance   Idle Control System - RPM lower than expected     P0506   Idle Control System - RPM lower than expected   Idle Control System - RPM higher than expected	P0444	Evap. Emission Ctrl. System - Purge Ctrl. Valve Circuit Open	-		-
P0506 Idle Control System - RPM lower than expected   P0507 Idle Control System - RPM higher than expected	P0445	Evap. Emission Ctrl. System - Purge Ctrl. Valve Circuit Shorted	-		-
P0507 Idle Control System - RPM higher than expected	P0501	Vehicle Speed Sensor Range / Performance			
	P0506	Idle Control System - RPM lower than expected			
P0560 System Voltage Malfunction	P0507	Idle Control System - RPM higher than expected			
	P0560	System Voltage Malfunction			

### WWW.DIGITALKHODRO.COM

#### 021-62999292

FLA -40

**FUEL SYSTEM** 

P0562	System Voltage Low		
P0563	System Voltage High		
P0600	Serial Communication Link Malfunction		
P0605	Internal Control Module Read Only Memory(ROM) Error		
P0650	Malfunction Indicator Lamp(MIL) Control Circuit Malfunction	-	-
P0170	O2 Sensor System - Lambda Controller at the Limit (Bank 1)	-	-
P0315	Segment Time Acquisition Incorrect	-	-
P1505	Idle Charge Actuator Signal Low of Coil #1		
P1506	Idle Charge Actuator Signal High of Coil #1		
P1507	Idle Charge Actuator Signal Low of Coil #2		
P1508	Idle Charge Actuator Signal High of Coil #2		
P0700	TCU Request for MIL On / Freeze Frame to ECU via CAN		
P1602	Serial Communication Problem with TCU (Timeout)		

.

: MIL ON & FAULT CODE MEMORY : MIL OFF & FAULT CODE MEMORY

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

FLA -41

### DTC P0011 "A" CAMSHAFT POSITION-TIMING OVER-ADVANCED OR SYSTEM PERFORMANCE (BANK 1)

#### COMPONENT LOCATION EF8DA46B



EGQE603M

#### GENERAL DESCRIPTION ECF661DE

The CVVT (Continuously Variable Valve Timing) system is installed to the chain sprocket of the exhaust camshaft. There is no variation in valve timing of the exhaust cam because the exhaust camshaft is driven by the timing belt. The timing of the intake cam is varied by the relative operation the CVVT vane to the housing. This system helps the engine decrease exhaust gases and increase engine power and fuel economy by changing the valve open/close timing of the intake camshaft.

#### DTC DESCRIPTION E9FCBFE7

The deviation of the camshaft position from the target point is evaluated during stable driving condition. The PCM accumulats this deviation for a certain period and sets DTC P0011 when the accumulated deviation is too high. The target camshaft position is predetermineded value depending on engine speed and throttle angle in the PCM.

#### **FUEL SYSTEM**

#### DTC DETECTING CONDITION EEGE1D8C

Item	Detecting Condition	Possible Cause
DTC Strategy	Monitor deviation between camshaft position setpoint and actual value	
Enable Conditions	No relevant failure 11V < Battery voltage < 16V CVVT control : enabled Holding position adaptation not active Camshaft setpoint moved more than 5 times for this Driving Cycle Camshaft target position is stable with less than 1.125°CRK moving 600rpm < Engine speed < 5000rpm 20 (68 ) < Engine oil temperature < 100 (212 )	Oil leakage Faulty Oil pump Faulty Intake valve control solenoid
Threshold Value	Integral of Camshaft position setpoint - Camshaft position actual value > 150°CRK/sec.	
Diagnostic Time	Approx. 38~300 seconds depending on CAM deviation	
Fail-Safe	CVVT control is disabled	
SPECIFICATION		Q 0

### SPECIFICATION E091CCFB

Intake valve control solenoid	Normal Parameter
Insulation Resistance ( )	above 50 MΩ

Temp.( )) 9	Temp.())	Resistance()	Temp.(9)	Temp.( )	Resistanc <mark>e()</mark>
0	32	6.2 ~ 7.4	60	140	8.0 ~ 9.2
10	50	6.5 ~ 7.7	70	158	8.3 ~ 9.5
20	68	6.8 ~ 8.0	80	176	8.6 ~ 9.8
30	86	7.1 ~ 8.3	90	194	8.9 ~ 10.1
40	104	7.4 ~ 8.6	100	212	9.0 ~ 10.4
50	122	7.7 ~ 8.9			

### DTC TROUBLESHOOTING PROCEDURES

### SCHEMATIC DIAGRAM E5010A97

Intake Valve Control Solenoid	PCM		PCM		. [		nec			-				1			_				
1			]	Te	rmina	al		-	onne							ction					
V-fr/1		ontro						1			PCI	И Те	rmin	al 11				Co	ntrol		
After Main Relay								2			Μ	ain R	elay				Ba	ttery	Volta	ige	
[CONNECTOR] IVCS Harness side connector						L		P	CM	side	term	ninal									
	6	7	8	9	10		*	*	14	*	*	17	18	*	*	21	22	23	24	5	4
	*	26	27	*	29	30	31	32	*	*	*	*	37	38	39	*	*	42	43	3	,
$\left( \begin{array}{c} 2 \\ 1 \end{array} \right) $	*	45	*	47	48	*	50	51	52	*	54	55	56	*	58	59	60	61	62	3	)
	*	64	65	66	67	68	69	70	71	72	73	*	75	76	77	78	*	80	81	2	1
C166										C13	0-1										
•																					

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode
- 2. Press F4(DTAL) to select DTC information from the DTCs menu
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions
- 4. Read "DTC Status" parameter

	<b>1.4 AMBIENT CONDITIONS</b>
To naviate to the "DTAL"menu	
01 HYUNDAI VEHICLE DIAGNOSIS	
Select model and year	1. MIL STATUS
└→02 ENGINE	2. DTC STATUS: <u>PRESENT</u>
Select engine	3. DTC READINESS FLAG : <u>COMPLETE</u>
<b>01</b> DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC
PART ERAS DTAL HELP	6. OP.HOUR AFTER ERASURE OF DTC

B00112

5. Is parameter displayed "History(Not Present) fault"?

#### 🔟 ΝΟΤΕ

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

### WWW.DIGITALKHODRO.COM

### YES

FUEL SYSTEM

Fault is intermittent caused by poor contact in the sensor's and/or PCM's connector or was repaired and PCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

#### NO

Go to "Component Inspection" procedure

#### COMPONENT INSPECTION ECC58DA1

#### VISUALLY CHECK INTAKE VALVE CONTROL SOLENOLD

- 1. Ignition "OFF".
- 2. Remove the intake valve control solenoid from the engine.
- 3. Visually check the Spool Column of intake valve control solenoid for contamination.
- 4. Connect 12V and a ground to 2 and 1 of the solenoid(Component side). Verify that spool column move to left as shown in the figure.
- 5. Disconnect 12V and verify that spool column move to original condition.

B00113

6. Has a problem been found?

Apply B4

#### YES

Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure

NO

Go to next step as below

#### CHECK INTAKE VALVE CONTROL SOLENOID RESISTANCE

- 1. Ignition " OFF".
- 2. Disconnect intake valve control solenoid connector.
- 3. Measure resistance between terminals 1 and 2 of the intake valve control solenoid connector.(Component side)

### WWW.DIGITALKHODRO.COM

### WWW.DIGITALKHODRO.COM

### DTC TROUBLESHOOTING PROCEDURES

#### SPECIFICATION

Temp.( )	Temp.( )	Resistance()	Temp.( )	Temp.( )	Resistance()
0	32	6.2 ~ 7.4	60	140	8.0 ~ 9.2
10	50	6.5 ~ 7.7	70	158	8.3 ~ 9.5
20	68	6.8 ~ 8.0	80	176	8.6 ~ 9.8
30	86	7.1 ~ 8.3	90	194	8.9 ~ 10.1
40	104	7.4 ~ 8.6	100	212	9.0 ~ 10.4
50	122	7.7 ~ 8.9			

<C166>



Replace the intake valve control solenoid and go to "Verification of Vehicle Repair" procedure

#### CHECK THE SUSPECTED AREA

- 1. Check the following items
  - · Intake valve control solenoid filter for sticking or contamination
  - Engine oil and it's level
  - Engine oil filter
- 2. Is there any problem?



Repair or replace the intake valve control solenoid and go to "Verification of Vehicle Repair" procedure

NO

Go to "Terminal and Connector Inspection" procedure

#### TERMINAL AND CONNECTOR INSPECTION EFEFB4A0

1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

### WWW.DIGITALKHODRO.COM

### WWW.DIGITALKHODRO.COM

#### 021-62999292

#### FLA -46

#### FUEL SYSTEM

- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

#### YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure

#### NO

Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure

#### VERIFICATION OF VEHICLE REPAIR EC8AEAB4

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode
- 2. Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions
- 3. Read "DTC Status" parameter
- 4. Is parameter displayed "History(Not Present) fault"?



NO

System performing to specification at this time. Clear the DTC

Go to the applicable troubleshooting procedure.



FLA -47

## DTC P0016 CRANKSHAFT POSITION-CAMSHAFT POSITION CORRELATION (BANK 1 SENSOR A)

#### GENERAL DESCRIPTION E1E348CE

The CVVT (Continuously Variable Valve Timing) system is installed to the chain sprocket of the exhaust camshaft. There is no variation in valve timing of the exhaust cam because the exhaust camshaft is driven by the timing belt. The timing of the intake cam is varied by the relative operation the CVVT vane to the housing. This system helps the engine decrease exhaust gases and increase engine power and fuel economy by changing the valve open / close timing of the intake camshaft.

#### DTC DESCRIPTION EDA7E64D

This diagnosis checks the camshaft position plausibility whether the expected range plus some margin is not violated that might be caused by a wrong engine repair, or a chain/belt misalignment. DTC P0016 is set when actual camshaft position is too much retarded or advanced than full retard position or full advance position. To continue the adjustment in such case could lead to a damage of the engine by hitting the valves with the piston.

#### DTC DETECTING CONDITION EAB723D1

Item	Detecting Condition	Possible Cause
DTC Strategy	Monitor Camshaft position in the full retard condition or during CVVT control	
Enable Conditions	No failure on oil control valve Battery voltage > 11V CVVT control state ="Ready" or "Adap- tation" or "Enable"	Abnormal installation of camshaft Abnormal installation of
فودرو در ایران	Actual measured camshaft position in full retard	crankshaft Abnormal installation of
Threshold Value	position ("Ready" or "Adaptation") is out of 105 ~ 145 °CRK Camshaft position in "Enable" condition is out of 70 °CRK ~ 140 °CRK	tone wheel
Diagnostic Time	8 Sec.	

#### MONITOR DTC STATUS EBE7B1DF

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode
- 2. Press F4(DTAL) to select DTC information from the DTCs menu
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions
- 4. Read "DTC Status" parameter

**FUEL SYSTEM** 

	1.4 AMBIENT CONDITIONS
To naviate to the "DTAL"menu	
<b>01</b> HYUNDAI VEHICLE DIAGNOSIS	
Select model and year	1. MIL STATUS
└─▶02 ENGINE	2. DTC STATUS: PRESENT
Select engine	3. DTC READINESS FLAG : <u>COMPLETE</u>
<b>01</b> DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC
PART ERAS DTAL HELP	6. OP.HOUR AFTER ERASURE OF DTC

B00112

5. Is parameter displayed "History(Not Present) fault"?

#### 🔟 NOTE

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

#### YES

Fault is intermittent caused by poor contact in the sensor's and/or PCM's connector or was repaired and PCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

#### اولین سامانه دیجیتال تعمیرکاران خودرو در <mark>اس</mark>ت NO

Go to "Component Inspection" procedure.

#### COMPONENT INSPECTION E96BA965

- 1. Timing Inspection
  - Set up an oscilloscope as follows : Channel A (+): terminal 2 of the CKPS, (-): ground Channel B (+): terminal 2 of the CMPS, (-): ground
  - 2) Start the engine and check for signal waveform whether synchronize with camshaft sensor or not and tooth is missing refer to sample waveforms as below.

FLA -49



#### VERIFICATION OF VEHICLE REPAIR ECEDCE63

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode
- 2. Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions
- 3. Read "DTC Status" parameter
- 4. Is parameter displayed "History(Not Present) fault"?



System performing to specification at this time. Clear the DTC



Go to the applicable troubleshooting procedure.

#### FUEL SYSTEM

### DTC P0030 HO2S HEATER CONTROL CIRCUIT (BANK 1 / SENSOR 1)

#### COMPONENT LOCATION EC19C14E



EGQE501N

#### GENERAL DESCRIPTION E8436F5E

The normal operating temperature of the HO2S(Heated Oxygen Sensor) ranges from 350 to 850 (662 to 1562). The HO2S heater greatly decreases the amount of time required for fuel control to become active. The PCM provides a pulse width modulated control circuit to adjust current through the heater. When the HO2S is cold, the value of the resistance is low and the current in the circuit is high. On the contrary, if the temperature in the resistor of the sensor rises, the current drops gradually.

### DTC DESCRIPTION E3DCB6D1

The PCM determines if a front HO2S heater fault has occurred and sets DTC P0030 if the front HO2S heater control driver inside the PCM fails, if HO2S is not operational (after an elapse of predetermined time) since engine start, or when the front HO2S tip temperature is out of normal working range.

#### DTC DETECTING CONDITION E9DA9CDB

ltem	Detecting Condition	Possible Cause
DTC Strategy	Evaluate O2 sensor element temperature via measuring element resistance	
Enable Conditions	Sensor preheating and full heating phases finished Time after start elapsed:240 sec. 11V < Battery voltage < 16V 1% < Heater power < 99% Exhaust gas temp. model < 650°C (1,202°F)	Related fuse blown or missing Heater control circuit open or short Power supply circuit open or short
Threshold Value	O2 sensor Element Resistance > 2100 Ohm	Contact resistance in connectors
Diagnostic Time	5 min.	Faulty HO2S
Fail-Safe	EVAP. emission control function is controlled in minimum operation mode	

### WWW.DIGITALKHODRO.COM

### DTC TROUBLESHOOTING PROCEDURES

#### SPECIFICATION EB9E0BE5

Temp.( )	Temp.( )	Front HO2S Heater Resistance( )	Temp.( )	Temp.( )	Front HO2S Heater Resistance( )
20	68	9.2	400	752	17.7
100	212	10.7	500	932	19.2
200	392	13.1	600	1,112	20.7
300	572	14.6	700	1,292	22.5

#### SCHEMATIC DIAGRAM E62A3FE4



FUEL SYSTEM

SIGNAL WAVEFORM E1318E78



The HO2S requires a minimum temperature to provide a closed loop fuel control system. So HO2S contains the heater element to reduce its warming-up time and ensure its performance during all driving conditions. The HO2S heater should be always ON after engine start. The ECM controls this heater element by duty cycle. The main relay supplies voltage to the heater and the ECM provides a ground circuit for activating the heater. The illustration is the signal waveform at idle after HO2S heater completes warming-up.



- 2. Press F4(DTAL) to select DTC information from the DTCs menu
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions
- 4. Read "DTC Status" parameter



B00112

5. Is parameter displayed "History(Not Present) fault"?

FLA -53

#### 🚺 ΝΟΤΕ

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

#### YES

Fault is intermittent caused by poor contact in the sensor's and/or PCM's connector or was repaired and PCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

#### NO

Go to "W/Harness Inspection" procedure

#### TERMINAL AND CONNECTOR INSPECTION E4ABC1FD

- 1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?



Repair as necessary and go to "Verification of Vehicle Repair" procedure

ولین سامانه دیجیتال تعمیر کاران خودرو در N

Go to "Power Supply Circuit Inspection" procedure.

#### POWER SUPPLY CIRCUIT INSPECTION EFC6790C

- 1. Ignition "OFF".
- 2. Disconnect HO2S connecto.
- 3. Ignition "ON" & Engine "OFF"
- 4. Measure voltage between terminal 4 of the HO2S heater harness connector and chassis ground.

Specification : Approx. B+

5. Is voltage display near the specified value?



Go to "Control Circuit Inspection" procedure.

#### NO

Check for an open in the power supply circuit between the main relay and the HO2S Especially check for "10A Sensor fuse" is installed and not blown. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

FUEL SYSTEM

#### CONTROL CIRCUIT INSPECTION EC4626AF

- 1. Check for open in control harness.
  - 1) Ignition "OFF".
  - 2) Disconnect PCM connector
  - Measure resistance between terminals 3 of the HO2S heater harness connector and 8 of the PCM harness connector.

Specification : Approx 0

4) Is resistance within the specification?



Go to next step as below

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

2. Check for short to ground in control circuit.

1) Measure resistance between terminal 3 of the HO2S heater harness connector and chassis ground.

Specification : infinite

2) Is resistance within the specification?

Go to next step as below

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

- 3. Check for short to power in control circuit.
  - 1) Reconnect the PCM connector.
  - 2) Ignition "ON" & Engine "OFF"
  - 3) Measure voltage between terminal 3 of the HO2S heater harness connector and chassis ground

Specification : Approx 0V

4) Is voltage within the specification?

YES

Go to "Component Inspection" procedure.

NO

Repair open or short to ground in control circuit and go to "Verification of Vehicle Repair" procedure

### WWW.DIGITALKHODRO.COM

FLA -55

#### COMPONENT INSPECTION E9CC9CA9

1. Measure resistance between terminals 3 and 4 of the sensor connector(Component side)

#### SPECIFICATION

Temp.( )	Temp.( )	Front HO2S Heater Resistance( )	Temp.( )	Temp.( )	Front HO2S Heater Resistance( )
20	68	9.2	400	752	17.7
100	212	10.7	500	932	19.2
200	392	13.1	600	1,112	20.7
300	572	14.6	700	1,292	22.5





Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

2.

Check HO2S for contamination, deterioration, or damage. Substitute with a known-good HO2S and check for proper operation. If the problem is corrected, replace HO2S and then go to "Verification of Vehicle Repair" procedure.

#### **FUEL SYSTEM**

#### VERIFICATION OF VEHICLE REPAIR E281111B

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode
- 2. Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 3. Read "DTC Status" parameter
- 4. Is parameter displayed "History(Not Present) fault"?



System performing to specification at this time. Clear the DTC

NO

Go to the applicable troubleshooting procedure.



ولین سامانه دیجیتال تعمیرکاران خودرو در ایران



FLA -57

### DTC P0031 HO2S HEATER CIRCUIT LOW (BANK 1 / SENSOR 1)

#### COMPONENT LOCATION E42B18D2

Refer to DTC P0030.

#### GENERAL DESCRIPTION E019ED6B

Refer to DTC P0030.

#### DTC DESCRIPTION E7F36BE9

PCM sets DTC P0031 if the PCM detects that the front HO2S heater control circuit is short to ground.

#### DTC DETECTING CONDITION EBBE00E8

ltem	Detecting Condition	Possible Cause
DTC Strategy	Check short circuit to ground on front HO2S heater line	
Enable Conditions	Battery voltage > 10V 1% < Heater power < 99%	Related fuse blown or missing Open or short to ground in power supply or control harness
Threshold Value	Short to ground	Contact resistance in
Diagnostic Time	10 sec.	connectors Faulty HO2S
Fail-Safe	Heater open loop control	

### SPECIFICATION EECESE8

Temp.( )	Temp.( )	Front HO2S Heater Resistance( )	Temp.( )	Temp.( )	Front HO2S Heater Resistance( )
20	68	9.2	400	752	17.7
100	212	10.7	500	932	19.2
200	392	13.1	600	1,112	20.7
300	572	14.6	700	1,292	22.5

### SCHEMATIC DIAGRAM EBB52593

Refer to DTC P0030.

#### SIGNAL WAVEFORM E67B32FD

Refer to DTC P0030.

#### MONITOR DTC STATUS EA05E00D

Refer to DTC P0030.

**FUEL SYSTEM** 

#### TERMINAL AND CONNECTOR INSPECTION EDA5B8A0

Refer to DTC P0030.

#### POWER SUPPLY CIRCUIT INSPECTION E1ABFDB0

- 1. Ignition "OFF".
- 2. Disconnect HO2S sensor connecto.
- 3. Ignition "ON" & Engine "OFF"
- 4. Measure voltage between terminal 4 of the HO2S heater harness connector and chassis ground.

Specification : Approx. B+

5. Is voltage display near the specified value?

#### YES

Go to "Control Circuit Inspection" procedure.

NO

Check for an open in the power supply circuit between the main relay and the HO2S Especially check for "10A Sensor fuse" is installed and not blown. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### CONTROL CIRCUIT INSPECTION EFF77B27

- 1. Check for open in control harness.
  - 1) Ignition "OFF".
  - 2) Disconnect PCM connector
  - Measure resistance between terminals 3 of the HO2S heater harness connector and 8 of the PCM harness connector.

Specification : Approx 0

4) Is resistance within the specification?



Go to next step as below

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

- 2. Check for short to ground in control circuit.
  - 1) Measure resistance between terminal 3 of the HO2S heater harness connector and chassis ground.

Specification : infinite

### WWW.DIGITALKHODRO.COM

2) Is resistance within the specification?



Go to "Component Inspection" procedure.



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### COMPONENT INSPECTION E2A0AA35

Refer to DTC P0030.

#### VERIFICATION OF VEHICLE REPAIR E7216E30

Refer to DTC P0030.



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



**FUEL SYSTEM** 

### DTC P0032 HO2S HEATER CIRCUIT HIGH (BANK 1 / SENSOR 1)

#### COMPONENT LOCATION E3ACEFC3

Refer to DTC P0030.

#### GENERAL DESCRIPTION EAF7DD5A

Refer to DTC P0030.

#### DTC DESCRIPTION E4A1FBDF

PCM sets DTC P0032 if the PCM detects that the front HO2S heater control line is open or short to battery circuit.

#### DTC DETECTING CONDITION E921CA6C

ltem	Detecting Condition	Possible Cause
DTC Strategy	Check open or short circuit to battery line on front HO2S heater line	
Enable Conditions	Batt <mark>er</mark> y voltage > 10V 1% < Heater power < 99%	Open or short to battery in control harnesss Contact resistance in
Threshold Value	Open or short to Battery	connectors
Diagnostic Time	10 sec.	Faulty HO2S
Fail-Safe	Heater open loop control	

#### SPECIFICATION ED2FA874

Temp.( )	Temp.( )	Front HO2S Heater Resistance( )	Temp.( )	Temp.( )	Front HO2S Heater Resistance( )
20	68	9.2	400	752	17.7
100	212	10.7	500	932	19.2
200	392	13.1	600	1,112	20.7
300	572	14.6	700	1,292	22.5

#### SCHEMATIC DIAGRAM EFEDBDE7

Refer to DTC P0030.

SIGNAL WAVEFORM EE26B2FF

Refer to DTC P0030.

#### MONITOR DTC STATUS EBC7F094

Refer to DTC P0030.

#### TERMINAL AND CONNECTOR INSPECTION ECA788FB

Refer to DTC P0030.

#### CONTROL CIRCUIT INSPECTION E17AE508

- 1. Check for open in control harness.
  - 1) Ignition "OFF".
  - 2) Disconnect HO2S and PCM connectors
  - 3) Measure resistance between terminals 3 of the HO2S heater harness connector and 8 of the PCM harness connector.

Specification : Approx 0

4) Is resistance within the specification?

YES

NO

Go to next step as below

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

2. Check for short to battery in control circuit.

1) Reconnect the PCM connector.

2) Ignition "ON" & Engine "OFF"

3) Measure voltage between terminal 3 of the HO2S heater harness connector and chassis ground.

Specification : Approx 0V

4) Is voltage within the specification?

#### YES

Go to "Component Inspection" procedure

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### COMPONENT INSPECTION EDOCOBI7

Refer to DTC P0030.

#### VERIFICATION OF VEHICLE REPAIR EAIDDABB

Refer to DTC P0030.

### OOTING PROCEDURES

**FUEL SYSTEM** 

### DTC P0036 HO2S HEATER CONTROL CIRCUIT (BANK 1 / SENSOR 2)

#### COMPONENT LOCATION EC557F7B



EGQE501M

#### GENERAL DESCRIPTION E03FD5EF

The normal operating temperature of the HO2S(Heated Oxygen Sensor) ranges from 350 to 850 (662 to 1562). The HO2S heater greatly decreases the amount of time required for fuel control to become active. The PCM provides a pulse width modulated control circuit to adjust current through the heater. When the HO2S is cold, the value of the resistance is low and the current in the circuit is high. On the contrary, if the temperature in the resistor of the sensor rises, the current drops gradually.

### DTC DESCRIPTION E83CAD65

The PCM determines when a rear HO2S heater fault occurs and sets DTC P0036 if measured rear HO2S resistance is lower than the predetermined threshold.

#### DTC DETECTING CONDITION E3CCD3E9

ltem	Detecting Condition	Possible Cause
DTC Strategy	Evaluate O2 sensor element temperature via measuring element resistance	
Enable Conditions	Sensor preheating and full heating phases finished Time after start elapsed:240 sec. 11V < Battery voltage < 16V 1% < Heater power < 99% Exhaust gas temp. model < 650°C (1,202°F)	Related fuse blown or missing Heater control circuit open or short Power supply circuit open or short
Threshold Value	O2 sensor Element Resistance > 1100 Ohm	Contact resistance in connectors
Diagnostic Time	5 min.	Faulty HO2S
Fail-Safe	EVAP. emission control function is controlled in minimum operation mode	

### DTC TROUBLESHOOTING PROCEDURES

#### SPECIFICATION E941BAEA

Temp.( )	Temp.( )	Rear HO2S Heater Resistance( )	Temp.( )	Temp.( )	Rear HO2S Heater Resistance( )
20	68	9.2	500	932	19.2
100	212	10.7	600	1,112	20.7
200	392	13.1	700	1,292	22.5
300	572	14.6	800	1,472	25.1
400	752	17.7	900	1,652	26.5

#### SCHEMATIC DIAGRAM EBF8CFF3



B00361

FUEL SYSTEM

SIGNAL WAVEFORM EACFC5F5



The HO2S requires a minimum temperature to provide a closed loop fuel control system. So HO2S contains the heater element to reduce its warming-up time and ensure its performance during all driving conditions. The HO2S heater should be always ON after engine start. The ECM controls this heater element by duty cycle. The main relay supplies voltage to the heater and the ECM provides a ground circuit for activating the heater. The illustration is the signal waveform at idle after HO2S heater completes warming-up.



- 2. Press F4(DTAL) to select DTC information from the DTCs menu
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions
- 4. Read "DTC Status" parameter



B00112

5. Is parameter displayed "History(Not Present) fault"?

FLA -65

#### 🚺 ΝΟΤΕ

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

#### YES

Fault is intermittent caused by poor contact in the sensor's and/or PCM's connector or was repaired and PCM memory was not cleared. Thoroughly check connectors for loose or poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

#### NO

Go to next step as below.

#### TERMINAL AND CONNECTOR INSPECTION E82F9007

- 1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?



Repair as necessary and go to "Verification of Vehicle Repair" procedure

ن سامانه دیجیتال تعمیرکاران خودرو د<mark>ر کر</mark>

Go to "Power Supply Circuit Inspection" procedure.

#### POWER SUPPLY CIRCUIT INSPECTION E593E8AC

- 1. Ignition "OFF".
- 2. Disconnect HO2S sensor connecto.
- 3. Ignition "ON" & Engine "OFF"
- 4. Measure voltage between terminal 3 of the HO2S heater harness connector and chassis ground.

Specification : Approx. B+

5. Is voltage within the specification?



Go to "Control Circuit Inspection" procedure.

#### NO

Check for an open in the power supply circuit between the main relay and the HO2S Especially check for "10A Sensor fuse" is installed and not blown. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

FUEL SYSTEM

#### CONTROL CIRCUIT INSPECTION EF27A51B

- 1. Check for open in control harness.
  - 1) Ignition "OFF".
  - 2) Disconnect PCM connector
  - Measure resistance between terminals 4 of the HO2S heater harness connector and 9 of the PCM harness connector.

Specification : Approx 0

4) Is resistance within the specification?



Go to next step as below

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

2. Check for short to ground in control circuit.

1) Measure resistance between terminal 4 of the HO2S heater harness connector and chassis ground.

Specification : infinite

2) Is resistance within the specification?

Go to next step as below

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

- 3. Check for short to power in control circuit.
  - 1) Reconnect the PCM connector.
  - 2) Ignition "ON" & Engine "OFF"
  - 3) Measure voltage between terminal 4 of the HO2S heater harness connector and chassis ground

Specification : Approx 0V

4) Is voltage within the specification?

YES

Go to "Component Inspection" procedure.

NO

Repair open or short to ground in control circuit and go to "Verification of Vehicle Repair" procedure

### WWW.DIGITALKHODRO.COM

#### COMPONENT INSPECTION ECC7D3BE

- 1. Ignition "OFF".
- 2. Measure resistance between terminals 3 and 4 of the sensor connector (Component side)

#### SPECIFICATION

Temp.( )	Temp.( )	Rear HO2S Heater Resistance( )	Temp.( )	Temp.( )	Rear HO2S Heater Resistance( )
20	68	9.2	500	932	19.2
100	212	10.7	600	1,112	20.7
200	392	13.1	700	1,292	22.5
300	572	14.6	800	1,472	25.1
400	752	17.7	900	1,652	26.5



Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Check HO2S for contamination, deterioration, or damage. Substitute with a known-good HO2S and check for proper operation. If the problem is corrected, replace HO2S and then go to "Verification of Vehicle Repair" procedure.

#### **FUEL SYSTEM**

#### VERIFICATION OF VEHICLE REPAIR EACDCAB8

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode
- 2. Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 3. Read "DTC Status" parameter
- 4. Is parameter displayed "History(Not Present) fault"?



System performing to specification at this time. Clear the DTC

#### NO

Go to the applicable troubleshooting procedure.



ولین سامانه دیجیتال تعمیرکاران خودرو در ایران



FLA -69

#### DTC P0037 HO2S HEATER CIRCUIT LOW (BANK 1 / SENSOR 2)

#### COMPONENT LOCATION E4D2EEFD

Refer to DTC P0036.

#### GENERAL DESCRIPTION EFE5A5FC

Refer to DTC P0036.

#### DTC DESCRIPTION EC9DDB98

PCM sets DTC P0037 if the PCM detects that the rear HO2S heater control line is short to ground.

#### DTC DETECTING CONDITION EOFCB009

ltem	Detecting Condition	Possible Cause
DTC Strategy	Check short circuit to ground on front HO2S heater line	
Enable Conditions	Battery voltage > 10V 1% < Heater power < 99%	Related fuse blown or missing Open or short to ground in power supply or control harness
Threshold Value	Short to ground	Contact resistance in
Diagnostic Time	شرکت دیجیتال خودرو سا .10 میں	connectors Faulty HO2S
Fail-Safe	Heater open loop control	
فمدر مدر الدان	اولين سامانه در جيتال تعميركاران	

#### SPECIFICATION E33ACFA2

Temp.( )	Temp.( )	Rear HO2S Heater Resistance( )	Temp.( )	Temp.( )	Rear HO2S Heater Resistance( )
20	68	9.2	500	932	19.2
100	212	10.7	600	1,112	20.7
200	392	13.1	700	1,292	22.5
300	572	14.6	800	1,472	25.1
400	752	17.7	900	1,652	26.5

#### SCHEMATIC DIAGRAM E76C7611

Refer to DTC P0036.

SIGNAL WAVEFORM E2E4B3B6

Refer to DTC P0036.

#### MONITOR DTC STATUS E8E19ABD

Refer to DTC P0036.

FUEL SYSTEM

#### TERMINAL AND CONNECTOR INSPECTION ED4DFE33

Refer to DTC P0036.

#### POWER SUPPLY CIRCUIT INSPECTION EFEF1D41

- 1. Ignition "OFF".
- 2. Disconnect HO2S sensor connecto.
- 3. Ignition "ON" & Engine "OFF"
- 4. Measure voltage between terminal 3 of the HO2S heater harness connector and chassis ground.

Specification : Approx. B+

5. Is voltage within the specification?

#### YES

Go to "Control Circuit Inspection" procedure.

NO

Check for an open in the power supply circuit between the main relay and the HO2S Especially check for "10A Sensor fuse" is installed and not blown. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### CONTROL CIRCUIT INSPECTION E489EB5E

- 1. Check for open in control harness.
  - 1) Ignition "OFF".
  - 2) Disconnect the PCM connector
  - 3) Measure resistance between terminals 4 of the HO2S heater harness connector and 9 of the PCM harness connector.

Specification : Approx 0

4) Is resistance within the specification?



Go to next step as below

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

- 2. Check for short to ground in control circuit.
  - 1) Measure resistance between terminal 4 of the HO2S heater harness connector and chassis ground.

Specification : infinite

### WWW.DIGITALKHODRO.COM

### 021- 62 99 92 92

2) Is resistance within the specification?



Go to "Component Inspection" procedure



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### COMPONENT INSPECTION EA764057

Refer to DTC P0036.

#### VERIFICATION OF VEHICLE REPAIR E3B35FDA

Refer to DTC P0036.







#### FUEL SYSTEM

### DTC P0038 HO2S HEATER CIRCUIT HIGH (BANK 1 / SENSOR 2)

#### COMPONENT LOCATION ED754112

Refer to DTC P0036.

#### GENERAL DESCRIPTION EC3E4E24

Refer to DTC P0036.

#### DTC DESCRIPTION EFCE9DB9

PCM sets DTC P0038 if the PCM detects that the rear HO2S heater control line is open or short to battery line.

#### DTC DETECTING CONDITION EAAEFC3E

ltem	Detecting Condition	Possible Cause		
DTC Strategy	Check open or short circuit to battery line on front HO2S heater line			
Enable Conditions	Battery voltage > 10V 1% < Heater power < 99%	Open or short to battery in control harness Contact resistance in		
Threshold Value	Open or short to battery	connectors		
Diagnostic Time	شرکت دیجیتال جودرو سامه 10 sec.	Faulty HO2S		
Fail-Safe	Heater open loop control			
ودرودر ایران	ا اولین سامانه دیجیتال تعمیر کاران ح			

#### SPECIFICATION E8E18ACB

Temp.( )	Temp.( )	Rear HO2S Heater Resistance( )	Temp.( )	Temp.( )	Rear HO2S Heater Resistance( )
20	68	9.2	500	932	19.2
100	212	10.7	600	1,112	20.7
200	392	13.1	700	1,292	22.5
300	572	14.6	800	1,472	25.1
400	752	17.7	900	1,652	26.5

#### SCHEMATIC DIAGRAM EBA4AFCB

Refer to DTC P0036.

#### SIGNAL WAVEFORM EE256D5E

Refer to DTC P0036.

#### MONITOR DTC STATUS E31BC367

Refer to DTC P0036.

### WWW.DIGITALKHODRO.COM
### TERMINAL AND CONNECTOR INSPECTION EEDFDAEA

Refer to DTC P0036.

### CONTROL CIRCUIT INSPECTION E4205E7B

- 1. Check for open in control harness.
  - 1) Ignition "OFF".
  - 2) Disconnect HO2S and PCM connectors.
  - 3) Measure resistance between terminals 4 of the HO2S heater harness connector and 9 of the PCM harness connector.

Specification : Approx 0

4) Is resistance within the specification?

YES

NO

Go to next step as below

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

2. Check for short to ground in control circuit.

1) Reconnect the PCM connector.

2) Ignition "ON" & Engine "OFF".

3) Measure voltage between terminal 4 of the HO2S heater harness connector and chassis ground.

Specification : Approx 0V

4) Is resistance within the specification?

#### YES

Go to "Component Inspection" procedure

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### COMPONENT INSPECTION E9CA05EE

Refer to DTC P0036.

### VERIFICATION OF VEHICLE REPAIR E1F0A3F4

Refer to DTC P0036.

### Co to "Component Inspection" -

FUEL SYSTEM

## DTC P0076 INTAKE VALVE CONTROL SOLENOID CIRCUIT LOW (BANK 1)

## COMPONENT LOCATION EE1769A8



EGQE603M

#### GENERAL DESCRIPTION EB2826A2

The CVVT (Continuously Variable Valve Timing) system built on the camshaft helps the engine decrease the exhaust gas and increase engine power and fuel economy by changing the valve open/close timing of the intake camshaft continuously. The intake valve control solenoid, the main control part of the CVVT, changes the direction of the oil path through the CVVT by the duty control of the PCM and changes the open and close timing of the intake and exhaust valves.

#### DTC DESCRIPTION EF2D8CBC

PCM sets DTC P0076 if the PCM detects that the intake valve control solenoid control circuit is short to ground.

#### DTC DETECTING CONDITION E1EB0226

ltem	Detecting Condition	Possible Cause
DTC Strategy	Electrical check	
Enable Conditions	100mS after ignition key ON 10 < Battery voltage < 16	Short to ground in control circuit Contact resistance in
Threshold Value	Short to ground	connectors Faulty Intake Valve Control
Diagnostic Time	2 seconds.	Solenoid
Fail-Safe	No intake valve control solenoid activity	

#### SPECIFICATION EDFDCF25

Intake valve control solenoid	Normal Parameter
Insulation Resistance ()	above 50 MΩ

Temp.( )	Temp.( )	Resistance()	Temp.( )	Temp.( )	Resistance()			
0	32	6.2 ~ 7.4	60	140	8.0 ~ 9.2			

## WWW.DIGITALKHODRO.COM

FLA -75

10	50	6.5 ~ 7.7	70	158	8.3 ~ 9.5
20	68	6.8 ~ 8.0	80	176	8.6 ~ 9.8
30	86	7.1 ~ 8.3	90	194	8.9 ~ 10.1
40	104	7.4 ~ 8.6	100	212	9.2 ~ 10.4
50	122	7.7 ~ 8.9			

#### SCHEMATIC DIAGRAM EAODFECA



FLA -76

#### **FUEL SYSTEM**

SIGNAL WAVEFORM E603DCC0



- 2. Press F4(DTAL) to select DTC information from the DTCs menu
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions
- 4. Read "DTC Status" parameter



B00112

5. Is parameter displayed "History(Not Present) fault"?

#### 🚺 ΝΟΤΕ

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

## YES

Fault is intermittent caused by poor contact in the sensor's and/or PCM's connector or was repaired and PCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

#### NO

Go to "Component Inspection" procedure

#### COMPONENT INSPECTION EBOAE9DD

1. Ignition "OFF".

SPECIFICATION

- 2. Disconnect intake valve control solenoid connector.
- 3. Measure resistance between terminals 1 and 2 of the solenoid connector(Component side).

Temp.( )	Temp.( )	Resistance()	Temp.( )	Temp.( )	Resistance()
یت م•دود	مانه (32سئول	6.2 ~ 7.4	شر60ت دیا	140	8.0 ~ 9.2
10	50	6.5 ~ 7.7	70	158	8.3 ~ 9.5
20	یر کار68 خود	انه د 8.0 ~ 8.0 زمره	او 80ن ساد	176	8.6 ~ <mark>9.8</mark>
30	86	7.1 ~ 8.3	90	194	8.9 ~ 10.1
40	104	7.4 ~ 8.6	100	212	9.2 ~ 10.4
50	122	7.7 ~ 8.9			

<C166>



Intake Valve Control
 Battery Voltage

4. Is resistance within specification?



Go to next step as below.

B00763

FUEL SYSTEM

#### FLA -78

#### NO

Check intake valve control solenoid for contamination, deterioration, or damage. Substitute with a known-good solenoid and check for proper operation. If the problem is corrected, replace solenoid and then go to "Verification of Vehicle Repair" procedure.

#### POWER SUPPLY CIRCUIT INSPECTION E3B1266A

- 1. Ignition "ON" & Engine "OFF"
- 2. Measure voltage between terminal 2 of the intake valve control solenoid harness connector and chassis ground.

Specification : Approx. B+

3. Is voltage within specification?

YES

Go to "Control Circuit Inspection" procedure.

NO

Repair open or short to ground in the power supply circuit and go to "Verification of Vehicle Repair" procedure.

#### CONTROL CIRCUIT INSPECTION E5FA2468

1. Measure resistance between terminal 1 of the intake valve control solenoid harness connector and chassis ground.

Specification : Infinite

2. Is resistance within specification?

#### YES

Go to "Terminal and Connector Inspection" procedure.

NO

Repair short to ground in control circuit and go to "Verification of Vehicle Repair" procedure.

### TERMINAL AND CONNECTOR INSPECTION EB65A1E4

- 1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure

### FLA -79

#### NO

Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### VERIFICATION OF VEHICLE REPAIR E6F9C973

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode
- 2. Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 3. Read "DTC Status" parameter
- 4. Is parameter displayed "History(Not Present) fault"?



NO

System performing to specification at this time. Clear the DTC

Go to the applicable troubleshooting procedure.

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



**FUEL SYSTEM** 

## DTC P0077 INTAKE VALVE CONTROL SOLENOID CIRCUIT HIGH (BANK 1)

#### COMPONENT LOCATION EAB79249

Refer to DTC P0076

#### GENERAL DESCRIPTION E5D02958

Refer to DTC P0076.

#### DTC DESCRIPTION E07A77D3

PCM sets DTC P0077 if the PCM detects that the OCV control circuit is open or short to battery.

#### DTC DETECTING CONDITION ED6E4CEC

Item	Detecting Condition	Possible Cause		
DTC Strategy	Electrical check	_ Open or short to battery		
Enable Conditions	100mS after ignition key ON 10 < Battery voltage < 16	in control circuit Contact resistance in		
Threshold Value	Open or short to battery	<ul> <li>connectors</li> <li>Faulty Intake Valve Control</li> </ul>		
Diagnostic Time	2 seconds.	Solenoid		

#### SPECIFICATION E3C2BB70

Intake valve control solenoid	Normal Parameter
Insulation Resistance ( )	above 50 MΩ

Temp.( )	Temp.( )	Resistance()	Temp.( )	Temp.( )	Resistance( )
0	32	6.2 ~ 7.4	60	140	8.0 ~ 9.2
10	50	6.5 ~ 7.7	70	158	8.3 ~ 9.5
20	68	6.8 ~ 8.0	80	176	8.6 ~ 9.8
30	86	7.1 ~ 8.3	90	194	8.9 ~ 10.1
40	104	7.4 ~ 8.6	100	212	9.2 ~ 10.4
50	122	7.7 ~ 8.9			

#### SCHEMATIC DIAGRAM EE7D69E9

Refer to DTC P0076.

#### SIGNAL WAVEFORM EBFD1E83

Refer to DTC P0076.

### MONITOR DTC STATUS EFE3849C

Refer to DTC P0076.

### COMPONENT INSPECTION E12A02FE

Refer to DTC P0076.

### CONTROL CIRCUIT INSPECTION EFBC4B83

- 1. Ignition "OFF".
- 2. Disconnect intake valve control solenoid and PCM connectors.
- 3. Ignition "ON".

YES

4. Measure voltage between terminals 1 of the intake valve control solenoid connector and chassis ground.

Specification : Below 0.5V

5. Is voltage within specification?



نت دیجیتال خود و سامانه (مسئولیت NOL)

Repair short to power in harness and go to "Verification of Vehicle Repair" procedure.

#### TERMINAL AND CONNECTOR INSPECTION EC3D99F8

Refer to DTC P0076.

#### VERIFICATION OF VEHICLE REPAIR E0326EFF

Refer to DTC P0076.

FUEL SYSTEM

### DTC P0101 MASS OR VOLUME AIR FLOW CIRCUIT RANGE/PERFORMANCE

#### COMPONENT LOCATION EEODDCAS



#### GENERAL DESCRIPTION E13A82A4

The Mass Air Flow Sensor (MAFS) is located between the air cleaner assembly and the throttle body. The MAFS uses a hot film type sensing element to measure the mass of intake air entering the engine. This hot film type air flow sensor consists of a hot film sensor, housing and metering ducts. Mass air flow rate is measured by detection of heat transfer from a hot film probe. The change in air flow rate causes change in the amount of heat being transferred from the hot film probe surface to the air. A large amount of intake air represents acceleration or high load conditions while a small amount of intake air represents deceleration or idle. The mass of intake air should increase at acceleration and be stable during constant engine speed. The PCM uses this information to determine the injection duration and ignition timing for the desired air/fuel ratio.

#### DTC DESCRIPTION E6CA391F

The PCM compares the actual measured Mass Air Flow signal to the modeled Mass Air Flow value and sets the DTC P0101 when the difference between these two value is too high or too low with lambda deviation in opposite direction. The PCM illuminates the MIL on the second consecutive driving cycle that the diagnostic runs and fails. The modeled Mass Air Flow value is determined by engine speed, throttle angle and ICA duty.

ltem	Detecting Condition	Possible Cause
DTC Strategy	Compare calculated MAF with MAF signal	Dirty air cleaner.
Enable Conditions	No relevant failure 11 Battery voltage 16V Lambda control active	Oil Cap or Dipstick missing or not installed correctly. Air leak in intake system.
Threshold Value	Calculated MAF - Measured MAF > 300 mg/rev	Contact resistance in connectors.
Diagnostic Time	200 revolutions.	Faulty MAFS or TPS

#### DTC DETECTING CONDITION E8AAB726

## WWW.DIGITALKHODRO.COM

## DTC TROUBLESHOOTING PROCEDURES

#### SPECIFICATION ED8414BB

Test Comdition	MAF(V)	MAF(kg/h)	TPS(V)	TPS(kΩ)
Idle	0.6 ~ 1.0	11.66 ~ 19.85	0.2 ~ 0.8	0.71 ~ 1.38
3000 rpm	1.7 ~ 2.0	43.84 ~ 58.79	-	-
W.O.T	-	-	4.3 ~ 4.8	0.2 ~ 3.4

#### SCHEMATIC DIAGRAM EF18D23A



#### SIGNAL WAVEFORM E42809CD

	1.5 U	URRE	NT DA	ATA					1.3	CURRE	NT DA	АТА				1.3 FLIGHT REC	ORD	
M M	ASS AIR FLOW ASS AIR FLOW NGINE SPEED			0.70	kg/h V rpm	•	×	MASS	AIR FLO AIR FLO NE SPEE	OW(V)		22.5 kg 1.13 V 862 rg		0.5		THROTTLE P.SENSOR()	r) V	-
														0.0 5.0 2.5 0.0		MASS AIR FLOW(V)	v 	~
F	IX PART F	ULL	HELP	GRPH	RCRD			FIX	PART	FULL	HELP	GRPH R	CRD	L	IST	[T-39]	FIX	HOME
Fig 1							Fig	2						Fig :	3			

Fig 3) Normal value with accelerating and decelerating : The MAFS and TPS signals increase at the same time with accelerating and decrease with releasing accelerator pedal

B01012

#### **FUEL SYSTEM**

#### MONITOR DTC STATUS EA2DEEC6

#### 🔟 ΝΟΤΕ

If any codes relating to TPS or MAFS are stored, do ALL REPAIRS associated with those codes before proceeding with further troubleshooting.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode
- 2. Press F4(DTAL) to select DTC information from the DTCs menu
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions
- 4. Read "DTC Status" parameter
- 5. Is parameter displayed "History(Not Present) fault"?



- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

#### YES

Fault is intermittent caused by poor contact in the sensor's and/or the PCM's connector, which was repaired but PCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

#### NO

Go to next step as below.

#### AIR CLEANER INSPECTION

1. Check air cleaner condition. Is air cleaner clogged with dirt?

#### YES

Replace air cleaner and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Air Leakage Inspection" procedure

#### AIR LEAKAGE INSPECTION E3EBF459

- 1. Check Check intake tube, breather hose and MAFS for source of any air leaks. Are there any cracks in intake tube, MAFS or breather hose.
- 2. Verify Verify oil cap and dipstick are properly installed and oil cap screwed on completely.
- 3. Has a problem been found?

YES

Repair or Replace as necessary and go to "Verification of Vehicle Repair" procedure.

## WWW.DIGITALKHODRO.COM

## NO

Go to "TPS Inspection" procedure

#### **TPS INSPECTION**

- 1. Ignition "ON" & Engine "OFF".
- 2. Install Scantool and monitor the "THROTTLE P.SENSOR(V)" parameter on the Scantool data list.

```
Specification :
Approx. 0.25~0.80V(Closed throttle Valve)
Approx 4.0~4.4V(Wide Open Throttle)
```

3. Is "THROTTLE P.SENSOR(V)" within specification?

## YES

Go to "Terminal and Connector Inspection" procedure.

#### NO

Inspect TP sensor and W/harness and repair or replace as necessary. Go to "Verification of Vehicle Repair" procedure

#### TERMINAL AND CONNECTOR INSPECTION EBB3F16B

- 1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

#### YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure

NO

Go to "Component Inspection" procedure.

#### COMPONENT INSPECTION EE4C4FE6

- 1. Engine "ON".
- 2. Install Scantool and monitor the "MASS AIR FLOW(V)" parameter on the Scantool data list.

```
Specification : Approx. 0.6 ~ 1.0V at idle & No load
```

3. Is MAF sensor voltage near the specified value?



Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### 021-62999292

**FUEL SYSTEM** 

#### FLA -86

#### NO

Check MAF for contamination, deterioration, or damage. Substitute with a known-good MAF and check for proper operation. If the problem is corrected, replace MAF and then go to "Verification of Vehicle Repair" procedure.

#### VERIFICATION OF VEHICLE REPAIR EFO3CE7C

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode
- 2. Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 3. Read "DTC Status" parameter
- 4. Is parameter displayed "History(Not Present) fault"?



NO

System performing to specification at this time. Clear the DTC

Go to the applicable troubleshooting procedure.

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران



FLA -87

### DTC P0102 MASS OR VOLUME AIR FLOW CIRCUIT LOW INPUT

#### COMPONENT LOCATION ED8E2CE0

Refer to DTC P0101.

#### GENERAL DESCRIPTION E00BD2F9

Refer to DTC P0101.

#### DTC DESCRIPTION E5B2A99C

PCM sets DTC P0102 if the PCM detects signal voltage lower than the possible range of a properly operating MAF sensor.

#### DTC DETECTING CONDITION ETAGEBOC

ltem	Detecting Condition	Possible Cause
DTC Strategy	Voltage range check	Open or short to ground
Enable Conditions	11 Battery voltage 16V Engine speed > Approx. 540 rpm	in signal circuit. Open in power supply circuit.
Threshold Value	Measured MAF < 2 kg/h	Contact resistance in connections.
Diagnostic Time	10 revolutions.	Faulty MAF sensor.

#### SPECIFICATION EC66F40E

Test Comdition	MAF(V)	MAF(kg/h)	TPS(V)	<b>TPS(</b> kΩ)
Idle	0.6 ~ 1.0	11.66 ~ 19.85	0.2 ~ 0.8	0.71 ~ 1.38
3000 rpm	1.7 ~ 2.0	43.84 ~ 58.79	-	-
W.O.T	-	-	4.3 ~ 4.8	0.2 ~ 3.4

#### SCHEMATIC DIAGRAM E8F9220D

Refer to DTC P0101.

#### SIGNAL WAVEFORM E30AE0AA

Refer to DTC P0101.

#### MONITOR DTC STATUS EF9E4EB1

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode
- 2. Press F4(DTAL) to select DTC information from the DTCs menu
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions
- 4. Read "DTC Status" parameter

## WWW.DIGITALKHODRO.COM

**FUEL SYSTEM** 

	1.4 AMBIENT CONDITIONS
To naviate to the "DTAL"menu	
01 HYUNDAI VEHICLE DIAGNOSIS	
Select model and year	1. MIL STATUS
└─▶ 02 ENGINE	2. DTC STATUS: <u>PRESENT</u>
Select engine	3. DTC READINESS FLAG : <u>COMPLETE</u>
→ 01 DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC
PART ERAS DTAL HELP	6. OP.HOUR AFTER ERASURE OF DTC

B00112

5. Is parameter displayed "History(Not Present) fault"?

#### 🔟 ΝΟΤΕ

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.



NO

Fault is intermittent caused by poor contact in the sensor's and/or the PCM's connector, which was repaired but PCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

Go to next step as below.

## TERMINAL AND CONNECTOR INSPECTION EGEICC3E

- 1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?



Repair as necessary and go to "Verification of Vehicle Repair" procedure

NO

Go to "Power Supply Circuit Inspection" procedure.

### POWER SUPPLY CIRCUIT INSPECTION EAA572CE

1. Ignition "OFF".

- 2. Disconnect MAF sensor connector.
- 3. Ignition "ON" & Engine "OFF"
- 4. Measure voltage between terminal 2 of the sensor harness connector and chassis ground.

Specification : Approx. B+

5. Is voltage within the specification?

## YES

Go to "Signal Circuit Inspection" procedure.

#### NO

Check for an open or short to ground in the power supply circuit between the MAF sensor and main relay. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### SIGNAL CIRCUIT INSPECTION EDADBF41

- 1. Check for open in signal harness.
  - 1) Ignition "OFF".
  - 2) Disconnect PCM connector.

3) Measure resistance between terminals 3 of sensor harness connector and 60 of the PCM harness connector.

#### Specification : Approx. 0

4) Is resistance within the specification?

#### YES

Go to next step as below

NO

Check for an open in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

- 2. Check for short to ground in signal harness.
  - 1) Measure resistance between terminal 3 of sensor harness connector and chassis ground.

Specification : Infinite

2) Is resistance within the specification?



Go to "Component Inspection" procedure.

#### NO

Check for short to ground in signal harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

## WWW.DIGITALKHODRO.COM

FLA -90

#### COMPONENT INSPECTION E1AB965B

Refer to DTC P0101.

#### VERIFICATION OF VEHICLE REPAIR E45FOCD5

Refer to DTC P0101.



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



**FUEL SYSTEM** 

FLA -91

## DTC P0103 MASS OR VOLUME AIR FLOW CIRCUIT HIGH INPUT

#### COMPONENT LOCATION E32AEDB0

Refer to DTC P0101.

#### GENERAL DESCRIPTION E1FB8B32

Refer to DTC P0101.

#### DTC DESCRIPTION E69B39C7

PCM sets DTC P0103 if the PCM detects signal voltage higher than the possible range of a properly operating MAF sensor.

#### DTC DETECTING CONDITION E85BCECC

Item	Detecting Condition	Possible Cause
DTC Strategy	Voltage range check	Open in ground harness.
Enable Conditions	10 Battery voltage 16V Engine speed > Approx. 540 rpm	Short to battery in signal harness.
Threshold Value	Measured MAF > 650 kg/h	Contact resistance in connections.
Diagnostic Time	شرکت دیجیتال خود .10 revolutions	Faulty MAF sensor.

## SPECIFICATION EDC62C5A prost line of the l

Test Comdition	MAF(V)	MAF(kg/h)	TPS(V)	TPS(kΩ)
Idle	0.6 ~ 1.0	11.66 ~ 19.85	0.2 ~ 0.8	0.71 ~ 1.38
3000 rpm	1.7 ~ 2.0	43.84 ~ 58.79	-	-
W.O.T	-	-	4.3 ~ 4.8	0.2 ~ 3.4

### SCHEMATIC DIAGRAM EOD9DB6A

Refer to DTC P0101.

SIGNAL WAVEFORM E570AF6D

Refer to DTC P0101.

### MONITOR DTC STATUS EAEEE775

Refer to DTC P0101.

## TERMINAL AND CONNECTOR INSPECTION ECICFCEF

1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

## 021-62999292

#### FLA -92

#### **FUEL SYSTEM**

- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

#### YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure

#### NO

Go to "Ground Circuit Inspection" procedure.

#### GROUND CIRCUIT INSPECTION EB75F1FA

- 1. Ignition "OFF".
- 2. Disconnect MAF sensor connector.
- 3. Measure resistance between terminal 1 of the sensor harness connector and chassis ground.

S	pecification : Approx. 0	
4.	Is resistance within the specification?	
	YES	
	Go to "Signal Circuit Inspection" procedure.	
	اولین سامانه دیجیتال تعمیرکاران خودرو در 🛛 NO	

Check for an open or short to battery in harness. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### SIGNAL CIRCUIT INSPECTION EEF5499D

- 1. Ignition "ON" & Engine "OFF".
- 2. Measure voltage between terminal 3 of sensor harness connector and chassis ground.

Specification : Approx. 0V

3. Is MAF sensor voltage within the specification?



Go to "Component Inspection" procedure.

NO

Repair short to battery in harness and go to "Verification of Vehicle Repair" procedure.

#### COMPONENT INSPECTION EB2DDAE9

Refer to DTC P0101.

## VERIFICATION OF VEHICLE REPAIR E0A04EBD

Refer to DTC P0101.



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



FLA -93

FUEL SYSTEM

### DTC P0111 INTAKE AIR TEMPERATURE SENSOR1 CIRCUIT RANGE/PERFORMANCE

#### COMPONENT LOCATION EEADOB7D



#### GENERAL DESCTIPTION E4AB7985

The Intake Air Temperature Sensor (IATS) is installed into the Mass Air Flow Sensor (MAFS). The IATS uses a thermistor whose resistance changes with the temperature. The electrical resistance of the IATS decreases as the temperature increases, and increases as the temperature decreases. The 5 V power source in the PCM is supplied to the IATS via a resistor in the PCM. That is, the resistor in the PCM and the thermistor in the IATS are connected in series. When the resistance value of the thermistor in IATS changes according to the intake air temperature, the signal voltage also changes. Using this signal, the information of the intake air temperature, the PCM corrects basic fuel injection duration and ignition timing.

#### DTC DESCRIPTION EA87D7FB

The purpose of this diagnosis is to detect a stuck intake air temperature signal. The diagnostic function checks whether after a variation of the calculated intake air temperature also a variation of the measured intake air temperature is detected. PCM sets DTC P0111 when the variation of measured intake air temperature from engine start is smaller than threshold while variation of calculated intake air temperature by PCM is greater than threshold.

### DTC DETECTING CONDITION E5119C9A

ltem	Detecting Condition	Possible Cause	
DTC Strategy	Check intake air temperature signal stuck.		
Enable Conditions	Time after engine start > 300sec. Coolant temp. > 76 (169) Coolant temp. increasing after start > 40 (104) Vehicle speed < 5km/h(3 mph) No relevant failure	Contact resistance in connections.	
Threshold value Difference between intake air temp. at stat and minimum air temp. < 1.5 (34.7) and difference between maximum air temp. and intake air temp. at stat and < 1.5 (34.7)		Faulty IAT sensor	
Diagonostic Time	5 sec.		

#### SPECIFICATION E02AC2A5

Temp.(°C)	Temp.(°F)	Resistance(k)	Temp.(°C)	Temp.(°F)	Resistance(k)
-20	-4	14.26 ~ 16.02	40	104	1.11 ~ 1.19
0	32	5.50 ~ 6.05	60	140	0.57 ~ 0.60
20	68	2.35 ~ 2.54	80	176	0.31 ~ 0.32

تبرکت دیجیتال خودرو سامانه (مسئولیت محدود)

### SCHEMATIC DIAGRAM E281C0AB



#### MONITOR DTC STATUS EFDD2E19

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.

## WWW.DIGITALKHODRO.COM

#### 021-62999292

#### FLA -96

**FUEL SYSTEM** 

B00112

- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter

	1.4 AMBIENT CONDITIONS
To naviate to the "DTAL"menu	
01 HYUNDAI VEHICLE DIAGNOSIS	
Select model and year	1. MIL STATUS
└→ 02 ENGINE	2. DTC STATUS: <u>PRESENT</u>
Select engine	3. DTC READINESS FLAG : <u>COMPLETE</u>
<b>01</b> DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC
PART ERAS DTAL HELP	6. OP.HOUR AFTER ERASURE OF DTC

5. Is parameter displayed "History(Not Present) fault"?

NOTE OF THE OF T	
<ul> <li>History (Not Present) fault : DTC occurred but has been cleared.</li> <li>Present fault : DTC is occurring at present time.</li> </ul>	
YES	

Fault is intermittent caused by poor contact in the sensor's and/or the PCM's connector, which was repaired but PCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to next step as below.

### TERMINAL & CONNECTOR INSPECTION E3FF6D18

- 1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

3. Has a problem been found?

## YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

### NO

Go to "Component Inspection" procedure .

#### COMPONENT INSPECTION E8091B23

- 1. Ignition "OFF"
- 2. Disconnect IATS connector.
- 3. Measure resistance between terminals 1 and 5 of the sensor connector(Component side).

#### SPECIFICATION

Temp.(°C)	Temp.(°F)	Resistance(k)	Temp.(°C)	Temp.(°F)	Resistance(k )
-20	-4	14.26 ~ 16.02	40	104	1.11 ~ 1.19
0	32	5.50 ~ 6.05	60	140	0.57 ~ 0.60
20	68	2.35 ~ 2.54	80	176	0.31 ~ 0.32

## شرکت دیجیتال خودرو سامانه (مسئولیت<113>دود)



B01111

4. Is resistance within the specification?

### YES

Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Check IATS for contamination, deterioration, or damage. Substitute with a known-good IATS and check for proper operation. If the problem is corrected, replace IATS and then go to "Verification of Vehicle Repair" procedure.

#### VERIFICATION OF VEHICLE REPAIR EC9E893C

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.

## WWW.DIGITALKHODRO.COM

## 021-62999292

#### FLA -98

**FUEL SYSTEM** 

- 2. Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions
- 3. Read "DTC Status" parameter
- 4. Is parameter displayed "History(Not Present) fault"?



System performing to specification at this time. Clear the DTC



Go to the applicable troubleshooting procedure.





FLA -99

### DTC P0112 INTAKE AIR TEMPERATURE SENSOR1 CIRCUIT LOW INPUT

#### COMPONENT LOCATION E22B25BF

Refer to DTC P0111.

#### GENERAL DESCTIPTION E8199BC9

Refer to DTC P0111.

#### DTC DESCRIPTION EBDD104B

PCM sets DTC P0112 if the PCM detects signal voltage lower than the possible range of a properly operating IATS.

#### DTC DETECTING CONDITION EFBE17DC

Item Detecting Condition		Possible Cause	
DTC Strategy	Voltage range check.	Short to ground in signal	
Enable Conditions	Enable Conditions 6 < Battery voltage < 16V After 60 seconds from engine start		
Threshold value	Measured intake air temperature > 142 (287 )	connections – Faulty IAT sensor	
Diagonostic Time	5 seconds.		

#### SPECIFICATION ECCE6C5F

Temp.(°C)	Temp.(°F)	Resistance(k)	Temp.(°C)	Temp.(°F)	Resistan <mark>ce(k</mark> )
-20	-4	14.26 ~ 16.02	40	104	1.11 ~ 1.19
0	32	5.50 ~ 6.05	60	140	0.57 ~ 0.60
20	68	2.35 ~ 2.54	80	176	0.31 ~ 0.32

#### SCHEMATIC DIAGRAM EE9ED26E

Refer to DTC P0111.

#### 021-62999292

#### **FLA -100**

#### **FUEL SYSTEM**

#### SIGNAL WAVEFORM E37A59E3



Fig 2) Short to ground in signal circuit : Approx. 0V

#### MONITOR DTC STATUS EE04F7E2

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter

	1.4 AMBIENT CONDITIONS
To naviate to the "DTAL"menu	
<b>01</b> HYUNDAI VEHICLE DIAGNOSIS	
Select model and year	1. MIL STATUS
└→02 ENGINE	2. DTC STATUS: <u>PRESENT</u>
Select engine	3. DTC READINESS FLAG : <u>COMPLETE</u>
DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC
PART ERAS DTAL HELP	6. OP.HOUR AFTER ERASURE OF DTC

B00112

B00121

5. Is parameter displayed "History(Not Present) fault"?

#### 🔟 NOTE

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

## WWW.DIGITALKHODRO.COM

### FLA -101

#### YES

Fault is intermittent caused by poor contact in the sensor's and/or the PCM's connector, which was repaired but PCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

### NO

Go to "Monitor Scantool Data" procedure

#### MONITOR SCANTOOL DATA EBA535E6

- 1. Ignition "ON" & Engine "OFF".
- 2. Disconnect IAT sensor connector.
- 3. Connect Scantool and monitor the "INT.AIR TEMP. SNSR(V)" parameter on the Scantool data list.

Specification	•	Approx	5V
Opcomodion		Appioz.	0.0

	1.3 CURRENT	DATA			
*	INT.AIR TEMP.SNSR(V) INT.AIR TEMP.SNSR	4.96 V 48.8 ℃			
	› (مسئولیت محدو باران خودرو در ایران			شرکت دیجیتال اولین سامانه در	
	FIX PART FULL HEI		•		

4. Is displayed IAT data near the specified value.?

#### YES

Possibility of sensor malfunction. Go to "Component Inspection" procedure.

NO

Possibility of signal circuit short to ground. Go to next step as below.

#### SIGNAL CIRCUIT INSPECTION E9ABABFE

- 1. Ignition "OFF".
- 2. Disconnect IATS connector.
- 3. Measure resistance between terminal 5 of the sensor harness connector and chassis ground.

Specification : Infinite

## WWW.DIGITALKHODRO.COM

#### 021-62999292

B01121

## 021-62999292

#### FLA -102

#### FUEL SYSTEM

	1.3 CURRENT	DATA	Ĵ.	<b>1.3 CURRENT DATA</b>
* *	INT.AIR TEMP.SNSR(V) INT.AIR TEMP.SNSR	2.59 V 48.0 °C	×	INT.AIR TEMP.SNSR(V) 4.96 V
		Ţ		
1	FIX PART FULL HE	LP GRPH RCRD		FIX PART FULL HELP GRPH RCRD
Fig	1		Fig	g 2
Fig	1) Signal decteases with incr Approx. 2.59V at 48℃(118		ure	and increases with decreasing sensor temperature

#### 4. Is resistance within the specification?



Refer to DTC P0111.

#### COMPONENT INSPECTION E6FBDE99

Refer to DTC P0111.

#### VERIFICATION OF VEHICLE REPAIR E19CA5AC

Refer to DTC P0111.

FLA -103

## DTC P0113 INTAKE AIR TEMPERATURE SENSOR1 CIRCUIT HIGH INPUT

#### COMPONENT LOCATION E492DCEB

Refer to DTC P0111.

#### GENERAL DESCRIPTION E6625B89

Refer to DTC P0111.

### DTC DESCRIPTION EB3DCAFD

PCM sets DTC P0113 if the PCM detects signal voltage higher than the possible range of a properly operating IATS.

### DTC DETECTING CONDITION E76F77FD

ltem	Detecting Condition	Possible Cause
DTC Strategy	Voltage range check	
Enable Conditions	6 < Battery voltage < 16V After 60 seconds from engine start	Short to battery in signal
Threshold Value	Measured intake air temperature < -46 (-51 ).	harness
Diagnostic Time	5 seconds	Open in signal or ground circuit Contact resistance in
ىئوليت محدود)	No failure detected on ECTS The limp home value of IATS depends on	connections Faulty IAT sensor
فودرو در ایران	engine coolant temperature. Failure detected on ECTS • PCM controls with mapping data.	

### SPECIFICATION E2EA2D0F

Temp.(°C)	Temp.(°F)	Resistance(k)	Temp.(°C)	Temp.(°F)	Resistance(k )
-20	-4	14.26 ~ 16.02	40	104	1.11 ~ 1.19
0	32	5.50 ~ 6.05	60	140	0.57 ~ 0.60
20	68	2.35 ~ 2.54	80	176	0.31 ~ 0.32

#### SCHEMATIC DIAGRAM EFE79210

Refer to DTC P0111.

#### FLA -104

#### **FUEL SYSTEM**

#### SIGNAL WAVEFORM EA140013

			1.3	CURR	ENT	DATA					1.	3 CURI	RENT	DATA		
* *				SNSR(V SNSR	7)		9 V 0 °C		×	INT.A	IR TEM	P.SNSR(1	7)	4.96	V	-
	FIX	PA	RT [	FULL	HELP	CDDU		<b>V</b>		DIV	PART	FULL	HELP	GRPH	PCPT	T
					11001	GRPH	KCR			FIX				Gate as	RCKI	ו
Fig	App	rox. 2	.59V	es with at 48℃	n increa	sing sen	sor tem	perat	Fig ure	2	-	with decr				
Fig	g 1) Sigr App	rox. 2	.59V	es with at 48℃	n increa	sing sen	sor tem	perat	-	2	-					
Fig Fig	g 1) Sigr App	rox. 2 ort to	.59V grou	es with at 48℃ nd in s	n increa	sing sen	sor tem	perat	-	2	-					
Fig Fig	(1) Sigr App (2) Sho (DTC (2) P011	rox. 2 ort to ST	.59V grou ATU	es with at 48 °C nd in s	n increa c(118°F ignal c	sing sen	sor temp	oV	ure	and inc	preases					
Fig Fig	(1) Sigr App (2) Sho (DTC (2) P011	rox. 2 ort to ST 1.	.59V grou ATU	es with at 48 °C nd in s S E	n increa (118°F ignal c FED1E2D	sing sen: ) ircuit : A	sor temp approx.	oV		and inc	reases ک ک شرک					
Fig Fig FOR DTC	(1) Sigr App (2) Sho (1) DTC (2) P011	rox. 2 ort to ST 1. NTC	.59V grou ATU	es with at 48 °C nd in s S EI	increa (118°F ignal c FED1E2D A EC	sing sen: ) ircuit : A	sor temp approx.	oV		and inc	reases ک ک شرک					

- 3. Connect Scantool and monitor the "INT.AIR TEMP. SNSR(V)" parameter on the Scantool data list.
- 4. Jumper the terminals 1 and 5 of the sensor harness connector together.

```
Specification : Approx. 0V
```

	1.3 CURRENT DATA	
×	INT.AIR TEMP.SNSR(V) 0.00 V	1
		_
	FIX PART FULL HELP GRPH RCRD	

5. Is IAT data near the specified value.?

B01132

### FLA -105

### YES

Possibility of sensor malfunction. Go to "Component Inspection" procedure.

#### NO

Go to next step as below.

- 6. Jumper the terminal 5 of the IATS harness connector to chassis ground.
- 7. Read "INT.AIR TEMP. SNSR(V)" parameter on the Scantool.

Specification : Approx. 0V

8. Is displayed IAT data near the specified value.?

### YES

Possibility of open in IATS ground circuit. Go to "Ground circuit inspection" procedure.

#### NO

Possibility of open or short to battery in IAT signal circuit. Go to "Signal Circuit Inspection" procedure.

### GROUND CIRCUIT INSPECTION ED5DDBCE

1. Ignition "OFF". شرکت دیجیتال خودرو سامانه (مسئو

- 2. Disconnect PCM connector.
- 3. Measure resistance between terminals 1 of the sensor harness connector and 48 of the PCM harness connector.

Specification : Approx. 0

4. Is resistance within the specification?

### YES

Go to "Terminal and Connector Inspection" procedure.

NO

Repair open circuit and go to "Verification of Vehicle Repair" procedure.

## SIGNAL CIRCUIT INSPECTION E3B94A44

- 1. Check for open in signal circuit.
  - 1) Measure resistance between terminals 5 of the sensor harness connector and 56 of the PCM harness connector.

Specification : Approx. 0

#### FLA -106

FUEL SYSTEM

2) Is resistance within the specification?



Go to next step as below.



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

- 2. Check for short to battery in signal circuit.
  - 1) Ignition "ON" & Engine "OFF".
  - 2) With IATS and PCM connector still disconnected, measure voltage between terminals 5 of sensor harness connector and 56 of the PCM harness connector.

Specification : Approx. 0V

3) Is voltage within the specification?



Go to "Terminal and Connector Inspection" procedure.

NO

Repair open circuit and go to "Verification of Vehicle Repair" procedure.

#### TERMINAL & CONNECTOR INSPECTION E7D38EC3

Refer to DTC P0111.

#### COMPONENT INSPECTION E2633D5E

Refer to DTC P0111.

#### VERIFICATION OF VEHICLE REPAIR E8DA026F

Refer to DTC P0111.

FLA -107

## DTC P0116 ENGINE COOLANT TEMPERATURE CIRCUIT RANGE/PERFORMANCE

## COMPONENT LOCATION EAE7C8BD



### GENERAL DESCTIPTION E75A263E

The Engine Coolant Temperature Sensor (ECTS) is located in the engine coolant passage of the cylinder head for detecting the engine coolant temperature. The ECTS uses a thermistor whose resistance changes with the temperature. The electrical resistance of the ECTS decreases as the temperature increases, and increases as the temperature decreases. The reference 5 V in the PCM is supplied to the ECTS via a resistor in the PCM. That is, the resistor in the PCM and the thermistor in the ECTS are connected in series. When the resistance according to the engine coolant temperature, the output voltage also changes. During cold engine operation the PCM increases the fuel injection duration and controls the ignition timing using the information of engine coolant temperature to avoid engine stalling and improve drivability.

### DTC DESCRIPTION EDD5E6B7

The purpose of this diagnosis is to detect a stuck coolant temperature signal. The diagnostic function checks whether after a variation of the calculated coolant temperature also a variation of the measured coolant temperature is detected.PCM sets DTC P0116 when the variation of measured engine coolant temperature from engine start is smaller than threshold while variation of calculated coolant temperature by PCM is greater than threshold.

ltem	Detecting Condition	Possible Cause
DTC Strategy	Check coolant temperature signal stuck.	
Enable Conditions	No ECTS failure 6 < Battery voltage < 16V	Contact resistance in
Threshold value	TCOmodel increase > Threshold But TCOmeas increase < Threshold (Threshold depends on Coolant start temp.	connections. Faulty ECT sensor
Diagonostic Time	10~30 minutes	

### DTC DETECTING CONDITION EA7D1C22

## WWW.DIGITALKHODRO.COM

#### **FUEL SYSTEM**

SPECIFICATION E66C813B

Temp.(°C)	Temp.(°F)	Resistance(k )	Temp.(°C)	Temp.(°F)	Resistance(k)
-20	-4	14.13~16.83	40	104	1.15
0	32	5.79	60	140	0.59
20	68	2.31~2.59	80	176	0.32

#### SCHEMATIC DIAGRAM EFAA09C6



B01161

# COOLANT TEMP.SNSR 0.5V 20S 4.4v @-9°C(16°F) 2.9v @ 37°C(98°F) 3.7v @ 18°C(64°F) 1.1v @ 86°C(186°F) Fig 1

E3CCC644

SIGNAL WAVEFORM

Signal decreases with increasign sensor temperature and increases with decreasing sensor temperature

A01161
#### MONITOR DTC STATUS E854F4CF

# 🔟 ΝΟΤΕ

If any codes relating to TPS or MAFS are stored, do ALL REPAIRS associated with those codes before proceeding with further troubleshooting

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode
- 2. Press F4(DTAL) to select DTC information from the DTCs menu
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions
- 4. Read "DTC Status" parameter



5. Is parameter displayed "History(Not Present) fault"?

#### 🔟 ΝΟΤΕ

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

## YES

Fault is intermittent caused by poor contact in the sensor's and/or the PCM's connector, which was repaired but PCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

#### NO

Go to next step as below.

#### TERMINAL & CONNECTOR INSPECTION E4C1DADO

- 1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

# WWW.DIGITALKHODRO.COM

# WWW.DIGITALKHODRO.COM

# FLA -110

FUEL SYSTEM

3. Has a problem been found?

## YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure

#### NO

Go to "Component Inspection" procedure

#### COMPONENT INSPECTION EE98E96C

- 1. Ignition "OFF"
- 2. Disconnect ECTS connector
- 3. Measure resistance between terminals 1 and 3 of the sensor connector(Component side)

#### SPECIFICATION

Temp.(°C)	Temp.(°F)	Resistance(k )	Temp.(°C)	Temp.(°F)	Resistance(k )
-20	-4	13.13~16.83	40	104	1.15
0	32	5.79	60	140	0.59
20	68	2.31~2.59	80	176	0.32





B01162

4. Is resistance within the specification?

#### YES

Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Check ECTS for contamination, deterioration, or damage. Substitute with a known-good ECTS and check for proper operation. If the problem is corrected, replace ECTS and then go to "Verification of Vehicle Repair" procedure.

#### VERIFICATION OF VEHICLE REPAIR ED5FED7D

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode

# WWW.DIGITALKHODRO.COM

# DTC TROUBLESHOOTING PROCEDURES

- 2. Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions
- 3. Read "DTC Status" parameter
- 4. Is parameter displayed "History(Not Present) fault"?



System performing to specification at this time. Clear the DTC



Go to the applicable troubleshooting procedure.



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



FUEL SYSTEM

# DTC P0117 ENGINE COOLANT TEMPERATURE CIRCUIT LOW INPUT

#### COMPONENT LOCATION E931AC5D

Refer to DTC P0116.

#### GENERAL DESCRIPTION ED3E7156

Refer to DTC P0116.

## DTC DESCRIPTION E8E59FDF

PCM sets DTC P0117 if the PCM detects signal voltage lower than the possible range of a properly operating ECTS.

## DTC DETECTING CONDITION EBA8BGEE

ltem	Detecting Condition	Possible Cause	
DTC Strategy	Voltage range check	Short to ground in signal	
6 < Battery voltage < 16V		harness Contact resistance in connections. Faulty ECT sensor	
Threshold value	Measured coolant temperature > 138 (280 ).		
Diagonostic Time	5 sec.		
Fall Safe	The limp-home value of ECTS depends on		
	intake air temperature.		

## SPECIFICATION EE1F7CE2

Temp.(°C)	Temp.(°F)	Resistance(k )	Temp.(°C)	Temp.(°F)	Resistance(k )
-20	-4	14.13~16.83	40	104	1.15
0	32	5.79	60	140	0.59
20	68	2.31~2.59	80	176	0.32

# SCHEMATIC DIAGRAM EC1641EC

Refer to DTC P0116.

#### SIGNAL WAVEFORM E0803889



# MONITOR DTC STATUS E41C6D98

1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.

- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.

	1.4 AMBIENT CONDITIONS
To naviate to the "DTAL"menu	
<b>01</b> HYUNDAI VEHICLE DIAGNOSIS	
Select model and year	1. MIL STATUS
└→02 ENGINE	2. DTC STATUS: <u>PRESENT</u>
Select engine	3. DTC READINESS FLAG : <u>COMPLETE</u>
→ 01 DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC
PART ERAS DTAL HELP	6. OP.HOUR AFTER ERASURE OF DTC

B00112

B01171

5. Is parameter displayed "History(Not Present) fault"?

#### 🔟 ΝΟΤΕ

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

# WWW.DIGITALKHODRO.COM

# YES

**FUEL SYSTEM** 

Fault is intermittent caused by poor contact in the sensor's and/or the PCM's connector, which was repaired but PCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

#### NO

Go to "Monitor Scantool Data" procedure.

#### MONITOR SCANTOOL DATA E9BC1CA3

- 1. Ignition "ON" & Engine "OFF".
- 2. Disconnect ECTS connector.
- 3. Connect Scantool and monitor the "COOLANT TEMP. SNSR(V)" parameter on the Scantool data list.

Specification : Approx. 5V



4. Is ECTS parameter near the specified value?

#### YES

Possibility of sensor malfunction. Go to "Component Inspection" procedure.

NO

Possibility of signal circuit short to ground. Go to next step as below.

#### SIGNAL CIRCUIT INSPECTION E5B18AAC

- 1. Ignition "OFF".
- 2. Measure resistance between terminal 1 of the sensor harness connector and chassis ground.

Specification : Infinite

3. Is resistance within the specification?

# WWW.DIGITALKHODRO.COM

# YES

Go to "Terminal and Connector Inspection" procedure.

#### NO

Repair short to ground in harness and go to "Verification of Vehicle Repair" procedure.

#### TERMINAL & CONNECTOR INSPECTION EF6F9FAE

Refer to DTC P0116.

#### COMPONENT INSPECTION E292BEBD

Refer to DTC P0116.

#### VERIFICATION OF VEHICLE REPAIR E802FC2A

Refer to DTC P0116.

**حیجیتال خودرو** سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران





#### FLA -115

**FUEL SYSTEM** 

# DTC P0118 ENGINE COOLANT TEMPERATURE CIRCUIT HIGH INPUT

#### COMPONENT LOCATION EFADFC78

Refer to DTC P0116.

#### GENERAL DESCRIPTION E4F3DA8F

Refer to DTC P0116.

## DTC DESCRIPTION EEC9EFFB

PCM sets DTC P0118 if the PCM detects signal voltage higher than the possible range of a properly operating ECTS.

# DTC DETECTING CONDITION ESFAG6F4

ltem	Detecting Condition	Possible Cause
DTC Strategy	Voltage range check	
Enable Conditions	6 < Battery voltage < 16V After 110 seconds from engine start in case of short ci <mark>rc</mark> uit to B+ or open circuit	Short to ground in signal harness
Threshold value	Measured coolant temperature < -46 (-51 ).	Contact resistance in connections.
Diagonostic Time	5 sec.	Faulty ECT sensor
Fall Safe The limp-home value of ECTS depends on intake air temperature.		

## SPECIFICATION E01AC30F

Temp.(°C)	Temp.(°F)	Resistance(k )	Temp.(°C)	Temp.(°F)	Resistance(k )
-20	-4	14.13~16.83	40	104	1.15
0	32	5.79	60	140	0.59
20	68	2.31~2.59	80	176	0.32

## SCHEMATIC DIAGRAM E27A31A6

Refer to DTC P0116.

## DTC TROUBLESHOOTING PROCEDURES

#### SIGNAL WAVEFORM EFD5B81B



# MONITOR DTC STATUS EC88561B

1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.

- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions Read "DTC Status" parameter.
- 4. Read "DTC Status" parameter.

	1.4 AMBIENT CONDITIONS
To naviate to the "DTAL"menu	
<b>01</b> HYUNDAI VEHICLE DIAGNOSIS	
Select model and year	1. MIL STATUS
└→02 ENGINE	2. DTC STATUS: <u>PRESENT</u>
Select engine	3. DTC READINESS FLAG : <u>COMPLETE</u>
DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC
PART ERAS DTAL HELP	6. OP.HOUR AFTER ERASURE OF DTC

B00112

5. Is parameter displayed "History(Not Present) fault"?

#### 🔟 ΝΟΤΕ

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

# WWW.DIGITALKHODRO.COM

**FUEL SYSTEM** 

# FLA -118

# YES

Fault is intermittent caused by poor contact in the sensor's and/or the PCM's connector, which was repaired but PCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

#### NO

Go to "Monitor Scantool Data" procedure.

#### MONITOR SCANTOOL DATA EFF9A4B6

- 1. Ignition "ON" & Engine "OFF".
- 2. Disconnect ECTS connector .
- 3. Connect Scantool and monitor the "COOLANT TEMP. SNSR(V)" parameter on the Scantool data list.
- 4. Jumper the terminals 1 and 3 of the sensor harness connector together.

Specification : Approx. 0V	
1.3 CURRENT DATA	
× COOLANT TEMP.SNSR(V) 0.00 V	شرکت دیجیتال خو
نال تعمیرکاران خودرو در ایران	اولین سامانه دیا عیا
FIX PART FULL HELP GRPH RCRD	

5. Is ECTS parameter near the specified value?

#### YES

Possibility of sensor malfunction. Go to "Component Inspection" procedure.

NO

Possibility of signal circuit short to ground. Go to "W/Harness Inspection" procedure.

- 6. Jumper the terminal 1 of the sensor harness connector to chassis ground.
- 7. Read the "COOLANT TEMP. SNSR(V)" parameter on the Scantool.

Specification : Approx. 0V

8. Is displayed ECT data near the specified value.?

# WWW.DIGITALKHODRO.COM

# 021-62999292

B01186

## FLA -119

# YES

Possibility of open in ECTS ground circuit Go to "Ground Circuit Inspection" procedure.

# NO

Possibility of open or short to battery in ECTS signal circuit. Go to "Signal Circuit Inspection" procedure.

#### GROUND CIRCUIT INSPECTION EDFD7AB7

- 1. Ignition "OFF".
- 2. Disconnect PCM connector.
- 3. Measure resistance between terminals 3 of the sensor harness connector and 73 of the PCM harness connector.

```
Specification : Approx. 0
```

4. Is resistance within the specification?

#### YES

Go to "Terminal and connector Inspection" procedure.

#### NO

Repair open circuit and go to "Verification of Vehicle Repair" procedure.

#### SIGNAL CIRCUIT INSPECTION E83C8930

- 1. Check for open in signal circuit.
  - 1) Measure resistance between terminals 1 of the sensor harness connector and 31 of the PCM harness connector.

Specification : Approx. 0

2) Is resistance within the specification?



Go to next step as below

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

- 2. Check for short to battery in signal circuit.
  - 1) Ignition "ON" & Engine "OFF".
  - 2) Measure voltage between terminals 1 of the sensor harness connector and 31 of the PCM harness connector.

Specification : Approx. 0V

3) Is voltage within the specification?

# WWW.DIGITALKHODRO.COM

# WWW.DIGITALKHODRO.COM

# 021-62999292

#### FLA -120

# YES

**FUEL SYSTEM** 

Go to "Terminal and Connector Inspection" procedure.

#### NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

## TERMINAL & CONNECTOR INSPECTION EDC729BD

Refer to DTC P0116.

#### COMPONENT INSPECTION EA4E8EBA

Refer to DTC P0116.

#### VERIFICATION OF VEHICLE REPAIR EE4D44C1

Refer to DTC P0116.



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



FLA -121

# DTC P0121 THROTTLE/PEDAL POSITION SENSOR/SWITCH "A" CIRCUIT RANGE/PERFORMANCE

# COMPONENT LOCATION E923F9AA



EGQE502D

#### GENERAL DESCTIPTION E4334D0D

The Throttle Position Sensor (TPS) is mounted on the throttle body and detects the opening angle of the throttle plate. The TPS has a variable resistor (potentiometer) whose characteristic is the resistance changing according to the throttle angle. During acceleration, the TPS resistance between the reference 5V and the signal terminal decreases and output voltage increases; during deceleration, the TPS resistance increases and TPS output voltage decreases. The PCM supplies a reference 5V to the TPS and the output voltage increases directly with the opening of the throttle valve. The TPS output voltage will vary from 0.2~0.8V at closed throttle to 4.3~4.8V at wide-open throttle. The PCM determines operating conditions such as idle (closed throttle), part load, acceleration/deceleration, and wide-open throttle from the TPS. Also The PCM uses the Mass Air Flow Sensor (MAFS) signal along with the TPS signal to adjust fuel injection duration and ignition timing.

#### DTC DESCRIPTION E6F34C12

The PCM compares the actual measured Mass Air Flow signal with the modeled Mass Air Flow value to detect implausible TPS signal. Because throttle position is one of key parameters in determining the modeled MAF. The modeled Mass Air Flow value is determined by engine speed, throttle angle and ISCA duty. The DTC P0121 is set when the difference between these two value is too high or too low with lambda deviation in same direction for a certain time.

# **FUEL SYSTEM**

## DTC DETECTING CONDITION ECEEBAB8

ltem	Detecting Condition	Possible Cause	
DTC Strategy	Compare calculated MAF with MAF signal		
Enable Conditions	No relevant failure 11 Battery voltage 16 Lambda control active		
Threshold value	Calculated MAF-Measured MAF > 300 mg/rev	Contact resistance in connectors	
Diagonostic Time	200 revolutions	Faulty TP Sensor(TPS)	
Fall Safe	Throttle position is determined by engine speed and MAF. EVAP. emission control function is controlled in minimum operation mode		

#### SPECIFICATION E7AA69B7

TPS		Fully Closed	Fully Open	
Throttle Angle (°)		0~0.5°	86°	
Signal Voltage (V)		0.2~0.8V	4.3~4.8V	
<b>Y</b> PY	Terminal 1 and 2	0.71 ~ 1.38k at all temperature	2.7k at all temperature	
Resistance(k)	Terminal 2 and 3	$1.6 \sim 2.4 \text{ k}\Omega$ at all throttle position		
ئولیت محدود)	ادر و سامانه (مسا	شرخت دیجیتال حو		

# SCHEMATIC DIAGRAM E31BA6B2



Connection Information]			
Terminal	Connected to	Function	
1	PCM Terminal 32	TPS signal	
2	PCM Terminal 38	Sensor ground	
3	PCM Terminal 45	Reference Voltage	

#### [CONNECTOR]

TPS Harness side connector



C159

2

3

1

B01211

## SIGNAL WAVEFORM EF09FCCB



Fig 1) Normal value with accelerating and decelerating : The MAFS and TPS signals increase at the same time with accelerating and decrease with releasing accelerator pedal
Fig 2) Signal increases proportionally with throttle opening angle

#### MONITOR DTC STATUS EBD5A146

#### **NOTE**

If any codes relating to TPS or MAFS are stored, do ALL REPAIRS associated with those codes before proceeding with further troubleshooting.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.

	1.4 AMBIENT CONDITIONS
To naviate to the "DTAL"menu	
01 HYUNDAI VEHICLE DIAGNOSIS	
Select model and year	1. MIL STATUS
└→02 ENGINE	2. DTC STATUS: <u>PRESENT</u>
Select engine	3. DTC READINESS FLAG : <u>COMPLETE</u>
<b>DI</b> DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC
PART ERAS DTAL HELP	6. OP.HOUR AFTER ERASURE OF DTC

B00112

5. Is parameter displayed "History(Not Present) fault"?

# WWW.DIGITALKHODRO.COM

#### 021-62999292

B01212

# FUEL SYSTEM

#### 🔟 ΝΟΤΕ

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

# YES

Fault is intermittent caused by poor contact in the sensor's and/or the PCM's connector, which was repaired but PCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

#### NO

Go to "Air Leakage Inspection" procedure.

#### AIR LEAKAGE INSPECTION ED893945

- 1. Visually/physically inspect the following items:
  - Vacuum hoses for splits, kinks and improper connections.
  - EVAP system for leakage.
  - PCV hose for proper installation.
- 2. Was a problem found in any of the above areas?

#### YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

# اولین سامانه دیجیتال تعمیرکاران خودرو در N<mark>O</mark>L

Go to next step as below.

#### TERMINAL & CONNECTOR INSPECTION EAF987DF

- 1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Component Inspection" procedure.

#### COMPONENT INSPECTION EEFE5C60

- 1. Ignition "OFF" .
- 2. Disconnect TPS connector.

# WWW.DIGITALKHODRO.COM

# DTC TROUBLESHOOTING PROCEDURES

3. Measure resistance between terminals 2 and 3 of the sensor connector(Component side).

Specification : Approx. 1.6 ~ 2.4 k at all throttle position

<C159>



1. TPS Signal 2. Sensor Ground

3. Reference Voltage

B01213

- 4. With still TPS connector disconnected, measure resistance between terminals 1 and 2 of the sensor connector(Component side).
- 5. Operate the throttle valve slowly from the idle position to the full open position and check the resistance changes smoothly in proportion with the throttle valve opening angle.

Specification : 0.71 ~ 1.38k at	closed throttle valve, 2.7k	at wide open throttle	Q \_
انه (مسئولیت ٥< <sub>C159&gt;</sub> د)	ديجيتال خودرو سام		
2. Ser	S Signal nsor Ground ference Voltage		

B01214

6. Is resistance within the specification?

## YES

Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Check TPS for contamination, deterioration, or damage. Substitute with a known-good TPS and check for proper operation. If the problem is corrected, replace TPS and then go to "Verification of Vehicle Repair" procedure.

#### VERIFICATION OF VEHICLE REPAIR E461CAEE

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode

# WWW.DIGITALKHODRO.COM

# WWW.DIGITALKHODRO.COM

# 021-62999292

#### FLA -126

**FUEL SYSTEM** 

- 2. Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions
- 3. Read "DTC Status" parameter
- 4. Is parameter displayed "History(Not Present) fault"?



System performing to specification at this time. Clear the DTC



Go to the applicable troubleshooting procedure.



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



FLA -127

# DTC P0122 THROTTLE/PEDAL POSITION SENSOR/SWITCH "A" CIRCUIT LOW INPUT

#### COMPONENT LOCATION E1408072

Refer to DTC P0121.

#### GENERAL DESCTIPTION E6DAB7F6

Refer to DTC P0121.

## DTC DESCRIPTION EB4F0DFE

PCM sets DTC P0122 if the PCM detects signal voltage lower than the possible range of a properly operating TPS.

# DTC DETECTING CONDITION EDFD139A

ltem	Detecting Condition	Possible Cause	
DTC Strategy	Voltage range check		
Enable Conditions 6 Battery voltage 16V		Open in power supply harnes Short to ground in power	
Threshold value	Voltage < 0.14V	supply or signal harness.	
Diagonostic Time	1 sec.	Contact resistance in connectors	
Fall Safe	Throttle position is determined by function of engine speed, mass air flow and idle duty.	Faulty TP Sensor	

# اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

## SPECIFICATION EBD6B0A2

TPS		Fully Closed		Fully Open	
Throttle Angle (°)		0~0.5°		86°	
Signal Voltage (V)		0.2~0.8V		4.3~4.8V	
	Terminal 1 and 2	0.71 ~ 1.38k	at all temperature	2.7k	at all temperature
Resistance(k )	Terminal 2 and 3	1.6 ~ 2.4 kΩ at all throttle position		osition	

## SCHEMATIC DIAGRAM EF6DEE1E

Refer to DTC P0121.

# FUEL SYSTEM

## SIGNAL WAVEFORM EA267D14



#### MONITOR DTC STATUS E70AD2BA

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.

To naviate to the "DTAL"menu	1.4 AMBIENT CONDITIONS
01 HYUNDAI VEHICLE DIAGNOSIS	
:Select model and year	1. MIL STATUS
→ 02 ENGINE	2. DTC STATUS: <u>PRESENT</u>
Select engine	3. DTC READINESS FLAG : <u>COMPLETE</u>
→ 01 DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC
PART ERAS DTAL HELP	6. OP.HOUR AFTER ERASURE OF DTC

B00112

5. Is parameter displayed "History(Not Present) fault"?

#### 🔟 NOTE

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

#### YES

Fault is intermittent caused by poor contact in the sensor's and/or the PCM's connector, which was repaired but PCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.



Go to next step as below.

#### TERMINAL & CONNECTOR INSPECTION E13C90BA

- 1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Power Supply Inspection" procedure.

#### POWER SUPPLY CIRCUIT INSPECTION EDC447C4

- 1. Ignition "OFF".
- 2. Disconnect TPS connector.
- 3. Ignition "ON" & Engine "OFF".
- 4. Measure voltage between terminal 3 of the sensor harness connector and chassis ground.

Specification : Approx. 5V

5. Is voltage within the specification?



Go to "Signal Circuit inspection" procedure.

NO

Possibility of open or short to ground in 5V reference circuit. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### SIGNAL CIRCUIT INSPECTION E2CB1DC5

- 1. Ignition "ON"
- 2. Measure voltage between terminal 1 of the sensor harness connector and chassis ground.

# WWW.DIGITALKHODRO.COM

# WWW.DIGITALKHODRO.COM

# 021-62999292

#### FLA -130

Specification : Approx. 5V

3. Is voltage within the specification?



Go to "Component Inspection" procedure.

```
NO
```

Check the short to ground in signal circuit. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### COMPONENT INSPECTION ED882348

Refer to DTC P0121.

#### VERIFICATION OF VEHICLE REPAIR E912D057

Refer to DTC P0121.





# FUEL SYSTEM

FLA -131

# DTC P0123 THROTTLE/PEDAL POSITION SENSOR/SWITCH "A" CIRCUIT HIGH INPUT

#### COMPONENT LOCATION E29A051D

Refer to DTC P0121.

#### GENERAL DESCTIPTION ED3E2BB9

Refer to DTC P0121.

## DTC DESCRIPTION EC972AB1

PCM sets DTC P0123 if the PCM detects signal voltage higher than the possible range of a properly operating TPS.

# DTC DETECTING CONDITION EFA8E736

ltem	Detecting Condition	Possible Cause
DTC Strategy	Voltage range check	
Enable Conditions	6 Battery voltage 16V	Open in signal or ground circuit.
Threshold value	Voltage > 4.86 V	Short to battery in signal circuit.
Diagonostic Time	1 sec.	connectors.
Fall Safe	Throttle position value is determined by function of engine speed, mass air flow and idle duty.	Faulty TP sensor.

# اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

## SPECIFICATION EAE875C3

TPS		Fully Closed		Fully Open	
Throttle Angle (°)		0~0.5°		86°	
Signal Voltage (V)		0.2~0.8V		4.3~4.8V	
	Terminal 1 and 2	0.71 ~ 1.38k	at all temperature	2.7k	at all temperature
Resistance(k)Terminal 2 and 31.6 ~ 2.4 k $\Omega$ at all throttle position		osition			

## SCHEMATIC DIAGRAM E75B625A

Refer to DTC P0121.

# FUEL SYSTEM

SIGNAL WAVEFORM EBED9A5F



#### MONITOR DTC STATUS EE9D4EDC

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.

	<b>1.4 AMBIENT CONDITIONS</b>
To naviate to the "DTAL"menu	
<b>01</b> HYUNDAI VEHICLE DIAGNOSIS	
Select model and year	1. MIL STATUS
└→02 ENGINE	2. DTC STATUS: <u>PRESENT</u>
Select engine	3. DTC READINESS FLAG : <u>COMPLETE</u>
<b>01</b> DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC
PART ERAS DTAL HELP	6. OP.HOUR AFTER ERASURE OF DTC

B00112

5. Is parameter displayed "History(Not Present) fault"?

#### 🔟 ΝΟΤΕ

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

# WWW.DIGITALKHODRO.COM

FLA -133

#### YES

Fault is intermittent caused by poor contact in the sensor's and/or the PCM's connector, which was repaired but PCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.



Go to next step as below.

#### TERMINAL & CONNECTOR INSPECTION E28315E4

- 1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

#### YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### NO

Go to "Ground Circuit Inspection" procedure.

#### GROUND CIRCUIT INSPECTION E5B03BE7

- 1. Ignition "OFF".
- 2. Disconnect TPS connector.
- 3. Ignition "ON" & Engine "OFF".
- 4. Measure voltage between terminal 2 of the sensor harness connector and chassis ground.

Specification : Approx. 0V

5. Is voltage within the specification?



Go to step "Signal Circuit Inspection" procedure.



Check the ground circuit for an open. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### SIGNAL CIRCUIT INSPECTION E9D3DAED

1. With connector still disconnected, measure voltage between terminal 1 of the sensor harness connector and chassis ground.

# WWW.DIGITALKHODRO.COM

# WWW.DIGITALKHODRO.COM

#### 021-62999292

**FUEL SYSTEM** 

#### FLA -134

Specification : Approx. 5V

2. Is voltage within the specification?



Go to "Component Inspection" procedure.



Possibility of open or short to power in signal circuit. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### COMPONENT INSPECTION EFC520DE

Refer to DTC P0121.

#### VERIFICATION OF VEHICLE REPAIR E4C29EE8

Refer to DTC P0121.





FLA -135

## DTC P0125 INSUFFICIENT COOLANT TEMPERATURE FOR CLOSED LOOP FUEL CONTROL

#### COMPONENT LOCATION EBAD8D8D



#### GENERAL DESCTIPTION E6C01B8C

An Engine Coolant Temperature Sensor (ECTS) monitors the temperature of the coolant. This input is used by the PCM for engine control and as an enabling criteria for related diagnostics. The air flow coming into the engine is accumulated and used to determine if the engine has been driven within conditions that would allow the engine coolant to heat up normally to the thermostat regulating temperature. If the coolant temperature does not reach regulating temperature of the thermostat, diagnostics that use engine coolant temperature as enabling criteria, may not run when expected. This DTC will set when there has been excessive time to reach a minimum coolant temperature required for closed loop fuel control.

## DTC DESCRIPTION E1506A9F

The purpose of this diagnosis is to monitor the minimum coolant temperature that enables lambda closed loop control after start. Minimum coolant temperature to run lambda control must be reached before the threshold time predetermined according to intake air temperature at start. If the lambda control is not active because of low engine coolant temperature within predetermined minimum time after start, the PCM sets DTC P0125.

# FUEL SYSTEM

## DTC DETECTING CONDITION EE5E3709

Item	Detecting Condition	Possible Cause
DTC Strategy	Check time to closed loop control start with coolant temperature model.	
Enable Conditions	Minimum time after engine start versus intake air temperature at start : 1) 2minutes for intake air temp. > 10 (50°F) 2) 5minutes for -7 (19°F) < Intake air temp. < 10 (50°F) 6 < Battery voltage(V) < 16	Contact resistance in connectors.
Threshold value	Measured coolant temperature < $5^{\circ}C(41^{\circ}F)$ When modeled coolant temperature > 5 (41°F)	Faulty cooling system. Faulty thermostat. Faulty ECT sensor.
Diagonostic Time	Immediate.	
Fall Safe	Calculated engine coolant temperature is used for engine control. Cooling/Condenser fan is active with MAX speed. EVAP. emission control function is controlled in minimum operation mode.	

## SPECIFICATION EAF44DA2

# [ECTS]

Temp.(°C)	Temp.(°F)	Resistance(k )
-20	-4	14.13 ~ 16.83
<u> </u>	32	5.79
20	68	2.31 ~ 2.59
40	104	1.15
60	140	0.59
80	176	0.32

#### [THERMOSTAT]

Thermostat	Normal Parameter
Valve Opening Temp.	80~84°C(176~183°F)
Valve Closing Temp.	77°C(170.6°F)
Full Open Lift	Above 10mm at 95°C(203°F)

# SCHEMATIC DIAGRAM ECBEE3A1



# SIGNAL WAVEFORM EFCF3A15



Signal decreases with increasign sensor temperature and increases with decreasing sensor temperature

A01161

#### MONITOR DTC STATUS EDB5A82D

#### 🔟 ΝΟΤΕ

If any codes relating to ECTs are stored, do ALL REPAIRS associated with those codes before proceeding with this troubleshooting.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.

# WWW.DIGITALKHODRO.COM

# 021-62999292

#### FLA -137

**FUEL SYSTEM** 

	1.4 AMBIENT CONDITIONS
To naviate to the "DTAL"menu	
01 HYUNDAI VEHICLE DIAGNOSIS	
Select model and year	1. MIL STATUS
└─▶ 02 ENGINE	2. DTC STATUS: <u>PRESENT</u>
Select engine	3. DTC READINESS FLAG : <u>COMPLETE</u>
<b>01</b> DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC
PART ERAS DTAL HELP	6. OP.HOUR AFTER ERASURE OF DTC

B00112

5. Is parameter displayed "History(Not Present) fault"?

#### 🔟 ΝΟΤΕ

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.



Fault is intermittent caused by poor contact in the sensor's and/or PCM's connector or was repaired and PCM memory was not cleared. Thoroughly check connectors for loose or poor connections, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Cooling System Inspection" procedure.

#### **COOLING SYSTEM INSPECTION**

- 1. Check cooling system coolant level and fill if low.
- 2. Check for a proper cooling system operation. Especially check that cooling and condenser fan working normally.
- 3. Remove the thermostat and check the following items:
  - Stuck or damaged
    - Verify the temperature at which the valve begins to open. Valve opening temperature : 80~84°C(176~183.2°F) Valve opening temperature : 95°C(203°F)
- 4. is a problem found?



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to next step as below.

# WWW.DIGITALKHODRO.COM

# DTC TROUBLESHOOTING PROCEDURES

## TERMINAL & CONNECTOR INSPECTION E20F9532

- 1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

#### YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Component Inspection" procedure.

#### COMPONENT INSPECTION E63CBB31

- 1. Ignition "OFF" .
- 2. Disconnect ECTS connector.
- 3. Measure resistance between terminals 1 and 3 of the sensor connector(Component side).

#### SPECIFICATION

Temp.(°C)	Temp.(°F)	Resistance(k)	Temp.(°C)	Temp.(°F)	Resistance(k)
-20	-4	14.13~16.83	40	104	1.15
درو در ایران	هميرك3ران خو	انه د 5.79 بتال ت	ار60 را ساد	140	0.59
20	68	2.31~2.59	80	176	0.32

4. Is resistance within the specification?

<C104>



B01253



Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

# WWW.DIGITALKHODRO.COM

# WWW.DIGITALKHODRO.COM

#### 021-62999292

**FUEL SYSTEM** 

#### FLA -140

#### NO

Check ECTS for contamination, deterioration, or damage. Substitute with a known-good ECTS and check for proper operation. If the problem is corrected, replace ECTS and then go to "Verification of Vehicle Repair" procedure.

# VERIFICATION OF VEHICLE REPAIR E1CC7ACD

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode
- 2. Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions
- 3. Read "DTC Status" parameter
- 4. Is parameter displayed "History(Not Present) fault"?



NO

System performing to specification at this time. Clear the DTC

Go to the applicable troubleshooting procedure.

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران



FLA -141

# DTC P0130 HO2S CIRCUIT (BANK 1/ SENSOR 1)

# COMPONENT LOCATION E6E00E1F



EGQE501N

#### GENERAL DESCRIPTION E0A435BF

The HO2S is used to supply the PCM with information regarding the composition of the air/fuel mixture. The HO2S is positioned in the exhaust pipe ahead of the TWC. To measure the oxygen content, the HO2S requires a supply of ambient air as a reference. Since this is supplied through the wiring, the lead must not be clamped or damaged in any other way. The HO2S produces a voltage that varies between 0.1V and 0.9V under normal operating conditions. The Engine Control Module (PCM) monitors this voltage and determines if the exhaust gas is lean or rich. If the voltage input at the PCM is under approx. 0.45V the exhaust is lean, and if the voltage input is over approx. 0.45V the exhaust is rich. The PCM constantly monitors the HO2S signal during closed loop operation and compensates for a rich or lean condition by decreasing or increasing injector pulse width as necessary.

#### DTC DESCRIPTION ED248B23

PCM sets DTC P0130 if the PCM detects that the front HO2S signal circuit is open.

# FUEL SYSTEM

# DTC DETECTING CONDITION EE84EA2A

ITEM		DETECTING CONDITION	POSSIBLE CAUSE
DTC Strategy		Voltage range check	Open in signal harness. Open in ground harness.
Enable Condition		Sensor preheating and full heating phases finished Modelled exhausr gas temp, > 600°C(1112°F) Lambda control active No relevant failure Battery voltage > 10V	
Case1)	Threshold Value	Lambda control not active within the defined time	Contact resistance in connectors. Faulty Heated O2 Sensor(HO2S).
Case2)		0,49V > Down HO2S > 0,37V and sensor element resistance > 60 K	
Case1)	Diagnostic Time	30~100 sec. depending on start temp.	
Case2)		10 sec.	

# SCHEMATIC DIAGRAM ECDF6EC7



B01301

## DTC TROUBLESHOOTING PROCEDURES

#### SIGNAL WAVEFORM E89BA5C6



## MONITOR DTC STATUS E3AB53C0

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.

	1.4 AMBIENT CONDITIONS
To naviate to the "DTAL"menu	
<b>01</b> HYUNDAI VEHICLE DIAGNOSIS	
Select model and year	1. MIL STATUS
└→02 ENGINE	2. DTC STATUS: PRESENT
Select engine	3. DTC READINESS FLAG : <u>COMPLETE</u>
<b>DI</b> DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC
PART ERAS DTAL HELP	6. OP.HOUR AFTER ERASURE OF DTC

B00112

5. Is parameter displayed "History(Not Present) fault"?

#### 🔟 ΝΟΤΕ

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

# WWW.DIGITALKHODRO.COM

# YES

FUEL SYSTEM

Fault is intermittent caused by poor contact in the sensor's and/or ECM's connector or was repaired and ECM memory was not cleared. Thoroughly check connectors for loose or poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.



Go to next step as below.

#### TERMINAL & CONNECTOR INSPECTION E9F9BADA

- 1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?



Repair as necessary and go to "Verification of Vehicle Repair" procedure.



Go to "Ground Circuit Inspection" procedure.

#### GROUND CIRCUIT INSPECTION EB46C86C

- 1. Ignition "OFF".
- 2. Disconnect HO2S and PCM connectors.

3. Measure resistance between terminals 2 of the sensor harness connector and 59 of the PCM harness connector.

Specification : Approx. 0

4. Is resistance within the specification?

YES

Go to "Signal circuit inspection" procedure.

NO

Repair open in the ground circuit and go to "Verification of Vehicle Repair" procedure.

#### SIGNAL CIRCUIT INSPECTION EAOECD76

1. Measure resistance between terminals 1 of the HO2S harness connector and 43 of the PCM harness connector.

Specification : Approx. 0

2. Is resistance within the specification?

# WWW.DIGITALKHODRO.COM
# FLA -145

# YES

Go to "Component Inspection" procedure.



Repair open in the ground circuit and go to "Verification of Vehicle Repair" procedure.

#### COMPONENT INSPECTION ED189BEA

- 1. Visually/physically inspect following items:
  - Inspect the front HO2S for any silicon contamination. This contamination will be indicated by a white powdery coating and this will result in a but false voltage signal. If contamination is evident on the HO2S, replace contaminated sensor and go to next step.
- 2. Warm up the engine to normal operating temperature and check that HO2S signal is active.
- 3. Connect Scantool and monitor the "O2 SNSR VOLT. (B1/S1)" parameter on the Scantool data list.

Specification : Verify signal is switching from rich(above 0.45V) to lean(below 0.45V) a minimum of 3 times in 10 seconds (voltage will vary between 0.1 and 0.9V).

#### 4. Is sensor switching properly?



Check for poor connection between ECM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

# اولین سامانه دیجیتال تعمیرکاران خودرو د<mark>ر ک</mark>ا

Check HO2S for contamination, deterioration, or damage. Substitute with a known-good HO2S and check for proper operation. If the problem is corrected, replace HO2S and then go to "Verification of Vehicle Repair" procedure.

#### VERIFICATION OF VEHICLE REPAIR EETEFAT8

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode
- 2. Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 3. Read "DTC Status" parameter.
- 4. Is parameter displayed "History(Not Present) fault"?



System performing to specification at this time. Clear the DTC

NO

Go to the applicable troubleshooting procedure.

**FUEL SYSTEM** 

# DTC P0131 HO2S CIRCUIT LOW VOLTAGE (BANK 1 / SENSOR 1)

#### COMPONENT LOCATION EED786DF

Refer to DTC P0130.

#### GENERAL DESCRIPTION EDC8C6D0

Refer to DTC P0130.

#### DTC DESCRIPTION EBCD1CDA

The control unit of the linear oxygen sensor built inside the PCM monitors short circuit errors on all front Heated Oxygen Sensor (HO2S) control lines and the PCM sets P0131 with short circuit to ground.

#### DTC DETECTING CONDITION E9A9AA7E

ITEM	DETECING CONDITION	POSSIBLE CAUSE
DTC Strategy	Voltage Range check	
Enable Conditions	Lambda regulation on Maximum Limit(50%) Canister Purge valve closed Battery voltage > 10V No relevant failure	
Threshold Value	Sensor voltage < 0,02 V and resistance < 30	Short to ground in signal harness. Contact resistance in connectors.
Diagnostic Time	لین سامانه دیجیتال تعمیر.60 sec	Faulty Heated O2 Sensor(HO2S).
Fail Safe	Reset lambda adaptation and fuel trim adaptation. Front HO2S heater is controlled in open loop control. EVAP. Emission control function is controlled in minimum operation mode.	

#### SCHEMATIC DIAGRAM E3C33FEE

Refer to DTC P0130.

SIGNAL WAVEFORM E853FD8A

Refer to DTC P0130.

#### MONITOR DTC STATUS E44A5382

Refer to DTC P0130.

#### TERMINAL & CONNECTOR INSPECTION EEFETAFD

1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

# WWW.DIGITALKHODRO.COM

# WWW.DIGITALKHODRO.COM

# 021-62999292

FLA -147

# DTC TROUBLESHOOTING PROCEDURES

- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

N	0	

Go to "Signal Circuit Inspection" procedure.

#### SIGNAL CIRCUIT INSPECTION E1BA08FC

- 1. Ignition "OFF"
- 2. Disconnect HO2S connector.
- 3. Measure resistance between terminal 1 of the HO2S harness connector and chassis ground.

Specification : Infinite		
4. Is resistance within the specification?	حرجينا	0
YES Go to "Component Inspection" pro	cedure.	
NO Repair open in the signal circuit an	d go to "Verification of Vehicle Re	epair" procedure.

#### COMPONENT INSPECTION E7BB56A8

Refer to DTC P0130.

#### VERIFICATION OF VEHICLE REPAIR EBB923AF

Refer to DTC P0130.

**FUEL SYSTEM** 

# DTC P0132 HO2S CIRCUIT HIGH VOLTAGE (BANK 1 / SENSOR 1)

### COMPONENT LOCATION EE4DEA66

Refer to DTC P0130.

### GENERAL DESCRIPTION EBEFOFE5

Refer to DTC P0130.

# DTC DESCRIPTION E6805D79

The control unit of the linear oxygen sensor built inside the PCM monitors short circuit errors on all front Heated Oxygen Sensor (HO2S) control lines and the PCM sets P0132 with short circuit to battery.

# DTC DETECTING CONDITION EB77238A

ITEM	DETECTING CONDITION	POSSIBLE CAUSE
DTC Strategy	Sensor voltage high	
Enable Conditions	Sensor preheating and full heating phases finished 10V Battery voltage 16V	Short to battery in signal
Threshold Value	Sensor voltage > 1.3V	harness. Contact resistance in
Diagnostic Time	شرکت دیجیتال خودرو سام <sub>.Sec</sub> (مس	connectors.
ن Fail Safe	Reset lambda adaptation and fuel trim adaptation. Front HO2S heater is controlled in open loop control. EVAP. Emission control function is controlled in minimum operation mode.	Faulty Heated O2 Sensor(HO2S).

#### SCHEMATIC DIAGRAM E9DAA0F6

Refer to DTC P0130.

#### SIGNAL WAVEFORM EC8548A5

Refer to DTC P0130.

#### MONITOR DTC STATUS EFF5F50A

Refer to DTC P0130.

# TERMINAL & CONNECTOR INSPECTION EADDF3A7

- 1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by in terference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

# WWW.DIGITALKHODRO.COM

# YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

# NO

Go to "Signal Circuit Inspection" procedure.

# SIGNAL CIRCUIT INSPECTION EE39701C

- 1. Ignition "OFF".
- 2. Disconnect HO2S connector.
- 3. Ignition "ON" & Engine "OFF".
- 4. Measure voltage between terminal 1 of the sensor harness connector and chassis ground.

Specification : Approx. 0V

5. Is voltage within the specification?



Refer to DTC P0130.

# VERIFICATION OF VEHICLE REPAIR E7EC66BE

Refer to DTC P0130.

**FUEL SYSTEM** 

# DTC P0133 HO2S CIRCUIT SLOW RESPONSE (BANK 1 / SENSOR 1)

#### COMPONENT LOCATION E9BF7E34

Refer to DTC P0130.

#### GENERAL DESCRIPTION EDB634CC

Refer to DTC P0130.

#### DTC DESCRIPTION E3FAB151

The PCM monitors front oxygen sensor amplitude level and compares it to predetermined minimum amplitude value which could increase emission or disturb lambda control by the effect of aging on the oxygen sensor. The PCM sets DTC P0133 when the amplitude of oxygen sensor is equal to or less than minimum amplitude threshold.

### DTC DETECTING CONDITION EEBC6F50

ITEM	DETECTING CONDITION	POSSIBLE CAUSE
DTC Strategy	Comparison of O2 sensor lean/rich period with calculated period.	- 0-
ئولىت محدود) Enable Conditions	Coolant temp. > 74°C(165) 400°C(752) < Catalyst temp. model 900°C(1652) 5km/h(3MPH) < Vehicle speed < 180km/h(112MPH) Engine speed < 3400rpm 200 < Engine load(mg/rev.) < 700 11V < Battery voltage Stable driving condition. Lambda regulation active. Canister Purge Valve not in CLOSE state.	Leak in intake or exhaust system. Faulty fuel system Front and rear HO2S connections reversed.
Threshold Value	Average Ratio between measured and maximum allowed frequency during.100 Lambda regulation cycles > 1	Contact resistance in connectors. HO2S contaminatio
Diagnostic Time	100 lambda controller cycles.	
Fail Safe	Reset lambda adaptation and fuel trim adaptation. Front HO2S heater is controlled in open loop control. EVAP. Emission control function is controlled in minimum operation mode	

#### SCHEMATIC DIAGRAM EB3C1EDC

Refer to DTC P0130.

#### SIGNAL WAVEFORM E8318CE5

Refer to DTC P0130.

# MONITOR DTC STATUS E1E89B7F

# 🔟 ΝΟΤΕ

If any misfire, Purge Solenoid Valve, Mass Air Flow Sensor or O2 Sensor heater codes are present, DO ALL REPAIRS associated with those codes before proceeding with this troubleshooting tree.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.



5. Is parameter displayed "History(Not Present) fault"?

#### 🔟 ΝΟΤΕ

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

# YES

Fault is intermittent caused by poor contact in the sensor's and/or ECM's connector or was repaired and ECM memory was not cleared. Thoroughly check connectors for loose or poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

# NO

Go to next step as below.

# VISUAL / PHYSICAL INSPECTION E5A2BFEE

- 1. Visually/physically inspect the following items:
  - Ensure that the HO2S is securely installed.
  - Check for corrosion on terminals.
  - Check for terminal tension (at the HO2S and at the PCM).
  - Check for damaged wiring.
  - Check the HO2S ground circuit for a good connection.

# WWW.DIGITALKHODRO.COM

# WWW.DIGITALKHODRO.COM

# 021-62999292

#### FLA -152

FUEL SYSTEM

- 2. Check front and rear HO2S for connections being reversed. If HO2S connections reversed, switch connections properly.
- 3. Was a problem found in any of the above areas?



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Air Leakage Inspection" procedure.

#### AIR LEAKAGE INSPECTION EOB27E82

- 1. Visually/physically inspect the following items:
  - Vacuum hoses for splits, kinks and improper connections.
  - Exhaust system between HO2S and Three way catalyst for air leakage.
  - EVAP system for leakage.
  - PCV hose for proper installation.
- 2. Was a problem found in any of the above areas?



- 1. Check the fuel for excessive water, alcohol, or other contaminants. Replace contaminated fuel as necessary.
- 2. Install a fuel pressure gage.
- 3. Inspect fuel pressure with engine idling at normal operating temperature.

```
Test Condition : Ignition "ON" & Engine "ON" & Vacuum hose disconnected at Idle Specification : 250~350kPa(2.50~3.50 kg/cm<sup>2</sup>, 36~50 psi)
```

4. Is the fuel pressure within the specified value?

# YES

Go to "Fuel Injector Inspection" procedure as below.



Repair as necessary refer to inspection note as below and go to "Verification of Vehicle Repair" procedure.

#### 🔟 ΝΟΤΕ

A. Check if fuel line pressure decreases when accelerating quickly.

- If it does, check fuel pump maximum pressure. If pressure is OK, check fuel line and filter for clogging.
- B. If fuel pressure is lower than specification : Check for fuel line pressure while pinching fuel return hose.

# WWW.DIGITALKHODRO.COM

- If pressure quickly increases, check pressure regulator.
- If pressure gradually increases, check for clogging between fuel pump and pressure regulator. If hose is not clogged, check fuel pump maximum pressure.
- C. If fuel pressure is higher than specification : Is fuel line clogged?
  - If it is not, replace pressure regulator.
  - If it is, replace it.

#### FUEL INJECTOR INSPECTION

- 1. Ignition "OFF"
- 2. Check the fuel injectors for clogging or any restrictions.

Specification : No clogging and restriction

3. Is the fuel injector OK?

#### YES

Go to "Component Inspection" procedure.

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### COMPONENT INSPECTION EGAAC492

Refer to DTC P0130.

VERIFICATION OF VEHICLE REPAIR EC8431A9

Refer to DTC P0130.

#### FLA -153

**FUEL SYSTEM** 

# DTC P0134 HO2S CIRCUIT NO ACTIVITY DETECTED (BANK 1 / SENSOR 1)

#### COMPONENT LOCATION E10FF7F8

Refer to DTC P0130.

#### GENERAL DESCRIPTION EE9EECFF

Refer to DTC P0130.

#### DTC DESCRIPTION EACCE291

Due to possible oxygen sensor defects (e.g. reference air poisoning) or faults in the injection system (e.g. leaking fuel injector), the rear oxygen sensor may not provide the expected lean or rich signal level during fuel cut-off or full load condition. Hence, the oxygen sensor signal is checked for plausibility during this engine operating states.

#### DTC DETECTING CONDITION EFA4F903

ITE	EM	DETECTING CONDITION	POSSIBLE CAUSE
	DTC Strategy	Signal plausibility during fuel cut off	
(Solor) Case1)	Enable Condi- tions	Sensor preheating and full heating phases finished Fuel Cut Off active Integrated Mass Air Flow > 16g Battery voltage > 10V	
ايران	Thresh- old Value	Voltage with fuel cut off > 0.1V	
	Diagnos- tic Time	5 Sec.	Related fuse blown or missing
	DTC Strategy	Signal stroke plausibility	Contact resistance in connectors
Case2)	Enable Condi- tions	Sensor preheating and full heating phases finished Signal stroke valid (5 P-jump after Lambda regulation activation) Lambda controller is not on the limit Lean / rich cycle time < 2.5 sec. Battery voltage > 10V	HO2S contamination
	Thresh- old Value	Sensor voltage < 0.25V	
	Diagnos- tic Time	2 min.	

### SCHEMATIC DIAGRAM ECACCEA8

Refer to DTC P0130.

#### SIGNAL WAVEFORM EDE43C15

Refer to DTC P0130.

### MONITOR DTC STATUS E25FB1BB

# 🔟 ΝΟΤΕ

If any misfire, Purge Solenoid Valve, Mass Air Flow Sensor or O2 Sensor heater codes are present, DO ALL REPAIRS associated with those codes before proceeding with this troubleshooting tree.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.

	1.4 AMBIENT CONDITIONS
To naviate to the "DTAL"menu	
<b>01</b> HYUNDAI VEHICLE DIAGNOSIS	
Select model and year	1. MIL STATUS
→ 02 ENGINE	2. DTC STATUS: <u>PRESENT</u>
Select engine	3. DTC READINESS FLAG : COMPLETE
DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC
	6. OP.HOUR AFTER ERASURE OF DTC
PART ERAS DTAL HELP	🗕 🚽 شرکت در

# اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

5. Is parameter displayed "History(Not Present) fault"?

#### 🚺 ΝΟΤΕ

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

# YES

Fault is intermittent caused by poor contact in the sensor's and/or ECM's connector or was repaired and ECM memory was not cleared. Thoroughly check connectors for loose or poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

#### NO

Go to next step as below.

#### TERMINAL AND CONNECTOR INSPECTION EGGB59BA

- 1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

# WWW.DIGITALKHODRO.COM

# 021-62999292

B00112

# WWW.DIGITALKHODRO.COM

# 021-62999292

**FUEL SYSTEM** 

#### FLA -156

#### YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure

#### NO

Go to "HO2S Fuse Inspection" procedure

#### **HO2S FUSE INSPECTION**

- 1. Ignition "OFF" & Engine "OFF"
- 2. Verify "10A Sensor fuse" is installed and not blown.
- 3. If OK, go to "Component Inspection" procedure. If NG, replace fuse and repair any shorts as necessary and go to "Verification of Vehicle Repair" procedure.

#### COMPONENT INSPECTION E1F2A73D

Refer to DTC P0130.

#### VERIFICATION OF VEHICLE REPAIR E7807C46

Refer to DTC P0130.

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران



FLA -157

# DTC P0136 HO2S CIRCUIT (BANK 1/ SENSOR 2)

# COMPONENT LOCATION E7C39ECE



EGQE501M

#### GENERAL DESCRIPTION ED0404C8

The rear heated oxygen sensor is mounted on the rear side of the Catalytic Converter (warm-up catalytic converter) or in the rear exhaust pipe, which detects the catalyst efficiency. The rear heated oxygen sensor (HO2S) produces a voltage between 0V and 1V. This rear heated oxygen sensor is used to estimate the oxygen storage capability. If a catalyst has good conversion properties, the oxygen fluctuations are smoothed by the oxygen storage capacity of the catalyst. If the conversion provided by the catalyst is low due to aging, poisoning or misfiring, then the oxygen fluctuations are similar to signals from the front oxygen sensor.

DTC DESCRIPTION AA4525C

PCM sets DTC P0136 if the PCM detects that the rear HO2S signal circuit is open.

#### DTC DETECTING CONDITION EBE4DODO

ITEM	DETECTING CONDITION	POSSIBLE CAUSE
DTC Strategy	Check open circuit on rear HO2S	
Enable Condition	Sensor preheating and full heating phases finished No relevant failure 10V < Battery voltage < 16V	Open in signal harness Open in ground harness Contact resistance in
Threshold Value	0.37 < Downstream O2 Sensor voltage < 0.49V & sensor element resistance > 60k	connectors Faulty Heated O2 Sensor(HO2S)
Diagnostic Time	30 sec.	

# 021-62999292

# **FLA -158**

# FUEL SYSTEM

#### SCHEMATIC DIAGRAM E95F376E



A01361

#### MONITOR DTC STATUS E99B22E0

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze 3. frame data or enable conditions.
- Read "DTC Status" parameter. 4.

FLA -159

B00112

	1.4 AMBIENT CONDITIONS
To naviate to the "DTAL"menu	
01 HYUNDAI VEHICLE DIAGNOSIS	
Select model and year	1. MIL STATUS
└─▶ 02 ENGINE	2. DTC STATUS: <u>PRESENT</u>
Select engine	3. DTC READINESS FLAG : <u>COMPLETE</u>
<b>01</b> DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC
PART ERAS DTAL HELP	6. OP.HOUR AFTER ERASURE OF DTC

5. Is parameter displayed "History(Not Present) fault"?

#### 🔟 ΝΟΤΕ

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

YES

Fault is intermittent caused by poor contact in the sensor's and/or ECM's connector or was repaired and ECM memory was not cleared. Thoroughly check connectors for loose or poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

# اولین سامانه دیجیتال تعمیرکاران خودرو د<mark>ر ۵</mark>۷

Go to next step as below.

# TERMINAL & CONNECTOR INSPECTION E580FFE1

- 1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Ground Circuit Inspection" procedure.

#### GROUND CIRCUIT INSPECTION EECGAE84

- 1. Ignition "OFF"
- 2. Disconnect HO2S connector.

# WWW.DIGITALKHODRO.COM

### 021-62999292

#### FLA -160

**FUEL SYSTEM** 

3. Measure resistance between terminals 1 of the sensor harness connector and 37 of the PCM harness connector.

Specification : Approx. 0

4. Is resistance within the specification?

YES

Go to "Signal circuit inspection" procedure.

#### NO

Repair open in the ground circuit and go to "Verification of Vehicle Repair" procedure

#### SIGNAL CIRCUIT INSPECTION E2D03DF3

1. Measure resistance between terminals 2 of the sensor harness connector and 42 of the PCM harness connector.

Specification : Approx. 0
Is resistance within the specification?
Go to "Component Inspection" procedure.
Repair open in the ground circuit and go to "Verification of Vehicle Repair" procedure.
COMPONENT INSPECTION E770FB98

- 1. Warm up the engine to normal operating temperature and check that HO2S signal is active.
- 2. Connect Scantool and monitor the "O2 SNSR VOLT.(B1/S2)" parameter on the Scantool data list.

Test Condition : Engine "ON" & In Idle("Closed Loop")condition Specification : Above 0.6V



Fig 1) Normal value with idle after warm up Above 0.6V Open in signal circuit : Approx. 0V

3. Is sensor data near the specified value?

# YES

Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### NO

Check HO2S for contamination, deterioration, or damage. Substitute with a known-good HO2S and check for proper operation. If the problem is corrected, replace HO2S and then go to "Verification of Vehicle Repair" procedure.

# VERIFICATION OF VEHICLE REPAIR ECCEDOOF

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 3. Read "DTC Status" parameter.
- 4. Is parameter displayed "History(Not Present) fault"?



System performing to specification at this time. Clear the DTC



Go to the applicable troubleshooting procedure.

FLA -161

021-62999292

# FUEL SYSTEM

# DTC P0137 HO2S CIRCUIT LOW VOLTAGE (BANK 1 / SENSOR 2)

# COMPONENT LOCATION EDE6098E

Refer to DTC P0136.

### GENERAL DESCRIPTION E91327F0

Refer to DTC P0136.

# DTC DESCRIPTION EEBE6E7D

PCM sets DTC P0137 if the PCM detects that the rear HO2S signal circuit is open.

### DTC DETECTING CONDITION EB38BD71

ITEM	DETECTING CONDITION	POSSIBLE CAUSE
DTC Strategy	Check short circuit to ground on rear HO2S	
Enable Condition	Catalyst temperature model > 400°C(752°F) No relevant failure 10 < Battery voltage < 16 Closed loop mode Lambda controller is not on the limit Catalyst purge after fuel cut off is not active	Short to ground in signal harness Contact resistance in connectors Faulty Heated O2 Sensor(HO2S)
Threshold Value	Downstream O2 Sensor voltage < 0.02V & sensor element resistance < 30	
Diagnostic Time	20 sec.	

# SCHEMATIC DIAGRAM EE25828A

Refer to DTC P0136.

SIGNAL WAVEFORM E1E20AF4

Refer to DTC P0136.

# MONITOR DTC STATUS E93C07A6

Refer to DTC P0136.

# TERMINAL & CONNECTOR INSPECTION E4C3D401

- 1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

# WWW.DIGITALKHODRO.COM

# DTC TROUBLESHOOTING PROCEDURES

# YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

# NO

Go to "Signal Circuit Inspection" procedure.

### SIGNAL CIRCUIT INSPECTION E6AC52AF

- 1. Ignition "OFF"
- 2. Disconnect HO2S connector.
- 3. Measure resistance between terminal 2 of the sensor harness connector and chassis ground.

Specification : Infinite

4. Is resistance within the specification?



#### VERIFICATION OF VEHICLE REPAIR E7117E2C

Refer to DTC P0136.

### FUEL SYSTEM

# DTC P0138 HO2S CIRCUIT HIGH VOLTAGE (BANK 1 / SENSOR 2)

### COMPONENT LOCATION E780EB14

Refer to DTC P0136.

### GENERAL DESCRIPTION ECEC6FBA

Refer to DTC P0136.

# DTC DESCRIPTION EFFFF7BA

PCM sets DTC P0138 if the PCM detects signal voltage higher than the possible range of a properly operating rear heated oxygen sensor (HO2S).

#### DTC DETECTING CONDITION ECAFCD3C

ITEM	DETECTING CONDITION	POSSIBLE CAUSE
DTC Strategy	Check short circuit to battery on rear HO2S	Short to Battery in signal
Enable Condition	10 < Battery voltage < 16V	harness Contact resistance in
Threshold Value	Sensor voltage > 1.3V	connectors Faulty Heated O2
Diagnostic Time	1 sec.	Sensor(HO2S)
ئولىت محدود)	شرکت دیجیتال خودرو سامانه (مس	

#### SCHEMATIC DIAGRAM EFA6A235

Refer to DTC P0136.

#### SIGNAL WAVEFORM E242B0C8

Refer to DTC P0136.

### MONITOR DTC STATUS EE766747

Refer to DTC P0136.

# TERMINAL & CONNECTOR INSPECTION EBF6A5D2

- 1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

# NO

Go to "Signal Circuit Inspection" procedure.

### SIGNAL CIRCUIT INSPECTION EEBC8BDB

- 1. Ignition "OFF"
- 2. Disconnect HO2S connector.
- 3. Ignition "ON"
- 4. Measure resistance between terminal 2 of the sensor harness connector and chassis ground.

Specification : Approx. 0V

5. Is voltage within the specification?

# YES

Go to "Component Inspection" procedure.

NO

Repair open in the ground circuit and go to "Verification of Vehicle Repair".

COMPONENT INSPECTION ECD8EF79

Refer to DTC P0136.

VERIFICATION OF VEHICLE REPAIR E9F1AE77

Refer to DTC P0136.

**FUEL SYSTEM** 

# DTC P0139 HO2S CIRCUIT SLOW RESPONSE (BANK 1 / SENSOR 2)

#### COMPONENT LOCATION EBOE1AEA

Refer to DTC P0136.

#### GENERAL DESCRIPTION E53AC7EA

Refer to DTC P0136.

#### DTC DESCRIPTION E1CBADED

The PCM monitors rich-lean switching time of rear heated oxygen sensor (HO2S) after fuel cut-off to validate dynamic behavior of rear heated oxygen sensor (HO2S). After detection of fuel cut-off engine operating state, the PCM measures rich-lean switching time of the rear heated oxygen sensor (HO2S) signal and compares it to the predetermined limit value. DTC P0139 is set when the switching time is bigger than the limit value.

#### DTC DETECTING CONDITION EAB30C1E

ITEM	DETECTING CONDITION	POSSIBLE CAUSE
DTC Strategy	Slow response(Switching time check at entry in fuel cut off)	
فولیت محدود) Enable Condition	Coolant temp > 74°C(165°F) Closed loop mode 5km/h(3mph) < Vehicle speed < 180km/h(112mph) Sensor preheating and full phase finished Catalyst temp.model > 350°C(662°C) No relevant failure 11 < Battery voltage < 16 Downstream O2 sensor signal at entry in fuel cut off > 0.55V	Leak in intake or exhaust system Faulty fuel system. Front and rear HO2S connections reversed. Contact resistance in connectors HO2S contamination
Threshold Value	Average ratio(between measured and maximum allowed switching time at entry in fuel cut-off) > 1	
Diagnostic Time	5 fuel cut-off phases	

#### SCHEMATIC DIAGRAM EE9EFAB3

Refer to DTC P0136.

SIGNAL WAVEFORM E22A28B2

Refer to DTC P0136.

### MONITOR DTC STATUS E7C1E63E

#### 🚺 NOTE

If any misfire, Purge Solenoid Valve, Mass Air Flow Sensor or O2 Sensor heater codes are present, DO ALL REPAIRS associated with those codes before proceeding with this troubleshooting tree.

1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.

# WWW.DIGITALKHODRO.COM

- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.



5. Is parameter displayed "History(Not Present) fault"?

### 🔟 ΝΟΤΕ

A. History (Not Present) fault : DTC occurred but has been cleared.
B. Present fault : DTC is occurring at present time.

# اولین سامانه دیجیتال تعمیرکاران خودرو د<mark>ا</mark> YES

Fault is intermittent caused by poor contact in the sensor's and/or ECM's connector or was repaired and ECM memory was not cleared. Thoroughly check connectors for loose or poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

#### NO

Go to next step as below.

# VISUAL / PHYSICAL INSPECTION E338CC47

- 1. Visually/physically inspect the following items:
  - Ensure that the HO2S is securely installed.
  - Check for corrosion on terminals
  - Check for terminal tension (at the HO2S and at the PCM)
  - Check for damaged wiring
  - Check the HO2S ground circuit for a good connection
- 2. Check front and rear HO2S for connections being reversed. If HO2S connections reversed, switch connections properly.
- 3. Was a problem found in any of the above areas?



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

# WWW.DIGITALKHODRO.COM

# 021-62999292

FUEL SYSTEM

#### FLA -168

### NO

Go to "Exhaust System Inspection" procedure.

#### EXHAUST SYSTEM INSPECTION EDE5D1CA

- 1. Check the exhaust system for an exhaust leak near the engine.
- 2. Was an exhaust leak found?

#### YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Air Leakage Inspection " procedure.

#### AIR LEAKAGE INSPECTION E0A9885F

- 1. Visually/physically inspect the following items:
  - Vacuum hoses for splits, kinks and improper connections.
  - Exhaust system between HO2S and Three way catalyst for air leakage
  - EVAP system for leakage
  - PCV hose for proper installation
- 2. Was a problem found in any of the above areas?

# اولین سامانه دیجیتال تعمیر کاران خودرو در <mark>ایران</mark>

'Repair as necessary and go to "Verification of Vehicle Repair" procedure

#### NO

Go to "Fuel Pressure Inspection" procedure.

#### FUEL PRESSURE INSPECTION

- 1. Check the fuel for excessive water, alcohol, or other contaminants. Replace contaminated fuel as necessary.
- 2. Install a fuel pressure gage
- 3. Inspect fuel pressure with engine idling at normal operating temperature.

Test Condition : Ignition "ON" & Engine "ON" & Vacuum hose disconnected at Idle Specification : 250~350kPa(2.50~3.50 kg/cm<sup>2</sup>, 36~50 psi)

4. Is the fuel pressure within the specified value?

#### YES

Go to "Fuel Injector Inspection" procedure as below.

#### NO

Repair as necessary refer to inspection note as below and go to "Verification of Vehicle Repair" procedure.

# WWW.DIGITALKHODRO.COM

# 🚺 ΝΟΤΕ

- A. Check if fuel line pressure decreases when accelerating quickly.
  - If it does, check fuel pump maximum pressure. If pressure is OK, check fuel line and filter for clogging.
- B. If fuel pressure is lower than specification : Check for fuel line pressure while pinching fuel return hose.
  - If pressure quickly increases, check pressure regulator.
  - If pressure gradually increases, check for clogging between fuel pump and pressure regulator. If hose is not clogged, check fuel pump maximum pressure.
- C. If fuel pressure is higher than specification : Is fuel line clogged?
  - If it is not, replace pressure regulator.
  - If it is, replace it.

#### FUEL INJECTOR INSPECTION

1. Ignition "OFF"

YES

2. Check the fuel injectors for clogging or any restrictions.

Specification : No clogging and restriction

- 3. Is the fuel injector OK?
  - Go to "Component Inspection" procedure.

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

شرکت دیجیتال خودرو سامانه (مسئولیت NO

#### COMPONENT INSPECTION E51F36D4

Refer to DTC P0136.

#### VERIFICATION OF VEHICLE REPAIR EA1EOCE4

Refer to DTC P0136.

FUEL SYSTEM

# DTC P0140 HO2S CIRCUIT NO ACTIVITY DETECTED (BANK 1 / SENSOR 2)

#### COMPONENT LOCATION E1DF1393

Refer to DTC P0136.

#### GENERAL DESCRIPTION E8C2A0AA

Refer to DTC P0136.

#### DTC DESCRIPTION EBD638AF

Due to possible oxygen sensor defects (e.g. reference air poisoning) or faults in the injection system (e.g. leaking fuel injector), the rear oxygen sensor may not provide the expected lean or rich signal level during fuel cut-off or full load condition. Hence, the oxygen sensor signal is checked for plausibility during this engine operating states. There are 2 cases which DTC P0140 sets.

(I) Signal monitoring during fuel cut-off: The PCM monitors rear O2 sensor signal level during fuel cut-off which normally shows near 0V and sets DTC P0140 when signal level is too high.

(II) Signal monitoring after fuel cut-off: The PCM monitors rear O2 sensor signal level for a certain time after leaving fuel cut-off and sets DTC P0140 when signal variation during checked period is too small.

### DTC DETECTING CONDITION EE768613

ITEM		DETECTING CONDITION	POSSIBLE CAUSE	
تحدود)	DTC Strategy	Signal plausibility during fuel cut off		
ايران	Enable	Sensor preheating and full heating phases finished In fuel cut off phase		
Case1)	Condi- tions	Integrated mass air flow > 20g No relevant failure 10V < Battery voltage < 16V		
	Threshold Value	Voltage with fuel cut off > 0.1V		
	Diagnostic Time	5 seconds		
	DTC Strategy	Signal plausibility after fuel cut off	Related fuse blown or missing Contact resistance in connectors HO2S contamination	
Case2)	Enable Condi- tions	Integrated engine load in fuel cut off > 12g Integrated engine load after fuel cut off > 40g Coolant temperature > 74°C(165°F) In Closed loop mode Catalyst temperature > 350°C(662°F) No relevant failure 11V < Battery voltage < 16V		
	Threshold Value	Sensor signal increase < 10mV		
	Diagnostic Time	5 after fuel cut off phase		

### SCHEMATIC DIAGRAM EF36E3AA

Refer to DTC P0136.

SIGNAL WAVEFORM E0917C0C

Refer to DTC P0136.

# MONITOR DTC STATUS EC251AAC

# 🔟 ΝΟΤΕ

If any misfire, Purge Solenoid Valve, Mass Air Flow Sensor or O2 Sensor heater codes are present, DO ALL REPAIRS associated with those codes before proceeding with this troubleshooting tree.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.

To naviate to the "DTAL"menu	1.4 AMBIENT CONDITIONS
01 HYUNDAI VEHICLE DIAGNOSIS	
Select model and year	1. MIL STATUS
مانه دي حيتال تعمير کار ENGINE	2. DTC STATUS: PRESENT
Select engine	3. DTC READINESS FLAG : COMPLETE
→ 01 DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC
	6. OP.HOUR AFTER ERASURE OF DTC
PART ERAS DTAL HELP	

B00112

5. Is parameter displayed "History(Not Present) fault"?

#### **NOTE**

- A. History (Not Present) fault : DTC occurred but has been cleared.
- B. Present fault : DTC is occurring at present time.

# YES

Fault is intermittent caused by poor contact in the sensor's and/or ECM's connector or was repaired and ECM memory was not cleared. Thoroughly check connectors for loose or poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

#### NO

Go to next step as below.

# WWW.DIGITALKHODRO.COM

# 021-62999292

FLA -171

# 021-62999292

#### FLA -172

#### **FUEL SYSTEM**

#### TERMINAL & CONNECTOR INSPECTION EFBD6F1E

- 1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

#### YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "HO2S Fuse Inspection" procedure.

#### HO2S FUSE INSPECTION

- 1. Ignition "OFF" & Engine "OFF".
- 2. Verify "10A Sensor fuse" is installed and not blown.
- 3. If OK, go to "Component Inspection" procedure. If NG, replace fuse and repair any shorts as necessary and go to "Verification of Vehicle Repair" procedure.

#### COMPONENT INSPECTION E5B23628

- 1. Visually/physically inspect following items:
  - Ensure that the sensor is securely installed
    - Check for corrosion on terminals
  - Check for damaged wiring
  - Repair as necessary and go to next step
- 2. Warm up the engine to normal operating temperature and check that HO2S signal is active.
- 3. Connect Scantool and monitor the "O2 SNSR VOLT.(B1/S2)" parameter on the Scantool data list.

Test Condition : Ignition "ON" & Engine "ON" & In Idle("Closed Loop")condition Specification : Above 0.6V



Fig 1) Normal value with idle after warm up Above 0.6V Open in signal circuit : Approx. 0V

#### 4. Is sensor data near the specified value?

#### YES

Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### NO

Check HO2S for contamination, deterioration, or damage. Substitute with a known-good HO2S and check for proper operation. If the problem is corrected, replace HO2S and then go to "Verification of Vehicle Repair" procedure.

#### VERIFICATION OF VEHICLE REPAIR E87F4CB1

Refer to DTC P0136.

FLA -173

A01361

FUEL SYSTEM

# DTC P0170 FUEL TRIM (BANK 1)

# COMPONENT LOCATION EOCFE38D



EGQE603N

#### GENERAL DESCRIPTION ECEBOA8C

In order to provide the best possible combination of drivability, fuel economy and emission control, the PCM uses a closed loop air/fuel metering system. The PCM monitors the HO2S signal voltage and adjusts fuel delivery based it in closed loop fuel control. Changes in fuel delivery will be indicated by the long-term and the short-term fuel trim values. The ideal fuel trim value is around 0%. The PCM will add fuel when the HO2S signal is indicating a lean condition. Additional fuel is indicated by fuel trim values that are above 0%. The PCM will reduce fuel when the HO2S signal is indicating a rich condition. Reduction in fuel is indicated by fuel trim values that are below 0%. The DTC relevant to fuel trim will be set when the amount reaches excessive levels because of a lean or rich condition.

#### DTC DESCRIPTION EF8C59F9

If the lambda controller reaches the maximum or minimum threshold, then feedback control is no longer possible and emissions will be increased. The PCM sets DTC P0170 if no proportional fuel adaptation occurs for a defined time after the lambda controller has reached its minimum or maximum threshold.

ITEM	DETECTING CONDITION	POSSIBLE CAUSE
DTC Strategy	Monitoring deviation of lambda controller	Air leakage or restriction in
Enable Condition	Lambda control active Coolant temperature > 70 (158 ) No relevant failure 10 < Battery voltage < 16	intake or exhaust system Dirty engine oil or oil level too high Front HO2S or MAFS contamination
Threshold Value	Lambda controller= -30%/+50%	Fuel system EVAP system
Diagnostic Time	40 seconds	Faulty sensor signals

### DTC DETECTING CONDITION E5E12DFF

# DTC TROUBLESHOOTING PROCEDURES

### MONITOR DTC STATUS EF274C02

# 🚺 ΝΟΤΕ

If any misfire, Purge Solenoid Valve, Mass Air Flow Sensor or O2 Sensor heater codes are present, DO ALL REPAIRS associated with those codes before proceeding with this troubleshooting tree.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.



5. Is parameter displayed "History(Not Present) fault"?

#### 🛄 NOTE

- A. History (Not Present) fault : DTC occurred but has been cleared.
- B. Present fault : DTC is occurring at present time.

# YES

Fault is intermittent caused by poor contact in the sensor's and/or ECM's connector or was repaired and ECM memory was not cleared. Thoroughly check connectors for loose or poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

# NO

Go to "Monitor Actuation Test" procedure.

### MONITOR ACTUATION TEST E68F41A5

# 🔟 ΝΟΤΕ

The main purpose of this test is to identify potential engine mechanical condition problems and fuel and ignition systems problems that are not common to all cylinders. For best results, perform this test while maintaining as steady an rpm reading as possible. Caution! Before beginning tests; set the parking brake, place gear selector in P or N and block drive wheels for safety.

# WWW.DIGITALKHODRO.COM

# WWW.DIGITALKHODRO.COM

#### FLA -176

#### FUEL SYSTEM

- 1. Warm up the engine to normal operating temperature and let it idle.
- 2. Install Scan Tool and select "INJECTOR #1" parameter on the Actuation Test mode shown in the figure.
- 3. Monitor engine rpm and shut off the injector #1 by pressing "STRT(F1)" key.
- 4. Repeat procedure on all injectors and record the engine rpm.

Specification : All cylinders should show an even RPM drop.

:	.6 ACTUATION TEST	-		
NO.1 INJEC	TOR			
DURATION	UNTIL STOP KEY			
METHOD	DEACTIVATION			
CONDITION	IG.KEY ON ENGINE RUNNING			
PRESS [: SELECT T STRT STC	EST ITEM USING UP/DOWN KEY			B00172
	cylinder's rpm drop within the sam			
Go to "	Check intake/exhaust system for re	estriction or leakage " proced	dure.	

Cylinders with the least amount of RPM drop are not contributing their share of power. Go to "Fuel Injector Inspection" procedure and check the suspect cylinders.

#### **NOTE**

If the RPM loss between cylinders is quite large(200RPM or more) and engine has high mileage, there is possibility of engine wear. Perform compression test with pressure gauge to check the engine wear.

#### CHECK INTAKE/EXHAUST SYSTEM FOR RESTRICTION OR LEAKAGE

- 1. Visually/physically inspect the air leakage in intake/exhaust system as following items
  - Vacuum hoses for splits, kinks and improper connections.
  - Throttle body gasket.
  - Gasket between intake manifold and cylinder head.
  - Seals between intake manifold and fuel injectors.
  - Exhaust system between HO2S and Three way catalyst for air leakage.
- 2. Visually/physically inspect the restriction in intake/exhaust system as following items,
  - Air cleaner filter element for excessive dirt or for any foreign objects.
  - Throttle body inlet for damage or for any foreign objects.
  - Throttle bore, throttle plate and the IAC passages for chocking and for any foreign objects.
  - Restricted exhaust system
- 3. Was a problem found in any of the above areas?

# WWW.DIGITALKHODRO.COM

# YES

Replace or repair as necessary and go to "Verification of Vehicle Repair" procedure.



Go to "Check the Engine Oil Contamination" procedure.

#### CHECK THE ENGINE OIL CONTAMINATION

- 1. Check the engine oil level. The oil level should be between the min. and max. marking. Fill to the correct oil level.
- 2. Warm up the engine to normal operating temperature.
- 3. Connect Scantool and note the "SHORT TERM FUEL-B1" parameter on the Scantool data list.
- 4. Disconnect and plug the positive crankcase ventilation.
- 5. Monitor the "SHORT TERM FUEL-B1" parameter on the Scantool data list once again.

Specification : The value should remain more or less unchanged.

6. Is the displayed value within the specified value?

YES Go to "Sensor Contamination Inspection" procedure. NO The engine oil is diluted with fuel. Chang the oil and oil filter and go to "Verification of Vehicle Repair" procedure.

#### SENSOR CONTAMINATION INSPECTION

- 1. Visually/physically inspect following items:
  - Remove and inspect the HO2S(B1S1) for any silicon contamination. This contamination will be indicated by a white powdery coating and this will result in a but false voltage signal.
  - Check MAFS for contamination, deterioration, or damage.
  - If contamination is evident on the HO2S or MAFS, replace contaminated sensor and go to next step.

#### CHECK FOR LEAKAGE IN EVAP SYSTEM

- 1. Check the EVAP. EM system for possible over.
  - 1) Remove the manifold side vacuum hose from the EVAP canister purge valve.
  - 2) Using a hand vacuum pump apply specified vacuum(Approx. 15 in, Hg) to the manifold side of the valve.
  - 3) Does the valve hold vacuum?

YES

Go to "Fuel System Inspection" procedure.

NO

Repair air leakage and go to "Verification of Vehicle Repair" procedure.

### FUEL SYSTEM INSPECTION E1FF9819

- 1. Check the fuel for excessive water, alcohol, or other contaminants. Replace contaminated fuel as necessary.
- 2. Disconnect the vacuum hose from the fuel pressure regulator and inspect the hose for the presence of fuel. If any fuel is present in the vacuum hose, replace the fuel pressure regulator. Go to next step.
- 3. Install a fuel pressure gage.
- 4. Start engine and let it idle. With the vacuum hose from the fuel pressure regulator disconnected, inspect fuel pressure.

Specification : 250~350kPa(2.50~3.50 kg/cm<sup>2</sup>, 36~50 psi)

5. Is fuel pressure within the specified value?

# YES

Go to "Fuel Injector Inspection" procedure as below

#### NO

Repair as necessary refer to inspection note as below and go to "Verification of Vehicle Repair" procedure.

**NOTE** 

A. Check if fuel line pressure decreases when accelerating quickly.
If it does, check fuel pump maximum pressure. If pressure is OK, check fuel line and filter for clogging.

B. If fuel pressure is lower than specification : Check for fuel line pressure while pinching fuel return hose. If pressure quickly increases, check pressure regulator.

If pressure gradually increases, check for clogging between fuel pump and pressure regulator. If hose is not clogged, check fuel pump maximum pressure.

- C. If fuel pressure is higher than specification : Is fuel line clogged?
  - If it is not, replace pressure regulator.
  - If it is, replace it.

#### FUEL INJECTOR INSPECTION

1. Check the fuel injectors for clogging or any restrictions.

Test Condition : Ignition "OFF". Specification : No clogging and restriction.

2. Is the fuel injector OK?



Visually/physically inspect the engine mechanical problem. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Check injector for contamination, deterioration, or damage. Substitute with a known-good injector and check for proper operation. If the problem is corrected, replace injector and then go to "Verification of Vehicle Repair" procedure.

#### VERIFICATION OF VEHICLE REPAIR E3DFF62E

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable condition.
- 3. Read "DTC Status" parameter.
- 4. Is parameter displayed "History(Not Present) fault"?



System performing to specification at this time. Clear the DTC.



Go to the applicable troubleshooting procedure.



ولین سامانه دیجیتال تعمیرکاران خودرو در ایران



**FUEL SYSTEM** 

# DTC P0171 SYSTEM TOO LEAN (BANK 1)

#### COMPONENT LOCATION E31BD1CE

Refer to DTC P0170.

#### GENERAL DESCRIPTION E9003FD7

Refer to DTC P0170.

#### DTC DESCRIPTION ED8CBD6C

Breaking lambda adaptation and lambda controller limits for a an extended period, which initially may have been caused by failures in the fuel or intake system, will involve emission rise, and therefore shall be diagnosed by fuel system monitoring. If same error code is set in the next driving cycle, the PCM illuminates the MIL. The lambda controller deviations, including adaptive terms, are used for fuel system monitoring. The time counter is increased if lambda controller deviations exceed a specific threshold and the PCM will then set DTC P0171 or P0172 respectively depending on the direction of the deviation. P0171 is set with positive deviation and P0172 is set with negative deviation.

#### DTC DETECTING CONDITION EATED3EB

ITEM	DETECTING CONDITION	POSSIBLE CAUSE	
DTC Strategy	Monitoring deviation of fuel control		
Enable Condition	No relevant failure Estimated canister loading < 1 Lambda control active		
مديمد البالج	Estimated fuel dilution in oil limited is in rich side	Air leakage	
Threshold Value	Lambda controller+Trim value > 36% The above condition is met for more than 60 sec. within 180 sec.	Leaking EVAP system Low fuel pressure Faulty sensor signals	
Diagnostic Time 60 seconds			
Fail Safe	EVAP. Emission control function is controlled in minimum operation mode.		

#### MONITOR DTC STATUS E5BEAA77

#### 🚺 ΝΟΤΕ

If any misfire, Purge Solenoid Valve, Mass Air Flow Sensor or O2 Sensor heater codes are present, DO ALL REPAIRS associated with those codes before proceeding with this troubleshooting tree.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.

# WWW.DIGITALKHODRO.COM
FLA -181

B00112

1.4 AMBIENT CONDITIONS
1. MIL STATUS
2. DTC STATUS: <u>PRESENT</u>
3. DTC READINESS FLAG : <u>COMPLETE</u>
4. STATISTIC COUNTER : 1
5. OP.HOUR AFTER DETECTION OF DTC
6. OP.HOUR AFTER ERASURE OF DTC

5. Is parameter displayed "History(Not Present) fault"?

#### 🔟 ΝΟΤΕ

- A. History (Not Present) fault : DTC occurred but has been cleared.
- B. Present fault : DTC is occurring at present time.

#### YES

Fault is intermittent caused by poor contact in the sensor's and/or ECM's connector or was repaired and ECM memory was not cleared. Thoroughly check connectors for loose or poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

## اولین سامانه دیجیتال تعمیرکاران خودرو د<mark>ر ۹</mark>۹

Go to "Monitor Actuation Test" procedure.

#### MONITOR ACTUATION TEST E7FE097D

## 🚺 ΝΟΤΕ

The main purpose of this test is to identify potential engine mechanical condition problems and fuel and ignition systems problems that are not common to all cylinders. For best results, perform this test while maintaining as steady an rpm reading as possible. Caution! Before beginning tests; set the parking brake, place gear selector in P or N and block drive wheels for safety.

- 1. Warm up the engine to normal operating temperature and let it idle.
- 2. Install Scan Tool and select "INJECTOR #1" parameter on the Actuation Test mode shown in the figure.
- 3. Monitor engine rpm and shut off the injector #1 by pressing "STRT(F1)" key.
- 4. Repeat procedure on all injectors and record the engine rpm.

Specification : All cylinders should show an even RPM drop.

<b>1.6 ACTUATION TEST</b>				
NO.1 INJECT	POR			
DURATION	UNTIL STOP KEY			
METHOD	DEACTIVATION			
CONDITION	IG.KEY ON			
	ENGINE RUNNING			
PRESS [STRT], IF YOU ARE READY ! SELECT TEST ITEM USING UP/DOWN KEY				
STRT STOP				

B00172

5. Was each cylinder's rpm drop within the same value?

#### YES

Go to "Air Leakage Inspection" procedure.

#### NO

Cylinders with the least amount of RPM drop are not contributing their share of power. Go to "Fuel Injector Inspection" procedure and check the suspect cylinders.

## شرکت دیجیتال خودرو سامانه (مسئولیتноте 🔟 د

If the RPM loss between cylinders is quite large(200RPM or more) and engine has high mileage, there is possibility of engine wear. Perform compression test with pressure gauge to check the engine wear.

#### AIR LEAKAGE INSPECTION E462F6F1

1. Visually/physically inspect the air leakage in intake/exhaust system as following items, If OK, go to next step.

If NG, repair as necessary and go to "Verification of Vehicle Repair" procedure.

- Vacuum hoses for splits, kinks and improper connections.
- Throttle body gasket
- Gasket between intake manifold and cylinder head
- Seals between intake manifold and fuel injectors
- Exhaust system between HO2S and Three way catalyst for air leakage
- 2. Check for air leakage in EVAP. Purge control valve
  - 1) Remove the manifold side vacuum hose from the EVAP canister purge valve.
  - 2) Using a hand vacuum pump apply specified vacuum(Approx. 15 in, Hg) to the manifold side of the valve.
  - 3) Does the valve hold vacuum?

YES

Go to "Fuel System Inspection" procedure.

NO

Repair air leakage and go to "Verification of Vehicle Repair" procedure.

## WWW.DIGITALKHODRO.COM

FUEL SYSTEM

## 021-62 99 92 92

## FUEL SYSTEM INSPECTION EF9524F0

- 1. Check the fuel for excessive water, alcohol, or other contaminants. Replace contaminated fuel as necessary.
- 2. Disconnect the vacuum hose from the fuel pressure regulator and inspect the hose for the presence of fuel. If any fuel is present in the vacuum hose, replace the fuel pressure regulator. Go to next step.
- 3. Install a fuel pressure gauge.
- 4. Start engine and let it idle. With the vacuum hose from the fuel pressure regulator disconnected, inspect fuel pressure.

Specification : 250~350kPa(2.50~3.50 kg/cm<sup>2</sup>, 36~50 psi)

5. Is fuel pressure within the specified value?

## YES

Go to "Fuel Injector Inspection" procedure as below

## NO

Repair as necessary refer to inspection note as below and go to "Verification of Vehicle Repair" procedure.

**NOTE** 

A. Check if fuel line pressure decreases when accelerating quickly.

- If it does, check fuel pump maximum pressure. If pressure is OK, check fuel line and filter for clogging.

B. If fuel pressure is lower than specification : Check for fuel line pressure while pinching fuel return hose.

If pressure quickly increases, check pressure regulator.

*If pressure gradually increases, check for clogging between fuel pump and pressure regulator. If hose is not clogged, check fuel pump maximum pressure.* 

- C. If fuel pressure is higher than specification : Is fuel line clogged?
  - If it is not, replace pressure regulator.
  - If it is, replace it.

#### FUEL INJECTOR INSPECTION

1. Check the fuel injectors for clogging or any restrictions.

Test Condition : Ignition "OFF". Specification : No clogging and restriction.

2. Is the fuel injector OK?



Visually/physically inspect the engine mechanical problem. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Check injector for contamination, deterioration, or damage. Substitute with a known-good injector and check for proper operation. If the problem is corrected, replace injector and then go to "Verification of Vehicle Repair" procedure.

#### **FUEL SYSTEM**

#### VERIFICATION OF VEHICLE REPAIR EC0671F5

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable condition.
- 3. Read "DTC Status" parameter.
- 4. Is parameter displayed "History(Not Present) fault"?

#### YES

System performing to specification at this time. Clear the DTC.

#### NO

Go to the applicable troubleshooting procedure.







## DTC TROUBLESHOOTING PROCEDURES

## DTC P0172 SYSTEM TOO RICH (BANK 1)

## COMPONENT LOCATION ECB65111

Refer to DTC P0170.

## GENERAL DESCRIPTION E66279AC

Refer to DTC P0170.

## DTC DESCRIPTION ECBC7D2E

Breaking lambda adaptation and lambda controller limits for a an extended period, which initially may have been caused by failures in the fuel or intake system, will involve emission rise, and therefore shall be diagnosed by fuel system monitoring. If same error code is set in the next driving cycle, the PCM illuminates the MIL. The lambda controller deviations, including adaptive terms, are used for fuel system monitoring. The time counter is increased if lambda controller deviations exceed a specific threshold and the PCM will then set DTC P0171 or P0172 respectively depending on the direction of the deviation. P0171 is set with positive deviation and P0172 is set with negative deviation.

#### DTC DETECTING CONDITION EF3CBCBB

DETECTING CONDITION		POSSIBLE CAUSE
DTC Strategy	Monitoring deviation of lambda controller	
Enable Condition	No relevant failure Estimated canister loading < 1 Lambda control active	Restricted intake or exhaust system Dirty engine oil or oil
فمديوديا ليراب	Estimated fuel dilution in oil limited is in rich side	level too high
Threshold Value	Lambda controller+Trim value > 36% The above condition is met for more than 60 sec. within 180	Front HO2S or MAFS contamination Over purging of the EVAP system
Diagnostic Time	60 seconds	High fuel pressure
Fail Safe	EVAP. Emission control function is controlled in minimum operation mode	Faulty sensor signals

#### MONITOR DTC STATUS EBOC2BCF

#### **NOTE**

If any misfire, Purge Solenoid Valve, Mass Air Flow Sensor or O2 Sensor heater codes are present, DO ALL REPAIRS associated with those codes before proceeding with this troubleshooting tree.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.

**FUEL SYSTEM** 

	1.4 AMBIENT CONDITIONS	
To naviate to the "DTAL"menu		
01 HYUNDAI VEHICLE DIAGNOSIS		
Select model and year	1. MIL STATUS	
└→ 02 ENGINE	2. DTC STATUS: <u>PRESENT</u>	
Select engine	3. DTC READINESS FLAG : <u>COMPLETE</u>	
→ 01 DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1	
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC	
PART ERAS DTAL HELP	6. OP.HOUR AFTER ERASURE OF DTC	

B00112

5. Is parameter displayed "History(Not Present) fault"?

#### 🔟 NOTE

- A. History (Not Present) fault : DTC occurred but has been cleared.
- B. Present fault : DTC is occurring at present time.

#### YES

Fault is intermittent caused by poor contact in the sensor's and/or ECM's connector or was repaired and ECM memory was not cleared. Thoroughly check connectors for loose or poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

## اولین سامانه دیجیتال تعمیرکاران خودرو در <mark>ایک</mark>ر

Go to "Monitor Actuation Test" procedure.

## MONITOR ACTUATION TEST EFEBAF45

## 🔟 ΝΟΤΕ

The main purpose of this test is to identify potential engine mechanical condition problems and fuel and ignition systems problems that are not common to all cylinders. For best results, perform this test while maintaining as steady an rpm reading as possible. Caution! Before beginning tests; set the parking brake, place gear selector in P or N and block drive wheels for safety.

- 1. Warm up the engine to normal operating temperature and let it idle.
- 2. Install Scan Tool and select "INJECTOR #1" parameter on the Actuation Test mode shown in the figure.
- 3. Monitor engine rpm and shut off the injector #1 by pressing "STRT(F1)" key.
- 4. Repeat procedure on all injectors and record the engine rpm.

Specification : All cylinders should show an even RPM drop.

1.	<b>1.6 ACTUATION TEST</b>			
NO.1 INJECT	OR			
DURATION	UNTIL STOP KEY			
METHOD DEACTIVATION				
CONDITION	IG.KEY ON			
ENGINE RUNNING				
PRESS [STRT], IF YOU ARE READY ! SELECT TEST ITEM USING UP/DOWN KEY				
STRT STOP				

5. Was each cylinder's rpm drop within the same value?

#### YES

Go to " Check for restricted intake or exhause system" procedure.

NO

Cylinders with the least amount of RPM drop are not contributing their share of power. Go to "Fuel Injector Inspection" procedure and check the suspect cylinders.

## شرکت دیجیتال خودرو سامانه (مسئولید**۲۰۳** ۹ د)

If the RPM loss between cylinders is quite large(200RPM or more) and engine has high mileage, there is possibility of engine wear. Perform compression test with pressure gauge to check the engine wear.

#### CHECK FOR RESTRICTED INTAKE OR EXHAUST SYSTEM

- 1. Visually/physically inspect the following items:
  - Air cleaner filter element for excessive dirt or for any foreign objects
  - Throttle body inlet for damage or for any foreign objects.
  - Throttle bore, throttle plate and the IAC passages for chocking and for any foreign objects.
  - Restricted exhaust system.
- 2. Was a problem found in any of the above areas?



Replace or repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### NO

Go to "Engine oil contamination Inspection" procedure.

#### ENGINE OIL CONTAMINATION INSPECTION

- 1. Check the engine oil level. The oil level should be between the min. and max. marking. Fill to the correct oil level.
- 2. Warm up the engine to normal operating temperature.
- 3. Install Scantool and note the "S/TERM FUEL TRIM(B1)" parameter on the Scantool data list.
- 4. Disconnect and plug the positive crankcase ventilation

## WWW.DIGITALKHODRO.COM

B00172

## 021-62999292

## FLA -188

## FUEL SYSTEM

5. Monitor the "S/TERM FUEL TRIM(B1)" parameter on the Scantool data list once again.

Specification : The value should remain more or less unchanged.

6. Is the displayed value within the specified value?

## YES

Go to "Sensor Contamination Inspection" procedure.

#### NO

The engine oil is diluted with fuel. Chang the oil and oil filter and go to "Verification of Vehicle Repair" procedure.

#### SENSOR CONTAMINATION INSPECTION

- 1. Visually/physically inspect following items:
  - Remove and inspect the HO2S(B1S1) for any silicon contamination. This contamination will be indicated by a white powdery coating and this will result in a but false voltage signal.
  - · Check MAFS for contamination, deterioration, or damage.
  - If contamination is evident on the HO2S or MAFS, replace contaminated sensor and go to next step.

#### OVER PURGING OF THE EVAP SYSTEM

1. Check the EVAP. EM system for possible over.

1) Remove the manifold side vacuum hose from the EVAP canister purge valve.

2) Using a hand vacuum pump apply specified vacuum(Approx. 15 in, Hg) to the manifold side of the valve.

3) Does the valve hold vacuum?

Go to "Fuel System Inspection" procedure.

NO

YES

Repair air leakage and go to "Verification of Vehicle Repair" procedure.

#### FUEL SYSTEM INSPECTION E3A14E44

- 1. Check the fuel for excessive water, alcohol, or other contaminants. Replace contaminated fuel as necessary.
- 2. Disconnect the vacuum hose from the fuel pressure regulator and inspect the hose for the presence of fuel. If any fuel is present in the vacuum hose, replace the fuel pressure regulator. Go to next step.
- 3. Install a fuel pressure gauge.
- 4. Start engine and let it idle. With the vacuum hose from the fuel pressure regulator disconnected, inspect fuel pressure.

Specification : 250~350kPa(2.50~3.50 kg/cm<sup>2</sup>, 36~50 psi)

5. Is fuel pressure within the specified value?

YES

Go to "Fuel Injector Inspection" procedure as below

## DTC TROUBLESHOOTING PROCEDURES

## NO

Repair as necessary refer to inspection note as below and go to "Verification of Vehicle Repair" procedure.

## 🔟 ΝΟΤΕ

- A. Check if fuel line pressure decreases when accelerating quickly.
  - If it does, check fuel pump maximum pressure. If pressure is OK, check fuel line and filter for clogging.
- B. If fuel pressure is lower than specification : Check for fuel line pressure while pinching fuel return hose.
  - If pressure quickly increases, check pressure regulator.
  - If pressure gradually increases, check for clogging between fuel pump and pressure regulator. If hose is not clogged, check fuel pump maximum pressure.
- C. If fuel pressure is higher than specification : Is fuel line clogged?
  - If it is not, replace pressure regulator.
  - If it is, replace it.

#### FUEL INJECTOR INSPECTION

1. Check the fuel injectors for clogging or any restrictions.

Test Condition : Ignition "OFF". Specification : No clogging and restriction.

2. Is the fuel injector OK?

YES

NO

Visually/physically inspect the engine mechanical problem. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

Check injector for contamination, deterioration, or damage. Substitute with a known-good injector and check for proper operation. If the problem is corrected, replace injector and then go to "Verification of Vehicle Repair" procedure.

#### VERIFICATION OF VEHICLE REPAIR E8B29C59

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable condition.
- 3. Read "DTC Status" parameter.
- 4. Is parameter displayed "History(Not Present) fault"?



System performing to specification at this time. Clear the DTC.

NO

Go to the applicable troubleshooting procedure.

FUEL SYSTEM

## DTC P0196 ENGINE OIL TEMP. SENSOR RANGE / PERFORMANCE

#### COMPONENT LOCATION E2D04625



EGQE601V

#### GENERAL DESCRIPTION E77A94BA

The fluid of the CVVT is the engine oil and its density changes according to the engine oil temperature. At this time the Oil Temperature Sensor (OTS) helps compensation against the temperature differences. The Oil Temperature Sensor measures the engine oil temperature before the engine oil comes into the Oil-flow Control Valve (OCV). According to the measured temperature, the Engine Control Module (PCM) compensates the oil-flow control valve operation time.

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

#### DTC DESCRIPTION EC6EGACA

The purpose of this diagnosis is to detect a stuck oil temperature signal or unplausibly low ,high signal. For the stuck signal detection, the PCM checks whether after a variation of the calculated oil temperature also a variation of the measured oil temperature is detected and sets DTC P0196 if the variation of the measured oil temperature is lower than the threshold.For the unplausibly high, low signal detection, the PCM compares measured engine oil temperature with calculated oil temperature or coolant temperature and sets DTC P0196 when one of following conditions is met.

- 1. Measured oil temperture is unplausibly low when calculated oil temperature is high.
- 2. Measured oil temperature is unplausibly high when coolant is low without any relevant failure.

## DTC DETECTING CONDITION EEAC794C

п	EM	DETECTING CONDITION	POSSIBLE CAUSE	
	DTC Strategy	Signal stuck		
(case1)	Enable Condi- tions	Engine coolant temperature at start < 40°C(104°F) No relevant failure 6 < Battery voltage < 16		
Case1)	Threshold Value	Calculated oil temperature increase > threshold but measured oil temperature increase < threshold(Threshold depends on Coolant temperature at start)		
	Diagnostic Time	10~30 minutes depending on coolant temperature at start and drive pattern	Contact resistance in	
	DTC Strategy	Signal plausibility	connectors Faulty OTS	
	Enable Condi- tions	No relevant failure 6 < Battery voltage < 16		
Case2)	Threshold Value	Coolant temperature at start < 40°C(104°F) & calculated oil temperature > 70°C(158°F) & measured oil temperature < 20°C(68°F) Coolant temperature < 70 (158°F) & measured oil temperature > 100 (212°F)		
ىحدود)	Diagnostic Time	15 seconds		

# SPECIFICATION EACEAE4B

Temp.(°C)	Temp.(°F)	Resistance(k )	Temp.(°C)	Temp.(°F)	Resistance(k )
-20	-4	16.52	40	104	1.11
0	32	6.00	60	140	0.54
20	68	2.45	80	176	0.29

FLA -191

## FUEL SYSTEM

## SCHEMATIC DIAGRAM E6586C5E



#### MONITOR DTC STATUS EBC5BB67

**NOTE** 

If any codes relating to OTS are stored, do ALL REPAIRS associated with those codes before proceeding with further troubleshooting.

1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.

2. Press F4(DTAL) to select DTC information from the DTCs menu.

- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.

	1.4 AMBIENT CONDITIONS
To naviate to the "DTAL"menu	
01 HYUNDAI VEHICLE DIAGNOSIS	
Select model and year	1. MIL STATUS
└─▶02 ENGINE	2. DTC STATUS: <u>PRESENT</u>
Select engine	3. DTC READINESS FLAG : <u>COMPLETE</u>
<b>01</b> DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC
PART ERAS DTAL HELP	6. OP.HOUR AFTER ERASURE OF DTC

B00112

5. Is parameter displayed "History(Not Present) fault"?

FLA -193

## 🚺 ΝΟΤΕ

- A. History (Not Present) fault : DTC occurred but has been cleared.
- B. Present fault : DTC is occurring at present time.

## YES

Fault is intermittent caused by poor contact in the sensor's and/or ECM's connector or was repaired and ECM memory was not cleared. Thoroughly check connectors for loose or poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

### NO

Go to next step as below.

## TERMINAL AND CONNECTOR INSPECTION E92F19EC

- 1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?



Repair as necessary and go to "Verification of Vehicle Repair" procedure



#### COMPONENT INSPECTION EB5356EB

- 1. Ignition "OFF"
- 2. Disconnect OTS connector.
- 3. Measure resistance between terminals 1 and 2 of OTS connector.(Component side)

#### SPECIFICATION

Temp.(°C)	Temp.(°F)	Resistance(k )	Temp.(°C)	Temp.(°F)	Resistance(k )
-20	-4	16.52	40	104	1.11
0	32	6.00	60	140	0.54
20	68	2.45	80	176	0.29

## FLA -194

FUEL SYSTEM



1. Sensor Ground 2. OTS Signal

B01962

4. Is sensor switching properly?

## YES

Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### NO

Check OTS for contamination, deterioration, or damage. Substitute with a known-good OTS and check for proper operation. If the problem is corrected, replace OTS and then go to "Verification of Vehicle Repair" procedure.

## VERIFICATION OF VEHICLE REPAIR E2C8BDAF

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 3. Read "DTC Status" parameter.
- 4. Is parameter displayed "History(Not Present) fault"?



System performing to specification at this time. Clear the DTC.

NO

Go to the applicable troubleshooting procedure.

FLA -195

## DTC P0197 ENGINE OIL TEMP. SENSOR LOW INPUT

## COMPONENT LOCATION EB25451D

Refer to DTC P0196.

### GENERAL DESCRIPTION ED85C312

Refer to DTC P0196.

## DTC DESCRIPTION E2DF30B8

PCM sets DTC P0197 if the PCM detects signal voltage lower than the possible range of a properly operating OTS.

## DTC DETECTING CONDITION EDFBEE27

ITEM	DETECTING CONDITION	POSSIBLE CAUSE
DTC Strategy	Voltage range check	
Enable Condition	Engine coolant temperature < 100°C(212°F)	Short circuit to ground Contact resistance in
Threshold Value	Oil temperature > 154°C(309°F)	connectors Faulty OTS
Diagnostic Time	5 seconds	

# SPECIFICATION EAAB15C2

Temp.(°C)	Temp.(°F)	Resistance(k )	Temp.(°C)	Temp.(°F)	Resistance(k)
-20	-4	16.52	40	104	1.11
0	32	6.00	60	140	0.54
20	68	2.45	80	176	0.29

## SCHEMATIC DIAGRAM E7F08BCB

Refer to DTC P0196.

#### SIGNAL WAVEFORM E0470A46

 1.2 CURRENT
 DATA

 ×
 OIL TEMP.SENSOR(V)
 0



MONITOR DTC STATUS E80E0758

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.

4. Read "DTC Status" parameter.

1.4 AMBIENT CONDITIONS
1. MIL STATUS
2. DTC STATUS: <u>PRESENT</u>
3. DTC READINESS FLAG : <u>COMPLETE</u>
4. STATISTIC COUNTER : 1
5. OP.HOUR AFTER DETECTION OF DTC
6. OP.HOUR AFTER ERASURE OF DTC

5. Is parameter displayed "History(Not Present) fault"?

#### 🚺 NOTE

- A. History (Not Present) fault : DTC occurred but has been cleared.
- B. Present fault : DTC is occurring at present time.

## 021-62999292

## FUEL SYSTEM

B00112

## DTC TROUBLESHOOTING PROCEDURES

## YES

Fault is intermittent caused by poor contact in the sensor's and/or ECM's connector or was repaired and ECM memory was not cleared. Thoroughly check connectors for loose or poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

#### NO

Go to "Monitor Scantool Data" procedure.

#### MONITOR SCANTOOL DATA E31855D2

- 1. Ignition "ON" & Engine "OFF"
- 2. Disconnect OTS connector
- 3. Connect Scantool and monitor the "OIL TEMP. SENSOR(V)" parameter on the Scantool data list.

Specification : Approx. 5V

4. Is OTS parameter near the specified value.?



#### SIGNAL CIRCUIT INSPECTION E57FD360

- 1. Ignition "OFF"
- 2. Disconnect OTS connector.
- 3. Measure resistance between terminal 2 of the sensor harness connector and chassis ground.

Specification : Infinite

4. Is resistance within the specification?

## YES

Go to "Terminal and Connector Inspection" procedure.

NO

Repair short to ground in harness and go to "Verification of Vehicle Repair" procedure.

#### TERMINAL AND CONNECTOR INSPECTION EBD240ED

Refer to DTC P0196.

## 021-62999292

FLA -198

**FUEL SYSTEM** 

### COMPONENT INSPECTION EEF6E7ED

Refer to DTC P0196.

### VERIFICATION OF VEHICLE REPAIR EB9DB58A

Refer to DTC P0196.



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

WWW.DIGITALKHODRO.COM

FLA -199

## DTC P0198 ENGINE OIL TEMP. SENSOR HIGH INPUT

## COMPONENT LOCATION EC760304

Refer to DTC P0196.

## GENERAL DESCRIPTION E23E101D

Refer to DTC P0196.

## DTC DESCRIPTION E7CEDEB0

PCM sets DTC P0198 if the PCM detects signal voltage higher than the possible range of a properly operating OTS.

## DTC DETECTING CONDITION E9AED52E

ITEM DETECTING CONDITION	
Voltage range check	
5 minutes after engine start if coolant temperature < -10°C(14°F)	Open or short circuit to battery Contact resistance in
Oil temperature < -36°C(-33°F)	Connectors Faulty OTS
Diagnostic Time 5 seconds	
	Voltage range check 5 minutes after engine start if coolant temperature < -10°C(14°F) Oil temperature < -36°C(-33°F)

#### SPECIFICATION E6F142B4

Temp.(°C)	Temp.(°F)	Resistance(k)	Temp.(°C)	Temp.(°F)	Resista <mark>nce(</mark> k )
-20	-4	16.52	40	104	1.11
0	32	6.00	60	140	0.54
20	68	2.45	80	176	0.29

#### SCHEMATIC DIAGRAM EAA580C3

Refer to DTC P0196.

## FUEL SYSTEM

### SIGNAL WAVEFORM ED25384E

		1.2 CURI	VENT .	DATA			- 10		1.2 CUR	.KENI .	DATA		
×	OIL TEMP.	.SENSOR(V)		4980	mV		×	OIL TEMP.	SENSOR(V	)	4980	mV	Γ
×	OIL TEMP.	.SENSOR		80.0	°C		×	OIL TEMP.	SENSOR		80.0	°C	
	02 SNSR V	/OLT.(B1/S1	 .)				_	02 SNSR V	OLT.(B1/S	 1)			
	02 SNSR V	OLT.(B1/S2	)					02 SNSR V	OLT.(B1/S	2)			
	MASS AIR	FLOW						MASS AIR	FLOW				
	BATTERY VOL	VOLTAGE						BATTERY V	VOLTAGE				
	COOLANT	TEMP. SE	NSOR					COOLANT	TEMP. SE	INSOR			
	COOLANT	TEMP. SN	SR(V)					COOLANT	TEMP. SN	ISR(V)			
						T.						0.000	Ŧ
	FIX PA	ART FULL	HELP	GRPH	RCRD			FIX PA	RT FULI	L HELP	GRPH	I RCRI	)
Fi	<b>g</b> 1					1	Fig	g 2					
Fig.	1) Open in	signal circuit	Approx.5	5V									
Eia	2) Open in	around airouit		<b>5</b> \/									

MONITOR DTC STATUS EA1BOD4F

1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.

2. Press F4(DTAL) to select DTC information from the DTCs menu.

- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.

	1.4 AMBIENT CONDITIONS
To naviate to the "DTAL"menu	
01 HYUNDAI VEHICLE DIAGNOSIS	
Select model and year	1. MIL STATUS
└→02 ENGINE	2. DTC STATUS: <u>PRESENT</u>
Select engine	3. DTC READINESS FLAG : <u>COMPLETE</u>
<b>01</b> DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC
PART ERAS DTAL HELP	6. OP.HOUR AFTER ERASURE OF DTC

B00112

B01981

5. Is parameter displayed "History(Not Present) fault"?

#### 🔟 ΝΟΤΕ

- A. History (Not Present) fault : DTC occurred but has been cleared.
- B. Present fault : DTC is occurring at present time.

## WWW.DIGITALKHODRO.COM

## YES

Fault is intermittent caused by poor contact in the sensor's and/or ECM's connector or was repaired and ECM memory was not cleared. Thoroughly check connectors for loose or poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

#### NO

Go to "Monitor Scantool Data" procedure.

#### MONITOR SCANTOOL DATA E4DF135B

- 1. Ignition "ON" & Engine "OFF"
- 2. Disconnect OTS connector
- 3. Connect Scantool and monitor the "OIL TEMP. SENSOR(V)" parameter on the Scantool data list.
- 4. Jumper the terminals 1 and 2 of the sensor harness connector together.

S	pecification : Approx. 0V	
5.	Is OTS parameter near the specified value.?	
	Possibility of sensor malfunction. Go to "Component Inspection" procedure.	
	NO left in the second of the s	
6.	Jumper the terminal 2 of the OTS harness connector to chassis ground.	

7. Observe the "OIL TEMP. SENSOR" parameter on the Scantool.

Specification : Approx. 0V

## YES

Possibility of open in OTS ground circuit. Go to "Ground Circuit Inspection" procedure.

NO

Possibility of open or short to battery in OTS signal circuit. Go to "Signal Circuit Inspection" procedure.

#### GROUND CIRCUIT INSPECTION EFFBCA5A

- 1. Ignition "OFF"
- 2. Disconnect PCM connector.
- 3. Measure resistance between terminals 1 of the OTS harness connector and 76 of the PCM harness connector.

Specification : Approx. 0

## WWW.DIGITALKHODRO.COM

## 021-62999292

#### FLA -202

**FUEL SYSTEM** 

4. Is resistance within the specification?

#### YES

Go to "Terminal and Connector Inspection" procedure.

#### NO

Repair short to ground in harness and go to "Verification of Vehicle Repair" procedure.

#### SIGNAL CIRCUIT INSPECTION ECACABDD

- 1. Check for open in signal circuit.
  - 1) Ignition "OFF"
  - 2) Measure resistance between terminals 2 of the OTS harness connector and 52 of the PCM harness connector.

Specification : Approx.
-------------------------

3)	Is resistance within specification?	
	YES	
	Go to next step as below.	
	Go to next step as below.	
	اولىرز سامانە دىجىتال تعمىركاران خودر ودر اير	
	Repair as necessary and go to "Verification of Vehicle Repair" procedure.	

- 2. Check for short to battery in signal circuit.
  - 1) Disconnected PCM connector.
  - 2) Ignition "ON" & Engine "OFF".
  - 3) Measure voltage between terminals 2 of the OTS harness connector and 52 of the PCM harness connector.

Specification : Approx. 0V

4) Is voltage within specification?

## YES

Go to "Terminal and Connector Inspection" procedure.

NO

Repair short to battery in harness and go to "Verification of Vehicle Repair" procedure.

#### TERMINAL AND CONNECTOR INSPECTION E9FOEDE6

Refer to DTC P0196.

## COMPONENT INSPECTION EE7D5B8B

Refer to DTC P0196.

## VERIFICATION OF VEHICLE REPAIR E00FF0FA

Refer to DTC P0196.



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



FLA -203

FUEL SYSTEM

## DTC P0230 FUEL PUMP PRIMARY CIRCUIT

## COMPONENT LOCATION EBDC05EE



The PCM provides ground to one side of the coil in the fuel pump relay to control the fuel pump relay. The other side of the fuel pump relay coil is connected to fuel pump relay, which activates when the ignition switch is ON. The PCM monitors the control circuit between the fuel pump relay and the PCM. When the ignition switch is turned ON, the PCM energizes the fuel pump relay, which sends power to the fuel pump.

#### 

PCM sets DTC P0230 if the PCM detects the fuel pump relay control circuit is open, short to ground or battery.

#### DTC DETECTING CONDITION ECDDAF9C

ITEM	DETECTING CONDITION	POSSIBLE CAUSE
DTC Strategy	Check open or short to ground/battery in control circuit	
Enable Condition	10V < Battery voltage < 16V	Open or short in harness Contact resistance in
Threshold Value	Open, short to battery or short to ground	connectors Faulty fuel pump relay
Diagnostic Time	3 seconds	Faulty fuel pullip felay

## SCHEMATIC DIAGRAM ECICFFEB



- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.

	1.4 AMBIENT CONDITIONS
To naviate to the "DTAL"menu	
<b>01</b> HYUNDAI VEHICLE DIAGNOSIS	
Select model and year	1. MIL STATUS
└→02 ENGINE	2. DTC STATUS: <u>PRESENT</u>
Select engine	3. DTC READINESS FLAG : <u>COMPLETE</u>
DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC
PART ERAS DTAL HELP	6. OP.HOUR AFTER ERASURE OF DTC

B00112

5. Is parameter displayed "History(Not Present) fault"?

#### 🔟 ΝΟΤΕ

- A. History (Not Present) fault : DTC occurred but has been cleared.
- B. Present fault : DTC is occurring at present time.

## WWW.DIGITALKHODRO.COM

## 021-62999292

#### FLA -205

#### FLA -206

## YES

**FUEL SYSTEM** 

Fault is intermittent caused by poor contact in the sensor's and/or ECM's connector or was repaired and ECM memory was not cleared. Thoroughly check connectors for loose or poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

#### NO

Go to "Component Inspection" procedure.

#### COMPONENT INSPECTION E421AB97

- 1. Ignition "OFF" & Engine "OFF"
- 2. Remove the fuel pump relay.
- 3. Apply 12V and a ground to 5 and 3 of the fuel pump relay(Component side).
- 4. Check if the fuel pump relay works well when it is energized. (If the fuel pump relay works normally, a clicking sound can be heard.)
- 5. Does the fuel pump relay operate normally?



Check relay for contamination, deterioration, or damage. Substitute with a known-good relay and check for proper operation. If the problem is corrected, replace relay and then go to "Verification of Vehicle Repair" procedure.

#### TERMINAL AND CONNECTOR INSPECTION E9CA5AF2

- 1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure

NO

Go to "Component Inspection" procedure

#### POWER SUPPLY CIRCUIT INSPECTION E5BF27AB

- 1. Remove the fuel pump relay.
- 2. Ignition "ON" & Engine "OFF".
- 3. Measure the voltage between terminal 5 of the fuel pump relay harness connector and chassis ground.

## 021- 62 99 92 92

## DTC TROUBLESHOOTING PROCEDURES

4. Measure the voltage between terminal 1 of the fuel pump relay harness connector and chassis ground.

Specification : Approx. B+

5. Is voltage within the specification?



Go to "Control Circuit Inspection" procedure



Check for an open or short to ground in the power supply circuit. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### CONTORL CIRCUIT INSPECTION EF7D4DAD

- 1. Check for short to ground in control circuit
  - 1) Ignition "OFF" & Relay connector : Disconnected.
  - 2) Measure resistance between terminal 3 of the relay harness connector and chassis ground.



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

- 2. Check for short to power in control circuit
  - 1) Disconnect PCM connector
  - 2) Ignition "ON" & Engine "OFF"
  - 3) Measure voltage between terminal 3 of the relay harness connector and chassis ground

Specification : Approx 0V

4) Is voltage within the specification?



Go to next step as below

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

3. Check for open in control harness

## WWW.DIGITALKHODRO.COM

### 021-62999292

#### FLA -208

FUEL SYSTEM

1) Measure resistance between terminals 3 of the relay harness connector and 69 of the PCM harness connector.

Specification : Approx 0

2) Is resistance within the specification?



Thoroughly Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### VERIFICATION OF VEHICLE REPAIR E30FE3AC

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 3. Read "DTC Status" parameter.
- 4. Is parameter displayed "History(Not Present) fault"?



NO

Go to the applicable troubleshooting procedure.

FLA -209

## DTC P0261 CYLINDER 1-INJECTOR CIRCUIT LOW

## COMPONENT LOCATION EAD92CEA



EGQE603L

#### GENERAL DESCRIPTION EBBF2B77

Based on information from various sensors, the PCM measures the fuel injection amount. The fuel injector is a solenoidoperated valve and the fuel injection amount is controlled by length of time the fuel injector is held open. The PCM controls each injector by grounding the control circuit. When the PCM energizes the injector by grounding the control circuit, the circuit voltage should be low (theoretically 0V) and the fuel is injected. When the PCM de-energizes the injector by opening the control circuit, the fuel injector is closed and circuit voltage should momentarily peak.

#### DTC DESCRIPTION E9A3AFF3

PCM sets DTC P0261 if the PCM detects that injector (Cylinder #1) control circuit is shorted to ground.

## DTC DETECTING CONDITION ECC746F2

ltem	Detecting Condition	Possible Cause
DTC Strategy	Driver Stage Check	Open in power supply harness
Enable Conditions	10 < Battery voltage(V) < 16 Engine speed(rpm) > 30	Short to ground in control harness
Threshold Value	Short to ground	Contact resistance in connectors
Diagnostic Time	1.5 sec.	Faulty injector

#### SPECIFICATION EF4EFC97

Temp.( )	Temp.( )	Resistance ( )	Temp.( )	Temp.( )	Resistance ( )
-20	-4	12.2 ~ 12.3	40	104	15.5 ~ 15.7
-10	14	12.9 ~ 13.1	50	122	16.1 ~ 16.3
0	32	13.3 ~ 13.5	60	140	16.6 ~ 16.8
10	50	13.9 ~ 14.0	80	176	17.7 ~ 17.9

## WWW.DIGITALKHODRO.COM

## FUEL SYSTEM

20	68	14.4 ~ 14.6	100	212	18.8 ~ 19.0
30	86	15.0 ~ 15.2	120	248	19.9 ~ 20.1

## SCHEMATIC DIAGRAM E44CD10E

		[Connection INJECTOR #1	Information]			
NJECTOR #1 2	24 - INJECTOR #1	Terminal	Connected to	Function		
After Main Relay		1	Main relay	Battery Voltage		
NJECTOR #2		2	PCM Terminal 24	Injector operation		
$\nabla (d\pi)^2$	62 - INJECTOR #2 INJECTOR #2					
After Main Relay		Terminal	Connected to	Function		
NJECTOR #3		1	Main relay	Battery Voltage		
¥40	61 - INJECTOR #3	2	PCM Terminal 62	Injector operation		
After Main Relay	After Main Relay		INJECTOR #3			
NJECTOR #4 2	23 - INJECTOR #4	Terminal	Connected to	Function		
After Main Relay		1	Main relay	Battery Voltage		
		2	PCM Terminal 61	Injector operation		
		INJECTOR #4				
		Terminal	Connected to	Function		
		1 Main relay		Battery Voltage		
		2	PCM Terminal 23	Injector operation		
[CONNECTOR] INJECTOR Harness side connector	بتال خودرو س	رکت دیجی	PCM side terminal			
	6	7 8 9 10 11	* * 14 * * 17 18	8 * * 21 22 • • 5 4		
	۷ دیجیتال تع	26 27 * 29 30	31 32 * * * * 3	7 38 39 * * 42 43		
$\left[ \left\{ \left( 2 \right)^{2} \right\} \right]$		45 * 47 48 *	50 51 52 * 54 55 50	6 * 58 59 60 <b>• •</b> 3		
	*	64 65 66 67 68	69 70 71 72 73 * 75	5 76 77 78 * 80 81 2 1		
C137-1		C130-1				
				В		

#### MONITOR DTC STATUS E7FAE911

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.

FLA -211

B00112

	1.4 AMBIENT CONDITIONS		
To naviate to the "DTAL"menu			
<b>01</b> HYUNDAI VEHICLE DIAGNOSIS			
Select model and year	1. MIL STATUS		
L->02 ENGINE	2. DTC STATUS: <u>PRESENT</u>		
Select engine	3. DTC READINESS FLAG : <u>COMPLETE</u>		
DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1		
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC		
PART ERAS DTAL HELP	6. OP.HOUR AFTER ERASURE OF DTC		
T T			

5. Is parameter displayed "History(Not Present) fault"?

#### 🔟 ΝΟΤΕ

- A. History (Not Present) fault : DTC occurred but has been cleared.
- B. Present fault : DTC is occurring at present time.

#### YES

Fault is intermittent, caused by poor contact in the sensor's and/or PCM's connector or was repaired and PCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

## اولین سامانه دیجیتال تعمیرکاران خودرو د<mark>ر ۵</mark>۹

Go to "Component Inspection" procedure.

#### COMPONENT INSPECTION E642FD23

- 1. Ignition "OFF".
- 2. Disconnect injector connector.
- 3. Measure resistance between terminals 1 and 2 of the injector connector(Component side).

#### SPECIFICATION

Temp.( )	Temp.( )	Resistance()	Temp.( )	Temp.( )	Resistance ( )
-20	-4	12.2 ~ 12.3	40	104	15.5 ~ 15.7
-10	14	12.9 ~ 13.1	50	122	16.1 ~ 16.3
0	32	13.3 ~ 13.5	60	140	16.6 ~ 16.8
10	50	13.9 ~ 14.0	80	176	17.7 ~ 17.9
20	68	14.4 ~ 14.6	100	212	18.8 ~ 19.0
30	86	15.0 ~ 15.2	120	248	19.9 ~ 20.1

## FLA -212

FUEL SYSTEM



Battery Voltage
 Injector Operation

B02614

4. Is resistance within the specification?

#### YES

Go to next step as below.

#### NO

Check injector for contamination, deterioration, or damage. Substitute with a known-good injector and check for proper operation. If the problem is corrected, replace injector and then go to "Verification of Vehicle Repair" procedure.

### TERMINAL AND CONNECTOR INSPECTION E1DBCCB8

- 1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure procedure.

NO

Go to "Power Supply Circuit Inspection" procedure.

## POWER SUPPLY CIRCUIT INSPECTION E3B23BBD

- 1. Ignition "ON" & Engine "OFF".
- 2. Measure voltage between terminal 1 of the injector harness connector and chassis ground.

Specification : Approx. B+

3. Is voltage within the specification?

YES

Go to "Control Circuit Inspection" procedure.

#### NO

Check for a open in the power supply circuit between the main relay and the Injector Check for open or blown 15A injector fuse. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### CONTROL CIRCUIT INSPECTION EA9EBF3B

- 1. Check for short to ground in control circuit.
  - 1) Ignition "OFF".
  - 2) Measure resistance between terminal 2 of the injector harness connector and chassis ground.

Specification : Infinite

2. Is resistance within the specification?

YES

Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Repair open or short to ground in control harness and go to "Verification of Vehicle Repair" procedure.

#### VERIFICATION OF VEHICLE REPAIR E42A5DCA

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 3. Read "DTC Status" parameter.
- 4. Is parameter displayed "History(Not Present) fault"?



System performing to specification at this time. Clear the DTC.



Go to the applicable troubleshooting procedure.

**FUEL SYSTEM** 

## DTC P0262 CYLINDER 1-INJECTOR CIRCUIT HIGH

#### COMPONENT LOCATION E61CCF2B

Refer to DTC P0261.

#### GENERAL DESCRIPTION E2BD9636

Refer to DTC P0261.

#### DTC DESCRIPTION E8B2EC3E

PCM sets DTC P0262 if the PCM detects that injector (Cylinder #1) control circuit is open or shorted to battery voltage.

#### DTC DETECTING CONDITION EAGFEBCO

ltem	Detecting Condition	Possible Cause	
DTC Strategy	Driver Stage Check		
Enable Conditions	10 < Battery voltage(V) < 16 Engine speed(rpm) > 30	Open or short to battery in control harness. Contact resistance in	
Threshold Value	Open or short to battery	connectors Faulty injector	
Diagnostic Time	1.5 sec.		

#### شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

#### SPECIFICATION EFBFF9D2

Temp.( )	Temp.( )	Resistance ( )	Temp.( )	Temp.( )	Resistanc <mark>e()</mark>
-20	-4	12.2 ~ 12.3	40	104	15.5 ~ 15.7
-10	14	12.9 ~ 13.1	50	122	16.1 ~ 16.3
0	32	13.3 ~ 13.5	60	140	16.6 ~ 16.8
10	50	13.9 ~ 14.0	80	176	17.7 ~ 17.9
20	68	14.4 ~ 14.6	100	212	18.8 ~ 19.0
30	86	15.0 ~ 15.2	120	248	19.9 ~ 20.1

## SCHEMATIC DIAGRAM EC4A3657

Refer to DTC P0261.

#### MONITOR DTC STATUS EDUAC4DC

Refer to DTC P0261.

#### COMPONENT INSPECTION E3E4216A

Refer to DTC P0261.

## WWW.DIGITALKHODRO.COM

## DTC TROUBLESHOOTING PROCEDURES

#### TERMINAL AND CONNECTOR INSPECTION EEA8D979

Refer to DTC P0261.

## POWER SUPPLY CIRCUIT INSPECTION EBB8AGEC

- 1. Ignition "ON" & Engine "OFF".
- 2. Measure voltage between terminal 1 of the injector harness connector and chassis ground.

Specification : Approx. B+

3. Is voltage within the specification?



Go to "Control Circuit Inspection" procedure.

### NO

Check for a open in the power supply circuit between the main relay and the Injector. Check for open or blown 15A injector fuse.

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### CONTROL CIRCUIT INSPECTION EFADECF5

1. Check for short to battery in control circuit.

1) Ignition "OFF".

2) Disconnect PCM connector.

- 3) Ignition "ON" & Engine "OFF".
- 4) Measure voltage between terminal 2 of the injector harness connector and chassis ground.

Specification : Approx. 0V

5) Is voltage within the specification?

YES

Go to next step as below.

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

- 2. Check for Open in Control Circuit.
  - 1) Ignition "OFF".
  - 2) Measure resistance between terminals 2 of the injector harness connector and 24 of the PCM harness connector.

Specification : Approx. 0

3) Is resistance within the specification?

## WWW.DIGITALKHODRO.COM

### 021-62999292

#### FLA -216

#### YES

#### **FUEL SYSTEM**

Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### VERIFICATION OF VEHICLE REPAIR E16BF29E

Refer to DTC P0261.



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران
FLA -217

# DTC P0264 CYLINDER 2-INJECTOR CIRCUIT LOW

# COMPONENT LOCATION E8F479ED

Refer to DTC P0261.

# GENERAL DESCRIPTION E305BE8A

Refer to DTC P0261.

# DTC DESCRIPTION E99B9480

PCM sets DTC P0264 if the PCM detects that injector (Cylinder #2) control circuit is shorted to ground.

## DTC DETECTING CONDITION EBCF0BF4

ltem	Detecting Condition	Possible Cause
DTC Strategy	Driver Stage Check	Open in power supply harness
Enable Conditions	10 < Battery voltage(V) < 16 Engine speed(rpm) > 30	Short to ground in control harness
Threshold Value	Short to ground	Contact resistance in connectors
Diagnostic Time	1.5 sec.	Faulty injector

### شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

# SPECIFICATION E6EBC993

Temp.( )	Temp.( )	Resistance ( )	Temp.( )	Temp.( )	Resistan <mark>ce(</mark> )
-20	-4	12.2 ~ 12.3	40	104	15.5 ~ 15.7
-10	14	12.9 ~ 13.1	50	122	16.1 ~ 16.3
0	32	13.3 ~ 13.5	60	140	16.6 ~ 16.8
10	50	13.9 ~ 14.0	80	176	17.7 ~ 17.9
20	68	14.4 ~ 14.6	100	212	18.8 ~ 19.0
30	86	15.0 ~ 15.2	120	248	19.9 ~ 20.1

# SCHEMATIC DIAGRAM E18B97A7

Refer to DTC P0261.

# MONITOR DTC STATUS E7E06CAE

Refer to DTC P0261.

# COMPONENT INSPECTION E45C5A24

Refer to DTC P0261.

**FUEL SYSTEM** 

#### TERMINAL AND CONNECTOR INSPECTION EF8E8F23

Refer to DTC P0261.

#### POWER SUPPLY CIRCUIT INSPECTION ECF83DBE

- 1. Ignition "ON" & Engine "OFF".
- 2. Measure voltage between terminal 1 of the injector harness connector and chassis ground.

Specification : Approx. B+

3. Is voltage within the specification?

#### YES

Go to "Control Circuit Inspection" procedure.

#### NO

Check for a open in the power supply circuit between the main relay and the Injector. Check for open or blown 15A injector fuse.

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### CONTROL CIRCUIT INSPECTION E9CB65DE

- 1. Check for short to ground in control circuit.
  - 1) Ignition "OFF".

2) Measure resistance between terminal 2 of the injector harness connector and chassis ground.



2. Is resistance within the specification?

#### YES

Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Repair open or short to ground in control harness and go to "Verification of Vehicle Repair" procedure.

#### VERIFICATION OF VEHICLE REPAIR EE17C273

Refer to DTC P0261.

FLA -219

021-62999292

# DTC P0265 CYLINDER 2-INJECTOR CIRCUIT HIGH

# COMPONENT LOCATION EC2FB54A



EGQE603L

#### GENERAL DESCRIPTION EEEDCBC4

Based on information from various sensors, the PCM measures the fuel injection amount. The fuel injector is a solenoidoperated valve and the fuel injection amount is controlled by length of time the fuel injector is held open. The PCM controls each injector by grounding the control circuit. When the PCM energizes the injector by grounding the control circuit, the circuit voltage should be low (theoretically 0V) and the fuel is injected. When the PCM de-energizes the injector by opening control circuit, the fuel injector is closed and circuit voltage should momentarily peak.

### DTC DESCRIPTION EAFF70D3

PCM sets DTC P0265 if the PCM detects that injector (Cylinder #2) control circuit is open or shorted to battery voltage.

# DTC DETECTING CONDITION E5AFBE6E

ltem	Detecting Condition	Possible Cause
DTC Strategy	Driver Stage Check	
Enable Conditions	10 Battery voltage(V) 16 Engine speed(rpm) > 30	Open or short to battery in control harness. Contact resistance in
Threshold Value	Open or short to battery	connectors Faulty injector
Diagnostic Time	1.5 sec.	

### SPECIFICATION EBA6F568

Temp.( )	Temp.( )	Resistance()	Temp.( )	Temp.( )	Resistance ( )
-20	-4	12.2 ~ 12.3	40	104	15.5 ~ 15.7
-10	14	12.9 ~ 13.1	50	122	16.1 ~ 16.3
0	32	13.3 ~ 13.5	60	140	16.6 ~ 16.8
10	50	13.9 ~ 14.0	80	176	17.7 ~ 17.9

# WWW.DIGITALKHODRO.COM

# FUEL SYSTEM

20	68	14.4 ~ 14.6	100	212	18.8 ~ 19.0
30	86	15.0 ~ 15.2	120	248	19.9 ~ 20.1

# SCHEMATIC DIAGRAM E443A37A

C137-2								(	C13(	<b>)-1</b>							
		*	64 65	66 6	/ 68	69 7	07	1 72	73	* 7	5 70	6 77	78	*	80	81	2
\\(2\\1)\\/				47 4	-	50 5	_	_		55 5	-	-		60			_
		* دیجیا	26 27	* 2	-	31 3		_	*		-	3 39	$ \rightarrow $		42	43	3
		6	7 8	9 1	_		* 1		*	17 1			++	22		-	5 4
INJECTOR Harness side cor	nnector	يەن خو	ديج		برت	P	СМ	side	term	ninal				5			
[CONNECTOR] INJECTOR Harness side cor	a) dilalurara	a															
				2		F	PCM	Termi	nal 2	3		In	jector	ope	eratio	n	
				1			M	ain re	lay			E	Batter	y Vo	ltage	,	
			Т	ermina	al		Cor	nnecte	ed to				Fu	nctio	on		
			INJ	IECTC	R #4												_
Allei				2		F	PCM	Termi	nal 6	1		In	jecto	ope	eratio	n	
After	Main Relay	24.2426.52		1			M	ain re	lay			E	Batter	y Vo	ltage	;	
JECTOR #4 2	23 - INJ	IECTOR #4	Т	ermina	al		Cor	nnecte	ed to				Fu	nctio	on .		
	Main Relay		INJ	IECTC	R #3												
¥4内	61 - INJ	IECTOR #3		2		F	PCM	Termi	nal 6	2		In	jecto	ope	eratio	n	
IJECTOR #3				1			M	ain re	lay			E	Batter	y Vo	ltage	;	
After	Main Relay		Т	ermina	al		Cor	nnecte	ed to				Fu	nctio	on .		
JECTOR #2	62 - INJ	IECTOR #2	INJ	IECTC	R #2						1		,				
10 Sector 2	Main Relay			2		F		Termi		4				-	eratio		
X4ML		IECTOR #1		1				ain re				E	-		ltage		
12		FOTOR #4		ermina	al		Cor	nnecte	ot he				Fu	nctio	าท		

### MONITOR DTC STATUS EBOCBA8C

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.

FLA -221

B00112

	1.4 AMBIENT CONDITIONS
To naviate to the "DTAL"menu	
01 HYUNDAI VEHICLE DIAGNOSIS	
Select model and year	1. MIL STATUS
D2 ENGINE	2. DTC STATUS: <u>PRESENT</u>
Select engine	3. DTC READINESS FLAG : <u>COMPLETE</u>
<b>01</b> DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC
PART ERAS DTAL HELP	6. OP.HOUR AFTER ERASURE OF DTC

5. Is parameter displayed "History(Not Present) fault"?

### 🔟 ΝΟΤΕ

- A. History (Not Present) fault : DTC occurred but has been cleared.
- B. Present fault : DTC is occurring at present time.

#### YES

Fault is intermittent, caused by poor contact in the sensor's and/or PCM's connector or was repaired and PCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

# اولین سامانه دیجیتال تعمیرکاران خودرو د<mark>ر N</mark>S.

Go to "Component Inspection" procedure

#### COMPONENT INSPECTION EEICEEFF

- 1. Ignition "OFF".
- 2. Disconnect injector connector.
- 3. Measure resistance between terminals 1 and 2 of the injector connector(Component side).

#### SPECIFICATION

Temp.( )	Temp.( )	Resistance ( )	Temp.( )	Temp.( )	Resistance ( )
-20	-4	12.2 ~ 12.3	40	104	15.5 ~ 15.7
-10	14	12.9 ~ 13.1	50	122	16.1 ~ 16.3
0	32	13.3 ~ 13.5	60	140	16.6 ~ 16.8
10	50	13.9 ~ 14.0	80	176	17.7 ~ 17.9
20	68	14.4 ~ 14.6	100	212	18.8 ~ 19.0
30	86	15.0 ~ 15.2	120	248	19.9 ~ 20.1

### FLA -222

FUEL SYSTEM



Battery Voltage
 Injector Operation

B02641

4. Is resistance within the specification?

### YES

Go to next step as below.

#### NO

Check injector for contamination, deterioration, or damage. Substitute with a known-good injector and check for proper operation. If the problem is corrected, replace injector and then go to "Verification of Vehicle Repair" procedure.

## TERMINAL AND CONNECTOR INSPECTION EABC6DF5

- 1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Power Supply Circuit Inspection" procedure.

### POWER SUPPLY CIRCUIT INSPECTION EEDBDB92

- 1. Ignition "ON" & Engine "OFF".
- 2. Measure voltage between terminal 1 of the injector harness connector and chassis ground.

Specification : Approx. B+

3. Is voltage within the specification?

YES

Go to "Control Circuit Inspection" procedure.

#### NO

Check for a open in the power supply circuit between the main relay and the Injector. Check for open or blown 15A injector fuse. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

### CONTROL CIRCUIT INSPECTION E1F28AA1

- 1. Check for short to battery in control circuit.
  - 1) Ignition "OFF".
  - 2) Disconnect PCM connector.
  - 3) Ignition "ON" & Engine "OFF".
  - 4) Measure voltage between terminal 2 of the injector harness connector and chassis ground.

```
Specification : Approx. 0V
```

5) Is voltage within the specification?

YES	
Go to next step as below.	
شرکت دیجیتال خودر و سامانه (مسئولیت محدود)	
Repair as necessary and go to "Verification of Vehicle Repair" procedure.	
2. Check for Open in Control Circuit.	
1) Ignition "OFF".	

2) Measure resistance between terminals 2 of the injector harness connector and 62 of the PCM harness connector

Specification : Approx. 0

3) Is resistance within the specification?



Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### VERIFICATION OF VEHICLE REPAIR E692CE15

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.

# 021-62999292

# FLA -224

# FUEL SYSTEM

- 3. Read "DTC Status" parameter.
- 4. Is parameter displayed "History(Not Present) fault"?

# YES

System performing to specification at this time. Clear the DTC.

# NO

Go to the applicable troubleshooting procedure.



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



# DTC P0267 CYLINDER 3-INJECTOR CIRCUIT LOW

### COMPONENT LOCATION E6122EBB



EGQE603L

#### GENERAL DESCRIPTION EFD93DBD

Based on information from various sensors, the PCM measures the fuel injection amount. The fuel injector is a solenoidoperated valve and the fuel injection amount is controlled by length of time the fuel injector is held open. The PCM controls each injector by grounding the control circuit. When the PCM energizes the injector by grounding the control circuit, the circuit voltage should be low (theoretically 0V) and the fuel is injected. When the PCM de-energizes the injector by opening control circuit, the fuel injector is closed and circuit voltage should momentarily peak.

#### DTC DESCRIPTION E3F26CCC

PCM sets DTC P0267 if the PCM detects that injector (Cylinder #3) control circuit is shorted to ground.

### DTC DETECTING CONDITION E8932A4F

ltem	Detecting Condition	Possible Cause
DTC Strategy	Driver Stage Check	Open in power supply harness
Enable Conditions	10 Battery voltage(V) 16 Engine speed(rpm) > 30	Short to ground in control harness
Threshold Value	Short to ground	Contact resistance in connectors
Diagnostic Time	1.5 sec.	Faulty injector

#### SPECIFICATION E49A8849

Temp.( )	Temp.( )	Resistance ( )	Temp.( )	Temp.( )	Resistance ( )
-20	-4	12.2 ~ 12.3	40	104	15.5 ~ 15.7
-10	14	12.9 ~ 13.1	50	122	16.1 ~ 16.3
0	32	13.3 ~ 13.5	60	140	16.6 ~ 16.8
10	50	13.9 ~ 14.0	80	176	17.7 ~ 17.9

# 021-62999292

FLA -225

# WWW.DIGITALKHODRO.COM

# FUEL SYSTEM

20	68	14.4 ~ 14.6	100	212	18.8 ~ 19.0
30	86	15.0 ~ 15.2	120	248	19.9 ~ 20.1

# SCHEMATIC DIAGRAM EB74E5DD

C137-3	6								С	:130	)-1									
		7	04 0	00 00	0/10	0000	9110	1/1	72	13	~	75	76	77	10	~	80	01	2	<u> </u>
۲ (2 1		*		* 47 65 66		_	50 51 59 70	+ +		54 73	55 : * :	-	-	-	59 78	60 *	•	● 81	2	1
	ميركاران لآب	<u>ه</u> دیجیتال تع	A	-				1 1	*	*			38 3	-	*		42	43	3	
े निष्ट	<b>a</b> L	6		8 9		_	* *	14	*	*	17				_	22		•	5	4
INJECTOR Harness	side connector	بال حودرو س				ىبر	PC	M si	de t	erm	inal					5				
[CONNECTOR]	امانه (مسئم	بتال خودرو س																		
					2		PC	М Те	rmin	nal 2	3		C	Inje	ector	ope	erati	on		
					1		_	Main				_	_	-	atter	-		-		
				Terminal Connected to					Function											
				INJEC	TOR #	<i>‡</i> 4														
					2		PC	M Te	rmin	nal 6	1			Inje	ector	ope	erati	on		
<u> </u>	After Main Relay				1			Main	rela	ay				Ba	atter	y Va	oltag	е		
JECTOR #4 22		23 - INJECTOR #4	[	Term	inal		C	Conne	ected	d to					Fu	nctio	on			
	After Main Relay		1	INJEC	TOR #	#3														
X400		61 - INJECTOR #3			2		PC	М Те	rmin	nal 6	2			Inje	ector	оре	erati	on		
IJECTOR #3		61 - INJECTOR #3			1		Main relay						Battery Voltage							
下行 1	After Main Relay			Term	inal		C	Conne	ected	d to					Fu	nctio	on			
2		62 - INJECTOR #2		INJEC	TOR #	‡2														
JECTOR #2	After Main Relay				2		PC	M Te	rmin	nal 24	4	╈		Inje	ector	ope	erati	on		
XKO					1			Main	rela	ay				Ba	atter	y Vo	oltag	е		
		24 - INJECTOR #1		Term	iinai		C C	Conne	ected	d to					Fu	nctio	on			

### MONITOR DTC STATUS ED98036C

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.

FLA -227

B00112

	1.4 AMBIENT CONDITIONS					
To naviate to the "DTAL"menu						
<b>01</b> HYUNDAI VEHICLE DIAGNOSIS						
Select model and year	1. MIL STATUS					
→ 02 ENGINE	2. DTC STATUS: <u>PRESENT</u>					
Select engine	3. DTC READINESS FLAG : <u>COMPLETE</u>					
<b>01</b> DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1					
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC					
PART ERAS DTAL HELP	6. OP.HOUR AFTER ERASURE OF DTC					

5. Is parameter displayed "History(Not Present) fault"?

### **NOTE**

- A. History (Not Present) fault : DTC occurred but has been cleared.
- B. Present fault : DTC is occurring at present time.

#### YES

Fault is intermittent, caused by poor contact in the sensor's and/or PCM's connector or was repaired and PCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

# اولین سامانه دیجیتال تعمیرکاران خودرو د<mark>ر ۵</mark>۹

Go to "Component Inspection" procedure

#### COMPONENT INSPECTION EAA860E9

- 1. Ignition "OFF".
- 2. Disconnect injector connector.
- 3. Measure resistance between terminals 1 and 2 of the injector connector(Component side).

#### SPECIFICATION

Temp.( )	Temp.( )	Resistance()	Temp.( )	Temp.( )	Resistance ( )
-20	-4	12.2 ~ 12.3	40	104	15.5 ~ 15.7
-10	14	12.9 ~ 13.1	50	122	16.1 ~ 16.3
0	32	13.3 ~ 13.5	60	140	16.6 ~ 16.8
10	50	13.9 ~ 14.0	80	176	17.7 ~ 17.9
20	68	14.4 ~ 14.6	100	212	18.8 ~ 19.0
30	86	15.0 ~ 15.2	120	248	19.9 ~ 20.1

### FLA -228

FUEL SYSTEM



Battery Voltage
 Injector Operation

B02671

4. Is resistance within the specification?

## YES

Go to next step as below.

#### NO

Check injector for contamination, deterioration, or damage. Substitute with a known-good injector and check for proper operation. If the problem is corrected, replace injector and then go to "Verification of Vehicle Repair" procedure.

## TERMINAL AND CONNECTOR INSPECTION EEAD3EEA

- 1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Power Supply Circuit Inspection" procedure

# POWER SUPPLY CIRCUIT INSPECTION E95B4583

- 1. Ignition "ON" & Engine "OFF".
- 2. Measure voltage between terminal 1 of the injector harness connector and chassis ground.

Specification : Approx. B+

3. Is voltage within the specification?

YES

Go to "Control Circuit Inspection" procedure.

#### NO

Check for a open in the power supply circuit between the main relay and the Injector. Check for open or blown 15A injector fuse. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

### CONTROL CIRCUIT INSPECTION ECEDEB82

- 1. Check for short to ground in control circuit.
  - 1) Ignition "OFF".
  - 2) Measure resistance between terminal 2 of the injector harness connector and chassis ground.

Specification : Infinite

3) Is resistance within the specification?



Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Repair open or short to ground in control harness and go to "Verification of Vehicle Repair" procedure.

### VERIFICATION OF VEHICLE REPAIR EF9E2A97

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 3. Read "DTC Status" parameter.
- 4. Is parameter displayed "History(Not Present) fault"?



System performing to specification at this time. Clear the DTC.



Go to the applicable troubleshooting procedure.

**FUEL SYSTEM** 

# DTC P0268 CYLINDER 3-INJECTOR CIRCUIT HIGH

#### COMPONENT LOCATION E584FE9E

Refer to DTC P0267.

#### GENERAL DESCRIPTION EBDE85AC

Refer to DTC P0267.

#### DTC DESCRIPTION E69B12AB

PCM sets DTC P0268 if the PCM detects that injector (Cylinder #3) control circuit is open or shorted to battery voltage.

#### DTC DETECTING CONDITION E1A2701E

ltem	Detecting Condition	Possible Cause
DTC Strategy	Driver Stage Check	
Enable Conditions	10 Battery voltage(V) 16 Engine speed(rpm) > 30	Open or short to battery in control harness. Contact resistance in
Threshold Value	Open or short to battery	connectors Faulty injector
Diagnostic Time	1.5 sec.	

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

### SPECIFICATION E7F93E28

Temp.( )	Temp.( )	Resistance ( )	Temp.( )	Temp.( )	Resistanc <mark>e()</mark>		
-20	-4	12.2 ~ 12.3	40	40 104 15			
-10	14	12.9 ~ 13.1	50	122	16.1 ~ 16.3		
0	32	13.3 ~ 13.5	60	140	16.6 ~ 16.8		
10	50	13.9 ~ 14.0	80	176	17.7 ~ 17.9		
20	68	14.4 ~ 14.6	100	212	18.8 ~ 19.0		
30	86	15.0 ~ 15.2	120	248	19.9 ~ 20.1		

### SCHEMATIC DIAGRAM EA46553A

Refer to DTC P0267.

#### MONITOR DTC STATUS E479F33A

Refer to DTC P0267.

#### COMPONENT INSPECTION E9EAC0C4

Refer to DTC P0267.

# DTC TROUBLESHOOTING PROCEDURES

### TERMINAL AND CONNECTOR INSPECTION EDTEAECD

Refer to DTC P0267.

# POWER SUPPLY CIRCUIT INSPECTION EXBCB5D8

- 1. Ignition "ON" & Engine "OFF".
- 2. Measure voltage between terminal 1 of the injector harness connector and chassis ground.

Specification : Approx. B+

3. Is voltage within the specification?



Go to "Control Circuit Inspection" procedure.

## NO

Check for a open in the power supply circuit between the main relay and the Injector. Check for open or blown 15A injector fuse.

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### CONTROL CIRCUIT INSPECTION EEE5B2D0

1. Check for short to battery in control circuit.

1) Ignition "OFF".

2) Disconnect PCM connector.

- 3) Ignition "ON" & Engine "OFF"
- 4) Measure voltage between terminal 2 of the injector harness connector and chassis ground.

Specification : Approx. 0V

5) Is voltage within the specification?

YES

Go to next step as below.

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

- 2. Check for Open in Control Circuit.
  - 1) Ignition "OFF".
  - 2) Measure resistance between terminals 2 of the injector harness connector and 61 of the PCM harness connector.

Specification : Approx. 0

3) Is resistance within the specification?

# WWW.DIGITALKHODRO.COM

# 021-62999292

#### FLA -232

### YES

FUEL SYSTEM

Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR EB9D7A65

Refer to DTC P0267.



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

FLA -233

# DTC P0270 CYLINDER 4-INJECTOR CIRCUIT LOW

# COMPONENT LOCATION E37BD831



EGQE603L

#### GENERAL DESCRIPTION EEOD8D4A

Based on information from various sensors, the PCM measures the fuel injection amount. The fuel injector is a solenoidoperated valve and the fuel injection amount is controlled by length of time the fuel injector is held open. The PCM controls each injector by grounding the control circuit. When the PCM energizes the injector by grounding the control circuit, the circuit voltage should be low (theoretically 0V) and the fuel is injected. When the PCM de-energizes the injector by opening control circuit, the fuel injector is closed and circuit voltage should momentarily peak.

### DTC DESCRIPTION EB1D3345

PCM sets DTC P0270 if the PCM detects that injector (Cylinder #4) control circuit is shorted to ground.

### DTC DETECTING CONDITION E8130A5D

ltem	Detecting Condition	Possible Cause
DTC Strategy	Driver Stage Check	Open in power supply harness
Enable Conditions	10 Battery voltage(V) 16 Engine speed(rpm) > 30	Short to ground in control harness
Threshold Value	Short to ground	Contact resistance in connectors
Diagnostic Time	1.5 sec.	Faulty injector

### SPECIFICATION EDFEFED1

Temp.( )	Temp.( )	Resistance()	Temp.( )	Temp.( )	Resistance ( )
-20	-4	12.2 ~ 12.3	40	104	15.5 ~ 15.7
-10	14	12.9 ~ 13.1	50	122	16.1 ~ 16.3
0	32	13.3 ~ 13.5	60	140	16.6 ~ 16.8
10	50	13.9 ~ 14.0	80	176	17.7 ~ 17.9

# WWW.DIGITALKHODRO.COM

# FUEL SYSTEM

20	68	14.4 ~ 14.6	100	212	18.8 ~ 19.0
30	86	15.0 ~ 15.2	120	248	19.9 ~ 20.1

# SCHEMATIC DIAGRAM E9BA25E0

C137-1										C	130	-1									
		L	* 64	65 66	67	68	69 7	0	/1 7	2	73	* 7	5 7	76 7	7	78	*	80	81	2	1
\(2 \( 1 ) \[ +			* 45				50 \$	-		-		55 5		-	-		50				_
	ميركاران		* 26	A		-							-	38 3	_	-	-	42	43	3	
المحوال			6 7	8 9		11		_	14	*	*	17 1					22			5	4
INJECTOR Harness side co	onnector	تان خودرو ش				ىرە	ΨP	CN	1 sid	e te	erm	nal					5		-		2
[CONNECTOR] INJECTOR Harness side co																					
					2		F	PCN	1 Ter	nina	al 23	3			Inje	ctor	ope	eratio	on		
					1			Ν	<i>l</i> lain	rela	y			_	Ba	attery	Vo	Itag	Э		
				Terr	ninal			Со	onneo	ted	l to					Fur	ctic	on			
				INJE	TOR	#4															
	, main reolay				2		F	PCN	1 Ter	nina	al 61				Inje	ctor	ope	eratio	on		
After 1	After Main Relay				1			Ν	Лаin	rela	y			Battery Voltage							
JECTOR #4 2		23 - INJECTOR #4		Terr	ninal			Сс	onneo	ted	l to					Fur	ctic	on			
	er Main Relay	.elay			TOR	#3															
X4M		61 - INJECTOR #3			2		F	PCN	1 Ter	nina	al 62	2			Inje	ctor	оре	eratio	on		
JECTOR #3	-	-			1 Main relay						Battery Voltage										
Att 1 → Afte	er Main Relay			Terr	ninal			Со	onne	ted	l to					Fur	ctic	n			
JECTOR #2 2		62 - INJECTOR #2		INJE	TOR	#2							1				•				
10.500 U	er Main Relay				2		F		1 Ter			ļ				ctor		-			
采内		24 - INJECTOR #1			1			N	<i>l</i> ain	rela	V				Ва	attery	v Vo	Itag	e		
JECTOR #1		24 - INJECTOR #1		Terr	ninal			Co	onneo	ted	l to					Fur	ctio	n			

### MONITOR DTC STATUS E4BAE375

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.

FLA -235

B00112

MIL STATUS DTC STATUS: <u>PRESENT</u>
DTC STATUS: PRESENT
DTC READINESS FLAG : <u>COMPLETE</u>
STATISTIC COUNTER : 1
OP.HOUR AFTER DETECTION OF DTC
OP.HOUR AFTER ERASURE OF DTC
]

5. Is parameter displayed "History(Not Present) fault"?

#### 🔟 ΝΟΤΕ

- A. History (Not Present) fault : DTC occurred but has been cleared.
- B. Present fault : DTC is occurring at present time.

#### YES

Fault is intermittent, caused by poor contact in the sensor's and/or PCM's connector or was repaired and PCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

# اولین سامانه دیجیتال تعمیرکاران خودرو د<mark>ر ۵</mark>۹

Go to "Component Inspection" procedure.

#### COMPONENT INSPECTION EAB84A8D

- 1. Ignition "OFF".
- 2. Disconnect injector connector.
- 3. Measure resistance between terminals 1 and 2 of the injector connector(Component side).

#### SPECIFICATION

Temp.( )	Temp.( )	Resistance ( )	Temp.( )	Temp.( )	Resistance ( )
-20	-4	12.2 ~ 12.3	40	104	15.5 ~ 15.7
-10	14	12.9 ~ 13.1	50	122	16.1 ~ 16.3
0	32	13.3 ~ 13.5	60	140	16.6 ~ 16.8
10	50	13.9 ~ 14.0	80	176	17.7 ~ 17.9
20	68	14.4 ~ 14.6	100	212	18.8 ~ 19.0
30	86	15.0 ~ 15.2	120	248	19.9 ~ 20.1

### FLA -236

FUEL SYSTEM



Battery Voltage
 Injector Operation

B02701

4. Is resistance within the specification?

### YES

Go to next step as below.

#### NO

Check injector for contamination, deterioration, or damage. Substitute with a known-good injector and check for proper operation. If the problem is corrected, replace injector and then go to "Verification of Vehicle Repair" procedure.

## TERMINAL AND CONNECTOR INSPECTION EC75588F

- 1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Power Supply Circuit Inspection" procedure.

### POWER SUPPLY CIRCUIT INSPECTION EE98F59E

- 1. Ignition "ON" & Engine "OFF".
- 2. Measure voltage between terminal 1 of the injector harness connector and chassis ground.

Specification : Approx. B+

3. Is voltage within the specification?

YES

Go to "Control Circuit Inspection" procedure.

#### NO

Check for a open in the power supply circuit between the main relay and the Injector. Check for open or blown 15A injector fuse. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

### CONTROL CIRCUIT INSPECTION EBA943FB

- 1. Check for short to ground in control circuit.
  - 1) Ignition "OFF".
  - 2) Measure resistance between terminal 2 of the injector harness connector and chassis ground.

Specification : Infinite

3) Is resistance within the specification?



Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Repair open or short to ground in control harness and go to "Verification of Vehicle Repair" procedure.

### VERIFICATION OF VEHICLE REPAIR EFADIAA3

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 3. Read "DTC Status" parameter.
- 4. Is parameter displayed "History(Not Present) fault"?



System performing to specification at this time. Clear the DTC.



Go to the applicable troubleshooting procedure.

**FUEL SYSTEM** 

# DTC P0271 CYLINDER 4-INJECTOR CIRCUIT HIGH

#### COMPONENT LOCATION E87C9A91

Refer to DTC P0270.

#### GENERAL DESCRIPTION EB0EBF99

Refer to DTC P0270.

#### DTC DESCRIPTION EE18ED04

PCM sets DTC P0271 if the PCM detects that injector (Cylinder #4) control circuit is open or shorted to battery voltage.

#### DTC DETECTING CONDITION EC05C31D

ltem	Detecting Condition	Possible Cause
DTC Strategy	Driver Stage Check	
Enable Conditions	10 Battery voltage(V) 16 Engine speed(rpm) > 30	Open or short to battery in control harness Contact resistance in
Threshold Value	Open or short to battery	connectors Faulty injector
Diagnostic Time	1.5 sec.	

#### شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

#### SPECIFICATION E7D2DABF

Temp.( )	Temp.( )	Resistance ( )	Temp.( )	Temp.( )	Resistanc <mark>e()</mark>
-20	-4	12.2 ~ 12.3	40	104	15.5 ~ 15.7
-10	14	12.9 ~ 13.1	50	122	16.1 ~ 16.3
0	32	13.3 ~ 13.5	60	140	16.6 ~ 16.8
10	50	13.9 ~ 14.0	80	176	17.7 ~ 17.9
20	68	14.4 ~ 14.6	100	212	18.8 ~ 19.0
30	86	15.0 ~ 15.2	120	248	19.9 ~ 20.1

### SCHEMATIC DIAGRAM EAE69FB7

Refer to DTC P0270.

### MONITOR DTC STATUS ED9ECD2B

Refer to DTC P0270.

#### COMPONENT INSPECTION E2FC13C2

Refer to DTC P0270.

# DTC TROUBLESHOOTING PROCEDURES

# TERMINAL AND CONNECTOR INSPECTION EF68A04F

Refer to DTC P0270.

# POWER SUPPLY CIRCUIT INSPECTION E391CF5E

- 1. Ignition "ON" & Engine "OFF".
- 2. Measure voltage between terminal 1 of the injector harness connector and chassis ground.

Specification : Approx. B+

3. Is voltage within the specification?

#### YES

Go to "Control Circuit Inspection" procedure.

### NO

Check for a open in the power supply circuit between the main relay and the Injector. Check for open or blown 15A injector fuse.

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### CONTROL CIRCUIT INSPECTION E8ABF5DB

1. Check for short to battery in control circuit.

1) Ignition "OFF".

2) Disconnect PCM connector.

- 3) Ignition "ON" & Engine "OFF".
- 4) Measure voltage between terminal 2 of the injector harness connector and chassis ground.

Specification : Approx. 0V

5) Is voltage within the specification?

YES

Go to next step as below.

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

- 2. Check for Open in Control Circuit.
  - 1) Ignition "OFF".
  - 2) Measure resistance between terminals 2 of the injector harness connector and 23 of the PCM harness connector.

Specification : Approx. 0

3) Is resistance within the specification?

# 021-62999292

#### FLA -240

#### YES

#### FUEL SYSTEM

Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### VERIFICATION OF VEHICLE REPAIR ECFFDBD3

Refer to DTC P0270.



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

FLA -241

# DTC P0300 RANDOM/MULTIPLE CYLINDER MISFIRE DETECTED

# COMPONENT LOCATION E3703CC8



EGQE501Q

#### GENERAL DESCRIPTION EDAE4AC1

The Misfire monitor diagnostic is based on crankshaft rotation velocity variation. The PCM determines crankshaft rotational velocity using the crankshaft position sensor and camshaft position sensor. When a cylinder misfires the crankshaft slows down momentarily. By monitoring the crankshaft and camshaft position sensor signals, the PCM can calculate when a misfire occurs. For a non-catalyst damaging misfire, the diagnostic will be required to report a misfire present within 1000-3200 engine revolutions. For catalyst damaging misfire, the diagnostic will respond to monitor 200 engine revolutions. Rough roads may cause false misfire detection. The rough road(acceleration)sensor consists of a piezoelectric vibration pick up which detects vertical acceleration of the vehicle. The sensor signal is used by the PCM to determine the degree of vertical movement of the car, for example, on a bumpy road. Since this may also cause uneven engine running, the PCM uses the signal to distinguish the phenomenon from actual misfiring.

#### DTC DESCRIPTION ECEF58DC

The PCM must monitor the engine for misfiring possibly caused by ignition coil defects or injector fails. If misfiring is detected, the PCM will identify the cylinder(s) that has(have) misfired and then calculate misfiring rate for a given duration. The DTC for Misfire (P0301 to 0304) is set as soon as the misfiring rate exceeds the limit which may result in damage to the catalyst or increase emissions. The PCM stores the individual DTC for a cylinder which has more than a 10% total misfire rate. With a more than two cylinder misfire detection, the PCM sets P0300.

ltem	Detecting Condition	Possible Cause
DTC Strategy	Calculation of engine roughness	Faulty spark plugs,
Enable Conditions	78 < Mass air flow(mg/stroke) < 356 540 < Engine speed(RPM) < 6500 Coolant temperature > 20°C if Start temperature < -7°C 11V < Battery voltage < 16V Throttle Angle gradient is in predetermined range No injector shut off No rough road	high-tension lead, or Ignition coil Incorrect valve timing Uneven compression Air leakage Improper Fuel pressure or dirty fuel Blocked/Leaking injectors Leakage between cooling
Threshold Value	Misfire detected on 2 or more cylinders	system and cylinder

### DTC DETECTING CONDITION EF8F0558

# WWW.DIGITALKHODRO.COM

# FUEL SYSTEM

SPECIFICATION EASFA36D

FLA -242

Temp.( )	Temp.( )	Ignition primary coil()	lgnition secondary coil (kΩ)
-20	-4	0.5	7.7
0	32	0.54	8.4
20	68	0.58	9.1
40	104	0.62	9.8
60	140	0.66	10.5
80	176	0.71	11.2
100	212	0.75	11.9

# SCHEMATIC DIAGRAM EBA7BB9C



# MONITOR DTC STATUS E6C05F0B

# **NOTE**

If any codes relating to injectors, HO2S, ECT(Engine Coolant Temperature)Sensor, Throttle Position sensor or Mass Air Flow Sensor are stored, do ALL REPAIRS associated with those codes before proceeding with this troubleshooting tree.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.

FLA -243

B00112

	1.4 AMBIENT CONDITIONS
To naviate to the "DTAL"menu	
<b>01</b> HYUNDAI VEHICLE DIAGNOSIS	
Select model and year	1. MIL STATUS
D2 ENGINE	2. DTC STATUS: <u>PRESENT</u>
Select engine	3. DTC READINESS FLAG : <u>COMPLETE</u>
→ 01 DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC
PART ERAS DTAL HELP	6. OP.HOUR AFTER ERASURE OF DTC

Is parameter displayed "History(Not Present) fault"?

#### 🔟 ΝΟΤΕ

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

#### YES

Fault is intermittent caused by poor contact in the sensor's and/or PCM's connector or was repaired and PCM memory was not cleared. Thoroughly check connectors for loose or poor connections, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

# اولین سامانه دیجیتال تعمیرکاران خودرو د<mark>ر P</mark>Q.

Go to "Monitor Actuation Test" procedure.

### MONITOR ACTUATION TEST E141AE17

# 🚺 ΝΟΤΕ

The main purpose of this test is to identify potential engine mechanical condition problems and fuel and ignition systems problems that are not common to all cylinders. For best results, perform this test while maintaining as steady an rpm reading as possible.

Caution! Before beginning tests; set the parking brake, place gear selector in P or N and block drive wheels for safety.

- 1. Warm up the engine to normal operating temperature and let it idle.
- 2. Install Scan Tool and select "INJECTOR #1" parameter on the Actuation Test mode shown in the figure.
- 3. Monitor engine rpm and shut off the injector #1 by pressing "STRT(F1)" key
- 4. Repeat procedure on all injectors and record the engine rpm.

Specification : All cylinders should show an even RPM drop.

<b>1.6 ACTUATION TEST</b>			
NO.1 INJECT	OR		
DURATION	UNTIL STOP KEY		
METHOD DEACTIVATION			
CONDITION IG.KEY ON			
	ENGINE RUNNING		
PRESS [STRT], IF YOU ARE READY ! SELECT TEST ITEM USING UP/DOWN KEY			
STRT STOP	ח		

B00172

#### 5. Was each cylinder's rpm drop within the same value?

#### YES

Go to "Timing Inspection" procedure.

#### NO

Cylinders with the least amount of RPM drop are not contributing their share of power. Go to "Spark plug cable Inspection" procedure.

# ال خودرو سامانه (مسئولیت**عمم آتا**د

If the RPM loss between cylinders is quite large(200RPM or more) and engine has high mileage, there is possibility of engine wear. Perform compression test with pressure gauge to check the engine wear.

#### SPARK PLUG CABLE INSPECTION

- 1. Remove suspect cylinder's spark plug cable.
- 2. Visually/physically inspect the following items:
  - Damage, cracks and flashover.
- 3. Measure the resistance of the spark plug cable referring to specification.

Specification : 5.6k /m ±20%

### 🔟 ΝΟΤΕ

Resistance should not be higher than 10,000 per foot of cable. If resistance is higher than specification, replace the cable.

4. Is the displayed value within the specified value?

YES

Go to "Spark Plug Inspection " procedure.

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

# WWW.DIGITALKHODRO.COM

FUEL SYSTEM

### SPARK PLUG INSPECTION

- 1. Remove suspect cylinder's spark plugs.
- 2. Visually/physically inspect the following items:
  - Damaged insulation, Worn electrodes, Oil or fuel fouled, Loose terminals and cracks.
  - Check for plug gap : 1.0 1.1 mm (0.039 0.043 in.)
  - Check if the spark plug for the relevant cylinder is lighter in color than the other plugs.
- 3. Was a problem found in any of the above areas?



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Fuel Injector Inspection" procedure.

#### FUEL INJECTOR INSPECTION

1. Check the fuel injectors for clogging or any restrictions.

Test Condition : Ignition "OFF". Specification : No clogging and restriction.	
Is the fuel injector OK? YES	
<ul> <li>Visually/physically inspect the engine mechanical problem as below:</li> <li>Leaky or sticky valves or rings.</li> <li>Excessive valve deposits.</li> <li>Weak valve spring.</li> </ul>	

- Leaking head gasket.

If NG, repair as necessary and go to "Verification of Vehicle Repair" procedure. If OK, go to "Ignition Coil Inspection" procedure.



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

### **IGNITION COIL INSPECTION**

- 1. Ignition "OFF".
- 2. Ignition coil connector : Disconnect.
- 3. Visually/physically inspect the following items:
  - Damage, cracks and flashover.
- 4. Measure the primary coil resistance between terminals 1,3 and 2,3.

### SPECIFICATION :

Temp.( )	Temp.( )	Ignition primary coil ( )
-20	-4	0.5

# WWW.DIGITALKHODRO.COM

# 021-62999292

FLA -246	FUEL SYSTEM	
0	32	0.54
20	68	0.58
40	104	0.62
60	140	0.66
80	176	0.71
100	212	0.75





Is resistance within the specified value?

YES

Go to "Timing Inspection" procedure.

NO

Replace as necessary and go to "Verification of Vehicle Repair" procedure.

#### TIMING INSPECTION

- Set up an oscilloscope as follows : 1. Channel A (+): terminal 2 of the CKPS, (-): ground Channel B (+): terminal 2 of the CMPS, (-): ground
- Start the engine and check for signal waveform whether synchronize with camshaft sensor or not and tooth is missing 2. refer to sample waveforms as below.



# WWW.DIGITALKHODRO.COM

FLA -247



#### 3. Is the signal waveform normal?



# ولین سامانه دیجیتال تعمیرکاران خودر وNOTE 🔟

Air gap [0.3~1.7 mm [0.012~0.067 in] = measure distance from hosing to teeth on flywheel/torque converter (measurement "A") and from mounting surface on sensor to sensor tip (measurement "B") subtract "B" from "A".

If fail to synchronize CKPS with CMPS, check that the crankshaft and camshaft are correctly aligned the matching marks of the pulleys. Repair or readjust as necessary and go to "Verification of Vehicle Repair" procedure.

# AIR LEAKAGE INSPECTION E7CF7417

1. Visually/physically inspect the air leakage in intake/exhaust system as following items. If OK, go to next step.

If NG, repair as necessary and go to "Verification of Vehicle Repair" procedure.

- Vacuum hoses for splits, kinks and improper connections.
- Throttle body gasket.
- Gasket between intake manifold and cylinder head.
- Seals between intake manifold and fuel injectors.
- Exhaust system between HO2S and Three way catalyst for air leakage.
- 2. Was a problem found in any of the above areas?



Go to "Fuel System Inspection" procedure.

NO

Repair air leakage and go to "Verification of Vehicle Repair" procedure.

# WWW.DIGITALKHODRO.COM

#### FUEL SYSTEM INSPECTION EA8D8BB0

- 1. Check the fuel for excessive water, alcohol, or other contaminants. Replace contaminated fuel as necessary.
- 2. Install a fuel pressure gage.
- 3. Start engine and let it idle. Inspect fuel pressure with vacuum hose disconnected.

Test Condition : Ignition "ON" & Engine "ON" at Idle Specification : 250~350kPa(2.50~3.50 kg/c㎡, 36~50 psi)

4. Is fuel pressure within the specified value?

### YES

Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### NO

Repair as necessary refer to inspection noted as below and go to "Verification of Vehicle Repair" procedure.

Ũ	NOTE
А.	Check if fuel line pressure decreases when accelerating quickly. - If it does, check fuel pump maximum pressure. If pressure is OK, check fuel line and filter for clogging.
دود) دود)	If fuel pressure is lower than specification : Check for fuel line pressure while pinching fuel return hose If pressure quickly increases, check pressure regulator If pressure gradually increases, check for clogging between fuel pump and pressure regulator. If hose is not
	clogged, check fuel pump maximum pressure.
C.	If fuel pressure is higher than specification : Is fuel line clogged? - If it is not, replace pressure regulator.

- If it is, replace it.

# VERIFICATION OF VEHICLE REPAIR E41F19B9

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 3. Read "DTC Status" parameter.
- 4. Is parameter displayed "History(Not Present) fault"?



System performing to specification at this time. Clear the DTC.

NO

Go to the applicable troubleshooting procedure.

FLA -249

# DTC P0301 CYLINDER 1-MISFIRE DETECTED

# COMPONENT LOCATION E98B32D4



EGQE501Q

#### GENERAL DESCRIPTION E4F389DF

The Misfire monitor diagnostic is based on crankshaft rotation velocity variation. The PCM determines crankshaft rotational velocity using the crankshaft position sensor and camshaft position sensor. When a cylinder misfires the crankshaft slows down momentarily. By monitoring the crankshaft and camshaft position sensor signals, the PCM can calculate when a misfire occurs. For a non-catalyst damaging misfire, the diagnostic will be required to report a misfire present within 1000-3200 engine revolutions. For catalyst damaging misfire, the diagnostic will respond to monitor 200 engine revolutions. Rough roads may cause false misfire detection. The rough road(acceleration)sensor consists of a piezoelectric vibration pick up which detects vertical acceleration of the vehicle. The sensor signal is used by the PCM to determine the degree of vertical movement of the car, for example, on a bumpy road. Since this may also cause uneven engine running, the PCM uses the signal to distinguish the phenomenon from actual misfiring.

#### DTC DESCRIPTION E0805EEF

The PCM must monitor the engine for misfiring possibly caused by ignition coil defects or injector fails. If misfiring is detected, the PCM will identify the cylinder(s) that has(have) misfired and then calculate misfiring rate for a given duration. The DTC for Misfire (P0301 to 0304) is set as soon as the misfiring rate exceeds the limit which may result in damage to the catalyst or increase emissions. The PCM stores the individual DTC for a cylinder which has more than a 10% total misfire rate.

# FUEL SYSTEM

# DTC DETECTING CONDITION EEDCCC8D

	ltem	Detecting Condition	Possible Cause
DTC	Strategy	Calculation of engine roughness	
Enable	Conditions	150 < Mass air flow(mg/rev.) < 710 512 < Engine speed(RPM) < 6500 Coolant temperature > 20°C if Start temperature < -7°C 11V < Battery voltage < 16V Throttle Angle gradient is in predetermined range No injector shut off No rough road	Faulty spark plugs, high-tension lead, or Ignition coil. Incorrect valve timing. Uneven compression. Air leakage.
Case1)	Threshold Value Diagnosis Time	Misfire= 12~54% within 200 rev.	Improper Fuel pressure or dirty fuel.
		200 revolution or 3*200 revolution.	Blocked/Leaking injectors. Leakage between cooling system and cylinder.
Case2)	Threshold	Misfire > 1.2% within 1000 revolutions.	system and cylinder.
	Value Diagnosis Time	1000 revolution or 4*1000 revolution	

# SPECIFICATION EAF87B8D

SPECIFICATION EAF87B8D					
Temp.( )	Temp.( )	Ignition primary coil ( )	lgnition secondary coil (kΩ)		
مسئولي <sub>20</sub> محدود)	دیتال خود <u>ہ و</u> سامانہ ا	0.5 (کت دیچ	7.7		
0	32	0.54	8.4		
ران خودرو20ر ایران	نه ديجيت <mark>8</mark> 8 تعميركا	0.5 <mark>8 لين ساما</mark>	9.1		
40	104	0.62	9.8		
60	140	0.66	10.5		
80	176	0.71	11.2		
100	212	0.75	11.9		

# DTC TROUBLESHOOTING PROCEDURES

# SCHEMATIC DIAGRAM E6083FFF



If any codes relating to injectors, HO2S, ECT(Engine Coolant Temperature)Sensor, Throttle Position sensor or Mass Air Flow Sensor are stored, do ALL REPAIRS associated with those codes before proceeding with this troubleshooting tree.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.



B00112

# 021-62999292

#### FLA -252

#### FUEL SYSTEM

5. Is parameter displayed "History(Not Present) fault"?

#### 🚺 NOTE

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

### YES

Fault is intermittent caused by poor contact in the sensor's and/or PCM's connector or was repaired and PCM memory was not cleared. Thoroughly check connectors for loose or poor connections, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

#### NO

Go to "Monitor Actuation Test" procedure

#### MONITOR ACTUATOR TEST E5C21CAC

#### 🔲 NOTE

The main purpose of this test is to identify potential engine mechanical condition problems and fuel and ignition systems problems that are not common to all cylinders. For best results, perform this test while maintaining as steady an rpm reading as possible.

Caution! Before beginning tests; set the parking brake, place gear selector in P or N and block drive wheels for safety.

- 1. Warm up the engine to normal operating temperature and let it idle.
- 2. Install Scan Tool and select "INJECTOR #1" parameter on the Actuation Test mode shown in the figure.
- 3. Monitor engine rpm and shut off the injector #1 by pressing "STRT(F1)" key.
- 4. Repeat procedure on all injectors and record the engine rpm.

Specification : All cylinders should show an even RPM drop.

#### 1.6 ACTUATION TEST 01/17

NO.1 INJEC	TOR	10.0100
DURAT I ON	UNTIL STOP KEY	
METHOD	DEACTIVATION	
CONDITION	IG.KEY ON	
	ENGINE RUNNING	

PRESS [STRT], IF YOU ARE READY \* SELECT TEST ITEM USING UP/DOWN KEY

STRT STOP

B03012

5. Was each cylinder's rpm drop within the same value?

#### YES

Go to "Timing Inspection" procedure.
## NO

Cylinders with the least amount of RPM drop are not contributing their share of power. Go to "Spark plug cable Inspection" procedure.

# 🔟 ΝΟΤΕ

If the RPM loss between cylinders is quite large(200RPM or more) and engine has high mileage, there is possibility of engine wear. Perform compression test with pressure gauge to check the engine wear.

#### SPARK PLUG CABLE INSPECTION

- 1. Remove suspect cylinder's spark plug cable.
- 2. Visually/physically inspect the following items:
  - Damage, cracks and flashover.
- 3. Measure the resistance of the spark plug cable referring to specification.

Sp	pecification: 5.6k /m ±20%
	<b>NOTE</b> Resistance should not be higher than 10,000 per foot of cable. If resistance is higher than specification, replace the cable.
4. (১	Is the displayed value within the specified value?
	Go to "Spark Plug Inspection " procedure. اولین سامانه در NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### SPARK PLUG INSPECTION

- 1. Remove suspect cylinder's spark plugs.
- 2. Visually/physically inspect the following items:
  - Damaged insulation, Worn electrodes, Oil or fuel fouled, Loose terminals and cracks.
  - Check for plug gap : 1.0 1.1 mm (0.039 0.043 in.)
  - Check if the spark plug for the relevant cylinder is lighter in color than the other plugs.
- 3. Was a problem found in any of the above areas?



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Fuel Injector Inspection" procedure.

#### FUEL INJECTOR INSPECTION

1. Check the fuel injectors for clogging or any restrictions.

# WWW.DIGITALKHODRO.COM

# WWW.DIGITALKHODRO.COM

## FLA -254

FUEL SYSTEM

Test Condition : Ignition "OFF". Specification : No clogging and restriction.

2. Is the fuel injector OK?

# YES

Visually/physically inspect the engine mechanical problem as below:

- Leaky or sticky valves or rings.
- Excessive valve deposits.
- Weak valve spring.
- Leaking head gasket.

If NG, repair as necessary and go to "Verification of Vehicle Repair" procedure. If OK, go to "Ignition Coil Inspection" procedure.

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### **IGNITION COIL INSPECTION**

- 1. Ignition "OFF".
- 2. Ignition coil connector : Disconnect.
- 3. Visually/physically inspect the following items:Damage, cracks and flashover.
- 4. Measure the primary coil resistance between terminals 1 and 3.

#### اولىن سامانە دىجىتال تعميركاران خود: SPECIFICATION

Temp.( )	Temp.( )	Ignition primary coil ( )
-20	-4	0.5
0	32	0.54
20	68	0.58
40	104	0.62
60	140	0.66
80	176	0.71
100	212	0.75

EBKD002H



5. Is resistance within the specified value?	
YES	
Go to "Timing Inspection" procedure.	
NO Replace as necessary and go to "Verification of Vehicle Repair" proc	cedure.
TIMING INSPECTION	

- Set up an oscilloscope as follows : Channel A (+): terminal 2 of the CKPS, (-): ground Channel B (+): terminal 2 of the CMPS, (-): ground
- 2. Start the engine and check for signal waveform whether synchronize with camshaft sensor or not and tooth is missing refer to sample waveforms as below.

# WWW.DIGITALKHODRO.COM

# 021-62999292

#### FLA -256

#### FUEL SYSTEM



#### 3. Is the signal waveform normal?

YES		
Go to " Air Leakage Inspection " procedure		
NO		
Remove Crankshaft Position Sensor(CKPS) an	d calculate air gap between senso	or and flywheel/torque converter.

# Readjust as necessary and go to next step.

# ولین سامانه دیجیتال تعمیرکاران خودرو 🗛 🔟

Air gap [0.3~1.7 mm [0.012~0.067 in] = measure distance from hosing to teeth on flywheel/torque converter (measurement "A") and from mounting surface on sensor to sensor tip (measurement "B") subtract "B" from "A".

If fail to synchronize CKPS with CMPS, check that the crankshaft and camshaft are correctly aligned the matching marks of the pulleys. Repair or readjust as necessary and go to "Verification of Vehicle Repair" procedure.

#### AIR LEAKAGE INSPECTION EF7DC2AB

 Visually/physically inspect the air leakage in intake/exhaust system as following items. If OK, go to next step.

If NG, repair as necessary and go to "Verification of Vehicle Repair" procedure.

- Vacuum hoses for splits, kinks and improper connections.
- Throttle body gasket.
- Gasket between intake manifold and cylinder head.
- Seals between intake manifold and fuel injectors.
- Exhaust system between HO2S and Three way catalyst for air leakage.
- 2. Was a problem found in any of the above areas?

YES

Go to "Fuel System Inspection" procedure.

NO

Repair air leakage and go to "Verification of Vehicle Repair" procedure.

# WWW.DIGITALKHODRO.COM

# FUEL SYSTEM INSPECTION ECFE9F17

- 1. Check the fuel for excessive water, alcohol, or other contaminants. Replace contaminated fuel as necessary.
- 2. Install a fuel pressure gage.
- 3. Start engine and let it idle. Inspect fuel pressure with vacuum hose disconnected.

Test Condition : Ignition "ON" & Engine "ON" at Idle Specification : 250~350kPa(2.50~3.50 kg/cm², 36~50 psi)

4. Is fuel pressure within the specified value?



Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

# NO

Repair as necessary refer to inspection noted as below and go to "Verification of Vehicle Repair" procedure.

	NOTE
<b>1</b> .	Check if fuel line pressure decreases when accelerating quickly. - If it does, check fuel pump maximum pressure. If pressure is OK, check fuel line and filter for clogging.
ور <u>2.</u> مذود)	If fuel pressure is lower than specification : Check for fuel line pressure while pinching fuel return hose If pressure quickly increases, check pressure regulator If pressure gradually increases, check for clogging between fuel pump and pressure regulator. If hose is not
	clogged, check fuel pump maximum pressure.
3.	If fuel pressure is higher than specification : Is fuel line clogged? - If it is not, replace pressure regulator.

- If it is, replace it.

## VERIFICATION OF VEHICLE REPAIR EAE4E72E

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 3. Read "DTC Status" parameter.
- 4. Is parameter displayed "History(Not Present) fault"?



System performing to specification at this time. Clear the DTC.

NO

Go to the applicable troubleshooting procedure.

# WWW.DIGITALKHODRO.COM

**FUEL SYSTEM** 

# DTC P0302 CYLINDER 2-MISFIRE DETECTED

#### COMPONENT LOCATION E04247A5

Refer to DTC P0301.

#### GENERAL DESCRIPTION EC75E4B4

Refer to DTC P0301.

#### DTC DESCRIPTION EFF6B2BF

The PCM must monitor the engine for misfiring possibly caused by ignition coil defects or injector fails. If misfiring is detected, the PCM will identify the cylinder(s) that has(have) misfired and then calculate misfiring rate for a given duration. The DTC for Misfire (P0301 to 0304) is set as soon as the misfiring rate exceeds the limit which may result in damage to the catalyst or increase emissions. The PCM stores the individual DTC for a cylinder which has more than a 10% total misfire rate.

# DTC DETECTING CONDITION E58CAFB9

Item		Detecting Condition	Possible Cause
DTC Strategy		Calculation of engine roughness	Q
وليت محدود) Enable Conditions ودرو در ايران		<ul> <li>150 &lt; Mass air flow(mg/rev.) &lt; 710</li> <li>512 &lt; Engine speed(RPM) &lt; 6500</li> <li>Coolant temperature &gt; 20°C if Start temperature &lt; -7°C</li> <li>11V &lt; Battery voltage &lt; 16V</li> <li>Throttle Angle gradient is in predetermined range</li> <li>No injector shut off</li> <li>No rough road</li> </ul>	Faulty spark plugs, high-tension lead, or Ignition coil. Incorrect valve timing. Uneven compression. Air leakage.
	Threshold Value	Misfire= 12~54% within 200 rev.	Improper Fuel pressure or dirty fuel.
Case1)	Diagnosis Time	200 revolution or 3*200 revolution.	Blocked/Leaking injectors. Leakage between cooling system and cylinder.
	Threshold Value	Misfire > 1.2% within 1000 revolutions.	System and Cymruch.
Case2)	Diagnosis Time	1000 revolution or 4*1000 revolution	

#### SPECIFICATION E8BAA73B

Temp.( )	Temp.( )	Ignition primary coil()	lgnition secondary coil (kΩ)
-20	-4	0.5	7.7
0	32	0.54	8.4
20	68	0.58	9.1
40	104	0.62	9.8
60	140	0.66	10.5
80	176	0.71	11.2
100	212	0.75	11.9

# WWW.DIGITALKHODRO.COM

# SCHEMATIC DIAGRAM EBDC4D4A

Refer to DTC P0301.

# MONITOR DTC STATUS EEGCF2C6

# 🚺 ΝΟΤΕ

If any codes relating to injectors, HO2S, ECT(Engine Coolant Temperature)Sensor, Throttle Position sensor or Mass Air Flow Sensor are stored, do ALL REPAIRS associated with those codes before proceeding with this troubleshooting tree.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.

To naviate to the "DTAL"menu	1.4 AMBIENT CONDITIONS
01 HYUNDAI VEHICLE DIAGNOSIS	
Select model and year	1. MIL STATUS
→02 ENGINE	2. DTC STATUS: PRESENT
Select engine	3. DTC READINESS FLAG : <u>COMPLETE</u>
01 DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC
	6. OP.HOUR AFTER ERASURE OF DTC
PART ERAS DTAL HELP	

B00112

5. Is parameter displayed "History(Not Present) fault"?

#### 🔟 ΝΟΤΕ

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

## YES

Fault is intermittent caused by poor contact in the sensor's and/or PCM's connector or was repaired and PCM memory was not cleared. Thoroughly check connectors for loose or poor connections, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

#### NO

Go to "Monitor Actuation Test" procedure.

# WWW.DIGITALKHODRO.COM

# 021-62999292

# FLA -260

# MONITOR ACTUATOR TEST E3616AD6

# 🔟 ΝΟΤΕ

The main purpose of this test is to identify potential engine mechanical condition problems and fuel and ignition systems problems that are not common to all cylinders. For best results, perform this test while maintaining as steady an rpm reading as possible.

Caution! Before beginning tests; set the parking brake, place gear selector in P or N and block drive wheels for safety.

- 1. Warm up the engine to normal operating temperature and let it idle.
- 2. Install Scan Tool and select "INJECTOR #1" parameter on the Actuation Test mode shown in the figure.
- 3. Monitor engine rpm and shut off the injector #1 by pressing "STRT(F1)" key.
- 4. Repeat procedure on all injectors and record the engine rpm.

Specification : All cylinders should show an even RPM drop.

1	.6 ACTUATION TEST 01/17	•	
NO.1 INJEC	TOR	]	
DURATION	UNTIL STOP KEY		
METHOD	DEACTIVATION		
CONDITION	IG.KEY ON ENGINE RUNNING	شرکت دیجیتال خ	
	STRTI, IF YOU ARE READY ? ST ITEM USING UP/DOWN KEY	اولىن سامانە دىج	
STRT STO	P		
			В

5. Was each cylinder's rpm drop within the same value?



Go to "Timing Inspection" procedure.



Cylinders with the least amount of RPM drop are not contributing their share of power. Go to "Spark plug cable Inspection" procedure.

# 🔟 ΝΟΤΕ

If the RPM loss between cylinders is quite large(200RPM or more) and engine has high mileage, there is possibility of engine wear. Perform compression test with pressure gauge to check the engine wear.

#### SPARK PLUG CABLE INSPECTION

- 1. Remove suspect cylinder's spark plug cable.
- 2. Visually/physically inspect the following items:
  - Damage, cracks and flashover.
- 3. Measure the resistance of the spark plug cable referring to specification.

# WWW.DIGITALKHODRO.COM

# 021-62999292

#### **FUEL SYSTEM**

FLA -261

Specification : 5.6k /m ±20%

# 🔟 ΝΟΤΕ

Resistance should not be higher than 10,000 per foot of cable. If resistance is higher than specification, replace the cable.

4. Is the displayed value within the specified value?

# YES

Go to "Spark Plug Inspection " procedure.

NO

2.

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### SPARK PLUG INSPECTION

- 1. Remove suspect cylinder's spark plugs.
  - Visually/physically inspect the following items:
    - Damaged insulation, Worn electrodes, Oil or fuel fouled, Loose terminals and cracks.
    - Check for plug gap: 1.0 1.1 mm (0.039 0.043 in.)
    - Check if the spark plug for the relevant cylinder is lighter in color than the other plugs.
- 3. Was a problem found in any of the above areas?

YES Repair as necessary and go to "Verification of Vehicle Repair" procedure.

Go to "Fuel Injector Inspection" procedure.

#### FUEL INJECTOR INSPECTION

1. Check the fuel injectors for clogging or any restrictions.

Test Condition : Ignition "OFF". Specification : No clogging and restriction.

2. Is the fuel injector OK?



NO

Visually/physically inspect the engine mechanical problem as below:

- Leaky or sticky valves or rings.
- Excessive valve deposits.
- Weak valve spring.
- Leaking head gasket.

If NG, repair as necessary and go to "Verification of Vehicle Repair" procedure. If OK, go to "Ignition Coil Inspection" procedure.

# WWW.DIGITALKHODRO.COM

## 021-62999292

#### FLA -262

# NO

FUEL SYSTEM

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### **IGNITION COIL INSPECTION**

- 1. Ignition "OFF".
- 2. Ignition coil connector : Disconnect.
- 3. Visually/physically inspect the following items:
  - Damage, cracks and flashover.
- 4. Measure the primary coil resistance between terminals 2 and 3.

#### **SPECIFICATION** :

-4	0.5
32	0.54
68	0.58
104	0.62
140	0.66
176	0.71
212	0.75
	32 68 104 140 176



EBKD002H

# WWW.DIGITALKHODRO.COM

5. Is resistance within the specified value?

## YES

Go to "Timing Inspection" procedure.

# NO

Replace as necessary and go to "Verification of Vehicle Repair" procedure.

#### TIMING INSPECTION

- Set up an oscilloscope as follows : Channel A (+): terminal 2 of the CKPS, (-): ground Channel B (+): terminal 2 of the CMPS, (-): ground
- 2. Start the engine and check for signal waveform whether synchronize with camshaft sensor or not and tooth is missing refer to sample waveforms as below.



#### 3. Is the signal waveform normal?

# YES



## NO

Remove Crankshaft Position Sensor(CKPS) and calculate air gap between sensor and flywheel/torque converter. Readjust as necessary and go to next step.

## 🔟 ΝΟΤΕ

Air gap [0.3~1.7 mm [0.012~0.067 in] = measure distance from hosing to teeth on flywheel/torque converter (measurement "A") and from mounting surface on sensor to sensor tip (measurement "B") subtract "B" from "A".

If fail to synchronize CKPS with CMPS, check that the crankshaft and camshaft are correctly aligned the matching marks of the pulleys. Repair or readjust as necessary and go to "Verification of Vehicle Repair" procedure.

# WWW.DIGITALKHODRO.COM

021-62999292

#### AIR LEAKAGE INSPECTION EA3DDED3

1. Visually/physically inspect the air leakage in intake/exhaust system as following items. If OK, go to next step.

If NG, repair as necessary and go to "Verification of Vehicle Repair" procedure

- Vacuum hoses for splits, kinks and improper connections.
- Throttle body gasket.
- Gasket between intake manifold and cylinder head.
- Seals between intake manifold and fuel injectors.
- Exhaust system between HO2S and Three way catalyst for air leakage.
- 2. Was a problem found in any of the above areas?

#### YES

Go to "Fuel System Inspection" procedure.

#### NO

Repair air leakage and go to "Verification of Vehicle Repair" procedure.

#### FUEL SYSTEM INSPECTION E56F84E2

- 1. Check the fuel for excessive water, alcohol, or other contaminants. Replace contaminated fuel as necessary.
- 2. Install a fuel pressure gage.
- شرکت دیجیتال خودرو سامانه (مسئولیت محدود)
- Start engine and let it idle. Inspect fuel pressure with vacuum hose disconnected.

Test Condition : Ignition "ON" & Engine "ON" at Idle.Specification : 250~350kPa(2.50~3.50 kg/cm², 36~50 psi)

4. Is fuel pressure within the specified value?

#### YES

Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### NO

Repair as necessary refer to inspection noted as below and go to "Verification of Vehicle Repair" procedure.

## 🔟 ΝΟΤΕ

- 1. Check if fuel line pressure decreases when accelerating quickly.
  - If it does, check fuel pump maximum pressure. If pressure is OK, check fuel line and filter for clogging.
- 2. If fuel pressure is lower than specification : Check for fuel line pressure while pinching fuel return hose.
  - If pressure quickly increases, check pressure regulator.
  - If pressure gradually increases, check for clogging between fuel pump and pressure regulator. If hose is not clogged, check fuel pump maximum pressure.
- 3. If fuel pressure is higher than specification : Is fuel line clogged?
  - If it is not, replace pressure regulator.
  - If it is, replace it.

# WWW.DIGITALKHODRO.COM

# VERIFICATION OF VEHICLE REPAIR EDEFC276

Refer to DTC P0301.



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

FLA -265

**FUEL SYSTEM** 

#### **CYLINDER 3-MISFIRE DETECTED DTC P0303**

#### COMPONENT LOCATION E890FA71

Refer to DTC P0301.

#### GENERAL DESCRIPTION EB142880

Refer to DTC P0301.

#### DTC DESCRIPTION EEBC8DF5

The PCM must monitor the engine for misfiring possibly caused by ignition coil defects or injector fails. If misfiring is detected, the PCM will identify the cylinder(s) that has(have) misfired and then calculate misfiring rate for a given duration. The DTC for Misfire (P0301 to 0304) is set as soon as the misfiring rate exceeds the limit which may result in damage to the catalyst or increase emissions. The PCM stores the individual DTC for a cylinder which has more than a 10% total misfire rate.

#### DTC DETECTING CONDITION E3B2439D

Item		Detecting Condition	Possible Cause	
DTC Strategy		Calculation of engine roughness	Q	
لولیت محدود) Enable Conditions ودرو در ایران		<ul> <li>150 &lt; Mass air flow(mg/rev.) &lt; 710</li> <li>512 &lt; Engine speed(RPM) &lt; 6500</li> <li>Coolant temperature &gt; 20°C if Start temperature &lt; -7°C</li> <li>11V &lt; Battery voltage &lt; 16V</li> <li>Throttle Angle gradient is in predetermined range</li> <li>No injector shut off</li> <li>No rough road</li> </ul>	Faulty spark plugs, high-tension lead, or Ignition coil Incorrect valve timing. Uneven compression. Air leakage.	
	Threshold Value	Misfire= 12~54% within 200 rev.	Improper Fuel pressure or dirty fuel.	
Case1)	Diagnosis Time	200 revolution or 3*200 revolution.	Blocked/Leaking injectors. Leakage between cooling system and cylinder.	
	Threshold	Misfire > 1.2% within 1000 revolutions.		
Case2)	Value Diagnosis Time	1000 revolution or 4*1000 revolution.		

#### SPECIFICATION E67F6AF8

Temp.( )	Temp.( )	Ignition primary coil()	lgnition secondary coil (kΩ)
-20	-4	0.5	7.7
0	32	0.54	8.4
20	68	0.58	9.1
40	104	0.62	9.8
60	140	0.66	10.5
80	176	0.71	11.2
100	212	0.75	11.9

# WWW.DIGITALKHODRO.COM

# 021-62999292

# SCHEMATIC DIAGRAM E09BF8A7

Refer to DTC P0301.

# MONITOR DTC STATUS ED12461B

# 🔟 ΝΟΤΕ

If any codes relating to injectors, HO2S, ECT(Engine Coolant Temperature)Sensor, Throttle Position sensor or Mass Air Flow Sensor are stored, do ALL REPAIRS associated with those codes before proceeding with this troubleshooting tree.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.

To naviate to the "DTAL"menu	1.4 AMBIENT CONDITIONS
01 HYUNDAI VEHICLE DIAGNOSIS	
Select model and year	1. MIL STATUS
→02 ENGINE	2. DTC STATUS: PRESENT
Select engine	3. DTC READINESS FLAG : COMPLETE
DI DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC
	6. OP.HOUR AFTER ERASURE OF DTC
PART ERAS DTAL HELP	

B00112

5. Is parameter displayed "History(Not Present) fault"?

#### 🔟 ΝΟΤΕ

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

## YES

Fault is intermittent caused by poor contact in the sensor's and/or PCM's connector or was repaired and PCM memory was not cleared. Thoroughly check connectors for loose or poor connections, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

#### NO

Go to "Monitor Actuation Test" procedure.

# WWW.DIGITALKHODRO.COM

# 021-62999292

# FLA -268

# MONITOR ACTUATION TEST E10ABC12

# 🔟 ΝΟΤΕ

The main purpose of this test is to identify potential engine mechanical condition problems and fuel and ignition systems problems that are not common to all cylinders. For best results, perform this test while maintaining as steady an rpm reading as possible.

Caution! Before beginning tests; set the parking brake, place gear selector in P or N and block drive wheels for safety.

- 1. Warm up the engine to normal operating temperature and let it idle.
- 2. Install Scan Tool and select "INJECTOR #1" parameter on the Actuation Test mode shown in the figure.
- 3. Monitor engine rpm and shut off the injector #1 by pressing "STRT(F1)" key.
- 4. Repeat procedure on all injectors and record the engine rpm.

Specification : All cylinders should show an even RPM drop.

1		•	
NO.1 INJEC	TOR	]	
DURATION	UNTIL STOP KEY		
METHOD	DEACTIVATION		
CONDITION	IG. KEY ON ENGINE RUNNING	شرکت دیجیتال خ	
	STRTI, IF YOU ARE READY ? ST ITEM USING UP/DOWN KEY	اولىن سامانە دىج	
STRT STO	P		
			В

5. Was each cylinder's rpm drop within the same value?



Go to "Timing Inspection" procedure.



Cylinders with the least amount of RPM drop are not contributing their share of power. Go to "Spark plug cable Inspection" procedure.

# 🔟 ΝΟΤΕ

If the RPM loss between cylinders is quite large(200RPM or more) and engine has high mileage, there is possibility of engine wear. Perform compression test with pressure gauge to check the engine wear.

#### SPARK PLUG CABLE INSPECTION

- 1. Remove suspect cylinder's spark plug cable.
- 2. Visually/physically inspect the following items:
  - Damage, cracks and flashover.
- 3. Measure the resistance of the spark plug cable referring to specification.

# WWW.DIGITALKHODRO.COM

# 021-62999292

#### **FUEL SYSTEM**

FLA -269

Specification : 5.6k /m ±20%

## 🔟 ΝΟΤΕ

Resistance should not be higher than 10,000 per foot of cable. If resistance is higher than specification, replace the cable.

4. Is the displayed value within the specified value?

# YES

Go to "Spark Plug Inspection " procedure.

NO

2.

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### SPARK PLUG INSPECTION

- 1. Remove suspect cylinder's spark plugs.
  - Visually/physically inspect the following items:
    - Damaged insulation, Worn electrodes, Oil or fuel fouled, Loose terminals and cracks.
    - Check for plug gap: 1.0 1.1 mm (0.039 0.043 in.)
    - Check if the spark plug for the relevant cylinder is lighter in color than the other plugs.
- 3. Was a problem found in any of the above areas?

YES Repair as necessary and go to "Verification of Vehicle Repair" procedure.

Go to "Fuel Injector Inspection" procedure.

#### FUEL INJECTOR INSPECTION

1. Check the fuel injectors for clogging or any restrictions.

Test Condition : Ignition "OFF". Specification : No clogging and restriction.

2. Is the fuel injector OK?



NO

Visually/physically inspect the engine mechanical problem as below:

- Leaky or sticky valves or rings.
- Excessive valve deposits.
- Weak valve spring.
- Leaking head gasket.

If NG, repair as necessary and go to "Verification of Vehicle Repair" procedure. If OK, go to "Ignition Coil Inspection" procedure.

# WWW.DIGITALKHODRO.COM

## FLA -270

# NO

**FUEL SYSTEM** 

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### **IGNITION COIL INSPECTION**

- 1. Ignition "OFF".
- 2. Ignition coil connector : Disconnect.
- 3. Visually/physically inspect the following items:
  - Damage, cracks and flashover.
- 4. Measure the primary coil resistance between terminals 2 and 3.

#### SPECIFICATION :

Temp.( )	Ignition primary coil ( )
-4	0.5
32	0.54
68	0.58
104	0.62
140	0.66
176	0.71
212	0.75
-	-4 32 68 104 140 176



EBKD002H

# WWW.DIGITALKHODRO.COM

5. Is resistance within the specified value?

## YES

Go to "Timing Inspection" procedure.

# NO

Replace as necessary and go to "Verification of Vehicle Repair" procedure.

#### TIMING INSPECTION

- Set up an oscilloscope as follows : Channel A (+): terminal 2 of the CKPS, (-): ground Channel B (+): terminal 2 of the CMPS, (-): ground
- 2. Start the engine and check for signal waveform whether synchronize with camshaft sensor or not and tooth is missing refer to sample waveforms as below.



#### 3. Is the signal waveform normal?



Go to " Air Leakage Inspection " procedure.

#### NO

Remove Crankshaft Position Sensor(CKPS) and calculate air gap between sensor and flywheel/torque converter. Readjust as necessary and go to next step.

## 🔟 ΝΟΤΕ

Air gap [0.3~1.7 mm [0.012~0.067 in] = measure distance from hosing to teeth on flywheel/torque converter (measurement "A") and from mounting surface on sensor to sensor tip (measurement "B") subtract "B" from "A".

If fail to synchronize CKPS with CMPS, check that the crankshaft and camshaft are correctly aligned the matching marks of the pulleys. Repair or readjust as necessary and go to "Verification of Vehicle Repair" procedure.

# WWW.DIGITALKHODRO.COM

# 021-62999292

FLA -271

## FUEL SYSTEM

021-62999292

#### AIR LEAKAGE INSPECTION ECD6B12D

1. Visually/physically inspect the air leakage in intake/exhaust system as following items. If OK, go to next step.

If NG, repair as necessary and go to "Verification of Vehicle Repair" procedure.

- Vacuum hoses for splits, kinks and improper connections.
- Throttle body gasket.
- Gasket between intake manifold and cylinder head.
- Seals between intake manifold and fuel injectors.
- Exhaust system between HO2S and Three way catalyst for air leakage.
- Was a problem found in any of the above areas? 2.

## YES

Go to "Fuel System Inspection" procedure.

#### NO

Repair air leakage and go to "Verification of Vehicle Repair" procedure.

#### FUEL SYSTEM INSPECTION E3A73F3E

- Check the fuel for excessive water, alcohol, or other contaminants. Replace contaminated fuel as necessary. 1.
- Install a fuel pressure gage. 2.
- 3. Start engine and let it idle. Inspect fuel pressure with vacuum hose disconnected

Test Condition : Ignition "ON" & Engine "ON" at Idle. Specification : 250~350kPa(2.50~3.50 kg/cm, 36~50 psi)

Is fuel pressure within the specified value? 4.

#### YES

Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

# NO

Repair as necessary refer to inspection noted as below and go to "Verification of Vehicle Repair" procedure.

# NOTE

- Check if fuel line pressure decreases when accelerating quickly.
  - If it does, check fuel pump maximum pressure. If pressure is OK, check fuel line and filter for clogging.
- В. If fuel pressure is lower than specification : Check for fuel line pressure while pinching fuel return hose.
  - If pressure quickly increases, check pressure regulator.
  - If pressure gradually increases, check for clogging between fuel pump and pressure regulator. If hose is not clogged, check fuel pump maximum pressure.
- C. If fuel pressure is higher than specification : Is fuel line clogged?
  - If it is not, replace pressure regulator.
  - If it is, replace it.

# WWW.DIGITALKHODRO.COM

# VERIFICATION OF VEHICLE REPAIR EBB88DCB

Refer to DTC P0301.



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

FLA -273

**FUEL SYSTEM** 

# DTC P0304 CYLINDER 4-MISFIRE DETECTED

#### COMPONENT LOCATION ED3CDAB1

Refer to DTC P0301.

#### GENERAL DESCRIPTION EAGE88B0

Refer to DTC P0301.

#### DTC DESCRIPTION E5EE3D35

The PCM must monitor the engine for misfiring possibly caused by ignition coil defects or injector fails. If misfiring is detected, the PCM will identify the cylinder(s) that has(have) misfired and then calculate misfiring rate for a given duration. The DTC for Misfire (P0301 to 0304) is set as soon as the misfiring rate exceeds the limit which may result in damage to the catalyst or increase emissions. The PCM stores the individual DTC for a cylinder which has more than a 10% total misfire rate.

#### DTC DETECTING CONDITION EA65034D

	ltem	Detecting Condition	Possible Cause
DTC Strategy		Calculation of engine roughness	Q
	Conditions	<ul> <li>150 &lt; Mass air flow(mg/rev.) &lt; 710</li> <li>512 &lt; Engine speed(RPM) &lt; 6500</li> <li>Coolant temperature &gt; 20°C if Start temperature &lt; -7°C</li> <li>11V &lt; Battery voltage &lt; 16V</li> <li>Throttle Angle gradient is in predetermined range</li> <li>No injector shut off</li> <li>No rough road</li> </ul>	Faulty spark plugs, high-tension lead, or Ignition coil. Incorrect valve timing. Uneven compression. Air leakage.
	Threshold Value	Misfire= 12~54% within 200 rev.	Improper Fuel pressure or dirty fuel.
Case1)	Diagnosis Time	200 revolution or 3*200 revolution.	Blocked/Leaking injectors. Leakage between cooling system and cylinder.
	Threshold	Misfire > 1.2% within 1000 revolutions.	system and cylinder.
Case2)	Value Diagnosis Time	1000 revolution or 4*1000 revolution.	

#### SPECIFICATION E8CFF0D2

Ignition secondary Temp.() Temp.() Ignition primary coil () coil (kΩ) 7.7 -20 -4 0.5 0 32 0.54 8.4 0.58 20 68 9.1 40 104 0.62 9.8 140 0.66 10.5 60 0.71 80 176 11.2 212 0.75 100 11.9

# WWW.DIGITALKHODRO.COM

# DTC TROUBLESHOOTING PROCEDURES

# SCHEMATIC DIAGRAM EBEB2F51

Refer to DTC P0301.

# MONITOR DTC STATUS EE8BE6D6

# 🔟 ΝΟΤΕ

If any codes relating to injectors, HO2S, ECT(Engine Coolant Temperature)Sensor, Throttle Position sensor or Mass Air Flow Sensor are stored, do ALL REPAIRS associated with those codes before proceeding with this troubleshooting tree.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.

To naviate to the "DTAL"menu	1.4 AMBIENT CONDITIONS
01 HYUNDAI VEHICLE DIAGNOSIS	
Select model and year	1. MIL STATUS
→02 ENGINE	2. DTC STATUS: PRESENT
Select engine	3. DTC READINESS FLAG : COMPLETE
DI DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC
	6. OP.HOUR AFTER ERASURE OF DTC
PART ERAS DTAL HELP	

B00112

5. Is parameter displayed "History(Not Present) fault"?

#### 🔟 ΝΟΤΕ

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

## YES

Fault is intermittent caused by poor contact in the sensor's and/or PCM's connector or was repaired and PCM memory was not cleared. Thoroughly check connectors for loose or poor connections, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

#### NO

Go to "Monitor Actuation Test" procedure.

# WWW.DIGITALKHODRO.COM

#### MONITOR ACTUATION TEST E3E04CED

# 🔟 ΝΟΤΕ

The main purpose of this test is to identify potential engine mechanical condition problems and fuel and ignition systems problems that are not common to all cylinders. For best results, perform this test while maintaining as steady an rpm reading as possible.

Caution! Before beginning tests; set the parking brake, place gear selector in P or N and block drive wheels for safety.

- 1. Warm up the engine to normal operating temperature and let it idle.
- 2. Install Scan Tool and select "INJECTOR #1" parameter on the Actuation Test mode shown in the figure.
- 3. Monitor engine rpm and shut off the injector #1 by pressing "STRT(F1)" key.
- 4. Repeat procedure on all injectors and record the engine rpm.

Specification : All cylinders should show an even RPM drop.

	To naviate to the "DTAL"menu	1.4 AMBIENT CONDITIONS
	01 HYUNDAI VEHICLE DIAGNOSIS	
	Select model and year	1. MIL STATUS
	→ 02 ENGINE	2. DTC STATUS: <u>PRESENT</u>
	Select engine	3. DTC READINESS FLAG : COMPLETE
1	→ 01 DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1
حدود	Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC
بران		6. OP.HOUR AFTER ERASURE OF DTC

B00112

5. Was each cylinder's rpm drop within the same value?

#### YES

Go to "Timing Inspection" procedure.

#### NO

Cylinders with the least amount of RPM drop are not contributing their share of power. Go to "Spark plug cable Inspection" procedure.

## 🔟 ΝΟΤΕ

If the RPM loss between cylinders is quite large(200RPM or more) and engine has high mileage, there is possibility of engine wear. Perform compression test with pressure gauge to check the engine wear.

#### SPARK PLUG CABLE INSPECTION

- 1. Remove suspect cylinder's spark plug cable.
- 2. Visually/physically inspect the following items:
  - Damage, cracks and flashover.
- 3. Measure the resistance of the spark plug cable referring to specification.

# WWW.DIGITALKHODRO.COM

# 021-62999292

#### **FUEL SYSTEM**

FLA -277

Specification : 5.6k /m ±20%

## 🔟 ΝΟΤΕ

Resistance should not be higher than 10,000 per foot of cable. If resistance is higher than specification, replace the cable.

4. Is the displayed value within the specified value?

# YES

Go to "Spark Plug Inspection " procedure.

NO

2.

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### SPARK PLUG INSPECTION

- 1. Remove suspect cylinder's spark plugs.
  - Visually/physically inspect the following items:
    - Damaged insulation, Worn electrodes, Oil or fuel fouled, Loose terminals and cracks.
    - Check for plug gap: 1.0 1.1 mm (0.039 0.043 in.)
    - Check if the spark plug for the relevant cylinder is lighter in color than the other plugs.
- 3. Was a problem found in any of the above areas?

YES Repair as necessary and go to "Verification of Vehicle Repair" procedure.

Go to "Fuel Injector Inspection" procedure.

#### FUEL INJECTOR INSPECTION

1. Check the fuel injectors for clogging or any restrictions.

Test Condition : Ignition "OFF". Specification : No clogging and restriction.

2. Is the fuel injector OK?



NO

Visually/physically inspect the engine mechanical problem as below:

- Leaky or sticky valves or rings.
- Excessive valve deposits.
- Weak valve spring.
- Leaking head gasket.

If NG, repair as necessary and go to "Verification of Vehicle Repair" procedure. If OK, go to "Ignition Coil Inspection" procedure.

# WWW.DIGITALKHODRO.COM

## FLA -278

#### NO

FUEL SYSTEM

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### **IGNITION COIL INSPECTION**

- 1. Ignition "OFF".
- 2. Ignition coil connector : Disconnect.
- 3. Visually/physically inspect the following items:
  - Damage, cracks and flashover.
- 4. Measure the primary coil resistance between terminals 1 and 3.

#### **SPECIFICATION** :

Temp.( )	Temp.( )	Ignition primary coil ( )
-20	-4	0.5
0	32	0.54
20	68	0.58
40	104	0.62
60	140	0.66
80	176	0.71
100	212	0.75



EBKD002H

# WWW.DIGITALKHODRO.COM

5. Is resistance within the specified value?

## YES

Go to "Timing Inspection" procedure.

# NO

Replace as necessary and go to "Verification of Vehicle Repair" procedure.

#### TIMING INSPECTION

- Set up an oscilloscope as follows : Channel A (+): terminal 2 of the CKPS, (-): ground Channel B (+): terminal 2 of the CMPS, (-): ground
- 2. Start the engine and check for signal waveform whether synchronize with camshaft sensor or not and tooth is missing refer to sample waveforms as below.



#### 3. Is the signal waveform normal?

# YES



## NO

Remove Crankshaft Position Sensor(CKPS) and calculate air gap between sensor and flywheel/torque converter. Readjust as necessary and go to next step.

## 🔟 ΝΟΤΕ

Air gap [0.3~1.7 mm [0.012~0.067 in] = measure distance from hosing to teeth on flywheel/torque converter (measurement "A") and from mounting surface on sensor to sensor tip (measurement "B") subtract "B" from "A".

If fail to synchronize CKPS with CMPS, check that the crankshaft and camshaft are correctly aligned the matching marks of the pulleys. Repair or readjust as necessary and go to "Verification of Vehicle Repair" procedure.

# WWW.DIGITALKHODRO.COM

021-62999292

#### FUEL SYSTEM

#### AIR LEAKAGE INSPECTION ED276A7F

1. Visually/physically inspect the air leakage in intake/exhaust system as following items. If OK, go to next step.

If NG, repair as necessary and go to "Verification of Vehicle Repair" procedure.

- Vacuum hoses for splits, kinks and improper connections.
- Throttle body gasket.
- Gasket between intake manifold and cylinder head.
- Seals between intake manifold and fuel injectors.
- Exhaust system between HO2S and Three way catalyst for air leakage.
- 2. Was a problem found in any of the above areas?

#### YES

Go to "Fuel System Inspection" procedure.

#### NO

Repair air leakage and go to "Verification of Vehicle Repair" procedure.

#### FUEL SYSTEM INSPECTION E0509F7F

- 1. Check the fuel for excessive water, alcohol, or other contaminants. Replace contaminated fuel as necessary.
- 2. Install a fuel pressure gage.
- شرکت دیجیتال خودرو سامانه (مسئولیت محدود)
- Start engine and let it idle. Inspect fuel pressure with vacuum hose disconnected.

Test Condition : Ignition "ON" & Engine "ON" at Idle.Specification : 250~350kPa(2.50~3.50 kg/cm², 36~50 psi)

4. Is fuel pressure within the specified value?

#### YES

Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### NO

Repair as necessary refer to inspection noted as below and go to "Verification of Vehicle Repair" procedure.

# 🔟 ΝΟΤΕ

- A. Check if fuel line pressure decreases when accelerating quickly.
  - If it does, check fuel pump maximum pressure. If pressure is OK, check fuel line and filter for clogging.
- B. If fuel pressure is lower than specification : Check for fuel line pressure while pinching fuel return hose.
  - If pressure quickly increases, check pressure regulator.
  - If pressure gradually increases, check for clogging between fuel pump and pressure regulator. If hose is not clogged, check fuel pump maximum pressure.
- C. If fuel pressure is higher than specification : Is fuel line clogged?
  - If it is not, replace pressure regulator.
  - If it is, replace it.

# WWW.DIGITALKHODRO.COM

# VERIFICATION OF VEHICLE REPAIR E5D14D8C

Refer to DTC P0301.



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



FLA -281

# FUEL SYSTEM

# DTC P0315 SEGMENT TIME ACQUISITION INCORRECT

# COMPONENT LOCATION E7BA5ACC



EGQE501B

#### GENERAL DESCRIPTION E24A0848

A Misfire induces a decrease in the engine speed and causes a variation in the segment period. Therefore, misfiring detection is based on the observation of this variation of the segment period.

# DTC DESCRIPTION E40AA6CD

Because of the tolerance in mechanical machining and assembling process of the target wheel, the duration of each segment are not always same but differ from segment to segment on the same engine. And this irregular segment duration can disturb misfiring detection which is based on the difference of engine rotational speed between the firing and the misfiring cylinder. The PCM compares segment duration of 4 cylinders during fuel cut-off and deceleration period. With this comparison PCM perform segment adaptation to adapt the difference of each segment duration. The PCM sets DTC P0315 if any of segment adaptation value is on the limit.

#### DTC DETECTING CONDITION EAE48C52

ltem	Detecting Condition	Possible Cause
DTC Strategy	Monitor segment time adaptation	
Enable Conditions	Engine speed is between 2000 and 3000 rpm after finishing segment time adaptation No relevant failure	Improperly installed target wheel Contact resistance in
Threshold Value	Segment adaptation value = 5/1000	connectors
Diagnostic Time		

# MONITOR DTC STATUS E5A8BA61

# **NOTE**

If any codes relating to CKPs are stored, do ALL REPAIRS associated with those codes before proceeding with troubleshooting.

1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.

# WWW.DIGITALKHODRO.COM

# WWW.DIGITALKHODRO.COM

# DTC TROUBLESHOOTING PROCEDURES

FLA -283

- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.



5. Is parameter displayed "History(Not Present) fault"?

#### 🚺 ΝΟΤΕ

History (Not Present) fault : DTC occurred but has been cleared.
 Present fault : DTC is occurring at present time.

# اولین سامانه دیجیتال تعمیرکاران خودرو د YES

Fault is intermittent caused by poor contact in the sensor's and/or the PCM's connector, which was repaired but PCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

## NO

Go to "Component Inspection" procedure.

#### COMPONENT INSPECTION EOB87FED

- Set up an oscilloscope as follows : Channel A (+): terminal 2 of the CKPS, (-): ground Channel B (+): terminal 2 of the CMPS, (-): ground
- 2. Start the engine and check for signal waveform whether synchronize with camshaft sensor or not and tooth is missing refer to sample waveforms as below.

# WWW.DIGITALKHODRO.COM

# 021-62999292

FLA -284

#### **FUEL SYSTEM**



#### 3. Is the signal waveform normal?

# YES Go to " Verification of Vehicle Repair " procedure. NO Remove Crankshaft Position Sensor(CKPS) and calculate air gap between sensor and flywheel/torque converter. Readjust as necessary and go to next step.

#### **NOTE**

Air gap [0.3~1.7 mm [0.012~0.067 in] = measure distance from hosing to teeth on flywheel/torque converter (measurement "A") and from mounting surface on sensor to sensor tip (measurement "B") subtract "B" from "A".

If fail to synchronize CKPS with CMPS, check that the crankshaft and camshaft are correctly aligned the matching marks of the pulleys. Repair or readjust as necessary and go to "Verification of Vehicle Repair" procedure.

## VERIFICATION OF VEHICLE REPAIR EDBDCGEE

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 3. Read "DTC Status" parameter.
- 4. Is parameter displayed "History(Not Present) fault"?



System performing to specification at this time. Clear the DTC.

NO

Go to the applicable troubleshooting procedure.

# WWW.DIGITALKHODRO.COM

#### **KNOCK SENSOR 1 CIRCUIT DTC P0325**

#### COMPONENT LOCATION EAC383BC

Knock Sensor

EGQE601C

#### **GENERAL DESCRIPTION**

The knock sensor is attached to the cylinder block and senses engine knocking. The sensor contains a piezoelectric element that converts vibration (or noise) into voltage signal and sends this signal to PCM. With input signals from camshaft position and crankshaft position sensor, PCM can identify which cylinder is knocking. PCM filters vibrations and determines if the vibrations are knocking signal. The Engine Control Module (PCM) uses this signal to suppress knocking by retarding ignition timing. The PCM will set a code (Malfunction Indicator Lamp will Not turn on) if during two driving cycles the Knock sensor's output voltage falls below minimum threshold. This code indicates an unexpected vibration is being read by the Knock sensor or PCM under normal engine operation.

#### DTC DESCRIPTION EA7768CE

The PCM monitors the range of the analog input signal from knock sensor to check sensor failure that is short circuit or open circuit. If the difference between knock signal and noise level is smaller than the threshold during defined time period, the DTC P0325 is set. In case the noise level is higher than the upper threshold or lower than the lower threshold, the DTC P0325 is set too.

#### DTC DETECTING CONDITION ED7CCDC7

ltem	Detecting Condition	Possible Cause
DTC Strategy	Voltage Range Check	
Enable Conditions	Engine speed > 2700 rpm Engine load > 440mg/rev. No relevant failure	Open/short in signal or ground circuit Contact resistance in
Threshold Value	Difference between sensor signal and noise level < 0.06V	connectors Faulty knock sensor
Diagnostic Time	10 seconds	



FLA -285

# FUEL SYSTEM

# SCHEMATIC DIAGRAM E9BAD45A



#### **NOTE**

If any codes relating to TPS or MAFS are stored, do ALL REPAIRS associated with those codes before proceeding with further troubleshooting.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.



B00112

5. Is parameter displayed "History(Not Present) fault"?

# WWW.DIGITALKHODRO.COM

FLA -287

## 🚺 ΝΟΤΕ

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

# YES

Fault is intermittent caused by poor contact in the sensor's and/or the PCM's connector, which was repaired but PCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

#### NO

Go to "W/Harness Inspection" procedure.

#### TERMINAL AND CONNECTOR INSPECTION E2FB0FEE

- 1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### NO

YES

Go to "Ground Circuit Inspection" procedure.

#### GROUND CIRCUIT INSPECTION E4D2AD7D

- 1. Ignition "OFF".
- 2. Disconnect Knock sensor and PCM connectors.
- 3. Measure resistance between terminals 2 of the sensor harness connector and 54 of the PCM harness connector.

Specification : Approx. 0

4. Is resistance within the specification?

YES

Go to "Signal Circuit Inspection" procedure.

NO

Check for an open in the ground circuit. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

# WWW.DIGITALKHODRO.COM

**FUEL SYSTEM** 

#### SIGNAL CIRCUIT INSPECTION EA2D9CE1

- 1. Check for open in signal harness.
  - 1) Measure resistance between terminals 1 of sensor harness connector and 10 of the PCM harness connector.

Specification : Approx. 0

2) Is resistance within the specification?



Go to next step as below.



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

- 2. Check for short to ground in signal harness.
  - 1) Measure resistance between terminal 1 of sensor harness connector and chassis ground.

Specification : Infinite	0
2) Is resistance within the specification?	
شرکت دیجیتال خودرو سامانه (مسئولیت محدود)	
Go to next step as below.	
اولین سامانه دیجیتال تعمیرکاران خودر <sub>NO</sub> را ن	

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

- 3. Check for short to power in signal harness
  - 1) Ignition "ON" & Engine "OFF".
  - 2) Measure voltage between terminals 1 of sensor harness connector and chassis ground.

Specification : Approx. 0V

3) Is voltage within the specification?



Go to "Component Inspection" procedure.

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

## COMPONENT INSPECTION E55AB1F0

- 1. Component resistance inspection.
  - 1) Ignition Off.

# WWW.DIGITALKHODRO.COM
## WWW.DIGITALKHODRO.COM

## DTC TROUBLESHOOTING PROCEDURES

- 2) Disconnect knock sensor connector.
- 3) Measure resistance between terminals 1 and 2 of the sensor connector(Component side).

Specification : Approx.  $5M\Omega$  at 20 (68 )

- 2. Output signal inspection.
  - 1) Remove knock sensor from vehicle and secure (across mounting boss) in a shop vise.
  - Set up an oscilloscope as follows : Channel A (+): terminal 1 (-): terminal 2.
  - Rap on vise with a ball peen hammer while monitoring oscilloscope screen (there should be a spike of less than 1 volt with each hammer strike).

Specification : knock sensor send a voltage spike with hammer strikes.

- 3. Installation torque inspection.
  - 1) Check the installation torque of the knock sensor.

Specification : Approx. 16 ~ 28N·m(160~250 kg·cm,11.8~18.4 lb·ft)

### 4. Has a problem been found?



Check knock sensor for contamination, deterioration, or damage. Substitute with a known-good sensor and check for proper operation. If the problem is corrected, replace sensor and then go to "Verification of Vehicle Repair" procedure.

#### NO

Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### VERIFICATION OF VEHICLE REPAIR E0E0E895

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 3. Read "DTC Status" parameter.
- 4. Is parameter displayed "History(Not Present) fault"?



System performing to specification at this time. Clear the DTC.

NO

Go to the applicable troubleshooting procedure.

FUEL SYSTEM

## DTC P0335 CRANKSHAFT POSITION SENSOR A CIRCUIT

## COMPONENT LOCATION ECB4ECFD



EGQE501B

#### GENERAL DESCRIPTION EF4CBB9F

The Crankshaft Position Sensor (CKPS) is a hall effect type sensor that generates voltage using a sensor and a target wheel mounted on the crankshaft; there are 58 slots in the target wheel where one is longer than the others. When the slot in the wheel aligns with the sensor, the sensor voltage outputs low. When the metal (tooth) in the wheel aligns with the sensor, the sensor voltage outputs low. When the metal (tooth) in the wheel aligns with the sensor, the sensor voltage outputs low. The provide the sensor voltage outputs high. During one crankshaft rotation there are 58 rectangular signals and one longer signal. The PCM calculates engine RPM by using the sensor's signal and controls the injection duration and the ignition timing. Using the signal differences caused by the longer slot, the PCM identifies which cylinder is at top dead center.

DTC DESCRIPTION ECA7503F COLUMN COLUMN

The PCM sets DTC P0335 when the number of crankshaft teeth during one revolution is incorrect or crankshaft signal is missing while camshaft signal is detected.

#### DTC DETECTING CONDITION EFBFAEA3

Т	EM	DETECTING CONDITION	POSSIBLE CAUSE
DTC S	Strategy	Check Crankshaft Signal Switching	
Enable (	le Conditions Camshaft position sensor signal is valid 6V < Battery voltage < 16V		Open or short in signal, ground
Case 1	Threshold Value	No Crankshaft Teeth detected after 4 Camshaft signal transitions Crankshaft teeth detected but synchronization is not successful	or power supply circuit Contact resistance in connectors Damage to the connecting
	Diagnosis Time	2 revolutions	flange/flywheel Misadjust crankshaft and camshaft pulley position
Case2	Threshold Value	Number of Crankshaft Teeth is not correct	Faulty CKP sensor
Casez	Diagnosis Time	2.5 revolutions	

## SCHEMATIC DIAGRAM E20B45A2



#### MONITOR DTC STATUS E3A960BE

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions
- 4. Read "DTC Status" parameter.

## WWW.DIGITALKHODRO.COM

**FUEL SYSTEM** 

	1.4 AMBIENT CONDITIONS
To naviate to the "DTAL"menu	
01 HYUNDAI VEHICLE DIAGNOSIS	
Select model and year	1. MIL STATUS
→ 02 ENGINE	2. DTC STATUS: <u>PRESENT</u>
Select engine	3. DTC READINESS FLAG : COMPLETE
<b>01</b> DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC
PART ERAS DTAL HELP	6. OP.HOUR AFTER ERASURE OF DTC

B00112

5. Is parameter displayed "History(Not Present) fault"?

#### 🔟 ΝΟΤΕ

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.



NO

Fault is intermittent caused by poor contact in the sensor's and/or the PCM's connector, which was repaired but PCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

Go to next step as below.

#### TERMINAL AND CONNECTOR INSPECTION EAFCDE34

- 1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Power Supply Circuit Inspection" procedure.

#### POWER SUPPLY CIRCUIT INSPECTION ECBEFC43

1. Ignition "OFF".

- 2. Disconnect CKP sensor connector.
- 3. Ignition "ON" & Engine "OFF".
- 4. Measure voltage between terminal 1 of the sensor harness connector and chassis ground.

Specification : Approx. B+

5. Is voltage within the specification?

## YES

Go to "Ground Circuit Inspection" procedure.

## NO

Check for a open in the power supply circuit between the main relay and the CKPS. Especially check for open or blown 10A sensor fuse. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

## GROUND CIRCUIT INSPECTION EF38CBC7

1. Ignition "OFF",

2. Measure resistance between terminal 3 of the sensor harness connector and chassis ground.

Specification : Approx.

3. Is resistance within the specification?

Go to "Signal Circuit Inspection" procedure.

0

#### NO

YES

Check for an open or short to battery in the ground circuit. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### SIGNAL CIRCUIT INSPECTION ED25A9DF

1. Check for open in signal harness.

- 1) Disconnect PCM connector.
- 2) Measure resistance between terminals 2 of sensor harness connector and 29 of the PCM harness connector.

Specification : Approx. 0

3) Is resistance within the specification?

YES

Go to next step as below.



**FUEL SYSTEM** 

#### FLA -294

## NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

- 2. Check for short to ground in signal harness.
  - 1) Measure resistance between terminal 2 of sensor harness connector and chassis ground.

Specification : Infinite

2) Is resistance within the specification?



Go to next step as below.

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

- 3. Check for short to power in signal harness.
  - 1) Ignition "ON" & Engine "OFF".
  - 2) Measure voltage between terminal 2 of the sensor harness connector and chassis ground.

Specification : Approx. 0V

Is voltage within the specification?

Go to "Component Inspection" procedure.

NO

YES

3)

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### COMPONENT INSPECTION E8E2BEDA

- 1. Reconnect the CKPS and PCM connectors.
- Set up an oscilloscope as follows : Channel A (+): terminal 2 of the CKPS, (-): ground Channel B (+): terminal 2 of the CMPS, (-): ground
- 3. Start the engine and check for signal waveform whether synchronize with camshaft sensor or not and tooth is missing.

## DTC TROUBLESHOOTING PROCEDURES



#### 4. Is the signal waveform normal?

#### YES

Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### NO

Remove CKP and calculate air gap between sensor and flywheel/torque converter. Readjust as necessary and go to next step.

#### **NOTE**

Air gap [0.3~1.8 mm [0.012~0.067 in] = measure distance from hosing to teeth on flywheel/torque converter (measurement "A") and from mounting surface on sensor to sensor tip (measurement "B") subtract "B" from "A".

If fail to synchronize with CMP sensor, readjust timing system and go to next step.

Check CKPS for contamination, deterioration, or damage. Substitute with a known-good CKPS and check for proper operation. If the problem is corrected, replace CKPS and then go to "Verification of Vehicle Repair" procedure.

## 021-62999292

#### FLA -296

#### **FUEL SYSTEM**

#### VERIFICATION OF VEHICLE REPAIR EBA55DDA

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 3. Read "DTC Status" parameter.
- 4. Is parameter displayed "History(Not Present) fault"?

#### YES

System performing to specification at this time. Clear the DTC.

#### NO

Go to the applicable troubleshooting procedure.





## DTC TROUBLESHOOTING PROCEDURES

# DTC P0340 CAMSHAFT POSITION SENSOR A CIRCUIT MALFUNCTION(SINGLE SENSOR)

### COMPONENT LOCATION E0F8FCC0



EGQE590A

#### GENERAL DESCRIPTION EA8946BA

The Camshaft Position Sensor (CMPS) is a sensor that detects the compression TDC of the NO. 1 cylinder. The CMPS consists of a hall type sensor and a target on the end of the intake camshaft. When the target triggers the sensor, the sensor voltage is 5V. If not, the sensor voltage is 0V. These CMPS signal is sent to the PCM and the PCM uses the CMPS signal for synchronizing the firing of sequential fuel injectors.

DTC DESCRIPTION EACC3BFD and Linear a dilaton and

The PCM monitors the camshaft sensor signal transition position which must change only once per crankshaft revolution. If no camshaft signal is detected while crankshaft signal is detected, the PCM sets DTC P0340.

#### DTC DETECTING CONDITION EDADDD60

ITEM	DETECTING CONDITION	POSSIBLE CAUSE
DTC Strategy	Check camshaft signal switching	
Enable Conditions	No crankshaft position sensor signal error 6V < Battery voltage < 16V	Open or short in signal, ground or power supply circuit. Contact resistance in
Threshold Value	No signal switching Rising/falling camshaft edge not within defined window : -5 ~ +5 teeth	connectors. Misadjust crankshaft and camshaft pulley position. Faulty CMP sensor.
Diagnostic Time	40 revolutions	

## FUEL SYSTEM

## SCHEMATIC DIAGRAM EBF3B36A



#### MONITOR DTC STATUS E3AACFE6

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.

## WWW.DIGITALKHODRO.COM

FLA -299

B00112

	1.4 AMBIENT CONDITIONS
To naviate to the "DTAL"menu	
<b>01</b> HYUNDAI VEHICLE DIAGNOSIS	
Select model and year	1. MIL STATUS
→ 02 ENGINE	2. DTC STATUS: <u>PRESENT</u>
Select engine	3. DTC READINESS FLAG : <u>COMPLETE</u>
<b>01</b> DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC
PART ERAS DTAL HELP	6. OP.HOUR AFTER ERASURE OF DTC

5. Is parameter displayed "History(Not Present) fault"?

#### 🔟 ΝΟΤΕ

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

YES

Fault is intermittent caused by poor contact in the sensor's and/or PCM's connector or was repaired and PCM memory was not cleared. Thoroughly check connectors for loose or poor connections, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

## اولین سامانه دیجیتال تعمیرکاران خودرو د<mark>ر ۵</mark>۷

Go to next step as below.

#### TERMINAL AND CONNECTOR INSPECTION E81B9580

- 1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Power Supply Circuit Inspection" procedure.

#### POWER SUPPLY CIRCUIT INSPECTION E07B9CF8

- 1. Ignition "OFF".
- 2. Disconnect CMP sensor connector.

## WWW.DIGITALKHODRO.COM

## 021-62999292

#### FLA -300

FUEL SYSTEM

3. Ignition "ON" & Engine "OFF".

4. Measure voltage between terminal 1 of the sensor harness connector and chassis ground.

Specification : Approx. B+

5. Is voltage within the specification?



Go to "Ground Circuit Inspection" procedure.



Check for a open in the power supply circuit between the main relay and the CMPS. Especially check for open or blown 10A sensor fuse. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### GROUND CIRCUIT INSPECTION EED5EA9C

- 1. Ignition "OFF".
- 2. Measure resistance between terminal 3 of the sensor harness connector and chassis ground.

Specification : Approx. 0

3. Is resistance within the specification?



Check for an open or short to battery in the ground circuit. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### SIGNAL CIRCUIT INSPECTION E189AFOC

- 1. Check for open in signal harness.
  - 1) Disconnect PCM connector.
  - 2) Measure resistance between terminals 2 of sensor harness connector and 72 of the PCM connector.

Specification : Approx. 0

3) Is resistance within the specification?

YES

Go to next step as below.

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

## WWW.DIGITALKHODRO.COM

## DTC TROUBLESHOOTING PROCEDURES

- 2. Check for short to ground in signal harness.
  - 1) Measure resistance between terminal 2 of the sensor harness connector and chassis ground.

```
Specification : Infinite
```

2) Is resistance within the specification?



Go to next step as below.

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

- 3. Check for short to battery in signal harness.
  - 1) Ignition "ON" & Engine "OFF".
  - 2) Measure voltage between terminal 2 of the sensor harness connector and chassis ground.

Specification : Approx. 0V	
3) Is voltage within the specification?	
Go to "Component Inspection" procedure.	
اولین سامانه دیجیتال تعمیرکاران خودر <mark>ر NO</mark> یران	

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### COMPONENT INSPECTION E6F9EDAE

- 1. Reconnect the CMPS and PCM connectors.
- Set up an oscilloscope as follows : Channel A (+): terminal 2 of the CKPS, (-): ground Channel B (+): terminal 2 of the CMPS, (-): ground
- 3. Start the engine and check for signal waveform whether synchronize with CKPS or not and tooth is missing.

## WWW.DIGITALKHODRO.COM

## 021-62999292

#### FLA -302

#### FUEL SYSTEM



#### D03332

#### 4. Is the signal waveform normal?

#### YES

Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### NO

Remove CMP and calculate air gap[1.8mm(0.07in)]. Readjust and repair as necessary and go to "Verification of Vehicle Repair" procedure. If OK, check CMPS for contamination, deterioration, or damage. Substitute with a known-good CMPS and check for proper operation. If the problem is corrected, replace CMPS and then go to "Verification of Vehicle Repair" procedure.

#### VERIFICATION OF VEHICLE REPAIR EBFEC3B8

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 3. Read "DTC Status" parameter.
- 4. Is parameter displayed "History(Not Present) fault"?

#### YES

System performing to specification at this time. Clear the DTC.



Go to the applicable troubleshooting procedure.

FLA -303

## DTC P0420 CATALYST SYSTEM EFFICIENCY BELOW THRESHOLD (BANK 1)

#### COMPONENT LOCATION EF62DCEF



EGQE501A

#### GENERAL DESCRIPTION EC9DFBFF

The PCM uses dual oxygen sensors to monitor the efficiency of the manifold catalytic converter (warm-up catalytic converter). By monitoring the oxygen storage capacity of a catalyst, its efficiency can be indirectly calculated. The upstream (front) HO2S is used to detect the amount of oxygen in the exhaust gas before it enters the catalytic converter. A low voltage indicates high oxygen contents (lean air mixture). A high voltage indicates low oxygen contents (rich air mixture). When the catalyst efficiency drops, no chemical reaction takes place. This means the concentration of oxygen will be the same at the rear as it is at the front. The output voltage of the rear HO2S copies the voltage of the front HO2S. To monitor the system, the lean-to-rich switches of the front HO2S to the rear HO2S is counted. The ratio of rear switches to front switches is used to determine whether the catalyst is operating properly. An effective catalyst will have fewer rear switches than front switches, that is, a ratio closer to zero.

#### DTC DESCRIPTION EFAECF9C

The PCM calculates oscillation size of rear HO2S signal which represents catalyst conversion properties. This oscillation size will determine if catalyst conversion is low due to aging or poisoning from leaded fuel or misfiring. The PCM sets P0420 if the average of calculated oscillation size of rear HO2S signal during predetermined duration is higher than the predetermined threshold.

#### **FUEL SYSTEM**

#### DTC DETECTING CONDITION ECF4A694

ITEM	DETECTING CONDITION	POSSIBLE CAUSE
DTC Strategy	Comparison of the signal ratio of upstream and downstream O2 sensor in a load and speed range.	
Enable Conditions	Coolant temperature > 74 (165 ) 400 (752 ) Catalyst temp. model 900 (1652 ) 5km/h(3MPH) < Vehicle speed < 180km/h(112MPH) 200 < Mass air flow(mg/rev.) < 700 Engine speed < 3400rpm 11V < Battery voltage < 16 Lambda regulation active Canister purge valve not in CLOSE state Catalyst purge after fuel cut-off finished No relevant failure	Exhaust gas leaks Faulty rear HO2S Faulty three way catalyst converter
Threshold Value	Averaged malfunction index > threshold value	
Diagnostic Time	110 lambda controller cycles	

#### MONITOR DTC STATUS E1EE93AA

#### **NOTE**

If any codes relating to injectors, HO2S, ECT(Engine Coolant Temperature)Sensor, Throttle Position sensor or Mass Air Flow Sensor are stored, do ALL REPAIRS associated with those codes before proceeding with this troubleshooting tree.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.

	1.4 AMBIENT CONDITIONS
To naviate to the "DTAL"menu	
<b>01</b> HYUNDAI VEHICLE DIAGNOSIS	
Select model and year	1. MIL STATUS
└→02 ENGINE	2. DTC STATUS: <u>PRESENT</u>
Select engine	3. DTC READINESS FLAG : <u>COMPLETE</u>
DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC
PART ERAS DTAL HELP	6. OP.HOUR AFTER ERASURE OF DTC

B00112

5. Is parameter displayed "History(Not Present) fault"?

## WWW.DIGITALKHODRO.COM

#### FLA -305

#### 🔟 ΝΟΤΕ

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

### YES

Fault is intermittent caused by poor contact in the sensor's and/or PCM's connector or was repaired and PCM memory was not cleared. Thoroughly check connectors for loose or poor connections, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

#### NO

Go to "Exhaust System Inspection" procedure.

#### EXHAUST SYSTEM INSPECTION E5ABBA1F

- 1. Visually/physically inspect the following conditions :
  - Exhaust system between HO2S and Three way catalyst for air leakage.
  - Damage, and for loose or missing hardware:
- 2. Was a problem found in any of the above areas?



#### **REAR HO2S INSPECTION**

- 1. Visually/physically inspect the rear HO2S for the following conditions:
  - Ensure that the HO2S is securely installed.(Pigtail and wiring harness not making contact with the exhaust pipe)
  - Check for corrosion on terminals.
  - Check for terminal tension. (at the HO2S and at the PCM)
  - Any road damage.
- 2. Was a problem found in any of the above areas?

#### YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure.



Go to "TWC Inspection " procedure.

#### TWC INSPECTION

- 1. Visually/physically inspect the three-way catalyst(TWC) converter for the following damage:
  - Severe discoloration caused by excessive temperature.
  - Dents and holes.
  - Internal rattle caused by a damaged catalyst.
- 2. Also, ensure that the TWC is a proper original equipment manufacturer part.

## WWW.DIGITALKHODRO.COM

## 021-62999292

### FLA -306

FUEL SYSTEM

3. Was a problem found?



Replace TWC and go to "Verification of Vehicle Repair" procedure.



Check for poor connection between ECM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification Vehicle Repair" procedure.

#### VERIFICATION OF VEHICLE REPAIR E01BE384

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 3. Read "DTC Status" parameter.
- 4. Is parameter displayed "History(Not Present) fault"?





FLA -307

## DTC P0444 EVAP. EMISSION SYSTEM-PURGE CTRL. VALVE CIRCUIT OPEN

#### COMPONENT LOCATION EFOC4FAD



EGQE502E

#### GENERAL DESCRIPTION E67EDADB

The evaporative emission control system prevents hydrocarbon (HC) vapors from the fuel tank from escaping into the atmosphere where they could form photochemical smog. Gasoline vapors are collected in the charcoal canister. The PCM controls the Purge Control Solenoid Valve (PCSV) to purge any collected vapors from the canister back to the engine for combustion. This valve is actuated by the purge control signal from the PCM and controls fuel vapor flow from the canister to the intake manifold.

## DTC DESCRIPTION EOF8BCFB

PCM sets DTC P0444 if the PCM detects that the PCSV control circuit is open.

#### DTC DETECTING CONDITION E17CDCFF

ITEM	DETECTING CONDITION	POSSIBLE CAUSE
DTC Strategy	Driver stage check	
Enable Conditions	10V < Battery voltage(V) < 16 2% < Canister purge duty < 98%	Open in PCSV harness. Contact resistance in
Threshold Value	Open circuit	connectors. Faulty PCSV.
Diagnostic Time	3 sec.	

#### SPECIFICATION E4174A29

Temp.( )	Temp.( )	PCSV Resis- tance( )	Temp.( )	Temp.( )	PCSV Resis- tance( )
-20	-4	20 ~ 24	40	104	25 ~ 29
0	32	22 ~ 26	60	140	27 ~ 31
20	68	24 ~ 28	80	176	29 ~ 33

## WWW.DIGITALKHODRO.COM

#### **FUEL SYSTEM**

#### SCHEMATIC DIAGRAM ED5D9DCF

PCSV 2		26 - PCSV			Terminal			Connected to				Function								
¥内 I	20-7030		20-20-2030		<u>-20 - PCSV</u> 1		1 Main Relay			Battery Voltage										
After Main Relay						2		PCM Terminal 26				PCSV operation								
PCSV Harness side connector	F		7 8	9	10	11	*	P *	СМ			ninal		*	*	21	22	23	24	5 4
$\cap$ $\cap$		6 /							117			11	101			~ '	~~	201		
	-	6 7 * [	27	-	+	30	31	32	*	*	*	*	37	38	39	*	*	42	43	
	,		27	7 *	+	30	31 50	L	* 52			* 55						$ \rightarrow $		3
	;	* <b>(</b> * 4	27 5 *	7 *	29 48	30 *	50	51	52	*	54	55		*	58			61	43	

#### MONITOR DTC STATUS E98F34CF

#### 🔟 ΝΟΤΕ

If any DTCs (or pending codes) are present, do ALL REPAIRS associated with those codes before proceeding with this troubleshooting tree.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.

	1.4 AMBIENT CONDITIONS
To naviate to the "DTAL"menu	
<b>01</b> HYUNDAI VEHICLE DIAGNOSIS	
Select model and year	1. MIL STATUS
└→02 ENGINE	2. DTC STATUS: <u>PRESENT</u>
Select engine	3. DTC READINESS FLAG : <u>COMPLETE</u>
DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC
PART ERAS DTAL HELP	6. OP.HOUR AFTER ERASURE OF DTC

B00112

5. Is parameter displayed "History(Not Present) fault"?

FLA -309

#### **NOTE**

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

## YES

Fault is intermittent, caused by poor contact in the sensor's and/or PCM's connector or was repaired and PCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

#### NO

Go to "Component Inspection" procedure.

#### COMPONENT INSPECTION E4FF8A43

- Ignition "OFF". 1.
- 2. Disconnect PCSV connector.
- Measure resistance between terminals 1 and 2 of the PCSV connector(Component side). 3.

Specification :	5				
Temp.(	مازه ).Temp ول	PCSV Resis- tance()	Temp.( )	Temp.( )	PCSV Resis- tance( )
-20	-4	20 ~ 24	40	104	25 ~ 29
رو در اوران	يرڪار <u>3</u> 3 خود	1.2 <u>22 ~ 26 مال</u>	او 60 ن ساد	140	27 ~ <mark>31</mark>
20	68	24 ~ 28	80	176	29 ~ 33

<C106>



1. Battery Voltage 2. PCSV Operation

B04442

Is resistance within the specification? 4.



Go to next step as below.

NO

Check PCSV for contamination, deterioration, or damage. Substitute with a known-good PCSV and check for proper operation. If the problem is corrected, replace PCSV and then go to "Verification of Vehicle Repair" procedure.

## WWW.DIGITALKHODRO.COM

## 021-62999292

#### FLA -310

#### FUEL SYSTEM

#### TERMINAL AND CONNECTOR INSPECTION EAF65853

- 1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

#### YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Power Supply Circuit Inspection" procedure.

#### POWER SUPPLY CIRCUIT INSPECTION EBC366D6

- 1. Ignition "ON" & Engine "OFF".
- 2. Measure voltage between terminal 1 of the PCSV harness connector and chassis ground.

Specification : Approx. B+

```
3. Is voltage within the specification?
```

YES

Go to "Control Circuit Inspection" procedure.

#### NO

Check for a open in the power supply circuit. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### CONTROL CIRCUIT INSPECTION EED7F465

- 1. Ignition "OFF".
- 2. Disconnect PCM connector.
- 3. Measure resistance between terminals 2 of the PCSV harness connector and 26 of the PCM harness connector.

Specification : Approx. 0

4. Is resistance within the specification?



Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

## DTC TROUBLESHOOTING PROCEDURES

## NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

## VERIFICATION OF VEHICLE REPAIR EB77D1E0

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 3. Read "DTC Status" parameter.
- 4. Is parameter displayed "History(Not Present) fault"?



System performing to specification at this time. Clear the DTC.

NO

Go to the applicable troubleshooting procedure.

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



**FUEL SYSTEM** 

## DTC P0445 EVAP. EMISSION SYSTEM-PURGE CTRL. VALVE CIRCUIT SHORTED

#### COMPONENT LOCATION EAE3E8DF

Refer to DTC P0444.

#### GENERAL DESCRIPTION E3C5FDFF

Refer to DTC P0444.

#### DTC DESCRIPTION EE441CD1

PCM sets DTC P0445 if the PCM detects that the PCSV control circuit is shorted to ground or shorted to battery voltage.

#### DTC DETECTING CONDITION ECDCEB7D

ITEM	DETECTING CONDITION	POSSIBLE CAUSE
DTC Strategy	Driver stage check	
Enable Conditions	10V < Battery voltage(V) < 16 2% < Canister purge duty < 98%	Short in PCSV harness. Contact resistance in
Threshold Value	Short to ground or Short to Battery	- connectors. Faulty PCSV.
Diagnostic Time	شرکت دیجیتال خودرو ساما <u>نه</u> (م	

## SPECIFICATION 9 E9DB3986

Temp.( )	Temp.( )	PCSV Resis- tance( )	Temp.( )	Temp.( )	PCSV Resis- tance( )
-20	-4	20 ~ 24	40	104	25 ~ 29
0	32	22 ~ 26	60	140	27 ~ 31
20	68	24 ~ 28	80	176	29 ~ 33

#### SCHEMATIC DIAGRAM E20F5EFF

Refer to DTC P0444.

MONITOR DTC STATUS E4C0ED79

Refer to DTC P0444.

#### COMPONENT INSPECTION E940BCE3

Refer to DTC P0444.

#### TERMINAL AND CONNECTOR INSPECTION E1001B8A

Refer to DTC P0444.

#### POWER SUPPLY CIRCUIT INSPECTION EFBCAFFE

- 1. Ignition "ON" & Engine "OFF".
- 2. Measure voltage between terminal 1 of the PCSV harness connector and chassis ground.

Specification : Approx. B+

#### 3. Is voltage within the specification?

## YES

Go to "Control Circuit Inspection" procedure.

#### NO

Check for a open in the power supply circuit. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

### CONTROL CIRCUIT INSPECTION E21F36FD

- 1. Check for short to ground in control circuit.
  - 1) Ignition "OFF".
  - 2) Disconnect PCM connector.

3) Measure resistance between terminals 2 of the PCSV harness connector and 26 of the PCM harness connector.

#### Specification : Approx. 0

4) Is resistance within the specification?

#### YES

Go to next step as below.

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

- 2. Check for short to battery in control circuit.
  - 1) Ignition "ON" & Engine "OFF".
  - 2) Measure voltage between terminal 2 of the PCSV harness connector and chassis ground.

Specification : Approx. 0V

3) Is voltage within the specification?



Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

## NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

## VERIFICATION OF VEHICLE REPAIR E7BFFC0A

Refer to DTC P0444.



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

**FUEL SYSTEM** 

FLA -315

## DTC P0501 VEHICLE SPEED SENSOR A RANGE/PERFORMANCE

### COMPONENT LOCATION E609DDBC



EGQE502B

#### GERNERAL DESCRIPTION EFD6DC27

The Wheel Speed Sensor (WSS) generates a waveform with a frequency proportional to the speed of the vehicle. The signal generated by the WSS informs the PCM not only if the vehicle speed is low or high but also if the vehicle is or is not moving. The PCM uses this signal to control the fuel injection, ignition timing, transaxle shift scheduling and torque converter clutch scheduling. The WSS signal is also used to detect rough road conditions.

شرکت دیجیتال خودر و سامانه (مسئولیت محدود)

#### DTP DESCRIPTION E4899A36

The PCM evaluates engine speed and mass air flow if there is no vehicle speed signal. This evaluation of both values will detect open circuit or short circuit errors on the wheel speed sensor. The PCM sets DTC P0501 if there is no vehicle speed signal from wheel speed sensor while both engine speed and mass air flow are higher than predetermined threshold during the predetermined time.

## 021-62 99 92 92

## FLA -316

### FUEL SYSTEM

## DTP DETDCING CONDITION E9F0CF4A

ITEM		DETECING CONDITION	POSSIBLE CAUSE		
	DTC Strategy	Plausibility check			
Case1)	Enable Conditions	Engine speed > 2100 rpm Engine load > 250 mg/rev. Coolant temperature > 60 (140 ) 10V < Battery voltage < 16V No fuel shut-off			
	Threshold Value	Vehicle speed=0 with high engine speed and engine load	Open or short in harness Contact resistance in connectors		
	Diagnostic Time	60 seconds			
	DTC Strategy	Electrical check	Faulty wheel speed sensor		
Case2)	Enable Conditions	Vehicle speed > 0 10V < Battery voltage < 16V			
	Threshold Value	PCM detects abnormal input voltage of the signal circuit			
9	Diagnostic Time	10 seconds			

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

## DTC TROUBLESHOOTING PROCEDURES

### SCHEMATIC DIGRAM EDFE164B

Vith ABS/TCS, ESP]	CM	[Connection	nformation]	
ABS	See	Terminal	Connected to	Function
CONTORL 3 39 - WSS SIGNA	NL _	3	PCM Terminal 39	WSS signal
		5	PCM Terminal 39	WSS signal
ESP CONTORL MODULE				
CONNECTOR] PCM side terminal				
6 7 8 9 10 11 * * 14 * * 17 18	* * 21 22 23	24 5 4		
* 26 27 * 29 30 31 32 * * * * 37	38 🗨 \star \star 42	43		
* 45 * 47 48 * 50 51 52 * 54 55 56	* 58 59 60 61	62 3		
* 64 65 66 67 68 69 70 71 72 73 * 75	76 77 78 * 80	81 2 1		
C130-1				
/ithout ABS/TCS, ESP]	PCM	[Connection I	nformation]	
WSS	SIGNAL (-)	Terminal	Connected to	Function
		1	PCM Terminal 17	WSS signal (-)
2 18 - WSS	S SIGNAL (+)	2	PCM Terminal 18	WSS signal (+)
6   7   8   9   10   11   *   *   14   *   *   ●     *   26   27   *   29   30   31   32   *   *   *   37	* * 21 22 23 38 39 * * 42	24 5 4 43		
* 45 * 47 48 * 50 51 52 * 54 55 56		62 3		
	76 77 78 * 80			
C130-1				
CHEMATIC DIAGRAM (II) - Except Europe]		[Connection	nformation]	
PC	M	Terminal	Connected to	Function
Vehicle Speed Sensor 39 - VSS SI	GNAL	3	PCM Terminal 39	VSS signal
	0			
CONNECTOR] PCM side terminal				
6 7 8 9 10 11 * * 14 * * 17 18	* * 21 22 23	24 5 4		
	38 • * * 42			
* 45 * 47 48 * 50 51 52 * 54 55 56	* 58 59 60 61	<u> </u>		
	76 77 78 <b>*</b> 80			
		<u> </u>		
C130-1				

B05011

## WWW.DIGITALKHODRO.COM

#### FLA -318

### FUEL SYSTEM

#### MONITOR DTC STATUS E261A3DE

- 1. Connect Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.



- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

#### YES

5.

Fault is intermittent, caused by poor contact in the sensor's and/or PCM's connector or was repaired and PCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

#### NO

[Europe & with ABS] Go to "Monitor Scan tool Data" procedure.

[Europe & without ABS system] Go to "Signal Circuit Inspection[Without ABS]" procedure.

[Except Europe] Open or short circuit between VSS and PCM control module.

If problems are found, repair as necessary and go to "Verification of Vehicle Repair" procedure.

If OK, check VSS. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

## MONITOR SCAN TOOL DATA ED9531DE

- 1. With vehicle raised on a lift , start the engine and place transaxle in Drive. Let vehicle idle and verify speedometer indicates approx. 10km/h or more(6mph or more) on the instrument cluster.
- 2. Conect Scantool and select ABS system.
- 3. Monitor the "WHEEL SPD SENSOR-FR" parameter on the current data list.

## WWW.DIGITALKHODRO.COM

FLA -319

Specification : 10km/h or more(6mph or more)

4. Is value within the specification?



Wheel speed sensor is OK. Go to "Signal Circuit Inspection[With ABS]" procedure.



Check for open or short circuit between wheel speed sensor(FR) and ABS(or ESP) control module. If problems are found, repair as necessary and go to "Verification of Vehicle Repair" procedure.

- If OK, Check wheel speed sensor(FR) as follow :
- Gap between ABS sensor and trigger wheel (Air gap : 0.3~1.1 mm(0.011 ~ 0.043 in))
- Trigger wheel condition
- Sensor resistance : Approx. 1,300~1,500 at 20 (68 ) Replace wheel speed sensor as necessary and go to "Verification of Vehicle Repair" procedure.

#### SIGNAL CIRCUIT INSPECTION EA05F86B

#### [WITH ABS]

1. Check for open in circuit.

1) Ignition "OFF".

2) Disconnect PCM and ABS or ESP Control Module connectors.

3) Measure resistance between terminals 39 of the PCM harness connector and 3 of the ABS Control Module harness connector(W/ABS)
Measure resistance between terminals 39 of the PCM harness connector and 5 of the ESP Control Module harness connector(W/ESP)



4) Is resistance within the specification?



Go to next step as below.

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

- 2. Check for short to ground in circuit.
  - 1) Measure resistance between terminal 39 of the PCM harness connector and chassis ground.

Specification : Infinite

2) Is resistance within the specification?



Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

## WWW.DIGITALKHODRO.COM

**FUEL SYSTEM** 

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### [EUROPE & WITHOUT ABS SYSTEM]

- 1. Check for open in circuit.
  - 1) Ignition "OFF".
  - 2) Disconnect PCM and wheel speed sensor(front right) harness connector.
  - 3) Measure resistance between wheel speed sensor harness connector and PCM harness connector.

Specification : Approx. 0

	[W/O 4WD] - Terminal 1(sensor) & Terminal 17(PCM) - Terminal 2(sensor) & Terminal 18(PCM) [WITH 4WD] - Terminal 3(sensor) & Terminal 17(PCM) - Terminal 4(sensor) & Terminal 18(PCM)
4)	Is resistance within the specification.
	Go to next step as below.
	NO Repair as necessary and go to "Verification of Vehicle Repair" procedure.
2. Cł	neck for short to ground in circuit.

- 1) Measure resistance between terminal 17 of the PCM harness connector and chassis ground.
- 2) Measure resistance between terminal 18 of the PCM harness connector and chassis ground.

Specification : Infinite

3) Is resistance within the specification?



Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### VERIFICATION OF VEHICLE REPAIR EE9BDD72

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.

## WWW.DIGITALKHODRO.COM

## DTC TROUBLESHOOTING PROCEDURES

- 2. Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 3. Read "DTC Status" parameter.
- 4. Is parameter displayed "History(Not Present) fault"?



System performing to specification at this time. Clear the DTC



Go to the applicable troubleshooting procedure.



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



FUEL SYSTEM

## DTC P0506 IDLE AIR CONTROL SYSTEM-RPM LOWER THAN EXPECTED

## COMPONENT LOCATION EE67C60D



EGQE602V

#### GENERAL DESCRIPTION ECEDE685

When the TP sensor's signal indicates closed throttle position and the engine is idling, the PCM adjusts the idle speed control actuator so that the engine runs at the correct idling speed, regardless of coolant temperature, load and etc. When the additional load applied in the engine, the air flow through the idle speed control actuator is increased momentarily to raise the idling speed.

#### DTC DESCRIPTION E7A9AC94

The PCM monitors engine speed deviation from the target idle engine speed when the vehicle is stopped and the idle speed valve opening is stable. The PCM sets DTC P0506 if the difference to the target idle engine speed is lower than the predetermined threshold.

#### DTC DETECTING CONDITION E2B9DB99

ltem	Detecting Condition	Possible Cause
DTC Strategy	Monitor deviation between target idle speed and actual engine speed	
Enable Conditions	Vehicle speed=0 Coolant temperature > 74 (165 ) Throttle angle: closed 20seconds after engine start. Engine load < 1000mg/rev. 10V < Battery voltage < 16 No relevant failure	Restriction in intake or exhaust system. Carbonustment of the accelerator cable. Contact resistance in connectors.
Threshold Value	Target idle speed-Engine speed > 100rpm (Engine speed too low)	Faulty ISC valve.
Diagnostic Time	16 seconds.	

## SPECIFICATION EFBEB90F

#### TPS

Throttle Position	Output Voltage
C.T (IDLE)	0.2 ~ 0.8V
W.O.T	4.3 ~ 4.8 V

#### ICA COIL #1 (OPEN)

Temp.( )	Temp.( )	ICA Coil #1 (OPEN)( )	Temp.( )	Temp.( )	ICA Coil #1 (OPEN)( )
-20	-4	9.2 ~ 10.8	40	104	12.0 ~ 13.6
-10	14	9.7 ~ 11.3	50	122	12.4 ~ 14.0
0	32	10.2 ~ 11.8	60	140	12.9 ~ 14.5
10	50	10.6 ~ 12.2	70	158	13.4 ~ 15.0
20	68	11.1 ~ 12.7	80	176	13.8 ~ 15.4
30	86	11.5 ~ 13.1	100	212	14.7 ~ 16.3

## ICA COIL #2 (CLOSE)

Temp.( )	Temp.( )	ICA Coil #2 (CLOSE)( )	Temp.( )	Temp.()	ICA Coil #2 (CLOSE)( )
ىت 20-دود)	مانه ( <del>4</del> سئول	12.1 ~ 13.7	شر 40 ت د ر	104	15.7 ~ 17.3
-10	14	12.8 ~ 14.4	50	122	16.3 ~ 17.9
0	32	13.4 ~ 15.0	60	140	16.9 <mark>~ 18.5</mark>
10	50	14.0 ~ 15.6	70	158	17.4 ~ 19.0
20	68	14.5 ~ 16.1	80	176	18.0 ~ 19.6
30	86	15.1 ~ 16.7	100	212	19.2 ~ 20.8

#### SCHEMATIC DIAGRAM E59016A6



#### B05061

## WWW.DIGITALKHODRO.COM

## WWW.DIGITALKHODRO.COM

#### 021-62999292

FLA -324

**FUEL SYSTEM** 

SIGNAL WAVEFORM EF24C4B5



The above waveforms are the voltage signals generated when the ICA operates. This ICA is a duty type and the time opened determines the duty amount. The left side is the waveform of the ICA Opening coil during idle. The right side is the waveform of the ICA Closing coil during idle.

#### MONITOR DTC STATUS EC34F129

If any TPS, MAFS or ICA Valve circuit codes are present, do ALL REPAIRS associated with them before proceeding with this troubleshooting tree.

1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.

- 2. Press F4(DTAL) to select DTC information from the DTCs menu
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter



B00112

B05062

5. Is parameter displayed "History(Not Present) fault"?

## WWW.DIGITALKHODRO.COM
FLA -325

## 🚺 ΝΟΤΕ

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

## YES

Fault is intermittent caused by poor contact in the sensor's and/or PCM's connector or was repaired and PCM memory was not cleared. Thoroughly check connectors for loose or poor connections, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

### NO

Go to "Check for restricted intake or exhaust system" procedure.

#### CHECK FOR RESTRICTED INTAKE OR EXHAUST SYSTEM

- 1. Visually/physically inspect the following items :
  - Air cleaner filter element for excessive dirt or for any foreign objects.
  - Throttle body inlet for damage or for any foreign objects.
  - Restricted exhaust system.
- 2. Was a problem found in any of the above areas?



#### TERMINAL AND CONNECTOR INSPECTION E02BDF3A

- 1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?



Repair as necessary and go to "Verification of Vehicle Repair" procedure

NO

Go to next step as below.

#### COMPONENT INSPECTION E3EFE63C

- 1. Ignition "ON".
- 2. Remove ICA Valve from Throttle body. Check for throttle bore, throttle plate and the ICA passages for chocking and for any foreign objects. Repair or clean as necessary.
- 3. Install the ICA valve.

# 021-62999292

## FLA -326

## FUEL SYSTEM

- 4. Ignition "ON" & Engine "OFF".
- 5. Install scan tool and select "IDLE SPEED ACTUATOR" parameter on the "Actuation Test" mode.
- 6. Activates ICA valve by pressing "STAT" key.
- 7. Check the ICA valve for clicking sound and visually verifying valve closes and opens.

# 🔟 ΝΟΤΕ

Repeat numerous times to ensure valve reliability.

8. Is ICA Valve OK?



Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### NO

Check ICA for contamination, deterioration, or damage. Substitute with a known-good ICA and check for proper operation. If the problem is corrected, replace ICA and then go to "Verification of Vehicle Repair" procedure.

# VERIFICATION OF VEHICLE REPAIR EBABIC4B

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode
- 2. Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 3. Read "DTC Status" parameter
- 4. Is parameter displayed "History(Not Present) fault"?

#### YES

System performing to specification at this time. Clear the DTC

NO

Go to the applicable troubleshooting procedure.

FLA -327

# DTC P0507 IDLE AIR CONTROL SYSTEM-RPM HIGHER THAN EXPECTED

## COMPONENT LOCATION EF7CBFEA

Refer to DTC P0506.

## GENERAL DESCRIPTION E5C90D87

Refer to DTC P0506.

## DTC DESCRIPTION E972CC96

The PCM monitors engine speed deviation from the target idle engine speed when the vehicle is stopped and the idle speed valve opening is stable. The PCM sets DTC P0507 if the difference to the target idle engine speed is higher than the predetermined threshold.

#### DTC DETECTING CONDITION ECFB9A9A

Item	Detecting Condition	Possible Cause
DTC Strategy	Monitor deviation between target idle speed and actual engine speed	0
سئولیت محدود) Enable Conditions فودرو در ایران	20seconds after engine start. Engine load < 1000mg/rev.	A stuck or binding throttle plate. Maladjustment of the accelerator cable. Contact resistance in connectors. Faulty ISC valve.
Threshold Value	Engine speed > (target RPM + 200)	
Diagnostic Time	16 seconds.	

#### SPECIFICATION EDEAD801

#### TPS

Throttle Position	Output Voltage
C.T (IDLE)	0.2 ~ 0.8V
W.O.T	4.3 ~ 4.8 V

#### ICA COIL #1 (OPEN)

Temp.( )	Temp.( )	ICA Coil #1 (OPEN)( )	Temp.( )	Temp.( )	ICA Coil #1 (OPEN)( )
-20	-4	9.2 ~ 10.8	40	104	12.0 ~ 13.6
-10	14	9.7 ~ 11.3	50	122	12.4 ~ 14.0
0	32	10.2 ~ 11.8	60	140	12.9 ~ 14.5
10	50	10.6 ~ 12.2	70	158	13.4 ~ 15.0

# WWW.DIGITALKHODRO.COM

### 021-62999292

FLA -328

**FUEL SYSTEM** 

20	68	11.1 ~ 12.7	80	176	13.8 ~ 15.4
30	86	11.5 ~ 13.1	100	212	14.7 ~ 16.3

#### ICA COIL #2 (CLOSE)

Temp.( )	Temp.( )	ICA Coil #2 (CLOSE)( )	Temp.( )	Temp.( )	ICA Coil #2 (CLOSE)( )
-20	-4	12.1 ~ 13.7	40	104	15.7 ~ 17.3
-10	14	12.8 ~ 14.4	50	122	16.3 ~ 17.9
0	32	13.4 ~ 15.0	60	140	16.9 ~ 18.5
10	50	14.0 ~ 15.6	70	158	17.4 ~ 19.0
20	68	14.5 ~ 16.1	80	176	18.0 ~ 19.6
30	86	15.1 ~ 16.7	100	212	19.2 ~ 20.8

#### SCHEMATIC DIAGRAM EC2EEEAC

Refer to DTC P0506.

#### SIGNAL WAVEFORM E75AA4AC

Refer to DTC P0506.

## MONITOR DTC STATUS E2E1DB28

# **NOTE**

If any TPS, MAFS or ICA Valve circuit codes are present, do ALL REPAIRS associated with them before proceeding with this troubleshooting tree.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter

FLA -329

B00112

	1.4 AMBIENT CONDITIONS
To naviate to the "DTAL"menu	
01 HYUNDAI VEHICLE DIAGNOSIS	
Select model and year	1. MIL STATUS
→ 02 ENGINE	2. DTC STATUS: <u>PRESENT</u>
Select engine	3. DTC READINESS FLAG : <u>COMPLETE</u>
<b>01</b> DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC
PART ERAS DTAL HELP	6. OP.HOUR AFTER ERASURE OF DTC
1	

5. Is parameter displayed "History(Not Present) fault"?

### 🔟 NOTE

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

#### YES

Fault is intermittent caused by poor contact in the sensor's and/or PCM's connector or was repaired and PCM memory was not cleared. Thoroughly check connectors for loose or poor connections, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

اولین سامانه دیجیتال تعمیرکاران خودر و د<mark>ر NO</mark>

Go to "Accelerator Cable & Throttle plate Inspection" procedure.

#### ACCELERATOR CABLE & THROTTLE PLATE INSPECTION

- 1. Visually/physically inspect the following items. Repair or adjust as necessary and go to next step
  - Check that the Accelerator Cable is not sticking or moving sluggishly.
  - Check Accelerator Cable free play [0.040~0.120 in. (1.0~3.0 mm)].
- 2. Remove Intake Hose and inspect Throttle Plate for excessive carbon deposits.
- 3. Is Throttle Plate being held open with excessive carbon deposits?

# YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Air Leakage Inspection" procedure.

#### AIR LEAKAGE INSPECTION E868B928

1. Visually/physically inspect the air leakage in intake/exhaust system as following items, If OK, go to next step

If NG, repair as necessary and go to "Verification of Vehicle Repair" procedure.

Vacuum hoses for splits, kinks and improper connections.

#### FLA -330

## 021-62999292

#### FUEL SYSTEM

- Throttle body gasket.
- Gasket between intake manifold and cylinder head.
- Seals between intake manifold and fuel injectors.
- Exhaust system between HO2S and Three way catalyst for air leakage.
- 2. Check for air leakage in EVAP. Purge control valve.
  - 1) Remove the manifold side vacuum hose from the EVAP canister purge valve.
  - 2) Using a hand vacuum pump apply specified vacuum(Approx. 15 in, Hg) to the manifold side of the valve.
  - 3) Does the valve hold vacuum?



Go to next step as below.

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### TERMINAL AND CONNECTOR INSPECTION E6CB1635

Refer to DTC P0506.

#### COMPONENT INSPECTION EAEDCC44

- 1. Ignition "OFF".
- 2. Remove ICA Valve from Throttle body. Check for throttle bore, throttle plate and the ICA passages for chocking and for any foreign objects. Repair or clean as necessary.
- 3. Install the ICA valve.
- 4. Ignition "ON" & Engine "OFF".
- 5. Install scan tool and select "IDLE SPEED ACTUATOR" parameter on the "Actuation Test" mode.
- 6. Activates ICA valve by pressing "STAT" key.
- 7. Check the ICA valve for clicking sound and visually verifying valve closes and opens.

#### 🚺 ΝΟΤΕ

Repeat numerous times to ensure valve reliability.

8. Is ICA Valve OK?



Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Check ICA for contamination, deterioration, or damage. Substitute with a known-good ICA and check for proper operation. If the problem is corrected, replace ICA and then go to "Verification of Vehicle Repair" procedure.

# WWW.DIGITALKHODRO.COM

# VERIFICATION OF VEHICLE REPAIR ED86AAC8

Refer to DTC P0506.



WWW.DIGITALKHODRO.COM

FLA -331

## FUEL SYSTEM

# DTC P0560 SYSTEM VOLTAGE

## COMPONENT LOCATION E4AF616F



The PCM provides ground to one side of the coil of the main relay and the other side is connected to the battery. The PCM monitors battery voltage and the voltage after the main relay.

### DTC DESCRIPTION E18FA7EA

The PCM measures the voltage from ignition key and from main relay respectively and compares two voltages. This comparison will watch if the Main Relay has switched and remains on after ignition Key-On and if it has switched off after the ignition Key-Off. The PCM sets DTC P0560 if the voltage after Main Relay is lower than a predetermined threshold after ignition key-off.

## DTC DETECTING CONDITION E6FA6C7D

Item		Detecting Condition	Possible Cause
DTC Strategy		Comparison of battery voltage and voltage after main relay	
	Enable Conditions	Battery voltage >10V Ignition ON	
Case 1)	Threshold Value	Voltage after main relay when ON < 6V	
	Diagnosis Time	180 mSec.	Open or short circuit Contact resistance in connectors
	Enable Conditions	Ignition OFF	
Case 2)	Threshold Value	Voltage after main relay when ON > 6V	
	Diagnosis Time	180 mSec.	

## DTC TROUBLESHOOTING PROCEDURES

# SCHEMATIC DIAGRAM EBF7C1F6



# MONITOR DTC STATUS E9EA299B

1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.

- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.

	1.4 AMBIENT CONDITIONS
To naviate to the "DTAL"menu	
<b>01</b> HYUNDAI VEHICLE DIAGNOSIS	
Select model and year	1. MIL STATUS
└→02 ENGINE	2. DTC STATUS: <u>PRESENT</u>
Select engine	3. DTC READINESS FLAG : <u>COMPLETE</u>
→ 01 DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC
PART ERAS DTAL HELP	6. OP.HOUR AFTER ERASURE OF DTC

B00112

5. Is parameter displayed "History(Not Present) fault"?

#### 🔟 ΝΟΤΕ

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

# WWW.DIGITALKHODRO.COM

# Y<u>ES</u>

#### FUEL SYSTEM

Fault is intermittent caused by poor contact in the sensor's and/or the PCM's connector, which was repaired but PCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

### NO

Go to "Component Inspection" procedure.

#### COMPONENT INSPECTION ECFDDE9B

- 1. Ignition "OFF".
- 2. Remove the main relay.
- 3. Apply 12V and a ground to 2 and 4 terminals of the main relay(Components side).
- 4. Check if the main relay works well when it is energized. (If the main relay works normally, a clicking sound can be heard.)
- 5. Does the main relay operate normally?



Check relay for contamination, deterioration, or damage. Substitute with a known-good relay and check for proper operation. If the problem is corrected, replace relay and then go to "Verification of Vehicle Repair" procedure.

### TERMINAL AND CONNECTOR INSPECTION EFOSOCAE

- 1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Power Supply Circuit Inspection" procedure.

#### POWER SUPPLY CIRCUIT INSPECTION E402EAA7

- 1. Ignition "ON" & Engine "OFF".
- 2. Measure the voltage between terminal 2 of the main relay harness connector and chassis ground.

# DTC TROUBLESHOOTING PROCEDURES

3. Measure the voltage between terminal 5 of the main relay harness connector and chassis ground.

Specification : Approx. B+

4. Is voltage within the specification?

YES

Go to "Control Circuit Inspection"

NO

Check for an open or short to ground in the power supply circuit. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

### CONTROL CIRCUIT INSPECTION E7C9FF10

- 1. Check for short to ground in control circuit.
  - 1) Ignition "OFF".
  - 2) Measure resistance between terminal 4 of the relay harness connector and chassis ground.



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

- 2. Check for short to power in control circuit.
  - 1) Disconnect PCM connectors.
  - 2) Ignition "ON" and Engine "OFF".
  - 3) Measure voltage between terminal 4 of the relay harness connector and chassis ground.

Specification : Approx 0V

4) Is voltage within the specification?



Go to next step as below

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

3. Check for open in control harness.

# WWW.DIGITALKHODRO.COM

## 021-62999292

#### FLA -336

FUEL SYSTEM

1) Measure resistance between terminals 4 of the relay harness connector and 67 of the ECM harness connector.

Specification : Approx 0

2) Is resistance within the specification?



Check for poor connection between ECM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### VERIFICATION OF VEHICLE REPAIR E173BEB9

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 3. Read "DTC Status" parameter.
- 4. Is parameter displayed "History(Not Present) fault"?

#### YES

System performing to specification at this time. Clear the DTC

#### NO

Go to the applicable troubleshooting procedure.

## DTC TROUBLESHOOTING PROCEDURES

# DTC P0562 SYSTEM VOLTAGE LOW

## COMPONENT LOCATION EECDA2B9

Refer to DTC P0560.

## GENERAL DESCRIPTION EA8BAA2B

Refer to DTC P0560.

## DTC DESCRIPTION ED1D4EBB

The sets DTC P0562 if the PCM detects system voltage lower than the possible range of battery voltage.

## DTC DETECTING CONDITION EA2DFD36

ltem	Detecting Condition	Possible Cause
DTC Strategy	Check system voltage	
Enable Conditions	No main relay failure Vehicle speed > 10km/h(6mph)	Contact resistance in connectors.
Threshold Value	Voltage after main relay when ON < 10V	Faulty charging system.
Diagnostic Time	30 sec. •• • • •	

#### SCHEMATIC DIAGRAM ED136247



B05601

# FUEL SYSTEM

## MONITOR DTC STATUS E3FEDOD3

# 🔟 ΝΟΤΕ

If any codes relating to system voltage(P0560) is stored, do ALL REPAIRS associated with those codes before proceeding with troubleshooting.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.

To naviate to the "DTAL"menu 01 HYUNDAI VEHICLE DIAGNOSIS	
Select model and year	1. MIL STATUS
D2 ENGINE	2. DTC STATUS: <u>PRESENT</u>
Select engine	3. DTC READINESS FLAG : <u>COMPLETE</u>
OI DIAGNOSTIC TROUBLE CODES :Select F4(DTAL)on the function bar	4. STATISTIC COUNTER : 1 5. OP.HOUR AFTER DETECTION OF DTC
PART ERAS DTAL	6. OP.HOUR AFTER ERASURE OF DTC

5. Is parameter displayed "History(Not Present) fault"?

### 🔟 ΝΟΤΕ

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

### YES

Fault is intermittent caused by poor contact in the sensor's and/or the PCM's connector, which was repaired but PCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

#### NO

Go to next step as below.

### TERMINAL AND CONNECTOR INSPECTION E7BA8ED2

Refer to DTC P0560.

### CHARGING SYSTEM INSPECTION E2BBC567

1. Check battery condition and Generator output.

# DTC TROUBLESHOOTING PROCEDURES

2. Are battery conditions and Generator output both okay?



Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

### VERIFICATION OF VEHICLE REPAIR EBBABEE

Refer to DTC P0560.



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



**FUEL SYSTEM** 

# DTC P0563 SYSTEM VOLTAGE HIGH

### COMPONENT LOCATION EFEDC4D7

Refer to DTC P0560.

### GENERAL DESCRIPTION E7C06CFB

Refer to DTC P0560.

## DTC DESCRIPTION E9A25A5D

PCM sets DTC P0563 if the PCM detects system voltage higher than the possible range of battery voltage.

## DTC DETECTING CONDITION EC907AF4

Item	Detecting Condition	Possible Cause
DTC Strategy	Check system voltage	
Enable Conditions	No main relay failure Vehi <mark>c</mark> le speed > 10km/h(6mph)	Contact resistance in connectors
Threshold Value	Voltage after main relay when ON > 16V	Faulty charging system
Diagnostic Time	30 sec.	

# SCHEMATIC DIAGRAM E90FA45C

Refer to DTC P0560.

## MONITOR DTC STATUS E16812D2

# 🚺 ΝΟΤΕ

If any codes relating to system voltage(P0560) is stored, do ALL REPAIRS associated with those codes before proceeding with troubleshooting.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.

FLA -341

B00112

	1.4 AMBIENT CONDITIONS
To naviate to the "DTAL"menu	
01 HYUNDAI VEHICLE DIAGNOSIS	
Select model and year	1. MIL STATUS
D2 ENGINE	2. DTC STATUS: <u>PRESENT</u>
Select engine	3. DTC READINESS FLAG : <u>COMPLETE</u>
<b>01</b> DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC
PART ERAS DTAL HELP	6. OP.HOUR AFTER ERASURE OF DTC

5. Is parameter displayed "History(Not Present) fault"?

#### 🔟 ΝΟΤΕ

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.



Fault is intermittent caused by poor contact in the sensor's and/or the PCM's connector, which was repaired but PCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

#### NO

Go to next step as below.

### TERMINAL AND CONNECTOR INSPECTION E8CBF96F

Refer to DTC P0560.

## CHARGING SYSTEM INSPECTION EBED3E7E

- 1. Check battery condition and Generator output.
- 2. Are battery conditions and Generator output both okay?



Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

# WWW.DIGITALKHODRO.COM

### VERIFICATION OF VEHICLE REPAIR EE87ECEB

Refer to DTC P0560.

**FUEL SYSTEM** 



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

## FLA -343

# DTC P0600 CAN COMMUNICATION BUS

## GENERAL DESCRIPTION ECE45BF2

A communication line exists between the Engine Control Module(PCM) and the Transaxle Control Module(TCM). The communication is through a Control Area Network(CAN). Without CAN communication, an independent pin and wiring is needed to receive a sensor information from a PCM. The more information to be communicated, the more wirings is required. In case of CAN communication type, all the information need to be communicated among control modules such as PCM and ABS control module use CAN lines.

### DTC DESCRIPTION E6216FF5

The PCM determines CAN communication error and sets DTC P0600 if communication with other engine control devices (e.g. ABS) via CAN is impossible or PCM detects that communication time via CAN exceeds threshold value.

#### DTC DETECTING CONDITION E48BE6AE

ltem		Detecting Condition	Possible Cause
	DTC Strategy	CAN message transfer incorrect	
Case1	Enable Conditions	Battery voltage > 10V En <mark>gi</mark> ne speed > Approx. 30 rpm	0
Gaser	Threshold Value	CAN message is incorrect	
حدود)	Diagnostic Time	20 wrong messages	Open or short in CAN line Contact resistance in
يران	DTC Strategy	No message from control module	connectors Faulty PCM
Case2	Enable Conditions	Battery voltage > 10V Engine speed > Approx. 30 rpm	
Casez	Threshold Value	Time exceeded without message = 1 sec.	
	Diagnostic Time	1 sec.	

#### MONITOR DTC STATUS E9F2B402

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.

**FUEL SYSTEM** 

B00112

	1.4 AMBIENT CONDITIONS	
To naviate to the "DTAL"menu		
<b>01</b> HYUNDAI VEHICLE DIAGNOSIS		
Select model and year	1. MIL STATUS	
→ 02 ENGINE	2. DTC STATUS: <u>PRESENT</u>	
Select engine	3. DTC READINESS FLAG : <u>COMPLETE</u>	
→ 01 DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1	
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC	
PART ERAS DTAL HELP	6. OP.HOUR AFTER ERASURE OF DTC	

5. Is parameter displayed "History(Not Present) fault"?

## 🔟 ΝΟΤΕ

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

#### YES

Fault is intermittent caused by poor contact in the sensor(s) and/or the PCM's connector was repaired and PCM memory was not cleared. Thoroughly check connectors for loose or poor connections, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

# اولین سامانه دیجیتال تعمیرکاران خودرو در 🛛 🔊

Go to "next step as below.

# TERMINAL AND CONNECTOR INSPECTION E1DB220A

- 1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "CAN High line Inspection" procedure.

### CAN HIGH LINE INSPECTION

- 1. Check for Open in harness. [With ABS]
  - 1) Ignition "OFF".

# DTC TROUBLESHOOTING PROCEDURES

 Measure resistance between terminals 7 of the PCM harness connectors and 11 of the ABS control module harness connector.

Specification : Approx. 0

3) Is resistance within the specification?



Go to "Check for short to ground in harness" procedure.



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

[Without ABS]

4) Measure resistance between terminals 7 of the PCM harness connectors and 2 of the vertical resistor.

Specification : Approx. 0

		s resistance within the specification?	
	بحدو	Go to "Check for short to ground in harness" procedure.	
		Repair as necessary and go to "Verification of Vehicle Repair" procedure.	
2	Chack	k for short to ground in harness	

- 2. Check for short to ground in harness.
  - 1) Measure resistance between terminals 7 of the PCM harness connectors and chassis ground.

Specification :	Infinite
-----------------	----------

2) Is resistance within the specification?



Go to next step as below.

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

- 3. Check for short to battery in harness.
  - 1) Ignition "ON" & Engine "OFF".
  - 2) Measure resistance between terminals 7 of the PCM harness connectors and chassis ground

Specification : Approx. 0V

3) Is voltage within the specification?

#### FLA -346

#### YES

FUEL SYSTEM

Go to "CAN Low Line Inspection" procedure.

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### CAN LOW LINE INSPECTION

- 1. Check for Open in harness. [With ABS]
  - 1) Measure resistance between terminals 6 of the PCM harness connectors and 10 of the ABS control module harness connector.

Specification : Approx. 0

2) Is resistance within the specification?

Y	ES

Go to "Check for short to ground in harness" procedure.

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

[Without ABS]

3) Measure resistance between terminals 6 of the PCM harness connectors and 1 of the vertical resistor.

Specification : Approx. 0

4) Is resistance within the specification?



Go to "Check for short to ground in harness" procedure.



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

- 2. Check for short to ground in harness.
  - 1) Measure resistance between terminals 6 of the PCM harness connectors and chassis ground.

Specification : Infinite

2) Is resistance within the specification?



Go to next step as below.

## NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

- 3. Check for short to battery in harness.
  - 1) Ignition "ON" & Engine "OFF".
  - 2) Measure resistance between terminals 6 of the PCM harness connectors and chassis ground.

Specification : Approx. 0V

3) Is voltage within the specification?

### YES

Using a scan tool, check PCM software version and upgrade as necessary. If version is the newest one, go to "Verification of Vehicle Repair" procedure.

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

## VERIFICATION OF VEHICLE REPAIR EFB6A9B6

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 3. Read "DTC Status" parameter.
- 4. Is parameter displayed "History(Not Present) fault"?

#### YES

System performing to specification at this time. Clear the DTC.



Go to the applicable troubleshooting procedure.

FUEL SYSTEM

# DTC P0605 INTERNAL CONTROL MODULE READ ONLY MEMORY(ROM) ERROR

# COMPONENT LOCATION EF40B4F7



EGQE501E

#### GENERAL DESCRIPTION E4FE8BE0

A malfunction is detected by using a checksum technique for verifying data. The digital data is composed of zeros and ones. A checksum is the total of all ones in a string of data. By comparing the checksum value with a stored value, a malfunction can be detected.

### DTC DESCRIPTION E0A90DFC

# اولین سامانه دیجیتال تعمیرگاران خودرو در ایران

The PCM monitors RAM areas and communication connections between microcontroller and output drivers and sets DTC P0605 if failure is detected.

## DTC DETECTING CONDITION E6AE72F5

Item Detecting Condition		Possible Cause	
DTC Strategy	Check RAM Area / Communication connections		
Enable Conditions	Ignition ON	Contact resistance in	
Threshold Value	Internal check	Connectors Faulty PCM	
Diagnostic Time	0.1 second		

#### MONITOR DTC STATUS EF5C9AFE

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.

FLA -349

B00112

1.4 AMBIENT CONDITIONS
1. MIL STATUS
2. DTC STATUS: <u>PRESENT</u>
3. DTC READINESS FLAG : <u>COMPLETE</u>
4. STATISTIC COUNTER : 1
5. OP.HOUR AFTER DETECTION OF DTC
6. OP.HOUR AFTER ERASURE OF DTC

5. Is parameter displayed "History(Not Present) fault"?

### 🔟 ΝΟΤΕ

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

YES

Fault is intermittent caused by poor contact in the sensor's and/or the PCM's connector, which was repaired but PCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

NO Go to "Back Up Voltage Inspection " procedure.

BACK UP VOLTAGE INSPECTION

- 1. Ignition "OFF".
- 2. Disconnect PCM connector.
- 3. Ignition "ON".
- 4. Measure voltage between terminal 3 of the PCM harness connector and chassis ground.

Specification : Remain stable at battery voltage

5. Are circuits remaining stable at battery voltage?



Using a scan tool, check PCM software version and upgrade as necessary. If version is the newest one, go to "Verification of Vehicle Repair" procedure.

NO

If voltage fluctuates, check circuit for loose, bent or corroded terminals, Repair as necessary and go to "Verification of Vehicle Repair" procedure.

# WWW.DIGITALKHODRO.COM

# 021-62999292

#### FLA -350

#### **FUEL SYSTEM**

#### VERIFICATION OF VEHICLE REPAIR EEA497AA

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 3. Read "DTC Status" parameter.
- 4. Is parameter displayed "History(Not Present) fault"?

### YES

System performing to specification at this time. Clear the DTC.

#### NO

Go to the applicable troubleshooting procedure.





FLA -351

# DTC P0650 MALFUNCTION INDICATOR LAMP(MIL) CONTROL CIRCUIT

## COMPONENT LOCATION EE29E0CA



P06501

## GENERAL DESCRIPTION EDADGAAD

The Malfunction Indicator Lamp (MIL), which is located in the instrument cluster, comes on to notify the driver that there may be a problem with the vehicle and that service is needed. Immediately after the ignition switch turns on, the malfunction indicator lamp is lit to indicate that the MIL operates normally and goes off after starting.

#### شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

#### DTC DESCRIPTION EEECC6F7

PCM sets DTC P0650 if the PCM detects that the MIL control line is open or short circuit to ground or battery line.

### DTC DETECTING CONDITION EAE4F5A7

ltem	Detecting Condition	Possible Cause	
DTC Strategy	Driver stage check	Open or short between MIL and PCM Contact resistance in connectors	
Enable Conditions	Ignit10 < Battery voltage < 16		
Threshold Value	Open, short to ground or battery		
Diagnostic Time	10 sec.	Burned out MIL bulb	

# FUEL SYSTEM

## SCHEMATIC DIAGRAM EGE16BAE



## MONITOR DTC STATUS EB4DDA24

1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.

- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter .

	1.4 AMBIENT CONDITIONS	
To naviate to the "DTAL"menu		
01 HYUNDAI VEHICLE DIAGNOSIS		
Select model and year	1. MIL STATUS	
└→02 ENGINE	2. DTC STATUS: <u>PRESENT</u>	
Select engine	3. DTC READINESS FLAG : <u>COMPLETE</u>	
<b>01</b> DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1	
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC	
PART ERAS DTAL HELP	6. OP.HOUR AFTER ERASURE OF DTC	

B00112

5. Is parameter displayed "History(Not Present) fault"?

### 🔟 ΝΟΤΕ

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

# WWW.DIGITALKHODRO.COM

## FLA -353

### YES

Fault is intermittent caused by poor contact in the sensor's and/or the PCM's connector, which was repaired but PCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

## NO

Go to next step as below.

### CONTROL CIRCUIT INSPECTION E7EFF7B3

- 1. Ignition "OFF".
- 2. Disconnect PCM connector.
- 3. Ignition "ON" & Engine "OFF".
- 4. Using a suitable wire, jumper the terminal 70 of the PCM harness connector to chassis ground.
- 5. Is MIL bulb illuminated?



Remove instrument cluster and inspect MIL bulb. If it is burned out, replace bulb. If bulb is okay, locate source of open between bulb and Meter Fuse. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

- 6. Remove wire from PCM harness connector.
- 7. Does MIL bulb go out?



Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.



Check for source of short to GND between bulb and PCM. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### VERIFICATION OF VEHICLE REPAIR E289C538

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 3. Read "DTC Status" parameter.
- 4. Is parameter displayed "History(Not Present) fault"?

### 021-62999292

# FLA -354

# YES

**FUEL SYSTEM** 

System performing to specification at this time. Clear the DTC.

#### NO

Go to the applicable troubleshooting procedure.



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

# DTC P0700 TCU REQUEST FOR MIL ON

#### GENERAL DESCRIPTIONT E8BE130E

The TCM can request activation of the MIL lamp via a communication line to the PCM. This is only a request from TCM to PCM to turn the MIL on. The fault code is stored in the TCM. Select Transaxle system on the Scantool and monitor DTC related automatic transaxle system.

DO ALL REPAIRS associated malfunction with A/T.

#### DTC DETECTING CONDITION ECB403E5

Item Detecting Condition		Possible Cause	
DTC Strategy	Freeze frame request via CAN	Transaxle system	
Enable Conditions	Battery voltage > 10V Engine speed > 256 rpm		
Threshold Value	MIL is requested by TCM		
Diagnostic Time Immediate			

### MONITOR DTC STATUS EB8D0A87

- 1. This is only a request from TCM to PCM to turn the MIL on. The fault code is stored in the TCM. The Freeze Frame Data is stored in the PCM under the P0700 request code. Be sure to retrieve freeze frame data before clearing code P0700 from PCM.
- 2. Check the transaxle system.

FLA -355

FUEL SYSTEM

# DTC P1505 IDLE CHARGE ACTUATOR SIGNAL LOW OF COIL #1

#### COMPONENT LOCATION EBD5C3FF



EGQE602V

#### GENERAL DESCRIPTION E7D18186

The Idle Charge Actuator Valve(ICAV) is installed on the intake manifold and controls the intake airflow that is bypassed around the throttle plate to keep constant engine speed when the throttle valve is closed. The function of the ICA valve is to maintain idle speed according to various engine loads and conditions, and also to provide additional air during starting. The ICA valve consists of an opening coil, a closing coil, and a permanent magnet. Based on information from various sensors, the PCM controls both coils by grounding their control circuits. According to the control signals from the PCM, the valve rotor rotates to control the by pass airflow into the engine.

DTC DESCRIPTION EEOBAGF9 DE UIL2

PCM sets DTC P1505 if the PCM detects that the ICAV(OPEN) control circuit is open or short to ground.

### DTC DETECTING CONDITION EA637A1C

Item	Detecting Condition	Possible Cause	
DTC Strategy	Driver stage check		
Enable Conditions	10V < Battery voltage < 16V 20% < ICA duty < 80%	Open or short to ground in harness Contact resistance in	
Threshold Value	Open or short to ground	connectors Faulty ICA valve	
Diagnostic Time	1 sec.		

### SPECIFICATION EDEC2E1F

#### ICA COIL #1 (OPEN)

Temp.( )	Temp.( )	ICA Coil #1 (OPEN)( )	Temp.( )	Temp.( )	ICA Coil #1 (OPEN)( )
-20	-4	9.2 ~ 10.8	40	104	12.0 ~ 13.6
-10	14	9.7 ~ 11.3	50	122	12.4 ~ 14.0
0	32	10.2 ~ 11.8	60	140	12.9 ~ 14.5

# WWW.DIGITALKHODRO.COM

FLA -357

10	50	10.6 ~ 12.2	70	158	13.4 ~ 15.0
20	68	11.1 ~ 12.7	80	176	13.8 ~ 15.4
30	86	11.5 ~ 13.1	100	212	14.7 ~ 16.3

#### ICA COIL #2 (CLOSE)

Temp.( )	Temp.( )	ICA Coil #2 (CLOSE)( )	Temp.( )	Temp.( )	ICA Coil #2 (CLOSE)( )
-20	-4	12.1 ~ 13.7	40	104	15.7 ~ 17.3
-10	14	12.8 ~ 14.4	50	122	16.3 ~ 17.9
0	32	13.4 ~ 15.0	60	140	16.9 ~ 18.5
10	50	14.0 ~ 15.6	70	158	17.4 ~ 19.0
20	68	14.5 ~ 16.1	80	176	18.0 ~ 19.6
30	86	15.1 ~ 16.7	100	212	19.2 ~ 20.8

## SCHEMATIC DIAGRAM E17A9529



### 021-62999292

#### FLA -358

#### **FUEL SYSTEM**

#### SIGNAL WAVEFORM E4BE1BBB



The above waveforms are the voltage signals generated when the ICA operates. This ICA is a duty type and the time opened determines the duty amount. The left side is the waveform of the ICA Opening coil during idle. The right side is the waveform of the ICA Closing coil during idle.

### MONITOR DTC STATUS E2EF1ACD

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.

	1.4 AMBIENT CONDITIONS		
To naviate to the "DTAL"menu			
<b>01</b> HYUNDAI VEHICLE DIAGNOSIS			
Select model and year	1. MIL STATUS		
└→02 ENGINE	2. DTC STATUS: <u>PRESENT</u>		
Select engine	3. DTC READINESS FLAG : <u>COMPLETE</u>		
<b>01</b> DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1		
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC		
PART ERAS DTAL HELP	6. OP.HOUR AFTER ERASURE OF DTC		
L T			

B00112

B05062

5. Is parameter displayed "History(Not Present) fault"?

#### 🔟 NOTE

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

# WWW.DIGITALKHODRO.COM

## FLA -359

## YES

Fault is intermittent caused by poor contact in the sensor's and/or the PCM's connector, which was repaired but PCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

## NO

Go to "Component Inspection" procedure.

#### COMPONENT INSPECTION E79FE74F

- 1. Ignition "OFF".
- 2. Disconnect ICA valve connector.
- 3. Measure resistance between terminals 1 and 2 of the valve connector(Component side).

#### SPECIFICATION

Temp.( )	Temp.( )	ICA Coil #1 (OPEN)( )	Temp.( )	Temp.( )	ICA Coil #1 (OPEN)( )
-20	-4	9.2 ~ 10.8	40	104	12.0 ~ 13.6
-10	14	9.7 ~ 11.3	<b>5</b> 0	122	12.4 ~ 14.0
یت م•دود)	مانه (32سئول	10.2 ~ 11.8	شر 60ے دیا	140	12.9 ~ 14.5
10	50	10.6 ~ 12.2	70	158	13.4 ~ 15.0
20	مر <mark>68 خورد</mark>	11.1 ~ 12.7	80	176	13.8 ~ <mark>15.4</mark>
30	86	11.5 ~ 13.1	100	212	14.7 ~ 16.3

<C115>



B15055

4. Is resistance within the specification?

ICA (Open)
Battery Voltage
ICA (Close)



Go to next step as below.

NO

Check ICA for contamination, deterioration, or damage. Substitute with a known-good ICA and check for proper operation. If the problem is corrected, replace ICA and then go to "Verification of Vehicle Repair" procedure.

# 021-62999292

## FLA -360

## FUEL SYSTEM

### TERMINAL AND CONNECTOR INSPECTION E959D5CE

- 1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

## YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Power Supply Circuit Inspection" procedure.

#### POWER SUPPLY CIRCUIT INSPECTION ED3C5253

- 1. Ignition "ON" & Engine "OFF".
- 2. Measure voltage between terminal 2 of the valve harness connector and chassis ground.

Specification : Approx. B+

```
3. Is voltage within the specification?
```

Go to "Signal Circuit Inspection" procedure. البين سامان في الم

#### NO

YES

Check for an open or short to ground in the power supply circuit between the ICA valve and main relay. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### SIGNAL CIRCUIT INSPECTION EA56FA62

- 1. Check for open in signal harness.
  - 1) Ignition "OFF".
  - 2) Disconnect PCM connector.
  - 3) Measure resistance between terminals 1 of the valve harness connector and 80 of the PCM harness connector.

Specification : Approx. 0

4) Is resistance within the specification?



Go to next step as below.
## NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

- 2. Check for short to ground in signal harness.
  - 1) Measure resistance between terminal 1 of valve harness connector and chassis ground.

Specification : Infinite

2) Is resistance within the specification?



Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Repair open or short in harness and go to "Verification of Vehicle Repair" procedure.

#### VERIFICATION OF VEHICLE REPAIR E5E73EE7

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 3. Read "DTC Status" parameter.
- 4. Is parameter displayed "History(Not Present) fault"?

#### YES

System performing to specification at this time. Clear the DTC.

NO

Go to the applicable troubleshooting procedure.

**FUEL SYSTEM** 

# DTC P1506 IDLE CHARGE ACTUATOR SIGNAL HIGH OF COIL #1

#### COMPONENT LOCATION E81FBA2F

Refer to DTC P1505.

#### GENERAL DESCRIPTION EABBB993

Refer to DTC P1505.

#### DTC DESCRIPTION E00E9D05

PCM sets DTC P1506 if the PCM detects that the ICAV(OPEN) control circuit is short to battery.

#### DTC DETECTING CONDITION EDACAB4D

ltem	Detecting Condition	Possible Cause
DTC Strategy	Driver stage check	
Enable Conditions	10V < Battery voltage < 16V 20% < ICA duty < 80%	Open or short to ground in harness Contact resistance in
Threshold Value	Open or short to ground	connectors Faulty ICA valve
Diagnostic Time	1 sec.	Faulty ICA valve
توليت محدود)	شرخت ذيجيتال حوذرو ساماته (مس	

#### SPECIFICATION EAB4DAC0

# اولین سامانه دیجیتال تعمیرکاران خودر و در ایران

#### ICA COIL #1 (OPEN)

Temp.( )	Temp.( )	ICA Coil #1 (OPEN)( )	Temp.( )	Temp.( )	ICA Coil #1 (OPEN)( )
-20	-4	9.2 ~ 10.8	40	104	12.0 ~ 13.6
-10	14	9.7 ~ 11.3	50	122	12.4 ~ 14.0
0	32	10.2 ~ 11.8	60	140	12.9 ~ 14.5
10	50	10.6 ~ 12.2	70	158	13.4 ~ 15.0
20	68	11.1 ~ 12.7	80	176	13.8 ~ 15.4
30	86	11.5 ~ 13.1	100	212	14.7 ~ 16.3

#### ICA COIL #2 (CLOSE)

Temp.( )	Temp.( )	ICA Coil #2 (CLOSE)( )	Temp.( )	Temp.( )	ICA Coil #2 (CLOSE)( )
-20	-4	12.1 ~ 13.7	40	104	15.7 ~ 17.3
-10	14	12.8 ~ 14.4	50	122	16.3 ~ 17.9
0	32	13.4 ~ 15.0	60	140	16.9 ~ 18.5
10	50	14.0 ~ 15.6	70	158	17.4 ~ 19.0
20	68	14.5 ~ 16.1	80	176	18.0 ~ 19.6
30	86	15.1 ~ 16.7	100	212	19.2 ~ 20.8

# WWW.DIGITALKHODRO.COM

# DTC TROUBLESHOOTING PROCEDURES

## SCHEMATIC DIAGRAM EB9C6FDE

Refer to DTC P1505.

## SIGNAL WAVEFORM E969CD63

Refer to DTC P1505.

# MONITOR DTC STATUS EC928C62

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter.

	1.4 AMBIENT CONDITIONS
To naviate to the "DTAL"menu	
01 HYUNDAI VEHICLE DIAGNOSIS	
Select model and year	1. MIL STATUS
02 ENGINE	2. DTC STATUS: PRESENT
Select engine	3. DTC READINESS FLAG : COMPLETE
DI DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC
مانه دیجیتال تعمیرکارا <u>ن</u> خودرو در	6. OP.HOUR AFTER ERASURE OF DTC
PART ERAS DTAL HELP	
1	

B00112

5. Is parameter displayed "History(Not Present) fault"?

## 🔟 ΝΟΤΕ

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

# YES

Fault is intermittent caused by poor contact in the sensor's and/or the PCM's connector, which was repaired but PCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

#### NO

Go to "Component Inspection" procedure.

#### COMPONENT INSPECTION EFABCA77

1. Ignition "OFF".

# 021-62999292

## FLA -364

FUEL SYSTEM

2. Disconnect ICA valve connector.

3. Measure resistance between terminals 1 and 2 of the valve connector(Component side).

#### SPECIFICATION

Temp.( )	Temp.( )	ICA Coil #1 (OPEN)( )	Temp.( )	Temp.( )	ICA Coil #1 (OPEN)( )
-20	-4	9.2 ~ 10.8	40	104	12.0 ~ 13.6
-10	14	9.7 ~ 11.3	50	122	12.4 ~ 14.0
0	32	10.2 ~ 11.8	60	140	12.9 ~ 14.5
10	50	10.6 ~ 12.2	70	158	13.4 ~ 15.0
20	68	11.1 ~ 12.7	80	176	13.8 ~ 15.4
30	86	11.5 ~ 13.1	100	212	14.7 ~ 16.3



Go to next step as below.

#### NO

Check ICA for contamination, deterioration, or damage. Substitute with a known-good ICA and check for proper operation. If the problem is corrected, replace ICA and then go to "Verification of Vehicle Repair" procedure.

# TERMINAL AND CONNECTOR INSPECTION E4AAA88E

- 1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

# WWW.DIGITALKHODRO.COM

# NO

Go to "Power Supply Circuit Inspection" procedure.

## POWER SUPPLY CIRCUIT INSPECTION EE4EBDFA

- 1. Ignition "ON" & Engine "OFF".
- 2. Measure voltage between terminal 2 of the valve harness connector and chassis ground.

Specification : Approx. B+

3. Is voltage within the specification?

#### YES

Go to "Signal Circuit Inspection" procedure.

#### NO

Check for an open or short to ground in the power supply circuit between the ICA valve and main relay. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### SIGNAL CIRCUIT INSPECTION E5A7B3F3

- 1. Ignition "OFF".
- 2. Disconnect PCM connector.
- ولین سامانه دیجیتال تعمیر کاران خود."Jgnition "ON، خود
- 4. Measure voltage between terminal 1 of valve harness connector and chassis ground.

Specification : Approx. 0

5. Is voltage within the specification?

## YES

Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### NO

Repair short in harness and go to "Verification of Vehicle Repair" procedure.

#### VERIFICATION OF VEHICLE REPAIR E01FE00E

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 3. Read "DTC Status" parameter.

# WWW.DIGITALKHODRO.COM

## 021-62999292

FLA -365

# 021-62999292

# FLA -366

4. Is parameter displayed "History(Not Present) fault"?

# YES

System performing to specification at this time. Clear the DTC.

## NO

Go to the applicable troubleshooting procedure.







# FUEL SYSTEM

FLA -367

# DTC P1507 IDLE CHARGE ACTUATOR SIGNAL LOW OF COIL #2

## COMPONENT LOCATION E887A24F

Refer to DTC P1505.

## GENERAL DESCRIPTION EAB3BOCB

Refer to DTC P1505.

## DTC DESCRIPTION E5D758DA

PCM sets DTC P1507 if the PCM detects that the ICAV(CLOSE) control line is open or short to ground.

## DTC DETECTING CONDITION E06E05DD

Item	Detecting Condition	Possible Cause	
DTC Strategy	Driver stage check		
Enable Conditions	10V < Battery voltage < 16 20% < ICA duty < 80%	Open or short to ground in harness. Contact resistance in	
Threshold Value	Open or short to ground	connectors. Faulty ICA valve.	
Diagnostic Time	1 sec.	Faulty ICA Valve.	
بتوليت محدود	سردت دیجیتال جودرو سامانه (میں		

# SPECIFICATION EEDD7BE6

# اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

# ICA COIL #1 (OPEN)

Temp.( )	Temp.( )	ICA Coil #1 (OPEN)( )	Temp.( )	Temp.( )	ICA Coil #1 (OPEN)( )
-20	-4	9.2 ~ 10.8	40	104	12.0 ~ 13.6
-10	14	9.7 ~ 11.3	50	122	12.4 ~ 14.0
0	32	10.2 ~ 11.8	60	140	12.9 ~ 14.5
10	50	10.6 ~ 12.2	70	158	13.4 ~ 15.0
20	68	11.1 ~ 12.7	80	176	13.8 ~ 15.4
30	86	11.5 ~ 13.1	100	212	14.7 ~ 16.3

#### ICA COIL #2 (CLOSE)

Temp.( )	Temp.( )	ICA Coil #2 (CLOSE)( )	Temp.( )	Temp.( )	ICA Coil #2 (CLOSE)( )
-20	-4	12.1 ~ 13.7	40	104	15.7 ~ 17.3
-10	14	12.8 ~ 14.4	50	122	16.3 ~ 17.9
0	32	13.4 ~ 15.0	60	140	16.9 ~ 18.5
10	50	14.0 ~ 15.6	70	158	17.4 ~ 19.0
20	68	14.5 ~ 16.1	80	176	18.0 ~ 19.6
30	86	15.1 ~ 16.7	100	212	19.2 ~ 20.8

# WWW.DIGITALKHODRO.COM

**FUEL SYSTEM** 

SCHEMATIC DIAGRAM E339DA7B

Refer to DTC P1505.

SIGNAL WAVEFORM EE629E8A

Refer to DTC P1505.

#### MONITOR DTC STATUS EBECCDF6

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter

To naviate to the "DTAL"menu	1.4 AMBIENT CONDITIONS
01 HYUNDAI VEHICLE DIAGNOSIS Select model and year	1. MIL STATUS
→ 02 ENGINE	2. DTC STATUS: PRESENT
Select engine	3. DTC READINESS FLAG : COMPLETE
<b>01</b> DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC
الله ويجيبان طسير عران حودرو در ايران	6. OP.HOUR AFTER ERASURE OF DTC
PART ERAS DTAL HELP	

B00112

5. Is parameter displayed "History(Not Present) fault"?

## 🔟 ΝΟΤΕ

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

#### YES

Fault is intermittent caused by poor contact in the sensor's and/or PCM's connector or was repaired and PCM memory was not cleared. Thoroughly check connectors for loose or poor connections, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Go to "Component Inspection" procedure.

#### COMPONENT INSPECTION ECC3CB8C

1. Ignition "OFF".

FLA -369

- 2. Disconnect ICA valve connector.
- 3. Measure resistance between terminals 2 and 3 of the valve connector(Component side)

## SPECIFICATION

Temp.( )	Temp.( )	ICA Coil #2 (CLOSE)( )	Temp.( )	Temp.( )	ICA Coil #2 (CLOSE)(   )
-20	-4	12.1 ~ 13.7	40	104	15.7 ~ 17.3
-10	14	12.8 ~ 14.4	50	122	16.3 ~ 17.9
0	32	13.4 ~ 15.0	60	140	16.9 ~ 18.5
10	50	14.0 ~ 15.6	70	158	17.4 ~ 19.0
20	68	14.5 ~ 16.1	80	176	18.0 ~ 19.6
30	86	15.1 ~ 16.7	100	212	19.2 ~ 20.8



Go to next step as below.

#### NO

Check ICA for contamination, deterioration, or damage. Substitute with a known-good ICA and check for proper operation. If the problem is corrected, replace ICA and then go to "Verification of Vehicle Repair" procedure.

# TERMINAL AND CONNECTOR INSPECTION E2BE2AF9

- 1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?



Repair as necessary and go to "Verification of Vehicle Repair" procedure.

**FUEL SYSTEM** 

#### FLA -370

# NO

Go to "Power Supply Circuit Inspection" procedure.

#### POWER SUPPLY CIRCUIT INSPECTION E6CA67A8

- 1. Ignition "ON" & Engine "OFF".
- 2. Measure voltage between terminal 2 of the valve harness connector and chassis ground.

Specification : Approx. B+

3. Is voltage within the specification?

#### YES

Go to "Signal Circuit Inspection" procedure.

#### NO

Check for an open or short to ground in the power supply circuit between the ICA valve and main relay. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

## SIGNAL CIRCUIT INSPECTION E1511513

- 1. Check for open in signal harness.
  - 1) Ignition "OFF".
  - 2) Disconnect PCM connector.
  - 3) Measure resistance between terminals 3 of the valve harness connector and 78 of the PCM harness connector.

Specification : Approx. 0

4) Is resistance within the specification?



Go to next step as below.

NO

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

- 2. Check for short to ground in signal harness.
  - 1) Measure resistance between terminal 3 of valve harness connector and chassis ground.

#### Specification : Infinite

2) Is resistance within the specification?

# DTC TROUBLESHOOTING PROCEDURES

# YES

Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

Repair open or short in harness and go to "Verification of Vehicle Repair" procedure.

#### VERIFICATION OF VEHICLE REPAIR EOB99DF0

After a repair, it is essential to verify that the fault has been corrected.

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode
- 2. Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 3. Read "DTC Status" parameter
- 4. Is parameter displayed "History(Not Present) fault"?

System performing to specification at this time. Clear the DTC

NO

YES

Go to the applicable troubleshooting procedure.

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران



**FUEL SYSTEM** 

# DTC P1508 IDLE CHARGE ACTUATOR SIGNAL HIGH OF COIL #2

# COMPONENT LOCATION E5194E96

Refer to DTC P1505.

# GENERAL DESCRIPTION EB16A50E

Refer to DTC P1505.

# DTC DESCRIPTION EDD3B3A9

PCM sets DTC P1508 if the PCM detects that the ICAV(CLOSE) control circuit is short to battery.

# DTC DETECTING CONDITION EFF6D0A8

Item	Detecting Condition	Possible Cause
DTC Strategy	Driver stage check	
Enable Conditions	10< Battery voltage <16V 20%< ICA duty <80%	Short to battery in harness Contact resistance in
Threshold Value	Short to battery	connectors
Diagnostic Time	1 sec.	Faulty ICA valve
Fail-Safe	PCM controls idle speed with predetermined value	
	الماريد بيرامانه ديجي التجميع كالرابيخ	0-

#### SPECIFICATION EC9EABAC

#### ICA COIL #1 (OPEN)

Temp.( )	Temp.( )	ICA Coil #1 (OPEN)( )	Temp.( )	Temp.( )	ICA Coil #1 (OPEN)( )
-20	-4	9.2 ~ 10.8	40	104	12.0 ~ 13.6
-10	14	9.7 ~ 11.3	50	122	12.4 ~ 14.0
0	32	10.2 ~ 11.8	60	140	12.9 ~ 14.5
10	50	10.6 ~ 12.2	70	158	13.4 ~ 15.0
20	68	11.1 ~ 12.7	80	176	13.8 ~ 15.4
30	86	11.5 ~ 13.1	100	212	14.7 ~ 16.3

#### ICA COIL #2 (CLOSE)

Temp.( )	Temp.( )	ICA Coil #2 (CLOSE)( )	Temp.( )	Temp.( )	ICA Coil #2 (CLOSE)( )
-20	-4	12.1 ~ 13.7	40	104	15.7 ~ 17.3
-10	14	12.8 ~ 14.4	50	122	16.3 ~ 17.9
0	32	13.4 ~ 15.0	60	140	16.9 ~ 18.5
10	50	14.0 ~ 15.6	70	158	17.4 ~ 19.0

# WWW.DIGITALKHODRO.COM

FLA -373

20	68	14.5 ~ 16.1	80	176	18.0 ~ 19.6
30	86	15.1 ~ 16.7	100	212	19.2 ~ 20.8

## SCHEMATIC DIAGRAM EA9CEDBC

Refer to DTC P1505.

SIGNAL WAVEFORM E7686B3A

Refer to DTC P1505.

## MONITOR DTC STATUS E192FA3F

- 1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
- 2. Press F4(DTAL) to select DTC information from the DTCs menu.
- 3. Confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 4. Read "DTC Status" parameter

To naviate to the "DTAL"menu	1.4 AMBIENT CONDITIONS
01 HYUNDAI VEHICLE DIAGNOSIS	مرکت دیا
Select model and year	1. MIL STATUS
انه دیجیتال تعمیر کار ENGINE 20€	2. DTC STATUS: PRESENT
Select engine	3. DTC READINESS FLAG : COMPLETE
<b>01</b> DIAGNOSTIC TROUBLE CODES	4. STATISTIC COUNTER : 1
Select F4(DTAL)on the function bar	5. OP.HOUR AFTER DETECTION OF DTC
	6. OP.HOUR AFTER ERASURE OF DTC
PART ERAS DTAL HELP	

B00112

5. Is parameter displayed "History(Not Present) fault"?

#### 🔟 ΝΟΤΕ

- History (Not Present) fault : DTC occurred but has been cleared.
- Present fault : DTC is occurring at present time.

## YES

Fault is intermittent caused by poor contact in the sensor(s) and/or the PCM's connector was repaired and PCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

#### NO

Go to "Component Inspection" procedure.

# WWW.DIGITALKHODRO.COM

# FUEL SYSTEM

COMPONENT INSPECTION EDABDECC

- 1. Ignition "OFF".
- 2. Disconnect ICA valve connector.
- 3. Measure resistance between terminals 2 and 3 of the valve connector(Component side)

#### SPECIFICATION

Temp.( )	Temp.( )	ICA Coil #2 (CLOSE)( )	Temp.( )	Temp.( )	ICA Coil #2 (CLOSE)( )
-20	-4	12.1 ~ 13.7	40	104	15.7 ~ 17.3
-10	14	12.8 ~ 14.4	50	122	16.3 ~ 17.9
0	32	13.4 ~ 15.0	60	140	16.9 ~ 18.5
10	50	14.0 ~ 15.6	70	158	17.4 ~ 19.0
20	68	14.5 ~ 16.1	80	176	18.0 ~ 19.6
30	86	15.1 ~ 16.7	100	212	19.2 ~ 20.8



4. Is resistance within the specification?



Go to next step as below.



Check ICA for contamination, deterioration, or damage. Substitute with a known-good ICA and check for proper operation. If the problem is corrected, replace ICA and then go to "Verification of Vehicle Repair" procedure.

# TERMINAL AND CONNECTOR INSPECTION E2AFB5D4

- 1. Many malfunctions in the electrical system are caused by poor harness(es) and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
- 2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
- 3. Has a problem been found?

# FLA -375

# YES

Repair as necessary and go to "Verification of Vehicle Repair" procedure.

## NO

Go to "Power Supply Circuit Inspection" procedure.

#### POWER SUPPLY CIRCUIT INSPECTION ED4DCBDE

- 1. Ignition "ON" & Engine "OFF".
- 2. Measure voltage between terminal 2 of the valve harness connector and chassis ground.

Specification : Approx. B+

3. Is voltage within the specification?

#### YES

NO

Go to "Signal Circuit Inspection" procedure.

Check for an open or short to ground in the power supply circuit between the ICA valve and main relay. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### SIGNAL CIRCUIT INSPECTION E9EA60DE

- 1. Ignition "OFF".
- 2. Disconnect PCM connector.
- 3. Ignition "ON".
- 4. Measure voltage between terminal 3 of valve harness connector and chassis ground.

Specification : Approx. 0V

5. Is voltage within the specification?

# YES

Check for poor connection between PCM and component: backed out terminal, improper mating, broken locks or poor terminal to wire connection. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

#### NO

Repair short in harness and go to "Verification of Vehicle Repair" procedure.

#### VERIFICATION OF VEHICLE REPAIR E480BE61

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode

# 021-62999292

#### FLA -376

**FUEL SYSTEM** 

- 2. Press F4(DTAL) and confirm that "DTC Readiness Flag" indicates "Complete". If not, drive the vehicle within conditions noted in the freeze frame data or enable conditions.
- 3. Read "DTC Status" parameter
- 4. Is parameter displayed "History(Not Present) fault"?



System performing to specification at this time. Clear the DTC



Go to the applicable troubleshooting procedure.





FUEL DELIVERY SYSTEM

FLA -377

# FUEL DELIVERY SYSTEM

# COMPONENTS E330E7C9



FUEL SYSTEM

# FUEL LINE AND VAPOR LINE

## FUEL PRESSURE TEST EB2AEC1E



EGQE602M

# WWW.DIGITALKHODRO.COM

# FUEL DELIVERY SYSTEM

#### 4. INSPECT FUEL LEAKAGE ON CONNECTION

- 1. Connect the battery negative (-) terminal.
- 2. Apply battery voltage to the fuel pump terminal and activate the fuel pump. With fuel pressure applied, check that there is no fuel leakage from the fuel pressure gauge or connection part.

#### 5. FUEL PRESURE TEST

- 1. Diconnect the negative (-) terminal from the battery.
- 2. Connect the fuel pump connector.
- 3. Connect the battery negative (-) terminal.
- 4. Start the engine and measure the fuel pressure at idle.

Standard Value: 350 kpa (3.5 kg/cm², 49.8 psi)

If the measured fuel pressure differs from the standard value, perform the necessary repairs using the table below.

6. Stop the engine and check for a change in the fuel pressure gauge reading.

After engine stops, the gage reading should hold for about 5 minutes

• Observing the declination of the fuel pressure when the gage reading drops and perform the necessary repairs using the table below.

Condition	Probable Cause	Supected Area
Fuel pressure drops slowly after engine is stopped	Injector leak	Injector
Fuel pressure drops immediately after engine is stopped	The check valve within the fuel pump is open	Fuel Pump

EGQE602O

# FUEL SYSTEM

## 6. RELEASE THE INTERNAL PRESSURE

- 1. Disconnect the fuel pump connector(B).
- 2. Start the engine and wait until fuel in fuel line is exhausted.
- 3. After the engine stalls, turn the ignition switch to OFF position
- and diconnect the negative (-) terminal from the battery.

#### 

FLA -380

Be sure to reduce the fuel pressure before disconnecting the fuel feed hose, otherwise fuel will spill out.



#### 7. REMOVE THE SPECIAL SERVICE TOOL (SST) AND CONNECT THE FUEL LINE

- 1. Disconnect the Fuel Pressure Gage and Hose (09353-24100) from the Fuel Pressure Gage Connector (09353-24000).
- 2. Disconnect the Fuel Pressure Gage Connector (09353-24000) from the Fuel Pressure Gage Adapter (09353-38000).
- 3. Disconnect the fuel feed hose from the Fuel Pressure Gage Adapter (09353-38000).
- 4. Disconnect the Fuel Pressure Gage Adapter (09353-38000) from the delivery pipe.

# CAUTION

5. Cover the hose connection with a shop towel to prevent splashing of fuel caused by residual pressure in the fuel line.

#### 8. INSPECT FUEL LEAKAGE ON CONNECTION

- 1. Connect the battery negative (-) terminal.
- 2. Apply battery voltage to the fuel pump terminal and activate the fuel pump. With fuel pressure applied, check that there is no fuel leakage from the fuel pressure gauge or connection part.
- 3. If the vehicle is normal, connect the fuel pump connector.

EGQE602N

# FUEL DELIVERY SYSTEM

# **INJECTOR**

#### **INSPECTION** E730BAB2

Measure resistance between the terminal 1 and 2 of 1. the injector.



# EGQE602P

**SPECIFICATION (RESISTANCE):** 

Temperature		Resistance ( )	ن سامان
-20	-4	12.2 ~ 12.3	
0	32	13.3 ~ 13.5	
20	68	14.4 ~ 14.6	
40	104	15.5 ~ 15.7	
60	140	16.6 ~ 16.8	
80	176	17.7 ~ 17.9	
100	212	18.8 ~ 19.0	
120	248	19.9 ~ 20.1	

If the resistance is not within specification, replace the 2. injector.



# 021-62999292

**FUEL SYSTEM** 

#### FLA -382

# FUEL TANK

REMOVAL E9FA2F2F

#### CAUTION

When lifting up or down vehicle, be sure to place blocks between vehicle and lifter to prevent fuel tank from being damaged.

4. Remove clamp(3EA) for fuel filler hose(A), leveling hose(B) and ventilation(C).



KFQE004G

KFQE004H

5. Support fuel tank with jack and remove fuel tank straps(2EA).



1. Remove front muffler and main muffler assemblys.

KFQE004V

- 2. Remove profellershaft assembly(4WD only).
- 3. Remove fuel tank under cover.

#### FUEL DELIVERY SYSTEM

6. Unfastem parking brake cable mounting bolts(2EA) in each right adn left sides.



KFQE004I

- 7. Lifting down fuel tank slowly, remove fuel pump wiring connector, and then main fuel hose and return fuel hose connected to fuel tank.
- 8. Disconnect fuel sender wiring connector.
- 9. Remove fuel tank.

#### INSTALLATION E6E4ADB5

1. Installation is in reverse order of remaval.

#### DISASSEMBLY EAA843C4

- 1. Remove the suction hose between fuel pump module and sub fuel sender unit.
- 2. Unscrew fuel pump module mounting bolts and sub fuel sender unit mounting bolts.
- 3. When lifting up fuel pump module and sub fuel sender, be careful not to do damage to the sender.

#### REASSEMBLY ED1F9A4F

1. Assembly is in reverse order of disassembly.



# FLA -383

# 021-62999292

**FUEL SYSTEM** 

# FLA -384

# FUEL PUMP (FP)

# DISASSEMBLY EA15685A

- 1. Trun ignition key off and disconnect battery(-) cable.
- 2. Remove the second seat.
- 3. Remove the capet covering service cover for fuel pump and service cover(A).

# یتال تعمیرکاران خودرو در ایرا

- 4. Disconnect the fuel pump wiring connector(B).
- 5. Spread out service towel around fuel hoses(C) and disconnect fuel hoses(C).
- 6. Unscrew fuel pump plate mounting bolts(D).



KFQE004D

KFQE004D

# Remove the fuel pump module.

7.



EGQE603K



# WWW.DIGITALKHODRO.COM