


آنتن برقی



آنتن برقی (FR) J3-01

*	*	L/R
*	B	P

سمبل سیم کشی : (P) (E) (EM) (INJ) (1) (R) (DR) (FR) (IN)

