


# POWER OUTSIDE MIRRORS

EE2FEAE9

## Power Outside Mirrors (1)

SD876-1









## Power Outside Mirrors (2)

The diagram illustrates the electrical connections for the Driver Door Module (SD876-1). Key components and connections include:

- Power Distribution:** Connections from the Memory Fuse (7.5A, SD876-1) and Ignition (IGN2) to the BEC-IF and various sensors.
- Driver Door Module (SD876-1):** The central component with multiple pins (1-25) for various functions.
- Passenger Power Outside Mirror & Mirror Folding Motor (PHOTO 98):** Connected to pins 1, 2, 3, 4, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25.
- Position Sensor (With IMS):** Connected to pins 1, 2, 3, 4, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25.
- Mirror Motor:** Connected to pins 1, 2, 3, 4, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25.
- Various Sensors and Motors:** Including the Mirror Sensor VCC, Mirror Sensor H, Mirror Sensor W, and the Mirror Sensor B.

POWER OUTSIDE MIRRORS

| SD876-3                                                                                                                                    |                                                                                                                                            |                                                                                                                                         |                                                                                                                                        |  |
|--------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------|--|
| Power Outside Mirrors (3)                                                                                                                  |                                                                                                                                            |                                                                                                                                         |                                                                                                                                        |  |
| <div>D03-B</div> <div></div> <div>KET_050_23F_W</div>   | <div>D03-C</div> <div></div> <div>KET_090II_10F_W</div> | <div>D05</div> <div></div> <div>AMP_040III_16M_W</div> | <div>D23-A</div> <div></div> <div>KET_050_23F_W</div> |  |
| <div>D23-B</div> <div></div> <div>KET_090II_10F_W</div> | <div>D25</div> <div></div> <div>AMP_040III_16M_W</div>  | <div>BLANK</div>                                                                                                                        |                                                                                                                                        |  |

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

POWER OUTSIDE MIRRORS

Power Outside Mirrors (4)

SD876-4

MEMO

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

