


C-1a




پشت آمپر



1M	1K	1I	1B	1E	1C	1A
B/W	L/R	B	V/B	B/L	B/R	B
B/W	L/R	L	L/O	L/R	B/Y	B
1H	1P	1N	1L	1J	1H	1F
2M	2K	2I	2B	2E	2C	2A
3M	3K	3I	3B	3E	3C	3A
4M	4K	4I	4B	4E	4C	4A
5M	5K	5I	5B	5E	5C	5A
6M	6K	6I	6B	6E	6C	6A
7M	7K	7I	7B	7E	7C	7A
8M	8K	8I	8B	8E	8C	8A
9M	9K	9I	9B	9E	9C	9A
10M	10K	10I	10B	10E	10C	10A


C-1a

سیمبل سیستم کشی : (F) (F) (E) (D) (D) (F)






پشت آمپر

C-1b




C-1b



سمبل سیم کشی : (F) (F) (E) (D) (D) (F)



一三



C-1c



سندیل سیم کشی : (F) (E) (D) (C) (B) (A)