



6.2 Circuit diagrams


Body Control Module (BCM) circuit diagrams (page 1)




Body Control Module (BCM) circuit diagrams (page 2)



Body Control Module (BCM) circuit diagrams (page 3)





Body Control Module (BCM) circuit diagrams (page 4)




Body Control Module (BCM) circuit diagrams (page 5)

*1: For A13AFL model
*2: For A13FL model






Body Control Module (BCM) circuit diagrams (page 6)



QREM070460

Body Control Module (BCM) circuit diagrams (page 7)


*1: For A13AFL model
 *2: For A13FL model



QREM070470

Body Control Module (BCM) circuit diagrams (page 8)


*1: For A13AFL model
*2: For A13FL model



دیجیتال خودرو


شرکت دیجیتال خودرو سانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران






QREM070480

Body Control Module (BCM) circuit diagrams (page 9)




Body Control Module (BCM) circuit diagrams (page 10)

*1: For A13AFL model
*2: For A13FL model




QREM070500

Body Control Module (BCM) circuit diagrams (page 11)




اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Body Control Module (BCM) circuit diagrams (page 12)





Body Control Module (BCM) circuit diagrams (page 13)



Body Control Module (BCM) circuit diagrams (page 14)

*1: For A13AFL model
*2: For A13FL model



QREM070540

Body Control Module (BCM) circuit diagrams (page 15)

