


Instrument Cluster

Circuit Diagram (Page 1 of 3)



09

ET11092101

Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-009	08-9	I-041	08-9	I-044	08-9
E-053	08-3	E-071	08-3	I-011	08-9

Fuse and Relay

Fuse/Relay	See Page	Fuse and Relay Box
RF08	06-15	Instrument Panel Fuse and Relay Box
RF12	06-15	Instrument Panel Fuse and Relay Box


Location of Junction Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-012, E-059	08-9, 08-3				

Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-009	12-7	I-041	12-7	I-044	12-7
E-053	12-2	E-071	12-2	I-011	12-7
I-012, E-059	12-7, 12-2				

Circuit Diagram (Page 2 of 3)



ET11092102

Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-041	08-9	I-080	08-9	E-028	08-3
E-023	08-3	I-019	08-9	B-028	08-13
I-016	08-9	I-011	08-9	I-071	08-9

Location of Junction Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-028, E-065	08-9, 08-3	I-047, B-011	08-9, 08-13		


Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-041	12-7	I-080	12-7	E-028	12-2
E-023	12-2	I-019	12-7	B-028	12-10
I-016	12-7	I-011	12-7	I-071	12-7
I-028, E-065	12-7, 12-2	I-047, B-011	12-7, 12-10		

شرکت دیجیتال خودرو (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Circuit Diagram (Page 3 of 3)



ET11092103