



Data Link Details (1)

SD200-1



Data Link Details (2)

From Data Link Connector
(SD200-1)

Data Link Details (3)

ECU JUNCTION BOX
[PHOTO 15]

ECU-1 10A

See Power Distribution (SD110-3)

E/R-FRTB
31 0.5L

E/R-CLG
21 0.3B
13 0.3Y

ECM
13

E/R-FRTB
5 0.5Br
13 0.5W

E/R-CLG
21 0.3B
13 0.3Y

From Data Link Connector (SD200-1)

Legend:

Pin	Function
1	Ground
2	CAN-HIGH
3	CAN-LOW
4	Memory power
5	K-Line
6	0.5Br
7	0.5W
8	0.3B
9	0.3Y
10	0.5L
11	0.5Br
12	0.5W
13	0.3B
14	0.3Y
15	0.5L
16	0.5Br
17	0.5W
18	0.3B
19	0.3Y
20	0.5L

ECU JUNCTION BOX
[PHOTO 15]

ECU-1 10A

See Power Distribution (SD110-3)

E/R-FRTB
31 0.5L

E/R-CLG
21 0.3B
13 0.3Y

ECM
13

E/R-FRTB
5 0.5Br
13 0.5W

E/R-CLG
21 0.3B
13 0.3Y


From Data Link Connector (SD200-1)

Legend:















Pin	Function
1	Ground
2	CAN-HIGH
3	CAN-LOW
4	Memory power
5	K-Line
6	0.5Br
7	0.5W
8	0.3B
9	0.3Y
10	0.5L
11	0.5Br
12	0.5W
13	0.3B
14	0.3Y
15	0.5L
16	0.5Br
17	0.5W
18	0.3B
19	0.3Y
20	0.5L

Data Link Details (4)

Data Link Details (4)



DATA LINK DETAILS

Data Link Details (5)			SD200-5
A05-A 	C11-2 	CSD-K 	AMP_ABG_24F_L_ECU KOSTAL_09447403 AMP_ECU_94F_B
CLG-A 	CLG09 	CSD09 	YAZ_TCMWP_16F_B YAZ_TCMWP_16F_B E01 
E02 	E05 	F01 	PKD_ECU_80F_GR_3 FCI_ABS_26F_B YAZ_025_16F_W
F06-B 	F08 	F19-B 	KET_DIAGNOSIS_20F_B_A AMP_MQS_26F_B AMP_0407_MII_26F_GY
F53-A 	AMP_0407_26F_W_HD		

DATA LINK DETAILS

SD200-6					
Data Link Details (6)					
F89 AMP_0407_26F_W_HD	M01-B AMP_040M2_16F_B	M04-C AMP_0407_16F_W_040	M05-A AMP_0407_26F_W_HD		
M05-B AMP_0407_22F_W_HD	M07-A KET_0409_24F_W	M07-B AMP_025_32F_W	M10 MLX_OBDII_16F_B_SIN		
M18 KET_0409_24F_W	M24-A AMP_DLI_16F_B	M30 AMP_MQS_08F_W	M67 AMP_040M1_16F_B		
M80-C1 AMP_AUDIO_06F_Y_C1	BLANK		BLANK		BLANK