Circuit diagram

Supplemental inflatable restraint system (SRS)



2. 0. 16. 1

□: switch and electrical device

No.	Description	Position
M1	To assistant's safety belt	Main harness
M6	To SRS controller	Main harness
M11	To driver's safety belt	Main harness
M21	To combined instrument	Main harness
M25	To assistant's SRS	Main harness
M36	To ETACS	Main harness
M46	To dock spring	Main harness



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران