


CAN System

Circuit Diagram (Page 1 of 2)



09

Parts Location

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-009	08-9	I-014	08-9	I-011	08-9
I-002	08-9	I-036	08-9	K-009	08-24
I-041	08-9	I-025	08-9		

Fuse and Relay

Fuse/Relay	See Page	Fuse and Relay Box
RF08	06-15	Instrument Panel Fuse and Relay Box

Location of Junction Connector



Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-026, K-006	08-9, 08-24				

Form of Connector

Connector Code	See Page	Connector Code	See Page	Connector Code	See Page
I-009	12-7	I-014	12-7	I-011	12-7
I-002	12-7	I-036	12-7	K-009	12-16
I-041	12-7	I-025	12-7	I-026, K-006	12-7, 12-16

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Circuit Diagram (Page 2 of 2)



09

ET11093002