


Instrument Panel Fuse and Relay Box



No.	Description	No.	Description	No.	Description
RF01	-	RF09	A/C/Power Outside Rear View Mirror/ Blower Relay	RF17	-
RF02	ABS/ESP/SAS	RF10	-	RF18	Rear Window Defroster Indicator
RF03	Instrument Cluster	RF11	A/C/Audio/Headlight Leveling Switch	RF19	-
RF04	Airbag	RF12	ECM/TCU/PEPS	RF20	Diagnostic Interface/ Key Switch
RF05	BCM	RF13	-	RF21	Instrument Cluster
RF06	-	RF14	-	RF22	Audio System
RF07	Audio System/BCM	RF15	Rear Window Defroster		
RF08	Cigarette Lighter	RF16	Rear Window Defroster Relay		