


4892-00 ABS/ESP



1) CONNECTOR

Connector Number (Pin Number/Color)	Connecting Wiring Harness	Connector Position	Remark
C203	18 White	W/H IP (Main) - IP Fuse & Relay BOX	Back Side of IP Fuse & Relay Box
C208	18 White	W/H Eng Room - IP Fuse & Relay BOX	Front Side of IP Fuse & Relay Box
C211	41 White	W/H Eng Room - W/H IP(Main)	Inside of Driver Cowl Side
C218	22 White	W/H Eng Room - W/H IP (Main)	Inside of Front Passenger Cowl Side
C219	18 White	W/H Eng Room - W/H Floor	Inside of Front Passenger Cowl Side

2) GROUND

Connector Number	Connecting Wiring Harness	Connecting Position	Remark
G102	W/H Eng Room	Above External Buzzer (back)	LH headlamp/side repeater, stop lamp switch, wiper motor
G106	W/H Eng Room	Frame above ABS	ABS

3) SPLICE PACK

4) CONNECTOR IDENTIFICATION SYMBOL & PIN NUMBER POSITION

