


Indicators & Gauges (1)

SD940-1



Indicators & Gauges (2)

SD940-2




INDICATORS & GAUGES

Indicators & Gauges (3)

SD940-3

SUPERVISION
TYPE




Indicators & Gauges (4)

[illegible]

INDICATORS & GAUGES

Indicators & Gauges (5)

SD940-5



Indicators & Gauges (6)

MLX 040II 20F Gr

10	9	★	7	6	5	4	3	2	1
★	19	★	17	16	★	★	13	12	11

KET 090II 02F W SPRK