





Sensor1(1.5TGDI)




A1 ENGINE ECU_E




C22 ECU_1.5T_GDI_C

A16 Intake pressure
temperature sensor






A23 Electronic throttle




E10 Accelerator pedal position sensor




M07 Clock spring _ horn

I1_EM Engine wiring harness
connecting the main line 1I1_ME Main beam connection
wire of 1 engineI3_EC Engine harness connection
control harnessI3_CE Control harness connection
engine harnessA32 High removal negative
pressure sensor


Sensor2(1.5TGDI)




A1 ENGINE ECU_E




C22 ECU_1.5T_GDI_C




A4 RCV valve




A5 Booster pressure sensor




A7 Intake camshaft position sensor




A8 High pressure oil pump




A9 Exhaust camshaft position sensor




A10 Carbon tank solenoid valve




A19 Exhaust OCV valve




A20 Intake OCV valve




A21 Crankshaft sensor




E34 Afteroxygen sensor




Sensor3(1.5TGDI)




A1 ENGINE ECU_E




A6 Control harness to nozzle harness




A24 Nozzle harness connection control harness




A25 Water temperature sensor




A26 Knock sensor




A27 Oil nozzle 4




A28 Oil nozzle 3




A29 Oil nozzle 2




A30 Oil nozzle 1




A31 Rail pressure sensor




Sensor4(1.5TGDI)




A1 ENGINE ECU_E




C22 ECU_1.5T_GDI_C




A11 Booster exhaust bypass valve




A18 Preoxygen sensor




I3_CE Control harness connection engine harness




I3_EC Engine harness connection control harness




C07 Electronic water pump



I2_BE Power harness connection engine harness



I2_EB Engine harness connection power harness




شرکت دیجیتال خودرو سامانه (مسئولیت محدود)


اولین شرکت جهتال تعمیرکاران خودرو ایران

۰۲۱ ۶۲ ۹۹ ۹۲ ۹۲


Sensor5(1.5TGDI)




A1 ENGINE ECU_E




C22 ECU_1.5T GDI_C



E27 GPF temperature sensor



E28 GPF pressure sensor



دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

