


Front lamp 1



Harness connector	Name	Page
M01	Lamp position adjust switch harness connector	25
M02	Body control panel C1 harness connector	25
M03	Body control panel C2 harness connector	26
M45	Main harness to engine harness 1	25
E11	Engine harness to main harness 1	16
E23	Engine harness to main harness 4	16
E26	Ground	61
E08	Ground	61


# دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Front lamp 2



Harness connector	Name	Page
M47	Lamp position adjust switch harness connector	26
ME1	Main harness to engine harness connector 1	25
EM1	Engine harness to main harness connector 1	17
E11	Right front lamp ( low beam lamp harness connector )	16
E23	Left front lamp ( low beam lamp harness connector )	16
E08	Ground	61
E26	Ground	61
M52	Ground	63
M42	Ground	63

# دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

