


DRIVER POWER SEAT SYSTEM

E2E80B22

DRIVER POWER SEAT SYSTEM (W/O IMS) (1)

SD880-1













TABLE

	HEI ADJ. SW (FR)		SLIDE ADJ. SW		HEI ADJ. SW (RR)		REC ADJ. SW		REMARKS
	UP	DOWN	LH	RH	UP	DOWN	N	REC	
2	○	○	○	○	○	○	○	○	(+)
8	○	○	○	○	○	○	○	○	SEAT MTR
9	○	○	○	○	○	○	○	○	SEAT MTR
13	○	○	○	○	○	○	○	○	SEAT LIMIT
14	○	○	○	○	○	○	○	○	SEAT LIMIT
11	○	○	○	○	○	○	○	○	REC MTR
1	○	○	○	○	○	○	○	○	REC LIMIT
4	○	○	○	○	○	○	○	○	REC LIMIT
3	○	○	○	○	○	○	○	○	REC LIMIT
17	○	○	○	○	○	○	○	○	HEI (FR) MTR
15	○	○	○	○	○	○	○	○	HEI (FR) MTR
18	○	○	○	○	○	○	○	○	HEI (FR) LIMIT (-)
16	○	○	○	○	○	○	○	○	HEI (FR) LIMIT (-)
6	○	○	○	○	○	○	○	○	HEI (RR) MTR
5	○	○	○	○	○	○	○	○	HEI (RR) MTR
7	○	○	○	○	○	○	○	○	HEI (RR) LIMIT (-)
12	○	○	○	○	○	○	○	○	HEI (RR) LIMIT (-)

ETGSD7880A

DRIVER POWER SEAT SYSTEM

DRIVER POWER SEAT SYSTEM (W/O IMS) (2)		SD880-2	
<p><b>S01</b></p>  <p>AMP_0900III_18F</p>	<p><b>S01R</b></p>  <p>AMP_0900III_18F</p>	<p><b>S02/S02R</b></p>  <p>KET_0900III_04F</p>	<p><b>S03/S03R</b></p>  <p>KET_250_03F</p>
<p><b>S05</b></p>  <p>KET_0900I_02M_L</p>	<p><b>S11/S11R</b></p>  <p>KET_250_03F</p>	<p><b>S16</b></p>  <p>KUM_SWP_02F</p>	<p><b>S17</b></p>  <p>KUM_SWP_02F</p>
<p><b>S18</b></p>  <p>KET_250D/L_02F</p>	<p><b>S19</b></p>  <p>KUM_SWP_02F</p>	<p>BLANK</p>	<p>BLANK</p>